



**ROHDE & SCHWARZ**

Test and Measurement  
Division

## **Operating Manual**

**Software Option:**

**1xEV-DO  
for R&S<sup>®</sup> CMU-B88**

**R&S<sup>®</sup> CMU-K88**

**1150.3900.02**

Printed in the Federal  
Republic of Germany

# Supplement to the Operating Manual for 1xEV-DO Software Option

## New Features in Versions 3.80 of Option R&S<sup>®</sup> CMU-K88 (with Base System V3.80)

### Interleaving Factor, Spectrum Results

With firmware version V3.80 of the 1xEV-DO software, a new control parameter has been introduced in the *Traffic* section of the *Generator* tab of the *Connection Control* menu.

The **Interleaving Factor** allows an increase of the rate of data packets sent to a specific user (access terminal AT 1 to 4). With the default setting 1, each of the four ATs receives one fourth of the packets. Selecting an interleaving factor 2, 3, or 4 for a particular AT doubles, triples, or quadruples the rate of data packets addressed to this AT; the residual packet rate is distributed among the other ATs. With interleaving factor 4, all packets are addressed to a single AT; which accelerates the DUT-assisted Packet Error Rate measurement.

<b>SOURce:RFGenerator:AT&lt;nr&gt;:IFACTor &lt;Factor&gt;</b>		Interleaving Factor		
<Factor>	Description of parameters	Def. value	Def. unit	FW vers.
<b>1 to 4</b>	Interleaving factor for AT <nr>	1	–	V3.80
Description of command				
This command specifies the interleaving factor for the access terminals 1 to 4 (<nr> = 1 to 4).				

In the **Spectrum** measurement a new remote control command controls the output of the `READ[:SCALar]:SPECTrum:ACP?`, `FETCH[:SCALar]:SPECTrum:ACP?`, and `SAMPLE[:SCALar]:SPECTrum:ACP?` commands.

<b>XTND:SPECTrum:ACP:STATistics[?] &lt;Enable&gt;</b>		Scope of scalar results		
Enable	Description of parameters	Def. value	Def. unit	FW vers.
<b>ON   OFF</b>	Statistical results returned No statistical results returned	OFF	–	V3.80
Description of command				
This command qualifies whether <code>READ[:SCALar]:SPECTrum:ACP?</code> , <code>FETCH...?</code> , <code>SAMPLE...?</code> return the statistical results <i>Out of Tolerance</i> and <i>Current Statistics</i> .				

Dear Customer,

throughout this manual, CMU-K88 is generally used as an abbreviation for software option R&S CMU-K88.  
The Universal Radio Communication Tester R&S CMU 200 is abbreviated as CMU200.

R&S® is a registered trademark of Rohde & Schwarz GmbH & Co. KG.  
Trade names are trademarks of the owners.

# Tabbed Divider Overview

## List of Figures and Tables

Certificate of Quality

List of R&S Representatives

Manuals for Universal Radio Communication Tester CMU

What's New in this Revision?

Abbreviations

Glossary

## Tabbed Divider

<b>1</b>	<b>Chapter 1: Installation</b>
<b>2</b>	<b>Chapter 2: Getting Started</b>
<b>3</b>	<b>Chapter 3: Manual Operation</b>
<b>4</b>	<b>Chapter 4: Functions and their Application</b>
<b>5</b>	<b>Chapter 5: Remote Control – Basics</b>
<b>6</b>	<b>Chapter 6: Remote Control – Commands</b>
<b>7</b>	<b>Chapter 7: Remote Control – Program Example</b>
<b>8</b>	<b>Chapter 8: Maintenance</b>
<b>9</b>	<b>Chapter 9: Error Codes</b>
<b>10</b>	<b>Index</b>

## List of Figures

Figure 1-1	Setup – Options menu .....	1.2
Figure 4-1	1xEV-DO applications.....	4.2
Figure 4-2	Measurement menu Analyzer / Generator .....	4.4
Figure 4-3	Display of results (Analyzer/Generator) .....	4.6
Figure 4-4	Modulation Configuration – Control.....	4.8
Figure 4-5	Modulation Configuration – Limits .....	4.10
Figure 4-6	Measurement menu Power .....	4.11
Figure 4-7	Display of results (NPower) .....	4.13
Figure 4-8	Power Configuration – Control .....	4.14
Figure 4-9	Modulation errors.....	4.16
Figure 4-10	Measurement menu Modulation .....	4.17
Figure 4-11	Modulation results display .....	4.20
Figure 4-12	Overview display.....	4.22
Figure 4-13	I/Q Analyzer displays.....	4.25
Figure 4-14	Modulation Configuration – Control.....	4.26
Figure 4-15	Modulation Configuration – Limits .....	4.27
Figure 4-16	Measurement menu Spectrum .....	4.29
Figure 4-17	Display of results (Analyzer/Generator) .....	4.31
Figure 4-18	Modulation Configuration – Control.....	4.33
Figure 4-19	Modulation Configuration – Limits .....	4.34
Figure 4-20	Code Domain Power measurement menu .....	4.35
Figure 4-21	Display of measurement results (Code Domain Power screen) .....	4.38
Figure 4-22	Display of measurement results (Code Domain Error Power screen) .....	4.40
Figure 4-23	Display of measurement results (Channel Power screen) .....	4.41
Figure 4-24	Code Domain Power Configuration – Control .....	4.42
Figure 4-25	Code Domain Power Configuration – Limits .....	4.45
Figure 4-26	Connection Control – Standard .....	4.47
Figure 4-27	Connection Control – Analyzer Settings.....	4.48
Figure 4-28	Connection Control – Generator (table) .....	4.51
Figure 4-29	Connection Control – IQ-Access Interface Setup.....	4.57
Figure 4-30	Connection Control – RF connectors .....	4.59
Figure 4-31	Connection Control – Synchronization .....	4.61
Figure 4-32	Connection Control – Trigger .....	4.63
Figure 4-33	Connection Control – I/Q-IF.....	4.65

## List of Tables

Table 1-1	CDMA networks supported.....	1.1
Table 3-1	Measurement Groups of 1xEV-DO.....	3.3
Table 4-1	Walsh codes for reverse 1xEV-DO channels .....	4.43
Table 5-1	Measurement objects in 1xEV-DO. ....	5.2
Table 5-2	Repetition mode in remote control.....	5.4
Table 5-3	Limits and limit check.....	5.5
Table 5-4	1xEV-DO bits used in the STAT:OPER:SUM1 2:CMU<nr> sub-registers .....	5.6
Table 6-1	Remote-control commands .....	6.107
Table 9-1	Error Codes .....	9.1

# Contents of Manuals for Universal Radio Communication Tester CMU

The user documentation for the R&S CMU 200/300 is divided in an operating manual for the basic instrument (including options CMU-B41, CMU-B17) and separate manuals for individual software and hardware options. The complete documentation is available on CD-ROM, stock no. PD 0757.7746.2x. The latest revisions of all manuals are also posted on the CMU Customer Web on GLORIS.

## Operating Manual CMU-K88 (Software Options for CMU-B88)

The present operating manual describes the application of CMU for 1xEV-DO mobile tests. It gives comprehensive information about the operating concept and about manual and remote control of the CMU tester. Typical measurement tasks are explained in detail using the functions offered by the graphical user interface and a selection of program examples.

The manual is organized as follows:

- Chapter 1** Describes the steps necessary for installing the software and putting the instrument into operation.
- Chapter 2** Gives an introduction to the application of CMU for 1xEV-DO mobile tests and presents some typical measurement examples.
- Chapter 3** Describes the operation in principle and the principles of measurement control.
- Chapter 4** Serves as a reference of all functions of the user interface and their application. Allowed settings, default values and the corresponding remote control commands are listed for all functions.
- Chapter 5** Describes the basics of remote control of the instrument for 1xEV-DO mobile tests.
- Chapter 6** Lists all remote control commands defined for 1xEV-DO mobile tests. At the end of the chapter the commands are grouped together according to their function and sorted by alphabetical order.
- Chapter 7** Contains program examples.
- Chapter 8** Describes preventive maintenance.
- Chapter 9** Contains a list of error codes
- Chapter 10** Contains an index for the operating manual.

## Operating Manual CMU200/CMU300

In the operating manual for CMU basic unit you will find everything that is needed to make yourself familiar with your Universal Radio Communication Tester CMU200. This includes information about the technical specifications of the CMU, the controls and connectors on the front and rear panel, necessary steps for putting the instrument into operation, the basic operating concept, manual and remote control. Typical measurement tasks are explained in detail using the functions of the user interface and program examples. In addition, the operating manual lists the most important warnings and error messages which may be output by the instrument.

General concepts of CMU control are described in the operating manual CMU200 and not repeated in the manuals for the individual software options.

## Service Manual Instrument

The service manual instrument informs on how to check compliance with rated specifications, on instrument function, repair, troubleshooting and fault elimination. It contains all information required for the maintenance of CMU by exchanging modules.

## Service Manual Modules

The service manual modules is not delivered with the instrument but may be obtained from your R&S service department using the order number 1100.4903.91.

Service manual modules contains information about the individual modules of CMU. This comprises the test and adjustment of the modules, fault detection within the modules and the interface description.

## Further Operating Manuals for Network Tests

The operating manuals listed in the following table describe the test of radio communication equipment supporting different standards by means of the CMU and the appropriate software and hardware options. The network test operating manuals are organized like the present 1xEV-DO operating manual.

Manual	Order Number	For Options		
		Type	Description	Stock No.
Operating Manual CMU-K20/-K21/ K22/-K23/-K24	1115.6088.12	CMU-K20	GSM400-MS for CMU-B21	1115.5900.02
		CMU-K21	GSM900-MS for CMU-B21	1115.6007.02
		CMU-K22	GSM1800-MS for CMU-B21	1115.6107.02
		CMU-K23	GSM1900-MS for CMU-B21	1115.6207.02
		CMU-K24	GSM850-MS for CMU-B21	1115.6307.02
		CMU-K42	GPRS software extension for GSM	1115.4691.02
		CMU-K43 CMU-K45	EGPRS software extension for GSM AMR GSM for CMU200	1115.6907.02 1150.3100.02
Operating Manual CMU-K27/-K28	1115.6688.12	CMU-K27	TDMA800-MS for CMU-B21	1115.6607.02
		CMU-K28	TDMA1900-MS for CMU-B21	1115.6707.02
Operating Manual CMU-K29	1115.6888.12	CMU-K29	AMPS-MS for CMU-B21	1115.6807.02
Operating Manual CMU-K30/-K31/ -K32/-K33/-K34	1115.4185.12	CMU-K30	GSM400-BS for CMU-B21	1115.4004.02
		CMU-K31	GSM900-BS for CMU-B21	1115.4104.02
		CMU-K32	GSM1800-BS for CMU-B21	1115.4204.02
		CMU-K33	GSM1900-BS for CMU-B21	1115.4304.02
		CMU-K34	GSM850-BS for CMU-B21	1115.4404.02
		CMU-K39 CMU-K41	MOC/MTC EDGE for CMU-K30/31/32/33	1115.4791.02 1115.4604.02
Operating Manual CMU-K53	1115.5081.12	CMU-K53	Bluetooth for CMU	1115.5000.02
Operating Manual CMU-K65/.../-K69	1115.4962.12	CMU-K65	WCDMA UE TX Test (3GPP/FDD)	1115.4891.02
		CMU-K66	WCDMA UE DL Generator (3GPP/FDD)	1115.5100.02
		CMU-K67	WCDMA UE Band III Signalling	1150.3000.02
		CMU-K68	WCDMA UE Band I Signalling	1115.5300.02
		CMU-K69	WCDMA UE Band II Signalling	1115.5400.02
Operating Manual CMU-K75/-K76	1150.3398.12	CMU-K75	WCDMA Node B TX Tests	1150.3200.02
		CMU-K76	WCDMA Generator (3GPP/FDD, Release 99, Uplink)	1150.3300.02
Operating Manual CMU-K81/-K82	1115.5581.12	CMU-K81	CDMA800-MS (IS95) for CMU-B81	1115.5500.02
		CMU-K82	CDMA1900-MS (IS95) for CMU-B81	1115.5600.02
Operating Manual CMU-K83/-K84/ -K85/-K86	1150.0382.12	CMU-K83	CDMA2000-MS (450 MHz band)	1150.3500.02
		CMU-K84	CDMA2000-MS (cellular band)	1150.3600.02
		CMU-K85	CDMA2000-MS (PCS band)	1150.3700.02
		CMU-K86	CDMA2000-MS (IMT-2000 band)	1150.3800.02

The GSM base station tests described in operating manual CMU-K30/-K31/-K32/-K33/-K34 and the WCDMA Node B tests described in operating manual CMU-K75/-K76 require a CMU300 (Universal Radio Communication Tester for BTS). Bluetooth tests can be performed with model CMU200, var. 02 or 53. All other radio communication equipment is tested with model CMU200, var.02.

## Frequently Used Abbreviations

3GPP2	3 <sup>rd</sup> Generation Partnership Project 2
Abs.	Absolute
Avg.	Average
AWGN	Additive White Gaussian Noise
CDMA	Code Division Multiple Access
CDP	Code Domain Power
Chan.	Channel
Channel.	Channelization
CRC	Cyclic Redundancy Code
Curr.	Current
Disp.	Display
DRC	Data Rate Control
DRCLock	Data Rate Control Lock
EIRP	Effective Isotropic Radiated Power
Err.	Error
ESN	Electronic Serial Number
EVM	Error Vector Magnitude
Ext., Extern.	External
FFT	Fast Fourier Transform
Freq.	Frequency
GPiB	General Purpose Interface Bus = IEEE488 Bus
HPSK	Hybrid Phase Shift Keying
I	In-phase
IF	Intermediate Frequency
Int.	Internal
Lev.	Level
MAC	Media Access Control
Magn.	Magnitude
Max.	Maximum (e.g. Level)
ME	Magnitude Error
Meas.	Measurement
Min.	Minimum
Ovw	Overview
PCS	Personal Communications Services
PCDE	Peak Code Domain Error
PE	Phase Error
PER	Packet Error Rate
Pk.	Peak
Q	Quadrature-phase
QPSK	Quadrature Phase Shift Keying
RA	Reverse Activity
RAB	Reverse Activity Bit
RBW	Resolution Bandwidth
Ref.	Reference
Rel.	Relative
RF	Radio Frequency
RMS	Root Mean Square
RPC	Reverse Power Control
RX	Receiver
Scr.	Scrambling
SW	Software
Sym.	Symbol
Sync.	Synchronous
Synch.	Synchronization
Trg.	Trigger
TX	Transmitter
Vect.	Vector

## Glossary of Terms

The following list contains definitions of terms that are often used throughout this manual.

<b>Access Channel</b>	A reverse communication channel used by a mobile station to communicate to a base station.
<b>Carrier Feedthrough</b>	Ratio of the I/Q offset vector (i.e. the estimated DC offset of the measured signal) to the average offset-corrected signal vector.
<b>Carrier frequency error</b>	Deviation of the mobile's modulated carrier frequency from the frequency received from the base station.
<b>Chip rate</b>	Product of the symbol rate and the spreading factor. For the CDMA2000® 1xEV-DO system a fixed chip rate of 1.2288 Mcps is specified.
<b>Code domain</b>	The entire set of channelization codes involved in a CDMA2000® 1xEV-DO signal configuration. Measuring a parameter in code domain means to determine its values as a function of the individual channelization codes.
<b>Code domain error</b>	Ratio of the RMS-averaged power of the error vector projected onto the code domain to the RMS-averaged power of the composite reference signal, expressed in dB.
<b>Code domain power</b>	Power in the individual code channels normalized to the power of the composite signal, expressed in dB.
<b>Crest factor</b>	Peak to average ratio: ratio of the peak transmit power in a slot (peak envelope power) to the average transmit power in a slot.
<b>Cyclic Redundancy Code (CRC)</b>	A class of linear error detecting codes which generate parity check bits by finding the remainder of a polynomial division.
<b><math>E_b</math></b>	Average energy per information bit for the Sync Channel, Paging Channel, or Forward Traffic Channel at the mobile station antenna connector.
<b><math>E_b/N_t</math></b>	The ratio of the combined received energy per bit to the effective noise power spectral density for the Sync Channel, Paging Channel, or Forward Traffic Channel at the mobile station antenna connector.
<b>Error vector magnitude</b>	Difference vector connecting the measured and the ideal modulated signal vector. The error vector magnitude (EVM) is the critical quantity to assess the modulation accuracy of the mobile's transmitter.
<b>I/Q imbalance</b>	Difference between the estimated I and Q amplitudes of the measured signal, normalized and expressed in dB units.
<b>MAC</b>	Used in two contexts. 1) The MAC layer is the Media Access Control layer that coordinates the operation of the physical layer with the needs of the traffic and signalling systems in the upper layers. 2) As a region within the forward link 1xEV-DO slot format, that contains Reverse Control bits and other indicators. This region is repeated four times within a slot.
<b>Magnitude error</b>	Difference in magnitude between the measured and the ideal modulated signal vector, normalized to the magnitude of the ideal vector.
<b>Maximum power</b>	Operating mode where the mobile is set to its maximum power control level.
<b>Minimum power</b>	Operating mode where the mobile is set to its minimum power control level.
<b>Modulation accuracy</b>	Ability of the mobile's transmitter to generate an ideally modulated signal.
<b><math>N_t</math></b>	The effective noise power spectral density at the mobile station antenna connector.

---

<b>Peak code domain error</b>	Maximum of the <i>code domain errors</i> for all codes in the domain, expressed in dB.
<b>Phase error</b>	Difference in phase between the measured and the ideal modulated signal vector.
<b>Reverse Power Control bit</b>	A bit sent (within the MAC region) in every slot. Each bit commands the access terminal to raise or lower its transmit power.
<b>Waveform quality</b>	Normalized correlated power between the actual and the ideal waveform, sampled at the constellation points. The waveform quality ( $\rho$ factor) is a measure of the modulation accuracy. For an ideal transmitter (ideal correlation), it is equal to 1, otherwise it is a positive number smaller than 1.

## References

TIA/EIA/IS-856-1, cdma2000® High Rate Packet Data Air Interface Specification - Addendum 1

## Contents

<b>1 Introduction .....</b>	<b>1.1</b>
<b>Installation Instructions.....</b>	<b>1.1</b>
<b>Software Installation or Update .....</b>	<b>1.2</b>
Creating a new Software Configuration .....	1.5
<b>Enabling Software Options .....</b>	<b>1.7</b>

# 1 Introduction

This chapter describes the installation and update of software options for the Universal Radio Communication Tester R&S CMU 200.

Table 1-1 lists the 1xEV-DO networks supported when the 1xEV-DO hardware and software option are installed to support 1xEV-DO functionality.

Table 1-1 CDMA networks supported

CMU Options for CDMA	Band Class	Network
CMU-K88 1xEV-DO NSig	Band Class 0	US and Korean Cellular
	Band Class 1	North American PCS
	Band Class 2	TACS
	Band Class 3	JTACS
	Band Class 4	Korean PCS
	Band Class 5	NMT-450
	Band Class 6	IMT-2000
	Band Class 7	North American 700 MHz
	Band Class 8	1800 MHz
	Band Class 9	900 MHz
	Band Class 10	Secondary 800 MHz

## Installation Instructions

Before performing any of the steps described in this manual, please make sure that the instrument is properly connected and put into operation according to the instructions given in chapter 1 of the CMU Operating manual. The hardware and software options available are shown in the *Startup* menu. The Hardware Option entry "CMU-B88" indicates the status of the hardware option required for 1xEV-DO mobile tests. The Software Option entry CMU-K88 indicates the status of the software option required for 1xEV-DO mobile tests.

- If version number is indicated, the CMU is ready to perform 1xEV-DO mobile tests. In this case you may skip this chapter, except if you wish to update the current software version.
- If `disabled` is indicated, the software option must be enabled using a key code; see section [Creating a new Software Configuration](#) on page 1.5.
- If `not installed` is indicated, the software must be installed via the PCMCIA interface or the floppy disk drive.




Figure 1-1 Setup – Options menu

## Software Installation or Update


The CMU is always delivered with the latest software version available. New CMU software versions are available for download on the R&S Lotus Notes Service board. To be loaded via the CMU's PCMCIA interface, the software must be copied to one or several flash disks/memory cards or PCMCIA hard disks as explained in the instructions supplied with the software download version. An appropriate memory card CMU-Z1, order no. 1100.7490.02, can be obtained from Rohde & Schwarz.

**Note:** *If your CMU is equipped with a floppy disk drive (option CMU-U61), a set of installation floppy disks must be generated instead of a flash disk. All other steps do not depend on the storage medium.*

To install the software proceed as follows:

- Switch off the CMU.
- Insert the flash disk into one of the two slots of the PCMCIA interface.
- Switch on the CMU.


The installation is started automatically while the CMU performs its start-up procedure. When ready to proceed, the *VersionManager* is displayed (for a detailed description of the *VersionManager* refer to chapter 1 of the CMU operating manual or to the on-line help accessible via *Info*):



Softkey no. 5 on the left softkey bar, *Install software...*, is used to install new software from an external storage medium. The CMU automatically recognizes the storage medium and indicates the corresponding slot number: Slot 0 or 1 denotes the left or right slot of the PCMCIA interface. If a floppy disk is used, the menu option reads *Install software version <version> from floppy*.


- Press left softkey no. 5 (*Install software...*) to start the installation.

If your storage medium contains several installation versions, the software version selection dialog is opened:



- Use the rotary knob or the cursor keys to scroll the list and select the *Measurements* version you intend to install.
- Press *Install* to start the installation.


The installation is started. To be operable on your instrument, a network option must be combined with a compatible version of the CMU base software. Any base software version installed on the CMU hard disk can be combined with one or several network options to form an independent software configuration. If none of the configurations is compatible to the new *Measurements* option, the *VersionManager* displays an error message and takes you back to the software selection dialog; see section [Creating a new Software Configuration](#) on page 1.5. Otherwise, the following upgrade selection dialog is opened:



The upgrade selection dialog displays a list of base software versions that can be combined with the new *Measurements* software.


- Select the appropriate base version and press *Upgrade*.

The new *Measurements* option is added to the configuration or updates the previous *Measurements* version of the configuration. To indicate that the storage medium must be changed the CMU issues the *Change volume* message:



- Replace the current disk with the disk requested.
- Use the cursor up/down keys to select "Process next volume" (default setting).
- Press *ENTER* to confirm that the new disk has been inserted and to continue the installation.

After processing the last disk the CMU displays the following screen:




- If you wish to install or upgrade other software versions, press left softkey no 4 or 5 (*Install next software...*) or insert new storage medium into the PCMCIA slot or floppy disk drive and press *Change disks*.
- To finish the installation, remove all disks from the drive and press *Finish installation*.

The *VersionManager* is closed and the CMU is rebooted. The new firmware options are now operational and listed in the *Menu Select* menu together with their version number. Besides, the last software configuration installed is automatically taken as the active one in the next measurement session.


## Creating a new Software Configuration

The CMU handles base software versions and network options on a separate basis. Different versions of the base software can be combined with different options to create new firmware configurations. For example, it is possible to update the base software without affecting the associated network options or vice versa. Moreover, the same base software version can be installed several times and combined with different network options (and vice versa), so it may enter into several firmware configurations.

If no compatible base software version can be found on the hard disk, then the CMU will refuse to install a new *Measurements* software option selected in the software selection dialog (see previous section). Instead, it displays the following error message:




- Press *Back to installation* to return to the software version selection dialog.



- Select a base software version that is compatible to your *Measurements* software option and press *Install*.

**Note:** As a rule, firmware versions for the base system and for network options are compatible if they differ only in the last digit.


With a new base software version, it is possible to either update an existing configuration or create a new one. A dialog selecting between the two alternatives is opened:



*Note:* This dialog is skipped if the new base software version is not compatible with any of the existing configurations. An incompatible new base software must be installed as a new base software.

- If you wish to add a new configuration to your hard disk, press *Install as new base*.
- To upgrade an existing configuration with the selected base software version in order to make it compatible to the new *Measurements* software option, press *Upgrade existing version*. The existing version to be upgraded must be selected in an additional dialog.

The installation is performed as described in section [Software Installation or Update](#) on p. 1.1. After adding the new base software as a new configuration or updating the existing configuration, the CMU displays the following screen:



- Press left softkey no 4 or 5 (*Install next software...*) and proceed as described in section [Software Installation or Update](#) on p.1.2. to install the new *Measurements* version and assign it to the new configuration.

## Enabling Software Options

A new CMU software option purchased is ready to operate after it is enabled by means of a key code supplied with the option. This key code is to be entered into the *Option Enable* popup window which in turn can be opened via from the *Setup – Options* menu. For details refer to Chapter 4 of the CMU Operating manual.

**Note:** *The CMU software is delivered in complete versions containing all software options available. Software installation and enabling of software options are completely independent from each other.*

## Contents

<b>2 Getting Started .....</b>	<b>2.1</b>
<b>Connecting an Access Terminal.....</b>	<b>2.2</b>
<b>Startup and Reset.....</b>	<b>2.4</b>
<b>Analyzer/Generator Tests.....</b>	<b>2.6</b>

## 2 Getting Started

This chapter provides examples of using the CMU Universal Radio Communication Tester to perform tests on an 1xEV-DO access terminal. It is intended to provide a quick overview of how to setup a test for the 1xEV-DO function group.

Before starting any measurements with the CMU, please note the instructions given in Chapter 1 of the CMU Operating manual for putting the instrument into operation. Chapters 2 through 4 of the CMU Operating manual contain information on customizing the instrument and display according to your personal preferences. For instructions about activating the 1xEV-DO option, refer to Chapter 1 of this manual.

The procedures in this chapter include:



- Connection of an access terminal
- Startup and reset
- Function group selection
- Analyzer/Generator operation

The left side of each double column page illustrates the steps and results obtained on the CMU screen. The right column of the page provides additional information on each step. If available, alternative settings and related measurements are provided.

Manual operation principles are discussed in Chapter 3. All menus, functions, and parameters (including 1xEV-DO background information) are discussed in Chapter 4.

## Connecting an Access Terminal

This chapter describes how to use the CMU to perform 1xEV-DO access terminal tests. Prior to starting any tests, the CMU must be correctly set up and connected to the AC power supply as described in the CMU operating manual. The 1xEV-DO option must be enabled as described in chapter 1 of this manual.



### Step 1

- Switch on the CMU using the mains switch on the rear panel.
- Check the status of the ON/STANDBY key on the front panel. The yellow LED should be illuminated indicating the CMU is in the standby operating mode.

### Step 2

- Connect the bi-directional RF connector RF 2 of the CMU to the Rx/TX connector of the access terminal.
- For certain tests the Rx connector of the access terminal can be connected to an further workstation.
- For GPIB tests connect a controlling workstation with the CMU.
- Supply the access terminal with the correct operating voltage (battery or power supply).

## Additional Information...

**... on Step 1****Mains switch on the rear panel**

When the mains switch at the rear is set to *OFF*, the instrument is disconnected from the power supply. When the mains switch is set to *ON*, the instrument is in standby mode or in operation, depending on the *ON/STANDBY* key.

**ON/STANDBY key on the front panel**

The *ON/STANDBY* key determines whether the instrument is in standby mode or in operation.

Standby mode:

Only the reference frequency oscillator is supplied with operating voltage, and the orange LED (*STANDBY*) is illuminated.

Operation:

The green LED (*ON*) is illuminated and all modules of the instrument are supplied with operating voltage.

**... on Step 2****RF connection of the access terminal**

A high-quality cable should be used for this connection, ideally with an attenuation of less than 0.5 dB.

Input and output connectors can be selected in the *AF/RF*  tab of the *Connect. Control* menu. The tab is also used to report an external input and output attenuation to the CMU.

Ensure that the attenuation cable or connector used is being taken into account by the CMU. During the test, the mobile receiver is being tested with very low RF signal levels, and even a small attenuation can cause the CMU to show a fail indication.

An external signal from a real network may interfere with the signal sent from the CMU to the access terminal. The tests should ideally be performed in a shielded room, however, if this is not possible, the channel(s) used for the test should be changed. If different results are obtained on neighboring channels, the problem is likely to be due to external interference.



**Alternative Settings and Measurements**

 Chapter 1 of the CMU operating manual

The CMU provides two bi-directional RF connectors (RF1 and RF2) differing by their input and output levels. RF2 is the recommended connector for 1xEV-DO access terminals.

The unidirectional connectors RF4 IN and RF3 OUT are intended for connecting modules requiring high input levels or modules with low RF output levels.

## Startup and Reset



### Step 3

- Press the *ON/STANDBY* front panel key on the CMU.

The startup menu displays while the CMU performs the power-up tests (see also additional information on p. 2.5).

After the power-up tests are complete, the CMU returns to the last menu used in the previous session.

### Step 4

- Press the *RESET* key to open the *Reset* popup menu.
- Proceed as described in Chapter 4, section *Reset of Instrument Settings*, of the CMU 200/300 operating manual to expand the tree of function groups.
- Select the 1xEV-DO function group to be reset. The corresponding nodes must be black.
- Use the cursor keys to activate the *Reset* button and press *ENTER*.
- In the popup window opened (*Are you sure?*), select *Yes* to confirm the instrument reset.

The CMU indicates that it performs a partial reset of the two selected function groups and is then ready to carry out the following steps. The *Reset* popup menu is closed automatically.

## Additional Information...

**... on Step 3****Startup menu**

The startup menu displays the following information:

- the status of the startup test (*Process*),
- the device name, serial number and software version (*Info*),
- the options and equipment installed (*Options*),
- the progress of the startup test (*Startup* bar graph).

Before starting a measurement, a reset is recommended to put the CMU in a known operating mode.

**... on Step 4**

The CMU indicates that it performs a reset of all settings in the selected function group(s). After finishing, the CMU is ready to carry out the remaining steps. The *Reset* popup menu closes automatically.

**Alternative Settings and Measurements**

 Chapter 4 of CMU operating manual


Chapter 4 also contains information on customizing the CMU.

# Analyzer/Generator Tests



## Step 5


- Press the *Menu Select* key to open the *Menu Select* menu.



The *Menu Select* menu indicates the function groups available. If a function group is selected, the corresponding modes and measurement menus are indicated.

From this menu, you can select the measurement you want to run.

- Select the *IMT-2000 Mobile Station* header
- Select the *1xEV-DO* function group.
- Scroll down to *Analyzer/Gen.* and expand the list.
- Scroll down to *ModQual HPSK* and press ENTER.
- This displays the *Analyzer/Generator* screen and starts the HPSK modulation quality measurement.



## Step 6

The *Analyzer/Generator* screen displays the current power and modulation measurement results and the RF generator and analyzer settings of the CMU.

Output fields displaying “---” indicate that no valid measurement results are available. Currently, no results are available, because the DUT is not supplying an RF signal to the CMU200

## Additional Information...

**... on Step 5****Menu Select menu**

The *Menu Select* menu shows all function groups installed and enabled on the CMU.

**... on Step 6****Analyzer/Generator screen**

The *Analyzer/Generator* screen contains two panels of information:

- Measurement results
- Settings

The status of the *Modulation* measurement is included in the softkey. For ongoing measurements, the results in the output fields are constantly updated.

Changing the RF Channel number automatically adjusts the base station's transmit and receive frequencies (BS Tx Frequency and BS Rx Frequency) to the corresponding RF Channel number.

**Alternative Settings and Measurements**



 Chapter 3

 Chapter 4

The section Chapter 4 of this manual provides detailed information about all measurement settings, measurement results, and a description of all softkey/hotkey menu buttons.

The current options for the measurement state are *RUN* (default) and *OFF*. A third state, *HLT*, occurs after a single-shot measurement.

Once selected, the Generator or Modulation measurement is switched off and on again by means of the toggle key *ON/OFF*.



### Step 7

- Press the *Connect Control* softkey. This displays the *Connection Control* screen.
- Select the *Generator* tab at the bottom of the display.

The *Generator* settings allow you to adjust all generator settings and turn the RF Generator on or off.

- Select (press) the *Generator* softkey and press ON/OFF to turn on the RF generator.

Press the *Connect Control* softkey again to return to the measurement screen.

### Step 8

- Press the *Analyzer Settings* softkey. This displays a set of hotkeys at the bottom of the screen.

The hotkeys at the bottom of the screen allow you to directly adjust the measurement control settings without opening an additional configuration menu.

- Press the *RF Frequency* softkey and adjust the analyzer frequency to the default generator frequency .
- If the input signal level at RF2 is still too low, press *Generator Level – AT Power* and increase the RF generator level.
- Select the *Long Code Mask* for the given setup. Without a valid *Long Code Mask* the measurements will not display any valid results.
- Select the configuration of the *Code Channel Filters* in order to filter the measurements results and display the desired results. .

## Additional Information...

Alternative Settings  
and Measurements**... on Step 7**

Additional tabs of the *Connection Control* screen allow the setup and control of other aspects of the CMU. These settings are described in Chapter 4 of this manual.

 Chapter 4

**... on Step 8**

After *Reset*, all parameters are set to their default values. The parameters are displayed in the *Settings* window.

 Chapter 4

Additional measurement settings are provided in the *Modulation Configuration* pop-up window. The *Modulation Configuration* pop-up window is accessed by pressing the measurement softkey twice (or once if already selected). In this example, the measurement softkey is labeled *Mod.Qual. HPSK*.

User-defined parameters are saved for later sessions when the CMU is switched off.

## Contents

<b>3 Manual Control</b> .....	<b>3.1</b>
<b>Menu Structure</b> .....	<b>3.1</b>
Test Modes .....	3.1
Status Symbols .....	3.2
Configurations .....	3.2
Measurement Groups .....	3.3
<b>General Settings</b> .....	<b>3.4</b>

## 3 Manual Control

This chapter gives a brief overview of the operating concept and structure of the user interface for 1xEV-DO access terminal tests. The CMU is designed for maximum operating convenience and flexibility. All instrument functions are grouped together in menus. Each menu provides configuration settings, displays a group of measured quantities, or a combination of both. Switching between the different menu groups and signalling modes is possible at any time.

In the following sections, the different measurement modes and measured quantities are discussed. Settings and measurement parameters frequently encountered are explained from a general point of view.

The formal aspects of measurement control are discussed in more detail in Chapter 5 (*Remote Control – Basics*). For information about the CMU's control elements, menu types and dialog elements within the menus refer to Chapter 3 of the CMU Operating manual.

### Menu Structure

The menus used to control 1xEV-DO measurements can be arranged in different ways. From a functional point of view, they form the following groups:

- General configurations (Connection Control)
- Measurement groups (*Analyzer/Generator, Power, Modulation, Spectrum, Code Domain Power*)
- Configurations specific to the measurement groups

The CMU uses main menus, popup menus, graphical measurement menus and dialog windows of various size. Refer to Chapter 3 of the CMU Operating manual for discussions about menus.

### Test Modes

1xEV-DO measurements are performed in the test mode *Non-signalling*. The *Non-Signalling* mode is typically used for module tests or test of access terminals in a special "factory test mode".

#### **Non-Signalling Mode**

In the *Non-Signalling* mode, the CMU generates an RF signal conforming to 1xEV-DO specifications and analyzes the signal transmitted by the device under test (DUT).

## Status Symbols

The non-signalling mode is displayed in the headline above the measurements. The following symbols define the status of the current settings:



### AT Channel



The CMU supports directly 4 AT channels for the measurements out of maximum 55 connected AT's

- The numbers represent the four supported AT channels. Active AT's are being highlighted in green color.
- The arrow points to the AT channel that will generate triggers.
- SyncMsg indicates if the Control Channel Sync message has been activated. If the SyncMsg has been activated the field will be highlighted in green color.

### Generator



This field indicates the status of the Generator. If the Generator has been switched on this field will be highlighted in green color.

### Manual Mode



This field indicates that the CMU is currently in manual mode.

## Configurations

The CMU offers a wide range of settings for the signal generator and analyzer, the signalling procedures, and the individual measurements. Configurations may apply to a whole function group (*Connection Control*) or to a particular measurement.

**Connection Control** The *Connection Control* softkey is located on the right side of the title bar of each main and measurement menu. Depending on the mode (non-signalling or signalling), it opens a popup menu with tabs configuring the following:

- The signal generators and analyzers of the instrument (*Analyzer* and *Generator*)
- The CMU receiver settings and input path configuration (included in *Analyzer, MS Signal*)
- The trigger settings (included in *Analyzer, MS Signal*)
- The RF connectors to be used and the external attenuation (*RF Input/Output*)
- The reference signal and the system clock (*Sync.*)

All settings made in the *Connection Control* menu apply to the whole function group. Many of them are suspended, however, by measurement-specific parameters while a measurement is active (see section *Measurement Environment* in Chapter 4).

**Configurations of measurements** A popup menu offering specific settings is assigned to each measurement group (*Power, Modulation, Code Domain Power, and Receiver Quality*). The following parameters can be defined for many measurements:

- The repetition mode, the stop condition, the statistic count and the display mode for the measurement (*Control*)
- Tolerances for the measured quantities (*Limits, Limit Lines*)

These settings are explained in more detail section [General Settings](#) on page 3.4).

**Configuration hotkeys** via The softkeys and associated hotkeys in the graphical measurement menus provide the most important configurations for the current measurement (refer to Chapters 3 and 4 of the CMU Operating manual). Settings made via hotkeys supersede the corresponding settings found in the measurement configuration menu.

## Measurement Groups

Measurement results are indicated in two different ways:

- Discrete values and parameters are displayed in output fields, lists and tables. In remote control, these results are referred to as scalars.
- Measurement curves (traces) are displayed in a Cartesian coordinate system, the time forming the x-axis scale. Relatively small sets of test points are generally viewed in a bar graph. In remote control, results of this type are referred to as arrays.

While the measurement is running in repetition mode *continuous* (see page 3.4), the indicated results are constantly updated. As shown in the table below, some of the measurement groups are different for the two test modes.

Table 3-1: Measurement Groups of 1xEV-DO

<b>Analyzer/Generator</b>	Shows the settings for the signals generated and analyzed by the instrument and presents an overview of the basic scalar power and modulation results.
<b>Power</b>	The Narrow Band Power is measured in different statistic modes.
<b>Modulation</b>	Shows the error vector magnitude, magnitude error and phase error of the transmitted waveform interval as a function of time. The carrier feedthrough, I/Q imbalance, frequency error, transmission time error, waveform quality and MS power error are displayed.  The I/Q Analyzer shows the I- and Q-parts of the signal in various diagrams to visualize the quality of the incoming signal.
<b>Spectrum</b>	Shows the ACP Spectrum for 4 different frequency offsets in a bar diagram.
<b>Code Domain Power</b>	The CMU measures the power of the access terminal's channels.

## General Settings

A number of settings can be made in several of the configuration menus assigned to the measurement groups *Analyzer/Generator*, *Power*, *Modulation*, *Spectrum* and *Code Domain Power*. In combination, these settings define the scope of the measurement, i.e. the number of waveform intervals measured and the results displayed. The following brief overview is intended to avoid confusion of terms.

**Application**            *Applications* are different measurements belonging to the same measurement group. They effectively split up a measurement group into various related sub-groups which can be configured separately.

They are selected via the *Application* softkey in the measurement menus.

**Statistic Count / Statistics Cycle**    The statistic count is equal to the integer number of evaluation periods which form one statistics cycle. An evaluation period corresponds to the duration of a waveform interval (all TX measurements). Depending on the *repetition mode* (see below), a measurement may extend over one or several statistics cycles.

The *statistic count* is set in the *Control* tab of the configuration popup menus assigned to each measurement group.

**Repetition Mode**            The *repetition mode* defines how many statistics cycles are measured if the measurement is not stopped by a limit failure (see stop condition *On Limit Failure* below). Two modes are available for all measurements:

*Single Shot*            The measurement is stopped after one statistics cycle

*Continuous*            The measurement is continued until explicitly terminated by the user; the results are periodically updated

A third repetition mode is available in remote control:

*Counting*              Repeated single shot measurement with a fixed number of statistics cycles

The *repetition mode* is set in the *Control* tab of the configuration popup-menus assigned to the individual measurement groups.

**Note:**                    *In contrast to other measurement settings, these repetition modes in manual and remote control are independent and do not overwrite each other. In most measurements, the default repetition mode in manual control is Continuous (observe results over an extended period of time), the default mode in remote control is Single Shot (perform one measurement and retrieve results).*

**Stop Condition**            For all TX measurements, two stop conditions can be selected:

*None*                      The measurement is performed according to its repetition mode, regardless of the measurement results,

*On Limit Failure*        The measurement is stopped as soon as one of the limits is exceeded, regardless of the repetition mode set. If no limit failure occurs, it is performed according to its repetition mode.

The *Stop Condition* is set in the *Control* tab of the configuration popup-menus assigned to each measurement group.

**Display Mode**              In graphical measurement diagrams, the *Display Mode* defines which of the measured and calculated traces is displayed if the measurement extends over several waveform intervals. In general, traces are evaluated at a set of fixed, equidistant test points (samples). After n waveform intervals, n measurement results per test point have been taken. After a single shot measurement extending over c waveform intervals, c measurement results per test point have been

taken.

<i>Current</i>	The current waveform interval, i.e. the last result for all test points, is displayed.
<i>Minimum</i>	At each test point, the minimum value of all waveform intervals measured is displayed.
<i>Maximum</i>	At each test point, the maximum value of all waveform intervals measured is displayed.
<i>Max./Min.</i>	At each test point, the extreme value of all waveform intervals measured is displayed, i.e. the maximum or minimum, whichever has a larger absolute value.
<i>Average</i>	At each test point, a suitably defined average over all waveform intervals measured is displayed; see paragraph on <i>Calculation of average quantities</i> below.

Note the difference in the calculation of *Average* on one hand, *Minimum*, *Maximum* and *Max./Min.* on the other hand, if the measurement extends over more than one statistic count (repetition mode *Continuous*, measurement time longer than one statistic count).

The *Display Mode* is set in the *Control* tab of the configuration popup-menus assigned to the individual measurement groups.

**Calculation of average quantities**

The *Average* traces in the menus are obtained as follows:

Let *c* be the number of waveform intervals forming one statistics cycle (one *Statistic Count*) and assume that *n* waveform intervals have been measured since the start of the measurement. In calculating the *Average* trace, the following two situations are distinguished:

***n* ≤ *c*** Single shot measurement or continuous measurement during the first statistics cycle: At each test point, *Average* trace no. *n* is calculated from *Average* trace no. *n* – 1 and *Current* trace no. *n* according to the following recurrence:

$$Avg(n) = \frac{n-1}{n} Avg(n-1) + \frac{1}{n} Curr(n) \quad (n = 1, \dots, c)$$

The *Average* trace represents the arithmetic mean value over all *n* waveform intervals measured.

***n* > *c*** Continuous measurement after the first statistics cycle: At each test point, *Average* trace no. *n* is calculated from *Average* trace no. *n* – 1 and *Current* trace no. *n* according to:

$$Avg(n) = \frac{c-1}{c} Avg(n-1) + \frac{1}{c} Curr(n) \quad (n > c)$$

Scalar quantities are averaged in analogy to *Average* traces. The formulas hold for *n* = 1 where the average trace becomes equal to the current trace (statistics off).

**Calculation of statistical quantities**

In *Power* and *Modulation* measurements the statistical functions *Average*, *Minimum*, *Maximum* and *Minimum/Maximum* are applied to a set of test points depending on two independent parameters:

- The time, i.e. the abscissa values *t<sub>i</sub>*, *i* ranging from 1 to the total number of test points comprising the trace.
- The waveform interval number ranging from 1 to the number *n* of the current waveform interval.

The result of the statistical operations depends on the parameter range considered and – in the case of statistics functions evaluated over several parameters – on the order of evaluations. This is why the definition of statistical quantities deserves some attention and is explained in the relevant sections in chapter 4. One particular example is:

In the *Modulation* menu quantities such as the *Frequency Error*, *Phase Error RMS*, *Phase Error Peak* etc. are first calculated for the current waveform interval and entered in the *Current* column of the output table. The results in the *Minimum/Maximum* column correspond to the extreme value of the *Current* results calculated over all waveform intervals measured. The results in the *Average* column correspond to the average of the *Current* results calculated according to the prescription in paragraph *Calculation of average quantities* above.

# Contents

- 4 Functions and their Application .....4.1**
- 1xEV-DO Module Tests .....4.2**
  - Analyzer/Generator Measurement.....4.3
    - Softkey Selections .....4.4
      - Measurement Control .....4.5
      - Common settings .....4.5
    - Measurement Results .....4.6
  - Analyzer/Generator Configuration .....4.7
    - Analyzer/Generator Configuration – Control.....4.7
    - Analyzer/Generator Configuration – Limits.....4.10
- Power Measurements .....4.11
  - Softkey Selections .....4.11
    - Measurement Control .....4.12
    - Common settings .....4.12
  - Measurement Results .....4.13
- Power Configuration .....4.14
  - Power Configuration – Control.....4.14

- Modulation Measurements.....4.16
- Softkey Selections .....4.17
  - Measurement Control .....4.17
  - Common settings .....4.19
- Measurement Results.....4.19
  - EVM H-PSK, Magn. Err. H-PSK and Phase Err. H-PSK.....4.19
  - Overview .....4.22
  - I/Q Analyzer .....4.22
- Modulation Configuration.....4.26
- Modulation Configuration – Control .....4.26
- Modulation Configuration – Limits .....4.27
- Spectrum Measurements.....4.29
- Softkey Selections .....4.29
  - Measurement Control .....4.30
  - Common settings .....4.30
- Measurement Results.....4.31
- Spectrum Configuration .....4.33
- Spectrum Configuration – Control .....4.33
- Spectrum Configuration – Limits.....4.34
- Code Domain Power Measurements.....4.35
- Softkey Selections .....4.35
  - Measurement Control .....4.36
  - Common settings .....4.37
- Measurement Results.....4.37
  - Code Domain Power.....4.37
  - Peak Code Domain Error Power .....4.40
  - Channel Power .....4.40
- Code Domain Power Configuration .....4.42
- Code Domain Power Configuration – Control.....4.42
- Code Domain Power Configuration – Limits.....4.44

Connection Control .....4.47

- Network Standard (Connection Control – Standard).....4.47
- Analyzer Control (Connection Control – Analyzer).....4.48
- Connection Control – Generator.....4.51
  - Generator Control (Connection Control – Generator) .....4.51
  - Generator Control (Connection Control – Generator – IQ-Access Interface).4.57
- AF/RF Connectors (Connection Control – AF/RF) .....4.58
- Reference Frequency (Connection Control – Sync.).....4.61
- Trigger (Connection Control – Trigger).....4.63
- I/Q-IF Interface (Connection Control – I/Q-IF).....4.65

**Marker Control.....4.67**

## 4 Functions and their Application

This chapter explains in detail all functions for the measurement of access terminals supporting the 1xEV-DO standard. The CMU 200 with Option K88 supports the networks listed in Table 1-1 (see Chapter 1).

The chapter is structured according to the provided measurements and configurations. In contrast to chapter 6, *Remote Control – Commands*, general measurement configurations are relegated to the end of each section.

The description of each softkey, select or input field is followed by the corresponding remote-control command(s). Similarly, the description of the commands in chapter 6 also contains the corresponding menus of the user interface.

Each menu and each panel is briefly described first and then illustrated together with its call button. The menu functions are explained according to the following scheme:

<b>Softkey</b>	Short function definition
Designation of select/input field	Definition of function.
	Further description of the function: purpose, interaction with other settings, notes...
	<i>Parameter 1</i> Description of parameter 1
	<i>Parameter 2</i> Description of parameter 2
	Further description of the parameters: purpose, interaction with other settings, notes...
	Remote control Remote-control command (long form)    Parameter1   Parameter2 ...

---

**Note:**      *For all numerical values, including their ranges and default settings, please refer to the description of the remote-control commands in Chapter 6. The description of the operating concept is found in Chapter 3 of the CMU200 operating manual.*

---

# 1xEV-DO Module Tests

The structure of this section is based on the configuration and measurement groups defined in the function group *IMT-2000 Mobile Station, 1xEV-DO*. The menus are described in the following order:

- Analyzer/Generator Measurement menu
- Power Measurement menu
- Modulation Measurements
- Code Domain Power Measurements
- Common settings for the function group (*Connection Control*)




Figure 4-1 1xEV-DO applications

## Analyzer/Generator Measurement

The *Analyzer/Generator* menu provides an overview over the 1xEV-DO function group, the current measurement status and the most important scalar parameters and measurement results.

The *Analyzer/Generator* menu is opened from the *Menu Select* menu (with associated key at the front of the instrument). The hotkeys associated to the *Menus* softkey switch over between the *Analyzer/Generator* menu and the remaining measurement menus of function group *1xEV-DO*.

In the softkey bar on the right side, the *Analyzer/Generator* menu provides different types of softkeys:

- The measurement control softkey *Mod. Qual. HPSK* controls the measurement, indicates its status (*RUN | HLT | OFF*) and opens the configuration menu *Modulation Quality Configuration*. The hotkeys associated to the measurement control softkey define the scope of the *Modulation* measurement.
- The other softkeys on the right side are combined with various hotkeys (e.g. the hotkeys *RF Max. Level* and *RF Mode* belong to the softkey *Analyzer Level*). The softkey/hotkey combinations provide test settings and switch over between different measurements.

Types of settings    The purpose of the *Analyzer/Generator* menu is to provide quick access to the most common *Modulation* measurements and to present the basic measurement results at a glance. All measurements provide two different types of settings:

- Common settings are valid for all applications of function group *1xEV-DO*. Changing common settings in any application will have an impact on all measurements and applications of the function group. All common settings are also provided in the [Connection Control](#) menu (see p. 4.47 ff.). Examples of common settings are the RF input level and trigger settings (softkey *Analyzer Level*) and the configuration of the RF generator (softkey *Generator*).
- Specific settings are relevant for one application only, or they can be set independently for several applications. Changing specific settings in an application will not affect the other measurements and applications of the function group. No specific settings are provided in the [Connection Control](#) menu (see p. 4.47 ff.). Examples of specific settings are the *Repetition* mode (to be set independently for all applications providing this mode).

Measurement results    The output fields in the left half of the *Analyzer/Generator* menu show the current measurement results. The results depend on the selected application. They are described in detail in section [Measurement Results](#) on p. 4.6 f.

The results displayed in the *Analyzer/Generator* menu represent only a fraction of the modulation results that the CMU is able to acquire. A comprehensive set of test results is displayed in the *Modulation* measurement menus. In particular, the *Modulation* menus show many quantities as functions of time.

**Menu Select** →

**1xEV-DO US Cellular Analyzer / Gen.**

**Current**

- 55.6 dBm AT Power
- 0.9970 Rho
- 148.8 Hz Carrier Frequency Error
- Transmit Time Error
- 41.0 dB Carrier Feedthrough
- I/Q Imbalance
- 40.0 dB Lower Sideband Suppr. (ACP 3)
- 41.4 dB Upper
- 100 Statistic Count
- +98.00 % Out Of Tolerance

**Settings**

- Meas. Control
  - Repetition: Continuous
  - Stop Condition: None
  - Statistic Count: 100
  - Sideband Freq. Offset: ± 900.00 kHz
- Generator Level
  - Output Power: -70.00 dBm
  - MAC RAB Level: -12.00 dB
  - MAC AT1 Level: -16.00 dB
  - MAC AT2 Level: -16.00 dB
  - MAC AT3 Level: -16.00 dB
  - MAC AT4 Level: -16.00 dB
- Impairments
- Generator Settings
  - RF Frequency: 878.4900 MHz
  - RF Channel [BC0]: 283
  - PN Offset: 0
- Traffic
- Control
  - Sync. Message: On
  - Packet Start Offset: 0
  - Data Rate: 38.4 kBit/s
- AT 1

**Connect Control**

**Mod. Qual. H-PSK**

**Analyzer Level Trg.**

**Analyzer Set. 1 2**

**Generator Level Imp.**

**Generator Set. P.Ctrl**

**Menus**

Repetition | Stop Condition | Display Mode | Statistic Count | Side Band Freq. Offset

**Trigger** Ana. Lvl. → Trigger Source | Trigger Level (RF) | Trigger Slope | AT Selection

**Analyzer Level Trg.** → RF Max. Level | RF Mode

**Analyzer Set. 1 2** → Rev. Link Frame Offs. | RF Channel | RF Frequency | Frequency Offset | DRC Filter | ACK Filter | Data Filter

**Analyzer Set. 2 1** → Long Code Mask I | Long Code Mask Q

**Generator Level Imp.** → Output Power OFF | MAC RAB Level | MAC AT1 Level | MAC AT2 Level | MAC AT3 Level | MAC AT4 Level

**Impairm. Gen. Lvl.** → AWGN Level | BS Freq. Offset

**Generator Set. P.Ctrl** → PN Offset | RF Channel | RF Frequency | Reverse Activity | Traffic Control | Traffic AT1 & AT3 | Traffic AT2 & AT4

**Power Ctrl Gen. Set.** → Power Ctrl. Bits | Execute AT1 Pattern Inj. | Execute AT2 Pattern Inj. | Execute AT3 Pattern Inj. | Execute AT4 Pattern Inj. | PCB Pattern AT1 & AT3 | PCB Pattern AT2 & AT4

**Menus** → Analyzer Generator | Power | Modulation | Spectrum | Code Dom. Power

Figure 4-2 Measurement menu Analyzer / Generator

### Softkey Selections

The *Analyzer/Generator* application is controlled by means of the measurement control softkey below the *Connect. Control* softkey and the associated hotkeys. The remaining softkeys select the application and provide application-specific settings.

## Measurement Control

The *Analyzer/Generator* application is controlled by means of the measurement control softkey below the *Connect. Control* softkey and the associated hotkeys.



The *Mod. Qual. H-PSK* softkey controls this measurement and indicates its status (*RUN | HLT | OFF*). To change the status, press the *Modulation* softkey once and then use the front panel keys *ON/OFF* or *CONT/HALT*.

Pressing the *Mod. Qual. H-PSK* softkey twice (once if already selected) opens the *Modulation Configuration* popup menu (see section [Analyzer/Generator Configuration](#) on p. 4.7 ff.).

Remote Control  
 INITiate:MODulation:OVERview:HPSK  
 ABORT:MODulation:OVERview:HPSK  
 STOP:MODulation:OVERview:HPSK  
 CONTinue:MODulation:OVERview:HPSK  
 FETCh[:SCALar]:MODulation:OVERview:HPSK:STATus?

### Measurement configuration

Pressing the *Modulation* softkey twice (once if already selected) opens the *Modulation Configuration* popup menu (see page 4.7). Besides, the measurement control softkey provides hotkeys to define the scope of the measurement. All these settings are also provided in the configuration menu and described in more detail in section [Analyzer/Generator Configuration – Control](#) on page 4.7 ff.

## Common settings

As outlined in section [Analyzer/Generator](#) on p. 4.3 ff., some of the hotkey/softkey combinations in the *Analyzer/Generator* menu are valid irrespective of the application. These common settings are also provided in the [Connection Control](#) menu; for a detailed description refer to p. 4.47 ff.

### Softkeys

- The *Trigger/Analyzer Level* softkey defines the trigger settings for the measurements and controls the level in the RF signal path. The settings are provided in the *Trigger* and *Analyzer* tabs of the *Connection Control* menu; see sections [Trigger \(Connection Control – Trigger\)](#) on p. 4.63 ff. and [Analyzer Control \(Connection Control – Analyzer\)](#) on p. 4.48 ff.
- The *Analyzer Settings 1/2* softkey defines the center frequency of the RF analyzer. The settings are provided in the *Analyzer* tab of the *Connection Control* menu; see section [Analyzer Control \(Connection Control – Analyzer\)](#) on p. 4.48 ff.
- The *Generator Level/Impairment* softkey defines the levels in all physical channels of the generated forward 1xEV-DO signal and configures an additive noise signal. The settings are provided in the *Generator* tab of the *Connection Control* menu; see section [Connection Control – Generator](#) on p. 4.51 ff.
- The *Generator Settings/Power Control* softkey defines the frequency of the generated forward 1xEV-DO signal, its modulation and an offset of the PN sequence. The settings are provided in the *Generator* tab of the *Connection Control* menu; see section [Connection Control – Generator](#) on p. 4.51 ff.

### Settings table

The *Settings* table in the right half of the *Analyzer/Generator* menu gives an overview of the measurement settings of the current application as defined by means of the softkey/hotkey combinations or in the configuration menus. It changes when a different application is selected. The roll-key scrolls and expands the *Setup* table.

**Measurement Results**

The results are displayed in various output fields in the left half of the measurement menu. The display mode (*Current, Min./Max. or Average*) can be selected with the softkey Display Mode which is visible when the Measurement Control softkey has been selected.

Display mode

Output fields




Figure 4-3 Display of results (Analyzer/Generator)

Filter settings for power measurements

The CMU measures and displays different power results, acquired with different measurement methods.

Most of the power measurements are performed using the baseband receiver filter specified in standard TIA/EIA/IS-856-2. In particular, this holds for *AT Power* displayed in the *Analyzer/Generator* menu. The power results listed in the table below are obtained with different measurement filters.

Table 4-7 Filer settings for power measurements

Value	Menu	Filter
AT Power	Analyzer/Generator, see below.	Receiver Filter according to 1xEV-DO standard
Sideband Suppression	Analyzer/Generator, see below.	30 kHz (Gaussian) spectrum analyzer filter
Wideband Power	Connection Control, AF/RF  (see p. 4.61)	Wideband measurement

**AT Power**

*AT Power* is the total transmitted power level from the access terminal. The AT power is measured at the analyzer frequency (*RF Frequency*, typically set to the carrier frequency) using the receiver filter specified in standard TIA/EIA/IS-856-2.

In addition to the *AT Power*, the CMU measures the power at an offset frequency from the carrier; see *Sideband Suppression* below.

**Rho**

*Rho* is the modulation accuracy of the transmitted signal. Rho is obtained by comparing the transmitted signal to an ideal signal as defined in standard TIA-866.

<b>Carrier Frequency Error</b>	<i>Carrier Frequency Error</i> is the difference between the nominal frequency of the selected channel and the measured frequency.
<b>Transmit Time Error</b>	<i>Transmission Time Error</i> is the time offset between the access terminal's signal and the CMU's signal.
<b>Carrier Feedthrough</b>	Carrier Feedthrough refers to the origin offset, which is the magnitude of the RF carrier relative to the magnitude of the modulated carrier.
<b>I/Q Imbalance</b>	<i>I/Q Imbalance</i> is the amplitude ratio between the in-phase (I) and quadrature (Q) components of the signal.
<b>Sideband Suppression</b>	<p><i>Sideband Suppression</i> is a power measurement at a user-configurable offset frequency used for spurious measurements. In contrast to the <i>AT Power</i> the sideband suppression is measured with a 30 kHz (Gaussian) spectrum analyzer filter. The frequency offset is set via the <i>Side Band Freq. Offset</i> hotkey associated to the measurement control softkey.</p> <p><i>Lower Sideband Suppr.</i> Ratio of the sideband power at <i>RF Frequency – Side Band Freq. Offset</i> to the <i>AT Power</i> in dB</p> <p><i>Upper Sideband Suppr.</i> Ratio of the sideband power at <i>RF Frequency + Side Band Freq. Offset</i> to the <i>AT Power</i> in dB</p> <p><b>Note:</b> <i>In remote control the lower and upper sideband suppression can be measured at up to 4 different frequencies; see keywords . . . ACP1 to . . . ACP4.</i></p>
<b>Statistic Count</b>	Number of waveform intervals per statistics cycle. The colored bar indicates the relative measurement progress in the statistics cycle.
<b>Out of Tolerance</b>	<p><i>Out of Tolerance</i> is the percentage of waveform intervals that exceed the defined limits.</p> <p>Remote control  READ[:SCALar]:MODulation:MQuality:HPSK?  FETCh[:SCALar]:MODulation:MQuality:HPSK?  SAMPle[:SCALar]:MODulation:MQuality:HPSK?</p>

## Analyzer/Generator Configuration

The popup menu *Modulation Configuration* contains two tabs to determine the parameters controlling the Modulation measurement including the error tolerances.

The popup menu *Modulation Configuration* is activated by pressing the measurement control softkey at the top right in the graphical measurement menu *Modulation* twice. It is possible to change between the tabs by pressing the associated hotkeys.

## Analyzer/Generator Configuration – Control

The *Control* tab controls the Modulation measurement by determining

- The *Repetition* mode
- The *Stop Condition* for the measurement
- The number of waveform intervals/evaluation periods forming a statistics cycle (*Statistic Count*)
- The type of result displayed (*Display Mode*)

- The frequency offset used for the sideband suppress power measurement (*Sideband Freq. Offset*)




Figure 4-4 Modulation Configuration – Control

**Default Settings** The *Default All Settings* switch assigns default values to all settings in the *Control* tab (the default values are quoted in the command description in chapter 6 of this manual). In addition, default switches for the individual applications are provided.

Remote control

DEFault:MODulation:MQuality:HPSK:CONTRol ON | OFF

**Repetition** The *Repetition* parameter defines how often the measurement is repeated:

*Single Shot* Single-shot measurement: the measurement is stopped after a statistics cycle (or after a stop condition is met, see below). A stopped measurement is indicated by the status display *HLT* in the *Modulation* softkey.

Unless otherwise stated, a statistics cycle corresponds to the number of waveform intervals/evaluation periods set under *Statistic Count*.

*Continuous* Continuous measurement: The CMU continues the measurement until it is terminated explicitly (or until the stop condition for the measurement is met, see below). The measurement results are valid after one statistics cycle; however, the measurement is continued, and the output is continuously updated. An ongoing measurement is indicated by the status display *RUN* in the softkey *Mod.Qual.HPSK*.

Single shot should be selected if only a single measurement result is required under fixed conditions. The continuous measurement is suitable for monitoring the evolution of a measured quantity in time, for example for adjustments.

**Note:** *In remote mode, the counting measurement (counting mode) is available as a further measurement mode with a defined number of measurement cycles to be performed, see chapter 6 of this manual. The Stop Condition setting can affect the Single Shot and Continuous repetition modes.*

Remote control  
 CONFigure:MODulation:MQuality:HPSK:CONTRol  
 CONTInuous | SINGleshot | 1 ... 10000,<StopCondition>,  
 <Stepmode> etc.

**Stop Condition** The *Stop Condition* field defines a stop condition for the measurement:  
*NONE* Continue measurement irrespective of the results of the limit check  
*On Limit Failure* Stop measurement as soon as the limit check fails (one of the tolerances is exceeded)

The *Stop Condition* setting is valid for both the *Single Shot* and *Continuous* repetition modes.

Remote control  
 CONFigure:MODulation:MQuality:HPSK:CONTRol  
 <Repetition>,<SONerror | NONE, <Stepmode> etc.

**Display Mode** The *Display Mode* field defines which of the four measured and calculated statistical measurement results is displayed. The measurement results differ in the way the waveform interval Modulation  $p(t)$  at a fixed point in time  $t$  is calculated if the measurement extends over several waveform intervals; see section *Common Settings* in Chapter 3:

*Current* Measured value for current waveform interval  
*Minimum/Maximum* Extreme value of a number of waveform intervals  
*Average* Average value over a number of waveform intervals

The number of waveform intervals for calculation of the statistical values *Minimum/Maximum* and *Average* – and thus the result – depends on the repetition mode set. In detail, this implies:

*Single shot* Display of minimum/maximum and average value from the performed statistics cycle.  
*Continuous* Display of minimum/maximum from all waveform intervals already measured. The average value, however, is calculated according to the rule in Chapter 3, section *General Settings*.

Remote control  
 no display mode set, the READ..., FETCH... and SAMPLE commands retrieve all values.

**Statistic Count** The input field *Statistic Count* defines the length of the statistics cycles in waveform intervals.

The settings *1* and *OFF* (press *ON/OFF* key) are equivalent. A statistics cycle determines the duration of single-shot measurements.

Remote control  
 CONFigure:MODulation:MQuality:HPSK:CONTRol  
 <Statistics>,<Repetition>,<Stop Cond>,<Step Mode>

**Side Band Freq. Offset** The *Side Band Freq. Offset* input field sets the frequency offset used for the *Sidband Suppression* power measurement; see section [Measurement Results](#) on p. 4.6 ff. The sideband suppression is measured at the two offset frequencies symmetrical to the *RF Frequency* (lower and upper sideband suppression).

In remote control up to 4 different frequency offsets can be defined so that up to 8 symmetrical sideband suppression values are available:

CONFigure:MODulation:MQuality:HPSK:CONTRol:FOFFset:SBSuppress  
:ACP<nr>, where <nr> = 1 to 4

### Analyzer/Generator Configuration – Limits

The *Limits* tab defines upper and lower error limits for the measured values of all three *Modulation* measurement applications. The limits are set independently for the display modes *Current* and *Max./Min.* on one hand, *Average* on the other hand; see section [Analyzer/Generator Configuration – Control](#) on p. 4.7 ff. All measured values are described in section [Measurement Results](#) on p. 4.6 ff.




Figure 4-5 Modulation Configuration – Limits

**Default All Settings**

The *Default All Settings* switch assigns default values to all parameters of the *Limits* tab. The default values are quoted in the command description in chapter 6 of this manual. In addition, default switches for the individual applications and statistical modes are provided.

Remote control

DEFault:MODulation:MQuality:HPSK:CMMax:LIMit ON | OFF  
DEFault:MODulation:MQuality:HPSK:AVERAge:LIMit ON | OFF

**Current & Max/Min**

*Current and Max/Min* sets the limits for the measured values in the current waveform interval or of the extreme values of all measured waveform intervals (*Min/Max*).

Remote control

CONFigure:MODulation:MQuality:HPSK:CMMax:LIMit

**Average**

*Average* sets the limits for the average value of the measured values obtained according to the averaging rules of Chapter 3, section *General Settings*.

Remote control

CONFigure:MODulation:MQuality:HPSK:AVERAge:LIMit

## Power Measurements

The *Power* menu provides access to the Narrow Band Power and the Open Loop measurement of the 1xEV-DO function group, the current measurement status and the most important scalar parameters and measurement results.

The *Power* menu is opened from the *Menu Select* menu (with associated key at the front of the instrument). The hotkeys associated to the *Menus* softkey switch over between the *Power* menu and the remaining measurement menus of function group 1xEV-DO.

In the softkey bar on the right side, the *Power* menu provides different types of softkeys:

- The measurement control softkey *NPower* controls the measurement, indicates its status (*RUN* / *HLT* / *OFF*) and opens the configuration menu *NPower*. The hotkeys associated to the measurement control softkey define the scope of the *Modulation* measurement.
- The other softkeys on the right side are combined with various hotkeys (e.g. the hotkeys RF Max. Level and RF Mode belong to the softkey Analyzer Level). The softkey/hotkey combinations provide test settings and switch over between different measurements.




Figure 4-6 Measurement menu Power

## Softkey Selections

The *Power* application is controlled by means of the measurement control softkey below the *Connect Control* softkey and the associated hotkeys. The remaining softkeys select the application and provide application-specific settings.

## Measurement Control

The *Power* application is controlled by means of the measurement control softkey below the *Connect*. *Control* softkey and the associated hotkeys.

<b>Appli- cation</b>	Currently, there is only the application <i>NPower</i> available.
<b>NPower</b>	<p>The <i>NPower</i> softkey controls the <i>NPower</i> measurement and indicates its status (<i>RUN</i>   <i>HLT</i>   <i>OFF</i>). To change the status, press the <i>NPower</i> softkey once and then use the front panel keys <i>ON/OFF</i> or <i>CONT/HALT</i>.</p> <p>Pressing the <i>NPower</i> softkey twice (once if already selected) opens the <i>NPower Configuration</i> popup menu (see section <a href="#">Power Configuration</a> on p. 4.14 ff.).</p>
Remote Control	<pre>INITiate:NPOWER ABORt:NPOWER STOP:NPOWER CONTinue:NPOWER FETCh[ :SCALar ]:NPOWER:STATus?</pre>
<b>Measurement configuration</b>	Pressing the <i>NPower</i> softkey twice (once if already selected) opens the <i>Power Configuration</i> popup menu (see page 4.14). Besides, the measurement control softkey provides hotkeys to define the scope of the measurement. All these settings are also provided in the configuration menu and described in more detail in section <a href="#">Analyzer/Generator Configuration – Control</a> on page 4.7 ff.

## Common settings

As outlined in section [Analyzer/Generator](#) on p. 4.3 ff., some of the hotkey/softkey combinations in the *Analyzer/Generator* menu are valid irrespective of the application. These common settings are also provided in the [Connection Control](#) menu; for a detailed description refer to p. 4.47 ff.

<b>Softkeys</b>	<ul style="list-style-type: none"> <li>• The <i>Trigger/Analyzer Level</i> softkey defines the trigger settings for the measurements and controls the level in the RF signal path. The settings are provided in the <i>Trigger</i> and <i>Analyzer</i> tabs of the <i>Connection Control</i> menu; see sections <a href="#">Trigger (Connection Control – Trigger)</a> on p. 4.63 ff. and <a href="#">Analyzer Control (Connection Control – Analyzer)</a> on p. 4.48 ff.</li> <li>• The <i>Analyzer Settings 1/2</i> softkey defines the center frequency of the RF analyzer. The settings are provided in the <i>Analyzer</i> tab of the <i>Connection Control</i> menu; see section <a href="#">Analyzer Control (Connection Control – Analyzer)</a> on p. 4.48 ff.</li> <li>• The <i>Generator Level/Impairment</i> softkey defines the levels in all physical channels of the generated forward 1xEV-DO signal and configures an additive noise signal. The settings are provided in the <i>Generator</i> tab of the <a href="#">Connection Control</a> menu; see section <a href="#">Connection Control – Generator</a> on p. 4.51 ff.</li> <li>• The <i>Generator Settings/Power Control</i> softkey defines the frequency of the generated forward 1xEV-DO signal, its modulation and an offset of the PN sequence. The settings are provided in the <i>Generator</i> tab of the <i>Connection Control</i> menu; see section <a href="#">Connection Control – Generator</a> on p. 4.51 ff.</li> </ul>
-----------------	---

### Measurement Results

The results are displayed in various output fields in the left half of the measurement menu. The result fields are grouped in two statistic types (*Current* or *Average*) which are themselves divided in three types of results (*Average*, *Minimum* and *Maximum*).

Display mode

Output fields



Figure 4-7 Display of results (NPower)

Filter settings for power measurements

The CMU measures and displays different power results, acquired with different measurement methods.

Most of the power measurements are performed using the baseband receiver filter specified in standard TIA/EIA/IS-856-2. In particular, this holds for *AT Power* displayed in the *Analyzer/Generator* menu. The power results listed in the table below are obtained with different measurement filters.

Table 4-7 Filer settings for power measurements

Value	Menu	Filter
AT Power	Analyzer/Generator, see below.	Receiver Filter according to 1xEV-DO standard

**Power (Current )**

The Narrow Band Power is measured over a given capture buffer size which by default has a size of 4096 measurement shots.

- **Average** The Average is calculated on the base of the shots in this capture buffer size.
- **Minimum** The Minimum Power value shot in the capture buffer size.
- **Maximum** The Maximum Power value shot in the capture buffer size.

**Power (Statistic)**

Statistic uses the Statistic Count to calculate the average over several capture buffers. e.g. with a Statistic Count of 100 the average is build over 409600 shots.

- **Average** This is the average of all the shots made in the Statistic Count period.
- **Minimum** The absolute minimum measured power over all the measurement shots in Statistic Count.

- **Maximum** The absolute maximum measured power over all the measurement shots in Statistic Count.

**Statistic Count** Number of waveform intervals per statistics cycle. The colored bar indicates the relative measurement progress in the statistics cycle.

Remote control

```
READ[ :SCALar ]:NPOWER?
```

```
FETCH[ :SCALar ]:NPOWER?
```

```
SAMPle[ :SCALar ]:NPOWER?
```

## Power Configuration

The popup menu *Power Configuration* contains a tab to determine the parameters controlling the Modulation measurement including the error tolerances.

The popup menu *Power Configuration* is activated by pressing the measurement control softkey at the top right in the graphical measurement menu *NPower* twice. It is possible to change between the tabs by pressing the associated hotkeys.

## Power Configuration – Control

The *Control* tab controls the Modulation measurement by determining

- The *Repetition* mode
- The *Stop Condition* for the measurement
- The number of evaluation periods forming a statistics cycle (*Statistic Count*)
- The power step control for the Open Loop Time Response measurement




Figure 4-8 Power Configuration – Control

All settings may not be available for all power measurement applications. The statistical settings *Repetition*, *Stop Condition*, *Statistic Count*, and *Display Mode* have the same meaning in all measurements; they are described in section [Analyzer/Generator Configuration – Control](#) on p.4.7 ff.

**Default Settings** The *Default All Settings* switch assigns default values to all settings in the *Control* tab (the default values are quoted in the command description in chapter 6 of this manual). In addition, default switches for the individual applications are provided.

**Capture Buffer Size** *Capture Buffer Size* allows the user to select the buffer size for all measurements shot.

Remote Control      CONFigure:NPOWER:CONTrol:CBSize <CaptureBufferSize>

## Modulation Measurements

The menu group *Modulation* contains several applications to measure the modulation parameters such as frequency error, waveform quality of the access terminal, and matching of the respective tolerance limits. Measurement results are displayed with a graph and a table of measurement results. The popup menu *Modulation Configuration* configures the parameters of the modulation measurements.

The *Analyzer/Generator* menu is opened from the *Menu Select* menu (with associated key at the front of the instrument). The hotkeys associated to the *Menus* softkey switch over between the *Analyzer/Generator* menu and the remaining measurement menus of function group *1xEV-DO*.

- The measurement control softkey *Overview H-PSK* changes to *EVM H-PSK* etc., depending on the application selected. This softkey controls the measurement, indicates its status (*RUN | HLT | OFF*) and opens the configuration menu *Modulation Configuration*. The hotkeys associated to the measurement control softkey define the scope of the *Modulation* measurement.
- The other softkeys on the right side are combined with various hotkeys (e.g. the hotkeys *RF Max. Level* and *RF Mode* belong to the softkey *Analyzer Level*). The softkey/hotkey combinations provide test settings and switch over between different measurements.

The CMU measures the H-PSK modulation accuracy by calculating the Phase Error, Magnitude Error, and Error Vector Magnitude of the modulated signal from the access terminal. [Figure 4-9](#) shows a representation of these signal errors compared to an ideal signal.

*Phase Error (PE)* is the measured phase difference of the I/Q components of the signal received (from the access terminal) and an ideal reference signal at the detection points.

*Magnitude Error (ME)* is the normalized magnitude (amplitude) difference of the I/Q components of the signal received from the access terminal and an ideal reference signal at the detection points.

*Error Vector Magnitude (EVM)* is the normalized magnitude of the calculated vector linking the measured I/Q values to the ideal signal's I/Q components at the detection points.

The In-phase and Quadrature reference components are based on an H-PSK waveform as specified in the IS-856-2 standards publication.

For a 1xEV-DO signal the composite Phase Error (PE), Magnitude Error (ME), Error Vector Magnitude (EVM), and Waveform Quality are calculated.

The measurement interval for is 616 chip intervals ( $\cong 0.5$  ms). The graphical displays represents 616 chips.




Figure 4-9 Modulation errors




Figure 4-10 Measurement menu Modulation

### Softkey Selections


Each *Modulation* application is controlled by means of the measurement control softkey below the *Connect. Control* softkey and the associated hotkeys. The remaining softkeys select the application and provide application-specific settings.

### Measurement Control

Each *Modulation* application is controlled by means of the measurement control softkey below the *Connect. Control* softkey and the associated hotkeys.

**Appli-  
cation**

The *Application* softkey activates a set of hotkeys to select a modulation application. When an application is selected, the corresponding measurement screen is displayed.



**Overview  
H-PSK**

The *Overview HPSK* hotkey displays the statistics for all modulation measurements. No graphical display is provided.

Remote  
Control

```
INITiate:MODulation:MQuality:HPSK
ABORt:MODulation:MQuality:HPSK
STOP:MODulation:MQuality:HPSK
CONTinue:MODulation:MQuality:HPSK
FETCh[:SCALar]:MODulation:MQuality:HPSK:STATus?
```

**EVM  
H-PSK**

Remote  
Control

The *Error Vector Magnitude H-PSK* hotkey displays the Error Vector Magnitude. The Error Vector Magnitude measurement is described in section [Measurement Results](#) on p. 4.19 ff.

INITiate:MODulation:EVMagnitude:HPSK  
 ABORt:MODulation:EVMagnitude:HPSK  
 STOP:MODulation:EVMagnitude:HPSK  
 CONTinue:MODulation:EVMagnitude:HPSK  
 FETCh[:SCALar]:MODulation:EVMagnitude:HPSK:STATus?

**Magn. Err.  
H-PSK**

Remote  
Control

The *Magnitude Error H-PSK* hotkey displays the Magnitude Error measurement. The Magnitude Error measurement is described in section [Measurement Results](#) on p. 4.19 ff.

INITiate:MODulation:MERRor:HPSK  
 ABORt:MODulation:MERRor:HPSK  
 STOP:MODulation:MERRor:HPSK  
 CONTinue:MODulation:MERRor:HPSK  
 FETCh[:SCALar]:MODulation:MERRor:HPSK:STATus?

**Phase Err.  
H-PSK**

Remote  
Control

The *Phase Error H-PSK* hotkey displays the Phase Error measurement. The Phase Error measurement is described in section [Measurement Results](#) on p. 4.19 ff.

INITiate:MODulation:PERRor:HPSK  
 ABORt:MODulation:PERRor:HPSK  
 STOP:MODulation:PERRor:HPSK  
 CONTinue:MODulation:PERRor:HPSK  
 FETCh[:SCALar]:MODulation:PERRor:HPSK:STATus?

**I/Q Analyz.  
H-PSK**

Remote  
Control

The *I/Q Analyz.* hotkey displays the I/Q Analyzer measurement. The I/Q Analyzer measurement is described in section [Measurement Results](#) on p. 4.19 ff.

INITiate:MODulation:IQANalyzer:HPSK  
 ABORt:MODulation:IQANalyzer:HPSK  
 STOP:MODulation:IQANalyzer:HPSK  
 CONTinue:MODulation:IQANalyzer:HPSK  
 FETCh[:SCALar]:MODulation:IQANalyzer:HPSK:STATus?

**Measurement  
configuration**

Pressing the *Modulation* softkey twice (once if already selected) opens the *Modulation Configuration* popup menu (see page 4.7). Besides, the measurement control softkey provides hotkeys to define the scope of the measurement. All these settings are also provided in the configuration menu and described in more detail in section [Analyzer/Generator Configuration – Control](#) on page 4.7 ff.

**Marker  
Display**

The *Marker/Display* softkey positions up to three markers and a baseline (D-Line) in the test diagram and outputs their values. Refer to page 4.67 ff for detailed information about markers.

The softkey is only available for the following applications: *EVM H-PSK.*, *Magn. Err H-PSK* and *Phase Err H-PSK*.

**Display**

The *Display* softkey is available for the application *I/Q Analyz* only. It allows to select the Zoom of the diagram and the displayed Waveform Type.

## Common settings

As outlined in section [Analyzer/Generator](#) on p. 4.3 ff., some of the hotkey/softkey combinations in the *Analyzer/Generator* menu are valid irrespective of the application. These common settings are also provided in the *Connection Control* menu; for a detailed description refer to p. 4.47 ff.

### Softkeys

- The *Trigger/Analyzer Level* softkey defines the trigger settings for the measurements and controls the level in the RF signal path. The settings are provided in the *Trigger* and *Analyzer* tabs of the *Connection Control* menu; see sections [Trigger \(Connection Control – Trigger\)](#) on p. 4.63 ff. and [Analyzer Control \(Connection Control – Analyzer\)](#) on p. 4.48 ff.
- The *Analyzer Settings 1/2* softkey defines the center frequency of the RF analyzer. The settings are provided in the *Analyzer* tab of the *Connection Control* menu; see section [Analyzer Control \(Connection Control – Analyzer\)](#) on p. 4.48 ff.
- The *Generator Level/Impairment* softkey defines the levels in all physical channels of the generated forward 1xEV-DO signal and configures an additive noise signal. The settings are provided in the *Generator* tab of the *Connection Control* menu; see section [Connection Control – Generator](#) on p. 4.51 ff.
- The *Generator Settings/Power Control* softkey defines the frequency of the generated forward 1xEV-DO signal, its modulation and an offset of the PN sequence. The settings are provided in the *Generator* tab of the *Connection Control* menu; see section [Connection Control – Generator](#) on p. 4.51 ff.

### Settings table

The *Settings* table on the right side of the *Modulation* menu gives an overview of the measurement settings of the current application as defined by means of the softkey/hotkey combinations or in the configuration menus. It changes when a different application is selected. The roll-key scrolls and expands the *Setup* table.

## Measurement Results

The modulation measurement screens are similar for the applications *EVM H-PSK*, *Magn. Err. H-PSK* and *Phase Err. H-PSK*. The *Overview H-PSK* application does not provide a graph. The application *I/Q Analyzer* will be described in section [I/Q Analyzer](#) on p. 4.22 ff.

## EVM H-PSK, Magn. Err. H-PSK and Phase Err. H-PSK

The description of the graphs and common output data follows below. Information specific to an application is located within the application heading. Limits for all modulation measurements are defined in the *Modulation Control* configuration menu.

The measurement screens can be divided into three groups:

- Scalar measurement results (parameter lines and output tables)
- Graph (a trace plotted as a function of time)
- Settings overview

Parameter lines  
1 and 2

Measurement  
graph

Output table




Figure 4-11 Modulation results display

**Parameter Lines** Scalar measurement results and settings are indicated in the two parameter lines above the test diagram and in the *Settings* table below.

1<sup>st</sup> Line The first parameter line contains the following settings:

- RF Max. Level* The total output power, either calculated as a function of the RF generator output level (Auto) or set manually.
- DRC* The settings of the DRC channel filter
- ACK* The settings of the ACK channel filter
- Data* The settings of the Data channel filter
- Ch./Freq* Channel and frequency set for the BS Signal

2<sup>nd</sup> Line The second parameter line contains the following marker values:

-  Level and time of reference marker
-  Level and time of marker 1 (setting *absolute*) and/or difference from reference marker (setting *relative*)
-  Level and time of marker 2 (setting *absolute*) and/or difference from reference marker (setting *relative*)

**Settings** The values shown in the *Settings* table are defined in the *Control* tab of the *Connection Control* menu; see section [Modulation Configuration – Control](#) on p. 4.26 ff.

**Measurement Graph** The *Measurement Graph* is displayed as a continuous curve together with the limit lines and all active markers.

The graph in each measurement shows the respective measurement error as a function of time. The display mode for the graph (*Current*, *Average*, *Max/Min*) is indicated in the upper right corner of the screen.

**Statistic Count** The *Statistic Count* is the number of intervals since the start of the measurement. The bar graph represents a percentage of intervals measured based on the number of intervals (*Statistic Count*) set in the configuration menu.

<b>Output Table</b>	<p>The output table contains a tabular overview of modulation related measurements. The first rows of data are specific to the selected modulation measurement. The remaining rows are identical for each modulation measurement.</p> <p>Three values are given for each row:</p> <table border="0"> <tr> <td style="padding-left: 20px;"><i>Current</i></td> <td>These are the current values of the measurement interval.</td> </tr> <tr> <td style="padding-left: 20px;"><i>Max/Min</i></td> <td>These are the extreme values (and their polarity) of all measurement intervals since the measurement started.</td> </tr> <tr> <td style="padding-left: 20px;"><i>Average</i></td> <td>These are the average values of a number of measurement intervals (defined by the <i>Statistic Count</i> setting; see section <i>General Settings</i> in Chapter 3).</td> </tr> </table> <p>Any values exceeding the defined limits appear with a red background. Limit values are set in the Limit tab of the <i>Modulation Configuration</i> menu.</p>	<i>Current</i>	These are the current values of the measurement interval.	<i>Max/Min</i>	These are the extreme values (and their polarity) of all measurement intervals since the measurement started.	<i>Average</i>	These are the average values of a number of measurement intervals (defined by the <i>Statistic Count</i> setting; see section <i>General Settings</i> in Chapter 3).
<i>Current</i>	These are the current values of the measurement interval.						
<i>Max/Min</i>	These are the extreme values (and their polarity) of all measurement intervals since the measurement started.						
<i>Average</i>	These are the average values of a number of measurement intervals (defined by the <i>Statistic Count</i> setting; see section <i>General Settings</i> in Chapter 3).						
Modulation Error	<p>Refer to the respective measurement type for information about the data reported in these first two rows.</p> <table border="0"> <tr> <td style="padding-left: 20px;"><i>Phase Error</i></td> <td>Measured phase difference of the I/Q components of the signal received (from the access terminal) and an ideal reference signal at the detection points.</td> </tr> <tr> <td style="padding-left: 20px;"><i>Magnitude Error</i></td> <td>Difference in magnitude (in percent) between the received signal waveform and an ideal HPSK signal waveform. The magnitude error is the difference in amplitude between the measured signal from the access terminal transmitter and an ideal signal waveform at the detection points.</td> </tr> <tr> <td style="padding-left: 20px;"><i>Error Vector Magnitude</i></td> <td>Calculated percentage of vector error (at the detection points) between the received signal and an ideal signal.</td> </tr> </table>	<i>Phase Error</i>	Measured phase difference of the I/Q components of the signal received (from the access terminal) and an ideal reference signal at the detection points.	<i>Magnitude Error</i>	Difference in magnitude (in percent) between the received signal waveform and an ideal HPSK signal waveform. The magnitude error is the difference in amplitude between the measured signal from the access terminal transmitter and an ideal signal waveform at the detection points.	<i>Error Vector Magnitude</i>	Calculated percentage of vector error (at the detection points) between the received signal and an ideal signal.
<i>Phase Error</i>	Measured phase difference of the I/Q components of the signal received (from the access terminal) and an ideal reference signal at the detection points.						
<i>Magnitude Error</i>	Difference in magnitude (in percent) between the received signal waveform and an ideal HPSK signal waveform. The magnitude error is the difference in amplitude between the measured signal from the access terminal transmitter and an ideal signal waveform at the detection points.						
<i>Error Vector Magnitude</i>	Calculated percentage of vector error (at the detection points) between the received signal and an ideal signal.						
Carrier Feedthrough	<i>Carrier Feedthrough</i> refers to the origin offset, which is the magnitude of the RF carrier relative to the magnitude of the modulated carrier.						
I/Q Imbalance	<i>I/Q Imbalance</i> is the amplitude ratio between the in-phase (I) and quadrature (Q) components of the signal.						
Carrier Freq Error	<i>Carrier Frequency Error</i> is the difference between the nominal frequency of the selected channel and the measured frequency.						
Transmit Time Error	<i>Transmission Time Error</i> is the time offset between the access terminal's signal and the CMU's signal.						
Rho	<i>Rho</i> is the modulation accuracy of the transmitted signal. The waveform quality is obtained by comparing the transmitted signal to an ideal HPSK signal as defined in standard TIA-866.						
AT Power	<i>AT Power</i> is the total transmitted power level from the access terminal.						
Remote Control	<pre> READ[ :SCALar ]:MODulation:OVERview:HPSK? FETCh[ :SCALar ]:MODulation:OVERview:HPSK? SAMPle[ :SCALar ]:MODulation:OVERview:HPSK?  READ[ :SCALar ]:MODulation:EVMagnitude:HPSK? FETCh[ :SCALar ]:MODulation:EVMagnitude:HPSK? SAMPle[ :SCALar ]:MODulation:EVMagnitude:HPSK?                 </pre>						

```

READ[:SCALar]:MODulation:MERRor:HPSK?
FETCh[:SCALar]:MODulation:MERRor:HPSK?
SAMPle[:SCALar]:MODulation:MERRor:HPSK?

READ[:SCALar]:MODulation:PERRor:HPSK?
FETCh[:SCALar]:MODulation:PERRor:HPSK?
SAMPle[:SCALar]:MODulation:PERRor:HPSK?
    
```

### Overview

The Overview application allows you to view all modulation measurements in a single output table (no graph of the measurements is provided).

The peak and the RMS values of the current measurement interval are displayed for each modulation application. The average values (positive or negative) are calculated over a user definable number of *Statistic Counts*. The Min/Max. values are the extreme values from the start of the measurement.




Figure 4-12 Overview display

### I/Q Analyzer


The I/Q Analyzer application displays I/Q diagrams to visualize the quality of the received measurements results. The benefit of this measurement is to easily identify issues with the received signals. To achieve this, the application I/Q-Analyzer can display the measurement results in 5 different diagrams:

- Constellation Diagram
- Vector Diagram
- I Phase Diagram
- Q Phase Diagram
- I Phase & Q Phase Diagram


Constellation Diagram and Vector Diagram contain additional scalar information of the current measurement.

The settings of the *Code Channel Filters* (section Analyzer Control (Connection Control – Analyzer) on pg. 4.48) have a major influence on evaluation and display of the measurement results.


**Constellation Diagram**




**Vector Diagram**



I Phase Diagram



Q Phase Diagram



**I Phase & Q Phase Diagram**




Figure 4-13 I/Q Analyzer displays

**Diagram**

Depending on the Setting of Waveform type, the different diagrams of the I/Q Analyzer are being displayed. The following diagrams can be displayed:

- Constellation Diagram** Displays the measurement shots of a full phase in a I/Q diagram. By the symmetry, the position of the measurement shots and their sharpness the quality of the current signal can be analyzed.
- Vector Diagram** Between the full phases three further measurement shots are being taken. These results are being connected by vectors and displayed in an I/Q diagram.
- I Phase** All measurement shots of the I Phase are being displayed on the base of two full measurement phases. The size of the eyes above the value of 1.0 visualizes the quality of the signal.
- Q Phase** Identical to the I Phase diagram, but displaying Q Phase results only.
- I Phase & Q Phase** Displays both I Phase and Q Phase diagrams (s.o.). This gives a good overview but the resolution is not as high as the specialized diagrams.

**Output Table**

The output table in the diagram types Constellation and Vector display the following results:

- AT Power** *AT Power* is the total transmitted power level from the access terminal.
- Rho** *Rho* is the modulation accuracy of the transmitted signal. The waveform quality is obtained by comparing the transmitted signal to an ideal HPSK signal as defined in standard TIA-866.

Carrier Feedthrough	<i>Carrier Feedthrough</i> refers to the origin offset, which is the magnitude of the RF carrier relative to the magnitude of the modulated carrier.
I/Q Imbalance	<i>I/Q Imbalance</i> is the amplitude ratio between the in-phase (I) and quadrature (Q) components of the signal.
Error Vector Magnitude	Calculated percentage of vector error (at the detection points) between the received signal and an ideal signal.
Magnitude Error	Difference in magnitude (in percent) between the received signal waveform and an ideal HPSK signal waveform. The magnitude error is the difference in amplitude between the measured signal from the access terminal transmitter and an ideal signal waveform at the detection points.
Phase Error	Measured phase difference of the I/Q components of the signal received (from the access terminal) and an ideal reference signal at the detection points.

### Modulation Configuration

The popup menu *Modulation Configuration* contains two tabs to define the parameters of the modulation measurements including the error tolerances.

Pressing the measurement softkey twice opens the popup menu *Modulation Configuration*. Press the associated hotkeys to change between tabs. Use the roll-key to expand or compress the list of settings displayed.

### Modulation Configuration – Control

The *Control* tab controls the modulation measurement applications. The control configuration is divided into settings for the different modulation applications




Figure 4-14 Modulation Configuration – Control

All settings may not be available for all modulation measurement applications. The statistical settings *Repetition* , *Stop Condition*, *Statistic Count*, and *Display Mode* have the same meaning in all

measurements; they are described in section *Analyzer/Generator Configuration – Control* on p. 4.7 ff. The *Display Mode* is available for measurement curves only.

- Zoom                      *Zoom* is available for the *I/Q Analyzer H-PSK only*. It can be used to zoom in and out of the diagram to closer study the diagram results.
- Constellation            *WaveForm Type* is available for the *I/Q Analyzer H-PSK only*. *WaveForm Type* allows the user to select the different available diagrams of *I/Q Analyzer H-PSK*.

### Modulation Configuration – Limits

The *Limits* tab defines the tolerance limits for each of the *Modulation* measurement applications, except the *I/Q Analyzer* which has no limit settings. Two sets of limits are configurable for each measurement: the *Current* and *Maximum/Minimum* measurement limits and the *Average* measurement limits.




Figure 4-15 Modulation Configuration – Limits

#### Default All Settings

The *Default All Settings* switch assigns default values to all parameters of the modulation *Limits* tab (the default values are quoted in the command description in chapter 6 of this manual). Additional default switches are provided for the individual applications.

#### Remote control

```
DEFault:MODulation:<Application>:LIMit ON | OFF
```

#### Current & Max/Min

*Current and Max/Min* sets the limits for the measured values in the current waveform interval or of the extreme values of all measured waveform intervals (Min/Max).

#### Remote control

```
CONFigure:MODulation:OEMP:HPSK:CMMax:LIMit[:SCALar]:
SYMMetric[:COMBined]:VALue
CONFigure:MODulation:OEMP:HPSK:CMMax:LIMit[:SCALar]:
SYMMetric[:COMBined]:ENABLE
CONFigure:MODulation:OEMP:HPSK:CMMax:LIMit[:SCALar]:
SYMMetric[:COMBined]
```

**Average**

*Average* sets the limits are for the average value of the measured values derived from the last statistic cycle.

**Remote control**

```
CONFigure:MODulation:OEMP:HPSK:AVERAge:LIMit[:SCALar]:  
SYMMetric[:COMBined]:VALue  
CONFigure:MODulation:OEMP:HPSK:AVERAge:LIMit[:SCALar]:  
SYMMetric[:COMBined]:ENABle  
CONFigure:MODulation:OEMP:HPSK:AVERAge:LIMit[:SCALar]:  
SYMMetric[:COMBined]
```

## Spectrum Measurements

The *Spectrum* menu provides access to the ACP spectrum measurement of 1xEV-DO. The measurement results are also available using the *Analyzer/Generator Measurement* on pg 4.3. This measurement however displays all results in a diagram.

The *Spectrum* menu is opened from the *Menu Select* menu (with associated key at the front of the instrument). The hotkeys associated to the *Menus* softkey switch over between the *Spectrum* menu and the remaining measurement menus of function group 1xEV-DO.

In the softkey bar on the right side, the *Spectrum* menu provides different types of softkeys:

- The measurement control softkey *ACP* controls the measurement, indicates its status (*RUN | HLT | OFF*) and opens the configuration menu *Spectrum Configuration*. The hotkeys associated to the measurement control softkey define the scope of the *Modulation* measurement.
- The other softkeys on the right side are combined with various hotkeys (e.g. the hotkeys *RF Max. Level* and *RF Mode* belong to the softkey *Analyzer Level*). The softkey/hotkey combinations provide test settings and switch over between different measurements.




Figure 4-16 Measurement menu Spectrum

## Softkey Selections

The *Spectrum* application is controlled by means of the measurement control softkey below the *Connect. Control* softkey and the associated hotkeys. The remaining softkeys select the application and provide application-specific settings.

## Measurement Control

The *Spectrum* application is controlled by means of the measurement control softkey below the *Connect. Control* softkey and the associated hotkeys.



The *ACP* softkey controls the *ACP* measurement and indicates its status (*RUN* | *HLT* | *OFF*). To change the status, press the *ACP* softkey once and then use the front panel keys *ON/OFF* or *CONT/HALT*.

Pressing the *ACP* softkey twice (once if already selected) opens the *Spectrum Configuration* popup menu (see section [Spectrum Configuration](#) on p. 4.33 ff.).

Remote Control

```
INITiate:SPECTrum:ACP
ABORt:SPECTrum:ACP
STOP:SPECTrum:ACP
CONTinue:SPECTrum:ACP
FETCh[:SCALar]:SPECTrum:ACP:STATus?
```

### Measurement configuration

Pressing the *ACP* softkey twice (once if already selected) opens the *Spectrum Configuration* popup menu (see page 4.33). Besides, the measurement control softkey provides hotkeys to define the scope of the measurement. All these settings are also provided in the configuration menu and described in more detail in section [Spectrum Configuration](#) on p. 4.33 ff.

## Common settings

As outlined in section [Analyzer/Generator](#) on p. 4.3 ff., some of the hotkey/softkey combinations in the *Analyzer/Generator* menu are valid irrespective of the application. These common settings are also provided in the [Connection Control](#) menu; for a detailed description refer to p. 4.47 ff.

### Softkeys

- The *Trigger/Analyzer Level* softkey defines the trigger settings for the measurements and controls the level in the RF signal path. The settings are provided in the *Trigger* and *Analyzer* tabs of the *Connection Control* menu; see sections [Trigger \(Connection Control – Trigger\)](#) on p. 4.63 ff. and [Analyzer Control \(Connection Control – Analyzer\)](#) on p. 4.48 ff.
- The *Analyzer Settings 1/2* softkey defines the center frequency of the RF analyzer. The settings are provided in the *Analyzer* tab of the *Connection Control* menu; see section [Analyzer Control \(Connection Control – Analyzer\)](#) on p. 4.48 ff.
- The *Generator Level/Impairment* softkey defines the levels in all physical channels of the generated forward 1xEV-DO signal and configures an additive noise signal. The settings are provided in the *Generator* tab of the [Connection Control](#) menu; see section [Connection Control – Generator](#) on p. 4.51 ff.
- The *Generator Settings/Power Control* softkey defines the frequency of the generated forward 1xEV-DO signal, its modulation and an offset of the PN sequence. The settings are provided in the *Generator* tab of the *Connection Control* menu; see section [Connection Control – Generator](#) on p. 4.51 ff.

### Settings table

The *Settings* table on the lower right side of the *Spectrum* menu gives an overview of the measurement settings of the current application as defined by means of the softkey/hotkey combinations or in the configuration menus. It changes when a different application is selected. The roll-key scrolls and expands the *Setup* table.

### Measurement Results

The results are displayed in various output fields in the left half of the measurement menu. The display mode (*Current, Min./Max. or Average*) can be selected with the softkey *Display Mode* that is visible when the Measurement Control softkey has been selected.

Parameter lines  
1 and 2

Measurement  
graph

Sideband Frequency  
Offset

Output table




Figure 4-17 Display of results (Analyzer/Generator)

Filter settings for  
power  
measurements

The CMU measures and displays different power results, acquired with different measurement methods.

Most of the power measurements are performed using the baseband receiver filter specified in standard TIA/EIA/IS-856-2. In particular, this holds for *AT Power* displayed in the *Analyzer/Generator* menu. The power results listed in the table below are obtained with different measurement filters.

Table 4-7 Filter settings for power measurements

Value	Menu	Filter
AT Power	Analyzer/Generator, see below.	Receiver Filter according to 1xEV-DO standard
Sideband Suppression	Analyzer/Generator, see below.	30 kHz (Gaussian) spectrum analyzer filter

Parameter Lines

Scalar measurement results and settings are indicated in the two parameter lines above the test diagram and in the *Settings* table below.

1<sup>st</sup> Line

The first parameter line contains the following settings:

- RF Max. Level* The total output power, either calculated in adaption to the signal level (Auto) or set manually.
- DRC* The settings of the DRC channel filter
- ACK* The settings of the ACK channel filter
- Data* The settings of the Data channel filter
- Ch./Freq* Channel and frequency set for the BS Signal

2 <sup>nd</sup> Line	<p>The second parameter line contains the following marker values:</p> <p><b>R</b> Level and time of reference marker</p> <p><b>1</b> Level and time of marker 1 (setting <i>absolute</i>) and/or difference from reference marker (setting <i>relative</i>)</p> <p><b>2</b> Level and time of marker 2 (setting <i>absolute</i>) and/or difference from reference marker (setting <i>relative</i>)</p>						
<b>Measurement Graph</b>	<p>The <i>Measurement Graph</i> is displayed as a set of vertical bar diagrams which represent ACP for the given Sideband Frequency Offset.</p> <p>The display mode for the graph (<i>Current, Average, Max/Min</i>) is indicated in the upper right corner of the screen.</p>						
<b>Channel Power</b>	<p>As a reference the <i>Channel Power</i> is displayed in the middle of the graph. The <i>Channel Power</i> is set according to the current settings of the <i>AT Power</i>.</p>						
<b>Sideband Frequency Offset</b>	<p>This line displays the selected Sideband Frequency Offsets for each graph and table of this measurement. The offset can be configured using the <a href="#">Spectrum Configuration – Control</a> on pg. 4.33.</p>						
<b>Settings</b>	<p>The values shown in the <i>Settings</i> table are defined in the <i>Control</i> tab of the <i>Connection Control</i> menu; see section <a href="#">Modulation Configuration – Control</a> on p. 4.26 ff.</p>						
<b>Statistic Count</b>	<p>The <i>Statistic Count</i> is the number of intervals since the start of the measurement. The bar graph represents a percentage of intervals measured based on the number of intervals (<i>Statistic Count</i>) set in the configuration menu.</p>						
<b>Output Table</b>	<p>The output table contains a tabular overview of the measurement results for the selected Sideband Frequency Offset.</p> <p>Each column contains three different measurement result:</p> <table border="0" style="margin-left: 40px;"> <tr> <td style="padding-right: 20px;"><i>Current</i></td> <td>These are the current values of the measurement interval.</td> </tr> <tr> <td style="padding-right: 20px;"><i>Max/Min</i></td> <td>These are the extreme values (and their polarity) of all measurement intervals since the measurement started.</td> </tr> <tr> <td style="padding-right: 20px;"><i>Average</i></td> <td>These are the average values of a number of measurement intervals (defined by the <i>Statistic Count</i> setting; see section <i>General Settings</i> in Chapter 3).</td> </tr> </table>	<i>Current</i>	These are the current values of the measurement interval.	<i>Max/Min</i>	These are the extreme values (and their polarity) of all measurement intervals since the measurement started.	<i>Average</i>	These are the average values of a number of measurement intervals (defined by the <i>Statistic Count</i> setting; see section <i>General Settings</i> in Chapter 3).
<i>Current</i>	These are the current values of the measurement interval.						
<i>Max/Min</i>	These are the extreme values (and their polarity) of all measurement intervals since the measurement started.						
<i>Average</i>	These are the average values of a number of measurement intervals (defined by the <i>Statistic Count</i> setting; see section <i>General Settings</i> in Chapter 3).						
Remote Control	<pre>READ[ :SCALar ] :SPECTrum :ACP? FETCh[ :SCALar ] :SPECTrum :ACP? SAMPle[ :SCALar ] :SPECTrum :ACP?</pre>						

## Spectrum Configuration

The popup menu *Spectrum Configuration* contains two tabs to define the parameters of the modulation measurements including the error tolerances.

Pressing the measurement softkey twice opens the popup menu *Spectrum Configuration*. Press the associated hotkeys to change between tabs. Use the roll-key to expand or compress the list of settings displayed.

### Spectrum Configuration – Control

The *Control* tab controls the modulation measurement applications. The control configuration is divided into settings for the different modulation applications




Figure 4-18 Modulation Configuration – Control

The statistical settings *Repetition*, *Stop Condition*, *Statistic Count*, and *Display Mode* have the same meaning in all measurements; they are described in section [Analyzer/Generator Configuration – Control](#) on pg. 4.7 ff.

**ACP Frequency Offset** *ACP Frequency Offset* allows the user to select the Frequency Offset from the selected Channel/Frequency. The selected *ACP Frequency Offset* will be displayed in the diagram under the measurement bars.

ACP1...4 *ACP 1..4* are the symmetrical offsets. The measurement supports up to 4 different offsets between 0 kHz and 2000 kHz.

**Remote Control** `CONFigure:SPECTrum:ACP:CONTrol:FOFFset:ACP1[?]`  
`CONFigure:SPECTrum:ACP:CONTrol:FOFFset:ACP2[?]`  
`CONFigure:SPECTrum:ACP:CONTrol:FOFFset:ACP3[?]`  
`CONFigure:SPECTrum:ACP:CONTrol:FOFFset:ACP4[?]`

## Spectrum Configuration – Limits

The *Limits* tab defines the tolerance limits for each of the *Spectrum* measurement application.




Figure 4-19 Modulation Configuration – Limits

**ACP 1..4 Limit**      *ACP 1..4 Limit* sets the limit for each ACP Frequency offset. The limits are used symmetrical for the positive and the negative offset.

Remote control      `CONFigure:SPECTrum:ACP:LIMit:ACP1[?]`  
`CONFigure:SPECTrum:ACP:LIMit:ACP2[?]`  
`CONFigure:SPECTrum:ACP:LIMit:ACP3[?]`  
`CONFigure:SPECTrum:ACP:LIMit:ACP4[?]`

## Code Domain Power Measurements

The menu group *Code Dom. Power* contains the functions to measure the Code Domain Power (CDP), Peak Code Domain Error Power (PCDEP), and Channel Power.

The *Code Dom. Power* menu is opened from the *Menu Select* menu or from any other measurement menu in *1xEV-DO* using the hotkey *Menu – Code Domain Power* (see Figure 4-20). The initial screen returns to the *Code Dom. Power* application last accessed.

In the softkey bar on the right side, the *Code Domain Power* menu provides different types of softkeys:

- The measurement control softkey *CDP H-PSK* changes to *PCDEP H-PSK* and *Ch. Power H-PSK*, depending on the application selected. This softkey controls the measurement, indicates its status (*RUN | HLT | OFF*) and opens the configuration menu *Code Dom. Power Configuration*. The hotkeys associated to the measurement control softkey define the scope of the *Code Domain Power* measurement.
- The other softkeys on the right side are combined with various hotkeys (e.g. the hotkeys *RF Max. Level* and *RF Mode* belong to the softkey *Analyzer Level*). The softkey/hotkey combinations provide test settings and switch over between different measurements.




Figure 4-20 Code Domain Power measurement menu

### Softkey Selections


Each *Code Dom. Power* application is controlled by means of the measurement control softkey below the *Connect. Control* softkey and the associated hotkeys. The remaining softkeys select the application and provide application-specific settings.

## Measurement Control

Each *Modulation* application is controlled by means of the measurement control softkey below the *Connect. Control* softkey and the associated hotkeys.

### Appli- cation

The *Application* softkey activates a set of hotkeys to select a modulation application. When an application is selected, the corresponding measurement screen is displayed.



### CDP H-PSK

The *CDP H-PSK* hotkey changes the power measurement application to measure the Code Domain Power of the access terminal.

Remote  
Control

```
INITiate:CDPower:CDPW
ABORt:CDPower:CDPW
STOP:CDPower:CDPW
CONTinue:CDPower:CDPW
FETCh[:SCALar]:CDPower:CDPW:STATUs?
```

### PCDEP H-PSK

The *PCDEP H-PSK* hotkey changes the power measurement application to measure the Peak Code Domain Error Power of the access terminal.

Remote  
Control

```
INITiate:CDPower:PCDep
ABORt:CDPower:PCDep
STOP:CDPower:PCDep
CONTinue:CDPower:PCDep
FETCh[:SCALar]:CDPower:PCDep:STATUs?
```

### Ch. Power H-PSK

The *Ch. Power H-PSK* hotkey changes the power measurement application to measure the Channel Power of the access terminal.

Remote  
Control

```
INITiate:CDPower:CHPW
ABORt:CDPower:CHPW
STOP:CDPower:CHPW
CONTinue:CDPower:CHPW
FETCh[:SCALar]:CDPower:CHPW:STATUs?
```

### Measurement configuration

Pressing the *CDP/PCDEP/Ch.Power* softkey twice (once if already selected) opens the *Code Dom. Power Configuration* popup menu (see page 4.7). Besides, the measurement control softkey provides hotkeys to define the scope of the measurement. All these settings are also provided in the configuration menu and described in more detail in section [Analyzer/Generator Configuration – Control](#) on page 4.7 ff.

### Marker Display

The *Marker/Display* softkey positions up to three markers and a baseline (D-Line) in the test diagram and outputs their values. Refer to page 4.67 for detailed information about markers.

The softkey is only available for the following applications: *EVM H-PSK.*, *Magn. Err H-PSK* and *Phase Err H-PSK*.

### Result Order

The *Result Order* softkey is available for the applications *CDP H-PSK* and *PCDEP H-PSK* only. It allows the measurement results to be displayed in the Hadamard order or the BitReversed order.

## Common settings

As outlined in section [Analyzer/Generator](#) on p. 4.3 ff., some of the hotkey/softkey combinations in the *Analyzer/Generator* menu are valid irrespective of the application. These common settings are also provided in the [Connection Control](#) menu; for a detailed description refer to p. 4.47 ff.

### Softkeys

- The *Trigger/Analyzer Level* softkey defines the trigger settings for the measurements and controls the level in the RF signal path. The settings are provided in the *Trigger* and *Analyzer* tabs of the *Connection Control* menu; see sections [Trigger \(Connection Control – Trigger\)](#) on p. 4.63 ff. and [Analyzer Control \(Connection Control – Analyzer\)](#) on p. 4.48 ff.
- The *Analyzer Settings 1/2* softkey defines the center frequency of the RF analyzer. The settings are provided in the *Analyzer* tab of the *Connection Control* menu; see section [Analyzer Control \(Connection Control – Analyzer\)](#) on p. 4.48 ff.
- The *Generator Level/Impairment* softkey defines the levels in all physical channels of the generated forward 1xEV-DO signal and configures an additive noise signal. The settings are provided in the *Generator* tab of the *Connection Control* menu; see section [Connection Control – Generator](#) on p. 4.51 ff.
- The *Generator Settings/Power Control* softkey defines the frequency of the generated forward 1xEV-DO signal, its modulation and an offset of the PN sequence. The settings are provided in the *Generator* tab of the *Connection Control* menu; see section [Connection Control – Generator](#) on p. 4.51 ff.

### Settings table

The *Settings* table on the right side of the *Code Domain Power* menu gives an overview of the measurement settings of the current application as defined by means of the softkey/hotkey combinations or in the configuration menus. It changes when a different application is selected. The roll-key scrolls and expands the *Setup* table.

## Measurement Results

The CMU measures the code power of the access terminal's physical channels, resulting in the Code Domain Power measurement. Three applications are available for Code Domain Power measurements.

*Code Domain Power* (CDP) is the power of the individual Walsh code channels of the access terminal. The screen displays a bar graph of the power level of the individual channels. Both I and Q signal power is displayed. The evaluation is done in code class 16.

*Peak Code Domain Error Power* (PCDEP) is the measured I/Q signal compared to an ideal reference signal.

*Channel Power* (*Ch. Power H-PSK*) is the power of the reverse physical channels of both the I and Q signal.

Each Channel is divided into an *RR1* and a *Pilot* channel using a time slicing mechanism. *RR1* and *Pilot* channels are measured separately and are displayed in independent bars over the corresponding channel number.

Measurement results are explained for each application.

## Code Domain Power

Code Domain Power measures the individual power level of each code channel and presents the results as bar graphs. Both the I-Signal and Q-Signal power levels are displayed.

The measurement screen for Code Domain Power can be divided into three groups:

- Scalar measurement results (parameter lines)
- Bar Graph
- Measurements and Settings

Parameter lines  
1 and 2

Measurement bar  
graphs

Measurements and  
Settings




Figure 4-21 Display of measurement results (Code Domain Power screen)

**Parameter Lines** Scalar measurement results and settings are indicated in the two parameter lines above the test diagram and in the *Settings* table below.

1<sup>st</sup> Line

The first parameter line contains the following settings:

<i>RF Max. Level</i>	The total output power, either calculated in adaption to the signal level (Auto) or set manually.
<i>DRC</i>	The settings of the DRC channel filter
<i>ACK</i>	The settings of the ACK channel filter
<i>Data</i>	The settings of the Data channel filter
<i>Ch./Freq</i>	Channel and frequency set for the BS Signal

2<sup>nd</sup> Line


The second parameter line contains the following marker values:

<b>R</b>	Level and time of reference marker
<b>1</b>	Level and time of marker 1 (setting <i>absolute</i> ) and/or difference from reference marker (setting <i>relative</i> )
<b>2</b>	Level and time of marker 2 (setting <i>absolute</i> ) and/or difference from reference marker (setting <i>relative</i> )

**Measurement Bar Graphs**

The *Measurement bar graph* displays the power of each channel together with the limit lines and all active markers.

- The bar graph either shows the current, average, or maximum levels as set in the configuration menu.
- The limit lines provide a quick reference point to view channels exceeding set limits. The limit line level is set in the configuration menu.
- The *active* channels are indicated with a solid bar graph while the *inactive* are outlined (see the legend below the diagrams).



**Measurements and Settings**

The area below the bar graphs displays the results of power and waveform quality measurements. Measurements in red indicate they exceed the limit set in the configuration menu.

- AT Power *AT Power* is the total transmitted power level from the access terminal.
- Carrier Feedthrough *Carrier Feedthrough* refers to the origin offset, which is the magnitude of the RF carrier relative to the magnitude of the modulated carrier.
- Frequency Error *Frequency Error* is the difference between the nominal frequency of the selected channel and the measured frequency.
- Rho Rho is the ratio of the correlated power to the total power. The correlated power is a calculated vector between a corrected signal and an ideal reference. The corrected signal is created by removing phase, frequency, and timing offsets.
- Statistic Count *Statistic Count* defines the length of the statistic cycles in waveform intervals/evaluation periods.
- Out of Tolerance *Out of Tolerance* is the percentage of waveform intervals that exceed the defined limits.
- Settings The Settings window lists the most important settings made in either the Configuration Menu or the hotkeys.

Remote Control  
 READ[ :SCALar ] :CDPower :CDPW?  
 FETCh[ :SCALar ] :CDPower :CDPW?  
 SAMPlE[ :SCALar ] :CDPower :CDPW?

## Peak Code Domain Error Power

*Peak Code Domain Error Power* (PCDEP) displays the error signal over the code domain channels. The error is the difference between the measured signal and the ideal reference signal.

Besides all settings and results are analogous the *Code Domain Power* results described in section [Code Domain Power](#) on p. 4.37 ff.

Parameter lines  
1 and 2

Measurement bar  
graphs

Measurements and  
Settings



Figure 4-22 Display of measurement results (Code Domain Error Power screen)

## Channel Power

*Channel Power* (*Ch. Power H-PSK*) is the power of the reverse physical channels of both the I and Q signal.

The measurement screen for Code Domain Channel Power can be divided into three groups:

- Scalar measurement results (parameter lines)
- Bar Graph
- Measurements and Settings

Parameter lines 1 and 2

Measurement graph

Measurements and settings



Figure 4-23 Display of measurement results (Channel Power screen)

**Parameter Lines and Settings**

Scalar measurement results and settings are indicated in the parameter line above the test diagram and in the *Settings* table below.

The first parameter line and the *Settings* table is identical to the *Code Domain Power* application; see section [Code Domain Power](#) on p. 4.37 ff. The second parameter line is omitted as no markers are available.

**Measurement Bar Graphs**


The *Measurement bar graph* displays the power of each channel together with the limit lines.

The bar graph either shows the current, average, or maximum levels as set in the configuration menu.

The limit lines provide a quick reference point to view channels exceeding set limits. The limit line level is set in the Configuration Menu.

The *active* channels are indicated with a solid bar graph while the *inactive* are outlined (see the legend below the diagrams).

Below each bar graph is its measured value.



**Measurements and Settings**

This area displays the results of power and waveform quality measurements. Measurements in red indicate they exceed the limit set in the Configuration Menu.

The values are identical to the *Code Domain Power* application; see section [Code Domain Power](#) on p. 4.37 ff.

Remote Control

```
READ[ :SCALar ] :POWER :CHPW?
FETCh[ :SCALar ] :POWER :CHPW?
SAMPlE[ :SCALar ] :POWER :CHPW?
```

## Code Domain Power Configuration

The popup menu *Code Domain Power Configuration* contains tabs to define the parameters of each code domain power application including the error tolerances.

Pressing the measurement softkey twice (once if already selected) opens the popup menu *Code Domain Power Configuration*. Use the hotkeys at the bottom of the screen to change between the tabs. Use the roll-key to expand or compress the list of displayed settings.

### Code Domain Power Configuration – Control

The *Control* tab controls each of the measurement applications. Each application lists the available settings for controlling the measurement.

The control settings consist of *Common Settings* (settings that affect all code domain power applications) followed by settings specific to an application.




Figure 4-24 Code Domain Power Configuration – Control

All settings may not be available for all CDP measurement applications. The statistical settings *Repetition*, *Stop Condition*, *Statistic Count*, and *Display Mode* have the same meaning in all measurements; they are described in section [Analyzer/Generator Configuration – Control](#) on pg. 4.7 ff. The *Display Mode* applies to the values in the bar graphs only.

**Code Domain Power/  
Peak C.D. Error Power/**

**Results Order** *Results Order* defines the method used to display the code channels. This setting is only available for *Code Domain* and *Peak Code Domain Error* measurement applications.

*Hadamard* The code channels are displayed in the order determined by the Hadamard matrix. The codes are numbered as Walsh codes  $W_n^{SF}$ , where SF is the *Spreading Factor*; see below.

The reverse 1xEV-DO channels use fixed Walsh codes with SFs ranging from 2 to 32; see standard TIA/EIA/IS-856-2 and [Table 4-1](#) below. The Walsh code numbers n can be read directly from the measurement bar graphs. Channels with a SF < 32 (<16, if a *Spreading Factor* of 16 is selected) and therefore higher data rate are displayed with several active bars. .

*Bit reverse* The code channels are displayed in the order defined by the Orthogonal Variable Spreading Factor (OVSF) code tree so that related code channels are adjacent to each other. This ensures that high data rate channels with smaller SF are always displayed as one contiguous block.

**Remote Control**    CONFigure:CDPower:CDPW:CONTrol:RORDER  
 CONFigure:CDPower:PCDEP:CONTrol:RORDER  
 HADamard | BITReverse

Table 4-1 Walsh codes for reverse 1xEV-DO channels

Channel Type	Walsh Function
RRI	I-Signal $W_0^{16}$
Pilot	I-Signal $W_0^{16}$
ACK	I-Signal $W_4^8$
DRC	Q-Signal $W_8^{16}$
Data	Q-Signal $W_2^4$


**Walsh codes and OVSF codes**

According to standard TIA/EIA/IS-856-2, 1xEV-DO channels are spread using orthogonal Walsh functions  $W_n^{SF}$  that are serially constructed from a  $SF \times SF$  Hadamard matrix. Hadamard matrices can be generated by means of the following recursive procedure:

$$H_1 = 0, \quad H_2 = \begin{bmatrix} 0 & 0 \\ 0 & 1 \end{bmatrix}, \quad H_{2N} = \begin{bmatrix} H_N & H_N \\ H_N & \overline{H_N} \end{bmatrix};$$

where  $N$  is a power of 2 and  $\overline{H_N}$  denotes the binary complement of  $H_N$ .

Orthogonal Variable Spreading Factor codes provide an alternative scheme of generating codes that preserve orthogonality between channels with different rates and spreading factors. According to standard 3GPP TS 25.213, they are generated using the following code tree:



For a given spreading factor  $SF$ , Walsh codes and OVSF codes can be derived from each other by assigning code numbers in binary format. The Walsh code no.  $n$  is equal to the OVSF code number  $m$  and vice versa, provided that  $m$  and  $n$  have inverse binary representation ( $n$  is converted into  $m$  by reversing the order of bits in the binary representation of  $n$ ). For numbers with symmetrical binary representation (e.g. 00 or 1001), the Walsh code and OVSF code numbers are equal.

E.g. for spreading factor  $SF = 4$ , the two schemes provide the following codes:

Hadamard (Walsh codes)			Bit reverse (OVSF codes)		
Code (SF = 4)	Code number Dec.	Code number Binary	Code (SF = 4)	Code number Dec.	Code number Binary
0 0 0 0	0	00	0 0 0 0	0	00
0 1 0 1	1	01	0 0 1 1	1	01
0 0 1 1	2	10	0 1 0 1	2	10
0 1 1 0	3	11	0 1 1 0	3	11

To obtain the *Bit reverse* representation from the *Hadamard* representation, the codes no. 01 and 10 (binary) must be interchanged.

**Code Domain Power Configuration – Limits**

The *Limits* tab defines tolerance limits for each of the Code Domain Power measurement applications.

The limits settings consist of both Common settings (settings that affect all code domain power applications) and then settings specific to an application.




Figure 4-25 Code Domain Power Configuration – Limits

**Default All Settings**

The *Default All Settings* switch assigns default values to all parameters of the modulation *Limits* tab (the default values are quoted in the command description in chapter 6 of this manual). Additional default switches are provided for common limit settings and for the individual applications.

Remote control

```
DEFault:CDPower:<Application>:LIMit ON | OFF
```

**Common Settings**

*Common Settings* are settings that affect all code domain power applications.

**Current & Max**

Sets the limits used when the display is set to the *Current* or *Min/Max* display mode.

Carrier Feedthr.

Upper limit for the difference between magnitude of the RF carrier and the modulated carrier.

Frequency Error

Upper limit for the difference between the measured and the expected frequency of the signal.

Rho

Upper limit of the ratio of the correlated power and the total power.

Remote Control

```
CONFigure:CDPower:CPCCommon:CMAx:LIMit:ASYMmetric  
[:COMBined]  
<Carrier Feedthrough Limit>, <Freq Error Limit>, <Rho Limit>
```

**Average**

Sets the limits used when the display is set to the *Average* display mode. The available settings are the same as described for the *Current & Max* display mode.

Remote Control

```
CONFigure:CDPower:CPCCommon:AVErAge:LIMit:ASYMmetric  
[:COMBined]  
<Carrier Feedthrough Limit>, <Freq Error Limit>, <Rho Limit>
```

**CDP**

*CDP* contains the limit settings applicable to the *Code Domain Power*.

**IQ Leakage Check**

The *IQ Leakage* check allows to set if the leakage of an active channel is being checked by the limit on the opposite Signal phase. If *IQ Leakage Check* is on and the Q-Signal of a channel which is active on the I-Signal (or vice versa) exceeds the limit, a limit violation will be displayed.

Current & Max	Sets the limits used when the display is set to the Current or Min/Max display mode.
CDP Limit	Value (and placement) of the limit line displayed on the measurement screen.
Remote Control	<pre> CONFigure:CDPower:CDPW:CMax:LIMit:ASYMmetric [:COMBined] &lt;CDP Limit Y&gt; </pre>
Average	Sets the limits used when the display is set to the Average display mode. The available settings are the same as described for the Current & Max display mode.
Remote Control	<pre> CONFigure:CDPower:CDPW:AVERage:LIMit:ASYMmetric [:COMBined] &lt;CDP Limit Y&gt; </pre>
<b>PCDEP</b>	<i>PCDEP</i> contains the limit settings applicable to the <i>Peak Code Domain Error Power</i> . The available settings are the same as described for the <i>CDP</i> .
Remote Control	<pre> CONFigure:CDPower:PCDEP:CMax:LIMit:ASYMmetric [:COMBined] CONFigure:CDPower:PCDEP:AVERage:LIMit:ASYMmetric [:COMBined] &lt;CDP Limit Y&gt; </pre>
<b>CHP</b>	<i>CHP</i> contains the limit settings applicable to the <i>Channel Power</i> . The available settings are the same as described for the <i>CDP</i> .
Remote Control	<pre> CONFigure:CDPower:CHPW:CMax:LIMit:ASYMmetric [:COMBined] CONFigure:CDPower:CHPW:AVERage:LIMit:ASYMmetric [:COMBined] &lt;CDP Limit Y&gt; </pre>

## Connection Control

The *Connection Control* menu consists of tabs to configure the inputs and outputs of the CMU and the respective signals in the function group *1xEV-DO*, define the network standard, the trigger settings and the routing of I/Q and IF signals.

The menu group is activated using the softkey *Connect Control* to the right of the header of the measurement menu. The individual tabs (*Standard*, *Analyzer*, *Generator*, *AF/RF*  $\oplus$ , *Sync.*, *Trigger*, *I/Q-IF*) can be accessed using the hotkeys at the bottom of the screen.

### Network Standard (Connection Control – Standard)

The popup menu *Standard* defines which network and standard is used for testing.




Figure 4-26 Connection Control – Standard

Refer to Table 1-1 in Chapter 1 for a list of the supported 1xEV-DO networks.

### Analyzer Control (Connection Control – Analyzer)

The *Analyzer* tab configures the RF input path by defining the analyzer level and frequency.




Figure 4-27 Connection Control – Analyzer Settings

**Default All Settings**

The *Default All Settings* switch assigns default values to all settings in the *Analyzer* tab (the default values are quoted in the command description in chapter 6 of this manual).

```
Remote control
DEFault:RFANalyer
```

**Analyzer Level – RF Mode**

The *Analyzer Level* table section sets the maximum input level that can be measured. Two alternative *RF Modes* for defining this value are provided:

- Manual* Manual input of maximum input level in the *RF Max. Level* field
- Auto* Automatic setting of maximum input level (*autoranging*) according to the peak power (PEP) of applied signal

```
Remote control
[SENSe:]LEVeL:MODE MANual | AUTomatic
```

**Analyzer Level – RF Manual Max. Level**

The maximum expected input level can be entered in the *RF Max. Level* input field. Input levels exceeding the *RF Manual Max. Level* overdrive the input path and cause invalid results (“--”).

```
Remote control
[SENSe:]LEVeL:MAXimum <Level>
```

**External input attenuation**

The range of *RF Max. Level* values depends on the RF input used. If an external input attenuation is reported to the instrument to compensate for a known path loss

(see section [AF/RF Connectors \(Connection Control – AF/RF\)](#) on page 4.58), all levels measured are referenced to the output of the DUT and therefore shifted with respect to the actual level at the input connectors of the CMU. The level ranges for the input connectors are shifted as well.

Error messages If the *RF Max. Level* is too high or too low, a window with the error message "*<Max\_Level> is out of range. <permissible max. value> is limit.*" and three fields will appear:

*Accept* The permissible max. value is accepted as *RF Max. Level*,

*Re-edit* *RF Max. Level* is entered once again,

*Cancel* The last valid input value is maintained.

When switching over to another input, the current value of *RF Max. Level* is automatically adapted, if required:

- Towards lower values to the maximum value of the new input,
- Towards upper values to the minimum value of the new input.

**Note:** *A maximum input level can be entered even if automatic level setting (autoranging) is selected. The entered level is used as a start value for the autoranging routine and is also important to ensure safe switchover to manual setting.*

#### Analyzer Settings – RF Channel [<>]

*RF Channel* defines the base station channel number (and frequency) of the generated RF signal. The brackets contain the current bandclass of the selected network.

The default settings for the channel numbers depend on the network selected. Changing the *RF Channel* also changes the *RF Frequency* setting.

Table 1-1 in Chapter 1 lists the networks and standards supported by the CMU with the 1xEV-DO options.

Remote control

```
[SENSe:]RFANalyzer:FREQuency:UNIT
```

```
[SENSe:]RFANalyzer:FREQuency <Frequency>
```

#### Frequency Offset

*Frequency Offset* determines a frequency offset to impair the RF analyzer signal.

Remote control

```
[SENSe:]RFANalyzer:FOfFset <Analyzer Freq. Offset>
```

#### Long Code Mask I/Q

*Longcode Mask* determines the used *I/Q-Long Code Masks* for the 1xEV-DO signal. In order of the measurements to work both long code masks have to be set according to the R-Signal

Remote control

```
[SENSe:]RFANalyzer:LCMask:I:LSB <HexString[8chars]>
```

```
[SENSe:]RFANalyzer:LCMask:I:MSB <HexString[3chars]>
```

```
[SENSe:]RFANalyzer:LCMask:Q:LSB <HexString[8chars]>
```

```
[SENSe:]RFANalyzer:LCMask:Q:MSB <HexString[3chars]>
```

#### Code Channel Filter DRC

*Code Channel Filter DRC* determines if the Analyzer should analyze the incoming signal based on the presence of the DRC channel. As the DRC, ACK, and Data code channels are not continuously present, the

measurement system allows the user to specify the conditions under which the measurement is performed. If these filters are specified in such a manner that the AT never generates, no measurements will be made. On the other hand, if one (or more) filter settings are „Don't care“, measurements will be made both with the channel is present and when it is not present. This may lead to confusing and/or rapidly changing results.

The following table shows the expected behavior according to the settings and the real signal.

Code Channel Setting AT	Code Channel Setting CMU	Expected Result
OFF	OFF	Valid Result
OFF	DON'T CARE	Valid Result
OFF	ON	No Result
ON	OFF	No Result
ON	DON'T CARE	The <i>I/Q Analyzer</i> will display results from two (or more) different types of waveforms. This can cause the display to appear very confused or erratic (for example it seems to be toggling or blinking).
ON	ON	Valid Result

If the actual setting is unknown, it is a good idea to set all three Code Channels to “DON'T CARE” and analyze the result using the *I/Q Analyzer* measurement (*I/Q Analyzer* on pg. 4.22) to determine the current setting of the incoming signal.

Remote control

[SENSe:]RFANalyzer:CCFilter:DRC ON | OFF | DCARe

**Code Channel Filter ACK**

*Code Channel Filter ACK* determines if the Analyzer should analyze the incoming signal based on the presence of the ACK channel.

Remote control

[SENSe:]RFANalyzer:CCFilter:ACK ON | OFF | DCARe

**Code Channel Filter Data**

*Code Channel Filter Data* determines if the Analyzer should analyze the incoming signals based on the presence of the DRC channel.

Remote control

[SENSe:]RFANalyzer:CCFilter:DATA ON | OFF | DCARe

**Reverse Link Frame Offset AT1-4**

*Reverse Link Frame Offset AT1-4* specifies the Frame Offset timing of the Reverse Link signal from the specified access terminal. Since the 1xEV-DO option does not actually control the access terminal, it is the responsibility of the operator to ensure that the value established by this command matches the frame offset that is used by the access terminal. In addition, this value affects the timing of the *Rev Frame Trigger* for the specific user.

The Generator Settings for *DRC Lock State*, *DRC Lock Period* and *DRC Lock Length* are displayed in the same line for each Access Terminal.

Remote control

[SENSe:]RFANalyzer:AT\$4\$:RLINK:FROffset <Value>|MIN|MAX|DEF

### Connection Control – Generator

The popup menu *Generator* provides the settings for:

- 1xEV-DO Generator [Option B88]
- IQ-Access Interface Setup [Option B82]

Generator and IQ-Access-Board can be switched alternately to ON or OFF or both to OFF. In order to switch the IQ-Access-Board on, the hardware option B-82 has to be installed in the CMU.

### Generator Control (Connection Control – Generator)

The Generator control tab allows the setting of all signals generated by the CMU.




Figure 4-28 Connection Control – Generator (table)

**Generator Control** The *Generator Control* switch indicates the operating status of the RF generator (*ON* or *OFF*). Selecting the *Generator* switch and the *ON/OFF* key switches the generator on or off. The *IQ-Access Interface Control* switch will be toggled with the *Generator Control* switch, since both modules can't operate at the same time.

```
Remote control
INITiate:RFGenerator
ABORt:RFGenerator
FETCh:RFGenerator:STATUs?
```

**Default Settings** The *Default Settings* switch assigns default values to all settings in the *Generator* tab (the default values are quoted in the command description in chapter 6 of this manual).

```
Remote control
DEFault:RFGenerator ON | OFF
```

- Output Power**      *Output Power* displays the total 1xEV-DO output power generated by the CMU
- Remote control  
 SOURCE:RFGenerator:POWer:OUTPut[?]
- RF Channel [<>]**      The *RF Channel* sets the base station channel number (and frequency) of the generated RF signal. Changing the RF Channel resets the RF Frequency setting. The default settings for the channel numbers are dependent on the network selected.
- Remote control  
 SOURCE:RFGenerator:FREQuency [:RF]:UNIT[?]  
 SOURCE:RFGenerator:FREQuency[:RF][?]
- PN Offset**              *PN Offset* sets the offset of the PN sequence. Changing the PN offset changes the timing of the short code spreading, the contents of the Sync message on the Control Channel.
- Remote control  
 SOURCE:RFGenerator:PROPerTy:PNOffset[?]
- Generator Mode**      *Generator Mode* sets the operating mode of the generator. Possible values are *Normal* and *Continuous Pilot*. In *Continuous Pilot* mode, the 1xEV-DO generator will generate a continuous pilot signal. The pilot signal will fill the entire slot. During this special mode, all other commands will be accepted and processed as normal, but the changes to the signal output will not occur until this special mode is disabled.
- Remote control  
 SOURCE:RFGenerator:PROPerTy:PNOffset[?]
- Impairments–  
AWGN Level**              *AWGN Level* turns on or off the Additive White Gaussian Noise generator and sets the level for modulation. This provides noise to more closely simulate actual operating conditions in the network.
- 
- Note:*                      *The total output power of the CMU is the sum of the Forward 1xEV-DO signal plus the AWGN signal. The CMU automatically limits the AWGN signal level so that the maximum possible total output power of the CMU's RF connector is not exceeded.*
- 
- Remote control  
 SOURCE:IMPairments:LEVel:AWGN <AWGN Level>
- Impairments–  
BS Freq. Offset**          *BS Freq. Offset* adjusts the carrier frequency of the CMU/base station. If the *RF Frequency* has been set to a frequency which doesn't apply to the actual selected *RF Channel*, the setting of *BS Freq. Offset* is disabled.
- Remote control  
 SOURCE:IMPairments:FOffset[:RF] <Freq. Offset>

**Traffic – Control – Sync. Message Enable** *Sync. Message Enable* allows the generator to create a synchronization message on the Control Channel.

Remote control  
 INIT:RFGenerator:SNcMessage  
 ABORT:RFGenerator:SNcMessage  
 FETCh:RFGenerator:SNcMessage:STATUs?

**Traffic – Control – Packet Start Offset** *Packet Start Offset* defines when the generator should create the Sync message on the Control Channel. The offset value is measured in the number of slots from the first slot of the Control Channel Cycle, the range of values is 0 to 3, inclusive.

Remote control  
 SOURce:RFGenerator:SNcMessage:PSOffset[?]

**Traffic – Control – Data Rate** *Sync. Message* defines the type of synchronization message on the traffic channel. It specifies a choice between the DRC Indexes 1 and 2. The table for the assignment of the DRC Indexes to the data rate and the number of slots can be found below in this table in the description of the Data Rate for the AT1-AT4 channels.

Remote control  
 SOURce:RFGenerator:SNcMessage:DRINdex[?]  
 SOURce:RFGenerator:SNcMessage:DRATE?

**Traffic – AT1..4 – Access Terminal Enable** The CMU supports the generation of data for up to 4 access terminals at the same time. *Access Terminal Enable* specifies the ON/OFF state of the each of the four data streams.

Remote control  
 INIT:RFGenerator:AT\$4\$:MAC:INDeX  
 ABORT:RFGenerator:AT\$4\$:MAC:INDeX  
 FETCh:RFGenerator:AT\$4\$:MAC:INDeX:STATUs?

**Traffic – AT1..4 – MAC Index** *MAC Index* specifies the MAC Index of the specified access terminal. MAC Index values of 5 to 63, inclusive are permitted. Each of the four access terminals must use a unique MAC Index.

Remote control  
 SOURce:RFGenerator:AT\$4\$:MAC:INDeX[?]

**Traffic – AT1..4 – MAC AT x Level** *MAC AT 1 Level* specifies the level relative to the generator output power for each of the AT channels. The range of level values are –7.0 to –25.0 dB, inclusive.

Remote control  
 SOURce:RFGenerator:AT\$4\$:MAC:LEVeL[?]

**Traffic – AT1..4 – Send Packets** *Send Packets* starts the transmission of Traffic Packets to the specified access terminal by pressing the *ENTER* button on the CMU keyboard. The *State* field can have the states OFF and RUN. The *Progress* field shows the progress of transmission.

Remote control  
 INIT:RFGenerator:AT\$4\$:PSTReam  
 ABORT:RFGenerator:AT\$4\$:PSTReam  
 FETCh:RFGenerator:AT\$4\$:PSTReam:STATUs?

**Traffic – AT1..4 – Packet Count** – *Packet Count* specifies the number of packets to be sent to the specified access terminal. If “infinite” is selected a continuous stream of packets will be sent.

Remote control  
 SOURCE:RFGenerator:AT\$4\$:PCOUNT[?]

**Traffic – AT1..4 – Packet Start Offset** – *Packet Start Offset* specifies the amount of time (in slots) from the end of the last packet (sent to the specified access terminal) to the start of the next packet (sent to the specified access terminal). Values of 0 to 255, inclusive are permitted.

Remote control  
 SOURCE:RFGenerator:AT\$4\$:PSOFFSET[?]

**Traffic – AT1..4 – Data – Rate** – *Rate* specifies the DRC Index of the forward traffic for a specific access terminal. The data rate and the number of slots within the packet are specified by the DRC Index, as described in the following table:

Index	Rate [kBit/s]	#Slots
1	38.4	16
2	76.8	8
3	153.6	4
4	307.2	2
5	307.2	4
6	614.4	1
7	614.4	2
8	921.6	2
9	1228.8	1
10	1228.8	2
11	1843.2	1
12	2457.6	1

Remote control  
 SOURCE:RFGenerator:AT\$4\$:DRINDEX[?]  
 SOURCE:RFGenerator:AT\$4\$:DRATE?

**Traffic – AT1..4 – Data - Pattern** – *Pattern* specifies a data pattern to be used within the forward link packets to a specific access terminal. The data consists of 32 bits, or 4 bytes. This pattern is repeated within the packet. The most significant bit is the first bit within the packet.

Remote control  
 SOURCE:RFGenerator:AT\$4\$:PATTERN[?]

**Traffic – AT1..4 – Power Control – Power Ctrl. Bits** – *Power Control Bits* defines how the power control bits are sent from the CMU to the specified access terminal. The power control bits control the access terminal's total output power (when the access terminal is using closed loop power control).

<i>Range Test</i>	The CMU sends a sequence of <i>up</i> power bits followed by a sequence of <i>down</i> power bits. The number of bits up and down are configurable.
<i>All Up</i>	The CMU sends only <i>up</i> power control bits.
<i>All Down</i>	The CMU sends only <i>down</i> power control bits. This may cause the access terminal's power level to decrease to a level too low for measurements to be made.
<i>Hold</i>	The CMU sends alternating <i>up/down</i> power control bits.
<i>Pattern</i>	A user defined pattern of power control bits will be sent by the CMU. This pattern is divided in 4 areas of power control bits which are described in the following <i>Pattern</i> parameters below.  For each area a user defined number of <i>Up</i> or <i>Down</i> bits can be defined and sent by the CMU.
<i>External (AUX3/4 – Pin 6)</i>	The state of Pin 6 of the CMU AUX3/4 connector is sampled at the start of the slot and used as the power control bit.

Remote control

SOURCE:RFGenerator:AT\$4\$:PCBits[?]

**Traffic – AT1..4 – Power Control – Range Test – Range Test Count** – *Range Test Count* sets the number of Power Control Bits to be used to perform the Range test. E.g. a value of 100 means that 100 *UP* bits are sent followed by 100 *DOWN* bits.

Remote control

SOURCE:RFGenerator:AT\$4\$:PCBits:RTES:NOBits[?]

**Traffic – AT1..4 – Power Control – Pattern – Inject Pattern** – *Inject Pattern* starts the injection of a power control bit pattern into the Power Control Bit stream. The configuration of the pattern is defined by the configuration fields below. This is the same pattern as may be selected by the pattern mode described above.

After activation, the button *Inject Pattern* remains disabled until the complete pattern has been sent. Only then can another pattern be sent.

The injection of the pattern starts only at the end of the current power control sequence.

Remote control

PROCEDURE:RFGenerator:AT\$4\$:PCBits:PATTERN <InjectStatus>

**Traffic – AT1..4 – Power Control – Pattern – Area 1..4 – Number of Bits** – *Number of Bits* defines the number of bits in the Area of the user defined pattern for a specific access terminal.

Remote control  
 SOURCE:RFGenerator:AT\$4\$:PCBits:PATtern:AREA\$1..4\$:NOBits[?]

**Traffic – AT1..4 – Power Control – Pattern – Area 1..4 – Polarity** *Polarity* defines the orientation of all power control bits in this area of the pattern for a specific access terminal. Possible values are *Up* or *Down*.

Remote control  
 SOURCE:RFGenerator:AT\$4\$:PCBits:PATtern:AREA\$1..4\$:POLarity[?]

**Traffic – AT1..4 – DRCLock – DRCLock State** The state of the *DRCLock* indicates to the access terminal the ability of the base station to receive its DRC channel. If the *DRCLOCK* state is 0, the access terminal will not request data from base station. Possible values are 0 and 1. The default value is 0. In the same line the current Analyzer Settings for the *Reverse Link Frame Offset* are displayed.

Remote control  
 SOURCE:RFGenerator:AT\$4\$:DRCLock:STATe[?]

**Traffic – AT1..4 – DRCLock – DRCLock Period** *DRCLock Period* defines period of DRCLock bit transmissions, in terms of slots. Possible values are OFF, 8 and 16. When DRCLock Period is set to OFF, the DRCLock bits are not transmitted.

Remote control  
 SOURCE:RFGenerator:AT\$4\$:DRCLock:PERiod[?]

**Traffic – AT1..4 – DRCLock – DRCLock Length** *DRCLock Length* defines how often the *DRCLock* bit will be transmitted, before it is updated with the DRCLock State. Possible values are 1, 4, 8, 16, and 32 and are expressed in terms of DRCLock Periods.

Remote control  
 SOURCE:RFGenerator:AT\$4\$:DRCLock:LENGth[?]

**Reverse Activity – MAC RAB Level** *MAC RAB Level* specifies the level for the reverse activity channel relative to the generator output power. The range of level values are –7.0 to –25.0 dB, inclusive.

Remote control  
 SOURCE:RFGenerator:RAB:MAC:LEVeL[?]

**Reverse Activity – RAB State** *RAB State* sets the value for the bit within the Reverse Activity channel. This channel is an indicator to the access terminal from the access network to reduce the transfer rates used on the reverse link. A value of zero, indicates normal network conditions, a value of 1 indicates that the access terminal may need to reduce its reverse link transfer rates. Possible values are 0 and 1.

Remote control  
 SOURCE:RFGenerator:RAB:STATe[?]

**Reverse Activity – RAB Offset** *RAB Offset* defines the starting position of the Reverse Activity (RA) bit. The starting position is specified in RABLength/8 units. The RA bit starts when the equation (SystemTime mod RABLength = RABOffset) is satisfied, with SystemTime expressed in units of slots. Possible values are 0 to 7, inclusive.

Remote control  
 SOURCE:RFGenerator:RAB:OFFSet[?]

**Reverse Activity – RAB Length** *RAB Length* defines the length (in slots) of a Reverse Activity (RA) bit. Possible values are 8, 16, 32 and 64.

Remote control  
 SOURCE:RFGenerator:RAB:LENGth[?]

**Other AT's – Count** *Other AT's – Count* defines the number of additional MAC Indexes that are in use within the MAC. No traffic is generated for these MAC Indexes, they are used only to construct a realistic MAC. Possible values are 1 to 55, inclusive.

Remote control  
 SOURCE:RFGenerator:OAT:COUNT[?]

### Generator Control (Connection Control – Generator – IQ-Access Interface)

The Generator control tab – IQ-Access Interface Setup allows the setting of all the settings for the IQ Access board.




Figure 4-29 Connection Control – IQ-Access Interface Setup

**IQ-Access Interface Control** The *IQ-Access Interface Control* controls the IQ-Access board operation. Pressing the *IQ-Access Interface Control* softkey switches the IQ-Access board ON or OFF. The *IQ-Access Interface Control* switch will be toggled with switching the *Generator Control*.

Remote control  
 INITiate: IQACcess  
 ABORt: IQACcess  
 FETCh: IQACcess: STATus?

**Default Settings** The *Default Settings* switch assigns default values to all settings in the *IQ-Access Interface Control* tab (the default values are quoted in the command description in chapter 6 of this manual).

Remote control  
 DEFault: IQACcess: CONTRol[?]

**Rx IQ Swap** *Rx IQ Swap* allows to switch the I/Q channels of the Receiver. This is useful if the signaling unit permutes the signals.

Remote control  
 CONFigure: IQACcess: RXSWap[?]

**Timing Control** *Timing Control* sets the timing and clock polarity control over Tx I/Q data. Bits 0-2 supply timing information. If bit 3 is set to “1”, external data is clocked on the negative edge of the CHIP16 clock, if set to “0”, then the positive edge of the clock is used.

Remote control  
 CONFigure: IQACcess: GMULTiplier[?]

**Gain Multiplier** *Gain Multiplier* sets the gain multiplier value for Tx I/Q data supplied to the access board. Possible values are 0, 1, 2, 4, 8 and 16.

Remote control  
 CONFigure: IQACcess: TCONTRol[?]

### AF/RF Connectors (Connection Control – AF/RF)

The *AF/RF*  tab configures the connectors for RF signals. This includes defining:

- The RF input and output of the CMU (*RF Output*, *RF Input*).
- External attenuation at the connectors (*Ext. Att. Output*, *Ext. Att. Input*).

The tab also controls the wideband peak power measurement (*Wideband Power*) and indicates the result.




Figure 4-30 Connection Control – RF connectors

**RF Output**

The *RF Output* softkey defines which of the three connectors RF 1, RF 2 and RF 3 OUT is to be used as the RF output connector. The symbol  $\odot$  indicates the selected RF output.

*Note:* Input and output connectors can be arbitrarily combined. The bi-directional connectors RF 1 and RF 2 can be selected as RF inputs and outputs at the same time. The front panel LEDs are on (lit) if the generator is switched on or the modulation test is started.

Remote control


```
OUTPut[:STATe] RF1 | RF2 | RF3
```

**Ext. Att. Output**

The *Ext. Att. Output* softkey defines an external attenuation (or gain, if the value is negative) at the selected RF output.

External attenuation is required if attenuation (such as a cable) is included in the test setup path, which is to be corrected by an increased signal level.

If an external attenuation is defined, the output signal level is referenced to the input of the device under test (DUT), the generator level is therefore shifted with respect to the actual level at the output connector of the CMU. The default value for the generator power and the level ranges for the RF outputs are also shifted provided that the generator can output the required power, compensating for the external attenuation or gain. Otherwise it is adapted to the level closest to the shifted default value.



Remote control

```
[SENSe:]CORRection:LOSS:OUTPut<nr>[:MAGNitude]
SOURce:CORRection:LOSS:OUTPut<nr>[:MAGNitude]
```

**RF Input**

The *RF Input* softkey defines which of the three connectors RF 1, RF 2, or RF 4 IN is to be used as the RF input connector. The symbol ⊕ indicates the selected RF input.

*Note:* Input and output connectors can be arbitrarily combined. The bi-directional connectors RF 1 and RF 2 can be selected as RF inputs and outputs at the same time. The front panel LEDs are on (lit) if a measurement is active.

Remote control


```
INPut[:STATe] RF1 | RF2 | RF4
```

**Ext. Att. Input**

The *Ext. Att. Input* softkey sets the value of the external attenuation (or gain) at the selected RF input.

Input of an external attenuation is required if, for example, external attenuator pads are used for protection of the sensitive RF inputs of the CMU or if path attenuation is included in the test setup.

If an external input attenuation is reported to the instrument, all levels measured are referenced to the output of the DUT and therefore shifted with respect to the actual level at the input connectors of the CMU. The level ranges for the input connectors are shifted as well.



Remote control

```
[SENSe:]CORRection:LOSS:INPut<nr>[:MAGNitude]
SOURce:CORRection:LOSS:INPut<nr>[:MAGNitude]
```

**Wideband Power**

The *Wideband Power* softkey controls the wideband power measurement and indicates its status (*RUN | HLT | OFF*). The status can be changed after softkey selection (pressing once) by means of the *ON/OFF* key or the *CONT/HALT* key. The measurement result is in units of dBm. The analog bar to the right of the softkey shows the measured power relative to the *RF Max. Level* (see section [AF/RF Connectors \(Connection Control – AF/RF\)](#) on page 4.58): The display range is between *RF Max. Level – 10 dB* and *RF Max. Level + 10 dB*.

The wideband power measurement is performed at the RF Frontend of the CMU and yields the peak power of the input signal inside a wide frequency range. It is most accurate in the input level range around 0 dBm (typically –10 dBm to +30 dBm on RF2). The main purpose of the wideband power measurement is to indicate whether an input signal is available and whether it is advisable to change the *Max Level* settings.

```
Remote control
INITiate:WPOwer
FETCh:WPOwer:STATus?
READ[:SCALar]:WPOwer?
FETCh[:SCALar]:WPOwer?
SAMPle[:SCALar]:WPOwer?
```

**Reference Frequency (Connection Control – Sync.)**

The popup menu *Sync.* defines the reference signals for synchronization. This includes:

- The internal or external Reference Frequency
- The output mode for the network-specific system clock (REF OUT 2)




Figure 4-31 Connection Control – Synchronization

**Reference Frequency**

The *Reference Frequency* softkey determines the source and the frequency of the reference signal. Two selections are available.

- Int. (10 MHz)*      The internal 10 MHz clock signal (TCXO or OCXO, CMU-B11/-B12) is used for synchronization. This signal is available at the REF OUT 1 connector at the rear of the instrument.
- Ext. (at REF IN)*      An external reference signal is to be supplied to the REF IN connector. The frequency of the external reference signal must be entered in the input field.

The reference signal used is available at the REF OUT 1 output connector at the rear of the instrument making it available for use by other instruments.

**Notes:**

*With external synchronization selected, a warning message cycles on and off if no synchronization has been performed e.g. because of missing or faulty input signal. At the same time, bit no. 6 (RFNL, Reference Frequency Not Locked) is set in the STATUS:OPERation:CMU:SUM1:CMU1 sub-register associated to the CMU base system and the query [SENSe:]SYNChronize:FREQuency:REFerence:LOCKed? returns the value ON.*

*In the case of external synchronization with squarewave signals (TTL) ensure correct signal matching to avoid reflections. Otherwise, resulting overshoots may cause trigger problems at the CMU input. A possible remedy is to use a lowpass filter or an attenuator pad directly at the CMU input. Correct synchronization may be checked by comparing the signal REF OUT 1 or REF OUT 2 with the input signal.*

*This configuration is valid in all CMU function groups.*

Remote control

The commands for the reference frequency are part of the CMU base system (see CMU200/300 operating manual):

```
CONFigure:SYNChronize:FREQuency:REFerence:MODE
    INTERNAL | EXTERNAL
CONFigure:SYNChronize:FREQuency:REFerence <Frequency>
[SENSe:]SYNChronize:FREQuency:REFerence:LOCKed?
```

**REF  
OUT 2**

The REF OUT 2 softkey configures a network-specific system clock available at the REF OUT 2 output connector at the rear of the instrument. The associated field allows selection between two settings:

- OFF (other network)*      The clock frequency of another active function group is made available at the REF OUT 2 connector instead of the current function group. The REF OUT 2 must be switched on in the other function group.
- On (current network)*      The network-specific system clock of the current function group is available at the REF OUT 2 output connector.

The clock frequency can be used to synchronize other instruments.

Remote control

```
SOURce:DM:CLOCK:STATE ON | OFF
SOURce:DM:CLOCK:FREQuency <Frequency>
```

### Trigger (Connection Control – Trigger)

The *Trigger* tab is part of the second group of tabs in the *Connection Control* menu. It is accessible after pressing the 1/2 toggle hotkey once. Pressing 1/2 again switches back to the first group of tabs described above.

The *Trigger* tab defines the trigger condition for the measurement and the routing of output trigger signals.




Figure 4-32 Connection Control – Trigger

**Default Settings** The *Default Settings* checkbox assigns the default setting to all functions in the *Trigger* tab (the default values are quoted in the command description in chapter 6 of this manual).

Remote control  
 DEFault:TRIGger[:SEquence][?]

**AT Selection** Only one Access Terminal at a time can be supported by the Trigger. *AT Selection* allows to choose one of the four supported Access Terminals.

Remote control  
 TRIGger:SElect:AT[?]

**Input – Source** *Source* sets the CMU200 to use its internal signal trigger source or use an external trigger supplied via the AUX 3 connector on the front panel.

The trigger setting affects the results of the *Transmit Time Error* measurement as described here.

- Free Run* No trigger. Timing error results are not possible.
- Internal* Timing error results are possible when DUT is correctly synchronized with the CMU. An output frame trigger signal can be routed to pins 2 to 5 of AUX 3; see below.
- External* Timing error results are possible if an external trigger

	signal is provided and the DUT is correctly synced with the CMU.																		
<i>RF Power</i>	Timing error results are not possible.																		
<i>IF Power</i>	Timing error results are not possible.																		
Remote control																			
	TRIGger[ :SEquence ] :SOURce[ ? ]																		
<b>Input – External</b>	<i>External</i> indicates that the external trigger signal is to be applied to <i>Pin 8</i> of the AUX 3 connector. This holds for all three modulation schemes.																		
<b>Input – Slope</b>	Allows the setting of which edge of the trigger signal should be interpreted as the actual trigger. The possible values are “Falling Edge” and “Rising Edge”.																		
Remote control																			
	TRIGger[ :SEquence ] :SLOPe[ ? ]																		
<b>Input – RF Power – Trigger Level</b>	Sets the RF Power level a signal burst has to reach to be interpreted as a incoming trigger. A setting too high results in no trigger at all, a setting to low doesn’t allow the measurement to identify any trigger. In both cases the measurement results will be invalid.																		
Remote control																			
	TRIGger[ :SEquence ] :THReshold:RFPower[ ? ]																		
<b>Input – IF Power – Trigger Level</b>	Sets the IF Power level a signal burst has to reach to be interpreted as a incoming trigger. A setting too high results in no trigger at all, a setting to low doesn’t allow the measurement to identify any trigger. In both cases the measurement results will be invalid.																		
Remote control																			
	TRIGger[ :SEquence ] :THReshold:IFPower[ ? ]																		
<b>Output – Routing</b>	The <i>Routing</i> functions select the type of periodic pulse signal (or no signal, setting <i>NONE</i> ) to be applied to pins 2, 3, 4,and 5 of the AUX 3 connector. The output frame trigger is available if the <i>Internal</i> trigger source is selected and the RF generator is switched on. It consists of a high-pulse TTL signal with its rising edge at the beginning of the frames of the forward signal.																		
	The CMU provides output trigger signals with the following periodicity:																		
	<table border="0"> <tr> <td><i>None</i></td> <td>---</td> </tr> <tr> <td><i>PP2S</i></td> <td>2.00 s</td> </tr> <tr> <td><i>Ctrl. Channel</i></td> <td>426.67 ms</td> </tr> <tr> <td><i>Ctrl. Slot</i></td> <td>&lt;variable&gt;</td> </tr> <tr> <td><i>AT Rev. Frame</i></td> <td>26.67 ms</td> </tr> <tr> <td><i>AT Fwd. Slot</i></td> <td>&lt;variable&gt;</td> </tr> <tr> <td><i>Slot</i></td> <td>1.67 ms</td> </tr> <tr> <td><i>PwrCtrlPattern</i></td> <td>&lt;variable&gt;</td> </tr> <tr> <td><i>Injection</i></td> <td>&lt;variable&gt;</td> </tr> </table>	<i>None</i>	---	<i>PP2S</i>	2.00 s	<i>Ctrl. Channel</i>	426.67 ms	<i>Ctrl. Slot</i>	<variable>	<i>AT Rev. Frame</i>	26.67 ms	<i>AT Fwd. Slot</i>	<variable>	<i>Slot</i>	1.67 ms	<i>PwrCtrlPattern</i>	<variable>	<i>Injection</i>	<variable>
<i>None</i>	---																		
<i>PP2S</i>	2.00 s																		
<i>Ctrl. Channel</i>	426.67 ms																		
<i>Ctrl. Slot</i>	<variable>																		
<i>AT Rev. Frame</i>	26.67 ms																		
<i>AT Fwd. Slot</i>	<variable>																		
<i>Slot</i>	1.67 ms																		
<i>PwrCtrlPattern</i>	<variable>																		
<i>Injection</i>	<variable>																		
	All signals can be selected for each of the pins 2 to 5. The current AUX 3 pin																		

assignment (including the external trigger input at pin 8) is shown in the diagram to the left of the trigger *Setup* table.

Remote control

TRIGger:OUTPut:PIN<nr>:SIGNal <Frame\_Period>

### I/Q-IF Interface (Connection Control – I/Q-IF)

The *I/Q-IF* tab is part of the second group of tabs in the *Connection Control* menu. It is accessible after pressing the 1 / 2 toggle hotkey once. Pressing 1 / 2 again switches back to the first group of tabs described above.

The *I/Q-IF* tab configures the signal paths for I/Q and IF signals. With option CMU-B17, *I/Q and IF Interfaces*, I/Q and IF signals can be used in the framework of *RF* measurements and in many network tests. For a detailed description of rear panel connectors for I/Q and IF input/output signals, test scenarios and application examples refer to the CMU200/300 operating manual.




Figure 4-33 Connection Control – I/Q-IF

**Default Settings** The *Default Settings* checkbox assigns the default setting to all functions in the *I/Q-IF* tab.

Remote control IQIF:DEFault ON | OFF

**I/Q-IF** Selects the I/Q-IF test scenario, overwriting the current *RX Path* and *TX Path* settings. Six different predefined test scenarios with fixed RX and TX path are provided; see [Table 4-8 below](#).

Additional scenarios may be defined by selecting any other combination of RX and TX paths. When this is done *I/Q-IF* is set to *User-defined*. The circuit diagram to the left of the *Setup* table shows the current RX and TX signal paths.

Remote control CONFIGure:IQIF:RXTXcombined  
 BYP | BYIQ | XOIO | IOIO | IOXO | FPAT | UDEF

**RX Path** Selects the RX signal path, leaving the *TX Path* unchanged but adapting the I/Q-IF test scenario to the new RX/TX path combination: If the combination corresponds to a predefined scenario, then *I/Q-IF* is set to the predefined scenario; otherwise it is set to *User-defined*.

The circuit diagram to the left of the *Setup* table shows the current RX and TX signal paths.

Remote control `CONFigure:IQIF:RXPath`  
`BYP | BYIQ | XOIO | IOIO | IOXO | FPAT | UDEF`

**RX Path** Selects the TX signal path, leaving the *RX Path* unchanged but adapting the I/Q-IF test scenario to the new RX/TX path combination: If the combination corresponds to a predefined scenario, then *I/Q-IF* is set to the predefined scenario; otherwise it is set to *User-defined*.

The circuit diagram to the left of the *Setup* table shows the current RX and TX signal paths.

Remote control `CONFigure:IQIF:TXPath`  
`BYP | BYIQ | XOIO | IOIO | IOXO | FPAT | UDEF`

Table 4-8 I/Q-IF scenarios and path settings

I/Q-IF	RX Path	TX Path	Remark/Application (see also CMU manual)
RX/TX Bypass	Bypass	Bypass	No I/Q or IF inputs/outputs connected Direct signal analysis and transmission with full measurement accuracy
Byb. w. I/Q-OF OUT	Bypass w. I/Q-IF OUT	Bypass w. I/Q-IF OUT	No I/Q or IF inputs connected Analysis of received and transmitted signal via I/Q or IF
I/Q IN/OUT	I/Q IN/OUT	I/Q IN/OUT	Insertion of signal to be analyzed and transmitted on I/Q level
IF IN_I/Q IN/OUT	IF IN_I/Q IN/OUT	IF IN_I/Q IN/OUT	Additional processing of received and transmitted signal on IF level (filters etc.) and analysis via I/Q
IF IN/OUT	IF IN/OUT	IF IN/OUT	Insertion of signal to be analyzed and transmitted on IF level
Fading	Bypass	I/Q IN/OUT	Direct analysis of received signal Modification (fading) of transmitted signal by means of an external fading simulator (SMIQ, ABFS)
User-defined	Any combination of RX Path and TX Path not listed above		Any combination of RX and TX test cases listed above

## Marker Control

Markers are references available with any application displaying a graph of the measurement. This section gives a detailed explanation of how to control each marker type. Marker information specific to an application is located with the application.

<b>Marker</b>	<p>The <i>Marker</i> softkey positions up to three markers and a D-line in the test diagram and reads their values.</p> <p><b>Markers</b>            Graphical tools for marking points on the measurement curve and for numerical output of measured values.</p> <p>The markers are turn activated by pressing the hotkey and pressing the <i>ON/OFF</i> key, or entering a value. Values can be entered directly with the keypad or with the <i>Variation</i> knob.</p> <p>The coordinates of the three markers are indicated in the format <i>Ordinate value (level)/abscissa value (time)</i> in a parameter line above the test diagram. The position of the reference marker is expressed in absolute units (level in dBm or percentage and time in symbols). The delta markers are expressed as absolute or relative values (relative position from the reference marker).</p> <p><b>D-Line</b>            The D-Line is a horizontal line that can be positioned to mark and read out an arbitrary level in the test diagram.</p>
---------------	---

Ref 	<p>The <i>Ref</i>  hotkey displays the status (On   Off) of the reference marker. Pressing the hotkey displays a popup menu to switch the reference marker on or off (use the <i>ON/OFF</i> key or the <i>Variation</i> knob).</p> <p>The reference marker is represented by the symbol  in the test diagram. The marker position (abscissa) is determined in the input field <i>Ref. Marker</i>. The marker can be positioned to arbitrary time values. If its position is outside the diagram area it will be invisible and its coordinates will be “- - - / &lt;abscissa_value&gt;“. The marker is switched off in the default setting (<i>OFF</i>). The marker level is defined by the measurement curve at the marker position.</p>
---	--

Delta 	<p>The <i>Delta</i>  hotkey displays the status (On   Off) of delta marker 1. Pressing the hotkey displays a popup menu to switch the delta marker 1 on or off (use the <i>ON/OFF</i> key or the <i>Variation</i> knob).</p> <p>Delta marker 1 is represented by the symbol  in the test diagram. The marker position (abscissa) is defined in the input field <i>Delta Marker 1</i>. The marker can be positioned to arbitrary time values. If its position is outside the diagram area it will be invisible and its coordinates will be “&lt;abscissa_value&gt; / - - -“. The marker is switched off in the default setting (<i>Off</i>). The marker level is defined by the trace at the marker position.</p> <p>Pressing the hotkey twice displays the <i>Delta 1 Config</i> popup display. It defines whether the position of delta marker 1 is measured and indicated in absolute units (of the horizontal scale) or relative to the reference marker.</p>
---	--

Delta 	<p>The <i>Delta</i>  hotkey switches the delta marker 2 on or off (use the <i>ON/OFF</i> key).</p> <p>The functions and control are identical to delta marker 1.</p>
---	---

**D-Line**

The *D-Line* hotkey activates and controls the position of the D-Line in the test diagram.

The D-line is a horizontal, colored auxiliary line in the test diagram used for marking a level value and for measuring level differences.

Press the hotkey once to turn the D-Line on or off (using the *ON/OFF* key). The level of the D-line is determined by entering an absolute or relative value with either the keypad or *Variation* knob.

Press the hotkey twice to open the *D-Line Config* popup to set the absolute or relative D-Line display.

In the Absolute setting, the D-Line is expressed in the vertical scale units and is limited to the value range of the vertical scale. In the Relative setting, the D-Line value is relative to the maximum vertical scale.

The default setting is Off.

## Contents

<b>5 Remote Control – Basics</b> .....	<b>5.1</b>
<b>Structure and Order of Commands</b> .....	<b>5.1</b>
<b>Measurement Control</b> .....	<b>5.2</b>
Measurement Groups .....	5.2
Measurement Statistics.....	5.3
Specifying Limits .....	5.4
<b>Status Reporting System</b> .....	<b>5.5</b>
<b>Special Terms and Notation</b> .....	<b>5.6</b>

## 5 Remote Control – Basics

This chapter gives a survey of the basic features and concepts of 1xEV-DO remote control commands. Remote control can be described in terms analogous to the ones used in Chapter 3 for the classification of menus and settings for the graphical user interface. In the following, we will particularly point out the similarities and differences between manual and remote control.

### Structure and Order of Commands

Chapter 6 of this manual gives a description of all 1xEV-DO remote control commands, including their parameters, default values and ranges of all numerical parameters.

#### Addressing

The CMU200 uses extended addressing. The instrument is assigned a primary address while each function group and test mode is identified via a secondary address. This allows the same remote commands to be used in several function groups and modes:

```
ibwrt(h_EVD01xAT_NSig, "INITiate:NPOWER")
ibwrt(h_CDMA2KPCSMS_Sig, "INITiate:NPOWER")
```

provided that the variables `h_EVD01xAT_NSig`, etc. have been appropriately defined, see program examples in Chapter 7 of the CMU Operating manual.

The remote control commands for first (`SYST:COMM:GPIB:ADDR`) and secondary (`SYST:REM:ADDR:SEC`) addressing are described in the CMU Operating manual. The `SYST:REM:ADDR:SEC` command uses the following name to address the 1xEV-DO network tests described in this manual:

```
EVD01XAT_NSig
```

#### Order of commands

The commands are arranged to form groups belonging to the same measurement or to the same type of configurations. These command groups are identified by the second-level keyword (as in `POWER`). Applications belonging to a measurement group (see Chapter 5 of the CMU200 base unit operating manual) are identified by the third-level keyword of each command (as in `MODulation:EVMagnitude`). Chapter 6 is organized as follows:

*1xEV-DO:*

- General purpose commands that are identical or almost identical in every function group (`OPTION`, `STATUS:OPERation`, `RESet`, `MMEMory`, `IQIF`)
- General configurations that are valid for the entire 1xEV-DO function group (second-level keywords `NETWork`, `LEVEL`, `INTernal`, `EXTernal`, `RFANalyzer`, `RFGenerator`, `INPut`, `OUTPut`, `CORRection:LOSS`, `DM:CLOCK`)
- Measurement groups: (second/third-level keywords `WPOWER`, `NPOWER`, `MODulation:MQuality`, `MODulation:OVERview`, `MODulation:EVMagnitude`, `MODulation:PERRor`, `MODulation:MERRor`, `MODulation:IQANalyzer`, `CDPower:CDPW`, `CDPower:PCDep`, `CDPower:CHPW`, `SPECTrum:ACP`).

The structure of Chapter 6 differs from Chapter 4 (*Functions and their Application*) where the measurements are presented first and configurations pertaining to the whole function group and test mode are reported at the end of each section.

The menu of the graphical user interface corresponding to a group of commands is quoted at the beginning of each section. A list of all commands is annexed to Chapter 6.

### SCPI Conformity

In view of the particular requirements of 1xEV-DO measurements not all commands could be taken from the SCPI standard. However, the syntax and structure of all commands is based on SCPI conventions. For a detailed description of the SCPI standard refer to Chapter 5 of the operating manual for the CMU basic unit.

SPCI confirmed and SPCI approved commands are explicitly marked in Chapter 6.

### Remote Control

All commands may be used for control of the CMU via the GPIB interface or serial (RS-232) interface.

## Measurement Control

The commands in the measurement groups WPOWer, NPOWer, POWer..., MODulation..., CDPower... have an analogous structure and syntax. The measurements are controlled according to common concepts which are explained in detail in Chapter 5 of the CMU operating manual. The following sections show how the general concepts are applied to 1xEV-DO measurements.

## Measurement Groups

The measurement groups are referred to as *measurement objects* (keyword <meas\_obj>) in remote control. Most measurement objects correspond to a measurement group or application in manual control. For 1xEV-DO measurements, the following measurement objects are defined:

Table 5-1 Measurement objects in 1xEV-DO.

1xEV-DO	
Meas. Object	Measurement group Application
WPOWer	Wide-band Power measurement.
NPOWer	Narrow-band Power measurement.
MODulation:MQuality	Modulation Quality measurement (H-PSK) AT power, waveform quality, frequency error, transmit time error, carrier feedthrough, I/Q imbalance and sideband suppression. Statistical results and the results of the limit check can be evaluated.
MODulation:OVERview	Modulation Overview measurement (H-PSK) H-PSK scalar modulation results. Summary of phase error, error vector magnitude and magnitude error of the AT transmitter output signal. The frequency error, average and RMS error, statistical results and the results of the limit check can be evaluated.

1xEV-DO	
Meas. Object	Measurement group Application
MODulation:EVMagnitude	<i>Modulation Error Vector Magnitude measurement (H-PSK)</i> Modulation waveform interval as a function of time of the AT transmitter output signal (H-PSK). The frequency error, average and RMS error, statistical results and the results of the limit check can be evaluated.
MODulation:MERROR	<i>Modulation Magnitude Error measurement (H-PSK)</i> Modulation waveform interval as a function of time of the AT transmitter output signal (H-PSK). The frequency error, average and RMS error, statistical results and the results of the limit check can be evaluated.
MODulation:PERROR	<i>Modulation Phase Error measurement (H-PSK)</i> Modulation waveform interval as a function of time of the AT transmitter output signal (H-PSK). The frequency error, average and RMS error, statistical results and the results of the limit check can be evaluated.
MODulation:IQAnalyzer	<i>Modulation IQ Analyzer (H-PSK)</i> Analysis of the AT signal in the I/Q plane.
CDPower:CDPW	<i>Code Domain Power measurement (H-PSK)</i> Code Domain Power in 16 code domain channels contributing to the reverse link 1xEV-DO signal. The slots for the Pilot and the RRI channel are evaluated within the same measurement shot. The AT power, carrier feedthrough, frequency error and rho factor, statistical results and the results of the limit check can be evaluated.
CDPower:PCDep	<i>Peak Code Domain Error Power measurement (H-PSK)</i> Peak Code Domain Error Power in 16 code domain channels contributing to the reverse link 1xEV-DO signal. The slots for the Pilot and the RRI channel are evaluated within the same measurement shot. The AT power, carrier feedthrough, frequency error and rho factor, statistical results and the results of the limit check can be evaluated.
CDPower:CHPW	<i>Channel Power measurement (H-PSK)</i> Channel Power of the reverse link physical channels of both the I and Q signal. The slots for the Pilot and the RRI channel are evaluated within the same measurement shot. The AT power, carrier feedthrough, frequency error and rho factor, statistical results and the results of the limit check can be evaluated.
SPECTrum:ACP	<i>Adjacent Channel Power Spectrum measurement</i> Power as a function of the offset frequency related to the Channel Power. Statistical results and the results of the limit check can be evaluated.

## Measurement Statistics

Together with the *Statistic Count*, the *Repetition Mode* defines how many evaluation periods are measured if the measurement is not stopped explicitly (measurement control commands *STOP...*, *ABORT...*) or by a limit failure. With remote control, the two repetition modes *Single Shot* and *Continuous* are available (*Counting* is not available in manual control, see chapter 3).

Generally four different traces are determined within one measurement:

- The result in the current period
- The maximum result
- The minimum result
- The average result (evaluated over a set number of waveform intervals)

The four results can be queried independently.

Table 5-2 Repetition mode in remote control

Setting	Description	Command
<b>Statistic Count</b>	Integer number of evaluation periods forming one statistics cycle. An evaluation period is equal to a burst.	<pre>CONFigure:&lt;meas_obj&gt;:CONTRol:STATistics 1 ... 1000   NONE  (&lt;meas_obj&gt; = NPOwer   MODulation:MQUality   MODulation:EVMagNitude   CDPower:CHPW   ...)</pre>
<b>Repetition Mode</b>  Single Shot	The measurement is stopped after one statistics cycle. All remote control measurements default to single shot.	<pre>CONFigure:&lt;meas_obj&gt;:CONTRol:REPetition <b>SINGLEshot</b>, &lt;StopCondition&gt;, &lt;Stepmode&gt; (&lt;meas_obj&gt; = NPOwer   MODulation:MQUality   MODulation:EVMagNitude   CDPower:CHPW   ...)</pre>
Continuous	The measurement is continued until stopped explicitly or by a limit failure. Average results are calculated according to the rules described in chapter 3.	<pre>CONFigure:&lt;meas_obj&gt;:CONTRol:REPetition <b>CONTinuous</b>, &lt;StopCondition&gt;, &lt;Stepmode&gt; (&lt;meas_obj&gt; = NPOwer   MODulation:MQUality   MODulation:EVMagNitude   CDPower:CHPW   ...)</pre>
Counting	Repeated single shot measurement with configured statistics cycles.	<pre>CONFigure:&lt;meas_obj&gt;:CONTRol:REPetition 1 ... 10000, &lt;StopCondition&gt;, &lt;Stepmode&gt; (&lt;meas_obj&gt; = NPOwer   MODulation:MQUality   MODulation:EVMagNitude   CDPower:CHPW   ...)</pre> <p>A counting measurement with 1 evaluation period is equivalent to a single shot measurement.</p>
<b>Traces</b>	<p>The specifiers <b>CURRENT</b>, <b>MMAx</b>, and <b>AVERAge</b> denote the traces for the current evaluation period, the extreme value, and the average of a set of evaluation periods. They correspond to the <i>Display Mode</i> set in the measurement configuration menus.</p> <p>In general all four traces are evaluated during the measurement. They are selected via the specifiers used as last keywords in the <b>READ...</b>, <b>FETCH...</b> or <b>SAMPle...</b> queries.</p>	<p>Measurement results:</p> <pre>READ:ARRAy:&lt;meas_obj&gt;:&lt;disp&gt;? READ:SUBarrays:&lt;meas_obj&gt;:&lt;disp&gt;? ...</pre> <p>&lt;disp&gt; = <b>CURRent</b>   <b>AVERAge</b>   <b>MAXimum</b>   <b>MINimum</b>   <b>MMAx</b> (not all modes are available for all measurements)</p> <pre>(&lt;meas_obj&gt; = NPOwer   MODulation:MQUality   MODulation:EVMagNitude   CDPower:CHPW   ...)</pre> <p>Limit matching:</p> <pre>CALCULATE[:SCALAr]:&lt;meas_obj&gt;:&lt;disp&gt;: MATChing:LIMit? &lt;Response&gt; ....</pre> <p>&lt;Response&gt; contains the limit matching identifiers for all three traces</p>

## Specifying Limits

The following table gives an overview of the types of limits and possible results of the limit check.

Table 5-3 Limits and limit check

Type	Description	Command
Scalar limits	Limit values for a single (scalar) measured quantity. Depending on the measured quantity, either an upper limit or upper and lower limits can be defined.	<pre> CONFigure:&lt;meas_obj&gt;:&lt;disp&gt;:LIMit [:SCALAr]:&lt;symmetry&gt;:&lt;Spec.&gt;:VALue  &lt;disp&gt; = CURRent   AVERAge           MMAX   CAMMax where CAMMax denotes a limit valid for all measurement curves (current and average and min/maximum)  (&lt;meas_obj&gt; = NPOWer   MODulation:MQuality    MODulation:EVMagnitude   CDPower:CHPW   ...)  &lt;symmetry&gt; = SYMMetric   ASYMmetric for symmetric or asymmetric upper and lower limits  &lt;Spec.&gt; = UPPer   LOWer   [:COMBined] for upper limits, lower limits, or combined upper and lower limits.                     </pre>
Limit check	All scalar limits belonging to the same measurement group are read out together with the command on the right side.	<pre> CALCulate:&lt;meas_obj.&gt;:MATChing:LIMit?  (&lt;meas_obj&gt; = NPOWer   MODulation:MQuality    MODulation:EVMagnitude   CDPower:CHPW   ...)                     </pre>
	Possible results of the scalar limit check are listed on the right side.	<pre> NMAU      not matching, underflow NMAL      not matching, overflow INV       measured value invalid OK        no limit failure                     </pre>
	The result of the limit check depends on the statistics settings (see section <a href="#">Measurement Statistics</a> on page 5.3).	<pre> CALCULATE:ARRay:&lt;meas_obj&gt;:&lt;disp&gt; :MATChing:LIMit? ...  where &lt;disp&gt; = :CURRent   :AVERAge                   :MMAximum   :MAXimum   :MINimum  (&lt;meas_obj&gt; = NPOWer   MODulation:MQuality    MODulation:EVMagnitude   CDPower:CHPW   ...)                     </pre>

## Status Reporting System

A general description of SCPI status registers and of the status reporting system is given in Chapter 5 of the CMU operating manual. This section is devoted to the particular features concerning 1xEV-DO measurements.

The CMU offers 30 independent `STATUS:OPERation:SUM1|2:CMU<nr>` sub-registers (<nr>=1 ... 15) which are implemented in hierarchical form. The bits of the 30 `STATUS:OPERation` registers are set only after the registers are assigned to a function group and measurement mode.

In the `EVENT` part, the `STATUS:OPERation` register contains information on which actions the instrument has executed since the last readout. All five parts of the registers can be read using one of the commands of the subsystem `STATUS:OPERation:SUM1|2:CMU<nr>:...`

**Note:** *Symbolic status register evaluation by means of the commands `STATUS:OPERation:SYMBOLic:ENABle` and `STATUS:OPERation:SYMBOLic[:EVENT]?` is a convenient alternative method of retrieving status information. See also section [Symbolic Status Event Register Evaluation](#) in chapter 5 of the CMU operating manual and chapter 6 of this manual.*

1xEV-DO access terminal tests comprise the *Non-Signalling factory test mode*. The secondary address of the 1xEV-DO function group must be used to access the correct status registers. The bit assignment is as follows:

Table 5-4 1xEV-DO bits used in the STAT:OPER:SUM1|2:CMU<nr> sub-registers

Bit-No.	Description	Symbol in STAT:OPER:SYMB...	Firmware Version
0	<b>Forward traffic (AT1) packet stream completed</b> This bit is set when all packets specified in the <i>Packet Count</i> parameter are sent to the access terminal <sup>°1</sup>	PS1C	V3.40
1	<b>Forward traffic (AT2) packet stream completed</b> This bit is set when all packets specified in the <i>Packet Count</i> parameter are sent to the access terminal <sup>°2</sup>	PS2C	V3.40
2	<b>Forward traffic (AT3) packet stream completed</b> This bit is set when all packets specified in the <i>Packet Count</i> parameter are sent to the access terminal <sup>°3</sup>	PS3C	V3.40
3	<b>Forward traffic (AT4) packet stream completed</b> This bit is set when all packets specified in the <i>Packet Count</i> parameter are sent to the access terminal <sup>°4</sup>	PS4C	V3.40
4	<b>Measurement Invalid</b> This bit is set when a measurement returns invalid results.	MINV	V3.40
11	<b>RF Input Overdriven</b> This bit is set if the RF input level at connector RF1, RF2 or RF 4 IN is larger than the specified RF Max. Level plus an appropriate margin.	RFIO	V3.40
12	<b>RF Input Underdriven</b> This bit is set while the RF input level at connector RF1, RF2 or RF 4 IN falls below the measurement range controlled by the specified RF Max. Level.	RFIU	V3.40

## Special Terms and Notation

Below we list some particular features in the syntax of the 1xEV-DO commands. The general description of the SCPI command syntax can be found in Chapter 5 of the CMU Operating manual, section "*Structure and Syntax of Device Messages*".

### Description of commands

The commands are arranged in tables; all of them are described along the same scheme. From top to bottom, the table rows contain the following entries:

1. Complete command syntax including the parameter list and a short description of the command
2. List and description of the parameters with their default values, the default units and unit rings
3. Detailed description of the command, signalling state required for command execution (in Signalling mode), required firmware version

Detailed lists of default values are annexed to the command description.

### Order of commands

The commands are arranged according to their function. The general purpose

of a command is described by the keyword in the second level. Lower-level keywords define the command in more detail. This means that commands with the same second-level, third-level etc. keywords are generally grouped together in the same sections.

**Example:**

```
CONFigure:MODulation:PERRor:HPSK:CONTRol:STATistics
    <Statistics>
```

Commands with the keyword *MODulation* in the second level belong to the modulation measurement. The keywords in the third, fourth and fifth level indicate that the command defines the number of bursts forming a statistics cycle in the measurement of the AT phase error.

**Combined measurements**

To limit the number of remote control commands in an application program, all scalar results of a measurement group are usually measured together and returned in a common list. Arrays (e.g. the traces for *CDPOWER* and *MODulation* measurements) are returned as comma-separated lists of values; it is possible to retrieve either the whole list (see commands *READ:ARRAY...* etc.) or the values located in a number of subranges that are part of the total measurement range (see commands *READ:SUBarrays...*; the subarrays are defined via *CONFigure:SUBarrays...*).

**Parameters**

Many commands are supplemented by a parameter or a list of parameters. Parameters either provide alternative options (setting a or setting b or setting c ..., see special character "|"), or they form a comma-separated list (setting x,y).

**<Par\_Name>**

Alternative settings are described by a common name (literal) written in angle brackets (<>). This literal serves as a description of the parameters only; in an application program it must be replaced by one of the settings given in the detailed parameter description.

**Example:**

```
CONFigure:MODulation:PERRor:HPSK:CONTRol:STATistics
    <Statistics>
    with      <Statistics> = 1 ... 10000 | NONE
    possible command syntax: CONF:MOD:PERR:CONT:STAT NONE
```

**NAN**

NAN (not a number) is generally used to represent missing data, e.g. if a portion of a trace has not been acquired yet. It is also returned after invalid mathematical operations such as division by zero. As defined in the SCPI standard, NAN is represented as 9.91 E 37.

**INV**

INV (invalid) is returned if a limit check is performed without defining the appropriate tolerance values.

**Upper / lower case**

Upper/lower case characters characterize the long and short form of the keywords in a command. The short form consists of all upper-case characters, the long form of all upper case plus all lower case characters. Either the short form or the long form are allowed; mixed forms are not generally recognized. The instrument itself does not distinguish upper case and lower case characters.

**Special characters**

|

A vertical stroke in the parameter list characterizes alternative parameter settings. Only one of the parameters separated by | must be selected.

**Example:** The following command has two alternative settings:

```
DEFault:LEVel ON | OFF
```

- [ ] *Key words* in square brackets can be omitted when composing the command header (see Chapter 5 of the CMU Operating manual, section "Structure of a Command"). The complete command must be recognized by the instrument for reasons of compatibility with the SCPI standard.
- Parameters* in square brackets are optional as well. They may be entered in the command or omitted.
- [?] Remote control commands that can also be used as a query are indicated with [?] at the end of the command. As a query, the "?" (question mark) must be part of the command.
- { } Braces or curly brackets enclose one or more parameters that may be included zero or more times.
- <nr> This symbol stands for a numeric suffix, e.g. an enumeration index for input and output connectors.

### List of Commands

- Command:** The *Command* column of the table contains all remote control commands arranged according to their function (configurations or measurement objects).
- Parameters:** The *Parameter* column lists the parameters of the commands.
- Remarks:** The *Remarks* column gives additional information about the commands which
- Have no query form (no query)
  - Have only a query form (query only)
  - Can be used both as setting commands and as queries (with query, this applies to all commands belonging to one of the two preceding categories)

## Contents

<b>6 Remote Control – Commands</b> .....	<b>6.1</b>
<b>General Commands</b> .....	<b>6.2</b>
Option Query.....	6.2
Partial Reset.....	6.2
Configuration File Management.....	6.3
I/Q-IF Interface .....	6.4
Symbolic Status Event Register Evaluation.....	6.6
<b>Band Class – Network Standard</b> .....	<b>6.7</b>
NETWork Standard .....	6.7
<b>Analyzer</b> .....	<b>6.8</b>
Subsystem RFAnalyzer .....	6.8
Subsystem FREQuency.....	6.8
Subsystem LEVel.....	6.10
Subsystem LCMask (Long Code Mask) .....	6.10
Subsystem CCFilter (Code Channel Filter) .....	6.11
Subsystem AT<nr> (Access Terminal).....	6.11
<b>Trigger</b> .....	<b>6.12</b>
Subsystem TRIGger.....	6.12
Subsystem SElect.....	6.12
Subsystem SLOPe.....	6.12
Subsystem OUTPut .....	6.13
Subsystem THReshold .....	6.13
Subsystem SOURce.....	6.14
<b>Generator</b> .....	<b>6.15</b>
Subsystem RFGenerator .....	6.15
Subsystem FREQuency.....	6.16
Subsystem POWer .....	6.17
Subsystem PROPerTy .....	6.17
Subsystem IMPairments.....	6.18
Subsystem SNCMessage (Sync. Message).....	6.18
Subsystem AT<nr> (Access Terminal).....	6.21
Subsystem RAB (Reverse Activity) .....	6.26
Subsystem OAT (Other Access Terminals).....	6.27
<b>RF Input and Output</b> .....	<b>6.28</b>
Subsystem RF Input and Output (External Attenuation at Connectors) .....	6.28
Subsystem DM:CLOCK (Synchronization).....	6.29
<b>Measurements</b> .....	<b>6.30</b>
WPOWER (Wide Band Power).....	6.30

Control of Measurement .....	6.30
Test Configuration.....	6.31
Subsystem CONTrol .....	6.31
Measured Values .....	6.31
NPOWer (Narrow Band Power) .....	6.32
Control of Measurement .....	6.32
Test Configuration.....	6.33
Subsystem CONTrol .....	6.33
Measured Values .....	6.34
MODulation:MQuality (Modulation Quality) .....	6.35
Control of Measurement .....	6.35
Test Configuration.....	6.36
Subsystem CONTrol .....	6.36
Subsystem LIMit.....	6.38
Measured Values .....	6.41
MODulation:OVERview .....	6.42
Control of Measurement .....	6.42
Test Configuration.....	6.44
Subsystem CONTrol .....	6.44
Subsystem LIMit.....	6.46
Measured Values .....	6.49
MODulation:EVMagnitude (Error Vector Magnitude).....	6.50
Control of Measurement .....	6.50
Test Configuration.....	6.52
Subsystem CONTrol .....	6.52
Subsystem LIMit.....	6.54
Subsystem SUBarrays.....	6.54
Measured Values .....	6.55
MODulation:PERRor (Phase Error) .....	6.57
Control of Measurement .....	6.57
Test Configuration.....	6.58
Subsystem CONTrol .....	6.58
Subsystem LIMit.....	6.60
Subsystem SUBarrays .....	6.60
Measured Values .....	6.61
MODulation:MERRor (Magnitude Error) .....	6.62
Control of Measurement .....	6.63
Test Configuration.....	6.63
Subsystem CONTrol .....	6.64
Subsystem LIMit.....	6.66
Subsystem SUBarrays .....	6.66
Measured Values .....	6.67
MODulation:IQANalyzer (IQ Analyzer) .....	6.69
Control of Measurement .....	6.69
Test Configuration.....	6.70
Subsystem CONTrol .....	6.70
Subsystem SUBarrays.....	6.71
Measured Values .....	6.72
CDPower:CDPW (Code Domain Power) .....	6.74
Control of Measurement .....	6.74

Test Configuration.....	6.75
Subsystem CONTrol .....	6.75
Subsystem LIMit.....	6.77
Measured Values .....	6.80
CDPower:PCDep (Peak Code Domain Error Power) .....	6.84
Control of Measurement .....	6.84
Test Configuration.....	6.85
Subsystem CONTrol .....	6.85
Subsystem LIMit.....	6.87
Measured Values .....	6.88
CDPower:CHPW (Channel Power).....	6.92
Control of measurement .....	6.92
Test Configuration.....	6.93
Subsystem CONTrol .....	6.93
Subsystem LIMit.....	6.95
Measured Values .....	6.96
SPECtrum:ACP (ACP Spectrum) .....	6.100
Control of Measurement .....	6.100
Test Configuration.....	6.101
Subsystem CONTrol .....	6.101
Subsystem LIMit.....	6.104
Measured Values .....	6.105
<b>List of Commands .....</b>	<b>6.107</b>

## 6 Remote Control – Commands

This chapter contains all remote-control commands for the 1xEV-DO function group. The commands are presented in tabular form with their parameters and the ranges of values. The structure of this chapter is analogous to that of the reference part for manual operation (Chapter 4).

Within the 1xEV-DO function group, the general configurations are presented first and then the individual measurement groups (test objects) are presented.

General notes on remote control in the 1xEV-DO function group can be found in Chapter 5. An introduction to remote control according to SCPI standard and the status registers of the CMU is given in Chapter 5 of the operating manual for the CMU basic instrument.

---

**Note:** *Remote control commands that can also be used as a query are indicated with [?] at the end of the command. As a query, the “?” (question mark) must be part of the command.*

*Otherwise the command documentation follows SCPI conventions (see also Chapter 5): Keywords and parameters enclosed in square brackets are optional and can be omitted without changing the effect of the command.*

---

## General Commands

The commands listed in this section describe the global CMU features that are supported in the 1xEV-DO function group. These commands are identical or almost identical in all CMU function groups that support the corresponding feature.

### Option Query

The *Options* subsystem contains the commands for querying information on the instrument and the available options. It corresponds to the *Options* tab in the *Setup* menu opened via the *SETUP* key on the front panel.

SYSTem:OPTions:INFO:CURRent?			Device Info
<b>Response</b>	Def. Value	Default unit	FW vers.
Example: Rohde&Schwarz,CMU 200-1100.0008.02,840675/018, V3.40:SP00 2003-04-05" EVDO1xAT_NSig"	–	–	V3.40
Command description			
This command returns the information on the device comprising the manufacturer, model, serial number and firmware version of the current function group. This command is always a query.			

SYSTem:VERSion:SW:MMI?			MMI Software Version
<b>Response</b>	Def. Value	Default unit	FW vers.
Example: "1.00C[3.40:SP00]"	–	–	V3.40
Command description			
This command returns the information about the current version of the 1xEV-DO MMI module. This command may be helpful for driver development as the MMI module determines the GPIB command set. This command is always a query.			

### Partial Reset

The *RESet* subsystem restores the (factory) default values for the 1xEV-DO function group (unless the secondary address of another function group is used). It corresponds to the 1xEV-DO path in the *Reset* menu opened via the *RESET* key on the front panel.

SYSTem:RESet:CURRent		Partial Reset
Command description		FW vers.
This command sets all parameters of the current function group and test mode to default values. The command is available in all function groups. In contrast to the <i>Reset</i> menu the command restores the default values defined for remote control operation. In cases where remote and manual control use distinct settings (e.g. the repetition mode for many measurements), the manual control settings are left unchanged.		V3.40

## Configuration File Management

The MMEMoRY system provides mass storage capabilities for the CMU. The functionality of this system is included in the *Data* menu; see CMU200/300 operating manual.

The mass storage of the CMU may be internal or external. The internal mass storage device is a section on the internal hard disk that is reserved for mass storage (directory c:\temp). The external mass storage device is either a floppy disk or a PCMCIA memory card, depending on the instrument configuration. The *<msus>* (mass storage unit specifier) parameter in the MMEMoRY commands denotes the root directory of the *INTernal* or *EXTernal* mass storage device.

The *<FileName>* parameter is a string. The contents of the string may contain characters for specifying subdirectories, e.g. "\TEMP\TRASH\test.txt" for the file named *test.txt* in the *TEMP\TRASH* subdirectory of the root directory or "TEMP\TRASH\test.txt" for the file named *test.txt* in the *TEMP\TRASH* subdirectory of the current directory, to be queried with the base system command MMEMoRY:DIRectory[:CURRent]?. The file name itself may contain the period as a separator for extensions.

<b>MMEMoRY:SAVE:CURRent &lt;FileName&gt; [,&lt;msus&gt;]</b> Save configurations in current function group and test mode				
<i>Parameters</i>	Parameter description	Def. value	Def. unit	FW vers.
"<FileName>", <b>INTernal   EXTernal</b>	Name of the config. file to be created Storage device of the config. file	– INTernal	– –	V3.40
Command description				
This command saves the configuration of the 1xEV-DO function group (unless the secondary address of another function group is used) to a configuration file. A "?" in the specified file name will be replaced by current numbers that are automatically incremented, starting with zero. The auto-increment function overwrites an existing file with a "9" in its file name. For instrument settings that may be different in manual and remote control (e.g. the repetition mode for many measurements) the manual setting is saved. The command is available in all function groups. This command is CMU-specific.				

<b>MMEMoRY:RECall:CURRent &lt;FileName&gt; [,&lt;msus&gt;]</b> Recall configurations in current function group and test mode				
<i>Parameters</i>	Parameter description	Def. value	Def. unit	FW vers.
"<FileName>", <b>INTernal   EXTernal</b>	Name of the config. file to be recalled Storage device of the config. file	– INTernal	– –	V3.40
Command description				
This command recalls the configuration of the current function group and test mode from a configuration file. The command is available in all function groups. This command is CMU-specific.				

## I/Q-IF Interface

The subsystem *IQIF* configures the signal paths for I/Q and IF signals provided by option CMU-B17, *I/Q and IF Interfaces*. It corresponds to the *I/Q-IF* tab in the second plane of the *Connection Control* menu.

**Hint:** *How to make sense out of parameter names*

*In all path configurations except bypass, both the I/Q and IF output are connected (to either the RF Unit, the Digital Unit or one of the I/Q-IF inputs). The paths differ in the connection of the input branches: The qualifier IO denotes a connected input (with connected output), XO denotes a disconnected input (with connected output). Many parameters of the IQIF commands are composed of two IO/XO qualifiers, the first one standing for the IF signal, the second for the I/Q signal.*

**Example:** *The parameter IOXO denotes a connected IF input and a disconnected IF output, while both output branches are connected.*

For more information see Chapter 4 and the application examples in the CMU200/300 operating manual.

CONFigure:IQIF:RXTXcombined[?] <Scenario>				I/Q-IF
<Scenario>	Description of parameters	Def. value	Def. unit	FW vers.
<b>BYP</b>	RX/TX Bypass, RXPath = BYP, TXPath = BYP	BYP	–	V3.40
<b>BYIQ</b>	Bypass w. I/Q-OF OUT, RXPath = TXPath =BYIQ			
<b>XOIO</b>	I/Q IN/OUT, RXPath = TXPath = XOIO			
<b>IOIO</b>	IF IN_I/Q IN/OUT, RXPath = TXPath = IOIO			
<b>IOXO</b>	IF IN/OUT, RXPath = TXPath = IOXO			
<b>FPAT</b>	Fading Path, RXPath = BYP, TXPath = XOIO			
<b>UDEF</b>	User-defined scenario, can not be set but may be returned by the query CONF:IQIF:RXTX?			
Description of command				
This command selects the I/Q-IF test scenario, overwriting the current RX and TX path settings (see commands CONFigure:IQIF:RXPath and CONFigure:IQIF:TXPath below). Six different predefined test scenarios with fixed RX and TX path are provided. Additional scenarios may be defined by selecting any other combination of RX and RX paths.				
<b>Note:</b> <i>UDEF is not provided as a setting parameter. If the RX/TX path combination defined via CONFigure:IQIF:RXPath and CONFigure:IQIF:TXPath doesn't correspond to any of the predefined scenarios, then a user-defined scenario is set implicitly, i.e. the query CONF:IQIF:RXTX? returns the value UDEF.</i>				

CONFigure:IQIF:RXPath[?] <Path>				RX Path
<Path>	Description of parameters	Def. value	Def. unit	FW vers.
<b>BYP</b>	Bypass	BYP	–	V3.40
<b>BYIQ</b>	Bypass w. I/Q-IF OUT			
<b>XOIO</b>	I/Q IN/OUT			
<b>IOIO</b>	IF IN_I/Q IN/OUT			
<b>IOXO</b>	IF IN/OUT			
Description of command				
This command selects the RX signal path, leaving the TX path (see command CONFigure:IQIF:TXPath below) unchanged but adapting the I/Q-IF test scenario to the new RX/TX path combination: If the combination corresponds to a predefined scenario, then CONFigure:IQIF:RXTXcombined is set to the predefined scenario; otherwise it is set to UDEF.				

<b>CONFigure:IQIF:TXPath[?] &lt;Path&gt;</b>				TX Path
<Path>	Description of parameters	Def. value	Def. unit	FW vers.
<b>BYP</b>	Bypass	BYP	–	V3.40
<b>BYIQ</b>	Bypass w. I/Q-IF OUT			
<b>XOIO</b>	I/Q IN/OUT			
<b>IOIO</b>	IF IN_I/Q IN/OUT			
<b>IOXO</b>	IF IN/OUT			
Description of command				
This command selects the TX signal path, leaving the RX path (see command <code>CONFigure:IQIF:RXPath</code> above) unchanged but adapting the I/Q-IF test scenario to the new RX/TX path combination: If the combination corresponds to a predefined scenario, then <code>CONFigure:IQIF:RXTXcombined</code> is set to the predefined scenario; otherwise it is set to <code>UDEF</code> .				

<b>IQIF:DEFAult[?] &lt;Enable&gt;</b>				Default Settings
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
<b>ON  </b>	The parameters are set to their default values	ON	–	V3.40
<b>OFF</b>	Some or all parameters differ from the default values			
Description of command				
If used as a setting command with the parameter <code>ON</code> this command sets all parameters of the subsystem to their default values (the setting <code>OFF</code> causes an error message).				
If used as a query the command returns whether all parameters are set to their default values ( <code>ON</code> ) or not ( <code>OFF</code> ).				

## Symbolic Status Event Register Evaluation

The following commands are used to retrieve the events reported in the 1xEV-DO function group. See section *Symbolic Status Event Register Evaluation* in Chapter 5 of the CMU operating manual.

<b>STATus:OPERation:SYMBOLic:ENABle &lt;Event&gt;{,&lt;Event&gt;}</b>		Symbolic status evaluation		
<i>Parameter list</i>	Parameter description	Def. Value <sup>1</sup>	Default Unit	FW vers.
<b>&lt;Event&gt;{,&lt;Event&gt;}   NONE</b>	List of symbols for events to be reported No event reported	NONE	–	V3.40
Command description				
This command enables event reporting for one or several events in the 1xEV-DO function group, i.e. it sets the corresponding bits in the STATus:OPERation:CMU:SUM<nr>:CMU<nr_event>:ENABle register (<nr> = 1   2, <nr_event> denotes the current function group) and in all sum registers up to the status byte. The events and the corresponding symbols for the function group are listed in Chapter 5 (see section <i>Status Registers</i> ). The symbols may be entered in arbitrary order.				

<b>STATus:OPERation:SYMBOLic[:EVENT]?</b>		Symbolic status evaluation		
<i>Response</i>	Parameter description	Def. Value <sup>2</sup>	Default Unit	FW vers.
<b>NONE   &lt;Event&gt;{,&lt;Event&gt;}</b>	No event in the 1xEV-DO function group List of reported events	NONE	–	V3.40
Command description				
This command is always a query. It lists the events reported in the 1xEV-DO function group and deletes these events in the STATus:OPERation:CMU:SUM<nr>:CMU<nr_event>:EVENT register as well as in all sum registers.				

<sup>1</sup> The default values quoted in this command are achieved after a STATus:PRESet command. \*RST does not overwrite the entries in the status registers; see section *Reset Values of the Status Reporting Systems* in chapter 5.

<sup>2</sup> The default values quoted in this command are achieved after a \*CLS command. \*RST does not overwrite the entries in the status registers; see section *Reset Values of the Status Reporting Systems* in chapter 5.

## Band Class – Network Standard

### NETWork Standard

The *NETWork* subsystem switches between the different 1xEV-DO network standards. The network standard determines the channel/frequency assignment for RF analyzer and generator. Furthermore some measurements provide separated default setups for each of the network standards.

CONFigure:NETWork:STANdard[?] <Standard>		Network Standard		
<Standard>	Description of parameters	Def. value	Def. Unit	FW vers
USC	Band Class 0, US Cellular	USC	–	V3.40
KCEL	Band Class 0, Korean Cellular			
NAPC	Band Class 1, North American PCS			
TACS	Band Class 2, TACS			
JTAC	Band Class 3, JTACS			
KPCS	Band Class 4, Korean PCS			
N45T	Band Class 5, NMT 450			
IM2K	Band Class 6, IMT-2000			
NA7C	Band Class 7, North American 700 MHz			
B18M	Band Class 8, 1800 MHz			
NA9C	Band Class 9, North American 900 MHz			
NA8S	Band Class 10, Secondary 800 MHz			

Description of command

This command activates the test mode according to one of the provided 1xEV-DO network standards.

**Note:** Changing the network standard will affect the frequency setting of the RF analyzer and the generator as well as the sideband suppression and ACP spectrum measurement. See commands

```
[SENSe:]RFANalyzer:FREQuency
SOURce:RFGenerator:FREQuency[:RF]
CONFigure:MODulation:MQuality:HPSK:CONTRol:F0FFset:SBSuppress:ACP<nr>
CONFigure:SPECTrum:ACP:CONTRol:F0FFset:ACP<nr>
```

## Analyzer

In the 1xEV-DO function group, the signal of an 1xEV-DO access terminal (mobile station) is analyzed. The remote-control commands presented in this section determine the RF analyzer settings. They correspond to the settings in the popup menu of the softkey *Connect Control*, located at the top right of each main menu. The *Analyzer* settings are general (global) settings that are valid for the entire function group.

### Subsystem RFAnalyzer

The subsystem *RFAnalyzer* configures the RF input path by defining the analyzer level and frequency. Furthermore it decodes the input signal in order to extract the relevant part of the signal. It corresponds to the tab *Analyzer* in the popup menu *Connection Control*.

DEFault:RFAnalyzer[?] <RF Analyzer>		RF Analyzer		
<RF Analyzer>	Description of parameters	Def. value	Def. unit	FW vers.
ON   OFF	The parameters are set to their default values The parameters differ from the default values (partially or totally)	ON	–	V3.40
Description of command				
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystems RFAnalyzer to their default values (the setting <i>OFF</i> results in an error message).				
If used as a query the command returns whether all parameters are set to their default values ( <i>ON</i> ) or not ( <i>OFF</i> ).				

### Subsystem FREQUENCY

The subsystem *FREQUENCY* controls the frequency in the RF input signal path. It corresponds to the table section *Analyzer Settings* in the *Analyzer* tab of the *Connection Control* menu.

[SENSe:]RFAnalyzer:FREQUENCY:UNIT[?] <Analyzer Freq. Unit>		Frequency Unit		
<Analyzer Freq. Unit>	Description of parameters	Def. Value	Def. unit	FW vers.
HZ   KHZ   MHZ   GHZ   CH	Frequency unit or Channel Number	HZ	–	V3.40
Description of command				
This command defines whether the frequency of the RF signal analyzed is specified in frequency units or as a 1xEV-DO channel number. Frequency units must be used to select input signals that are outside the designated channel range.				

[SENSe:]RFAnalyzer:FREQUENCY[?] <Frequency>			RF Frequency	
<RF Frequency>	Description of parameters	Def. Value	Def. unit	FW vers.
	Input frequency Default input frequency for following standards:		Hz	V3.40
9.990000 MHz to 2700.000000 MHz	Band Class 0, US Cellular	833.4900 MHz CH 283		
9.990000 MHz to 2700.000000 MHz	Band Class 0, Korean Cellular	833.4900 MHz CH 283		
10.000000 MHz to 2700.000000 MHz	Band Class 1, North American PCS	1857.5000 MHz CH 150		
9.987500 MHz to 2699.987500 MHz	Band Class 2, TACS	891.9625 MHz CH 79		
10.000000 MHz to 2700.000000 MHz	Band Class 3, JTACS	915.9500 MHz CH 76		
10.000000 MHz to 2700.000000 MHz	Band Class 4, Korean PCS	1752.2500 MHz CH 45		
10.000000 MHz to 2700.000000 MHz	Band Class 5, NMT 450	450.6000 MHz CH 25		
10.000000 MHz to 2700.000000 MHz	Band Class 6, IMT-2000	1920.6000 MHz CH 12		
10.000000 MHz to 2700.000000 MHz	Band Class 7, North American 700 MHz	776.7000 MHz CH 14		
10.000000 MHz to 2700.000000 MHz	Band Class 8, 1800 MHz	1710.8000 MHz CH 16		
10.000000 MHz to 2700.000000 MHz	Band Class 9, North American 900 MHz	880.9000 MHz CH 18		
10.000000 MHz to 2700.000000 MHz	Band Class 10, Secondary 800 MHz	807.2500 MHz CH 50		
Description of command				
<p>This command defines the frequency of the RF signal analyzed. With the command [SENSe:]RFAnalyzer:FREQUENCY:UNIT, the default frequency unit can be changed, and even 1xEV-DO channel numbers can be entered instead of frequencies. In the latter case, the assignment of channel numbers and frequencies meets the specification for the reverse channel (signal direction from access terminal to CMU).</p> <p><b>Note:</b> Changing the network standard with the command CONFigure:NETWork:STANdard will also change the analyzer RF frequency.</p>				

[SENSe:]RFAnalyzer:FOFFset[?] <Analyzer Freq. Offset>			Frequency Offset	
<Analyzer Freq. Offset>	Description of parameters	Def. value	Def. unit	FW vers.
-50.0 kHz to +50.0 kHz   ON   OFF	Frequency offset setting Frequency offset on, last setting re-activated No frequency offset	OFF	Hz	V3.40
Description of command				
This command determines a frequency offset to the RF signal analyzed.				

## Subsystem LLEVEL

The subsystem *LLEVEL* controls the level in the RF input signal path. It corresponds to the table section *Analyzer Level* in the *Analyzer* tab of the *Connection Control* menu.

[SENSE:]LEVEL:MODE[?] <RF Level Mode>		RF Level Mode		
<RF Level Mode>	Description of parameters	Def. value	Def. unit	FW vers.
AUTomatic   MANual	Maximum input level mode for RF	MAN	–	V3.40
Description of command				
This command defines whether the maximum expected input level is set manually or using by auto ranging. Using auto-ranging might result in a loss of performance.				

[SENSE:]LEVEL:MAXimum[?] <RF Manual Max Level>		Max. RF Level		
<RF Manual Max Level>	Description of parameters	Def. value	Def. unit	FW vers.
–40 dBm to +44 dBm	Maximum input level for RF 1	0.0	dBm	V3.40
–54 dBm to +30 dBm	Maximum input level for RF 2	0.0	dBm	
–80 dBm to +9 dBm	Maximum input level for RF 4 IN	0.0	dBm	
Description of command				
This command defines the maximum expected input level. The value range depends on the RF input used and the external attenuation set (see [SENSE:]CORREction:LOSS:INPut<nr>[:MAGNitude] command).				

## Subsystem LCMask (Long Code Mask)

The subsystem *LCMask* determines the *Long Code Mask* of the reverse link RF signal. It corresponds to the table section *Analyzer Settings / Long Code Mask* in the *Analyzer* tab of the *Connection Control* menu.

[SENSE:]RFANalyzer:LCMask:I:LSB[?] [SENSE:]RFANalyzer:LCMask:Q:LSB[?] <LSB Long Code Mask>		LSB Long Code Mask		
<LSB Long Code Mask>	Description of parameters	Def. value	Def. unit	FW vers.
"00000000" to "FFFFFFFF"	Hexadecimal formatted string representing the LSB of the long code mask	"00000000"	–	V3.40
Description of command				
This command defines the least significant bits (0 to 31) of the I and Q signal long code masks.				

[SENSE:]RFANalyzer:LCMask:I:MSB[?] [SENSE:]RFANalyzer:LCMask:Q:MSB[?] <MSB Long Code Mask>		MSB Long Code Mask		
<MSB Long Code Mask>	Description of parameters	Def. value	Def. unit	FW vers.
"000" to "3FF"	Hexadecimal formatted string representing the MSB of the long code mask	"000" for I and for Q	–	V3.40
Description of command				
This command defines the most significant bits (32 to 41) of the I and Q signal long code masks.				

### Subsystem CCFilter (Code Channel Filter)

The subsystem *CCFilter* determines the reverse link code channels to be evaluated. It corresponds to the table section *Analyzer Settings / Code Channel Filter* in the *Analyzer* tab of the *Connection Control* menu.

[SENSe:]RFANalyzer:CCFilter:DRC[?] [SENSe:]RFANalyzer:CCFilter:ACK[?] [SENSe:]RFANalyzer:CCFilter:DATA[?] <Code Channel Filter>				
Code Channel Filter				
<Code Channel Filter>	Description of parameters	Def. Value	Def. unit	FW vers.
<b>ON  </b>	The code channel will be measured unless it is inactive. If the code channel is inactive, the appropriate results will return INV.	DCARe	–	V3.40
<b>OFF  </b>	The code channel will not be measured, regardless of whether it is active or not.			
<b>DCARe</b>	Do not care. The code channel will be measured in any case (active or not). Thus the results of some certain measurements appear to be unstable.			
Description of command				
These commands determine if the specified reverse link code channel is evaluated. As the DRC, ACK, and Data code channels are not continuously present, the code channel filters allow the user to specify the conditions under which the measurements are performed.				
<b>Note:</b> If these filters are specified in such a manner that the AT never generates, the measurements will return invalid results.				

### Subsystem AT<nr> (Access Terminal)

The subsystem *AT<nr>* is a container for all analyzer settings that apply separately to one of the four access terminals. It corresponds to the table section *Analyzer Settings / Reverse Link Frame Offset* in the *Analyzer* tab of the *Connection Control* menu.

[SENSe:]RFANalyzer:AT<nr>:RLINK:FROffset[?] <Reverse Link Frame Offset>				
Reverse Link Frame Offset				
<Reverse Link Frame Offset>	Description of parameters	Def. value	Def. unit	FW vers.
<b>0 to 15   DEfault</b>	Reverse link frame offset Use default setting	0	–	V3.40
Description of command				
This command determines the reverse link frame offset for the access terminal <nr> = 1 to 4.				

## Trigger

The remote-control commands presented in this section determine the RF trigger settings. The *Trigger* settings are general (global) settings that are valid for the entire function group.

### Subsystem TRIGger

The subsystem *TRIGger* defines the trigger conditions for the measurements and the routing of output trigger signals. It corresponds to the *Trigger* tab in the second plane of the *Connection Control* menu.

DEFault:TRIGger[:SEQuence][?] <Trigger Source>		Default All Settings		
<Trigger Source>	Description of parameters	Def. value	Def. unit	FW vers.
ON   OFF	The parameters are set to their default values Some or all parameters are not set to default	ON	–	V3.40
Description of command				
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystem TRIGger to their default values (the setting <i>OFF</i> results in an error message).				
If used as a query the command returns whether all parameters are set to their default values ( <i>ON</i> ) or not ( <i>OFF</i> ).				

### Subsystem SElect

TRIGger:SElect:AT[?] <Select Access Terminal>		Select Access Terminal		
<Select Access Terminal>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 4   DEFault	Access terminal number Use default settings	1	–	V3.40
Description of command				
This command selects the specified access terminal. The trigger output signals (see command TRIGger:OUTPut:PIN<nr>:SIGNal) refer to the selected AT.				

### Subsystem SLOPe

TRIGger[:SEQuence]:SLOPe[?] <Trigger Slope>		Trigger Slope		
<Trigger Slope>	Description of parameters	Def. value	Def. unit	FW vers.
NEGative   POSitive   DEFault	Negative Slope (falling edge) Positive Slope (rising edge) Use default settings	POS	–	V3.40
Description of command				
This command defines whether the trigger event occurs on the <i>Rising Edge</i> or on the <i>Falling Edge</i> of the trigger signal. The setting has no influence on <i>Free Run</i> measurements (see TRIGger[:SEQuence]:SOURce).				

### Subsystem OUTPUT

TRIGGER:OUTPUT:PIN<nr>:SIGNAL[?] <Frame_Period>		Trigger Signal Output Routing		
<Trigger Output Routing>	Description of parameters	Def. value	Def. unit	FW vers.
NONE	No output trigger signal	<nr> = 2: NONE <nr> = 3: NONE <nr> = 4: NONE <nr> = 5: NONE	-	V3.40
PP2S	Periodic pulse with period 2 s			
CCHannel	Control channel, 80 ms			
CSLot	Control slot, 26.67 ms			
ATRFrame	Access terminal reverse frame			
ATFSLot	Access terminal forward slot			
SLOT	Slot			
CPCPattern	Periodic pulse, period is determined by the length of the power control pattern.			
IPCPattern	Single pulse that will be set as the first bit of the injected pattern is being sent.			
Description of command				
This command selects the type of periodic pulse signal (or no signal, setting NONE) to be applied to pin <nr> (<nr> = 2 to 5) of the AUX 3 connector.				

### Subsystem THRESHOLD

TRIGGER[:SEQUENCE]:THRESHOLD:RFPower[?] <Threshold RF Power>		Threshold RF Power		
<Threshold RF Power>	Description of parameters	Def. value	Def. unit	FW vers.
LOW	Low trigger threshold (-26 dB)	MED	-	V3.40
MEDium	Medium trigger threshold (-16 dB)			
HIGH	High trigger threshold (-6 dB)			
DEFault	Use default settings			
Description of command				
This command sets the RF signal level at which the measurement is triggered relative to the maximum RF input level; see [SENSE:]LEVEL:MAXimum. The setting has effect for trigger source RFPower only (see TRIGGER[:SEQUENCE]:SOURCE).				

TRIGGER[:SEQUENCE]:THRESHOLD:IFPower[?] <Threshold IF Power >		Threshold IF Power		
<Threshold RF Power>	Description of parameters	Def. value	Def. unit	FW vers.
-47.0 to 0	IF power trigger threshold	-16.0	dB	V3.40
DEFault	Use default settings			
Description of command				
This command sets the IF signal level at which the measurement is triggered. The IF power threshold is defined relative to the maximum RF input level; see [SENSE:]LEVEL:MAXimum. The setting has effect for trigger source IFPower only (see TRIGGER[:SEQUENCE]:SOURCE).				

Subsystem SOURCE

TRIGger[:SEQuence]:SOURce[?] <Source>		Trigger Source		
<Source>	Description of parameters	Def. Value	Def. unit	FW vers.
<b>INT</b> ernal	Trigger source from internal clock	INT	–	V3.40
<b>EXT</b> ernal	External Trigger source supplied			
<b>FRUN</b>	Trigger set to free run			
<b>RFPower</b>	Trigger set to wide-band IF Power			
<b>IFPower</b>	Trigger set to narrow-band RF Power			
<b>DEFault</b>	Use default setting			
Description of command				
This command sets the source of the trigger signal.				
The external trigger source is supplied via the AUX 3 connector on the front panel. The AUX 3 pin assignments are:				
Output trigger signals:	See command TRIGger:OUTPut:PIN<nr>:SIGNal[?]			
Input trigger:	Pin 8			
The trigger setting affects the results of the Transmit Time Error measurement as described here.				
Trigger Free Run	No timing error results are possible.			
Trigger Internal	Timing error results are possible when DUT is correctly synchronized with the CMU.			
IF Power	No timing error results are possible.			
RF Power	No timing error results are possible.			
Trigger External	Timing error results are possible if an external trigger signal is provided and the DUT is correctly synced with the CMU.			
<b>Note:</b>	Using an external trigger source will cause routing conflicts with an external power control bit supply. See also command SOURce:RFGenerator:AT<nr>:PCBits			

## Generator

In the 1xEV-DO function group, an 1xEV-DO forward link test signal can be generated. No signalling parameters are transferred. The only *Control Channel* message that is ever sent is the *Sync. Message*. Furthermore a packet stream for up to four access terminals can be generated.

The remote-control commands presented in this section determine the signals generated by the CMU. They correspond to the settings in the popup menu of the softkey *Connect Control*, located at the top right of each main menu.

In the 1xEV-DO function group the generator settings are general (global) settings that are valid for the entire function group.

## Subsystem RFGenerator

The subsystem *RFGenerator* configures the RF signals generated by the CMU. It corresponds to the tab *Generator* in the popup menu *Connection Control*.

DEFault:RFGenerator[?]		RF Generator		
<RF Analyzer>				
<RF Analyzer>	Description of parameters	Def. value	Def. unit	FW vers.
ON   OFF	The parameters are set to their default values Some or all parameters are not set to default	ON	–	V3.40
Description of command				
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystem <i>RFGenerator</i> to their default values (the setting <i>OFF</i> results in an error message).				
If used as a query the command returns whether all parameters are set to their default values ( <i>ON</i> ) or not ( <i>OFF</i> ).				

INITiate:RFGenerator	Start RF generator, reserve resources	⇒	<i>RUN</i>
ABORt:RFGenerator	Switch off RF generator, release resources	⇒	<i>OFF</i>
Description of command			FW vers.
These commands have no query form. They start and stop the RF generator, setting it to the status indicated in the top right column.			V3.40

FETCh:RFGenerator:STATus?		Generator Status		
Returned values	Description of parameters	Def. Value	Def. unit	FW vers.
OFF   RUN   ERR	Generator switched off (ABORt or *RST) Running (INITiate) Switched off (could not be started)	OFF	–	V3.40
Description of command				
This command is always a query. It returns the current generator status.				

Subsystem FREquency

SOURCE:RFGenerator:FREquency[:RF]:UNIT[?]				Frequency Unit
<Unit>				
<Unit>	Description of parameters	Def. Value	Def. unit	FW vers.
HZ   KHZ   MHZ   GHZ   CH	Frequency unit or Channel Number	HZ	-	V3.40
Description of command				
This command defines whether the frequency of the RF signal generated is specified in frequency units or as an 1xEV-DO channel number. Frequency units must be used to select input signals that are outside the designated 1xEV-DO channel range.				

SOURCE:RFGenerator:FREquency[:RF][?]				RF Frequency
<Frequency>				
<Frequency>	Description of parameters	Def. Value	Def. unit	FW vers.
	RF generator frequency Default frequency for following standards:		Hz	V3.40
9.990000 MHz to 2700.000000 MHz	Band Class 0, US Cellular	878.49 MHz CH 283		
9.990000 MHz to 2700.000000 MHz	Band Class 0, Korean Cellular	878.49 MHz CH 283		
10.000000 MHz to 2700.000000 MHz	Band Class 1, North American PCS	1937.50 MHz CH 150		
9.987500 MHz to 2699.987500 MHz	Band Class 2, TACS	936.9625 MHz CH 79		
10.000000 MHz to 2700.000000 MHz	Band Class 3, JTACS	860.95 MHz CH 76		
10.000000 MHz to 2700.000000 MHz	Band Class 4, Korean PCS	1842.25 MHz CH 45		
10.000000 MHz to 2700.000000 MHz	Band Class 5, NMT 450	460.60 MHz CH 25		
10.000000 MHz to 2700.000000 MHz	Band Class 6, IMT-2000	2110.60 MHz CH 12		
10.000000 MHz to 2700.000000 MHz	Band Class 7, North American 700 MHz	746.60 MHz CH 14		
10.000000 MHz to 2700.000000 MHz	Band Class 8, 1800 MHz	1805.80 MHz CH 16		
10.000000 MHz to 2700.000000 MHz	Band Class 9, North American 900 MHz	925.90 MHz CH 18		
10.000000 MHz to 2700.000000 MHz	Band Class 10, Secondary 800 MHz	852.25 MHz CH 50		
Description of command				
This command defines the frequency of the RF signal generated. With the command SOURCE:RFGenerator:FREquency:UNIT, the default frequency unit can be changed, and even 1xEV-DO channel numbers can be entered instead of frequencies. In the latter case, the assignment of channel numbers and frequencies meets the specification for the forward channel (signal direction from CMU to the AT under test).				
<b>Note:</b> Changing the network standard with the command CONFIGure:NETWork:STANdard will also change the generator RF frequency.				

### Subsystem POWER

SOURce:RFGenerator:POWER:OUTPut[?]		Output Power		
<Output Power>				
<Output Power>	Description of parameters	Def. value	Def. unit	FW vers.
-120.0 dBm to -33.0 dBm   -120.0 dBm to -16.0 dBm   -99.0 dBm to +5.0 dBm	RF1 OUT, 0 dB ext. atten. RF2 OUT, 0 dB ext. atten. RF3 OUT, 0 dB ext. atten	-70.0	dBm	V3.40
Description of command				
This command determines total output power (absolute value, in dBm). The output power value range depends on the RF input used and the external attenuation set (see [SENSE:]CORRection:LOSS:OUTPut<nr>[:MAGNitude] command).				

### Subsystem PROPerTy

SOURce:RFGenerator:PROPerTy:PNOffset[?]		PN Offset		
<PN Offset>				
<PN Offset>	Description of parameters	Def. value	Def. unit	FW vers.
0 to +511   DEfault	PN offset Use default settings	0	-	V3.40
Description of command				
This command defines the PN offset.				

SOURce:RFGenerator:MODE[?]		RF Generator Mode		
<RF Generator Mode>				
<RF Generator Mode>	Description of parameters	Def. value	Def. unit	FW vers.
NORMal   CPILot	RF generator mode	NORM	-	V3.40
Description of command				
This command determines the RF generator mode. Setting the generator mode to <i>CPILot</i> will generate a continuous pilot signal. The pilot signal will fill the entire slot and the power of the signal is determined by the command: SOURce:RFGenerator:POWER:OUTPut[?]				
All other generator commands will be accepted and processed as normal, but the changes to the signal will not occur until the generator mode is switched back to <i>NORMal</i> .				

### Subsystem IMPairments

The subsystem *IMPairments* configures the settings to impair the generated RF signal. It corresponds to table section *Impairments* in the tab *Generator* of the popup menu *Connection Control*.

<b>SOURce:IMPairments:LEVel:AWGN[?]</b>		AWGN Level		
<b>&lt;AWGN Level&gt;</b>				
<b>&lt;AWGN Level&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>-20.0 dB to +4.0 dB   DEF   ON   OFF</b>	AWGN level Sets the value to the default setting AWGN generator on, last setting re-activated AWGN generator off	OFF	dB	V3.40
Description of command				
This command determines an <i>Additional White Gaussian Noise</i> level to impair the RF generator signal.				

<b>SOURce:IMPairments:FOFFset[:RF][?]</b>		RF Frequency Offset		
<b>&lt;Freq. Offset&gt;</b>				
<b>&lt;Freq. Offset&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>-50.0 kHz to +50.0 kHz   DEF   ON   OFF</b>	BS frequency offset setting Sets the value to the default setting BS frequency offset on, last setting re-activated No frequency offset	OFF	Hz	V3.40
Description of command				
This command defines an offset for the RF generator frequency set with the command [SENSe:]RFGenerator:FREQuency <Number>. The offset frequency must be in multiples of 1 Hz.				

### Subsystem SNCMessage (Sync. Message)

The subsystem *SNCMessage* configures the *Sync. Message of the Control Channel* that is required to synchronize access terminals with the CMU. The control channel messages will have the highest priority for placement within the slots. The Sync. Message will be updated constantly, even when the control channel is not enabled.

The subsystem *SNCMessage* corresponds to the tab *Generator* in the popup menu *Connection Control*.

<b>INITiate:RFGenerator:SNCMessage</b>	Start Sync. message (if possible) Start later (if currently not possible)	⇒ RUN ⇒ ON
Description of command		FW vers.
This command has no query form. It initiates the Sync message of the control channel. If sending the Sync. message is currently not possible, the <b>INITiate</b> will take effect when the generator meets the following preconditions:		V3.40
INIT:RFGenerator FETCh:RFGenerator:STATus? RUN		

<b>ABORt:RFGenerator:SNCMessage</b>	Abort Sync. Message	⇒ OFF
Description of command		FW vers.
This command has no query form. This aborts the Sync. message. If no Sync. message is in progress due to wrong generator preconditions the <b>ABORt</b> will delete a previous <b>INITiate</b> from the action list.		V3.40

<b>FETCh:RFGenerator:SNCMessage:STATus?</b>		Generator Sync. Message Status		
Returned values	Description of parameters	Def. Value	Def. unit	FW vers.
<b>OFF  </b>	No Sync. message initiated	ON	–	V3.40
<b>ON  </b>	Sync message initiated but cannot run. Will be started as soon as possible			
<b>RUN</b>	Sync message in progress			
Description of command				
This command is always a query. It returns the current Sync. Message status.				
<b>Note:</b> The default status is <i>ON</i> . Thus the sync. message starts automatically, when the RF generator is initiated. See command <b>FETCh:RFGenerator:STATus?</b>				

<b>SOURce:RFGenerator:SNCMessage:PSOffset[?]</b>		Packet Start Offset		
<b>&lt;Packet Start Offset&gt;</b>				
<Packet Start Offset>	Description of parameters	Def. value	Def. unit	FW vers.
<b>0 to 3  </b>	Packet start offset	0	–	V3.40
<b>DEFault</b>	Sets the value to the default setting			
Description of command				
This command establishes the offset (in slots) from the start of the control channel cycle to the start of the synchronous message capsule that contains the Sync. Message.				

<b>SOURce:RFGenerator:SNCMessage:DRINdex[?]</b>		Data Rate Index																																									
<b>&lt;Data Rate Index&gt;</b>																																											
<b>&lt;Data Rate Index&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.																																							
<b>1 to 2   DEFAult</b>	Data rate index Sets the value to the default setting	1	–	V3.40																																							
Description of command																																											
This command sets the data rate index for the control channel sync. message. The data rate index defines an unambiguous assignment of the data rate and the slot count:																																											
<table border="1"> <thead> <tr> <th>Data Rate Index:</th> <th>Data Rate (kBit/s):</th> <th>SlotCount:</th> </tr> </thead> <tbody> <tr><td>1</td><td>38.4</td><td>16</td></tr> <tr><td>2</td><td>76.8</td><td>8</td></tr> <tr><td>3</td><td>153.6</td><td>4</td></tr> <tr><td>4</td><td>307.2</td><td>2</td></tr> <tr><td>5</td><td>307.2</td><td>4</td></tr> <tr><td>6</td><td>614.4</td><td>1</td></tr> <tr><td>7</td><td>614.4</td><td>2</td></tr> <tr><td>8</td><td>921.6</td><td>2</td></tr> <tr><td>9</td><td>1,228.8</td><td>1</td></tr> <tr><td>10</td><td>1,228.8</td><td>2</td></tr> <tr><td>11</td><td>1,843.2</td><td>1</td></tr> <tr><td>12</td><td>2,457.6</td><td>1</td></tr> </tbody> </table>					Data Rate Index:	Data Rate (kBit/s):	SlotCount:	1	38.4	16	2	76.8	8	3	153.6	4	4	307.2	2	5	307.2	4	6	614.4	1	7	614.4	2	8	921.6	2	9	1,228.8	1	10	1,228.8	2	11	1,843.2	1	12	2,457.6	1
Data Rate Index:	Data Rate (kBit/s):	SlotCount:																																									
1	38.4	16																																									
2	76.8	8																																									
3	153.6	4																																									
4	307.2	2																																									
5	307.2	4																																									
6	614.4	1																																									
7	614.4	2																																									
8	921.6	2																																									
9	1,228.8	1																																									
10	1,228.8	2																																									
11	1,843.2	1																																									
12	2,457.6	1																																									
The data rate can be queried with the command <code>SOURce:RFGenerator:SNCMessage:DRATe?</code>																																											
The slot count can be queried with the command <code>SOURce:RFGenerator:SNCMessage:SCOUnt?</code>																																											

<b>SOURce:RFGenerator:SNCMessage:DRATe?</b>		Data Rate		
<b>&lt;Data Rate&gt;</b>				
<b>&lt;Data Rate&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>38.4 to 76.8</b>	Data rate	38.4	kBit/s	V3.40
Description of command				
This command is always a query. It returns the data rate assigned to the data rate index that can be set with the command <code>SOURce:RFGenerator:SNCMessage:DRINdex</code>				

<b>SOURce:RFGenerator:SNCMessage:SCOUnt?</b>		Slot Count		
<b>&lt;Slot Count&gt;</b>				
<b>&lt;Slot Count&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>8 to 16</b>	Slot count	16	–	V3.40
Description of command				
This command is always a query. It returns the slot count assigned to the data rate index that can be set with the command <code>SOURce:RFGenerator:SNCMessage:DRINdex</code>				

### Subsystem AT<nr> (Access Terminal)

The subsystem *AT<nr>* is a container for all generator settings that apply separately to one of the four access terminals. It corresponds to the table section *Generator Settings/Traffic/AT<nr>* in the *Generator* tab of the popup menu *Connection Control*.

<b>INITiate:RFGenerator:AT&lt;nr&gt;:MAC:INDEX</b> Place MAC index within MAC channel (if possible)		⇒ RUN
Place later (if currently not possible)		⇒ ON
Description of command		FW vers.
<p>This command has no query form.</p> <p>It enables AT&lt;nr&gt; (&lt;nr&gt; = 1 to 4) by placing the proper MAC index within the MAC channel. Packets may then be sent to the AT&lt;nr&gt; with the command <code>INIT:RFGenerator:AT&lt;nr&gt;:PSTream</code></p> <p>If enabling the AT&lt;nr&gt; is currently not possible due to wrong preconditions, the <code>INITiate</code> will take effect when the generator meets the preconditions:</p>		V3.40
<pre>INIT:RFGenerator FETCh:RFGenerator:STATus? RUN</pre>		

<b>ABORt:RFGenerator:AT&lt;nr&gt;:MAC:INDEX</b> Abort MAC Index placement		⇒ OFF
Description of command		FW vers.
<p>This command has no query form.</p> <p>It aborts the placement of the MAC index for AT&lt;nr&gt; within the MAC channel. Thus all transfers to the specified AT will be aborted either. If currently no MAC index can be placed within the MAC channel due to wrong generator preconditions the <code>ABORt</code> will delete a previous <code>INITiate</code> from the action list.</p>		V3.40

<b>FETCh:RFGenerator:AT&lt;nr&gt;:MAC:INDEX:STATus?</b>		MAC Index placement Status		
Returned values	Description of parameters	Def. Value	Def. unit	FW vers.
<b>OFF  </b>	No MAC Index placement initiated	<nr> = 1: ON	–	V3.40
<b>ON  </b>	MAC Index placement initiated but cannot run. Placement will start as soon as possible.	<nr> = 2: OFF <nr> = 3: OFF		
<b>RUN</b>	MAC Index placement in progress	<nr> = 4: OFF		
Description of command				
This command is always a query. It returns the current MAC index placement status.				
<b>Note:</b> The default status for the first AT is <i>ON</i> . Thus the packets may immediately be sent to AT1, when the RF generator is initiated. See command <code>FETCh:RFGenerator:STATus?</code>				

<b>SOURce:RFGenerator:AT&lt;nr&gt;:MAC:INDEX[?]</b>		MAC Index		
<b>&lt;MAC Index&gt;</b>				
<MAC Index>	Description of parameters	Def. Value	Def. Unit	FW vers.
<b>5 to 63  </b> <b>DEFault</b>	MAC Index for AT<nr> Sets the value to the default setting	<nr> = 1: 8 <nr> = 2: 16 <nr> = 3: 25 <nr> = 4: 50	–	V3.40
Description of command				
This command determines the MAC index for the AT<nr> (<nr> = 1 to 4). Each access terminal requires an individual MAC index. If the entered MAC Index conflicts with another access terminal an "Execution error" is generated.				

SOURCE:RFGenerator:AT<nr>:MAC:LEVel[?] <MAC Level>				MAC Level	
<MAC Level>	Description of parameters	Def. value	Def. unit	FW vers.	
-25.0 dB to -7.0 dB   Default	MAC channel level Sets the value to the default setting	-16.0	dB	V3.40	
Description of command					
This command sets the signal level of the MAC channel of the forward 1xEV-DO channel and enables or disables the signal. The individual MAC channel levels for AT<nr> (<nr> = 1 to 4) are in units relative to the total output power.					

INITiate:RFGenerator:AT<nr>:PSTReam	Send Packets to AT<nr> (if possible) Send packets later (if currently not possible)	⇒ RUN ⇒ ON
Description of command		FW vers.
This command has no query form. It initiates the packet stream to AT<nr> (<nr> = 1 to 4). The number of packets to be sent is determined by the command: SOURCE:RFGenerator:AT<nr>:PCOunt When the transmission of a finite number of packets is completed the PSTReam:STATus changes to RDY.  If sending packets is currently not possible, the INITiate will take effect when the generator meets the following preconditions:  INIT:RFGenerator FETCh:RFGenerator:STATus? RUN INIT:RFGenerator:AT<nr>:MAC:INDEx FETCh:RFGenerator:AT<nr>:MAC:INDEx:STATus? RUN		V3.40

ABORt:RFGenerator:AT<nr>:PSTReam	Abort packet transfer	⇒ OFF
Description of command		FW vers.
This command has no query form. It aborts the packet stream to AT<nr>. If no packet stream is in progress due to wrong generator preconditions the ABORt will delete a previous INITiate from the action list.		V3.40

FETCh:RFGenerator:AT<nr>:PSTReam:STATus?				Packet Stream Status	
Returned values	Description of parameters	Def. Value	Def. unit	FW vers.	
OFF	No packet stream initiated	<nr> = 1: ON, 0 <nr> = 2: OFF, 0	-	V3.40	
ON	Packet stream initiated but cannot run. Will started as soon as possible.	<nr> = 3: OFF, 0 <nr> = 4: OFF, 0			
RUN	Packet stream in progress				
RDY	Ready: All (finite) specified packets have been sent to the AT<nr>				
, 0 to 65535	Current number of packets (progress).				
Description of command					
This command is always a query. It returns the status of the packet streams.					
<b>Note:</b> The default status for the first AT is ON. Thus the packets are immediately be sent to AT1, when the RF generator is initiated. See command FETCh:RFGenerator:STATus?					

<b>SOURCE:RFGenerator:AT&lt;nr&gt;:PCOUNT[?]</b> <b>&lt;Packet Count&gt;</b>		Packet Count		
<b>&lt;Packet Start Offset&gt;</b>	Description of parameters	Def. Value	Def. unit	FW vers.
<b>0 to 65535   INFinite   MINimum   MAXimum   DEFault</b>	Packet start offset An unlimited number of packets is sent to AT<nr> Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	<nr> = 1: INF <nr> = 2: 100 <nr> = 3: 100 <nr> = 4: 10	–	V3.40
Description of command				
This command determines the number of packets, that will be sent to AT<nr> (<nr> = 1 to 4).				
<b>Note:</b> MAXimum will set the Packet Count to 65535, not to INFinite.				

<b>SOURCE:RFGenerator:AT&lt;nr&gt;:PSOFFSET[?]</b> <b>&lt;Packet Start Offset&gt;</b>		Packet Start Offset		
<b>&lt;Packet Start Offset&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>0 to +255   DEFault</b>	Packet start offset Sets the value to the default setting	0	–	V3.40
Description of command				
This command will establish the minimum number of slots that are inserted past the end of one packet and the beginning of the next.				
For single slot packets, a value of zero will cause the next packet to be sent in the immediate next slot. For multiple slot packets, a value of zero will cause the next packet transmission to start three slots after the end of the previous packet. The three slot delay is identical to the interleaving delay between slots for multiple slot packets. The offset value is attached to the end of the preceding packet. Therefore, an offset value of zero with a rate change from a single slot packet to a multiple slot packet will cause the first slot of the multiple slot packet to be transmitted in the slot immediately following the single slot packet.				

<b>SOURCE:RFGenerator:AT&lt;nr&gt;:DRINDEX[?]</b> <b>&lt;Data Rate Index&gt;</b>		Data Rate Index		
<b>&lt;Data Rate Index&gt;</b>	Description of parameters	Def. Value	Def. unit	FW vers.
<b>1 to 12   DEFault</b>	Data rate index Sets the value to the default setting	1	–	V3.40
Description of command				
This command sets the data rate index for AT<nr> (<nr> = 1 to 4). The data rate index defines an unambiguous assignment of the data rate and the slot count. This assignment is listed in the description of the command <code>SOURCE:RFGenerator:SNCMessAge:DRINDEX[?]</code> on page 6.20.				
The data rate can be queried with the command <code>SOURCE:RFGenerator:AT&lt;nr&gt;:DRATE?</code>				
The slot count can be queried with the command <code>SOURCE:RFGenerator:AT&lt;nr&gt;:SCOUNT?</code>				

<b>SOURCE:RFGenerator:AT&lt;nr&gt;:DRATE?</b> <b>&lt;Data Rate&gt;</b>		Data Rate		
<b>&lt;Data Rate&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>38.4 to 2457.6</b>	Data rate	38.4	kBit/s	V3.40
Description of command				
This command is always a query. It returns the data rate assigned to the data rate index that can be set with the command <code>SOURCE:RFGenerator:AT&lt;nr&gt;:DRINDEX</code>				

<b>SOURce:RFGenerator:AT&lt;nr&gt;:SCOunt?</b>				Slot Count
<b>&lt;Slot Count&gt;</b>				
<Slot Count>	Description of parameters	Def. value	Def. unit	FW vers.
<b>8 to 16</b>	Slot count	16	–	V3.40
Description of command				
This command is always a query. It returns the slot count assigned to the data rate index that can be set with the command <code>SOURce:RFGenerator:AT&lt;nr&gt;:DRIndex</code>				

<b>SOURce:RFGenerator:AT&lt;nr&gt;:PATTern[?]</b>				Pattern
<b>&lt;Pattern&gt;</b>				
<Pattern>	Description of parameters	Def. value	Def. unit	FW vers.
<b>"00000000" to "FFFFFFF"</b>	Hexadecimal formatted string representing a data pattern.	"00000000"	–	V3.40
Description of command				
This command defines the data patterns that are sent to AT<nr> (<nr> = 1 to 4). The MSB of this value is the first bit of the packet and the word is repeated to fill all space within the packet.				

<b>SOURce:RFGenerator:AT&lt;nr&gt;:DRCLock:STATe[?]</b>				DRCLock State
<b>&lt;DRCLock State&gt;</b>				
<DRCLock State>	Description of parameters	Def. value	Def. unit	FW vers.
<b>0 to 1   DEFAult</b>	DRCLock State Sets the value to the default setting	1	–	V3.40
Description of command				
This command will set the state of the DRCLock bit for the access terminal specified in <nr> (<nr> = 1 to 4).				

<b>SOURce:RFGenerator:AT&lt;nr&gt;:DRCLock:PERiod[?]</b>				DRCLock Period
<b>&lt;DRCLock Period&gt;</b>				
<DRCLock Period>	Description of parameters	Def. value	Def. unit	FW vers.
<b>8   16   ON   OFF   DEFAult</b>	DRCLock period Enable DRCLock period, last setting re-activated Disable DRCLock period Sets the value to the default setting	8	–	V3.40
Description of command				
This command will establish the period (measured in slots) of time between successive transmissions of the DRCLock bit for the access terminal specified in <nr> (<nr> = 1 to 4).				
Any not allowed value within the range is rounded to the nearest allowed value.				

<b>SOURce:RFGenerator:AT&lt;nr&gt;:DRCLock:LENGth[?]</b>				DRCLock Length
<b>&lt;DRCLock Length&gt;</b>				
<DRCLock Length>	Description of parameters	Def. value	Def. unit	FW vers.
<b>1   4   8   16   32   DEFAult</b>	DRCLock length Sets the value to the default setting	1	–	V3.40
Description of command				
This command determines the DRCLock length for the access terminal specified in <nr> (<nr> = 1 to 4). It will establish the number of DRCLock periods that the state of the DRCLock will be held constant.				
Any not allowed value within the range is rounded to the nearest allowed value.				

<b>SOURce:RFGenerator:AT&lt;nr&gt;:PCBits[?]</b> <i>&lt;Power Control Bits&gt;</i>		Power Control Bits		
<i>&lt;Power Control Bits&gt;</i>	Description of parameters	Def. value	Def. unit	FW vers.
<b>HOLD  </b>	Alternating up/down control bits	HOLD	–	V3.40
<b>ADOW  </b>	All power control bits down			
<b>AUP  </b>	All power control bits up			
<b>RTES  </b>	Range test mode			
<b>PATtern  </b>	User specified pattern (continuously repeated)			
<b>EXTernal  </b>	External power control bit source supplied			
<b>DEFault</b>	Sets the value to the default setting			
Description of command				
<p>This command defines the power control bits in the RF generator signal. The state of the power control bit is sampled at the beginning of the slot.</p> <p>The access terminals AT&lt;nr&gt; (&lt;nr&gt; = 1 to 4) can use individual power control bits. A user pattern can be defined with the commands of the :PCBits:PATtern subsystem.</p> <p>The external power control bit source is supplied via pin 8 of the AUX 3 connector on the front panel.</p> <p><b>Note:</b> Using an external power control bit source will cause routing conflicts with an external trigger source. See also command TRIGger[:SEquence]:SOURce</p>				

<b>SOURce:RFGenerator:AT&lt;nr&gt;:PCBits:RTES:NOBits[?]</b> <i>&lt;Number Of Bits&gt;</i>		Number Of Bits		
<i>&lt;Number Of Bits&gt;</i>	Description of parameters	Def. Value	Def. Unit	FW vers.
<b>1 to 256  </b>	Number of bits for range test mode.	100	–	V3.40
<b>DEFault</b>	Sets the value to the default setting			
Description of command				
<p>This command determines the number of bits for the range test mode (&lt;nr&gt; =1 to 4).</p>				

<b>PROCedure:RFGenerator:AT&lt;nr&gt;:PCBits:PATtern[?]</b> <i>&lt;Power Control Bits&gt;</i>		Power Control Pattern Injection		
<i>&lt;Pwr. Ctrl. Pattern Injection&gt;</i>	Description of parameters	Def. value	Def. unit	FW vers.
<b>INJect  </b>	Injects a single power control bit pattern	RDY	–	V3.40
<b>RDY</b>	Ready: Injection cycle is completed (query only)			
Description of command				
<p>The command injects a user defined power control bit pattern into the PCB bit stream for AT&lt;nr&gt;. RDY is a query only.</p>				

SOURCE:RFGenerator:AT<nr1>:PCBits:PATtern:AREA<nr2>:NOBits[?] <Number Of Bits>				Number Of Bits
<Number Of Bits>	Description of parameters	Def. Value	Def. Unit	FW vers.
1 to 128   DEFault	Number of bits in the first pattern area. Sets the value to the default setting	<nr2> = 1: 32	–	V3.40
1 to 128   DEFault	Number of bits in the second pattern area. Sets the value to the default setting	<nr2> = 2: 100		
1 to 128   DEFault	Number of bits in the third pattern area. Sets the value to the default setting	<nr2> = 3: 100		
1 to 128   DEFault	Number of bits in the fourth pattern area. Sets the value to the default setting	<nr2> = 4: 100		
Description of command				
This command determines the number of bits for each of the four areas (<nr2> = 1 to 4). These areas can be configured individually for the AT<nr1> (<nr1> = 1 to 4).				

SOURCE:RFGenerator:AT<nr2>:PCBits:PATtern:AREA<nr2>:POLarity[?] <Polarity>				Polarity
<Polarity>	Description of parameters	Def. value	Def. unit	FW vers.
UP   DOWN   DEFault	Bits up Bits down Sets the value to the default setting	<nr2> = 1: DOWN <nr2> = 2: UP <nr2> = 3: DOWN <nr2> = 4: UP	–	V3.40
Description of command				
This command defines the polarity of the bits for the areas<nr2> = 1 to 4. Each of the access terminals <nr1> = 1 to 4 can use individual settings.				

### Subsystem RAB (Reverse Activity)

The subsystem *RAB* configures the RAB channel.

SOURCE:RFGenerator:RAB:MAC:LEVel[?] <MAC Level>				MAC Level
<MAC Level>	Description of parameters	Def. value	Def. unit	FW vers.
–25.0 dB to –7.0 dB   DEFault	MAC channel level Sets the value to the default setting	–12.0	dB	V3.40
Description of command				
This command will set the amount of power within the MAC channel that is dedicated to the RAB channel. The MAC channel level for the reverse activity bit is in a unit relative to the total output power.				

SOURCE:RFGenerator:RAB:STATe[?] <RAB State>				RAB State
<RAB State>	Description of parameters	Def. value	Def. unit	FW vers.
0 to 1   DEFault	RAB State Sets the value to the default setting	0	–	V3.40
Description of command				
This command sets the state of the <i>Reverse Activity Bit</i> .				

<b>SOURce:RFGenerator:RAB:OFFSet[?]</b>		RAB Offset		
<b>&lt;RAB Offset&gt;</b>				
<b>&lt;RAB Offset&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>0 to 7   DEFAult</b>	RAB offset Sets the value to the default setting	0	–	V3.40
Description of command				
This command will establish the starting time offset of the RA bit. This command is specified in RABLength/8 units. The RA bit starts when the equation (SystemTime mod RABLength = RABOffset) is satisfied, with SystemTime expressed in units of slots.				

<b>SOURce:RFGenerator:RAB:LENGth[?]</b>		RAB Length		
<b>&lt;RAB Length&gt;</b>				
<b>&lt;RAB Length&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>8   16   32   64   DEFAult</b>	RAB length Sets the value to the default setting	8	–	V3.40
Description of command				
This command determines the RAB length. It will establish the duration (in slots) of a RA (Reverse Activity) bit. Any not allowed value within the range is rounded to the nearest allowed value.				

### Subsystem OAT (Other Access Terminals)

The subsystem OAT configures other access terminals (beyond the four defined access terminals). These ATs will never have a packet addressed to them, but are used to provide fill in the MAC channel code domain. These other access terminals are used to evenly distribute the excess power (beyond what is required by the AT<nr> and RAB channels).

<b>SOURce:RFGenerator:OAT:COUNT[?]</b>		Other Access Terminal Count		
<b>&lt;RAB Offset&gt;</b>				
<b>&lt;Count&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>1 to 55   DEFAult</b>	Packet start offset Sets the value to the default setting	5	–	V3.40
Description of command				
This command will establish the number of additional access terminals that appear in the MAC Channel				

## RF Input and Output

The remote-control commands presented in this section determine the inputs and outputs used and the reference frequency. They correspond to the settings in the popup menu of the softkey *Connect Control*, located at the top right of each main menu.

These are general (global) settings that are valid for the entire function group.

### Subsystem RF Input and Output (External Attenuation at Connectors)

The subsystem for input and output configures the input and output RF connectors. The subsystem corresponds to the tab *AF/RF*  in the popup menu *Connect Control*.

<b>INPut[:STATe][?]</b>				RF Input
<b>&lt;State&gt;</b>				
<b>&lt;State&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>RF1  </b>	Connector RF 1 used as input	RF2	–	V3.40
<b>RF2  </b>	Connector RF 2 used as input			
<b>RF4</b>	Connector RF 4 IN used as input			
Description of command				
This command determines the connector to be used for RF input signals. The bidirectional connectors RF 1 and RF 2 can be used both as input and output connectors in the same measurement (see <i>OUTPut[:STATe]</i> ).				
Only one input and one output may be active at the same time, a new RF input setting supersedes the previous one.				

<b>OUTPut[:STATe][?]</b>				RF Output
<b>&lt;State&gt;</b>				
<b>&lt;State&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>RF1  </b>	Connector RF 1 used as output	RF2	–	V3.40
<b>RF2  </b>	Connector RF 2 used as output			
<b>RF3</b>	Connector RF 3 OUT used as output			
Description of command				
This command determines the connector to be used for RF output signals. The bidirectional connectors RF 1 and RF 2 can be used as input and output connectors in the same measurement (see <i>INPut[:STATe]</i> ).				
Only one input and one output may be active at the same time, a new RF output setting supersedes the previous one.				

<b>[SENSe:]CORRection:LOSS:INPut&lt;nr&gt;[:MAGNitude][?]</b>				Ext. Att. Input
<b>SOURce:CORRection:LOSS:INPut&lt;nr&gt;[:MAGNitude][?]</b>				
<b>&lt;Attenuation&gt;</b>				
<b>&lt;Attenuation&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>–50 dB to +90 dB</b>	Value for external attenuation at the input <nr>, where <nr> = 1, 2, 4	0.0	dB	V3.40
Description of command				
This command assigns an external attenuation value to the inputs of the instrument ( <i>RF 1, RF 2, RF 4 IN</i> ).				

[SENSe:]CORREction:LOSS:OUTPut<nr>[:MAGNitude][?] SOURce:CORREction:LOSS:OUTPut<nr>[:MAGNitude][?] <Attenuation>		Ext. Att. Output		
<Attenuation>	Description of parameters	Def. value	Def. unit	FW vers.
-50 dB to +90 dB	Value for external attenuation at output <nr>, where <nr> = 1, 2, 3	0.0	dB	V3.40
Description of command				
This command assigns an external attenuation value to the outputs of the instrument ( <i>RF 1, RF 2, RF 3 OUT</i> ).				

## Subsystem DM:CLOCK (Synchronization)

The subsystem *DM:CLOCK* sets a system clock specific to the network. This frequency is set in the tab *Synch.* in the popup menu *Connect. Control*.

SOURce:DM:CLOCK:STATe[?] <Mode>		REF OUT 2		
<Mode>	Description of parameters	Def. Value	Def. unit	FW vers.
ON   OFF	Switch on/off system clock	OFF	–	V3.40
Description of command				
This commands switches the system clock specific to the network at the <i>REF OUT 2</i> connector on or off. When set to on, the frequency is set at 13.1072 MHz.				

SOURce:DM:CLOCK:FREQuency[?] <Frequency> <Frequency>		System Clock		
<Frequency>	Description of parameters	Def. Value	Def. unit	FW vers.
39.3216 MHz   19.6608 MHz   13.1072 MHz   9.8304 MHz	System Clock Frequency	39.3216 MHz	Hz	V3.40
Description of command				
This command determines the system clock frequency applied to <i>REF OUT 2</i> .				
Any not allowed value within the range is rounded to the nearest allowed value.				

## Measurements

This section describes the measurements that are provided by the 1xEV-DO function group. Please note that both, the specific measurement setup and the general (global) settings from the *RF Analyzer* section have an effect on the measurement results.

## WPOWER (Wide Band Power)

The subsystem *WPOWER* measures the power of the signal transmitted by the access terminal using a wideband filter. It corresponds to the softkey *WPower* in RF connector tab of the *Connect. Control* menu. The main purpose of the wideband power measurement is to indicate whether an input signal is available and whether it is advisable to change the *Max Level* settings.

### Control of Measurement

<b>INITiate:WPOWER</b>	Start new measure ment	⇒ <i>RUN</i>
<b>ABORt:WPOWER</b>	Abort measurement and switch off	⇒ <i>OFF</i>
<b>STOP:WPOWER</b>	Stop measurement	⇒ <i>STOP</i>
<b>CONTinue:WPOWER</b>	Next measurement step (only <i>counting mode</i> )	⇒ <i>RUN</i>
Description of command		FW vers.
These commands have no query form. They start or stop the measurement, setting it to the status given in the top right column.		V3.40

<b>CONFigure:WPOWER:EREPorting[?] &lt;Mode&gt;</b>		Event Reporting		
<Mode>	Description of parameters	Def. value	Def. unit	FW vers.
<b>SRQ  </b>	Service request	OFF	–	V3.40
<b>SOPC  </b>	Single operation complete			
<b>SRSQ  </b>	SRQ and SOPC			
<b>OFF</b>	No reporting			
Description of command				
This command defines the events generated when the measurement is terminated or stopped ( <i>event reporting</i> , see chapter 5 of CMU200 operating manual).				

<b>FETCH:WPOWER:STATus?</b>		Measurement		
<i>Return</i>	Description of parameters	Def. value	Def. unit	FW vers.
<b>OFF  </b>	Measurement in the <i>OFF</i> state (*RST or ABORt)	OFF	–	V3.40
<b>RUN  </b>	Running (after INITiate, CONTinue or READ)			
<b>STOP  </b>	Stopped (STOP)			
<b>ERR  </b>	<i>OFF</i> (could not be started)			
<b>STEP  </b>	Stepping mode (<stepmode>=STEP)	NONE	–	
<b>RDY,</b>	Stopped according to repetition mode and stop condition			
<b>1 ... 10000  </b>	Counter for current statistics cycle			
<b>NONE</b>	No counting mode set			
Description of command				
This command is always a query. It returns the status of the measurement (see chapters 3 and 5 of CMU operating manual).				

## Test Configuration

The commands of the following subsystems configure the WPOWer measurement in *RF connector* tab of the *Connect. Control* menu.

## Subsystem CONTROL

CONFigure:WPOWer:CONTRol:REPetition[?] <Repetition>,<StopCond>,<Stepmode>				Test cycles
<Repetition>	Description of parameters	Def. value	Def. unit	FW vers.
<b>CONTInuous   SINGleshot   1 ... 10000</b>	Continuous measurement (until <i>STOP</i> or <i>ABORT</i> ) Single shot measurement (until <i>Status = RDY</i> ) Multiple measurement ( <i>counting</i> , until <i>Status = STEP   RDY</i> )	SING	–	V3.40
<StopCond>	Description of parameters	Def. value	Def. unit	FW vers.
<b>SONerror   NONE</b>	Start measurement in case of error ( <i>stop on error</i> ) Continue measurement even in case of error	NONE	–	V3.40
<Stepmode>	Description of parameters	Def. value	Def. unit	FW vers.
<b>STEP   NONE</b>	Interrupt measurement after each statistics cycle Continue measurement according to its rep. mode	NONE	–	V3.40
Description of command				
This command determines the number of statistics cycles, the stop condition and the stepping mode for the measurement.				
<b>Note:</b> In the case of <i>READ</i> commands ( <i>READ: ...</i> ), the <Repetition> parameter has no effect; the measurement is always stopped after a single shot.				

## Measured Values

The subsystem *WPOWer?* retrieves the results of the wideband power measurement.

READ[:SCALar]:WPOWer?		Start single shot measurement and return results		
FETCh[:SCALar]:WPOWer?		Read out measurement results (unsynchronized)		
SAMPlE[:SCALar]:WPOWer?		Read out measurement results (synchronized)		
Return	Description of parameters	Def. value	Def. unit	FW vers.
<b>–30.0dBm to +30.0 dBm</b>	Maximum burst power (not averaged)	NAN	dBm	V3.40
Description of command				
These commands are always queries. They start the measurement of the maximum burst power ( <i>peak burst power</i> ) and return the result.				

## NPOwer (Narrow Band Power)

The subsystem *NPOwer* measures the *Narrow Band Power* using the 1xEV-DO receiver filter (according to IS-856-1). The subsystem corresponds to the *NPower* menu and the popup menu *Power Configuration* in the front panel menus. The measurement can be made with a variable number of samples, see command `CONFigure:NPOwer:CONTRol:CBSize`.

### Control of Measurement

The subsystem *NPower* controls the narrow band power measurement. It corresponds to the softkey *NPower* in the measurement menu *Power*.

<b>INITiate:NPOwer</b>	Start new measurement	⇒ <i>RUN</i>
<b>ABORt:NPOwer</b>	Abort running measurement and switch off	⇒ <i>OFF</i>
<b>STOP:NPOwer</b>	Stop measurement after current stat. cycle	⇒ <i>STOP</i>
<b>CONTInue:NPOwer</b>	Next measurement step ( <i>stepping mode</i> )	⇒ <i>RUN</i>
Description of command		FW vers.
These commands have no query form. They start and stop the power measurement, setting it to the status indicated in the top right column.		V3.40

<b>CONFigure:NPOwer:EREPorting[?]</b>		Event Reporting		
<b>&lt;Report Mode&gt;</b>				
<b>&lt;Report Mode&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>SRQ  </b>	Service request	OFF	–	V3.40
<b>SOPC  </b>	Single operation complete			
<b>SRSQ  </b>	SRQ and SOPC			
<b>OFF</b>	No reporting			
Description of command				
This command defines the events generated when the measurement is terminated or stopped (see <i>Event Reporting</i> in Chapter 5 of the CMU manual).				

<b>FETCh[:SCALAr]:NPOwer:STATus?</b>		Measurement Status		
<b>Return</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>OFF  </b>	Measurement in the OFF state (*RST or ABORt)	OFF	–	
<b>RUN  </b>	Running (after INITiate, CONTInue or READ)			
<b>STOP  </b>	Stopped (STOP)			
<b>ERR  </b>	OFF (could not be started)			
<b>STEP  </b>	Stepping mode (<stepmode>=STEP)			
<b>RDY</b>	Stopped according to repetition mode and stop condition			
<b>1 to 10000  </b>	Counter for current statistics cycle	NONE	–	
<b>NONE</b>	No counting mode set			
<b>1 to 1000</b>	Counter for current evaluation period within a cycle	NONE	–	V3.40
<b>NONE</b>	Statistic count set to off			
Description of command				
This command is always a query. It returns the status of the measurement (see Chapters 3 and 5).				

## Test Configuration

The commands of the following subsystems configure the *NPower* measurement in the *Power* menu. They correspond to the *Power Configuration* menu.

## Subsystem CONTROL

The subsystem *NPOWER:CONTROL* defines the repetition mode and statistic count of the measurement.

CONFigure:NPOwer:CONTROL[?] <Statistics>, <Repetition>, <Stop Condition>, <Step Mode>		Scope of Measurement		
<Statistics>	Description of parameters	Def. value	Def. unit	FW vers.
<b>1 to 1000  </b> <b>MINimum  </b> <b>MAXimum  </b> <b>DEF,</b>	Number of bursts per statistics cycle Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	100	–	V3.40
<Repetition>	Description of parameters	Def. value	Def. unit	FW vers.
<b>1 to 10000  </b> <b>CONTinuous  </b> <b>SINGleshot  </b> <b>DEFault,</b>	Multiple measurement (counting, until Status = STEP   RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–	V3.40
<Stop Condition>	Description of parameters	Def. value	Def. unit	FW vers.
<b>NONE  </b> <b>SON,</b>	Continue measurement even in case of error Stop measurement in case of error ( <i>stop on error</i> )	NONE	–	V3.40
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
<b>NONE  </b> <b>STEP</b>	Continue measurement according to its rep. mode Interrupt measurement after each statistics cycle	NONE	–	V3.40
Description of command				
This command combines the ...CONTROL:STATistics and the ...CONTROL:REPetition commands				

CONFigure:NPOwer:CONTROL:STATistics[?] <Statistics>		Statistic Count		
<Statistics>	Description of parameters	Def. value	Def. unit	FW vers.
<b>1 to 1000  </b> <b>MINimum  </b> <b>MAXimum  </b> <b>DEF</b>	Number of bursts per statistics cycle Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	100	–	V3.40
Description of command				
This command specifies the type of measured values and defines the number of bursts forming a statistics cycle.				

CONFigure:NPOwer:CONTRol:REPetition[?] <Repetition>, <Stop Cond>, <Step Mode>				Test Cycles
<Repetition>	Description of parameters	Def. value	Def. unit	FW vers.
<b>1 to 10000  </b> <b>CONTinuous  </b> <b>SINGleshot  </b> <b>DEFault,</b>	Multiple measurement (counting, until Status = STEP   RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–	V3.40
<Stop Cond>	Description of parameters	Def. value	Def. unit	FW vers.
<b>NONE  </b> <b>SONerror  </b> <b>DEFault,</b>	Continue measurement even in case of error Stop measurement in case of error ( <i>stop on error</i> ) Default value	NONE	–	V3.40
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
<b>NONE  </b> <b>STEP  </b> <b>DEFault</b>	Continue measurement according to its rep. mode Interrupt measurement after each statistics cycle Default value	NONE	–	V3.40
Description of command				
This command determines the number of statistics cycles for the measurement.				
<b>Note:</b> In the case of <i>READ</i> commands ( <i>READ:...</i> ), the <Repetition> parameter has no effect; the measurement is always stopped after a single shot.				

CONFigure:NPOwer:CONTRol:CBSize[?] <Samples>				Extend Capture Buffer
<Samples>	Description of parameters	Def. value	Def. unit	FW vers.
<b>1024 to 32768  </b> <b>DEFault</b>	Total number of samples Sets the value to the default setting	4096	–	V3.40
Description of command				
This command specifies the number of samples acquired to calculate a single shot NPOwer result. The default value corresponds to an oversampling factor of 4. Increasing the number of samples slows down the measurement but may be necessary to obtain stable and accurate results, because 1xEV-DO signals typically show rapid variations in time and a large crest factor.				

## Measured Values

The subsystem *NPOwer* determines and outputs the results of the Narrow Band Power measurements.

READ[:SCALar]:NPOwer? FETCh[:SCALar]:NPOwer? SAMPle[:SCALar]:NPOwer?				Scalar results:
		Start single shot measurement and return results		
		Read out measurement results (unsynchronized)		
		Read out measurement results (synchronized)		
Returned values	Description	Def. value	Def. unit	FW vers.
<b>Avg. Power of Current evaluation period,</b>	-137 dBm to +53 dBm		dBm	V3.40
<b>Min. Power of Current evaluation period,</b>	-137 dBm to +53 dBm		dBm	
<b>Max. Power of Current evaluation period,</b>	-137 dBm to +53 dBm		dBm	
<b>Avg. Power referenced to a stat. cycle,</b>	-137 dBm to +53 dBm		dBm	
<b>Min. Power of the entire measurement,</b>	-137 dBm to +53 dBm		dBm	
<b>Max. Power of the entire measurement</b>	-137 dBm to +53 dBm		dBm	
Description of command				
These commands are always queries. They start a measurement and output all scalar measurement results.				

## MODulation:MQQuality (Modulation Quality)

The subsystem *MODulation:MQQuality* measures general scalar modulation parameters. The subsystem corresponds to the *Analyzer/Generator* menu and the popup menu *Modulation Quality Configuration*.

### Control of Measurement

The subsystem *MODulation:MQQuality* controls the modulation quality measurement. It corresponds to the softkey *Mod. Qual.* in the measurement menu *Analyzer/Generator*.

<b>INITiate:MODulation:MQQuality:HPSK</b>	Start new measurement	⇒	<i>RUN</i>
<b>ABORt:MODulation:MQQuality:HPSK</b>	Abort running measurement and switch off	⇒	<i>OFF</i>
<b>STOP:MODulation:MQQuality:HPSK</b>	Stop measurement after current stat. Cycle	⇒	<i>STOP</i>
<b>CONTinue:MODulation:MQQuality:HPSK</b>	Next measurement step ( <i>stepping mode</i> )	⇒	<i>RUN</i>
Description of command			FW vers.
These commands have no query form. They start and stop the modulation measurement, setting it to the status indicated in the top right column.			V3.40

<b>CONFigure:MODulation:MQQuality:HPSK:EREPorting[?]</b>		Event Reporting		
<i>&lt;Report Mode&gt;</i>				
<b>&lt;Report Mode&gt;</b>	Description of parameters	Def. Value	Def. unit	FW vers.
<b>SRQ  </b>	Service request	OFF	–	V3.40
<b>SOPC  </b>	Single operation complete			
<b>SRSQ  </b>	SRQ and SOPC			
<b>OFF  </b>	No reporting			
<b>DEFault</b>	Sets the value to the default setting			
Description of command				
This command defines the events generated when the measurement is terminated or stopped (see Chapter 5 of the CMU 200 Operating manual about event reporting).				

<b>FETCH[:SCALar]:MODulation:MQQuality:HPSK:STATus?</b>		Measurement Status		
<b>Returned values</b>	Description of parameters	Def. Value	Def. unit	FW vers.
<b>OFF  </b>	Measurement in the OFF state (*RST or ABORT)	OFF	–	V3.40
<b>RUN  </b>	Running (after INITiate, CONTinue or READ)			
<b>STOP  </b>	Stopped (STOP)			
<b>ERR  </b>	OFF (could not be started)			
<b>STEP  </b>	Stepping mode (<stepmode>=STEP)			
<b>RDY</b>	Stopped according to repetition mode and stop condition			
<b>1 to 10000  </b>	Counter for current statistics cycle			
<b>NONE</b>	No counting mode set			
<b>1 to 1000</b>	Counter for current evaluation period within a cycle			
<b>NONE</b>	Statistic count set to off			
Description of command				
This command is always a query. It returns the status of the measurement (see Chapters 3 and 5).				

**Test Configuration**

The commands of the following subsystems configure the *Modulation Quality* measurement in the *Analyzer/Generator* menu. They correspond to the *Modulation Quality Configuration* menu.

**Subsystem CONTROL**

The subsystem *MODulation:MQuality:CONTROL* configures the modulation quality measurement. It corresponds to the *Control* tab in the popup menu *Modulation Quality Configuration*.

<b>DEFault:MODulation:MQuality:HPSK:CONTROL[?]</b>		Default Settings		
<b>&lt;Enable&gt;</b>				
<b>&lt;Enable&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>ON  </b>	The parameters are set to their default values	ON	–	V3.40
<b>OFF</b>	Some or all parameters are not set to default			
Description of command				
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the <i>MODulation:MQuality:HPSK:CONTROL</i> subsystem to their default values (the setting <i>OFF</i> results in an error message).				
If used as a query the command returns whether all parameters are set to their default values ( <i>ON</i> ) or not ( <i>OFF</i> ).				

<b>CONFigure:MODulation:MQuality:HPSK:CONTROL[?]</b>		Scope of Measurement		
<b>&lt;Statistics&gt;, &lt;Repetition&gt;, &lt;Stop Cond&gt;, &lt;Step Mode&gt;</b>				
<b>&lt;Statistics&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>1 to 1000,</b>	Number of bursts within a statistics cycle	100	–	V3.40
<b>&lt;Repetition&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>1 to 10000  </b>	Multiple measurement (counting, until Status = STEP   RDY)Continuous measurement (until STOP or ABORT)	SING	–	V3.40
<b>CONT  </b>	Single shot measurement (until Status = RDY)			
<b>SING  </b>	Sets the value to the default setting			
<b>DEF,</b>				
<b>&lt;Stop Cond&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>NONE  </b>	Continue measurement even in case of error	NONE	–	V3.40
<b>SONerror  </b>	Stop measurement in case of error ( <i>stop on error</i> )			
<b>DEF,</b>	Sets the value to the default setting			
<b>&lt;Step Mode&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>NONE  </b>	Continue measurement according to its rep. mode	NONE	–	V3.40
<b>STEP  </b>	Interrupt measurement after each statistics cycle			
<b>DEF</b>	Sets the value to the default setting			
Description of command				
This command sets all measurement control parameters. It combines the <i>...CONTROL:STATistics</i> and the <i>...CONTROL:REPetition</i> commands.				

CONFigure:MODulation:MQuality:HPSK:CONTrol:STATistics[?]				Statistic Count
<Statistics>				
<Statistics>	Description of parameters	Def. Value	Def. unit	FW vers.
1 to 1000	Number of bursts within a statistics cycle	100	–	V3.40
Description of command				
This command selects the type of measured values and determines the number of bursts forming one statistics cycle.				

CONFigure:MODulation:MQuality:HPSK:CONTrol:REPetition[?]				Test Cycles
<Repetition>, <Stop Cond>, <Step Mode>				
<Repetition>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 10000 CONT   SING   DEF,	Multiple measurement (counting, until Status = STEP   RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–	V3.40
<Stop Cond>	Description of parameters	Def. value	Def. unit	FW vers.
NONE   SONerror   DEF,	Continue measurement even in case of error Stop measurement in case of error ( <i>stop on error</i> ) Sets the value to the default setting	NONE	–	V3.40
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
NONE   STEP   DEF	Continue measurement according to its rep. mode Interrupt measurement after each statistics cycle Sets the value to the default setting	NONE	–	V3.40
Description of command				
This command determines the number of statistics cycles, the stop condition and the stepping mode for the measurement.				
<b>Note:</b> In the case of READ commands (READ:...), the <Repetition> parameter has no effect; the measurement is always stopped after a single shot.				

CONFigure:MODulation:MQuality:HPSK:CONTrol:FOFFset:SBSuppress:ACP<nr>[?]				Sideband Frequency Offset
<Freq. Offset>				
<Freq. Offset>	Description of parameters	Def. value	Def. unit	FW vers.
0 to 2 MHz   DEF   OFF   ON	Sideband frequency offset Sets the value to the default setting   minimum   maximum Measurement disabled, result INV Enable measurement, last setting re-activated	see below	Hz	V3.40
Description of command				
The sideband suppression measurement yields 4 pairs of results corresponding to symmetrical frequency offsets to the RF frequency (command [SENSe:]RFANalyzer:FREQUENCY[?]) using a gaussian filter with a bandwidth of 30 kHz.				
This command determines these four frequency offset values (<nr> = 1 to 4). The sideband suppression frequency offset depends on the network standard (CONFigure:NETWork:STANdard). The default values are the same as listed in the command: CONFigure:SPECTrum:ACP:CONTrol:FOFFset:ACP<nr>[?]				

**Subsystem LIMit**

The subsystem *MODulation:MQuality...:LIMit* defines tolerance values for the modulation quality measurement. The subsystem corresponds to the *Limits* tab in the popup menu *Modulation Quality Configuration*.

CONFigure:MODulation:MQuality:HPSK:CMMax:LIMit[?]				Limits
<Rho Limit>, <Carrier Freq. Error Limit>, <Transmit Time Error Limit>, <Carrier Feedthrough Limit>, <IQ Imbalance>, <Sideband Suppr. 1>, <Sideband Suppr. 2>, <Sideband Suppr. 3>, <Sideband Suppr. 4>				
<Rho Limit>	Description of parameters	Def. value	Def. unit	FW vers.
0.0 to 1.0   OFF   ON,	Limit for Rho No Rho limit check Limit check on, last setting re-activated	0.944	–	V3.40
<Carrier Freq. Error Limit>	Description of parameters	Def. value	Def. unit	FW vers.
0 Hz to 1000 Hz   OFF   ON,	Upper limit for carrier frequency error No carrier frequency error limit check Limit check on, last setting re-activated	300	Hz	V3.40
<Transmit Time Error Limit>	Description of parameters	Def. value	Def. unit	FW vers.
0.0 s to 0.00001 s   OFF   ON,	Upper limit for transmit time error No transmit time error limit Limit check on, last setting re-activated	0.000001	s	V3.40
<Carrier Feedthrough Limit>	Description of parameters	Def. value	Def. unit	FW vers.
–120 dB to –20 dB   OFF   ON,	Upper limit for carrier feedthrough No carrier feedthrough limit check Limit check on, last setting re-activated	–25	dB	V3.40
<IQ Imbalance>	Description of parameters	Def. value	Def. unit	FW vers.
–120.0 dB to –20.0 dB   OFF   ON,	Upper limit for IQ Imbalance.	–30	dB	V3.40
<Sideband Suppr. 1>	Description of parameters	Def. value	Def. unit	FW vers.
–128 dB to 0 dB   OFF   ON,	Limit for sideband suppression at freq. offset 1 No sideband suppres limit check Limit check on, last setting re-activated	–43	dB	V3.40
<Sideband Suppr. 2>	Description of parameters	Def. value	Def. unit	FW vers.
–128 dB to 0 dB   OFF   ON,	Limit for sideband suppression at freq. offset 2 No sideband suppres limit check Limit check on, last setting re-activated	–54	dB	V3.40
<Sideband Suppr. 3>	Description of parameters	Def. value	Def. unit	FW vers.
–128 dB to 0 dB   OFF   ON,	Limit for sideband suppression at freq. offset 3 No sideband suppres limit check Limit check on, last setting re-activated	–43	dB	V3.40
<Sideband Suppr. 4>	Description of parameters	Def. value	Def. unit	FW vers.
–128 dB to 0 dB   OFF   ON	Limit for sideband suppression at freq. offset 4 No sideband suppres limit check Limit check on, last setting re-activated	–43	dB	V3.40
Description of command				
This command defines limits for <i>Current</i> and <i>Max/Min</i> quantities describing the modulation quality.				

CONFigure:MODulation:MQuality:HPSK:AVERage:LIMit[?]				Limits
<Rho Limit>, <Carrier Freq. Error Limit>, <Transmit Time Error Limit>, <Carrier Feedthrough Limit>, <IQ Imbalance>, <Sideband Suppr. 1>, <Sideband Suppr. 2>, <Sideband Suppr. 3>, <Sideband Suppr. 4>				
<Rho Limit>	Description of parameters	Def. value	Def. unit	FW vers.
0.0 to 1.0   OFF   ON,	Limit for Rho No Rho limit check Limit check on, last setting re-activated	0.944	–	V3.40
<Carrier Freq. Error Limit>	Description of parameters	Def. value	Def. unit	FW vers.
0 Hz to 1000 Hz   OFF   ON,	Upper limit for carrier frequency error No carrier frequency error limit check Limit check on, last setting re-activated	300	Hz	V3.40
<Transmit Time Error Limit>	Description of parameters	Def. value	Def. unit	FW vers.
0.0 s to 0.00001 s   OFF   ON,	Upper limit for transmit time error No transmit time error limit Limit check on, last setting re-activated	0.000001	s	V3.40
<Carrier Feedthrough Limit>	Description of parameters	Def. value	Def. unit	FW vers.
–120 dB to –20 dB   OFF   ON,	Upper limit for carrier feedthrough No carrier feedthrough limit check Limit check on, last setting re-activated	–25	DB	V3.40
<IQ Imbalance>	Description of parameters	Def. value	Def. unit	FW vers.
–120.0 dB to –20.0 dB   OFF   ON,	Upper limit for IQ Imbalance.	–30	dB	V3.40
<Sideband Suppr. 1>	Description of parameters	Def. value	Def. unit	FW vers.
–128 dB to 0 dB   OFF   ON,	Limit for sideband suppression at freq. offset 1 No sideband suppress limit check Limit check on, last setting re-activated	–43	dB	V3.40
<Sideband Suppr. 2>	Description of parameters	Def. value	Def. unit	FW vers.
–128 dB to 0 dB   OFF   ON,	Limit for sideband suppression at freq. offset 2 No sideband suppress limit check Limit check on, last setting re-activated	–54	dB	V3.40
<Sideband Suppr. 3>	Description of parameters	Def. value	Def. unit	FW vers.
–128 dB to 0 dB   OFF   ON,	Limit for sideband suppression at freq. offset 3 No sideband suppress limit check Limit check on, last setting re-activated	–43	dB	V3.40
<Sideband Suppr. 4>	Description of parameters	Def. value	Def. unit	FW vers.
–128 dB to 0 dB   OFF   ON	Limit for sideband suppression at freq. offset 4 No sideband suppress limit check Limit check on, last setting re-activated	–43	dB	V3.40
Description of command				
This command defines limits for the Average quantities describing the modulation quality.				

<b>DEFAult:MODulation:MQuality:HPSK:CMMax:LIMit[?]</b>		Default Settings		
<b>&lt;Enable&gt;</b>				
<b>&lt;Enable&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>ON  </b>	The parameters are set to their default values	ON	–	V3.40
<b>OFF</b>	Some or all parameters are not set to default			
Description of command				
<p>If used as a setting command with the parameter <i>ON</i>, this command sets all parameters of the MODulation:MQuality*:LIMit subsystem to their default values (the setting <i>OFF</i> results in an error message). The length of the parameter lists in the CONFigure:MODulation:MQuality...CMMax:LIMit commands is not affected.</p> <p>If used as a query, the command returns whether all parameters are set to their default values (<i>ON</i>) or not (<i>OFF</i>).</p> <p>The keyword <i>CMMax</i> refers to the <i>Current</i> and <i>Max./Min.</i> limits.</p>				

<b>DEFAult:MODulation:MQuality:HPSK:AVERage:LIMit[?]</b>		Default Settings		
<b>&lt;Enable&gt;</b>				
<b>&lt;Enable&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>ON  </b>	The parameters are set to their default values	ON	–	V3.40
<b>OFF</b>	Some or all parameters are not set to default			
Description of command				
<p>If used as a setting command with the parameter <i>ON</i>, this command sets all parameters of the MODulation:MQuality*:LIMit subsystem to their default values (the setting <i>OFF</i> results in an error message). The length of the parameter lists in the CONFigure:MODulation:MQuality...AVERage:LIMit commands is not affected.</p> <p>If used as a query, the command returns whether all parameters are set to their default values (<i>ON</i>) or not (<i>OFF</i>).</p>				

**Measured Values**

The subsystem *MODulation* measures and returns the modulation parameters and compares them with the tolerance values. The subsystem corresponds to the various output elements in the measurement menu *Analyzer/Generator*.

<b>READ[:SCALar]:MODulation:MQuality:HPSK?</b>		Start single shot measurement and return results		
<b>FETCh[:SCALar]:MODulation:MQuality:HPSK?</b>		Read out measurement results (unsynchronized)		
<b>SAMPlE[:SCALar]:MODulation:MQuality:HPSK?</b>		Read out measurement results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
<b>AT Power (x3),</b>	-120.0 dBm to -33.0 dBm	NAN	dBm	V3.40
<b>Rho (x3),</b>	0.0 to +1.0	NAN	-	
<b>Carrier Frequency Error (x3),</b>	-10.0 Hz to 0.0 Hz	NAN	Hz	
<b>Transmit Time Error (x3),</b>	0.0 to 0.00001	NAN	s	
<b>Carrier Feedthrough (x3),</b>	-120.0 dB to -20.0 dB	NAN	dB	
<b>IQ Imbalance (x3),</b>	-120.0 dB to -20.0 dB	NAN	dB	
<b>Lower Sideband Supp. 1 (x3),</b>	-120 dB to 10 dB	NAN	dB	
<b>Upper Sideband Supp. 1 (x3)</b>	-120 dB to 10 dB	NAN	dB	
<b>Lower Sideband Supp. 2 (x3),</b>	-120 dB to 10 dB	NAN	dB	
<b>Upper Sideband Supp. 2 (x3)</b>	-120 dB to 10 dB	NAN	dB	
<b>Lower Sideband Supp. 3 (x3),</b>	-120 dB to 10 dB	NAN	dB	
<b>Upper Sideband Supp. 3 (x3)</b>	-120 dB to 10 dB	NAN	dB	
<b>Lower Sideband Supp. 4 (x3),</b>	-120 dB to 10 dB	NAN	dB	
<b>Upper Sideband Supp. 4 (x3)</b>	-120 dB to 10 dB	NAN	dB	
<b>Out of Tolerance</b>	0% to 100 %	NAN	%	
Description of command				
<p>These commands are always queries. They start a modulation measurement and output all scalar measurement results (see Chapter 4). The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i>, the <i>Average</i>, and the <i>MMax</i> value. Sideband Supp. 1 to Sideband Supp. 4 denotes the sideband suppression at offset frequencies 1 to 4; see command</p> <p>CONFigure:MODulation:MQuality:HPSK:CONTRol:FOffset:SBSuppress:ACP&lt;nr&gt;[?].</p>				

CALCulate[:SCALar]:MODulation:MQuality:HPSK:MATChing:LIMIt?		Limit Matching														
Returned values	Value range	Def. value	Def. unit	FW vers.												
Rho (x3), Carrier Frequency Error (x3), Transmit Time Error (x3), Carrier Feedthrough (x3), IQ Imbalance (x3), Lower Sideband Supp. 1 (x3), Upper Sideband Supp. 1 (x3), Lower Sideband Supp. 2 (x3), Upper Sideband Supp. 2 (x3), Lower Sideband Supp. 3 (x3), Upper Sideband Supp. 3 (x3), Lower Sideband Supp. 4 (x3), Upper Sideband Supp. 4 (x3)	For all measured values:  NMAU   NMAL   INV   OK	INV INV INV INV INV INV INV INV INV INV INV INV	- - - - - - - - - - - -	V3.40												
Description of command																
<p>This command is always a query. It indicates whether and in which way the error limits for the scalar measured values (see above command) have been exceeded. The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i>, the <i>Average</i>, and the <i>MMax</i> value. Sideband Supp. 1 to Sideband Supp. 4 denotes the sideband suppression at offset frequencies 1 to 4; see command <code>CONFigure:MODulation:MQuality:HPSK:CONTrol:FOFFset:SBSuppress:ACP&lt;nr&gt;[?]</code>.</p> <p>The following messages may be output for all measured values:</p> <table border="0"> <tr> <td>NMAU</td> <td>Underflow of tolerance value</td> <td><i>not matching, underflow</i></td> </tr> <tr> <td>NMAL</td> <td>Tolerance value exceeded</td> <td><i>not matching, overflow</i></td> </tr> <tr> <td>INV</td> <td>Measurement invalid</td> <td><i>invalid</i></td> </tr> <tr> <td>OK</td> <td>all tolerances matched</td> <td></td> </tr> </table>					NMAU	Underflow of tolerance value	<i>not matching, underflow</i>	NMAL	Tolerance value exceeded	<i>not matching, overflow</i>	INV	Measurement invalid	<i>invalid</i>	OK	all tolerances matched	
NMAU	Underflow of tolerance value	<i>not matching, underflow</i>														
NMAL	Tolerance value exceeded	<i>not matching, overflow</i>														
INV	Measurement invalid	<i>invalid</i>														
OK	all tolerances matched															

## MODulation:OVERview

The subsystem *MODulation:OVERview* measures general scalar modulation parameters of the AT transmitter output signal. The subsystem corresponds to the measurement menu *Modulation* and the associated popup menu *Modulation Configuration*.

### Control of Measurement

The subsystem *MODulation:OVERview* controls the modulation overview measurement. It corresponds to the softkey *Overview HPSK* in the measurement menu *Modulation*.

<b>INITiate:MODulation:OVERview:HPSK</b>	Start new measurement	⇒ <i>RUN</i>
<b>ABORT:MODulation:OVERview:HPSK</b>	Abort running measurement and switch off	⇒ <i>OFF</i>
<b>STOP:MODulation:OVERview:HPSK</b>	Stop measurement after current stat. cycle	⇒ <i>STOP</i>
<b>CONTinue:MODulation:OVERview:HPSK</b>	Next measurement step ( <i>stepping mode</i> )	⇒ <i>RUN</i>
Description of command		FW vers.
These commands have no query form. They start and stop the modulation overview measurement, setting it to the status indicated in the top right column.		V3.40

CONFigure:MODulation:OVERview:HPSK:EREPorting[?] <Report Mode>		Event Reporting		
<Report Mode>	Description of parameters	Def. value	Def. unit	FW vers.
<b>SRQ</b>	Service request	OFF	–	V3.40
<b>SOPC</b>	Single operation complete			
<b>SRSQ</b>	SRQ and SOPC			
<b>OFF</b>	No reporting			
<b>Default</b>	Sets the value to the default setting			
Description of command				
This command defines the events generated when the measurement is terminated or stopped (see <i>Event Reporting</i> in Chapter 5 of the CMU manual).				

FETCh[:SCALar]:MODulation:OVERview:HPSK:STATus?		Measurement Status		
Returned values	Description of parameters	Def. value	Def. unit	FW vers.
<b>OFF</b>	Measurement in the OFF state (*RST or ABORt)	OFF	–	V3.40
<b>RUN</b>	Running (after INITiate, CONTInue or READ)			
<b>STOP</b>	Stopped (STOP)			
<b>ERR</b>	OFF (could not be started)			
<b>STEP</b>	Stepping mode (<stepmode>=STEP)			
<b>RDY</b>	Stopped according to repetition mode and stop condition			
<b>1 to 10000</b>	Counter for current statistics cycle	NONE	–	
<b>NONE</b>	No counting mode set			
<b>1 to 1000</b>	Counter for current evaluation period within a cycle	NONE	–	
<b>NONE</b>	Statistic count set to off			
Description of command				
This command is always a query. It returns the status of the measurement (see Chapters 3 and 5).				

## Test Configuration

The commands of the following subsystems configure the *Modulation Overview* measurement in the *Modulation* menu. They correspond to the *Modulation Overview Configuration* menu.

## Subsystem CONTROL

The subsystem *MODulation:OVERview:CONTRol* configures the modulation overview measurement. It corresponds to the *Control* tab in the popup menu *Modulation Configuration*.

DEFault:MODulation:OVERview:HPSK:CONTRol[?]		Default Settings		
<b>&lt;Enable&gt;</b>				
Enable	Description of parameters	Def. value	Def. unit	FW vers.
<b>ON   OFF</b>	The parameters are set to their default values Some or all parameters are not set to default	ON	–	V3.40
Description of command				
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystem <i>MODulation:OVERview:...:CONTRol</i> to their default values (the setting <i>OFF</i> results in an error message).				
If used as a query, the command returns whether all parameters are set to their default values ( <i>ON</i> ) or not ( <i>OFF</i> ).				

CONFiGure:MODulation:OVERviewHPSK:CONTRol[?]		Scope of Measurement		
<b>&lt;Statistic Count&gt;, &lt;Repetition&gt;, &lt;Stop Cond&gt;, &lt;Step Mode&gt;</b>				
<Statistic Count>	Description of parameters	Def. value	Def. unit	FW-Vers.
<b>1 to 1000,</b>	Number of bursts per statistics cycle	100	–	V3.40
<Repetition>	Description of parameters	Def. value	Def. unit	FW-Vers.
<b>1 to 10000   CONTInuous   SINGleshot   DEFault,</b>	Multiple measurement (counting, until Status = STEP   RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–	V3.40
<Stop Cond>	Description of parameters	Def. value	Def. unit	FW-Vers.
<b>NONE   SONerror   DEFault,</b>	Continue measurement even in case of error Stop measurement in case of error ( <i>stop on error</i> ) Sets the value to the default setting	NONE	–	V3.40
<Step Mode>	Description of parameters	Def. value	Def. unit	FW-Vers.
<b>STEP   NONE   DEFault</b>	Interrupt measurement after each statistics cycle Continue measurement according to its rep. Mode Sets the value to the default setting	NONE	–	V3.40
Description of command				
This command combines the <i>...CONTRol:STATistics</i> and the <i>...CONTRol:REPetition</i> commands, see below.				

CONFiGure:MODulation:OVERview:HPSK:CONTRol:STATistics[?]		Statistic Count		
<b>&lt;Statistic Count&gt;</b>				
<Statistic Count>	Description of parameters	Def. value	Def. unit	FW-Vers.
<b>1 to 1000</b>	Number of bursts per statistics cycle	100	–	V3.40
Description of command				
This command specifies the type of measured values and defines the number of bursts forming a statistics cycle.				

CONFigure:MODulation:OVERview:HPSK:CONtrol:REPetition[?] <Repetition>, <Stop Cond>, <Step Mode>				Test Cycles
<Repetition>	Description of parameters	Def. value	Def. unit	FW vers.
<b>1 to 10000  </b> <b>CONTInuous  </b> <b>SINGleshot  </b> <b>DEFault,</b>	Multiple measurement (counting, until Status = STEP   RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–	V3.40
<Stop Cond>	Description of parameters	Def. value	Def. unit	FW vers.
<b>NONE  </b> <b>SONerror  </b> <b>DEFault,</b>	Continue measurement even in case of error Stop measurement in case of error ( <i>stop on error</i> ) Sets the value to the default setting	NONE	–	V3.40
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
<b>STEP  </b> <b>NONE  </b> <b>DEFault</b>	Interrupt measurement after each statistics cycle Continue measurement according to its rep. Mode Sets the value to the default setting	NONE	–	V3.40
Description of command				
This command determines the repetition mode, stop condition, and stepping mode for the measurement.				
<b>Note:</b> In the case of READ commands (READ: ...), the <Repetition> parameter has no effect; the measurement is always stopped after a single shot.				

### Subsystem LIMit

The subsystem *MODulation:OEMP:...:LIMit* defines the tolerance values for the scalar results of the following modulation measurements (*OEMP*):

- Overview
- Error Vector Magnitude
- Magnitude Error
- Phase Error.

The subsystem corresponds to the *Limits* tab in the popup menu *Modulation Quality Configuration*. Different limits can be configured for the the *Current* and *Max./Min.* traces.

CONFigure:MODulation:OEMP:HPSK:CMMax:LIMit[:SCALar]:SYMMetric[:COMBined][?]		Limits		
<Limit_Peak_EVM>, <Enable>, <Limit_RMS_EVM>, <Enable>, <Limit_Peak_ME>, <Enable>, <Limit_RMS_ME>, <Enable>, <Limit_Peak_PE>, <Enable>, <Limit_RMS_PE>, <Enable>, <Carrier_Feedthrough_Limit>, <Enable>, <IQ_Imbalance_Limit>, <Enable>, <Carrier_Freq_Error_Limit>, <Enable>, <Tx_Time_Error_Limit>, <Enable>, <Rho_Limit>, <Enable>				
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON   OFF,	Switch limit check for parameter preceding <Enable> on or off	ON	–	V3.40
Parameters	Description of parameters	Def. value	Def. unit	FW vers.
0.0 % to +100.0 %,	(EVM) Error Vector Magnitude Error Peak	+33.4	%	V3.40
0.0 % to +100.0 %,	(EVM) Error Vector Magnitude Error RMS	+23.6	%	
0.0 % to +100.0 %,	(ME) Magnitude Error Peak	+33.4	%	
0.0 % to +100.0 %,	(ME) Magnitude Error RMS	+23.6	%	
0.0 deg to 180.0 deg,	(PE) Phase Error Peak	OFF	deg	
0.0 deg to 180.0 deg,	(PE) Phase Error RMS	OFF	deg	
–120.0 dB to –20.0 dB,	Carrier Feedthrough	–25.0	dB	
–120.0 dB to –20.0 dB,	IQ Imbalance	–30.0	dB	
0 Hz to 1000 Hz,	Carrier Frequency Error	+300	Hz	
0.0 μs to 10.0 μs	Transmit Time Error	1.0	s	
0.0 to 1.0	Rho	0.944	–	
Description of command				
This command defines upper limits for the different traces and for the scalar modulation parameters derived from them. The keyword <i>CMMax</i> refers to the <i>Current</i> and <i>Max./Min.</i> traces. After each parameter definition, the limit check for this parameter can be enabled or disabled.				
Limit definition and enabling of the limit check can be done separately.				

				Limits
<b>CONFigure:MODulation:OEMP:HPSK:AVERage:LIMit[:SCALar]:SYMMetric[:COMBined][?]</b> <Limit_Peak_EVM>, <Enable>, <Limit_RMS_EVM>, <Enable>, <Limit_Peak_ME>, <Enable>, <Limit_RMS_ME>, <Enable>, <Limit_Peak_PE>, <Enable>, <Limit_RMS_PE>, <Enable>, <Carrier_Feedthrough_Limit>, <Enable>, <IQ_Imbalance_Limit>, <Enable>, <Carrier_Freq_Error_Limit>, <Enable>, <Tx_Time_Error_Limit>, <Enable>, <Rho_Limit>, <Enable>				
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON   OFF,	Switch limit check for parameter preceding <Enable> on or off	ON	–	V3.40
Parameters	Description of parameters	Def. value	Def. unit	FW vers.
0.0 % to +100.0 %,	(EVM) Error Vector Magnitude Error Peak	+33.4	%	V3.40
0.0 % to +100.0 %,	(EVM) Error Vector Magnitude Error RMS	+23.6	%	
0.0 % to +100.0 %,	(ME) Magnitude Error Peak	+33.4	%	
0.0 % to +100.0 %,	(ME) Magnitude Error RMS	+23.6	%	
0.0 deg to 180.0 deg,	(PE) Phase Error Peak	19.6	deg	
0.0 deg to 180.0 deg,	(PE) Phase Error RMS	13.6	deg	
–120.0 dB to –20.0 dB,	Carrier Feedthrough	–25.0	dB	
–120.0 dB to –20.0 dB,	IQ Imbalance	–30.0	dB	
0 Hz to 1000 Hz,	Carrier Frequency Error	+300	Hz	
0.0 μs to 10.0 μs	Transmit Time Error	1.0	s	
0.0 to 1.0	Rho	0.944	–	
Description of command				
This command defines upper limits for the different traces and for the scalar modulation parameters derived from them. The keyword <i>AVERage</i> refers to the <i>Average</i> trace. After each parameter definition, the limit check for this parameter can be enabled or disabled.				
Limit definition and enabling of the limit check can be done separately.				

				Limit values
<b>CONFigure:MODulation:OEMP:HPSK:CMMax:LIMit[:SCALar]:SYMMetric[:COMBined]:VALue[?]</b> <Limit_Peak_EVM>, <Limit_RMS_EVM>, <Limit_Peak_ME>, <Limit_RMS_ME>, <Limit_Peak_PE>, <Limit_RMS_PE>, <Carrier_Feedthrough_Limit>, <IQ_Imbalance_Limit>, <Carrier_Freq_Error_Limit>, <Tx_Time_Error_Limit>, <Rho_Limit>				
Parameter	Description of parameters	Def. value	Def. unit	FW vers.
0.0 % to +100.0 %,	(EVM) Error Vector Magnitude Error Peak	+33.4	%	V3.40
0.0 % to +100.0 %,	(EVM) Error Vector Magnitude Error RMS	+23.6	%	
0.0 % to +100.0 %,	(ME) Magnitude Error Peak	+33.4	%	
0.0 % to +100.0 %,	(ME) Magnitude Error RMS	+23.6	%	
0.0 deg to 180.0 deg,	(PE) Phase Error Peak	OFF	deg	
0.0 deg to 180.0 deg,	(PE) Phase Error RMS	OFF	deg	
–120.0 dB to –20.0 dB,	Carrier Feedthrough	–25.0	dB	
–120.0 dB to –20.0 dB,	IQ Imbalance	–30.0	dB	
0 Hz to 1000 Hz,	Carrier Frequency Error	+300	Hz	
0.0 μs to 10.0 μs,	Transmit Time Error	1.0	s	
0.0 to 1.0	Rho	0.944	–	
Description of command				
This command defines upper limits for the different traces and for the scalar modulation parameters derived from them. The keyword <i>CMMax</i> refers to the <i>Current</i> and <i>Max./Min.</i> traces.				

Limit values

**CONFigure:MODulation:OEMP:HPSK:AVERAge:LIMit[:SCALar]:SYMMetric[:COMBined]:VALue[?]**  
 <Limit\_Peak\_EVM>, <Limit\_RMS\_EVM>, <Limit\_Peak\_ME>, <Limit\_RMS\_ME>, <Limit\_Peak\_PE>,  
 <Limit\_RMS\_PE>, <Carrier\_Feedthrough\_Limit>, <IQ\_Imbalance\_Limit>, <Carrier\_Freq\_Error\_Limit>,  
 <Tx\_Time\_Error\_Limit>, <Rho\_Limit>

Parameter	Description of parameters	Def. value	Def. unit	FW vers.
0.0 % to +100.0 %,	(EVM) Error Vector Magnitude Error Peak	+33.4	%	V3.40
0.0 % to +100.0 %,	(EVM) Error Vector Magnitude Error RMS	+23.6	%	
0.0 % to +100.0 %,	(ME) Magnitude Error Peak	+33.4	%	
0.0 % to +100.0 %,	(ME) Magnitude Error RMS	+23.6	%	
0.0 deg to +45.0 deg,	(PE) Phase Error Peak	19.6	deg	
0.0 deg to +45.0 deg,	(PE) Phase Error RMS	13.6	deg	
-120.0 dB to -20.0 dB,	Carrier Feedthrough	-25.0	dB	
-120.0 dB to -20.0 dB,	IQ Imbalance	-30.0	dB	
0 Hz to 1000 Hz,	Carrier Frequency Error	+300	Hz	
0.0 μs to 10.0 μs,	Transmit Time Error	1.0	s	
0.0 to 1.0	Rho	0.944	-	

Description of command

This command defines upper limits for the different traces and for the scalar modulation parameters derived from them. The keyword *AVERAge* refers to the *Average* trace.

Limit Enable

**CONFigure:MODulation:OEMP:HPSK:CMMax:LIMit[:SCALar]:SYMMetric[:COMBined]:ENABle[?]**  
 <Limit\_Peak\_EVM>, <Limit\_RMS\_EVM>, <Limit\_Peak\_ME>, <Limit\_RMS\_ME>, <Limit\_Peak\_PE>,  
 <Limit\_RMS\_PE>, <Carrier\_Feedthrough\_Limit>, <IQ\_Imbalance\_Limit>, <Carrier\_Freq\_Error\_Limit>,  
 <Tx\_Time\_Error\_Limit>, <Rho\_Limit>

<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON   OFF	Switch limit check for corresponding parameter on or off.	ON (see below)	-	V3.40

Description of command

This command enables or disables the limit check for the different traces and for the scalar modulation parameters derived from them. The keyword *CMMax* refers to the *Current* and *Max./Min.* traces.

**Note:** The default value is *ON* for all limits except the **phase error** limits (Def. Value = *OFF*).

Limit Enable

**CONFigure:MODulation:OEMP:HPSK:AVERAge:LIMit[:SCALar]:SYMMetric[:COMBined]:ENABle[?]**  
 <Limit\_Peak\_EVM>, <Limit\_RMS\_EVM>, <Limit\_Peak\_ME>, <Limit\_RMS\_ME>, <Limit\_Peak\_PE>,  
 <Limit\_RMS\_PE>, <Carrier\_Feedthrough\_Limit>, <IQ\_Imbalance\_Limit>, <Carrier\_Freq\_Error\_Limit>,  
 <Tx\_Time\_Error\_Limit>, <Rho\_Limit>

<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON   OFF	Switch limit check for corresponding parameter on or off.	ON	-	V3.40

Description of command

This command enables or disables the limit check for the different traces and for the scalar modulation parameters derived from them. The keyword *AVERAge* refers to the *Average* trace.

DEFault:MODulation:OEMP:HPSK:LIMit[?]		Default Settings		
<Enable>				
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON   OFF	The parameters are set to their default values Some or all parameters differ from their default values	ON	–	V3.40
Description of command				
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystem <i>MODulation:OEMP:LIMit</i> to their default values (the setting <i>OFF</i> results in an error message). If used as a query the command returns whether all parameters are set to their default values ( <i>ON</i> ) or not ( <i>OFF</i> ).				

### Measured Values

The subsystem *MODulation:OVERview* measures and returns the modulation overview parameters and compares them with the tolerance values. The subsystem corresponds to the various output elements in the measurement menu *MODulation*, application *Overview*.

READ[:SCALar]:MODulation:OVERview:HPSK?		Scalar Results		
FETCh[:SCALar]:MODulation:OVERview:HPSK?		Start single shot measurement and return results		
SAMPle[:SCALar]:MODulation:OVERview:HPSK?		Read out meas. results (unsynchronized)		
		Read out measurement results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
EVM Peak (x3), EVM RMS (x3), Magn. Error Peak (x3), Magn. Error RMS (x3), Phase Error Peak (x3), Phase Error RMS (x3),	0.0 % to 100.0 % 0.0 % to 100.0 % 0.0 % to 100.0 % 0.0 % to 100.0 % 0.0 deg to +45.0 deg 0.0 deg to +45.0 deg	NAN NAN NAN NAN NAN NAN	% % % % deg deg	V3.40
Carrier Feedthrough (x3), I/Q Imbalance (x3), Carrier Freq. Error (x3), Tx Time Error (x3), Rho (x3), AT Power (x3),	–120.0 dB to –20.0 dB –120.0 dB to –20.0 dB 0 Hz to 1000 Hz 0 µs to 10 µs 0 to 1 –133.0 dBm to +19.0 dBm	NAN NAN NAN NAN NAN NAN	dB dB Hz µs – dB	
Current Statistics, Limit Matching	1 to 1000 0.0 % to 100.0 %	NAN NAN	– %	
Description of command				
These commands are always queries. They start a modulation overview measurement and output all scalar measurement results (see Chapter 4). The calculation of results in an <i>average</i> or <i>peak</i> measurement is described in Chapter 3 (see <i>calculation of statistical quantities</i> ). The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i> , the <i>Average</i> , and the <i>MMax</i> value.				

CALCulate[:SCALAR]:MODulation:OVERview:HPSK:MATChing:LIMit?		Limit Matching		
Returned values	Value range	Def. value	Def. unit	FW vers.
<b>EVM Peak (x3),</b>	For all measured values:  NMAU   NMAL   INV   OK	INV	–	V3.40
<b>EVM RMS (x3),</b>		INV	–	
<b>Magn Error Peak (x3),</b>		INV	–	
<b>Magn Error RMS (x3),</b>		INV	–	
<b>Phase Error Peak (x3),</b>		INV	–	
<b>Phase Error RMS (x3),</b>		INV	–	
<b>Carrier Feedthrough (x3),</b>		INV	–	
<b>I/Q Imbalance (x3),</b>		INV	–	
<b>Carrier Freq. Error (x3),</b>		INV	–	
<b>Tx Time Error (x3),</b>		INV	–	
<b>Rho (x3),</b>	INV	–		
<b>AT Power (x3)</b>	INV	–		
Description of command				
This command is always a query. It indicates whether and in which way the error limits for the scalar measured values (see above command) have been exceeded. The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i> , the <i>Average</i> , and the <i>MMax</i> value.				
The following messages may be output for all measured values:				
NMAU	Underflow of tolerance value	<i>not matching, underflow</i>		
NMAL	Tolerance value exceeded	<i>not matching, overflow</i>		
INV	Measurement invalid	<i>invalid</i>		
OK	all tolerances matched			

## MODulation:EVMagnitude (Error Vector Magnitude)

The subsystem *MODulation:EVMagnitude* measures the error vector magnitude as well as general scalar modulation parameters. The subsystem corresponds to the measurement menu *Modulation*, application *EVM H-PSK*, and the associated popup menu *Modulation Configuration*.

### Control of Measurement

The subsystem *MODulation:EVMagnitude* controls the error vector magnitude measurement. It corresponds to the softkey *EVM H-PSK* in the measurement menu *Modulation*.

<b>INITiate:MODulation:EVMagnitude:HPSK</b>	Start new measurement	⇒ <i>RUN</i>
<b>ABOrt:MODulation:EVMagnitude:HPSK</b>	Abort running measurement and switch off	⇒ <i>OFF</i>
<b>STOP:MODulation:EVMagnitude:HPSK</b>	Stop measurement after current stat. cycle	⇒ <i>STOP</i>
<b>CONTinue:MODulation:EVMagnitude:HPSK</b>	Next measurement step ( <i>stepping mode</i> )	⇒ <i>RUN</i>
Description of command		FW vers.
These commands have no query form. They start and stop the error vector magnitude measurement, setting it to the status indicated in the top right column.		V3.40

CONFigure:MODulation:EVMagnitude:HPSK:ERePorting[?] <Report Mode>		Event Reporting		
<Report Mode>	Description of parameters	Def. value	Def. unit	FW vers.
<b>SRQ</b>	Service request	OFF	–	V3.40
<b>SOPC</b>	Single operation complete			
<b>SRSQ</b>	SRQ and SOPC			
<b>OFF</b>	No reporting			
<b>Default</b>	Sets the value to the default setting			
Description of command				
This command defines the events generated when the measurement is terminated or stopped (see <i>Event Reporting</i> in Chapter 5 of the CMU manual).				

FETCh[:SCALar]:MODulation:EVMagnitude:HPSK:STATus?		Measurement Status		
Returned values	Description of parameters	Def. value	Def. unit	FW vers.
<b>OFF</b>	Measurement in the OFF state (*RST or ABORt)	OFF	–	V3.40
<b>RUN</b>	Running (after INITiate, CONTInue or READ)			
<b>STOP</b>	Stopped (STOP)			
<b>ERR</b>	OFF (could not be started)			
<b>STEP</b>	Stepping mode (<stepmode>=STEP)			
<b>RDY</b>	Stopped according to repetition mode and stop condition			
<b>1 to 10000</b>	Counter for current statistics cycle	NONE	–	
<b>NONE</b>	No counting mode set			
<b>1 to 1000</b>	Counter for current evaluation period within a cycle	NONE	–	
<b>NONE</b>	Statistic count set to off			
Description of command				
This command is always a query. It returns the status of the measurement (see Chapters 3 and 5).				

**Test Configuration**

The commands of the following subsystems configure the *Error Vector Magnitude* measurement in the *Modulation* menu. They correspond to the *Modulation Configuration* menu.

**Subsystem CONTROL**

The subsystem *MODulation:EVMagnitude:CONTROL* configures the error vector magnitude measurement. It corresponds to the *Control* tab in the popup menu *Modulation Configuration*.

<b>CONFigure:MODulation:EVMagnitude:HPSK:CONTROL[?]</b>		Scope of Measurement		
<b>&lt;Statistics Count&gt;, &lt;Repetition&gt;, &lt;Stop Cond&gt;, &lt;Step Mode&gt;</b>				
<b>&lt;Result Mode&gt;</b>	Description of parameters	Def. value	Def. unit	FW-Vers.
<b>SCALar   ARRay,</b>	Scalar values only (incl. ramp matching) Scalar measured values and arrays	ARR	–	V3.40
<b>&lt;Statistics Count&gt;</b>	Description of parameters	Def. value	Def. unit	FW-Vers.
<b>1 to 1000,</b>	Number of bursts per statistics cycle	100	–	V3.40
<b>&lt;Repetition&gt;</b>	Description of parameters	Def. value	Def. unit	FW-Vers.
<b>1 to 10000   CONTInuous   SINGleshot   DEFault,</b>	Multiple measurement (counting, until Status = STEP   RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–	V3.40
<b>&lt;Stop Cond&gt;</b>	Description of parameters	Def. value	Def. unit	FW-Vers.
<b>NONE   SONerror   DEFault,</b>	Continue measurement even in case of error Stop measurement in case of error ( <i>stop on error</i> ) Sets the value to the default setting	NONE	–	V3.40
<b>&lt;Step Mode&gt;</b>	Description of parameters	Def. value	Def. unit	FW-Vers.
<b>STEP   NONE   DEFault</b>	Interrupt measurement after each statistics cycle Continue measurement according to its rep. mode Sets the value to the default setting	NONE	–	V3.40
Description of command				
This command combines the ...CONTROL:STATistics and ...CONTROL:REPetition commands, see below.				

<b>CONFigure:MODulation:EVMagnitude:HPSK:CONTROL:RMODE[?]</b>		Result mode		
<b>&lt;Result Mode&gt;</b>				
<b>&lt;Result Mode&gt;</b>	Description of parameters	Def. value	Def. unit	FW-Vers.
<b>SCALar   ARRay</b>	Scalar values only (incl. ramp matching) Scalar measured values and arrays	ARR	–	V3.40
Description of command				
This command specifies the type of measured values.				

CONFigure:MODulation:EVMagnitude:HPSK:CONTRol:STATistics[?] <Statistics Count>				Statistics Count
<Statistics Count>	Description of parameters	Def. value	Def. unit	FW-Vers.
<b>1 to 1000</b>	Number of bursts per statistics cycle	100	–	V3.40
Description of command				
This command specifies the type of measured values and defines the number of bursts forming a statistics cycle.				

CONFigure:MODulation:EVMagnitude:HPSK:CONTRol:REPetition[?] <Repetition> ,<Stop Cond>, <Step Mode>				Test Cycles
<Repetition>	Description of parameters	Def. value	Def. unit	FW vers.
<b>1 to 10000  </b> <b>CONTinuous  </b> <b>SINGleshot  </b> <b>DEFault,</b>	Multiple measurement (counting, until Status = STEP   RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–	V3.40
<Stop Cond>	Description of parameters	Def. value	Def. unit	FW vers.
<b>NONE  </b> <b>SONerror  </b> <b>DEFault,</b>	Continue measurement even in case of error Stop measurement in case of error ( <i>stop on error</i> ) Sets the value to the default setting	NONE	–	V3.40
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
<b>STEP  </b> <b>NONE  </b> <b>DEFault</b>	Interrupt measurement after each statistics cycle Continue measurement according to its rep. mode Sets the value to the default setting	NONE	–	V3.40
Description of command				
This command determines the repetition mode, stop condition, and stepping mode for the measurement.				
<b>Note:</b> In the case of READ commands (READ: ...), the <Repetition> parameter has no effect; the measurement is always stopped after a single shot.				

DEFault:MODulation:EVMagnitude:HPSK:CONTRol[?] <Enable>				Default Settings
Enable	Description of parameters	Def. value	Def. unit	FW vers.
<b>ON  </b> <b>OFF</b>	The parameters are set to their default values Some or all parameters are not set to default	ON	–	V3.40
Description of command				
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystem MODulation:EVMagnitude:...:CONTRol to their default values (the setting <i>OFF</i> results in an error message).				
If used as a query, the command returns whether all parameters are set to their default values ( <i>ON</i> ) or not ( <i>OFF</i> ).				

**Subsystem LIMit**

The subsystem *MODulation:OEMP:...:LIMit* (refer to page 6.46) defines the tolerance values for the *OEMP* modulation measurements. The subsystem corresponds to the *Modulation* section in the *Limits* tab in the popup menu *Modulation Configuration*.

**Subsystem SUBarrays**

The subsystem *SUBarrays:MODulation* defines the measurement range and the type of output values.

<b>CONFigure:SUBarrays:MODulation:EVMagnitude:HPSK[?]</b>		Definition of Subarrays		
<b>&lt;Mode&gt;, &lt;Start&gt;, &lt;Samples&gt;</b>				
<b>&lt;Mode&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>ALL  </b>	Return all measurement values	ALL	–	V3.40
<b>ARITHmetical  </b>	Return arithm. mean value in every range			
<b>MINimum  </b>	Return minimum value in every range			
<b>MAXimum</b>	Return maximum value in every range			
<b>&lt;Start&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>0 μs to 833 μs</b>	Start time in current range	NAN	s	V3.40
<b>&lt;Samples&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>0 to 1024</b>	Number of samples in current range	NAN	–	V3.40
Description of command				
<p>This command configures the <code>READ:SUBarrays...</code>, <code>FETCh:SUBarrays...</code>, and <code>SAMPlE:SUBarrays:MODulation:EVMagnitude</code> commands. It restricts the measurement to up to 32 subranges where either all measurement results (the number of which is given by the second numerical parameter) or a single statistical value is returned. The subranges are defined by the start time and the number of test points which are located on a fixed, equidistant grid with a step width of 1 symbol period.</p> <p>The subranges may overlap but must be within the total range of the <i>Modulation</i> measurement. Test points outside this range are not measured (result <i>NAN</i>) and do not enter into the <i>ARITHmetical</i>, <i>MINimum</i> and <i>MAXimum</i> values.</p> <p>By default, only one range corresponding to the total measurement range is used and all measurement values are returned.</p>				

Measured Values

The subsystem *MODulation:EVMagnitude* measures and returns the error vector magnitude results and compares them with the tolerance values. The subsystem corresponds to the various output elements in the measurement menu *MODulation*, application *Error Vector Magnitude*.

		Scalar Results		
<b>READ[:SCALar]:MODulation:EVMagnitude:HPSK?</b>		Start single shot measurement and return results		
<b>FETCh[:SCALar]:MODulation:EVMagnitude:HPSK?</b>		Read out meas. results (unsynchronized)		
<b>SAMPlE[:SCALar]:MODulation:EVMagnitude:HPSK?</b>		Read out measurement results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
<b>EVM Peak (x3),</b>	0.0 % to 100.0 %	NAN	%	V3.40
<b>EVM RMS (x3),</b>	0.0 % to 100.0 %	NAN	%	
<b>Carrier Feedthrough (x3),</b>	-120.0 dB to -20.0 dB	NAN	dB	
<b>I/Q Imbalance (x3),</b>	-120.0 dB to -20.0 dB	NAN	dB	
<b>Carrier Freq. Error (x3),</b>	0 Hz to 1000 Hz	NAN	Hz	
<b>Tx Time Error (x3),</b>	0 μs to 10 μs	NAN	μs	
<b>Rho (x3),</b>	0 to 1	NAN	–	
<b>AT Power (x3),</b>	-133.0 dBm to +19.0 dBm	NAN	dB	
<b>Current Statistics,</b>	1 to 1000	NAN	–	
<b>Limit Matching</b>	0.0 % to 100.0 %	NAN	%	
Description of command				
These commands are always queries. They start a EVM measurement and output the scalar measurement results (see Chapter 4). The calculation of results in an <i>average</i> or <i>peak</i> measurement is described in Chapter 3 (see <i>calculation of statistical quantities</i> ). The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i> , the <i>Average</i> , and the <i>MMax</i> value.				

<b>CALCulate[:SCALar]:MODulation:EVMagnitude:HPSK:MATCHing:LIMit?</b>		Out of Tolerance		
Returned values	Value range	Def. value	Def. unit	FW vers.
<b>EVM Peak (x3),</b>	For all measured values:  NMAU   NMAL   INV   OK	INV	–	V3.40
<b>EVM RMS (x3),</b>		INV	–	
<b>Carrier Feedthrough (x3),</b>		INV	–	
<b>I/Q Imbalance (x3),</b>		INV	–	
<b>Carrier Freq. Error (x3),</b>		INV	–	
<b>Tx Time Error (x3),</b>		INV	–	
<b>Rho (x3),</b>		INV	–	
<b>AT Power (x3)</b>		INV	–	
Description of command				
This command is always a query. It indicates whether and in which way the error limits for the scalar measured values (see above command) have been exceeded. The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i> , the <i>Average</i> , and the <i>MMax</i> value. The limits are defined with the <i>CONFigure:MODulation:OEMP...</i> commands.				
The following messages may be output for all measured values:				
NMAU	Underflow of tolerance value	<i>not matching, underflow</i>		
NMAL	Tolerance value exceeded	<i>not matching, overflow</i>		
INV	Measurement invalid	<i>invalid</i>		
OK	all tolerances matched			

EVM in Evaluation Period				
<b>READ:ARRay:MODulation:EVMagnitude:HPSK:CURRent?</b> <b>READ:ARRay:MODulation:EVMagnitude:HPSK:AVERAge?</b> <b>READ:ARRay:MODulation:EVMagnitude:HPSK:MMAx?</b>				
Start single shot measurement and return results				
<b>FETCh:ARRay:MODulation:EVMagnitude:HPSK:CURRent?</b> <b>FETCh:ARRay:MODulation:EVMagnitude:HPSK:AVERAge?</b> <b>FETCh:ARRay:MODulation:EVMagnitude:HPSK:MMAx?</b>				
Read measurement results (unsynchronized)				
<b>SAMPlE:ARRay:MODulation:EVMagnitude:HPSK:CURRent?</b> <b>SAMPlE:ARRay:MODulation:EVMagnitude:HPSK:AVERAge?</b> <b>SAMPlE:ARRay:MODulation:EVMagnitude:HPSK:MMAx?</b>				
Read measurement results (synchronized)				
Returned values	Value range	Def. value	Def. unit	FW vers.
<b>1<sup>st</sup> value for error vector magnitude,</b>	0.0 % to + 100.0 %,	NAN	%	V3.40
<b>x<sup>th</sup> value for error vector magnitude</b>	0.0 % to + 100.0 %	NAN	%	
Description of command				
These commands are always queries. They return the error vector magnitude vs. time at fixed, equidistant test points. The number of measured values is 1024, corresponding to a time range of 0 symbols to 833 microseconds.				
The calculation of <i>current</i> , <i>average</i> , and <i>mmax</i> (Min./Max.) results is explained in Chapter 3 (see <i>display mode</i> ).				

Subarray Results				
<b>READ:SUBarrays:MODulation:EVMagnitude:HPSK:CURRent?</b> <b>READ:SUBarrays:MODulation:EVMagnitude:HPSK:AVERAge?</b> <b>READ:SUBarrays:MODulation:EVMagnitude:HPSK:MMAx?</b>				
Start measurement and wait for end ⇒ RUN				
<b>FETCh:SUBarrays:MODulation:EVMagnitude:HPSK:CURRent?</b> <b>FETCh:SUBarrays:MODulation:EVMagnitude:HPSK:AVERAge?</b> <b>FETCh:SUBarrays:MODulation:EVMagnitude:HPSK:MMAx?</b>				
Read meas. results (unsynchronized) ⇒ RUN				
<b>SAMPlE:SUBarrays:MODulation:EVMagnitude:HPSK:CURRent?</b> <b>SAMPlE:SUBarrays:MODulation:EVMagnitude:HPSK:AVERAge?</b> <b>SAMPlE:SUBarrays:MODulation:EVMagnitude:HPSK:MMAx?</b>				
Read results (synchronized) ⇒ RUN				
Returned values	Value range	Def. value	Def. unit	FW vers.
<b>1<sup>st</sup> value for error vector magnitude</b>	0.0 % to + 100.0 %,	NAN	%	V3.40
<b>x<sup>th</sup> value for error vector magnitude</b>	0.0 % to + 100.0 %	NAN	%	
Description of command				
These commands are always queries. They measure and return the error vector magnitude versus time in the subranges defined by means of the <code>CONFigure:SUBarrays:MODulation:EVMagnitude</code> command.				
The <code>CONFigure:SUBarrays:MODulation:EVMagnitude</code> command defines a maximum of 32 subranges. If one of the statistical modes ( <code>ARITHmetical</code> , <code>MINimum</code> , <code>MAXimum</code> ) is set, only one value is returned per subrange.				
The calculation of <i>current</i> , <i>average</i> , <i>minimum</i> , and <i>maximum</i> results is explained in Chapter 3 (see <i>display mode</i> ).				

## MODulation:PERRor (Phase Error)

The subsystem *MODulation:PERRor* measures the phase error as well as general scalar modulation parameters. The subsystem corresponds to the measurement menu *Modulation*, application *Phase Error*, and the associated popup menu *Modulation Configuration*.

### Control of Measurement

The subsystem *MODulation:PERRor* controls the phase error measurement. It corresponds to the softkey *Phase Error* in the measurement menu *Modulation*.

<b>INITiate:MODulation:PERRor:HPSK</b>	Start new measurement	⇒	<i>RUN</i>
<b>ABORt:MODulation:PERRor:HPSK</b>	Abort running measurement and switch off	⇒	<i>OFF</i>
<b>STOP:MODulation:PERRor:HPSK</b>	Stop measurement after current stat. cycle	⇒	<i>STOP</i>
<b>CONTinue:MODulation:PERRor:HPSK</b>	Next measurement step ( <i>stepping mode</i> )	⇒	<i>RUN</i>
Description of command			FW vers.
These commands have no query form. They start and stop the phase error measurement, setting it to the status indicated in the top right column.			V3.40

<b>CONFigure:MODulation:PERRor:HPSK:EREPorting[?]</b>		Event Reporting		
<b>&lt;Report Mode&gt;</b>				
<b>&lt;Report Mode&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>SRQ  </b>	Service request	OFF	–	V3.40
<b>SOPC  </b>	Single operation complete			
<b>SRSQ  </b>	SRQ and SOPC			
<b>OFF  </b>	No reporting			
<b>DEFault</b>	Sets the value to the default setting			
Description of command				
This command defines the events generated when the measurement is terminated or stopped (see <i>Event Reporting</i> in Chapter 5 of the CMU manual).				

<b>FETCh[:SCALar]:MODulation:PERRor:HPSK:STATus?</b>		Measurement Status		
<b>Return</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>OFF  </b>	Measurement in the OFF state (*RST or ABORt)	OFF	–	V3.40
<b>RUN  </b>	Running (after INITiate, CONTinue or READ)			
<b>STOP  </b>	Stopped (STOP)			
<b>ERR  </b>	OFF (could not be started)			
<b>STEP  </b>	Stepping mode (<stepmode>=STEP)			
<b>RDY</b>	Stopped according to repetition mode and stop condition			
<b>1 to 10000  </b>	Counter for current statistics cycle	NONE	–	
<b>NONE</b>	No counting mode set			
<b>1 to 1000</b>	Counter for current evaluation period within a cycle	NONE	–	
<b>NONE</b>	Statistic count set to off			
Description of command				
This command is always a query. It returns the status of the measurement (see Chapters 3 and 5).				

### Test Configuration

The commands of the following subsystems configure the *Phase Error* measurement in the *Modulation* menu. They correspond to the *Modulation Configuration* menu.

### Subsystem CONTROL

The subsystem *MODulation:PERRor:CONTRol* configures the phase error measurement. It corresponds to the tab *Control* in the popup menu *Modulation Configuration*.

CONFigure:MODulation:PERRor:HPSK:CONTRol[?]		Scope of Measurement		
<Result Mode>, <Statistics Count>, <Repetition>, <Stop Cond>, <Step Mode>				
<Result Mode>	Description of parameters	Def. value	Def. unit	FW-Vers.
SCALar   ARRay,	Scalar values only (incl. ramp matching) Scalar measured values and arrays	ARR	–	V3.40
<Statistics Count>	Description of parameters	Def. value	Def. unit	FW-Vers.
1 to 1000,	Number of bursts per statistics cycle	100	–	V3.40
<Repetition>	Description of parameters	Def. value	Def. unit	FW-Vers.
1 to 10000   CONTInuous   SINGleshot   DEFault,	Multiple measurement (counting, until Status = STEP   RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–	V3.40
<Stop Cond>	Description of parameters	Def. value	Def. unit	FW-Vers.
NONE   SONerror   DEFault,	Continue measurement even in case of error Stop measurement in case of error ( <i>stop on error</i> ) Sets the value to the default setting	NONE	–	V3.40
<Step Mode>	Description of parameters	Def. value	Def. unit	FW-Vers.
STEP   NONE   DEFault	Interrupt measurement after each statistics cycle Continue measurement according to its rep. Mode Sets the value to the default setting	NONE	–	V3.40
Description of command				
This command combines the ...CONTRol:STATistics, ...CONTRol:REPetition and ...CONTRol:RMODE commands.				

CONFigure:MODulation:PERRor:HPSK:CONTRol:STATistics[?]		Statistics Count		
<Statistics Count>				
<Statistics Count>	Description of parameters	Def. value	Def. unit	FW-Vers.
1 to 1000	Number of bursts per statistics cycle	100	–	V3.40
Description of command				
This command specifies the type of measured values and defines the number of bursts forming a statistics cycle.				

CONFigure:MODulation:PERRor:HPSK:CONTRol:REPetition[?] <Repetition>, <Stop Cond>, <Step Mode>				Test Cycles
<Repetition>	Description of parameters	Def. value	Def. unit	FW vers.
<b>1 to 10000  </b> <b>CONTInuous  </b> <b>SINGleshot  </b> <b>DEFault,</b>	Multiple measurement (counting, until Status = STEP   RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–	V3.40
<Stop Cond>	Description of parameters	Def. value	Def. unit	FW vers.
<b>NONE  </b> <b>SONerror  </b> <b>DEFault,</b>	Continue measurement even in case of error Stop measurement in case of error ( <i>stop on error</i> ) Sets the value to the default setting	NONE	–	V3.40
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
<b>STEP  </b> <b>NONE  </b> <b>DEFault</b>	Interrupt measurement after each statistics cycle Continue measurement according to its rep. Mode Sets the value to the default setting	NONE	–	V3.40
Description of command				
This command determines the number of statistics cycles, the stop condition and the stepping mode for the measurement.				
<b>Note:</b> In the case of READ commands (READ: ...), the <Repetition> parameter has no effect; the measurement is always stopped after a single shot.				

CONFigure:MODulation:PERRor:HPSK:CONTRol:RMODE[?] <Result Mode>				Result Mode
<Result Mode>	Description of parameters	Def. value	Def. unit	FW-Vers.
<b>SCALar  </b> <b>ARRay</b>	Scalar values only (incl. ramp matching) Scalar measured values and arrays	ARR	–	V3.40
Description of command				
This command specifies the type of measured values.				

DEFault:MODulation:PERRor:HPSK:CONTRol[?] <Enable>				Default Settings
Enable	Description of parameters	Def. value	Def. unit	FW vers.
<b>ON  </b> <b>OFF</b>	The parameters are set to their default values Some or all parameters are not set to default	ON	–	V3.40
Description of command				
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystem MODulation:PERRor:...:CONTRol to their default values (the setting <i>OFF</i> results in an error message).				
If used as a query, the command returns whether all parameters are set to their default values ( <i>ON</i> ) or not ( <i>OFF</i> ).				

### Subsystem LIMit

The subsystem *MODulation:OEMP:...:LIMit* (refer to page 6.46) defines the tolerance values for the *OEMP* modulation measurements. The subsystem corresponds to the *Modulation* section in the *Limits* tab in the popup menu *Modulation Configuration*.

### Subsystem SUBarrays

The subsystem *SUBarrays:MODulation:PERRor* defines the measurement range and the type of output values.

CONFigure:SUBarrays:MODulation:PERRor:HPSK[?] <Mode>, <Start>, <Samples>		Definition of Subarrays		
<Mode>	Description of parameters	Def. value	Def. unit	FW vers.
<b>ALL</b>   <b>ARITHmetical</b>   <b>MINimum</b>   <b>MAXimum</b> ,	Return all measurement values Return arithm. mean value in every range Return minimum value in every range Return maximum value in every range	ALL	–	V3.40
<Start>	Description of parameters	Def. value	Def. unit	FW vers.
<b>0 μs to 833 μs</b> ,	Start time in current range	NAN	s	V3.40
<Samples>	Description of parameters	Def. value	Def. unit	FW vers.
<b>0 to 1024</b>	Number of samples in current range	NAN	–	V3.40
Description of command				
<p>This command configures the <code>READ:SUBarrays...</code>, <code>FETCh:SUBarrays...</code>, and <code>SAMPlE:SUBarrays:MODulation:PERRor</code> commands. It restricts the measurement to up to 32 subranges where either all measurement results (the number of which is given by the second numerical parameter) or a single statistical value is returned. The subranges are defined by the start time and the number of test points which are located on a fixed, equidistant grid with a step width of 1 symbol period.</p> <p>The subranges may overlap but must be within the total range of the <i>Modulation</i> measurement. Test points outside this range are not measured (result <i>NAN</i>) and do not enter into the <i>ARITHmetical</i>, <i>MINimum</i> and <i>MAXimum</i> values.</p> <p>By default, only one range corresponding to the total measurement range is used and all measurement values are returned.</p>				

**Measured Values**

The subsystem *MODulation:PERRor* measures and returns the phase error results and compares them with the tolerance values. The subsystem corresponds to the various output elements in the measurement menu *MODulation*, application *Phase Error*.

READ[:SCALar]:MODulation:PERRor:HPSK? FETCh[:SCALar]:MODulation:PERRor:HPSK? SAMPle[:SCALar]:MODulation:PERRor:HPSK?		Scalar Results:		
		Start single shot measurement and return results		
		Read out meas. Results (unsynchronized)		
		Read out measurement results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
PE Peak (x3), PE RMS (x3),	0.0 deg to +45.0 deg 0.0 deg to +45.0 deg	NAN NAN	% %	V3.40
Carrier Feedthrough (x3), I/Q Imbalance (x3), Carrier Freq. Error (x3), Tx Time Error (x3), Rho (x3), AT Power (x3),	-120.0 dB to -20.0 dB -120.0 dB to -20.0 dB 0 Hz to 1000 Hz 0 µs to 10 µs 0 to 1 -133.0 dBm to -19.0 dBm	NAN NAN NAN NAN NAN NAN	dB dB Hz µs - dBm	
Current Statistics, Limit Matching	1 to 1000 0.0 % to 100.0 %	NAN NAN	- %	
Description of command				
These commands are always queries. They start a phase error measurement and output the scalar measurement results (see Chapter 4). The calculation of results in an <i>average</i> or <i>peak</i> measurement is described in Chapter 3 (see <i>calculation of statistical quantities</i> ). The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i> , the <i>Average</i> , and the <i>MMax</i> value.				

CALCulate[:SCALar]:MODulation:PERRor:HPSK:MATCHing:LIMit?		Out of Tolerance		
Returned values	Value range	Def. value	Def. unit	FW vers.
PE Peak (x3), PE RMS (x3),	For all measured values:  NMAU   NMAL   INV   OK	INV INV	- -	V3.40
Carrier Feedthrough (x3), I/Q Imbalance (x3), Carrier Freq. Error (x3), Tx Time Error (x3), Rho (x3), AT Power (x3)		INV INV INV INV INV INV	- - - - - -	
Description of command				
This command is always a query. It indicates whether and in which way the error limits for the scalar measured values (see above command) have been exceeded. The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i> , the <i>Average</i> , and the <i>MMax</i> value. The limits are defined with the <i>CONFigure:MODulation:OEMP...</i> commands.				
The following messages may be output for all measured values:				
NMAU	Underflow of tolerance value	<i>not matching, underflow</i>		
NMAL	Tolerance value exceeded	<i>not matching, overflow</i>		
INV	Measurement invalid	<i>invalid</i>		
OK	all tolerances matched			

Phase Error in Burst				
<b>READ:ARRay:MODulation:PERRor:HPSK:CURRent?</b> <b>READ:ARRay:MODulation:PERRor:HPSK:AVERAge?</b> <b>READ:ARRay:MODulation:PERRor:HPSK:MMAx?</b>				
Start single shot measurement and return results				
<b>FETCh:ARRay:MODulation:PERRor:HPSK:CURRent?</b> <b>FETCh:ARRay:MODulation:PERRor:HPSK:AVERAge?</b> <b>FETCh:ARRay:MODulation:PERRor:HPSK:MMAx?</b>				
Read measurement results (unsynchronized)				
<b>SAMPlE:ARRay:MODulation:PERRor:HPSK:CURRent?</b> <b>SAMPlE:ARRay:MODulation:PERRor:HPSK:AVERAge?</b> <b>SAMPlE:ARRay:MODulation:PERRor:HPSK:MMAx?</b>				
Read measurement results (synchronized)				
Returned values	Value range	Def. value	Def. unit	FW vers.
1 <sup>st</sup> value for phase error	-100.0 deg to + 100.0 deg,	NAN	deg	V3.40
x <sup>th</sup> value for phase error	-100.0 deg to + 100.0 deg	NAN	deg	
Description of command				
These commands are always queries. They return the phase error vs. time at fixed, equidistant test points. The number of measured values is 1024, corresponding to a time range of 0 symbols to 833 microseconds.				
The calculation of <i>current</i> , <i>average</i> , and <i>mmax</i> (Min./Max.) results is explained in Chapter 3 (see <i>display mode</i> ).				

Subarray Results				
<b>READ:SUBarrays:MODulation:PERRor:HPSK:CURRent?</b> <b>READ:SUBarrays:MODulation:PERRor:HPSK:AVERAge?</b> <b>READ:SUBarrays:MODulation:PERRor:HPSK:MMAx?</b>				
Start measurement and wait for end ⇒ RUN				
<b>FETCh:SUBarrays:MODulation:PERRor:HPSK:CURRent?</b> <b>FETCh:SUBarrays:MODulation:PERRor:HPSK:AVERAge?</b> <b>FETCh:SUBarrays:MODulation:PERRor:HPSK:MMAx?</b>				
Read meas. results (unsynchronized) ⇒ RUN				
<b>SAMPlE:SUBarrays:MODulation:PERRor:HPSK:CURRent?</b> <b>SAMPlE:SUBarrays:MODulation:PERRor:HPSK:AVERAge?</b> <b>SAMPlE:SUBarrays:MODulation:PERRor:HPSK:MMAx?</b>				
Read results (synchronized) ⇒ RUN				
Returned values	Value range	Def. value	Def. unit	FW vers.
1 <sup>st</sup> value for phase error	100.0 deg to + 100.0 deg,	NAN	deg	V3.40
x <sup>th</sup> value for phase error	-100.0 deg to + 100.0 deg	NAN	deg	
Description of command				
These commands are always queries. They measure and return the phase error versus time in the subranges defined by means of the <code>CONFigure:SUBarrays:MODulation:PERRor</code> command.				
The <code>CONFigure:SUBarrays:MODulation:PERRor</code> command defines a maximum of 32 subranges. If one of the statistical modes ( <code>ARITHmetical</code> , <code>MINimum</code> , <code>MAXimum</code> ) is set, only one value is returned per subrange.				
The calculation of <i>current</i> , <i>average</i> , <i>minimum</i> , and <i>maximum</i> results is explained in Chapter 3 (see <i>display mode</i> ).				

## MODulation:MERRor (Magnitude Error)

The subsystem *MODulation:MERRor* measures the magnitude error as well as general scalar modulation parameters. The subsystem corresponds to the measurement menu *Modulation*, application *Magnitude Error*, and the associated popup menu *Modulation Configuration*.

### Control of Measurement

The subsystem *MODulation:MERRor* controls the magnitude error measurement. It corresponds to the softkey *Magn. Error* in the measurement menu *Modulation*.

<b>INITiate:MODulation:MERRor:HPSK</b>	Start new measurement	⇒	<i>RUN</i>
<b>ABORt:MODulation:MERRor:HPSK</b>	Abort running measurement and switch off	⇒	<i>OFF</i>
<b>STOP:MODulation:MERRor:HPSK</b>	Stop measurement after current stat. cycle	⇒	<i>STOP</i>
<b>CONTInue:MODulation:MERRor:HPSK</b>	Next measurement step ( <i>stepping mode</i> )	⇒	<i>RUN</i>
Description of command			FW vers.
These commands have no query form. They start and stop the magnitude error measurement, setting it to the status indicated in the top right column.			V3.40

<b>CONFigure:MODulation:MERRor:HPSK:EREPorting[?]</b>		Event Reporting		
<b>&lt;Report Mode&gt;</b>				
<b>&lt;Report Mode&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>SRQ  </b>	Service request	OFF	–	V3.40
<b>SOPC  </b>	Single operation complete			
<b>SRSQ  </b>	SRQ and SOPC			
<b>OFF  </b>	No reporting			
<b>DEFault</b>	Sets the value to the default setting			
Description of command				
This command defines the events generated when the measurement is terminated or stopped (see <i>Event Reporting</i> in Chapter 5 of the CMU manual).				

<b>FETCh[:SCALar]:MODulation:MERRor:HPSK:STATus?</b>		Measurement Status		
<b>Return</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>OFF  </b>	Measurement in the OFF state (*RST or ABORt)	OFF	–	V3.40
<b>RUN  </b>	Running (after INITiate, CONTInue or READ)			
<b>STOP  </b>	Stopped (STOP)			
<b>ERR  </b>	OFF (could not be started)			
<b>STEP  </b>	Stepping mode (<stepmode>=STEP)			
<b>RDY</b>	Stopped according to repetition mode and stop condition			
<b>1 to 10000  </b>	Counter for current statistics cycle	NONE	–	
<b>NONE</b>	No counting mode set			
<b>1 to 1000</b>	Counter for current evaluation period within a cycle	NONE	–	
<b>NONE</b>	Statistic count set to off			
Description of command				
This command is always a query. It returns the status of the measurement (see Chapters 3 and 5).				

### Test Configuration

The commands of the following subsystems configure the *Magnitude Error* measurement in the *Modulation* menu. They correspond to the *Modulation Configuration* menu.

**Subsystem CONTROL**

The subsystem *MODulation:MERRor:CONTROL* configures the magnitude error measurement. It corresponds to the tab *Control* in the popup menu *Modulation Configuration*.

<b>CONFigure:MODulation:MERRor:HPSK:CONTROL[?]</b>		Scope of Measurement		
<b>&lt;Result Mode&gt;, &lt;Statistics Count&gt;, &lt;Repetition&gt;, &lt;Stop Cond&gt;, &lt;Step Mode&gt;</b>				
<b>&lt;Result Mode&gt;</b>	Description of parameters	Def. value	Def. unit	FW-Vers.
<b>SCALar   ARRay,</b>	Scalar values only (incl. ramp matching) Scalar measured values and arrays	ARR	–	V3.40
<b>&lt;Statistics Count&gt;</b>	Description of parameters	Def. value	Def. unit	FW-Vers.
<b>1 to 1000,</b>	Number of bursts per statistics cycle	100	–	V3.40
<b>&lt;Repetition&gt;</b>	Description of parameters	Def. value	Def. unit	FW-Vers.
<b>1 to 10000   CONTInuous   SINGleshot   DEFault,</b>	Multiple measurement (counting, until Status = STEP   RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–	V3.40
<b>&lt;Stop Cond&gt;</b>	Description of parameters	Def. value	Def. unit	FW-Vers.
<b>NONE   SONerror   DEFault,</b>	Continue measurement even in case of error Stop measurement in case of error ( <i>stop on error</i> ) Sets the value to the default setting	NONE	–	V3.40
<b>&lt;Step Mode&gt;</b>	Description of parameters	Def. value	Def. unit	FW-Vers.
<b>STEP   NONE   DEFault</b>	Interrupt measurement after each statistics cycle Continue measurement according to its rep. Mode Sets the value to the default setting	NONE	–	V3.40
Description of command				
This command combines the ...CONTROL:RMODE, ...CONTROL:STATistics, and ...CONTROL:REPetition commands, see below.				

<b>CONFigure:MODulation:MERRor:HPSK:CONTROL:RMODE[?]</b>		Result mode		
<b>&lt;Result Mode&gt;</b>				
<b>&lt;Result Mode&gt;</b>	Description of parameters	Def. value	Def. unit	FW-Vers.
<b>SCALar   ARRay</b>	Scalar values only (incl. ramp matching) Scalar measured values and arrays	ARR	–	V3.40
Description of command				
This command specifies the type of measured values.				

<b>CONFigure:MODulation:MERRor:HPSK:CONTROL:STATistics[?]</b>		Statistics Count		
<b>&lt;Statistics Count&gt;</b>				
<b>&lt;Statistics Count&gt;</b>	Description of parameters	Def. value	Def. unit	FW-Vers.
<b>1 to 1000</b>	Number of bursts per statistics cycle	100	–	V3.40
Description of command				
This command specifies the type of measured values and defines the number of bursts forming a statistics cycle.				

CONFigure:MODulation:MERRor:HPSK:CONTRol:REPetition[?] <Repetition>, <Stop Cond>, <Step Mode>				Test Cycles
<Repetition>	Description of parameters	Def. value	Def. unit	FW vers.
<b>1 to 10000</b>   <b>CONTinuous</b>   <b>SINGleshot</b>   <b>DEFault</b> ,	Multiple measurement (counting, until Status = STEP   RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–	V3.40
<Stop Cond>	Description of parameters	Def. value	Def. unit	FW vers.
<b>NONE</b>   <b>SONerror</b>   <b>DEFault</b> ,	Continue measurement even in case of error Stop measurement in case of error ( <i>stop on error</i> ) Sets the value to the default setting	NONE	–	V3.40
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
<b>STEP</b>   <b>NONE</b>   <b>DEFault</b>	Interrupt measurement after each statistics cycle Continue measurement according to its rep. Mode Sets the value to the default setting	NONE	–	V3.40
Description of command				
This command determines the repetition mode, stop condition, and stepping mode for the measurement.				
<b>Note:</b> In the case of READ commands (READ: ...), the <Repetition> parameter has no effect; the measurement is always stopped after a single shot.				

DEFault:MODulation:MERRor:HPSK:CONTRol[?] <Enable>				Default Settings
Enable	Description of parameters	Def. value	Def. unit	FW vers.
<b>ON</b>   <b>OFF</b>	The parameters are set to their default values Some or all parameters are not set to default	ON	–	V3.40
Description of command				
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystem MODulation:MERRor:...:CONTRol to their default values (the setting <i>OFF</i> results in an error message).				
If used as a query, the command returns whether all parameters are set to their default values ( <i>ON</i> ) or not ( <i>OFF</i> ).				

### Subsystem LIMit

The subsystem *MODulation:OEMP:...:LIMit* (refer to page 6.46) defines the tolerance values for the *OEMP* modulation measurements. The subsystem corresponds to the *Modulation* section in the *Limits* tab in the popup menu *Modulation Configuration*.

### Subsystem SUBarrays

The subsystem *SUBarrays:MODulation:MERRor* defines the measurement range and the type of output values.

CONFigure:SUBarrays:MODulation:MERRor:HPSK[?] <Mode>, <Start>, <Samples>		Definition of Subarrays		
<Mode>	Description of parameters	Def. value	Def. unit	FW vers.
ALL   ARITHmetical   MINimum   MAXimum,	Return all measurement values Return arithm. mean value in every range Return minimum value in every range Return maximum value in every range	ALL	–	V3.40
<Start>	Description of parameters	Def. value	Def. unit	FW vers.
0 μs to 833 μs,	Start time in current range	NAN	s	V3.40
<Samples>	Description of parameters	Def. value	Def. unit	FW vers.
0 to 1024	Number of samples in current range	NAN	–	V3.40
Description of command				
<p>This command configures the <code>READ:SUBarrays...</code>, <code>FETCh:SUBarrays...</code>, and <code>SAMple:SUBarrays:MODulation:MERRor</code> commands. It restricts the measurement to up to 32 subranges where either all measurement results (the number of which is given by the second numerical parameter) or a single statistical value is returned. The subranges are defined by the start time and the number of test points which are located on a fixed, equidistant grid with a step width of 1 symbol period.</p> <p>The subranges may overlap but must be within the total range of the <i>Modulation</i> measurement. Test points outside this range are not measured (result <i>NAN</i>) and do not enter into the <i>ARITHmetical</i>, <i>MINimum</i> and <i>MAXimum</i> values.</p> <p>By default, only one range corresponding to the total measurement range is used and all measurement values are returned.</p>				

### Measured Values

The subsystem *MODulation:MERRor* measures and returns the magnitude error results and compares them with the tolerance values. The subsystem corresponds to the various output elements in the measurement menu *MODulation*, application *Magnitude Error*.

<b>READ[:SCALar]:MODulation:MERRor:HPSK?Start</b>				single shot measurement and	Scalar Results return results
<b>FETCh[:SCALar]:MODulation:MERRor:HPSK?Read</b>				out meas. results	(unsynchronized)
<b>SAMPlE[:SCALar]:MODulation:MERRor:HPSK?Read</b>				out measurement results	(synchronized)
Returned values	Value range	Def. value	Def. unit	FW vers.	
<b>ME Peak (x3),</b>	0.0 % to 100.0 %	NAN	%	V3.40	
<b>ME RMS (x3),</b>	0.0 % to 100.0 %	NAN	%		
<b>Carrier Feedthrough (x3),</b>	-120.0 dB to -20.0 dB	NAN	dB		
<b>I/Q Imbalance (x3),</b>	-120.0 dB to -20.0 dB	NAN	dB		
<b>Carrier Freq. Error (x3),</b>	0 Hz to 1000 Hz	NAN	Hz		
<b>Transmit Time Error (x3),</b>	0 μs to 10 μs	NAN	μs		
<b>Rho (x3),</b>	0 to 1	NAN	—		
<b>AT Power (x3),</b>	-133.0 dBm to +19.0 dBm	NAN	dB		
<b>Current Statistics,</b>	1 to 1000	NAN	—		
<b>Limit Matching</b>	0.0 % to 100.0 %	NAN	%		
Description of command					
<p>These commands are always queries. They start a magnitude error measurement and output the scalar measurement results (see Chapter 4). The calculation of results in an <i>average</i> or <i>peak</i> measurement is described in Chapter 3 (see <i>calculation of statistical quantities</i>). The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i>, the <i>Average</i>, and the <i>MaxMin</i> value.</p>					

<b>CALCulate[:SCALar]:MODulation:MERRor:HPSK:MATCHing:LIMit?</b>				Out of Tolerance	
Returned values	Value range	Def. value	Def. unit	FW vers.	
<b>ME Peak (x3),</b>	For all measured values: NMAU   NMAL   INV   OK	INV	—	V3.40	
<b>ME RMS (x3),</b>		INV	—		
<b>Carrier Feedthrough (x3),</b>		INV	—		
<b>I/Q Imbalance (x3),</b>		INV	—		
<b>Carrier Freq. Error (x3),</b>		INV	—		
<b>Transmit Time Error (x3),</b>		INV	—		
<b>Rho (x3),</b>		INV	—		
<b>AT Power (x3)</b>		INV	—		
Description of command					
<p>This command is always a query. It indicates whether and in which way the error limits for the scalar measured values (see above command) have been exceeded. The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i>, the <i>Average</i>, and the <i>MaxMin</i> value. The limits are defined with the <code>CONFigure:MODulation:OEMP...</code> commands.</p> <p>The following messages may be output for all measured values:</p>					
NMAU	Underflow of tolerance value	<i>not matching, underflow</i>			
NMAL	Tolerance value exceeded	<i>not matching, overflow</i>			
INV	Measurement invalid	<i>invalid</i>			
OK	all tolerances matched				

Magnitude Error in Evaluation Period				
<b>READ:ARRay:MODulation:MERRor:HPSK:CURRent?</b> <b>READ:ARRay:MODulation:MERRor:HPSK:AVERAge?</b> <b>READ:ARRay:MODulation:MERRor:HPSK:MMAx?</b>				
Start single shot measurement and return results				
<b>FETCh:ARRay:MODulation:MERRor:HPSK:CURRent?</b> <b>FETCh:ARRay:MODulation:MERRor:HPSK:AVERAge?</b> <b>FETCh:ARRay:MODulation:MERRor:HPSK:MMAx?</b>				
Read measurement results (unsynchronized)				
<b>SAMPlE:ARRay:MODulation:MERRor:HPSK:CURRent?</b> <b>SAMPlE:ARRay:MODulation:MERRor:HPSK:AVERAge?</b> <b>SAMPlE:ARRay:MODulation:MERRor:HPSK:MMAx?</b>				
Read measurement results (synchronized)				
Returned values	Value range	Def. value	Def. unit	FW vers.
1 <sup>st</sup> value for magnitude error,	0.0 % to + 100.0 %,	NAN	%	V3.40
x <sup>th</sup> value for magnitude error	0.0 % to + 100.0 %	NAN	%	
Description of command				
These commands are always queries. They return the magnitude error vs. time at fixed, equidistant test points. The number of measured values is 1024, corresponding to a time range of 0 symbols to 833 microseconds.				
The calculation of <i>current</i> , <i>average</i> , and <i>mmax</i> (Min./Max.) results is explained in Chapter 3 (see <i>display mode</i> ).				

Subarray Results				
<b>READ:SUBarrays:MODulation:MERRor:HPSK:CURRent?</b> <b>READ:SUBarrays:MODulation:MERRor:HPSK:AVERAge?</b> <b>READ:SUBarrays:MODulation:MERRor:HPSK:MMAx?</b>				
Start measurement and wait for end ⇒ RUN				
<b>FETCh:SUBarrays:MODulation:MERRor:HPSK:CURRent?</b> <b>FETCh:SUBarrays:MODulation:MERRor:HPSK:AVERAge?</b> <b>FETCh:SUBarrays:MODulation:MERRor:HPSK:MMAx?</b>				
Read meas. results (unsynchronized) ⇒ RUN				
<b>SAMPlE:SUBarrays:MODulation:MERRor:HPSK:CURRent?</b> <b>SAMPlE:SUBarrays:MODulation:MERRor:HPSK:AVERAge?</b> <b>SAMPlE:SUBarrays:MODulation:MERRor:HPSK:MMAx?</b>				
Read results (synchronized) ⇒ RUN				
Returned values	Description of parameters	Def. value	Def. unit	FW vers.
1 <sup>st</sup> value for magnitude error	0.0 % to + 100.0 %,	NAN	%	V3.40
x <sup>th</sup> value for magnitude error	0.0 % to + 100.0 %	NAN	%	
Description of command				
These commands are always queries. They measure and return the magnitude error versus time in the subranges defined by means of the <code>CONFIgure:SUBarrays:MODulation:MERRor</code> command.				
The <code>CONFIgure:SUBarrays:MODulation:MERRor</code> command defines a maximum of 32 subranges. If one of the statistical modes ( <code>ARITHmetical</code> , <code>MINimum</code> , <code>MAXimum</code> ) is set, only one value is returned per subrange.				
The calculation of <i>current</i> , <i>average</i> , <i>minimum</i> , and <i>maximum</i> results is explained in Chapter 3 (see <i>display mode</i> ).				

## MODulation:IQAnalyzer (IQ Analyzer)

The subsystem *MODulation:IQAnalyzer* measures the I and Q amplitudes of the received HPSK signal as a function of time. The subsystem corresponds to the measurement menu *Modulation*, application *I/Q Analyzer HPSK*, and the sections in the popup menu *Modulation Configuration* that are related to the *I/Q Analyzer* application.

### Control of Measurement

The subsystem *MODulation:IQAnalyzer* controls the measurement. It corresponds to the softkey *IQ Analyzer* in the measurement menu *Modulation*.

<b>INITiate:MODulation: IQAnalyzer:HPSK</b>	Start new measurement	⇒	<i>RUN</i>
<b>ABORT:MODulation: IQAnalyzer:HPSK</b>	Abort running measurement and switch off	⇒	<i>OFF</i>
<b>STOP:MODulation: IQAnalyzer:HPSK</b>	Stop measurement after current stat. cycle	⇒	<i>STOP</i>
<b>CONTinue:MODulation: IQAnalyzer:HPSK</b>	Next measurement step ( <i>stepping mode</i> )	⇒	<i>RUN</i>
Description of command			FW vers.
These commands have no query form. They start and stop the IQ Analyzer measurement, setting it to the status indicated in the top right column.			V3.40

<b>CONFigure:MODulation: IQAnalyzer:HPSK:EREPorting[?]</b>		Event Reporting		
<b>&lt;Report Mode&gt;</b>				
<b>&lt;Report Mode&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>SRQ  </b>	Service request	OFF	–	V3.40
<b>SOPC  </b>	Single operation complete			
<b>SRSQ  </b>	SRQ and SOPC			
<b>OFF  </b>	No reporting			
<b>DEFault</b>	Sets the value to the default setting			
Description of command				
This command defines the events generated when the measurement is terminated or stopped (see <i>Event Reporting</i> in Chapter 5 of the CMU manual).				

<b>FETCh[:SCALar]:MODulation: IQAnalyzer:HPSK:STATus?</b>		Measurement Status		
<b>Return</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>OFF  </b>	Measurement in the OFF state (*RST or ABORT)	OFF	–	V3.40
<b>RUN  </b>	Running (after INITiate, CONTinue or READ)			
<b>STOP  </b>	Stopped (STOP)			
<b>ERR  </b>	OFF (could not be started)			
<b>STEP  </b>	Stepping mode (<stepmode>=STEP)			
<b>RDY</b>	Stopped according to repetition mode and stop condition			
<b>1 to 10000  </b>	Counter for current statistics cycle	NONE	–	
<b>NONE</b>	No counting mode set			
<b>1 to 1000</b>	Counter for current evaluation period within a cycle	NONE	–	
<b>NONE</b>	Statistic count set to off			
Description of command				
This command is always a query. It returns the status of the measurement (see Chapters 3 and 5).				

## Test Configuration

The commands of the following subsystems configure the *IQ Analyzer* measurement in the *Modulation* menu. They correspond to the sections in the *Modulation Configuration* menu that are related to the *I/Q Analyzer* application.

### Subsystem CONTROL

The subsystem *MODulation:IQANalyzer:CONTROL* configures the measurement. It corresponds to the tab *Control* in the popup menu *Modulation Configuration*.

CONFigure:MODulation:IQANalyzer:HPSK:CONTROL:REPetition[?]				Test Cycles
<b>&lt;Repetition&gt;, &lt;Stop Cond&gt;, &lt;Step Mode&gt;</b>				
<Repetition>	Description of parameters	Def. value	Def. unit	FW vers.
<b>1 to 10000  </b>	Multiple measurement (counting, until Status = STEP   RDY)	SING	–	V3.40
<b>CONTInuous   SINGleshot  </b>	Continuous measurement (until STOP or ABORT)			
<b>DEFault,</b>	Single shot measurement (until Status = RDY)			
	Sets the value to the default setting			
<Stop Cond>	Description of parameters	Def. value	Def. unit	FW vers.
<b>NONE  </b>	Continue measurement even in case of error	NONE	–	V3.40
<b>SONerror  </b>	Stop measurement in case of error ( <i>stop on error</i> )			
<b>DEFault,</b>	Sets the value to the default setting			
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
<b>STEP  </b>	Interrupt measurement after each statistics cycle	NONE	–	V3.40
<b>NONE  </b>	Continue measurement according to its rep. Mode			
<b>DEFault</b>	Sets the value to the default setting			
Description of command				
This command determines the repetition mode, stop condition, and stepping mode for the measurement.				
<b>Note:</b> In the case of READ commands (READ: ...), the <Repetition> parameter has no effect; the measurement is always stopped after a single shot.				

CONFigure:MODulation:IQANalyzer:HPSK:CONTROL:RMODE[?]				Result mode
<b>&lt;Result Mode&gt;</b>				
<Result Mode>	Description of parameters	Def. value	Def. unit	FW-Vers.
<b>SCALar  </b>	Scalar values only	ARR	–	V3.40
<b>ARRay</b>	Scalar measured values and arrays			
Description of command				
This command specifies the type of measured values.				

DEFAult:MODulation:IQAnalyzer:HPSK:CONTRol[?] <Enable>		Default Settings		
Enable	Description of parameters	Def. value	Def. unit	FW vers.
<b>ON   OFF</b>	The parameters are set to their default values Some or all parameters are not set to default	ON	–	V3.40
Description of command				
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystem <code>MODulation:IQAnalyzer:...:CONTRol</code> to their default values (the setting <i>OFF</i> results in an error message).				
If used as a query, the command returns whether all parameters are set to their default values ( <i>ON</i> ) or not ( <i>OFF</i> ).				

### Subsystem SUBarrays

The subsystem `SUBarrays:MODulation:IQAnalyzer` defines the measurement range and the type of output values.

CONFIgure:SUBarrays:IQAnalyzer:HPSK[?] <Mode>, <Start>, <Samples>		Definition of Subarrays		
<Mode>	Description of parameters	Def. value	Def. unit	FW vers.
<b>ALL</b>	Return all measurement values	ALL	–	V3.40
<Start>	Description of parameters	Def. value	Def. unit	FW vers.
<b>0 <math>\mu</math>s to 833 <math>\mu</math>s,</b>	Start time in current range	NAN	s	V3.40
<Samples>	Description of parameters	Def. value	Def. unit	FW vers.
<b>0 to 4096</b>	Number of samples in current range	NAN	–	V3.40
Description of command				
This command configures the <code>READ:SUBarrays...</code> , <code>FETCh:SUBarrays...</code> , and <code>SAMPlE:SUBarrays:MODulation:IQAnalyzer</code> commands. It restricts the measurement to up to 32 subranges where either all measurement results (the number of which is given by the second numerical parameter) or a single statistical value is returned. The subranges are defined by the start time and the number of test points which are located on a fixed, equidistant grid with a step width of 1 symbol period.				
The subranges may overlap but must be within the total range of the <i>IQ Analyzer</i> measurement. Test points outside this range are not measured (result <i>NAN</i> ).				
By default, only one range corresponding to the total measurement range is used and all measurement values are returned.				

**Measured Values**

The subsystem *MODulation:IQAnalyzer* measures and returns the IQ Analyzer results. No limit check is performed. The subsystem corresponds to the various output elements in the measurement menu *MODulation*, application *IQ Analyzer*.

		Scalar Results		
<b>READ[:SCALar]:MODulation:IQAnalyzer:HPSK?</b>		Start single shot measurement and return results		
<b>FETCh[:SCALar]:MODulation: IQAnalyzer:HPSK?</b>		Read out meas. results (unsynchronized)		
<b>SAMPlE[:SCALar]:MODulation: IQAnalyzer:HPSK?</b>		Read out measurement results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
<b>IQ Peak (x3),</b>	0.0 % to 100.0 %	NAN	%	V3.40
<b>IQ RMS (x3),</b>	0.0 % to 100.0 %	NAN	%	
<b>Carrier Feedthrough (x3),</b>	-120.0 dB to -20.0 dB	NAN	dB	
<b>I/Q Imbalance (x3),</b>	-120.0 dB to -20.0 dB	NAN	dB	
<b>Carrier Freq. Error (x3),</b>	0 Hz to 1000 Hz	NAN	Hz	
<b>Transmit Time Error (x3),</b>	0 μs to 10 μs	NAN	μs	
<b>Rho (x3),</b>	0 to 1	NAN	–	
<b>AT Power (x3),</b>	-133.0 dBm to +19.0 dBm	NAN	dB	
Description of command				
These commands are always queries. They start a modulation measurement and output the scalar measurement results (see Chapter 4). The calculation of results in an <i>average</i> or <i>peak</i> measurement is described in Chapter 3 (see <i>calculation of statistical quantities</i> ). The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i> , the <i>Average</i> , and the <i>MaxMin</i> value.				

		Normalized I phase amplitude		
<b>READ:ARRay:MODulation:IQAnalyzer:HPSK:IPHase?</b>		Start single shot measurement and return results		
<b>FETCh:ARRay:MODulation:IQAnalyzer:HPSK:IPHase?</b>		Read measurement results (unsynchronized)		
<b>SAMPlE:ARRay:MODulation:IQAnalyzer:HPSK:IPHase?</b>		Read measurement results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
<b>-2.0 to +2.0,</b>	1 <sup>st</sup> value for normalized I amplitude,	NAN	–	V3.40
<b>....,</b>				
<b>-2.0 to +2.0</b>	4096 <sup>th</sup> value for normalized I amplitude	NAN	–	
Description of command				
These commands are always queries. They return the normalized I amplitude. The number of measured values is 4096. This corresponds to an oversampling factor of four compared to the <i>OEMP</i> modulation measurements. The time range of 0 symbols to 833 microseconds.				

<b>READ:ARRay:MODulation:IQANalyzer:HPSK:QPHase?</b>		Normalized Q phase amplitude		
		Start single shot measurement and return results		
<b>FETCh:ARRay:MODulation:IQANalyzer:HPSK:QPHase?</b>		Read measurement results (unsynchronized)		
<b>SAMPlE:ARRay:MODulation:IQANalyzer:HPSK:QPHase?</b>		Read measurement results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
-2.0 to +2.0, ..., -2.0 to +2.0	1 <sup>st</sup> value for normalized Q amplitude, 4096 <sup>th</sup> value for normalized Q amplitude	NAN NAN	- -	V3.40
Description of command				
These commands are always queries. They return the normalized Q amplitude. The number of measured values is 4096. This corresponds to an oversampling factor of four compared to the <i>OEMP</i> modulation measurements. The time range of 0 symbols to 833 microseconds.				

<b>READ:SUBarrays:MODulation:IQANalyzer:HPSK:IPHase?</b>		Subarray Results		
		Start measurement and wait for end		
<b>FETCh:SUBarrays:MODulation:IQANalyzer:HPSK:IPHase?</b>		Read meas. results (unsynchronized)		
<b>SAMPlE:SUBarrays:MODulation:IQANalyzer:HPSK:IPHase?</b>		Read results (synchronized)		
Returned values	Description of parameters	Def. value	Def. unit	FW vers.
-2.0 to +2.0, ..., -2.0 to +2.0	1 <sup>st</sup> value for normalized I amplitude, n <sup>th</sup> value for normalized I amplitude	NAN NAN	- -	V3.40
Description of command				
These commands are always queries. They return the normalized I amplitude in the subranges defined by means of the <code>CONFigure:SUBarrays:MODulation:IQANalyzer:HPSK:IPHase</code> command.				
The <code>CONFigure:SUBarrays:MODulation:IQANalyzer:HPSK:IPHase</code> command defines a maximum of 32 subranges.				

<b>READ:SUBarrays:MODulation:IQANalyzer:HPSK:QPHase?</b>		Subarray Results		
		Start measurement and wait for end		
<b>FETCh:SUBarrays:MODulation:IQANalyzer:HPSK:QPHase?</b>		Read meas. results (unsynchronized)		
<b>SAMPlE:SUBarrays:MODulation:IQANalyzer:HPSK:QPHase?</b>		Read results (synchronized)		
Returned values	Description of parameters	Def. value	Def. unit	FW vers.
-2.0 to +2.0, ..., -2.0 to +2.0	1 <sup>st</sup> value for normalized Q amplitude, n <sup>th</sup> value for normalized Q amplitude	NAN NAN	- -	V3.40
Description of command				
These commands are always queries. They return the normalized Q amplitude in the subranges defined by means of the <code>CONFigure:SUBarrays:MODulation:IQANalyzer:HPSK:QPHase</code> command.				
The <code>CONFigure:SUBarrays:MODulation:IQANalyzer:HPSK:QPHase</code> command defines a maximum of 32 subranges.				

## CDPower:CDPW (Code Domain Power)

The subsystem *CDPower:CDPW* measures the Code Domain Power output of the access terminal. Both the *RRI* and the *Pilot* time slot are evaluated in the same measurement shot. The *CDPower:CDPW* subsystem corresponds to the measurement menu *Code Domain Power*, application *CDP* and the sections related to this application in the associated popup menu *Code Domain Power Configuration*.

### Control of Measurement

The subsystem *CDPower:CDPW* controls the code domain power measurement. It corresponds to the softkey *CDP* in the measurement menu *Code Domain Power*.

<b>INITiate:CDPower:CDPW</b>	Start new measurement	⇒	<i>RUN</i>
<b>ABORt:CDPower:CDPW</b>	Abort running measurement and switch off	⇒	<i>OFF</i>
<b>STOP:CDPower:CDPW</b>	Stop measurement after current stat. cycle	⇒	<i>STOP</i>
<b>CONTinue:CDPower:CDPW</b>	Next measurement step ( <i>stepping mode</i> )	⇒	<i>RUN</i>
Description of command			FW vers.
These commands have no query form. They start and stop the code domain power measurement, setting it to the status indicated in the top right column.			V3.40

<b>CONFigure:CDPower:CDPW:EREPorting[?]</b>		Event Reporting		
<b>&lt;Report Mode&gt;</b>				
<b>&lt;Report Mode&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>SRQ  </b>	Service request	OFF	–	V3.40
<b>SOPC  </b>	Single operation complete			
<b>SRSQ  </b>	SRQ and SOPC			
<b>DEFault  </b>	Sets the value to the default setting			
<b>OFF</b>	No reporting			
Description of command				
This command defines the events generated when the measurement is terminated or stopped (see <i>Event Reporting</i> in Chapter 5 of the CMU manual).				

<b>FETCh[:SCALar]:CDPower:CDPW:STATus?</b>		Measurement Status		
<b>Return</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>OFF  </b>	Measurement in the OFF state (*RST or ABORt)	OFF	–	V3.40
<b>RUN  </b>	Running (after INITiate, CONTinue or READ)			
<b>STOP  </b>	Stopped (STOP)			
<b>ERR  </b>	OFF (could not be started)			
<b>STEP  </b>	Stepping mode (<stepmode>=STEP)			
<b>RDY</b>	Stopped according to repetition mode and stop condition			
<b>1 to 10000  </b>	Counter for current statistics cycle	NONE	–	
<b>NONE</b>	No counting mode set			
<b>1 to 1000</b>	Counter for current evaluation period within a cycle	NONE	–	
<b>NONE</b>	Statistic count set to off			
Description of command				
This command is always a query. It returns the status of the measurement (see Chapters 3 and 5).				

## Test Configuration

The commands of the following subsystems configure the *Code Domain Power* measurement in the *Code Domain Power* menu. They correspond to the *Code Domain Power Configuration* popup menu.

## Subsystem CONTROL

The subsystem *CDPower:CDPW:CONTROL* configures the Code Domain Power measurement. It defines the result mode, result order, repetition mode, statistic count and stop condition of the measurement. It corresponds to the tab *Control* in the popup menu *Code Domain Power Configuration*.

<b>CONFigure:CDPower:CDPW:CONTROL[?]</b>		Scope of Measurement		
<b>&lt;Result Mode&gt;, &lt;Current Statistics&gt;, &lt;Repetition&gt;, &lt;Stop Cond&gt;, &lt;Step Mode&gt;</b>				
<b>&lt;Result Mode&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>SCALar   ARRay,</b>	Scalar values only (incl. ramp matching) Scalar measured values and arrays	ARR	–	V3.40
<b>&lt;Current Statistics&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>1 to 1000,</b>	Number of bursts per statistics cycle	100	–	V3.40
<b>&lt;Repetition&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>1 to 10000   CONTInuous   SINGleshot   DEFault,</b>	Multiple measurement ( <i>counting</i> , until <i>Status = STEP   RDY</i> ) Continuous measurement (until <i>STOP</i> or <i>ABORT</i> ) Single shot measurement (until <i>Status = RDY</i> ) Sets the value to the default setting	SING	–	V3.40
<b>&lt;Stop Cond&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>NONE   SONerror   DEFault,</b>	Continue measurement even in case of error Stop measurement in case of error ( <i>stop on error</i> ) Sets the value to the default setting	NONE	–	V3.40
<b>&lt;Step Mode&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>STEP   NONE   DEFault</b>	Interrupt measurement after each statistics cycle Continue measurement according to its rep. Mode Sets the value to the default setting	NONE	–	V3.40
Description of command				
This command combines the ...CONTROL:RMODE, ...CONTROL:STATISTICS and the ...CONTROL:REPETITION commands, see below.				

<b>CONFigure:CDPower:CDPW:CONTROL:RMODE[?]</b>		Result mode		
<b>&lt;Result Mode&gt;</b>				
<b>&lt;Result Mode&gt;</b>	Description of parameters	Def. value	Def. unit	FW-Vers.
<b>SCALar   ARRay</b>	Scalar values only (incl. ramp matching) Scalar measured values and arrays	ARR	–	V3.40
Description of command				
This command specifies the type of measured values.				

CONFigure:CDPower:CDPW:CONTRol:STATistics[?] <Current Statistics >				Statistic Count
<Statistics Count>	Description of parameters	Def. value	Def. unit	FW-Vers.
<b>1 to 1000</b>	Number of bursts per statistics cycle	100	–	V3.40
Description of command				
This command defines the number of bursts forming a statistics cycle.				

CONFigure:CDPower:CDPW:CONTRol:REPetition[?] <Repetition>, <Stop Cond>, <Step Mode>				Test Cycles
<Repetition>	Description of parameters	Def. value	Def. unit	FW vers.
<b>1 to 10000  </b> <b>CONTinuous  </b> <b>SINGleshot  </b> <b>DEFault,</b>	Multiple measurement ( <i>counting</i> , until <i>Status = STEP   RDY</i> ) Continuous measurement (until <i>STOP</i> or <i>ABORT</i> ) Single shot measurement (until <i>Status = RDY</i> ) Sets the value to the default setting	SING	–	V3.40
<Stop Cond>	Description of parameters	Def. value	Def. unit	FW vers.
<b>NONE  </b> <b>SONerror  </b> <b>DEFault,</b>	Continue measurement even in case of error Stop measurement in case of error ( <i>stop on error</i> ) Sets the value to the default setting	NONE	–	V3.40
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
<b>STEP  </b> <b>NONE  </b> <b>DEFault</b>	Interrupt measurement after each statistics cycle Continue measurement according to its rep. Mode Sets the value to the default setting	NONE	–	V3.40
Description of command				
This command determines the repetition mode, stop condition, and stepping mode for the measurement.				
<b>Note:</b> In the case of READ commands (READ: ...), the <Repetition> parameter has no effect; the measurement is always stopped after a single shot.				

CONFigure:CDPower:CDPW:CONTRol:RORder[?] <Result Order>				Result Order
<Result Order>	Description of parameters	Def. value	Def. unit	FW vers.
<b>HADamard  </b> <b>BITReverse</b>	Walsh code channels returned using Hadamard matrix Walsh code channels returned at MSB to LSB	HAD	–	V3.40
Description of command				
This command defines the method used to display the code channels. <i>HADamard</i> displays the code channels in order determined by the Hadamard matrix. <i>BITReverse</i> displays the code channels so that the related code channels are adjacent to each other.				
This setting is only available for Code Domain and Peak Code Domain Error measurement applications.				

DEFault:CDPower:CDPW:CONTRol[?]				Default Settings
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
<b>ON  </b> <b>OFF</b>	The parameters are set to their default values Some or all parameters are not set to default	ON	–	V3.40
Description of command				
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystem <i>CDPower:CDPW:CONTRol</i> to their default values (the setting <i>OFF</i> results in an error message).				
If used as a query the command returns whether all parameters are set to their default values ( <i>ON</i> ) or not ( <i>OFF</i> ).				

**Subsystem LIMit**

**CDPower:CPCCommon:LIMit**

The subsystem *CDPower:CPCCommon:LIMit* defines common tolerance values for the scalar results of the following Code Domain Power applications (*CPCCommon*):

- Code Domain Power (*CDP*)
- Peak Code Domain Error Power (*PCDep*)
- Channel Power (*CHPW*)

CONFigure:CDPower:CPCCommon:CMAx:LIMit:ASYMmetric[:COMBined][?]				Limits
<Carrier Feedthrough Limit>, <Carrier Freq. Error Limit>, <Rho Limit>				
<Carrier Feedthrough Limit>	Description of parameters	Def. value	Def. unit	FW vers.
-120.0 to -20.0   DEFAult   OFF   ON,	Carrier feedthrough limit Sets the value to the default setting Disables the tolerance check Tolerance check enabled, last value re-activated	-25.0	dB	V3.40
<Carrier Freq. Error Limit>	Description of parameters	Def. value	Def. unit	FW vers.
0 to 1000.0 Hz   DEFAult   OFF   ON,	Carrier frequency error limit Sets the value to the default setting Disables the tolerance check Tolerance check enabled, last value re-activated	300.0	Hz	V3.40
<Rho Limit>	Description of parameters	Def. value	Def. unit	FW vers.
0.0 to 1.0   DEFAult   OFF   ON	Correlated power to the total power ratio limit Sets the value to the default setting Disables the tolerance check Tolerance check enabled, last value re-activated	0.944	-	V3.40
Description of command				
This command defines upper limits for the different traces and for the scalar modulation parameters derived from them. The keywords <i>CMAx</i> and <i>AVERage</i> refer to the <i>Current</i> and <i>Max.</i> display and for the <i>Average</i> display, respectively.				

CONFigure:CDPower:CPCCommon:AVERage:LIMit:ASYMmetric[:COMBined][?] <Carrier Feedthrough Limit Average>, <Carrier Freq. Error Limit Average>, <Rho Limit Average>				Limits
<Carrier Feedthrough Limit>	Description of parameters	Def. value	Def. unit	FW vers.
-120.0 to -20.0   DEFAult   OFF   ON,	Carrier feedthrough limit Sets the value to the default setting Disables the tolerance check Tolerance check enabled, last value re-activated	-25.0	dB	V3.40
<Carrier Freq. Error Limit>	Description of parameters	Def. value	Def. unit	FW vers.
0 to 1000.0 Hz   DEFAult   OFF   ON,	Carrier frequency error limit Sets the value to the default setting Disables the tolerance check Tolerance check enabled, last value re-activated	300.0	Hz	V3.40
<Rho Limit>	Description of parameters	Def. value	Def. unit	FW vers.
0.0 to 1.0   DEFAult   OFF   ON	Correlated power to the total power ratio limit Sets the value to the default setting Disables the tolerance check Tolerance check enabled, last value re-activated	0.944	–	V3.40
Description of command				
This command defines upper limits for the different traces and for the scalar modulation parameters derived from them. The keywords CMAX and AVERage refer to the <i>Current</i> and <i>Max.</i> display and for the <i>Average</i> display, respectively.				

DEFAult:CDPower:CPCCommon:LIMit[?] <Enable>				Default Settings
Enable	Description of parameters	Def. value	Def. unit	FW vers.
ON   OFF	The parameters are set to their default values Some or all parameters are not set to default	ON	–	V3.40
Description of command				
If used as a setting command with the parameter ON, this command sets all parameters of the subsystem CDPower:CPCCommon:LIMit to their default values (the setting OFF results in an error message).				
If used as a query, the command returns whether all parameters are set to their default values (ON) or not (OFF).				

## CDPower:CDPW:LIMit

The subsystem *CDPower:CDPW:LIMIT* defines the tolerance values that apply to the Code Domain Power application only.

CONFigure:CDPower:CDPW:CMAX:LIMit:ASYMmetric[:COMBined][?] <CDP Limit Y>				Limits
<CDP Limit Y>	Description of parameters	Def. value	Def. unit	FW vers.
-60.0 to 0   DEFAult   OFF   ON	Peak code domain power Y limit Sets the value to the default setting Disables the tolerance check Tolerance check enabled, last value re-activated	-23.0	dB	V3.40
Description of command				
This command defines the upper limit for the code domain power of the inactive channels (I and Q signal). The active channels are not checked. The keywords CMAX and AVERage refer to the <i>Current</i> and <i>Max.</i> display and for the <i>Average</i> display, respectively.				

CONFigure:CDPower:CDPW:AVERage:LIMit:ASYMmetric[:COMBined][?] <CDP Limit Y Average>				Limits
<CDP Limit Y>	Description of parameters	Def. value	Def. unit	FW vers.
-60.0 to 0   DEFault   OFF   ON	Peak code domain power Y limit Sets the value to the default setting Disables the tolerance check Tolerance check enabled, last value re-activated	-23.0	dB	V3.40
Description of command				
This command defines the upper limit for the code domain power of the inactive channels (I and Q signal). The active channels are not checked. The keywords CMAX and AVERage refer to the Current and Max. display and for the Average display, respectively.				

CONFigure:CDPower:CDPW:LIMit:IQLCheck[?] <IQ Leakage Check>				IQ Leakage Check
<IQ Leakage Check>	Description of parameters	Def. value	Def. unit	FW vers.
DEFault   OFF   ON	Sets the value to the default setting IQ Leakage Check disabled IQ Leakage Check enabled	ON	-	V3.40
Description of command				
This command enables or disables the IQ leakage check. When enabled, the tolerance check will be performed for all inactive channels regardless of whether the corresponding channel on the opposite signal phase is active or not. Disabling the IQ leakage check will only indicate tolerance violations of those inactive channels that have no active correspondance on the opposite signal phase.				

DEFault:CDPower:CDPW:LIMit[?] <Enable>				Default Settings
Enable	Description of parameters	Def. value	Def. unit	FW vers.
ON   OFF	The parameters are set to their default values Some or all parameters are not set to default	ON	-	V3.40
Description of command				
If used as a setting command with the parameter ON, this command sets all parameters of the subsystem CDPower:CDPW:LIMit to their default values (the setting OFF results in an error message).				
If used as a query, the command returns whether all parameters are set to their default values (ON) or not (OFF).				

**Measured Values**

The subsystem CDPower:CDPW determines and outputs the results of the Code Domain Power measurement.

		Scalar results:		
<b>READ[:SCALar]:CDPower:CDPW?</b>		Start single shot measurement and return results		
<b>FETCh[:SCALar]:CDPower:CDPW?</b>		Read out measurement results (unsynchronized)		
<b>SAMPlE[:SCALar]:CDPower:CDPW?</b>		Read out measurement results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
<b>AT Power (x3),</b>	-100.0 dBm to -50.0 dBm	NAN	dBm	V3.40
<b>Carrier Feedthrough (x3),</b>	-120.0 dB to -20.0 dB	NAN	dB	
<b>Carrier Freq. Error (x3),</b>	0 to 1000.0 Hz	NAN	Hz	
<b>Rho (x3),</b>	0.0 to 1.0	NAN	-	
<b>Out of Tolerance,</b>	0.0% to 100.0%	NAN	-	
<b>Current Statistics</b>	1 to 10000	NAN	-	
Description of command				
These commands are always queries. They start a measurement and output all scalar measurement results. The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i> , the <i>Average</i> , and the <i>MMax</i> value.				

		Limit Matching		
<b>CALCulate[:SCALar]:CDPower:CDPW:MATChing:LIMit?</b>				
Returned values	Value range	Def. value	Def. unit	FW vers.
<b>Carrier Feedthrough (x3),</b>	For all values	INV	-	V3.40
<b>Carrier Freq. Error (x3),</b>		INV	-	
<b>Rho (x3)</b>	NMAU   NMAL   INV   OK	INV	-	
Description of command				
This command is always a query. It indicates whether and in which way the (fixed) limit have been exceeded. The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i> , the <i>Average</i> , and the <i>MMax</i> value. The following messages may be generated:				
NMAU	Tolerance value underflow	<i>not matching, underflow</i>		
NMAL	Tolerance value exceeded	<i>not matching, overflow</i>		
INV	Measurement invalid	<i>invalid</i>		
OK	Tolerance value matched			

		I Signal Measurement		
<b>READ:ARRAy:CDPower:CDPW:ISIGnal[:VALue]:CURRent?</b>		Start single shot meas. and return results		
<b>FETCh:ARRAy:CDPower:CDPW:ISIGnal[:VALue]:CURRent?</b>		Read meas. results (unsynchronized)		
<b>SAMPlE:ARRAy:CDPower:CDPW:ISIGnal[:VALue]:CURRent?</b>		Read results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
<b>W<sub>0</sub><sup>16</sup> RRI time,</b>	-60.0 dB to +10.0 dB,	NAN	dB	V3.40
<b>W<sub>0</sub><sup>16</sup> Pilot time,</b>	...,			
<b>...,</b>	...,			
<b>W<sub>15</sub><sup>16</sup> RRI time,</b>	...,			
<b>W<sub>15</sub><sup>16</sup> Pilot time</b>	-60.0 dB to +10.0 dB			
Description of command				
These commands are always queries. They start a measurement and output the levels of the Walsh Code of the in-phase signal path (I-signal). 32 values are returned representing the alternating results of the RRI and the Pilot time. The calculation of <i>Current</i> is explained in Chapter 3 (see <i>display mode</i> ).				

		I Signal Measurement		
<b>READ:ARRAY:CDPower:CDPW:ISIGNAL[:VALUE]:AVERAGE?</b>		Start single shot meas. and return results		
<b>FETCH:ARRAY:CDPower:CDPW:ISIGNAL[:VALUE]:AVERAGE?</b>		Read meas. results (unsynchronized)		
<b>SAMPLE:ARRAY:CDPower:CDPW:ISIGNAL[:VALUE]:AVERAGE?</b>		Read results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
<b>W<sub>0</sub><sup>16</sup> RRI time,</b>	-60.0 dB to +10.0 dB,	NAN	dB	V3.40
<b>W<sub>0</sub><sup>16</sup> Pilot time,</b>	...,			
...,	...,			
<b>W<sub>15</sub><sup>16</sup> RRI time,</b>	...,			
<b>W<sub>15</sub><sup>16</sup> Pilot time</b>	-60.0 dB to +10.0 dB			
Description of command				
<p>These commands are always queries. They start a measurement and output the levels of the Walsh Code of the in-phase signal path (I-signal). 32 values are returned representing the alternating results of the RRI and the Pilot time. The calculation of <i>Average</i> is explained in Chapter 3 (see <i>display mode</i>).</p>				

		I Signal Measurement		
<b>READ:ARRAY:CDPower:CDPW:ISIGNAL[:VALUE]:MAXIMUM?</b>		Start single shot meas. and return results		
<b>FETCH:ARRAY:CDPower:CDPW:ISIGNAL[:VALUE]:MAXIMUM?</b>		Read meas. results (unsynchronized)		
<b>SAMPLE:ARRAY:CDPower:CDPW:ISIGNAL[:VALUE]:MAXIMUM?</b>		Read results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
<b>W<sub>0</sub><sup>16</sup> RRI time,</b>	-60.0 dB to +10.0 dB,	NAN	dB	V3.40
<b>W<sub>0</sub><sup>16</sup> Pilot time,</b>	...,			
...,	...,			
<b>W<sub>15</sub><sup>16</sup> RRI time,</b>	...,			
<b>W<sub>15</sub><sup>16</sup> Pilot time</b>	-60.0 dB to +10.0 dB			
Description of command				
<p>These commands are always queries. They start a measurement and output the levels of the Walsh Code of the in-phase signal path (I-signal). 32 values are returned representing the alternating results of the RRI and the Pilot time. The calculation of <i>Maximum</i> is explained in Chapter 3 (see <i>display mode</i>).</p>				

		Q signal Measurement		
<b>READ:ARRAY:CDPower:CDPW:QSIGnal[:VALUE]:CURRENT?</b>		Start single shot meas. and return results		
<b>FETCH:ARRAY:CDPower:CDPW:QSIGnal[:VALUE]:CURRENT?</b>		Read meas. results (unsynchronized)		
<b>SAMPLE:ARRAY:CDPower:CDPW:QSIGnal[:VALUE]:CURRENT?</b>		Read results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
<b>W<sub>0</sub><sup>16</sup> RRI time,</b>	-60.0 dB to +10.0 dB,	NAN	dB	V3.40
<b>W<sub>0</sub><sup>16</sup> Pilot time,</b>	...,			
...,	...,			
<b>W<sub>15</sub><sup>16</sup> RRI time,</b>	...,			
<b>W<sub>15</sub><sup>16</sup> Pilot time</b>	-60.0 dB to +10.0 dB			
Description of command				
<p>These commands are always queries. They start a measurement and output the levels of the Walsh Code of the quadrature signal path (Q-signal). 32 values are returned representing the alternating results of the RRI and the Pilot time. The calculation of <i>Current</i> is explained in Chapter 3 (see <i>display mode</i>).</p>				

		Q Signal Measurement		
<b>READ:ARRAY:CDPower:CDPW:QSIGnal[:VALue]:AVERAge?</b>		Start single shot meas. and return results		
<b>FETCh:ARRAY:CDPower:CDPW:QSIGnal[:VALue]:AVERAge?</b>		Read meas. results (unsynchronized)		
<b>SAMPlE:ARRAY:CDPower:CDPW:QSIGnal[:VALue]:AVERAge?</b>		Read results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
<b>W<sub>0</sub><sup>16</sup> RRI time,</b>	-60.0 dB to +10.0 dB,	NAN	dB	V3.40
<b>W<sub>0</sub><sup>16</sup> Pilot time,</b>	...			
...	...			
<b>W<sub>15</sub><sup>16</sup> RRI time,</b>	...			
<b>W<sub>15</sub><sup>16</sup> Pilot time</b>	-60.0 dB to +10.0 dB			
Description of command				
These commands are always queries. They start a measurement and output the levels of the Walsh Code of the quadrature signal path (Q-signal). 32 values are returned representing the alternating results of the RRI and the Pilot time. The calculation of <i>Average</i> is explained in Chapter 3 (see <i>display mode</i> ).				

		Q Signal Measurement		
<b>READ:ARRAY:CDPower:CDPW:QSIGnal[:VALue]:MAXimum?</b>		Start single shot meas. and return results		
<b>FETCh:ARRAY:CDPower:CDPW:QSIGnal[:VALue]:MAXimum?</b>		Read meas. results (unsynchronized)		
<b>SAMPlE:ARRAY:CDPower:CDPW:QSIGnal[:VALue]:MAXimum?</b>		Read results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
<b>W<sub>0</sub><sup>16</sup> RRI time,</b>	-60.0 dB to +10.0 dB,	NAN	dB	V3.40
<b>W<sub>0</sub><sup>16</sup> Pilot time,</b>	...			
...	...			
<b>W<sub>15</sub><sup>16</sup> RRI time,</b>	...			
<b>W<sub>15</sub><sup>16</sup> Pilot time</b>	-60.0 dB to +10.0 dB			
Description of command				
These commands are always queries. They start a measurement and output the levels of the Walsh Code of the quadrature signal path (Q-signal). 32 values are returned representing the alternating results of the RRI and the Pilot time. The calculation of <i>Maximum</i> is explained in Chapter 3 (see <i>display mode</i> ).				

<b>CALCulate:ARRAY:CDPower:CDPW:ISIGnal:CURRent[:RESult]:MATChing:LIMit?</b>		I Signal Tolerance		
Returned value	Description	Def. value	Def. unit	FW vers.
<b>32 bit value</b>	Indicator for limit matching in code channel W <sub>0</sub> <sup>16</sup> RRI (least significant bit) to W <sub>15</sub> <sup>16</sup> Pilot	NAN	–	V3.40
Description of command				
This command is always a query. If a bit is set in the returned value the I signal limit in the corresponding code channel is exceeded.				
<b>Note:</b> Even bits are assigned to the RRI time slot and odd bits are assigned to the pilot time slot.				

<b>CALCulate:ARRAY:CDPower:CDPW:ISIGnal:AVERAge[:RESult]:MATChing:LIMit?</b>		I Signal Tolerance		
Returned value	Description	Def. value	Def. unit	FW vers.
<b>32 bit value</b>	Indicator for limit matching in code channel W <sub>0</sub> <sup>16</sup> RRI (least significant bit) to W <sub>15</sub> <sup>16</sup> Pilot	NAN	–	V3.40
Description of command				
This command is always a query. If a bit is set in the returned value the I signal limit in the corresponding code channel is exceeded.				
<b>Note:</b> Even bits are assigned to the RRI time slot and odd bits are assigned to the pilot time slot.				

CALCulate:ARRay:CDPower:CDPW:ISignal:MAXimum[:RESult]:MATChing:LIMit?		I Signal Tolerance		
Returned value	Description	Def. value	Def. unit	FW vers.
32 bit value	Indicator for limit matching in code channel $W_0^{16}$ RRI (least significant bit) to $W_{15}^{16}$ Pilot	NAN	–	V3.40
Description of command				
This command is always a query. If a bit is set in the returned value the I signal limit in the corresponding code channel is exceeded.				
<b>Note:</b> Even bits are assigned to the RRI time slot and odd bits are assigned to the pilot time slot.				

CALCulate:ARRay:CDPower:CDPW:QSignal:CURRent[:RESult]:MATChing:LIMit?		Q Signal Tolerance		
Returned value	Description	Def. value	Def. unit	FW vers.
32 bit value	Indicator for limit matching in code channel $W_0^{16}$ RRI (least significant bit) to $W_{15}^{16}$ Pilot	NAN	–	V3.40
Description of command				
This command is always a query. If a bit is set in the returned value the Q signal limit in the corresponding code channel is exceeded.				
<b>Note:</b> Even bits are assigned to the RRI time slot and odd bits are assigned to the pilot time slot.				

CALCulate:ARRay:CDPower:CDPW:QSignal:AVERAge[:RESult]:MATChing:LIMit?		Q Signal Tolerance		
Returned value	Description	Def. value	Def. unit	FW vers.
32 bit value	Indicator for limit matching in code channel $W_0^{16}$ RRI (least significant bit) to $W_{15}^{16}$ Pilot	NAN	–	V3.40
Description of command				
This command is always a query. If a bit is set in the returned value the Q signal limit in the corresponding code channel is exceeded.				
<b>Note:</b> Even bits are assigned to the RRI time slot and odd bits are assigned to the pilot time slot.				

CALCulate:ARRay:CDPower:CDPW:QSignal:MAXimum[:RESult]:MATChing:LIMit?		Q Signal Tolerance		
Returned value	Description	Def. value	Def. unit	FW vers.
32 bit value	Indicator for limit matching in code channel $W_0^{16}$ RRI (least significant bit) to $W_{15}^{16}$ Pilot	NAN	–	V3.40
Description of command				
This command is always a query. If a bit is set in the returned value the Q signal limit in the corresponding code channel is exceeded.				
<b>Note:</b> Even bits are assigned to the RRI time slot and odd bits are assigned to the pilot time slot.				

## CDPower:PCDep (Peak Code Domain Error Power)

The subsystem *CDPower:PCDep* measures the Peak Code Domain Error Power output of the access terminal. Both the *RR1* and the *Pilot* time slot are evaluated in the same measurement shot. The subsystem corresponds to the measurement menu *Code Domain Power*, application *PCDep*, and the sections related to this application in the associated pop-up menu *Code Domain Power Configuration*.

### Control of Measurement

The subsystem *CDPower:PCDep* controls the peak code domain error power measurement. It corresponds to the softkey *PCDEP* in the measurement menu *Code Domain Power*.

<b>INITiate:CDPower:PCDep</b>	Start new measurement	⇒	<i>RUN</i>
<b>ABORt:CDPower:PCDep</b>	Abort running measurement and switch off	⇒	<i>OFF</i>
<b>STOP:CDPower:PCDep</b>	Stop measurement after current stat. cycle	⇒	<i>STOP</i>
<b>CONTinue:CDPower:PCDep</b>	Next measurement step ( <i>stepping mode</i> )	⇒	<i>RUN</i>
Description of command			FW vers.
These commands have no query form. They start and stop the peak code domain error power measurement, setting it to the status indicated in the top right column.			V3.40

<b>CONFigure:CDPower:PCDep:EREPorting[?]</b>		Event Reporting		
<b>&lt;Report Mode&gt;</b>				
<b>&lt;Report Mode&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>SRQ  </b>	Service request	OFF	–	V3.40
<b>SOPC  </b>	Single operation complete			
<b>SRSQ  </b>	SRQ and SOPC			
<b>OFF</b>	No reporting			
Description of command				
This command defines the events generated when the measurement is terminated or stopped (see <i>Event Reporting</i> in Chapter 5 of the CMU manual).				

<b>FETCh[:SCALar]:CDPower:PCDep:STATus?</b>		Measurement Status		
<b>Return</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>OFF  </b>	Measurement in the OFF state (*RST or ABORt)	OFF	–	V3.40
<b>RUN  </b>	Running (after INITiate, CONTinue or READ)			
<b>STOP  </b>	Stopped (STOP)			
<b>ERR  </b>	OFF (could not be started)			
<b>STEP  </b>	Stepping mode (<stepmode>=STEP)			
<b>RDY</b>	Stopped according to repetition mode and stop condition			
<b>1 to 10000  </b>	Counter for current statistics cycle	NONE	–	
<b>NONE</b>	No counting mode set			
<b>1 to 1000</b>	Counter for current evaluation period within a cycle	NONE	–	
<b>NONE</b>	Statistic count set to off			
Description of command				
This command is always a query. It returns the status of the measurement (see Chapters 3 and 5).				

## Test Configuration

The commands of the following subsystems configure the *Peak Code Domain Error Power* measurement in the *Code Domain Power* menu. They correspond to the *Code Domain Power Configuration* popup menu.

## Subsystem CONTROL

The subsystem *CDPower:PCDep:CONTROL* defines the result mode, result order, repetition mode, statistic count and stop condition of the measurement. These settings are provided in the *Control* tab in the popup menu *Code Domain Power Configuration*.

CONFigure:CDPower:PCDep:CONTROL[?]		Scope of Measurement		
<Result Mode>, <Current Statistics>, <Repetition>, <Stop Cond>, <Step Mode>				
<Result Mode>	Description of parameters	Def. value	Def. unit	FW-Vers.
SCALar   ARRay,	Scalar values only (incl. ramp matching) Scalar measured values and arrays	ARR	–	V3.40
<Current Statistics>	Description of parameters	Def. value	Def. unit	FW-Vers.
1 to 1000,	Number of bursts per statistics cycle	100	–	V3.40
<Repetition>	Description of parameters	Def. value	Def. unit	FW-Vers.
1 to 10000   CONTInuous   SINGleshot   DEFault,	Multiple measurement (counting, until Status = STEP   RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–	V3.40
<Stop Cond>	Description of parameters	Def. value	Def. unit	FW-Vers.
NONE   SONerror   DEFault,	Continue measurement even in case of error Stop measurement in case of error ( <i>stop on error</i> ) Sets the value to the default setting	NONE	–	V3.40
<Step Mode>	Description of parameters	Def. value	Def. unit	FW-Vers.
STEP   NONE   DEFault	Interrupt measurement after each statistics cycle Continue measurement according to its rep. Mode Sets the value to the default setting	NONE	–	V3.40
Description of command				
This command combines the ...CONTROL:RMODE, ...CONTROL:STATISTICS and the ...CONTROL:REPETITION commands, see below.				

CONFigure:CDPower:PCDep:CONTROL:RMODE[?]		Result Mode		
<Result Mode>				
<Result Mode>	Description of parameters	Def. value	Def. unit	FW-Vers.
SCALar   ARRay	Scalar values only (incl. ramp matching) Scalar measured values and arrays	ARR	–	V3.40
Description of command				
This command specifies the type of measured values.				

CONFigure:CDPower:PCDep:CONTRol:RORDER[?]				Result Order
<Result Order>				
<Result Order>	Description of parameters	Def. value	Def. unit	FW-Vers.
<b>HADamard   BITReverse</b>	Walsh code channels returned using Hadamard matrix Walsh code channels returned at MSB to LSB	HAD	–	V3.40
Description of command				
This command defines the method used to display the code channels. <i>HADamard</i> displays the code channels in order determined by the Hadamard matrix. <i>BITReverse</i> displays the code channels so that the related code channels are adjacent to each other.				
This setting is only available for Code Domain and Peak Code Domain Error measurement applications.				

CONFigure:CDPower:PCDep:CONTRol:STATistics[?]				Statistic Count
<Current Statistics>				
<Current Statistics>	Description of parameters	Def. value	Def. unit	FW-Vers.
<b>1 to 1000</b>	Number of bursts per statistics cycle	100	–	V3.40
Description of command				
This command defines the number of bursts forming a statistics cycle.				

CONFigure:CDPower:PCDep:CONTRol:REPetition[?]				Test Cycles
<Repetition>, <Stop Cond>, <Step Mode>				
<Repetition>	Description of parameters	Def. value	Def. unit	FW vers.
<b>1 to 10000   CONTInuous   SINGleshot   DEFault,</b>	Multiple measurement (counting, until Status = STEP   RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–	V3.40
<Stop Cond>	Description of parameters	Def. value	Def. unit	FW vers.
<b>NONE   SONerror   DEFault,</b>	Continue measurement even in case of error Stop measurement in case of error ( <i>stop on error</i> ) Sets the value to the default setting	NONE	–	V3.40
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
<b>STEP   NONE   DEFault</b>	Interrupt measurement after each statistics cycle Continue measurement according to its rep. Mode Sets the value to the default setting	NONE	–	V3.40
Description of command				
This command determines the repetition mode, stop condition, and stepping mode for the measurement.				
<b>Note:</b> In the case of READ commands (READ: ...), the <Repetition> parameter has no effect; the measurement is always stopped after a single shot.				

DEFault:CDPower:PCDep:CONTRol[?]				Default Settings
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
<b>ON   OFF</b>	The parameters are set to their default values Some or all parameters are not set to default	ON	–	V3.40
Description of command				
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystem <i>CDPower:PCDep:CONTRol</i> to their default values (the setting <i>OFF</i> results in an error message).				
If used as a query the command returns whether all parameters are set to their default values ( <i>ON</i> ) or not ( <i>OFF</i> ).				

## Subsystem LIMit

### CDPower:CPCCommon:LIMit

The subsystem *CDPower:CPCCommon:LIMit* defines common tolerance values for the scalar results of the *CPCCommon* Code Domain Power applications. These commands are described in on page 6.77.

### CDPower:PCDep:LIMit

The subsystem *CDPower:PCDep:LIMit* defines the tolerance values that apply to the Peak Code Domain Error Power application only.

CONFigure:CDPower:PCDep:CMAx:LIMit:ASYMmetric[:COMBined][?]				Limits
<CDP Limit Y>				
<PCDep Limit Y>	Description of parameters	Def. value	Def. unit	FW vers.
-60.0 to 0   DEFault   OFF   ON	Peak code domain error power limit Sets the value to the default setting Disables the tolerance check Tolerance check enabled, last value re-activated	-23.0	dB	V3.40
Description of command				
This command defines the upper limit for the peak code domain error power. The keywords <i>CMAx</i> and <i>AVERAge</i> refer to the <i>Current</i> and <i>Max.</i> display and for the <i>Average</i> display, respectively.				

CONFigure:CDPower:PCDep:AVERAge:LIMit:ASYMmetric[:COMBined][?]				Limits
<PCD Limit Y Average>				
<PCDep Limit Y>	Description of parameters	Def. value	Def. unit	FW vers.
-60.0 to 0   DEFault   OFF   ON	Peak code domain error power limit Sets the value to the default setting Disables the tolerance check Tolerance check enabled, last value re-activated	-23.0	dB	V3.40
Description of command				
This command defines the upper limit for the peak code domain error power. The keywords <i>CMAx</i> and <i>AVERAge</i> refer to the <i>Current</i> and <i>Max.</i> display and for the <i>Average</i> display, respectively.				

DEFault:CDPower:PCDep:LIMit[?]				Default Settings
<Enable>				
Enable	Description of parameters	Def. value	Def. unit	FW vers.
ON   OFF	The parameters are set to their default values Some or all parameters are not set to default	ON	-	V3.40
Description of command				
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystem <i>DEFault:CDPower:PCDep:LIMit</i> to their default values (the setting <i>OFF</i> results in an error message).				
If used as a query, the command returns whether all parameters are set to their default values ( <i>ON</i> ) or not ( <i>OFF</i> ).				

Measured Values

The subsystem *CDPower:PCDep* determines and outputs the results of the Peak Code Domain Error Power measurement. The peak code domain error power is the difference between the ideal code domain power and the measured signal.

<b>READ[:SCALar]:CDPower:PCDep?</b> <b>FETCh[:SCALar]:CDPower:PCDep?</b> <b>SAMPlE[:SCALar]:CDPower:PCDep?</b>		Scalar results: Start single shot measurement and return results Read out measurement results (unsynchronized) Read out measurement results (synchronized)		
Returned values	Description	Def. value	Def. unit	FW vers.
<b>AT Power (x3),</b>	-100.0 dBm to -50.0 dBm	NAN	dBm	V3.40
<b>Carrier Feedthrough (x3),</b>	-120.0 dB to -20.0 dB	NAN	dB	
<b>Carrier Freq. Error (x3),</b>	0 to 1000.0 Hz	NAN	Hz	
<b>Rho (x3),</b>	0.0 to 1.0	NAN	-	
<b>Out of Tolerance,</b>	0.0% to 100.0%	NAN	-	
<b>Current Statistics</b>	1 to 10000	NAN	-	
Description of command				
These commands are always queries. They start a measurement and output all scalar measurement results. The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i> , the <i>Average</i> , and the <i>MMax</i> value.				

<b>CALCulate[:SCALar]:CDPower:PCDep:MATChing:LIMit?</b>		Limit Matching		
Returned values	Description	Def. value	Def. unit	FW vers.
<b>Carrier Feedthrough (x3),</b>	For all values	NAN	-	V3.40
<b>Carrier Freq. Error (x3),</b>			-	
<b>Rho (x3)</b>	NMAU   NMAL   INV   OK		-	
Description of command				
This command is always a query. It indicates whether and in which way the (fixed) limit have been exceeded. The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i> , the <i>Average</i> , and the <i>MMax</i> value. The following messages may be generated:				
NMAU	Tolerance value underflow	<i>not matching, underflow</i>		
NMAL	Tolerance value exceeded	<i>not matching, overflow</i>		
INV	Measurement invalid	<i>invalid</i>		
OK	Tolerance value matched			

<b>READ:ARRAy:CDPower:PCDep:ISIGnal[:VALue]:CURRent?</b> <b>FETCh:ARRAy:CDPower:PCDep:ISIGnal[:VALue]:CURRent?</b> <b>SAMPlE:ARRAy:CDPower:PCDep:ISIGnal[:VALue]:CURRent?</b>		I Signal Measurement Start single shot meas. and return results Read meas. results (unsynchronized) Read results (synchronized)		
Returned values	Description of parameters	Def. value	Def. unit	FW vers.
<b>W<sub>0</sub><sup>16</sup> RRI time,</b>	-60.0 dB to +10.0 dB,	NAN	dB	V3.40
<b>W<sub>0</sub><sup>16</sup> Pilot time,</b>	...,			
<b>...,</b>	...,			
<b>W<sub>15</sub><sup>16</sup> RRI time,</b>	...,			
<b>W<sub>15</sub><sup>16</sup> Pilot time</b>	-60.0 dB to +10.0 dB			
Description of command				
These commands are always queries. They start a measurement and output the code domain error power of the Walsh Code of the in-phase signal path (I-signal). 32 values are returned representing the alternating results of the RRI and the Pilot time. The calculation of <i>Current</i> is explained in Chapter 3 (see <i>display mode</i> ).				

		I Signal Measurement		
<b>READ:ARRAY:CDPower:PCDep:ISIGNAL[:VALUE]:AVERAGE?</b>		Start single shot meas. and return results		
<b>FETCH:ARRAY:CDPower:PCDep:ISIGNAL[:VALUE]:AVERAGE?</b>		Read meas. results (unsynchronized)		
<b>SAMPLE:ARRAY:CDPower:PCDep:ISIGNAL[:VALUE]:AVERAGE?</b>		Read results (synchronized)		
Returned values	Description of parameters	Def. value	Def. unit	FW vers.
<b>W<sub>0</sub><sup>16</sup> RRI time,</b> <b>W<sub>0</sub><sup>16</sup> Pilot time,</b> ..., ..., <b>W<sub>15</sub><sup>16</sup> RRI time,</b> <b>W<sub>15</sub><sup>16</sup> Pilot time</b>	-60.0 dB to +10.0 dB, ..., ..., ..., -60.0 dB to +10.0 dB	NAN	dB	V3.40
Description of command				
These commands are always queries. They start a measurement and output the code domain error power of the Walsh Code of the in-phase signal path (I-signal). 32 values are returned representing the alternating results of the RRI and the Pilot time. The calculation of <i>Average</i> is explained in Chapter 3 (see <i>display mode</i> ).				

		I Signal Measurement		
<b>READ:ARRAY:CDPower:PCDep:ISIGNAL[:VALUE]:MAXIMUM?</b>		Start single shot meas. and return results		
<b>FETCH:ARRAY:CDPower:PCDep:ISIGNAL[:VALUE]:MAXIMUM?</b>		Read meas. results (unsynchronized)		
<b>SAMPLE:ARRAY:CDPower:PCDep:ISIGNAL[:VALUE]:MAXIMUM?</b>		Read results (synchronized)		
Returned values	Description of parameters	Def. value	Def. unit	FW vers.
<b>W<sub>0</sub><sup>16</sup> RRI time,</b> <b>W<sub>0</sub><sup>16</sup> Pilot time,</b> ..., ..., <b>W<sub>15</sub><sup>16</sup> RRI time,</b> <b>W<sub>15</sub><sup>16</sup> Pilot time</b>	-60.0 dB to +10.0 dB, ..., ..., ..., -60.0 dB to +10.0 dB	NAN	dB	V3.40
Description of command				
These commands are always queries. They start a measurement and output the code domain error power of the Walsh Code of the in-phase signal path (I-signal). 32 values are returned representing the alternating results of the RRI and the Pilot time. The calculation of <i>Maximum</i> is explained in Chapter 3 (see <i>display mode</i> ).				

		Q Signal Measurement		
<b>READ:ARRAY:CDPower:PCDep:QSIGnal[:VALUE]:CURRENT?</b>		Start single shot meas. and return results		
<b>FETCH:ARRAY:CDPower:PCDep:QSIGnal[:VALUE]:CURRENT?</b>		Read meas. results (unsynchronized)		
<b>SAMPLE:ARRAY:CDPower:PCDep:QSIGnal[:VALUE]:CURRENT?</b>		Read results (synchronized)		
Returned values	Description of parameters	Def. value	Def. unit	FW vers.
<b>W<sub>0</sub><sup>16</sup> RRI time,</b> <b>W<sub>0</sub><sup>16</sup> Pilot time,</b> ..., ..., <b>W<sub>15</sub><sup>16</sup> RRI time,</b> <b>W<sub>15</sub><sup>16</sup> Pilot time</b>	-60.0 dB to +10.0 dB, ..., ..., ..., -60.0 dB to +10.0 dB	NAN	dB	V3.40
Description of command				
These commands are always queries. They start a measurement and output the code domain error power of the Walsh Code of the quadrature signal path (Q-signal). 32 values are returned representing the alternating results of the RRI and the Pilot time. The calculation of <i>Current</i> is explained in Chapter 3 (see <i>display mode</i> ).				

		Q Signal Measurement		
<b>READ:ARRAY:CDPower:PCDep:QSignal[:VALue]:AVERage?</b>		Start single shot meas. and return results		
<b>FETCh:ARRAY:CDPower:PCDep:QSignal[:VALue]:AVERage?</b>		Read meas. results (unsynchronized)		
<b>SAMPlE:ARRAY:CDPower:PCDep:QSignal[:VALue]:AVERage?</b>		Read results (synchronized)		
Returned values	Description of parameters	Def. value	Def. unit	FW vers.
<b>W<sub>0</sub><sup>16</sup> RRI time,</b> <b>W<sub>0</sub><sup>16</sup> Pilot time,</b> ..., ..., <b>W<sub>15</sub><sup>16</sup> RRI time,</b> <b>W<sub>15</sub><sup>16</sup> Pilot time</b>	-60.0 dB to +10.0 dB, ..., ..., ..., -60.0 dB to +10.0 dB	NAN	dB	V3.40
Description of command				
These commands are always queries. They start a measurement and output the code domain error power of the Walsh Code of the quadrature signal path (Q-signal). 32 values are returned representing the alternating results of the RRI and the Pilot time. The calculation of <i>Average</i> is explained in Chapter 3 (see <i>display mode</i> ).				

		Q Signal Measurement		
<b>READ:ARRAY:CDPower:PCDep:QSignal[:VALue]:MAXimum?</b>		Start single shot meas. and return results		
<b>FETCh:ARRAY:CDPower:PCDep:QSignal[:VALue]:MAXimum?</b>		Read meas. results (unsynchronized)		
<b>SAMPlE:ARRAY:CDPower:PCDep:QSignal[:VALue]:MAXimum?</b>		Read results (synchronized)		
Returned values	Description of parameters	Def. value	Def. unit	FW vers.
<b>W<sub>0</sub><sup>16</sup> RRI time,</b> <b>W<sub>0</sub><sup>16</sup> Pilot time,</b> ..., ..., <b>W<sub>15</sub><sup>16</sup> RRI time,</b> <b>W<sub>15</sub><sup>16</sup> Pilot time</b>	-60.0 dB to +10.0 dB, ..., ..., ..., -60.0 dB to +10.0 dB	NAN	dB	V3.40
Description of command				
These commands are always queries. They start a measurement and output the code domain error power of the Walsh Code of the quadrature signal path (Q-signal). 32 values are returned representing the alternating results of the RRI and the Pilot time. The calculation of <i>Maximum</i> is explained in Chapter 3 (see <i>display mode</i> ).				

<b>CALCulate:ARRAY:CDPower:PCDep:ISignal:CURRent[:RESult]:MATChing:LIMit?</b>		I Signal Tolerance		
Returned value	Description	Def. value	Def. unit	FW vers.
<b>32 bit value</b>	Indicator for limit matching in code channel W <sub>0</sub> <sup>16</sup> RRI (least significant bit) to W <sub>15</sub> <sup>16</sup> Pilot	NAN	–	V3.40
Description of command				
This command is always a query. If a bit is set in the returned value the I signal limit in the corresponding code channel is exceeded.				
<b>Note:</b> Even bits are assigned to the RRI time slot and odd bits are assigned to the pilot time slot.				

<b>CALCulate:ARRAY:CDPower:PCDep:ISignal:AVERage[:RESult]:MATChing:LIMit?</b>		I Signal Tolerance		
Returned value	Description	Def. value	Def. unit	FW vers.
<b>32 bit value</b>	Indicator for limit matching in code channel W <sub>0</sub> <sup>16</sup> RRI (least significant bit) to W <sub>15</sub> <sup>16</sup> Pilot	NAN	–	V3.40
Description of command				
This command is always a query. If a bit is set in the returned value the I signal limit in the corresponding code channel is exceeded.				
<b>Note:</b> Even bits are assigned to the RRI time slot and odd bits are assigned to the pilot time slot.				

CALCulate:ARRay:CDPower:PCDep:ISIGNAL:MAXimum[:RESult]:MATChing:LIMit?		I Signal Tolerance		
Returned value	Description	Def. value	Def. unit	FW vers.
32 bit value	Indicator for limit matching in code channel $W_0^{16}$ RRI (least significant bit) to $W_{15}^{16}$ Pilot	NAN	–	V3.40
Description of command				
This command is always a query. If a bit is set in the returned value the I signal limit in the corresponding code channel is exceeded.				
<b>Note:</b> Even bits are assigned to the RRI time slot and odd bits are assigned to the pilot time slot.				

CALCulate:ARRay:CDPower:PCDep:QSIGnal:CURRent[:RESult]:MATChing:LIMit?		Q Signal Tolerance		
Returned value	Description	Def. value	Def. unit	FW vers.
32 bit value	Indicator for limit matching in code channel $W_0^{16}$ RRI (least significant bit) to $W_{15}^{16}$ Pilot	NAN	–	V3.40
Description of command				
This command is always a query. If a bit is set in the returned value the Q signal limit in the corresponding code channel is exceeded.				
<b>Note:</b> Even bits are assigned to the RRI time slot and odd bits are assigned to the pilot time slot.				

CALCulate:ARRay:CDPower:PCDep:QSIGnal:AVERAge[:RESult]:MATChing:LIMit?		Q Signal Tolerance		
Returned value	Description	Def. value	Def. unit	FW vers.
32 bit value	Indicator for limit matching in code channel $W_0^{16}$ RRI (least significant bit) to $W_{15}^{16}$ Pilot	NAN	–	V3.40
Description of command				
This command is always a query. If a bit is set in the returned value the Q signal limit in the corresponding code channel is exceeded.				
<b>Note:</b> Even bits are assigned to the RRI time slot and odd bits are assigned to the pilot time slot.				

CALCulate:ARRay:CDPower:PCDep:QSIGnal:MAXimum[:RESult]:MATChing:LIMit?		Q Signal Tolerance		
Returned value	Description	Def. value	Def. unit	FW vers.
32 bit value	Indicator for limit matching in code channel $W_0^{16}$ RRI (least significant bit) to $W_{15}^{16}$ Pilot	NAN	–	V3.40
Description of command				
This command is always a query. If a bit is set in the returned value the Q signal limit in the corresponding code channel is exceeded.				
<b>Note:</b> Even bits are assigned to the RRI time slot and odd bits are assigned to the pilot time slot.				

## CDPower:CHPW (Channel Power)

The subsystem *CDPower:CHPW* measures the Channel Power output. The subsystem corresponds to the measurement menu *Code Domain Power*, application *Channel Power*, and the sections related to this application in the associated popup menu *Code Domain Power Configuration*.

### Control of measurement

The subsystem *CDPower:CHPW* controls the channel power measurement. It corresponds to the softkey *ChP* in the measurement menu *Code Domain Power*.

<b>INITiate:CDPower:CHPW</b>	Start new measurement	⇒	<i>RUN</i>
<b>ABORT:CDPower:CHPW</b>	Abort running measurement and switch off	⇒	<i>OFF</i>
<b>STOP:CDPower:CHPW</b>	Stop measurement after current stat. cycle	⇒	<i>STOP</i>
<b>CONTinue:CDPower:CHPW</b>	Next measurement step ( <i>stepping mode</i> )	⇒	<i>RUN</i>
Description of command			FW vers.
These commands have no query form. They start and stop the channel power measurement, setting it to the status indicated in the top right column.			V3.40

<b>CONFigure:CDPower:CHPW:EREPorting[?]</b>		Event Reporting		
<b>&lt;Report Mode&gt;</b>				
<b>&lt;Report Mode&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>SRQ  </b>	Service request	OFF	–	V3.40
<b>SOPC  </b>	Single operation complete			
<b>SRSQ  </b>	SRQ and SOPC			
<b>OFF</b>	No reporting			
Description of command				
This command defines the events generated when the measurement is terminated or stopped (see <i>Event Reporting</i> in Chapter 5 of the CMU manual).				

<b>FETCh[:SCALar]:CDPower:CHPW:STATus?</b>		Measurement Status		
<b>Return</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>OFF  </b>	Measurement in the OFF state (*RST or ABORt)	OFF	–	V3.40
<b>RUN  </b>	Running (after INITiate, CONTinue or READ)			
<b>STOP  </b>	Stopped (STOP)			
<b>ERR  </b>	OFF (could not be started)			
<b>STEP  </b>	Stepping mode (<stepmode>=STEP)			
<b>RDY</b>	Stopped according to repetition mode and stop condition			
<b>1 to 10000  </b>	Counter for current statistics cycle	NONE	–	
<b>NONE</b>	No counting mode set			
<b>1 to 1000</b>	Counter for current evaluation period within a cycle	NONE	–	
<b>NONE</b>	Statistic count set to off			
Description of command				
This command is always a query. It returns the status of the measurement (see Chapters 3 and 5).				

## Test Configuration

The commands of the following subsystems configure the *Channel Power* measurement in the *Code Domain Power* menu. They correspond to the *Code Domain Power Configuration* popup menu.

## Subsystem CONTROL

The subsystem *CDPower:CHPW:CONTROL* defines the result mode, repetition mode, statistic count and stop condition of the measurement. These settings are provided in the *Control* tab in the popup menu *Code Domain Power Configuration*.

CONFIGure:CDPower:CHPW:CONTROL[?]		Scope of Measurement		
<Result Mode>, <Current Statistics>, <Repetition>, <Stop Cond>, <Step Mode>				
<Result Mode>	Description of parameters	Def. value	Def. unit	FW-Vers.
SCALar   ARRay,	Scalar values only (incl. ramp matching) Scalar measured values and arrays	ARR	–	V3.40
<Current Statistics>	Description of parameters	Def. value	Def. unit	FW-Vers.
1 to 1000,	Number of bursts per statistics cycle	100	–	V3.40
<Repetition>	Description of parameters	Def. value	Def. unit	FW-Vers.
1 to 10000   CONTInuous   SINGleshot   DEFault,	Multiple measurement (counting, until Status = STEP   RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–	V3.40
<Stop Cond>	Description of parameters	Def. value	Def. unit	FW-Vers.
NONE   SONerror   DEFault,	Continue measurement even in case of error Stop measurement in case of error ( <i>stop on error</i> ) Sets the value to the default setting	NONE	–	V3.40
<Step Mode>	Description of parameters	Def. value	Def. unit	FW-Vers.
STEP   NONE   DEFault	Interrupt measurement after each statistics cycle Continue measurement according to its rep. Mode Sets the value to the default setting	NONE	–	V3.40
Description of command				
This command combines the ...CONTROL:RMODe, ...CONTROL:STATistics and the ...CONTROL:REPetition commands, see below.				

CONFIGure:CDPower:CHPW:CONTROL:RMODe[?]		Result Mode		
<Result Mode>				
<Result Mode>	Description of parameters	Def. value	Def. unit	FW-Vers.
SCALar   ARRay	Scalar values only (incl. ramp matching) Scalar measured values and arrays	ARR	–	V3.40
Description of command				
This command specifies the type of measured values.				

CONFigure:CDPower:CHPW:CONTRol:STATistics[?] <Current Statistics >		Statistic Count		
<Current Statistics>	Description of parameters	Def. value	Def. unit	FW-Vers.
<b>1 to 1000</b>	Number of bursts per statistics cycle	100	–	V3.40
Description of command				
This command defines the number of bursts forming a statistics cycle.				

CONFigure:CDPower:CHPW:CONTRol:REPetition[?] <Repetition>, <Stop Cond>, <Step Mode>		Test Cycles		
<Repetition>	Description of parameters	Def. value	Def. unit	FW vers.
<b>1 to 10000  </b> <b>CONTInuous  </b> <b>SINGleshot  </b> <b>DEFault,</b>	Multiple measurement (counting, until Status = STEP   RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–	V3.40
<Stop Cond>	Description of parameters	Def. value	Def. unit	FW vers.
<b>NONE  </b> <b>SONerror  </b> <b>DEFault,</b>	Continue measurement even in case of error Stop measurement in case of error ( <i>stop on error</i> ) Sets the value to the default setting	NONE	–	V3.40
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
<b>STEP  </b> <b>NONE  </b> <b>DEFault</b>	Interrupt measurement after each statistics cycle Continue measurement according to its rep. Mode Sets the value to the default setting	NONE	–	V3.40
Description of command				
This command determines the repetition mode, stop condition, and stepping mode for the measurement.				
<b>Note:</b> In the case of READ commands (READ: ...), the <Repetition> parameter has no effect; the measurement is always stopped after a single shot.				

DEFault:CDPower:CHPW:CONTRol[?]		Default Settings		
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
<b>ON  </b> <b>OFF</b>	The parameters are set to their default values Some or all parameters are not set to default	ON	–	V3.40
Description of command				
If used as a setting command with the parameter ON, this command sets all parameters of the subsystem CDPower:CHPW:CONTRol to their default values (the setting OFF results in an error message).				
If used as a query the command returns whether all parameters are set to their default values (ON) or not (OFF).				

## Subsystem LIMit

### CDPower:CPCCommon:LIMit

The subsystem *CDPower:CPCCommon:LIMit* defines common tolerance values for the scalar results of the *CPCCommon* Code Domain Power applications. These commands are described in on page 6.77.

### CDPower:CHPW:LIMit

The subsystem *CDPower:CHPW:LIMIT* defines the tolerance values that apply to the Channel Power application only.

CONFigure:CDPower:CHPW:CMAX:LIMit:ASYMmetric[:COMBined][?]				Limits
<CHPW Limit Y>				
<CHPW Limit Y>	Description of parameters	Def. value	Def. unit	FW vers.
-60.0 to 0   DEFAult   OFF   ON	Channel power Y limit Sets the value to the default setting Disables the tolerance check Tolerance check enabled, last value re-activated	-23.0	dB	V3.40
Description of command				
This command defines the upper limit for the channel power (Y value). The keywords CMAX and AVERAge refer to the <i>Current</i> and <i>Max.</i> display and for the <i>Average</i> display, respectively.				

CONFigure:CDPower:CHPW:AVERAge:LIMit:ASYMmetric[:COMBined][?]				Limits
<CHPW Limit Y Average>				
<CHPW Limit Y Average>	Description of parameters	Def. value	Def. unit	FW vers.
-60.0 to 0   DEFAult   OFF   ON	Channel power Y limit Sets the value to the default setting Disables the tolerance check Tolerance check enabled, last value re-activated	-23.0	dB	V3.40
Description of command				
This command defines the upper limit for the channel power (Y value). The keywords CMAX and AVERAge refer to the <i>Current</i> and <i>Max.</i> display and for the <i>Average</i> display, respectively.				

DEFAult:CDPower:CHPW:LIMit[?]				Default Settings
<Enable>				
Enable	Description of parameters	Def. value	Def. unit	FW vers.
ON   OFF	The parameters are set to their default values Some or all parameters are not set to default	ON	-	V3.40
Description of command				
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystem <i>CDPower:CHPW:LIMit</i> to their default values (the setting <i>OFF</i> results in an error message).				
If used as a query, the command returns whether all parameters are set to their default values ( <i>ON</i> ) or not ( <i>OFF</i> ).				

Measured Values

The subsystem CDPower:CHPW determines and outputs the results of the Channel Power measurement.

READ[:SCALar]:CDPower:CHPW?		Scalar results:		
FETCh[:SCALar]:CDPower:CHPW?		Start single shot measurement and return results		
SAMPle[:SCALar]:CDPower:CHPW?		Read out measurement results (unsynchronized)		
		Read out measurement results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
AT Power (x3),	-100.0 dBm to -50.0 dBm	NAN	dBm	V3.40
Carrier Feedthrough (x3),	-120.0 dB to -20.0 dB	NAN	dB	
Carrier Freq. Error (x3),	0 to 1000.0 Hz	NAN	Hz	
Rho (x3),	0.0 to 1.0	NAN	-	
Out of Tolerance,	0.0% to 100.0%	NAN	%	
Current Statistics	1 to 1000	NAN	-	
Description of command				
These commands are always queries. They start a measurement and output all scalar measurement results. The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i> , the <i>Average</i> , and the <i>MMax</i> value.				

CALCulate[:SCALar]:CDPower:CHPW:MATChing:LIMit?		Limit Matching		
Returned values	Value range	Def. value	Def. unit	FW vers.
Carrier Feedthrough (x3),	For all values	INV	-	V3.40
Carrier Freq. Error (x3),		INV	-	
Rho (x3)	NMAU   NMAL   INV   OK	INV	-	
Description of command				
This command is always a query. It indicates whether and in which way the (fixed) limit lines have been exceeded. The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i> , the <i>Average</i> , and the <i>MMax</i> value. The following messages may be generated:				
NMAU	Tolerance value underflow	<i>not matching, underflow</i>		
NMAL	Tolerance value exceeded	<i>not matching, overflow</i>		
INV	Measurement invalid	<i>invalid</i>		
OK	Tolerance value matched			

READ:ARRay:CDPower:CHPW:ISIGnal[:VALue]:CURRent?		I Signal Measurement		
FETCh:ARRay:CDPower:CHPW:ISIGnal[:VALue]:CURRent?		Start single shot meas. and return results		
SAMPle:ARRay:CDPower:CHPW:ISIGnal[:VALue]:CURRent?		Read meas. results (unsynchronized)		
		Read results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
W <sub>0</sub> <sup>16</sup> RRI,	-60.0 dB to +10.0 dB,	NAN	dB	V3.40
W <sub>0</sub> <sup>16</sup> Pilot,	-60.0 dB to +10.0 dB,			
W <sub>4</sub> <sup>8</sup> ACK	-60.0 dB to +10.0 dB			
Description of command				
These commands are always queries. They start a measurement and output the levels of the RRI, Pilot and the ACK channel of the in-phase signal path (I-signal). The calculation of <i>Current</i> is explained in Chapter 3 (see <i>display mode</i> ).				

Returned values		Value range	Def. value	Def. unit	FW vers.
<b>W<sub>0</sub><sup>16</sup></b>	<b>RRI,</b>	-60.0 dB to +10.0 dB,	NAN	dB	V3.40
<b>W<sub>0</sub><sup>16</sup></b>	<b>Pilot,</b>	-60.0 dB to +10.0 dB,			
<b>W<sub>4</sub><sup>8</sup></b>	<b>ACK</b>	-60.0 dB to +10.0 dB			

**READ:ARRay:CDPower:CHPW:ISIGnal[:VALue]:AVERage?**  
**FETCh:ARRay:CDPower:CHPW:ISIGnal[:VALue]:AVERage?**  
**SAMPlE:ARRay:CDPower:CHPW:ISIGnal[:VALue]:AVERage?**

I Signal Measurement  
 Start single shot meas. and return results  
 Read meas. results (unsynchronized)  
 Read results (synchronized)

Description of command

These commands are always queries. They start a measurement and output the levels of the RRI, Pilot and the ACK channel of the in-phase signal path (I-signal). The calculation of *Average* is explained in Chapter 3 (see *display mode*).

Returned values		Value range	Def. value	Def. unit	FW vers.
<b>W<sub>0</sub><sup>16</sup></b>	<b>RRI,</b>	-60.0 dB to +10.0 dB,	NAN	dB	V3.40
<b>W<sub>0</sub><sup>16</sup></b>	<b>Pilot,</b>	-60.0 dB to +10.0 dB,			
<b>W<sub>4</sub><sup>8</sup></b>	<b>ACK</b>	-60.0 dB to +10.0 dB			

**READ:ARRay:CDPower:CHPW:ISIGnal[:VALue]:MAXimum?**  
**FETCh:ARRay:CDPower:CHPW:ISIGnal[:VALue]:MAXimum?**  
**SAMPlE:ARRay:CDPower:CHPW:ISIGnal[:VALue]:MAXimum?**

I Signal Measurement  
 Start single shot meas. and return results  
 Read meas. results (unsynchronized)  
 Read results (synchronized)

Description of command

These commands are always queries. They start a measurement and output the levels of the RRI, Pilot and the ACK channel of the in-phase signal path (I-signal). The calculation of *Maximum* is explained in Chapter 3 (see *display mode*).

Returned values		Value range	Def. value	Def. unit	FW vers.
<b>W<sub>8</sub><sup>16</sup></b>	<b>DRC,</b>	-60.0 dB to +10.0 dB,	NAN	dB	V3.40
<b>W<sub>2</sub><sup>4</sup></b>	<b>Data</b>	-60.0 dB to +10.0 dB			

**READ:ARRay:CDPower:CHPW:QSIGnal[:VALue]:CURRent?**  
**FETCh:ARRay:CDPower:CHPW:QSIGnal[:VALue]:CURRent?**  
**SAMPlE:ARRay:CDPower:CHPW:QSIGnal[:VALue]:CURRent?**

Q Signal Measurement  
 Start single shot meas. and return results  
 Read meas. results (unsynchronized)  
 Read results (synchronized)

Description of command

These commands are always queries. They start a measurement and output the levels of the DRC and the DATA channel of the quadrature signal path (Q-signal). The calculation of *Current* is explained in Chapter 3 (see *display mode*).

Returned values		Value range	Def. value	Def. unit	FW vers.
<b>W<sub>8</sub><sup>16</sup></b>	<b>DRC,</b>	-60.0 dB to +10.0 dB,	NAN	dB	V3.40
<b>W<sub>2</sub><sup>4</sup></b>	<b>Data</b>	-60.0 dB to +10.0 dB			

**READ:ARRay:CDPower:CHPW:QSIGnal[:VALue]:AVERage?**  
**FETCh:ARRay:CDPower:CHPW:QSIGnal[:VALue]:AVERage?**  
**SAMPlE:ARRay:CDPower:CHPW:QSIGnal[:VALue]:AVERage?**

Q Signal Measurement  
 Start single shot meas. and return results  
 Read meas. results (unsynchronized)  
 Read results (synchronized)

Description of command

These commands are always queries. They start a measurement and output the levels of the DRC and the DATA channel of the quadrature signal path (Q-signal). The calculation of *Average* is explained in Chapter 3 (see *display mode*).



CALCulate:ARRay:CDPower:CHPW:QSignal:CURRENT[:RESult]:MATCHing:LIMit?		Q Signal Tolerance		
Returned value	Description	Def. value	Def. unit	FW vers.
<b>32 bit value</b>	Indicator for limit matching in: $W_8^{16}$ DRC bit 0 $W_2^4$ Data bit 1 (bit 0 is the least significant)	NAN	–	V3.40
Description of command				
This command is always a query. If a bit is set in the returned value the Q signal limit in the corresponding code channel is exceeded.				

CALCulate:ARRay:CDPower:CHPW:QSignal:AVERAGE[:RESult]:MATCHing:LIMit?		Q Signal Tolerance		
Returned value	Description	Def. value	Def. unit	FW vers.
<b>32 bit value</b>	Indicator for limit matching in: $W_8^{16}$ DRC bit 0 $W_2^4$ Data bit 1 (bit 0 is the least significant)	NAN	–	V3.40
Description of command				
This command is always a query. If a bit is set in the returned value the Q signal limit in the corresponding code channel is exceeded.				

CALCulate:ARRay:CDPower:CHPW:QSignal:MAXimum[:RESult]:MATCHing:LIMit?		Q Signal Tolerance		
Returned value	Description	Def. value	Def. unit	FW vers.
<b>32 bit value</b>	Indicator for limit matching in: $W_8^{16}$ DRC bit 0 $W_2^4$ Data bit 1 (bit 0 is the least significant)	NAN	–	V3.40
Description of command				
This command is always a query. If a bit is set in the returned value the Q signal limit in the corresponding code channel is exceeded.				

## SPECTrum:ACP (ACP Spectrum)

The subsystem *SPECTrum:ACP* measures the power of four adjacent channel pairs. These four pairs correspond to symmetrical frequency offsets to the RF frequency (command [SENSE: ]RFANalyzer:FREQUENCY[?]). The subsystem corresponds to the measurement menu *Spectrum* and the associated popup menu *Spectrum Configuration*.

### Control of Measurement

The subsystem *SPECTrum:ACP* controls the adjacent channel power spectrum measurement. It corresponds to the softkey *ACP* in the measurement menu *Spectrum*.

<b>INITiate:SPECTrum:ACP</b>	Start new measurement	⇒ RUN
<b>ABORt:SPECTrum:ACP</b>	Abort running measurement and switch off	⇒ OFF
<b>STOP:SPECTrum:ACP</b>	Stop measurement after current stat. cycle	⇒ STOP
<b>CONTINUE:SPECTrum:ACP</b>	Next measurement step ( <i>stepping mode</i> )	⇒ RUN
Description of command		FW vers.
These commands have no query form. They start and stop the ACP spectrum measurement, setting it to the status indicated in the top right column.		V3.40

<b>CONFigure:SPECTrum:ACP:EREPorting[?]</b>		Event Reporting		
<b>&lt;Report Mode&gt;</b>				
<b>&lt;Report Mode&gt;</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>SRQ  </b>	Service request	OFF	–	V3.40
<b>SOPC  </b>	Single operation complete			
<b>SRSQ  </b>	SRQ and SOPC			
<b>DEFAult  </b>	Sets the value to the default setting			
<b>OFF</b>	No reporting			
Description of command				
This command defines the events generated when the measurement is terminated or stopped (see <i>Event Reporting</i> in Chapter 5 of the CMU manual).				

<b>FETCh[:SCALAr]:SPECTrum:ACP:STATus?</b>		Measurement Status		
<b>Return</b>	Description of parameters	Def. value	Def. unit	FW vers.
<b>OFF  </b>	Measurement in the OFF state (*RST or ABORt)	OFF	–	V3.40
<b>RUN  </b>	Running (after INITiate, CONTINUE or READ)			
<b>STOP  </b>	Stopped (STOP)			
<b>ERR  </b>	OFF (could not be started)			
<b>STEP  </b>	Stepping mode (<stepmode>=STEP)			
<b>RDY</b>	Stopped according to repetition mode and stop condition			
<b>1 to 10000  </b>	Counter for current statistics cycle	NONE	–	
<b>NONE</b>	No counting mode set			
<b>1 to 1000</b>	Counter for current evaluation period within a cycle	NONE	–	
<b>NONE</b>	Statistic count set to off			
Description of command				
This command is always a query. It returns the status of the measurement (see Chapters 3 and 5).				

## Test Configuration

The commands of the following subsystems configure the *ACP Spectrum* measurement in the *Spectrum* menu. They correspond to the *Spectrum Configuration popup* menu.

## Subsystem CONTROL

The subsystem *SPECTrum:ACP:CONTROL* configures the ACP Spectrum measurement. It defines the repetition mode, statistic count, stop condition and the offset frequencies of the measurement. It corresponds to the tab *Control* in the popup menu *Spectrum Configuration*.

CONFigure:SPECTrum:ACP:CONTROL[?] <Current Statistics>, <Repetition>, <Stop Cond>, <Step Mode>		Scope of Measurement		
<Current Statistics>	Description of parameters	Def. value	Def. unit	FW vers.
<b>1 to 1000,</b>	Number of bursts per statistics cycle	100	–	V3.40
<Repetition>	Description of parameters	Def. value	Def. unit	FW vers.
<b>1 to 10000  </b> <b>CONTInuous  </b> <b>SINGleshot  </b> <b>DEFault,</b>	Multiple measurement ( <i>counting</i> , until <i>Status = STEP   RDY</i> ) Continuous measurement (until <i>STOP</i> or <i>ABORT</i> ) Single shot measurement (until <i>Status = RDY</i> ) Sets the value to the default setting	SING	–	V3.40
<Stop Cond>	Description of parameters	Def. value	Def. unit	FW vers.
<b>NONE  </b> <b>SONerror  </b> <b>DEFault,</b>	Continue measurement even in case of error Stop measurement in case of error ( <i>stop on error</i> ) Sets the value to the default setting	NONE	–	V3.40
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
<b>STEP  </b> <b>NONE  </b> <b>DEFault</b>	Interrupt measurement after each statistics cycle Continue measurement according to its rep. Mode Sets the value to the default setting	NONE	–	V3.40
Description of command				
This command combines the ...CONTROL:RMODE, ...CONTROL:STATISTICS and the ...CONTROL:REPETITION commands, see below.				

CONFigure:SPECTrum:ACP:CONTROL:STATISTICS[?] <Current Statistics >		Statistic Count		
<Statistics Count>	Description of parameters	Def. value	Def. unit	FW-Vers.
<b>1 to 1000</b>	Number of bursts per statistics cycle	100	–	V3.40
Description of command				
This command defines the number of bursts forming a statistics cycle.				

CONFigure:SPECTrum:ACP:CONTRol:REPetition[?] <Repetition>, <Stop Cond>, <Step Mode>		Test Cycles		
<Repetition>	Description of parameters	Def. value	Def. unit	FW vers.
<b>1 to 10000  </b>	Multiple measurement ( <i>counting</i> , until Status = STEP   RDY)	SING	–	V3.40
<b>CONTinuous  </b>	Continuous measurement (until STOP or ABORT)			
<b>SINGleshot  </b>	Single shot measurement (until Status = RDY)			
<b>DEFault,</b>	Sets the value to the default setting			
<Stop Cond>	Description of parameters	Def. value	Def. unit	FW vers.
<b>NONE  </b>	Continue measurement even in case of error	NONE	–	V3.40
<b>SONerror  </b>	Stop measurement in case of error ( <i>stop on error</i> )			
<b>DEFault,</b>	Sets the value to the default setting			
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
<b>STEP  </b>	Interrupt measurement after each statistics cycle	NONE	–	V3.40
<b>NONE  </b>	Continue measurement according to its rep. Mode			
<b>DEFault</b>	Sets the value to the default setting			
Description of command				
This command determines the repetition mode, stop condition, and stepping mode for the measurement.				
<b>Note:</b> In the case of READ commands (READ: ...), the <Repetition> parameter has no effect; the measurement is always stopped after a single shot.				

DEFault:SPECTrum:ACP:CONTRol[?]		Default Settings		
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
<b>ON  </b>	The parameters are set to their default values	ON	–	V3.40
<b>OFF</b>	Some or all parameters are not set to default			
Description of command				
If used as a setting command with the parameter ON, this command sets all parameters of the subsystem SPECTrum:ACP:CONTRol to their default values (the setting OFF results in an error message).				
If used as a query the command returns whether all parameters are set to their default values (ON) or not (OFF).				

CONFigure:SPECTrum:ACP:CONTRol:FOFFset:ACP<nr>[?] <Freq. Offset>		ACP Frequency Offset		
<Freq. Offset>	Description of parameters	Def. value	Def. unit	FW vers.
	The ACP frequency offset depends on the network standard:		Hz	V3.40
<b>0 to 2 MHz   OFF   ON</b>	<b>Band Class 0, US Cellular</b> Measurement disabled, result INV Enable measurement, last setting re-activated	<nr> = 1: 870.00 kHz <nr> = 2: 885.00 kHz <nr> = 3: 900.00 kHz <nr> = 4: 1980.00 kHz		
<b>0 to 2 MHz   OFF   ON</b>	<b>Band Class 0, Korean Cellular</b> Measurement disabled, result INV Enable measurement, last setting re-activated	<nr> = 1: 870.00 kHz <nr> = 2: 885.00 kHz <nr> = 3: 900.00 kHz <nr> = 4: 1980.00 kHz		
<b>0 to 2 MHz   OFF   ON</b>	<b>Band Class 1, North American PCS</b> Measurement disabled, result INV Enable measurement, last setting re-activated	<nr> = 1: 1150.00 kHz <nr> = 2: 1200.00 kHz <nr> = 3: 1250.00 kHz <nr> = 4: 1980.00 kHz		
<b>0 to 2 MHz   OFF   ON</b>	<b>Band Class 2, TACS</b> Measurement disabled, result INV Enable measurement, last setting re-activated	<nr> = 1: 870.00 kHz <nr> = 2: 885.00 kHz <nr> = 3: 900.00 kHz <nr> = 4: 1980.00 kHz		
<b>0 to 2 MHz   OFF   ON</b>	<b>Band Class 3, JTACS</b> Measurement disabled, result INV Enable measurement, last setting re-activated	<nr> = 1: 870.00 kHz <nr> = 2: 885.00 kHz <nr> = 3: 900.00 kHz <nr> = 4: 1980.00 kHz		
<b>0 to 2 MHz   OFF   ON</b>	<b>Band Class 4, Korean PCS</b> Measurement disabled, result INV Enable measurement, last setting re-activated	<nr> = 1: 1150.00 kHz <nr> = 2: 1200.00 kHz <nr> = 3: 1250.00 kHz <nr> = 4: 1980.00 kHz		
<b>0 to 2 MHz   OFF   ON</b>	<b>Band Class 5, NMT 450</b> Measurement disabled, result INV Enable measurement, last setting re-activated	<nr> = 1: 870.00 kHz <nr> = 2: 885.00 kHz <nr> = 3: 900.00 kHz <nr> = 4: 1980.00 kHz		
<b>0 to 2 MHz   OFF   ON</b>	<b>Band Class 6, IMT-2000</b> Measurement disabled, result INV Enable measurement, last setting re-activated	<nr> = 1: 1150.00 kHz <nr> = 2: 1200.00 kHz <nr> = 3: 1250.00 kHz <nr> = 4: 1980.00 kHz		
<b>0 to 2 MHz   OFF   ON</b>	<b>Band Class 7, North American 700 MHz</b> Measurement disabled, result INV Enable measurement, last setting re-activated	<nr> = 1: 870.00 kHz <nr> = 2: 885.00 kHz <nr> = 3: 900.00 kHz <nr> = 4: 1980.00 kHz		
<b>0 to 2 MHz   OFF   ON</b>	<b>Band Class 8, 1800 MHz</b> Measurement disabled, result INV Enable measurement, last setting re-activated	<nr> = 1: 1150.00 kHz <nr> = 2: 1200.00 kHz <nr> = 3: 1250.00 kHz <nr> = 4: 1980.00 kHz		
<b>0 to 2 MHz   OFF   ON</b>	<b>Band Class 9, North American 900 MHz</b> Measurement disabled, result INV Enable measurement, last setting re-activated	<nr> = 1: 870.00 kHz <nr> = 2: 885.00 kHz <nr> = 3: 900.00 kHz <nr> = 4: 1980.00 kHz		
<b>0 to 2 MHz   OFF   ON</b>	<b>Band Class 10, Secondary 800 MHz</b> Measurement disabled, result INV Enable measurement, last setting re-activated	<nr> = 1: 870.00 kHz <nr> = 2: 885.00 kHz <nr> = 3: 900.00 kHz <nr> = 4: 1980.00 kHz		
Description of command				
This command determines four frequency offset values (<nr> = 1 to 4) which define the four adjacent channel pairs. <i>OFF</i> will disable the measurement on the specified frequency pair and <i>INV</i> will be returned as result. See also the command CONFigure:NETWork:STANdard				

## Subsystem LIMit

## SPECTrum:ACP:LIMit

The subsystem *SPECTrum:ACP:LIMit* defines tolerance values for the ACP Spetrum measurement.

CONFigure:SPECTrum:ACP:LIMit:ACP<nr>[?] <ACP Limit>				Limits
<ACP Limit>	Description of parameters	Def. value	Def. unit	FW vers.
-80.0 to +10.0   OFF	Power limit for ACP<nr> Disables the tolerance check for ACP<nr>	<nr> = 1: -43 dB <nr> = 2: -43 dB <nr> = 3: -43 dB <nr> = 4: -54 dB	dB	V3.40
Description of command				
This command defines the upper power limits for the adjacent channel pairs <nr> = 1 to 4. These limits apply to any of the statistic evaluation modes ( <i>Current, Average and Maximum</i> ).				

DEFault:SPECTrum:ACP:LIMit[?] <Enable>				Default Settings
Enable	Description of parameters	Def. value	Def. unit	FW vers.
ON   OFF	The parameters are set to their default values Some or all parameters are not set to default	ON	–	V3.40
Description of command				
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystem <i>SPECTrum:ACP:LIMit</i> to their default values (the setting <i>OFF</i> results in an error message).				
If used as a query, the command returns whether all parameters are set to their default values ( <i>ON</i> ) or not ( <i>OFF</i> ).				

### Measured Values

The subsystem *SPECTrum:ACP* determines and outputs the results of the ACP Spectrum measurement.

Returned values		Value range	Def. value	Def. unit	FW vers.
<b>READ[:SCALar]:SPECTrum:ACP?</b>					
<b>FETCh[:SCALar]:SPECTrum:ACP?</b>					
<b>SAMPlE[:SCALar]:SPECTrum:ACP?</b>					
					Scalar results:
					Start single shot measurement and return results
					Read out measurement results (unsynchronized)
					Read out measurement results (synchronized)
Power of adj. Channel -4	(Current),	-80.0 dB to 0.0 dB	NAN	dB	V3.40
Power of adj. Channel -3	(Current),		NAN		
Power of adj. Channel -2	(Current),		NAN		
Power of adj. Channel -1	(Current),		NAN		
Power of adj. Channel +1	(Current),		NAN		
Power of adj. Channel +2	(Current),		NAN		
Power of adj. Channel +3	(Current),		NAN		
Power of adj. Channel +4	(Current),		NAN		
Power of adj. Channel -4	(Average),	-80.0 dB to 0.0 dB	NAN	dB	
Power of adj. Channel -3	(Average),		NAN		
Power of adj. Channel -2	(Average),		NAN		
Power of adj. Channel -1	(Average),		NAN		
Power of adj. Channel +1	(Average),		NAN		
Power of adj. Channel +2	(Average),		NAN		
Power of adj. Channel +3	(Average),		NAN		
Power of adj. Channel +4	(Average),		NAN		
Power of adj. Channel -4	(Maximum),	-80.0 dB to 0.0 dB	NAN	dB	
Power of adj. Channel -3	(Maximum),		NAN		
Power of adj. Channel -2	(Maximum),		NAN		
Power of adj. Channel -1	(Maximum),		NAN		
Power of adj. Channel +1	(Maximum),		NAN		
Power of adj. Channel +2	(Maximum),		NAN		
Power of adj. Channel +3	(Maximum),		NAN		
Power of adj. Channel +4	(Maximum),		NAN		
Channel Power	(Current),	-80.0 dBm to 0.0 dBm	NAN	dBm	
Channel Power	(Average),		NAN		
Channel Power	(Maximum),		NAN		
Out of Tolerance,		0 to 100 %	NAN	-	
Current Statistics		1 to 10000	NAN	-	
Description of command					
These commands are always queries. They start a measurement and output all scalar measurement results.					

CALCulate[:SCALar]:SPECTrum:ACP:MATCHing:LIMit?		Limit Matching			
Returned values		Value range	Def. value	Def. unit	FW vers.
Tolerance Channel -4	(Current),	NMAU   NMAL   INV   OK	INV	-	V3.40
Tolerance Channel -3	(Current),				
Tolerance Channel -2	(Current),				
Tolerance Channel -1	(Current),				
Tolerance Channel +1	(Current),				
Tolerance Channel +2	(Current),				
Tolerance Channel +3	(Current),				
Tolerance Channel +4	(Current),				
Tolerance Channel -4	(Average),	NMAU   NMAL   INV   OK	INV	-	
Tolerance Channel -3	(Average),				
Tolerance Channel -2	(Average),				
Tolerance Channel -1	(Average),				
Tolerance Channel +1	(Average),				
Tolerance Channel +2	(Average),				
Tolerance Channel +3	(Average),				
Tolerance Channel +4	(Average),				
Tolerance Channel -4	(Maximum),	NMAU   NMAL   INV   OK	INV	-	
Tolerance Channel -3	(Maximum),				
Tolerance Channel -2	(Maximum),				
Tolerance Channel -1	(Maximum),				
Tolerance Channel +1	(Maximum),				
Tolerance Channel +2	(Maximum),				
Tolerance Channel +3	(Maximum),				
Tolerance Channel +4	(Maximum),				
Description of command					
<p>This command is always a query. It indicates whether and in which way the (fixed) limit have been exceeded. The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i>, the <i>Average</i>, and the <i>Maximum</i> value. The following messages may be generated:</p>					
NMAU	Tolerance value underflow	<i>not matching, underflow</i>			
NMAL	Tolerance value exceeded	<i>not matching, overflow</i>			
INV	Measurement invalid	<i>invalid</i>			
OK	Tolerance value matched				

# List of Commands

In the following, all remote-control commands of the 1xEV-DO function group are listed. They are arranged in order of appearance of the subsystems.

Table 6-1 Remote-control commands

## Common Command Groups

CONFigure: IQIF:RXTXcombined[?]	6.4
CONFigure:IQIF:RXPath[?]	6.4
CONFigure:IQIF:TXPath[?]	6.5
IQIF:DEFAult[?]	6.5
MMEMory:RECall:CURRent<FileName> [,<msus>]	6.3
MMEMory:SAVE:CURRent<FileName> [,<msus>]	6.3
STATus:OPERation:SYMBOLic:ENABLE[?] <Event>{,<Event>}	6.6
STATus:OPERation:SYMBOLic:EVENT[?] <Event>{,<Event>}	6.6
SYSTem: RESet:CURRent	6.2
SYSTem:OPTions:INFO:CURRent?	6.2
SYSTem:VERsion:SW:MMI?	6.2

## Band Class – Network Standard

CONFigure:NETWork:STANdard[?]	6.7
-------------------------------	-----

## Analyzer

[SENSe:]LEVel:MAXimum[?]	6.10
[SENSe:]LEVel:MODE[?]	6.10
[SENSe:]RFANalyzer:AT<nr>:RLINK:FROFFset[?]	6.11
[SENSe:]RFANalyzer:CCFilter:ACK[?]	6.11
[SENSe:]RFANalyzer:CCFilter:DATA[?]	6.11
[SENSe:]RFANalyzer:CCFilter:DRC[?]	6.11
[SENSe:]RFANalyzer:FOFFset[?]	6.9
[SENSe:]RFANalyzer:FREQuency:UNIT[?]	6.8
[SENSe:]RFANalyzer:FREQuency[?]	6.9
[SENSe:]RFANalyzer:LcMask:l:LSB[?]	6.10
[SENSe:]RFANalyzer:LcMask:l:MSB[?]	6.10
[SENSe:]RFANalyzer:LcMask:Q:LSB[?]	6.10
[SENSe:]RFANalyzer:LcMask:Q:MSB[?]	6.10
DEFAult:RFANalyzer[?]	6.8

## Trigger

DEFAult:TRIGger[:SEQuence][?]	6.12
TRIGger:OUTPut:PIN<nr>:SIGNal[?]	6.13
TRIGger:SElect:AT[?]	6.12
TRIGger[:SEQuence]:SLOPe[?]	6.12
TRIGger[:SEQuence]:SOURce[?]	6.14
TRIGger[:SEQuence]:THReshold:IFPower[?]	6.13
TRIGger[:SEQuence]:THReshold:RFPower[?]	6.13

## Generator

ABORt:RFGenerator	6.15
ABORt:RFGenerator:AT<nr>:MAC:INDex	6.21
ABORt:RFGenerator:AT<nr>:PSTReam	6.22
ABORt:RFGenerator:SNcMessage	6.19

DEFault:RFGenerator[?]	6.15
FETCh:RFGenerator:AT<nr>:MAC:INDEX:STATUS?	6.21
FETCh:RFGenerator:AT<nr>:PSTReam:STATUS?	6.22
FETCh:RFGenerator:SNCMessAge:STATUS?	6.19
FETCh:RFGenerator:STATUS?	6.15
INITiate:RFGenerator	6.15
INITiate:RFGenerator:SNCMessAge	6.18
INITiate:RFGenerator:AT<nr>:MAC:INDEX	6.21
INITiate:RFGenerator:AT<nr>:PSTReam	6.22
PROCedure:RFGenerator:AT<nr>:PCBits:PATTeRn[?]	6.25
SOURce:IMPairments:FOFFset[:RF][?]	6.18
SOURce:IMPairments:LEVel:AWGN[?]	6.18
SOURce:RFGenerator:AT<nr>:DRATe?	6.23
SOURce:RFGenerator:AT<nr>:DRCLock:LENGth[?]	6.24
SOURce:RFGenerator:AT<nr>:DRCLock:PERiod[?]	6.24
SOURce:RFGenerator:AT<nr>:DRCLock:STATe[?]	6.24
SOURce:RFGenerator:AT<nr>:DRINDEX[?]	6.23
SOURce:RFGenerator:AT<nr>:MAC:INDEX[?]	6.21
SOURce:RFGenerator:AT<nr>:MAC:LEVel[?]	6.22
SOURce:RFGenerator:AT<nr>:PATTeRn[?]	6.24
SOURce:RFGenerator:AT<nr>:PCBits:RTES:NOBits[?]	6.25
SOURce:RFGenerator:AT<nr>:PCBits[?]	6.25
SOURce:RFGenerator:AT<nr>:PCOunt[?]	6.23
SOURce:RFGenerator:AT<nr>:PSOFFset[?]	6.23
SOURce:RFGenerator:AT<nr>:SCOunt?	6.24
SOURce:RFGenerator:AT<nr1>:PCBits:PATTeRn:AREA<nr2>:NOBits[?]	6.26
SOURce:RFGenerator:AT<nr1>:PCBits:PATTeRn:AREA<nr2>:POLarity[?]	6.26
SOURce:RFGenerator:FREQuency[:RF]:UNIT[?]	6.16
SOURce:RFGenerator:FREQuency[:RF][?]	6.16
SOURce:RFGenerator:MODE[?]	6.17
SOURce:RFGenerator:OAT:COUNT[?]	6.27
SOURce:RFGenerator:POWEr:OUTPut[?]	6.17
SOURce:RFGenerator:PROPerty:PNOFFset[?]	6.17
SOURce:RFGenerator:RAB:LENGth[?]	6.27
SOURce:RFGenerator:RAB:MAC:LEVel[?]	6.26
SOURce:RFGenerator:RAB:OFFSet[?]	6.27
SOURce:RFGenerator:RAB:STATe[?]	6.26
SOURce:RFGenerator:SNCMessAge:DRATe?	6.20
SOURce:RFGenerator:SNCMessAge:DRINDEX[?]	6.20
SOURce:RFGenerator:SNCMessAge:PSOFFset[?]	6.19
SOURce:RFGenerator:SNCMessAge:SCOunt?	6.20

**RF Input and Output**

[SENSe:]CORRection:LOSS:INPut<nr>[:MAGNitude][?]	6.28
[SENSe:]CORRection:LOSS:OUTPut<nr>[:MAGNitude][?]	6.29
INPut[:STATe][?]	6.28
OUTPut[:STATe][?]	6.28
SOURce:CORRection:LOSS:INPut<nr>[:MAGNitude][?]	6.28
SOURce:CORRection:LOSS:OUTPut<nr>[:MAGNitude][?]	6.29
SOURce:DM:CLOCK:FREQuency[?]	6.29
SOURce:DM:CLOCK:STATe[?]	6.29

**WPOWER Measurement**

ABORt:WPOWER	6.30
--------------	------

CONFigure:WPOWer:CONTRol:REPetition[?] .....6.31  
 CONFigure:WPOWer:EREPorting[?].....6.30  
 CONTInue:WPOWer .....6.30  
 FETCh:WPOWer:STATus? .....6.30  
 FETCh[:SCALar]:WPOWer?.....6.31  
 INITiate:WPOWer.....6.30  
 READ[:SCALar]:WPOWer? .....6.31  
 SAMPlE[:SCALar]: WPOWer? .....6.31  
 STOP:WPOWer.....6.30

**NPOWer Measurement**

ABORt:NPOWer .....6.32  
 CONFigure:NPOWer:CONTRol:CBSize[?] .....6.34  
 CONFigure:NPOWer:CONTRol:REPetition[?] .....6.34  
 CONFigure:NPOWer:CONTRol:STATistics[?].....6.33  
 CONFigure:NPOWer:CONTRol[?].....6.33  
 CONFigure:NPOWer:EREPorting[?] .....6.32  
 CONTInue:NPOWer .....6.32  
 FETCh[:SCALar]:NPOWer:STATus? .....6.32  
 FETCh[:SCALar]:NPOWer? .....6.34  
 INITiate:NPOWer.....6.32  
 READ[:SCALar]:NPOWer? .....6.34  
 SAMPlE[:SCALar]:NPOWer? .....6.34  
 STOP:NPOWer .....6.32

**MQUality Measurement**

ABORt:MODulation:MQUality:HPSK.....6.35  
 CALCulate[:SCALar]:MODulation:MQUality:HPSK:MATChing:LIMit?.....6.42  
 CONFigure:MODulation:MQUality:HPSK:AVERage:LIMit[?].....6.39  
 CONFigure:MODulation:MQUality:HPSK:CMMax:LIMit[?] .....6.38  
 CONFigure:MODulation:MQUality:HPSK:CONTRol:FOFFset:SBSuppress:ACP<nr>[?] .....6.37  
 CONFigure:MODulation:MQUality:HPSK:CONTRol:REPetition[?] .....6.37  
 CONFigure:MODulation:MQUality:HPSK:CONTRol:STATistics[?] .....6.37  
 CONFigure:MODulation:MQUality:HPSK:CONTRol[?] .....6.36  
 CONFigure:MODulation:MQUality:HPSK:EREPorting[?] .....6.35  
 CONTInue:MODulation:MQUality:HPSK .....6.35  
 DEFault:MODulation:MQUality:HPSK:AVERage:LIMit[?].....6.40  
 DEFault:MODulation:MQUality:HPSK:CMMax:LIMit[?] .....6.40  
 DEFault:MODulation:MQUality:HPSK:CONTRol[?] .....6.36  
 FETCh[:SCALar]:MODulation:MQUality:HPSK:STATus? .....6.35  
 FETCh[:SCALar]:MODulation:MQUality:HPSK? .....6.41  
 INITiate:MODulation:MQUality:HPSK.....6.35  
 READ[:SCALar]:MODulation:MQUality:HPSK?.....6.41  
 SAMPlE[:SCALar]:MODulation:MQUality:HPSK?.....6.41  
 STOP:MODulation:MQUality:HPSK .....6.35

**MODulation:OVERview Measurement**

ABORt:MODulation:OVERview:HPSK .....6.42  
 CALCulate[:SCALar]:MODulation:OVERview:HPSK:MATChing:LIMit? .....6.50  
 CONFigure:MODulation:OEMP:HPSK:AVERage:LIMit[:SCALar]:SYMMetric[:COMBined][?] .....6.47  
 CONFigure:MODulation:OEMP:HPSK:AVERage:LIMit[:SCALar]:SYMMetric[:COMBined]:VALue[?].....6.48  
 CONFigure:MODulation:OEMP:HPSK:AVERage:LIMit[:SCALar]:SYMMetric[:COMBined]:ENABle[?] .....6.48  
 CONFigure:MODulation:OEMP:HPSK:CMMax:LIMit[:SCALar]:SYMMetric[:COMBined][?] .....6.46  
 CONFigure:MODulation:OEMP:HPSK:CMMax:LIMit[:SCALar]:SYMMetric[:COMBined]:VALue[?] .....6.47

CONFigure:MODulation:OEMP:HPSK:CMMax:LIMit[:SCALar]:SYMMetric[:COMBined]:ENABLE[?] .....6.48  
 CONFigure:MODulation:OVERview:HPSK:CONTRol:REPetition[?].....6.45  
 CONFigure:MODulation:OVERview:HPSK:CONTRol:STATistics[?] .....6.44  
 CONFigure:MODulation:OVERview:HPSK:CONTRol[?] .....6.44  
 CONFigure:MODulation:OVERview:HPSK:EREPorting[?].....6.43  
 CONTinue:MODulation:OVERview:HPSK.....6.42  
 DEFault:MODulation:OEMP:HPSK:LIMit[?].....6.49  
 DEFault:MODulation:OVERview:HPSK:CONTRol[?].....6.44  
 FETCh[:SCALar]:MODulation:OVERview:HPSK:STATus? .....6.43  
 FETCh[:SCALar]:MODulation:OVERview:HPSK? .....6.49  
 INITiate:MODulation:OVERview:HPSK .....6.42  
 READ[:SCALar]:MODulation:OVERview:HPSK? .....6.49  
 SAMPlE[:SCALar]:MODulation:OVERview:HPSK? .....6.49  
 STOP:MODulation:OVERview:HPSK.....6.42

**MODulation:EVMagnitude Measurement**

ABORt:MODulation:EVMagnitude:HPSK .....6.50  
 CALCulate[:SCALar]:MODulation:EVMagnitude:HPSK:MATChing:LIMit? .....6.55  
 CONFigure:MODulation:EVMagnitude:HPSK:CONTRol:REPetition[?] .....6.53  
 CONFigure:MODulation:EVMagnitude:HPSK:CONTRol:RMODE[?] .....6.52  
 CONFigure:MODulation:EVMagnitude:HPSK:CONTRol:STATistics[?] .....6.53  
 CONFigure:MODulation:EVMagnitude:HPSK:CONTRol[?] .....6.52  
 CONFigure:MODulation:EVMagnitude:HPSK:EREPorting[?].....6.51  
 CONFigure:SUBarrays:MODulation:EVMagnitude:HPSK[?] .....6.54  
 CONTinue:MODulation:EVMagnitude:HPSK.....6.50  
 DEFault:MODulation:EVMagnitude:HPSK:CONTRol[?] .....6.53  
 FETCh:ARRay:MODulation:EVMagnitude:HPSK:AVERAge? .....6.56  
 FETCh:ARRay:MODulation:EVMagnitude:HPSK:CURRent?.....6.56  
 FETCh:ARRay:MODulation:EVMagnitude:HPSK:MMAx? .....6.56  
 FETCh:SUBarrays:MODulation:EVMagnitude:HPSK:AVERAge? .....6.56  
 FETCh:SUBarrays:MODulation:EVMagnitude:HPSK:CURRent?.....6.56  
 FETCh:SUBarrays:MODulation:EVMagnitude:HPSK:MMAx? .....6.56  
 FETCh[:SCALar]:MODulation:EVMagnitude:HPSK:STATus?.....6.51  
 FETCh[:SCALar]:MODulation:EVMagnitude:HPSK?.....6.55  
 INITiate:MODulation:EVMagnitude:HPSK .....6.50  
 READ:ARRay:MODulation:EVMagnitude:HPSK:AVERAge? .....6.56  
 READ:ARRay:MODulation:EVMagnitude:HPSK:CURRent? .....6.56  
 READ:ARRay:MODulation:EVMagnitude:HPSK:MMAx? .....6.56  
 READ:SUBarrays:MODulation:EVMagnitude:HPSK:AVERAge?.....6.56  
 READ:SUBarrays:MODulation:EVMagnitude:HPSK:CURRent? .....6.56  
 READ:SUBarrays:MODulation:EVMagnitude:HPSK:MMAx?.....6.56  
 READ[:SCALar]:MODulation:EVMagnitude:HPSK? .....6.55  
 SAMPlE:ARRay:MODulation:EVMagnitude:HPSK:AVERAge?.....6.56  
 SAMPlE:ARRay:MODulation:EVMagnitude:HPSK:CURRent? .....6.56  
 SAMPlE:ARRay:MODulation:EVMagnitude:HPSK:MMAx? .....6.56  
 SAMPlE:SUBarrays:MODulation:EVMagnitude:HPSK:AVERAge?.....6.56  
 SAMPlE:SUBarrays:MODulation:EVMagnitude:HPSK:CURRent? .....6.56  
 SAMPlE:SUBarrays:MODulation:EVMagnitude:HPSK:MMAx?.....6.56  
 SAMPlE[:SCALar]:MODulation:EVMagnitude:HPSK? .....6.55  
 STOP:MODulation:EVMagnitude:HPSK.....6.50

**MODulation:PERRor Measurement**

ABORt:MODulation:PERRor:HPSK.....6.57  
 CALCulate[:SCALar]:MODulation:PERRor:HPSK:MATChing:LIMit? .....6.61

CONFigure:MODulation:PERRor:HPSK:CONTrol:REPetition[?].....6.59  
 CONFigure:MODulation:PERRor:HPSK:CONTrol:RMODe[?].....6.59  
 CONFigure:MODulation:PERRor:HPSK:CONTrol:STATistics[?].....6.58  
 CONFigure:MODulation:PERRor:HPSK:CONTrol[?].....6.58  
 CONFigure:MODulation:PERRor:HPSK:EREPorting[?].....6.57  
 CONFigure:SUBarrays:MODulation:PERRor:HPSK[?].....6.60  
 CONTinue:MODulation:PERRor:HPSK.....6.57  
 DEFault:MODulation:PERRor:HPSK:CONTrol[?].....6.59  
 FETCh:ARRay:MODulation:PERRor:HPSK:AVErAge?.....6.62  
 FETCh:ARRay:MODulation:PERRor:HPSK:CURRent?.....6.62  
 FETCh:ARRay:MODulation:PERRor:HPSK:MMAX?.....6.62  
 FETCh:SUBarrays:MODulation:PERRor:HPSK:AVErAge?.....6.62  
 FETCh:SUBarrays:MODulation:PERRor:HPSK:CURRent?.....6.62  
 FETCh:SUBarrays:MODulation:PERRor:HPSK:MMAX?.....6.62  
 FETCh[:SCALar]:MODulation:PERRor:HPSK:STATus?.....6.57  
 FETCh[:SCALar]:MODulation:PERRor:HPSK?.....6.61  
 INITiate:MODulation:PERRor:HPSK.....6.57  
 READ:ARRay:MODulation:PERRor:HPSK:AVErAge?.....6.62  
 READ:ARRay:MODulation:PERRor:HPSK:CURRent?.....6.62  
 READ:ARRay:MODulation:PERRor:HPSK:MMAX?.....6.62  
 READ:SUBarrays:MODulation:PERRor:HPSK:AVErAge?.....6.62  
 READ:SUBarrays:MODulation:PERRor:HPSK:CURRent?.....6.62  
 READ:SUBarrays:MODulation:PERRor:HPSK:MMAX?.....6.62  
 READ[:SCALar]:MODulation:PERRor:HPSK?.....6.61  
 SAMPlE:ARRay:MODulation:PERRor:HPSK:AVErAge?.....6.62  
 SAMPlE:ARRay:MODulation:PERRor:HPSK:CURRent?.....6.62  
 SAMPlE:ARRay:MODulation:PERRor:HPSK:MMAX?.....6.62  
 SAMPlE:SUBarrays:MODulation:PERRor:HPSK:AVErAge?.....6.62  
 SAMPlE:SUBarrays:MODulation:PERRor:HPSK:CURRent?.....6.62  
 SAMPlE:SUBarrays:MODulation:PERRor:HPSK:MMAX?.....6.62  
 SAMPlE[:SCALar]:MODulation:PERRor:HPSK?.....6.61  
 STOP:MODulation:PERRor:HPSK.....6.57

**MODulation:MERRor Measurement**

ABORt:MODulation:MERRor:HPSK.....6.63  
 CALCulate[:SCALar]:MODulation:MERRor:HPSK:MATChing:LIMit?.....6.67  
 CONFigure:MODulation:MERRor:HPSK:CONTrol:REPetition[?].....6.65  
 CONFigure:MODulation:MERRor:HPSK:CONTrol:RMODe[?].....6.64  
 CONFigure:MODulation:MERRor:HPSK:CONTrol:STATistics[?].....6.64  
 CONFigure:MODulation:MERRor:HPSK:CONTrol[?].....6.64  
 CONFigure:MODulation:MERRor:HPSK:EREPorting[?].....6.63  
 CONFigure:SUBarrays:MODulation:MERRor:HPSK[?].....6.66  
 CONTinue:MODulation:MERRor:HPSK.....6.63  
 DEFault:MODulation:MERRor:HPSK:CONTrol[?].....6.65  
 FETCh:ARRay:MODulation:MERRor:HPSK:AVErAge?.....6.68  
 FETCh:ARRay:MODulation:MERRor:HPSK:CURRent?.....6.68  
 FETCh:ARRay:MODulation:MERRor:HPSK:MMAX?.....6.68  
 FETCh:SUBarrays:MODulation:MERRor:HPSK:AVErAge?.....6.68  
 FETCh:SUBarrays:MODulation:MERRor:HPSK:CURRent?.....6.68  
 FETCh:SUBarrays:MODulation:MERRor:HPSK:MMAX?.....6.68  
 FETCh[:SCALar]:MODulation:MERRor:HPSK:STATus?.....6.63  
 FETCh[:SCALar]:MODulation:MERRor:HPSK?.....6.67  
 INITiate:MODulation:MERRor:HPSK.....6.63  
 READ:ARRay:MODulation:MERRor:HPSK:AVErAge?.....6.68

READ:ARRay:MODulation:MERRor:HPSK:CURRent?	6.68
READ:ARRay:MODulation:MERRor:HPSK:MMAx?	6.68
READ:SUBarrays:MODulation:MERRor:HPSK:AVERage?	6.68
READ:SUBarrays:MODulation:MERRor:HPSK:CURRent?	6.68
READ:SUBarrays:MODulation:MERRor:HPSK:MMAx?	6.68
READ[:SCALar]:MODulation:MERRor:HPSK?	6.67
SAMPlE:ARRay:MODulation:MERRor:HPSK:AVERage?	6.68
SAMPlE:ARRay:MODulation:MERRor:HPSK:CURRent?	6.68
SAMPlE:ARRay:MODulation:MERRor:HPSK:MMAx?	6.68
SAMPlE:SUBarrays:MODulation:MERRor:HPSK:AVERage?	6.68
SAMPlE:SUBarrays:MODulation:MERRor:HPSK:CURRent?	6.68
SAMPlE:SUBarrays:MODulation:MERRor:HPSK:MMAx?	6.68
SAMPlE[:SCALar]:MODulation:MERRor:HPSK?	6.67
STOP:MODulation:MERRor:HPSK	6.63

**MODulation:IQANalyzer Measurement**

ABORt:MODulation:IQANalyzer:HPSK	6.69
CONFigure: MODulation:IQANalyzer:HPSK:CONTRol:RMODE[?]	6.70
CONFigure:MODulation:IQANalyzer:HPSK:CONTRol:REPetition[?]	6.70
CONFigure:MODulation:IQANalyzer:HPSK:EREPorting[?]	6.69
CONFigure:SUBarrays:IQANalyzer:MERRor:HPSK[?]	6.71
CONTInue:MODulation:IQANalyzer:HPSK	6.69
DEFault:MODulation:IQANalyzer:HPSK:CONTRol[?]	6.71
FETCh:ARRay:MODulation:IQANalyzer:HPSK:IPHase?	6.72
FETCh:ARRay:MODulation:IQANalyzer:HPSK:QPHase?	6.73
FETCh:SUBarrays:MODulation:IQANalyzer:HPSK:IPHase?	6.73
FETCh:SUBarrays:MODulation:IQANalyzer:HPSK:QPHase?	6.73
FETCh[:SCALar]:MODulation: IQANalyzer:HPSK?	6.72
FETCh[:SCALar]:MODulation:IQANalyzer:HPSK:STATus?	6.69
INITiate:MODulation:IQANalyzer:HPSK	6.69
READ:ARRay:MODulation:IQANalyzer:HPSK:IPHase?	6.72
READ:ARRay:MODulation:IQANalyzer:HPSK:QPHase?	6.73
READ:SUBarrays:MODulation:IQANalyzer:HPSK:IPHase?	6.73
READ:SUBarrays:MODulation:IQANalyzer:HPSK:QPHase?	6.73
READ[:SCALar]:MODulation: IQANalyzer:HPSK?	6.72
SAMPlE:ARRay:MODulation:IQANalyzer:HPSK:IPHase?	6.72
SAMPlE:ARRay:MODulation:IQANalyzer:HPSK:QPHase?	6.73
SAMPlE:SUBarrays:MODulation:IQANalyzer:HPSK:IPHase?	6.73
SAMPlE:SUBarrays:MODulation:IQANalyzer:HPSK:QPHase?	6.73
SAMPlE[:SCALar]:MODulation: IQANalyzer:HPSK?	6.72
STOP:MODulation:IQANalyzer:HPSK	6.69

**CDPower:CDPW Measurement**

ABORt:CDPower:CDPW	6.74
CALCulate:ARRay:CDPower:CDPW:ISIGnal:AVERage[:RESult]:MATChing:LIMit?	6.82
CALCulate:ARRay:CDPower:CDPW:ISIGnal:CURRent[:RESult]:MATChing:LIMit?	6.82
CALCulate:ARRay:CDPower:CDPW:ISIGnal:MAXimum[:RESult]:MATChing:LIMit?	6.83
CALCulate:ARRay:CDPower:CDPW:QSIGnal:AVERage[:RESult]:MATChing:LIMit?	6.83
CALCulate:ARRay:CDPower:CDPW:QSIGnal:CURRent[:RESult]:MATChing:LIMit?	6.83
CALCulate:ARRay:CDPower:CDPW:QSIGnal:MAXimum[:RESult]:MATChing:LIMit?	6.83
CALCulate[:SCALar]:CDPower:CDPW:MATChing:LIMit?	6.80
CONFigure:CDPower:CDPW:AVERage:LIMit:ASYMmetric[:COMBined][?]	6.79
CONFigure:CDPower:CDPW:CMAX:LIMit:ASYMmetric[:COMBined][?]	6.78
CONFigure:CDPower:CDPW:CONTRol:REPetition[?]	6.76

CONFigure:CDPower:CDPW:CONTRol:RMODE[?] .....6.75  
 CONFigure:CDPower:CDPW:CONTRol:RORDER[?] .....6.76  
 CONFigure:CDPower:CDPW:CONTRol:STATistics[?] .....6.76  
 CONFigure:CDPower:CDPW:CONTRol[?] .....6.75  
 CONFigure:CDPower:CDPW:EREPorting[?].....6.74  
 CONFigure:CDPower:CDPW:LIMit:IQLCheck[?].....6.79  
 CONFigure:CDPower:CPCCommon:AVERAge:LIMit:ASYMmetric[:COMBined][?] .....6.78  
 CONFigure:CDPower:CPCCommon:CMAX:LIMit:ASYMmetric[:COMBined][?].....6.77  
 CONTinue:CDPower:CDPW .....6.74  
 DEFault:CDPower:CDPW:CONTRol[?] .....6.76  
 DEFault:CDPower:CDPW:LIMit[?].....6.79  
 DEFault:CDPower:CPCCommon:LIMit[?] .....6.78  
 FETCh:ARRAy:CDPower:CDPW:ISIGnal[:VALue]:AVERAge? .....6.81  
 FETCh:ARRAy:CDPower:CDPW:ISIGnal[:VALue]:CURRent? .....6.80  
 FETCh:ARRAy:CDPower:CDPW:ISIGnal[:VALue]:MAXimum? .....6.81  
 FETCh:ARRAy:CDPower:CDPW:QSIGnal[:VALue]:AVERAge? .....6.82  
 FETCh:ARRAy:CDPower:CDPW:QSIGnal[:VALue]:CURRent? .....6.81  
 FETCh:ARRAy:CDPower:CDPW:QSIGnal[:VALue]:MAXimum? .....6.82  
 FETCh[:SCALar]:CDPower:CDPW:STATus? .....6.74  
 FETCh[:SCALar]:CDPower:CDPW? .....6.80  
 INITiate:CDPower:CDPW .....6.74  
 READ:ARRAy:CDPower:CDPW:ISIGnal[:VALue]:AVERAge? .....6.81  
 READ:ARRAy:CDPower:CDPW:ISIGnal[:VALue]:CURRent? .....6.80  
 READ:ARRAy:CDPower:CDPW:ISIGnal[:VALue]:MAXimum? .....6.81  
 READ:ARRAy:CDPower:CDPW:QSIGnal[:VALue]:AVERAge? .....6.82  
 READ:ARRAy:CDPower:CDPW:QSIGnal[:VALue]:CURRent? .....6.81  
 READ:ARRAy:CDPower:CDPW:QSIGnal[:VALue]:MAXimum? .....6.82  
 READ[:SCALar]:CDPower:CDPW? .....6.80  
 SAMPlE:ARRAy:CDPower:CDPW:ISIGnal[:VALue]:AVERAge? .....6.81  
 SAMPlE:ARRAy:CDPower:CDPW:ISIGnal[:VALue]:CURRent? .....6.80  
 SAMPlE:ARRAy:CDPower:CDPW:ISIGnal[:VALue]:MAXimum? .....6.81  
 SAMPlE:ARRAy:CDPower:CDPW:QSIGnal[:VALue]:AVERAge? .....6.82  
 SAMPlE:ARRAy:CDPower:CDPW:QSIGnal[:VALue]:CURRent? .....6.81  
 SAMPlE:ARRAy:CDPower:CDPW:QSIGnal[:VALue]:MAXimum? .....6.82  
 SAMPlE[:SCALar]:CDPower:CDPW? .....6.80  
 STOP:CDPower:CDPW .....6.74

**CDPower:PCDep Measurement**

ABORt:CDPower:PCDep .....6.84  
 CALCulate:ARRAy:CDPower:PCDep:ISIGnal:AVERAge[:RESult]:MATChing:LIMit? .....6.90  
 CALCulate:ARRAy:CDPower:PCDep:ISIGnal:CURRent[:RESult]:MATChing:LIMit? .....6.90  
 CALCulate:ARRAy:CDPower:PCDep:ISIGnal:MAXimum[:RESult]:MATChing:LIMit? .....6.91  
 CALCulate:ARRAy:CDPower:PCDep:QSIGnal:AVERAge[:RESult]:MATChing:LIMit? .....6.91  
 CALCulate:ARRAy:CDPower:PCDep:QSIGnal:CURRent[:RESult]:MATChing:LIMit? .....6.91  
 CALCulate:ARRAy:CDPower:PCDep:QSIGnal:MAXimum[:RESult]:MATChing:LIMit? .....6.91  
 CALCulate[:SCALar]:CDPower:PCDep:MATChing:LIMit? .....6.88  
 CONFigure:CDPower:PCDep:AVERAge:LIMit:ASYMmetric[:COMBined][?] .....6.87  
 CONFigure:CDPower:PCDep:CMAX:LIMit:ASYMmetric[:COMBined][?] .....6.87  
 CONFigure:CDPower:PCDep:CONTRol:REPetition[?].....6.86  
 CONFigure:CDPower:PCDep:CONTRol:RMODE[?].....6.85  
 CONFigure:CDPower:PCDep:CONTRol:RORDER[?] .....6.86  
 CONFigure:CDPower:PCDep:CONTRol:STATistics[?] .....6.86  
 CONFigure:CDPower:PCDep:CONTRol[?] .....6.85  
 CONFigure:CDPower:PCDep:EREPorting[?].....6.84

CONTinue:CDPower:PCDep ..... 6.84  
 DEFault:CDPower:PCDep:CONTrol[?] ..... 6.86  
 DEFault:CDPower:PCDep:LIMit[?] ..... 6.87  
 FETCh:ARRay:CDPower:PCDep:ISIGnal[:VALue]:AVERAge? ..... 6.89  
 FETCh:ARRay:CDPower:PCDep:ISIGnal[:VALue]:CURRent? ..... 6.88  
 FETCh:ARRay:CDPower:PCDep:ISIGnal[:VALue]:MAXimum? ..... 6.89  
 FETCh:ARRay:CDPower:PCDep:QSIGnal[:VALue]:AVERAge? ..... 6.90  
 FETCh:ARRay:CDPower:PCDep:QSIGnal[:VALue]:CURRent? ..... 6.89  
 FETCh:ARRay:CDPower:PCDep:QSIGnal[:VALue]:MAXimum? ..... 6.90  
 FETCh[:SCALar]:CDPower:PCDep:STATus? ..... 6.84  
 FETCh[:SCALar]:CDPower:PCDep? ..... 6.88  
 INITiate:CDPower:PCDep ..... 6.84  
 READ:ARRay:CDPower:PCDep:ISIGnal[:VALue]:AVERAge? ..... 6.89  
 READ:ARRay:CDPower:PCDep:ISIGnal[:VALue]:CURRent? ..... 6.88  
 READ:ARRay:CDPower:PCDep:ISIGnal[:VALue]:MAXimum? ..... 6.89  
 READ:ARRay:CDPower:PCDep:QSIGnal[:VALue]:AVERAge? ..... 6.90  
 READ:ARRay:CDPower:PCDep:QSIGnal[:VALue]:CURRent? ..... 6.89  
 READ:ARRay:CDPower:PCDep:QSIGnal[:VALue]:MAXimum? ..... 6.90  
 READ[:SCALar]:CDPower:PCDep? ..... 6.88  
 SAMPlE:ARRay:CDPower:PCDep:ISIGnal[:VALue]:AVERAge? ..... 6.89  
 SAMPlE:ARRay:CDPower:PCDep:ISIGnal[:VALue]:CURRent? ..... 6.88  
 SAMPlE:ARRay:CDPower:PCDep:ISIGnal[:VALue]:MAXimum? ..... 6.89  
 SAMPlE:ARRay:CDPower:PCDep:QSIGnal[:VALue]:AVERAge? ..... 6.90  
 SAMPlE:ARRay:CDPower:PCDep:QSIGnal[:VALue]:CURRent? ..... 6.89  
 SAMPlE:ARRay:CDPower:PCDep:QSIGnal[:VALue]:MAXimum? ..... 6.90  
 SAMPlE[:SCALar]:CDPower:PCDep? ..... 6.88  
 STOP:CDPower:PCDep ..... 6.84

**CDPower:CHPW Measurement**

ABORt:CDPower:CHPW ..... 6.92  
 CALCulate:ARRay:CDPower:CHPW:ISIGnal:AVERAge[:RESult]:MATChing:LIMit? ..... 6.98  
 CALCulate:ARRay:CDPower:CHPW:ISIGnal:CURRent[:RESult]:MATChing:LIMit? ..... 6.98  
 CALCulate:ARRay:CDPower:CHPW:ISIGnal:MAXimum[:RESult]:MATChing:LIMit? ..... 6.98  
 CALCulate:ARRay:CDPower:CHPW:QSIGnal:AVERAge[:RESult]:MATChing:LIMit? ..... 6.99  
 CALCulate:ARRay:CDPower:CHPW:QSIGnal:CURRent[:RESult]:MATChing:LIMit? ..... 6.99  
 CALCulate:ARRay:CDPower:CHPW:QSIGnal:MAXimum[:RESult]:MATChing:LIMit? ..... 6.99  
 CALCulate[:SCALar]:CDPower:CHPW:MATChing:LIMit? ..... 6.96  
 CONFigure:CDPower:CHPW:AVERAge:LIMit:ASYMmetric[:COMBined][?] ..... 6.95  
 CONFigure:CDPower:CHPW:CMAX:LIMit:ASYMmetric[:COMBined][?] ..... 6.95  
 CONFigure:CDPower:CHPW:CONTrol:REPetition[?] ..... 6.94  
 CONFigure:CDPower:CHPW:CONTrol:RMODE[?] ..... 6.93  
 CONFigure:CDPower:CHPW:CONTrol:STATistics[?] ..... 6.94  
 CONFigure:CDPower:CHPW:CONTrol[?] ..... 6.93  
 CONFigure:CDPower:CHPW:EREPorting[?] ..... 6.92  
 CONTinue:CDPower:CHPW ..... 6.92  
 DEFault:CDPower:CHPW:CONTrol[?] ..... 6.94  
 DEFault:CDPower:CHPW:LIMit[?] ..... 6.95  
 FETCh:ARRay:CDPower:CHPW:ISIGnal[:VALue]:AVERAge? ..... 6.97  
 FETCh:ARRay:CDPower:CHPW:ISIGnal[:VALue]:CURRent? ..... 6.96  
 FETCh:ARRay:CDPower:CHPW:ISIGnal[:VALue]:MAXimum? ..... 6.97  
 FETCh:ARRay:CDPower:CHPW:QSIGnal[:VALue]:AVERAge? ..... 6.97  
 FETCh:ARRay:CDPower:CHPW:QSIGnal[:VALue]:CURRent? ..... 6.97  
 FETCh:ARRay:CDPower:CHPW:QSIGnal[:VALue]:MAXimum? ..... 6.98  
 FETCh[:SCALar]:CDPower:CHPW:STATus? ..... 6.92

FETCh[:SCALar]:CDPower:CHPW? .....6.96  
 INITiate:CDPower:CHPW .....6.92  
 READ:ARRay:CDPower:CHPW:ISIGnal[:VALue]:AVERage? .....6.97  
 READ:ARRay:CDPower:CHPW:ISIGnal[:VALue]:CURRent? .....6.96  
 READ:ARRay:CDPower:CHPW:ISIGnal[:VALue]:MAXimum? .....6.97  
 READ:ARRay:CDPower:CHPW:QSIGnal[:VALue]:AVERage? .....6.97  
 READ:ARRay:CDPower:CHPW:QSIGnal[:VALue]:CURRent? .....6.97  
 READ:ARRay:CDPower:CHPW:QSIGnal[:VALue]:MAXimum? .....6.98  
 READ[:SCALar]:CDPower:CHPW? .....6.96  
 SAMPlE:ARRay:CDPower:CHPW:ISIGnal[:VALue]:AVERage? .....6.97  
 SAMPlE:ARRay:CDPower:CHPW:ISIGnal[:VALue]:CURRent? .....6.96  
 SAMPlE:ARRay:CDPower:CHPW:ISIGnal[:VALue]:MAXimum? .....6.97  
 SAMPlE:ARRay:CDPower:CHPW:QSIGnal[:VALue]:AVERage? .....6.97  
 SAMPlE:ARRay:CDPower:CHPW:QSIGnal[:VALue]:CURRent? .....6.97  
 SAMPlE:ARRay:CDPower:CHPW:QSIGnal[:VALue]:MAXimum? .....6.98  
 SAMPlE[:SCALar]:CDPower:CHPW? .....6.96  
 STOP:CDPower:CHPW .....6.92

**SPECTrum:ACP Measurement**

ABORt:SPECTrum:ACP .....6.100  
 CALCulate[:SCALar]:SPECTrum:ACP:MATChing:LIMit? .....6.106  
 CONFigure:SPECTrum:ACP:CONTRol:FOFFset:ACP<nr>[?] .....6.103  
 CONFigure:SPECTrum:ACP:CONTRol:REPetition[?] .....6.102  
 CONFigure:SPECTrum:ACP:CONTRol:STATistics[?] .....6.101  
 CONFigure:SPECTrum:ACP:CONTRol[?] .....6.101  
 CONFigure:SPECTrum:ACP:EREPorting[?] .....6.100  
 CONFigure:SPECTrum:ACP:LIMit:ACP1[?] .....6.104  
 CONTinue:SPECTrum:ACP .....6.100  
 DEFault:SPECTrum:ACP:CONTRol[?] .....6.102  
 DEFault:SPECTrum:ACP:LIMit[?] .....6.104  
 FETCh[:SCALar]:SPECTrum:ACP:STATus? .....6.100  
 FETCh[:SCALar]:SPECTrum:ACP? .....6.105  
 INITiate:SPECTrum:ACP .....6.100  
 READ[:SCALar]:SPECTrum:ACP? .....6.105  
 SAMPlE[:SCALar]:SPECTrum:ACP? .....6.105  
 STOP:SPECTrum:ACP .....6.100

## 7 Remote Control – Program Example

The following example program illustrates primary and secondary addressing by setting up a call and performing simple measurements with the CMU. In the example, remote control via GPIB bus and the programming language *Winbatch* is used.

A large variety of additional GPIB examples can be found on the CMU customer web.

*Winbatch* uses device names such as *CMUBASE*, *1xEV-DO-N* which are previously defined and assigned to the primary address, secondary address, and some general device settings.

With these device names, a complete command line reads:

```
CMUBASE: <CMU_Command>
```

where *<CMU\_Command>* may be any of the commands (setting commands or queries) specified within the function group and mode identified by the device name *CMUBASE*. Program sequences consisting of commands that are defined in several function groups and modes can be re-used with an exchanged device name.

In addition to these data transfer commands, *Winbatch* provides *WHILE*, *GOTO*, and *IF* statements to express conditions and define loops.

With the statement:

```
WHILE 1xEV-DO-N: FETC:SPEC:ACP:STAT? <> RDY
```

the instrument waits until the spectrum measurement has finished before it executes the following commands.

For a C program assigning secondary addresses, refer to Chapter 7 of the CMU operating manual.

In the program example preliminary configurations for different measurements are defined, and the network parameters are set before performing actual measurements.

Before running the program, configure your *Winbatch* settings such that *CMUBASE* is the device name for the CMU *BASE* system and *1xEV-DO-N* denote the function group *1xEV-DO Non-Signalling*.

```
ECHO ON
```

```
FPRINT -----
FPRINT INITIALISATION ROUTINE:
FPRINT ASK FOR THE IDENTIFIER OF THE CMU, RESET THE INSTRUMENT,
FPRINT DEFINE THE SECONDARY ADDRESSES FOR ALL AVAILABLE FUNCTION GROUPS
FPRINT -----
```

```
CMUBASE: *IDN?
CMUBASE: *RST;*OPC?
CMUBASE: *CLS
```

```
CMUBASE: TRAC:REM:MODE:DISP ON
```

```

; Get primary and secondary addresses
CMUBASE: SYSTEM:REMOTE:ADDR:PRIM?
CMUBASE: SYST:REM:ADDR:SEC?

; Set the secondary address of the functional groups
CMUBASE: SYST:REM:ADDR:SEC?

CMUBASE: SYST:REM:ADDR:SEC 1,"CDMA2K450MS_Sig"
CMUBASE: SYST:REM:ADDR:SEC 2,"CDMA2K450MS_NSig"
CMUBASE: SYST:REM:ADDR:SEC 3,"CDMA2KCellMS_Sig"
CMUBASE: SYST:REM:ADDR:SEC 4,"CDMA2KCellMS_NSig"
CMUBASE: SYST:REM:ADDR:SEC 5,"CDMA2KPCSMS_Sig"
CMUBASE: SYST:REM:ADDR:SEC 6,"CDMA2KPCSMS_NSig"
CMUBASE: SYST:REM:ADDR:SEC 7,"CDMA2KIMT2KMS_Sig"
CMUBASE: SYST:REM:ADDR:SEC 8,"CDMA2KIMT2KMS_NSig"
CMUBASE: SYST:REM:ADDR:SEC 10,"EVDO1XAT_NSig"

CMUBASE: SYST:REM:ADDR:SEC?

```

```

FPRINT -----
FPRINT Configure the connector
FPRINT -----

```

```

1xEV-DO-N: INP:STAT RF2
1xEV-DO-N: OUTP:STAT RF2
1xEV-DO-N: SENS:CORR:LOSS:INP2 1.0
1xEV-DO-N: SENS:CORR:LOSS:OUTP2 1.0

```

```

FPRINT -----
FPRINT Network configuration
FPRINT -----

```

```

1xEV-DO-N: CONFigure:NETWork:STANDard USC
1xEV-DO-N: CONFigure:NETWork:STANDard?

```

```

FPRINT -----
FPRINT Analyzer configuration
FPRINT -----

```

```

1xEV-DO-N: RFANalyzer:FREQuency:UNIT CH

1xEV-DO-N: RFANalyzer:FOFFset 0

1xEV-DO-N: RFANalyzer:LCMask:I:LSB "00000000"
1xEV-DO-N: RFANalyzer:LCMask:I:MSB "000"

1xEV-DO-N: RFANalyzer:LCMask:Q:LSB "00000000"
1xEV-DO-N: RFANalyzer:LCMask:Q:MSB "000"

1xEV-DO-N: RFANalyzer:CCFilter:DRC DCAR
1xEV-DO-N: RFANalyzer:CCFilter:ACK DCAR
1xEV-DO-N: RFANalyzer:CCFilter:DATA DCAR

```

```

FPRINT -----
FPRINT Measurement configuration
FPRINT -----

```

```

1xEV-DO-N: TRIGger:SOURce FRUN

```

```

; Ana/Gen

1xEV-DO-N: CONFigure:MODulation:MQuality:HPSK:CONTRol:STATistics 10

1xEV-DO-N:
CONFigure:MODulation:MQuality:HPSK:CONTRol:FOFFset:SBSuppress:ACP1 ON
1xEV-DO-N:
CONFigure:MODulation:MQuality:HPSK:CONTRol:FOFFset:SBSuppress:ACP2 ON
1xEV-DO-N:
CONFigure:MODulation:MQuality:HPSK:CONTRol:FOFFset:SBSuppress:ACP3 ON
1xEV-DO-N:
CONFigure:MODulation:MQuality:HPSK:CONTRol:FOFFset:SBSuppress:ACP4 ON

1xEV-DO-N:
CONFigure:MODulation:MQuality:HPSK:CONTRol:FOFFset:SBSuppress:ACP1?
1xEV-DO-N:
CONFigure:MODulation:MQuality:HPSK:CONTRol:FOFFset:SBSuppress:ACP2?
1xEV-DO-N:
CONFigure:MODulation:MQuality:HPSK:CONTRol:FOFFset:SBSuppress:ACP3?
1xEV-DO-N:
CONFigure:MODulation:MQuality:HPSK:CONTRol:FOFFset:SBSuppress:ACP4?

1xEV-DO-N: CONFigure:MODulation:MQuality:HPSK:CMMax:LIMit?
1xEV-DO-N: CONFigure:MODulation:MQuality:HPSK:AVERAge:LIMit?

; NarrowBandPower

1xEV-DO-N: CONFigure:NPOWER:CONTRol:STATistics 10
1xEV-DO-N: CONFigure:NPOWER:CONTRol:CBSize?

; Code Domain Power (Channel Power)

1xEV-DO-N: CONFigure:CDPower:CPCCCommon:CMAX:LIMit:ASYMmetric?
1xEV-DO-N: CONFigure:CDPower:CPCCCommon:AVERAge:LIMit:ASYMmetric?

1xEV-DO-N: CONFigure:CDPower:CHPW:CONTRol:RMODE?

1xEV-DO-N: CONFigure:CDPower:CHPW:CONTRol:STATistics 10

1xEV-DO-N: CONFigure:CDPower:CHPW:CMAX:LIMit:ASYMmetric?
1xEV-DO-N: CONFigure:CDPower:CHPW:AVERAge:LIMit:ASYMmetric?

FPRINT -----
FPRINT Generator configuration
FPRINT -----

1xEV-DO-N: SOURce:RFGenerator:MODE NORM

1xEV-DO-N: SOURce:RFGenerator:FREQuency:UNIT CH

1xEV-DO-N: SOURce:IMPairments:LEVel:AWGN OFF
1xEV-DO-N: SOURce:IMPairments:FOFFset OFF

1xEV-DO-N: SOURce:RFGenerator:PROPerTy:PNOFFset 0

; Sync Message

```

```
1xEV-DO-N: SOURCE:RFGenerator:SNCMessage:PSOffset 0
1xEV-DO-N: SOURCE:RFGenerator:SNCMessage:DRINDEX 1
1xEV-DO-N: SOURCE:RFGenerator:SNCMessage:DRATE?
1xEV-DO-N: SOURCE:RFGenerator:SNCMessage:SCOUNT?
```

```
; Configuration Access Terminal 1
```

```
1xEV-DO-N: SOURCE:RFGenerator:AT1:MAC:INDEX 63
1xEV-DO-N: SOURCE:RFGenerator:AT1:MAC:LEVEL -15
1xEV-DO-N: SOURCE:RFGenerator:AT1:PCOUNT INF
1xEV-DO-N: SOURCE:RFGenerator:AT1:PSOFFSET 8
1xEV-DO-N: SOURCE:RFGenerator:AT1:DRINDEX 12
1xEV-DO-N: SOURCE:RFGenerator:AT1:DRATE?
1xEV-DO-N: SOURCE:RFGenerator:AT1:SCOUNT?
1xEV-DO-N: SOURCE:RFGenerator:AT1:PATTERN "B4B4B4B4"
1xEV-DO-N: SOURCE:RFGenerator:AT1:DRCLock:STATE 1
1xEV-DO-N: SOURCE:RFGenerator:AT1:DRCLock:PERIOD 16
1xEV-DO-N: SOURCE:RFGenerator:AT1:DRCLock:LENGTH 16
```

```
; Reverse Activity
```

```
1xEV-DO-N: SOURCE:RFGenerator:RAB:MAC:LEVEL -10
1xEV-DO-N: SOURCE:RFGenerator:RAB:STATE 1
1xEV-DO-N: SOURCE:RFGenerator:RAB:OFFSET 3
1xEV-DO-N: SOURCE:RFGenerator:RAB:LENGTH 8
```

```
1xEV-DO-N: SOURCE:RFGenerator:OAT:COUNT 10
```

```
1xEV-DO-N: INIT:RFGenerator;*OPC?
```

```
1xEV-DO-N: INIT:RFGenerator:AT1:MAC:INDEX
1xEV-DO-N: INIT:RFGenerator:AT1:PSTREAM
```

```
1xEV-DO-N: SOURCE:RFGenerator:POWER:OUTPUT -50
1xEV-DO-N: SOURCE:RFGenerator:FREQUENCY 300
```

```
1xEV-DO-N: SOURCE:RFGenerator:AT1:PCBITS HOLD
```

```
FPRINT -----
FPRINT Maximum Output Power Measurement
FPRINT -----
```

```
1xEV-DO-N: LEVEL:MODE MAN
1xEV-DO-N: LEVEL:MAXIMUM 25dBm
1xEV-DO-N: RFANALYZER:FREQUENCY 300
```

```
1xEV-DO-N: SOURCE:RFGenerator:POWER:OUTPUT -105.5
1xEV-DO-N: SOURCE:RFGenerator:FREQUENCY 300
```

```
1xEV-DO-N: SOURCE:RFGenerator:AT1:PCBITS AUP
```

```
1xEV-DO-N: INIT:MODULATION:MQuality:HPSK
1xEV-DO-N: FETCh:MODULATION:MQuality:HPSK?
```

```
1xEV-DO-N: INITiate:CDPower:CHPW
1xEV-DO-N: FETCh:CDPower:CHPW?
```

```
FPRINT -----
FPRINT Minimum Output Power Measurement
FPRINT -----
```

```
1xEV-DO-N: LEVel:MODE MAN
1xEV-DO-N: LEVel:MAXimum -50dBm
1xEV-DO-N: RFANalyzer:FREQuency 300

1xEV-DO-N: SOURce:RFGenerator:POWer:OUTPut -25
1xEV-DO-N: SOURce:RFGenerator:FREQuency 300

1xEV-DO-N: SOURce:RFGenerator:AT1:PCBits ADOW

1xEV-DO-N: INIT:MODulation:MQuality:HPSK
1xEV-DO-N: FETCh:MODulation:MQuality:HPSK?

1xEV-DO-N: INITiate:NPOWer
1xEV-DO-N: FETCh:NPOWer?

1xEV-DO-N: INITiate:CDPower:CHPW
1xEV-DO-N: FETCh:CDPower:CHPW?
```

## 8 Maintenance

The CMU does not require any special maintenance. Remove any contamination on the instrument by means of a soft cloth. Make sure that the air vents are not obstructed.

Refer to the CMU Operating manual detailed maintenance, storage, and packing procedures. The CMU Operating manual also contains a list of support and service centers.

Refer to the CMU Service manual for information on troubleshooting, repair, and calibration.

## 9 Error Codes

Table 9-1 lists the error codes and associated messages that may occur when you are using the remote control commands.

Table 9-1 Error Codes

<b>Error Code</b>	<b>Message</b>
0	No error
-100	Command error
-101	Invalid character
-102	Syntax error
-103	Invalid separator
-104	Data type error
-105	GET not allowed
-108	Parameter not allowed
-109	Missing parameter
-111	Header separator error
-112	Program mnemonic too long
-113	Undefined header
-113	Undefined header
-114	Header suffix out of range
-120	Numeric data error
-121	Invalid character in number
-123	Exponent too large
-124	Too many digits
-128	Numeric data not allowed
-131	Invalid suffix
-134	Suffix too long
-138	Suffix not allowed
-141	Invalid character data
-144	Character data too long
-148	Character data not allowed
-151	Invalid string data
-158	String data not allowed
-161	Invalid block data
-168	Block data not allowed
-171	Invalid expression
-178	Expression data not allowed
-180	Macro error
-200	Execution error

-211	Trigger ignored
-221	Setting conflict
-222	Data out of range
-223	Too much data
-224	Illegal parameter value
-230	Data corrupt or stale
-240	Hardware error
-241	Hardware missing
-250	Mass storage error
-251	Missing mass storage
-252	Missing media
-253	Corrupt media
-254	Media full
-255	Directory full
-256	File name not found
-257	File name error
-258	Media protected
-300	Device-specific error
-310	System error
-311	Memory error
-313	Calibration memory lost
-314	Save/recall memory lost
-315	Configuration memory lost
-330	Self test failed
-350	Queue overflow
-360	Communication error
-361	Parity error in program message
-362	Framing error in program message
-363	Input buffer overrun
-400	Query error
-410	Query INTERRUPTED
-420	Query UNTERMINATED
-430	Query DEADLOCKED
-440	Query UNTERMINATED after indefinite response

# Index

## A

- Access Terminal
  - Connection ..... 2.2
  - SElect ..... 6.12
  - Subsystem, Analyzer ..... 6.11
  - Subsystem, Generator ..... 6.21
- ACK ..... 6.11, 6.96
- ACP ..... 6.100
- ACP Spectrum ..... 6.100
  - Remote Control ..... 6.100
- ACP Spectrum measurement (control)
  - Remote control ..... 6.101
- Analyzer ..... 4.48
- Analyzer Level ..... 4.48
- Analyzer/Generator ..... 4.3
- Application ..... 3.4
  - Modulation ..... 4.17, 4.36
- Attenuation ..... 4.59
- Autoranging ..... 4.48
- Average ..... 4.9
- Average values (calculation) ..... 3.5
- AWGN ..... 6.18
- AWGN Level ..... 4.52

## B

- Band class ..... 6.7
- Bit reverse ..... 4.43
  - Code domain power ..... 4.43
- BS frequency offset ..... 4.52

## C

- Capture Buffer (NPOWer) ..... 6.34
- Carrier feedthrough ..... 4.7
- Carrier frequency error ..... 4.7
- Channel power ..... 4.40
  - Remote control ..... 6.92
  - Statistic count ..... 6.94
- Channelpower(control)
  - Remotecontrol ..... 6.93
- Clock
  - Frequency ..... 6.29
- Clock frequency ..... 6.29
- Clock state ..... 6.29
- Closed loop power control ..... 4.55
- Code Channel
  - ACK ..... 6.11, 6.96
  - DATA ..... 6.11, 6.97
  - DRC ..... 6.11, 6.97
  - Pilot ..... 6.96
  - RRI ..... 6.96
- Code Channel Filter
  - Remote Control ..... 6.11
- Code domain error power
  - Remote control ..... 6.74, 6.84
- Code domain power ..... 4.37
  - Remote control ..... 6.74
- Code Domain Power
  - Remote control ..... 6.75, 6.85, 6.93
- Code domain power configuration ..... 4.42
- Code domain power measurement (control) ..... 4.42
- Code Domain Power measurement (control)
  - Remote control ..... 6.75
- Code Domain Power, IQ Leakage Check ..... 6.79
- Command

- Order ..... 5.6
- Structure ..... 5.1
- Tables (description) ..... 5.6
- Command Set ..... 6.2
- Commands
  - List ..... 6.107
- Configurations ..... 3.2
- Connection control ..... 4.47
- Connectors (RF) ..... 2.3
- Continuous ..... 5.4
- Continuous measurement ..... 4.8
- Control
  - Channel power ..... 6.94
  - Control Channel ..... 6.15, 6.18
- Counting ..... 5.4
- Current ..... 4.9

## D

- DATA ..... 6.11, 6.97
- Data Rate ..... 6.20, 6.23
- Data Rate Index ..... 6.20, 6.23
- Default
  - Modulation configuration ..... 4.27
- Default Settings ..... 4.8, 4.15
- Delta marker ..... 4.67
- Display mode ..... 3.4, 3.5
- Display Mode
  - Modulation ..... 4.9
- D-Line ..... 4.68
- DRC ..... 6.11, 6.97
- DRClock Length ..... 6.24
- DRClock Period ..... 6.24
- DRClock State ..... 6.24

## E

- Enable software ..... 1.7
- Error codes ..... 9.1
- External (Trigger) ..... 4.64
- Ext. att. input ..... 4.60, 6.28
- Ext. att. output ..... 4.59, 6.29
- External attenuation ..... 4.59
  - Remote control ..... 6.28
- External triggering ..... 4.64

## F

- Factory test mode ..... 5.6
- Filter
  - Code Channel ..... 6.11
- Frame Period ..... 6.13
- Frequency offset ..... 6.18
  - Analyzer ..... 6.9
- Frequency unit ..... 6.8, 6.16

## G

- Gain ..... 4.59
- Generator ..... 4.51, 4.58
- Generator frequency ..... 4.49, 4.52
- Getting started ..... 2.1
- GPIB Command Set Version ..... 6.2
- GPIB commands ..... 6.1
  - List ..... 6.107
- GPIB error codes ..... 9.1
- Graph

Error .....	4.20	Menu select .....	2.6
<b>H</b>		Menu structure .....	3.1
Hadamard matrix .....	4.43	Messages, error .....	9.1
Code domain power .....	4.43	Modulation	
Hotkeys .....	3.3	Analyzer/Generator .....	4.5, 4.12, 4.30
<b>I</b>		Remote control .....	6.52, 6.58, 6.63
I signal		Remote control .....	6.42
Channel power .....	6.96	MODulation	
Code domain power .....	6.80, 6.81	OEMP, limits .....	6.46, 6.48
Long Code Mask .....	6.10	Modulation configuration .....	4.14
Peak code domain error power .....	6.88	Modulation configuration .....	4.7
I/Q-IF .....	4.65, 6.4	Modulation configuration .....	4.26, 4.33
I/Q-IF Interface		Modulation measurement .....	4.16
remote control .....	6.4	Remote control .....	6.35, 6.42, 6.50, 6.57, 6.62
Impairments		Modulation measurement (control) .....	4.7, 4.14
Analyzer .....	4.49, 4.50	Remote control .....	6.35, 6.42, 6.50, 6.57, 6.63, 6.69
Info .....	6.2	Modulation Overview configuration	
Installation .....	1.1	Remote control .....	6.44
Installing software .....	1.2	Modulation quality configuration	
Flash disk .....	1.2	Remote control .....	6.36
Floppy disks .....	1.2	Modulation measurement (control)	
Interference .....	2.3	Remote control .....	6.36, 6.44, 6.52, 6.58, 6.64, 6.70
IQ Analyzer		MSB Long Code Mask .....	6.10
Remote control .....	6.69	<b>N</b>	
IQ Leakage Check .....	6.79	Narrow band	
<b>L</b>		Statistics .....	6.33
Limit		Narrow Band Power .....	6.32
Check .....	5.5	Network Standard .....	6.7
Specify .....	5.5	Networks Supported .....	1.1
Limit matching		Notation	
Modulation, overview .....	6.50	Remote control .....	5.6
Limit matching		NPower	
Modulation .....	6.42	Repetition .....	6.34
Limits		NPower .....	6.32
Channel Power, CHPW .....	6.95	Remote control .....	6.33
Code Domain Power .....	6.77, 6.78, 6.87, 6.95, 6.104	NPower measurement (control)	
Code domain power measurement .....	4.44	Remote control .....	6.33
Code Domain Power, CDPW .....	6.78, 6.104	Number of Bits .....	6.25, 6.26
Code Domain Power, CPCCCommon .....	6.77, 6.87, 6.95	<b>O</b>	
IQ Leakage Check .....	6.79	OEMP .....	6.72, 6.73
Modulation .....	6.38, 6.46	OEMP measurements .....	6.72, 6.73
Modulation measurement, signalling .....	4.10, 4.27, 4.34	OEMP Modulation .....	6.72, 6.73
Modulation, OEMP .....	6.46, 6.47, 6.48	On Limit Failure .....	4.9
Peak Code Domain Error Power .....	6.87	Operating concept .....	3.1
Peak Code Domain Error Power, PCDep .....	6.87	Options (Setup)	
Limits (Modulation) .....	4.10	remote control .....	6.2
Literal .....	5.7	Orthogonal Variable Spreading Factor .....	4.43
Long Code Mask .....	6.10	Other Access Terminal Count .....	6.27
I signal .....	6.10	Out of tolerance .....	4.7
LSB .....	6.10	Out of Tolerance	
MSB .....	6.10	Modulation, EVM .....	6.55
Q signal .....	6.10	Modulation, magnitude error .....	6.67
LSB Long Code Mask .....	6.10	Modulation, phase error .....	6.61
<b>M</b>		Output power .....	6.17
MAC Index .....	6.21	Output Power .....	4.52
MAC Level .....	6.22, 6.26	Output Routing .....	6.13
Main power switch .....	2.2	OVSF .....	4.43
Maintenance .....	8.1	<b>P</b>	
Manual control .....	3.1	Packet Count .....	6.23
Markers .....	4.67	Packet Start Offset .....	6.19, 6.23, 6.27
Measurement		Packing .....	8.1
Control .....	5.2	Parameter	
Measurement groups .....	3.3	command .....	5.7
Measurement object .....	5.2	Partial reset .....	6.2
		Pattern .....	6.24
		Peak code domain error power .....	4.40, 6.90

Peak Code Domain Error Power  
     PCDep..... 6.84  
     Remote control..... 6.84  
 Peak codedomainpowermeasurement(control)  
     Remotecontrol..... 6.85  
 Pilot..... 6.74, 6.80, 6.81, 6.82, 6.84, 6.88, 6.89, 6.90  
 PN offset..... 6.17  
 Polarity..... 6.26  
 Power (wide band)..... 4.61  
 Power (wideband)  
     remote control ..... 6.30  
 Power control bits ..... 4.55  
 Power Control Bits..... 6.25  
 Power switch ..... 2.3  
 Primary address..... 5.1  
 Program example ..... 7.1

**Q**

Q signal  
     Channel Power..... 6.97  
     Code domain power ..... 6.81, 6.82  
     Long Code Mask ..... 6.10  
     Peak code domain error power ..... 6.89

**R**

RAB Length ..... 6.27  
 RAB State..... 6.26  
 range test..... 6.25  
 Recall  
     current ..... 6.3  
 Reference frequency ..... 4.61  
     Remote control..... 6.29  
 Reference line ..... 4.68  
 Rel. 1 ..... 4.67  
 Rel. 2 ..... 4.67  
 Remote control  
     basics ..... 5.1  
     Commands..... 6.1  
     Notation..... 5.6  
     Program example..... 7.1  
 Repetition  
     ACP Spectrum..... 6.102  
     Channel power ..... 6.94  
     Code domain power ..... 6.76  
     Modulation..... 6.37  
     Modulation..... 4.8  
     Modulation, EVM..... 6.53  
     Modulation, IQ Analyzer ..... 6.70  
     Modulation, magnitude error ..... 6.65  
     Modulation, overview ..... 6.45  
     Modulation, phase error ..... 6.59  
     NPower..... 6.34  
     Peak code domain ..... 6.86  
 Repetition mode..... 3.4, 5.4  
 Report mode ..... 6.32  
 Reset ..... 2.4, 2.5  
 Result  
     ACP Spectrum..... 6.105  
     Channel power ..... 6.96  
     Code domain power ..... 6.80  
     Error vector magnitude..... 6.55  
     IQ Analyzer..... 6.72  
     Magnitude error..... 6.67  
     Modulation overview ..... 6.49  
     Modulation quality ..... 6.41  
     Narrow band power..... 6.34  
     Peak code domain error power ..... 6.88  
     Phase error..... 6.61  
     Wide band power..... 6.31  
 Result (power) ..... 4.37

Result mode  
     Channel power..... 6.93  
     Code domain power..... 6.75  
     Modulation, EVM..... 6.52  
     Modulation, IQ Analyzer..... 6.70  
     Modulation, magnitude error..... 6.64  
     Modulation, phase error..... 6.59  
     Peak code domain ..... 6.85  
 Result order  
     Code domain power..... 6.76  
     Peak code domain ..... 6.86  
 Reverse Activity Bit ..... 6.26  
 Reverse Link Frame Offset ..... 6.11  
 RF channel  
     Generator..... 4.49, 4.52  
 RF connector..... 2.2  
 RF connectors..... 2.3, 4.58, 6.28  
 RF frequency..... 6.9, 6.16  
 RF frequency..... 4.49  
 RF generator ..... 6.15  
     mode..... 6.17  
     Remote control..... 6.15  
 RF input..... 4.60, 6.28  
 RF level, mode ..... 6.10  
 RF Max. Level ..... 4.48, 6.10  
 RF Mode..... 4.48  
 RF output..... 4.59, 6.28  
 RFANalyzer  
     Remote control..... 6.8  
 Routing (Trigger) ..... 4.64  
 RRI ..... 6.96  
 RRI ..... 6.74, 6.80, 6.81, 6.82, 6.84, 6.88, 6.89, 6.90  
 RX Path..... 4.66, 6.4

**S**

Save  
     current..... 6.3  
 SCPI standard..... 5.2  
 Secondary address ..... 5.1, 5.6  
 Select Access Terminal..... 6.12  
 Side band freq. offset  
     Modulation ..... 4.9  
 Sideband frequency offset  
     Modulation ..... 6.37  
 Single shot ..... 5.4  
 Single-shot measurement ..... 4.8  
 Slot Count ..... 6.20, 6.24  
 Softkeys ..... 3.3  
 Software  
     Update and installation ..... 1.1  
     Software (enable)..... 1.7  
     Software configuration ..... 1.5  
     Special character ..... 5.8  
 Spectrum ..... 6.100  
     Remote control..... 6.101  
 Standby mode ..... 2.3  
 Startup menu..... 1.1, 2.4  
 Statistic count..... 4.39, 5.4  
     ACP Spectrum ..... 6.101  
     Channel power..... 6.94  
     Code domain power..... 6.75  
     Modulation ..... 6.37  
     Modulation, EVM..... 6.53  
     Modulation, magnitude error..... 6.64  
     Modulation, overview ..... 6.44  
     Modulation, phase error..... 6.58  
     Peak code domain ..... 6.85, 6.86  
 Statistic count..... 4.7, 4.14  
 Statistic Count ..... 3.4  
     Modulation ..... 4.9  
 Statistical quantities ..... 3.6

Statistics	
NPower.....	6.33
Remote control.....	5.3
Statistics cycle.....	3.4
STATus	
OPERation register.....	6.6
OPERation register - Symbolic evaluation.....	6.6
Status indication.....	2.7
Status reporting system.....	5.5
Status symbols.....	3.2
Stepping mode	
ACP Spectrum.....	6.102
Channel power.....	6.94
Code domain power.....	6.76
Modulation.....	6.37
Modulation, EVM.....	6.53
Modulation, IQ Analyzer.....	6.70
Modulation, magnitude error.....	6.65
Modulation, overview.....	6.45
Modulation, phase error.....	6.59
Peak code domain.....	6.86
Stop condition	
ACP Spectrum.....	6.102
Channel power.....	6.94
Code domain power.....	6.76
Modulation.....	6.37
Modulation, EVM.....	6.53
Modulation, IQ Analyzer.....	6.70
Modulation, magnitude error.....	6.65
Modulation, overview.....	6.45
Modulation, phase error.....	6.59
Peak code domain.....	6.86
Stop Condition.....	3.4
Modulation.....	4.9
Storing.....	8.1
Subarrays	
Modulation, EVM.....	6.54
Modulation, IQ Analyzer.....	6.71
Modulation, magnitude error.....	6.66
Modulation, phase error.....	6.60
Symbolic evaluation of status register.....	5.5, 6.6
Sync. Message.....	6.15, 6.18
Synchronization	
Remote control.....	6.29
<b>T</b>	
Test modes.....	3.1
Tests	
1xEV-DO.....	4.2
Threshold IF Power.....	6.13
Threshold RF Power.....	6.13
Trace.....	5.4
Transmit time error.....	4.7
Trigger.....	4.63
remote control.....	6.12
Trigger Output.....	6.13
Trigger Slope.....	6.12
Trigger source.....	6.14
Trigger source.....	4.64, 4.65
Triggering	
External.....	4.64
TX Path.....	4.66, 6.5
<b>U</b>	
Updating software.....	1.2
<b>V</b>	
Version.....	6.2
Version manager.....	1.2
<b>W</b>	
Waveform quality	
Modulation.....	4.21, 4.25
Waveform quality.....	4.6
White noise.....	6.18
White noise, Gaussian.....	6.18
Wideband power	
remote control.....	6.30
Wideband Power.....	4.61