



ROHDE & SCHWARZ

Test and Measurement
Division

Operating Manual

Software Options

CDMA2000 for R&S[®] CMU-B83

R&S[®] CMU-K83/-K84/-K85/-K86

1150.3500.02/1150.3600.02/1150.3700.02/1150.3800.02

Including the extension

CDMA2000 Data Testing

R&S[®] CMU-K87

1150.4007.02

Throughout this manual, CMU-K83/-K84/-K85/-K86 is generally used as an abbreviation for software options R&S[®] CMU-K83/-K84/-K85/-K86. The Universal Radio Communication Tester R&S[®] CMU 200 is abbreviated as CMU200.

R&S[®] is a registered trademark of Rohde & Schwarz GmbH & Co. KG.
Trade names are trademarks of the owners.

CDMA2000[®] is a registered trademark of the Telecommunications Industry Association (TIA – USA).

Tabbed Divider Overview

Certificate of Quality
List of R&S Representatives

Manuals for Universal Radio Communication Tester CMU
What's New in this Revision?
Abbreviations
Glossary
References

Tabbed Divider

1	Chapter 1: Installation
2	Chapter 2: Getting Started
3	Chapter 3: Manual Operation
4	Chapter 4: Functions and their Application
5	Chapter 5: Remote Control – Basics
6	Chapter 6: Remote Control – Commands
7	Chapter 7: Remote Control – Program Example
8	Chapter 8: CDMA2000 Data Testing
9	Chapter 9: Error Codes
10	Index

Contents of Manuals for Universal Radio Communication Tester CMU

The user documentation for the R&S CMU 200/300 is divided in a Quick Start Guide, the operating manual for the basic instrument (including options CMU-B41, CMU-B17) and separate manuals for individual software and hardware options. The complete documentation is available on CD-ROM, stock no. PD 0757.7746.2x.



For an overview and order information about printed manuals refer to the beginning of the Quick Start Guide. The latest revisions of all manuals are also posted on the CMU Customer Web on GLORIS.

Operating Manual CMU-K83/-K84/-K85/-K86 (Software Options for CMU-B81)

The present operating manual describes the application of CMU for CDMA2000 mobile tests including option R&S CMU-K87, *CDMA2000 Data Testing*. It gives comprehensive information about the operating concept and about manual and remote control of the CMU tester. Typical measurement tasks are explained in detail using the functions offered by the graphical user interface and a selection of program examples.

The manual is organized as follows:

- | | |
|-------------------|--|
| Chapter 1 | Describes the steps necessary for installing the software and putting the instrument into operation. |
| Chapter 2 | Gives an introduction to the application of CMU for CDMA2000 mobile tests and presents some typical measurement examples. |
| Chapter 3 | Describes the operation in principle and the principles of measurement control. |
| Chapter 4 | Serves as a reference of all functions of the user interface and their application. Allowed settings, default values and the corresponding remote control commands are listed for all functions. |
| Chapter 5 | Describes the basics of remote control of the instrument for CDMA2000 mobile tests. |
| Chapter 6 | Lists all remote control commands defined for CDMA2000 mobile tests. At the end of the chapter the commands are grouped together according to their function and sorted by alphabetical order. |
| Chapter 7 | Contains program examples. |
| Chapter 8 | Describes option R&S CMU-K87, CDMA2000 Data Testing. |
| Chapter 9 | Contains a list of error codes |
| Chapter 10 | Contains an index for the operating manual. |

What's new in this Revision...

This operating manual describes version V3.80 of the CDMA2000 firmware package. Compared to previous versions, this new firmware provides numerous extensions and improvements. The new features described in this manual are listed below.

New Features	Description	Refer to...
Non Signalling measurements	The <i>Modulation, Spectrum, and Code Domain Power</i> measurement is also available in <i>Non Signalling</i> mode.	Chapter 4, CDMA Module Tests (Non Signalling) → Modulation Measurements → Spectrum Measurements → Code Domain Power Measurements
Authentication for simple IP connections	The maximum string length for the <i>Username</i> and the <i>Password</i> used in the PPP authentication algorithm has been extended to 72 characters.	Chapter 8, CDMA 2000 Data Testing → Packet Data Service Configuration
MIP authentication	Authentication for Mobile IP connections according to the standards RFC 2002 or RFC 2002bis, <i>IP Mobility Support</i> .	Chapter 8, CDMA 2000 Data Testing → Packet Data Service Configuration
TCP/IP settings	TCP/IP settings for R&S CMU-B83 are accessible from the <i>Setup</i> menu (R&S CMU200 base system parameters)	Operating manual for R&S CMU200/300

Frequently Used Abbreviations

3GPP2	3 rd Generation Partnership Project 2
Abs.	Absolute
Avg.	Average
AWGN	Additive White Gaussian Noise
CDMA	Code Division Multiple Access
CDP	Code Domain Power
Chan.	Channel
Channel.	Channelization
CRC	Cyclic Redundancy Code
Curr.	Current
DHCP	Dynamic Host Configuration Protocol
Disp.	Display
EIRP	Effective Isotropic Radiated Power
Err.	Error
ESN	Electronic Serial Number
EVM	Error Vector Magnitude
Ext., Extern.	External
FER	Frame Error Rate
FFT	Fast Fourier Transform
Freq.	Frequency
FTP	File Transfer Protocol
GPIB	General Purpose Interface Bus = IEEE488 Bus
I	In-phase
IF	Intermediate Frequency
Int.	Internal
IP	Internet Protocol
Lev.	Level
Magn.	Magnitude
Max.	Maximum (e.g. Level)
ME	Magnitude Error
Meas.	Measurement
Min.	Minimum
MIP	Mobile IP
OCNS	Orthogonal Channel Noise Simulator
OVSF	Orthogonal Variable Spreading Factor
Ovw	Overview
PCS	Personal Communications Services
PCDE	Peak Code Domain Error
PDSN	Packet Data Service Node
PE	Phase Error
Pk.	Peak
PPP	Point-to-Point Protocol
Q	Quadrature-phase
QPSK	Quadrature Phase Shift Keying
RBW	Resolution Bandwidth
Ref.	Reference
Rel.	Relative
RF	Radio Frequency
RLP	Radio Link Protocol Type 3
RMS	Root Mean Square
RX	Receiver
Scr.	Scrambling
SW	Software
Sym.	Symbol
Sync.	Synchronous
Synch.	Synchronization
TCP/IP	Transmission Control Protocol/Internet Protocol
Trg.	Trigger
TX	Transmitter
Vect.	Vector

Glossary of Terms

The following list contains definitions of terms that are often used throughout this manual.

Access Channel	A reverse communication channel used by a mobile station to communicate to a base station.
Carrier Feedthrough	Ratio of the I/Q offset vector (i.e. the estimated DC offset of the measured signal) to the average offset-corrected signal vector.
Carrier frequency error	Deviation of the mobile's modulated carrier frequency from the frequency received from the base station.
Chip rate	Product of the symbol rate and the spreading factor. For the 3GPP2 CDMA2000 1X system a fixed chip rate of 1.2288 Mcps is specified.
Code domain	The entire set of channelization codes involved in a CDMA2000 signal configuration. Measuring a parameter in code domain means to determine its values as a function of the individual channelization codes.
Code domain error	Ratio of the RMS-averaged power of the error vector projected onto the code domain to the RMS-averaged power of the composite reference signal, expressed in dB.
Code domain power	Power in the individual code channels normalized to the power of the composite signal, expressed in dB.
Crest factor	Peak to average ratio: ratio of the peak transmit power in a slot (peak envelope power) to the average transmit power in a slot.
Cyclic Redundancy Code (CRC)	A class of linear error detecting codes which generate parity check bits by finding the remainder of a polynomial division.
E_b	Average energy per information bit for the Sync Channel, Paging Channel, or Forward Traffic Channel at the mobile station antenna connector.
E_b/N_t	The ratio of the combined received energy per bit to the effective noise power spectral density for the Sync Channel, Paging Channel, or Forward Traffic Channel at the mobile station antenna connector.
Error vector magnitude	Difference vector connecting the measured and the ideal modulated signal vector. The error vector magnitude (EVM) is the critical quantity to assess the modulation accuracy of the mobile's transmitter.
I/Q imbalance	Difference between the estimated I and Q amplitudes of the measured signal, normalized and expressed in dB units.
Magnitude error	Difference in magnitude between the measured and the ideal modulated signal vector, normalized to the magnitude of the ideal vector.
Maximum power	Operating mode where the mobile is set to its maximum power control level.
Minimum power	Operating mode where the mobile is set to its minimum power control level.
Modulation accuracy	Ability of the mobile's transmitter to generate an ideally modulated signal.
N_t	The effective noise power spectral density at the mobile station antenna connector.
Paging channel	A forward communication channel used by a base station to communication to a mobile station when it is not assigned to a traffic channel.
Peak code domain error	Maximum of the <i>code domain errors</i> for all codes in the domain, expressed in dB.
Phase error	Difference in phase between the measured and the ideal modulated signal vector.

Power control bit	A bit sent in every 1.25 ms interval on the Forward Traffic Channel to signal the mobile station to increase or decrease its transmit power.
Power control group	A 1.25 ms interval on the Forward Traffic Channel and the Reverse Traffic Channel. See also Power Control Bit.
Waveform quality	Normalized correlated power between the actual and the ideal waveform, sampled at the constellation points. The waveform quality (ρ factor) is a measure of the modulation accuracy. For an ideal transmitter (ideal correlation), it is equal to 1, otherwise it is a positive number smaller than 1.

References

- TIA/EIA/IS-2000.1-A, *Introduction to cdma2000 Standards for Spread Spectrum Systems*, March, 2000.
- TIA/EIA/IS-2000.2-A, *Physical Layer Standard for cdma2000 Spread Spectrum Systems*, March, 2000.
- TIA/EIA/IS-2000.3-A, *Medium Access Control (MAC) Standard for cdma2000 Spread Spectrum Systems*, March, 2000.
- TIA/EIA/IS-2000.4-A, *Signaling Link Access Control (LAC) Standard for cdma2000 Spread Spectrum Systems*, March, 2000.
- TIA/EIA/IS-2000.5-A, *Upper Layer (Layer 3) Signaling Standard for cdma2000 Spread Spectrum Systems*, March, 2000.
- TIA/EIA/IS-2000.6-A, *Analog Signaling Standard for cdma2000 Spread Spectrum Systems*, March, 2000.
- TIA/EIA-126-B, *Mobile Station Loopback Service Options Standard*, August, 1998.
- TIA/EIA/IS-707-A, *Data Service Options for Wideband Spread Spectrum Systems*, April, 1999.
- TIA/EIA/IS-707-A-1, *Data Service Options for Wideband Spread Spectrum Systems – Addendum 1*, January, 2000.
- TIA/IS-707-A-3, *Data Service Options for Wideband Spread Spectrum Systems – Addendum 3*, February, 2003.
- 3GPP2 C.S0031-0, *Signaling Conformance Tests for cdma2000 Spread Spectrum Systems*, July, 2001
- Application Note 1MA34_0E: "Generating and Analyzing cdma2000 Signals: Solutions from Rohde & Schwarz"
- Application Note 1CM51: "Packet Data Testing"

Supplement to the Operating Manual for CDMA2000 Software Options

New Features in Version V3.85 of Options R&S CMU-K83/-K84/-K85/-K86 (with Base System V3.85)

Smart Alignment, RX/TX Frequency Coupling, Home Agent Secret

Dear CMU Customer,

With the new software version V3.85 of options R&S CMU-K83/-K84/-K85/-K86, *CDMA2000 for R&S CMU-B83*, the Universal Radio Communication Tester R&S CMU 200 offers an extended measurement functionality that could not be reported yet in the current revision of the operating manual, 1150.0382.12-07-. The following pages are to provide you with comprehensive information about the new features.

Table of Contents

Smart Alignment	2
Test Procedures.....	2
Example for TX Calibration.....	2
Example for RX Calibration	4
TX Calibration Results	6
Smart Alignment Configuration	7
Remote Control Commands	9
Measurement Control	9
Subsystem POWER:SALignment:CONTRol	10
Subsystem POWER:SALignment?.....	13
Rx/Tx Frequency Coupling	14
Home Agent Secret	15

Smart Alignment

Smart Alignment (option R&S CMU-K47) is a supplementary software option extending the CDMA2000-MS network test options. The option has been designed for fast mobile transmitter and receiver adjustments (TX and RX calibrations) over a wide range of channels and powers. To enable parallel mobile transmitter and receiver tests, the R&S CMU can simultaneously change its generator and analyzer settings after equal time periods (step widths) of 2 ms to 40 ms. The default step width of 20 ms corresponds to a typical CDMA2000 frame length.

Smart Alignment is an application of the *Power* measurement group. All test settings can be defined in the *Control* tab of the *Power Configuration* menu.

- For a TX calibration, the analyzer frequency and maximum input power of the R&S CMU is set in accordance with the expected TX frequencies and powers of the mobile under test. The R&S CMU provides a table of measured average powers.
- For an RX calibration the R&S CMU generates a CDMA2000 RF test signal with definite frequencies and powers, to be compared with the power measured at the mobile receiver.

Smart Alignment is available in *Non Signalling* mode. With the minimum step width of 2 ms, it is possible to perform the entire test procedure for the mobile transmit and receive power adjustment at 320 different level/frequency pairs in approx. 2/3 s.



Smart Alignment is also available for GSM-MS and WCDMA UE measurements. For details refer to the relevant manuals.

Test Procedures

The *Power* menu provides all test settings for option *Smart Alignment* and displays the TX calibration results. To achieve maximum speed the TX and RX calibrations are configured in the same menu and preferably performed in parallel, however, it is also possible to switch off the RF generator while carrying out a TX calibration. The following examples show how to perform an TX calibration and an RX calibration separately.

Example for TX Calibration

For a TX calibration the R&S CMU measures the mobile output power in a series of configurable time periods. The measurement is typically performed with an *RF Power* or *IF Power* trigger. *Free Run* is not a suitable trigger configuration for this measurement. Moreover the expected RF input level should be set manually (*Analyzer Level – RF Mode: Manual*).

Measurement task Verify the transmitter output power of a CDMA2000 mobile phone in the output power range between 0 dBm and + 20 dBm and in the first 12 reverse channels of the US cellular network (825.030 MHz to 825.360 MHz). Use a 10 ms time period for each single power measurement.

Mobile Configuration

1. Stimulate the mobile transmitter to change its power periodically as shown in Fig. 1 below. Start power: 0 dBm; increment: 2 dBm; DTX frame after the mobile has reached +20 dBm (each 12th frame).
2. Ensure that the mobile changes its frequency after each sequence of power steps, using the 12 different uplink channels no 1 (825.030 MHz), 2 (825.060 MHz), ..., 12 (825.360 MHz).




Fig. 1 TX calibration: mobile power settings

R&S CMU Settings

3. In the *Menu Select* menu, select the CDMA2000 Cellular network and the measurement menu *Non Signalling – Power – Smart Alignment*. Press *RESET* to set the instrument to a defined state. Press *ENTER CONT/HALT* to set the measurement to the *HLT* state and eliminate the *Trigger not found !* message.
4. Press *Analyzer Lvl. – RF Mode* and select *Manual* to enable manual RF input level setting.
5. Press *Analyzer Lvl. – RF Max. Level* and select *+5 dB* to adjust the RF analyzer to the initial input level from the mobile, allowing for an appropriate margin.
6. Press the measurement control softkey *Smart Alignment* twice to open the *Power Configuration* menu. In the *Control* tab, expand the *Smart Alignment* section and define the *Step Width*, the *Step Count*, and then the list of *RF Analyzer Max. Levels* in accordance with the 11 power steps of your mobile signal.

For a total dynamic range of 20 dB, two different *RF Analyzer Max. Level* settings are sufficient, e.g.:

▼Power	
Step Width	10,000 ms
Step Count	11
▼Power List	
Step 1	- 93.0 dBm
Step 2	- 33.0 dBm
Step 3	- 36.0 dBm
Step 4	- 39.0 dBm
Step 5	- 42.0 dBm
Step 6	- 45.0 dBm
Step 7	- 48.0 dBm
Step 8	- 51.0 dBm
Step 9	- 54.0 dBm
	RF Analyzer Max. Level
	+ 12.0 dBm
	+ 12.0 dBm
	+ 12.0 dBm
	+ 12.0 dBm
	+ 12.0 dBm
	+ 22.0 dBm
	+ 22.0 dBm
	+ 22.0 dBm

The first, non-editable *RF Analyzer Max. Level* is given by the common *RF Max. Level* defined in step 4.

7. Press *Analyzer Settings – RF Frequency* and select 825.030 MHz to adjust the RF analyzer to the initial frequency of the mobile signal.
8. Expand the *Frequency* section, select a *Sequence Count* of 12, and verify that the *RF Analyzer* frequencies are in accordance with the frequency sequence of your mobile.

▼Frequency			
Sequence Count	1		
Frequency Unit	MHz		
▼Frequency List	RF Generator		RF Analyzer
Sequence 1	870.030 MHz		825.030 MHz
Sequence 2	870.060 MHz		825.060 MHz
Sequence 3	870.090 MHz		825.090 MHz
Sequence 4	870.120 MHz		825.120 MHz
Sequence 5	870.150 MHz		825.150 MHz
Sequence 6	870.180 MHz		825.180 MHz
Sequence 7	870.210 MHz		825.210 MHz
Sequence 8	870.240 MHz		825.240 MHz
Sequence 9	870.270 MHz		825.270 MHz

The first, non-editable *RF Analyzer* frequency is given by the common analyzer frequency defined in step 7.

9. Press Smart Alignment again to close the Power Configuration menu.
10. Press Analyzer Lvl. / Trigger twice and select Trigger Source – IF Power.
11. Start the *Smart Alignment* measurement (*Smart Alignment – ENTER CONT/HALT*), connect the mobile to the RF2 connector of the CMU and switch on.

The measurement starts as soon as the R&S CMU detects the first power step of the mobile signal. The results for all power steps and frequencies are displayed in the output table; see section [TX Calibration Results](#) on p. 6 ff.



Define an external input attenuation (Connection Control – Ext. Att. Input for RF2 or Frequency Dependent Attenuation) to compensate for a known attenuation in the signal path from the mobile antenna connector to the R&S CMU input.

Example for RX Calibration

For an RX calibration the R&S CMU generates an RF test signal with definite frequencies and powers, to be compared with the power measured at the mobile receiver. The characteristics of the generated signal, in particular the modulated bits, are according the settings in the *Generator* tab of the *Connection Control* menu.

Both the RF generator and the *Smart Alignment* measurement must be running (*ON, RUN*) in order to generate the test signal. In addition, a suitable trigger configuration (*IF Power, RF Power*) is needed.

Measurement task Verify the receiver power adjustment of a CDMA2000 mobile in the power range between –50 dBm and –30.0 dBm and in the first 12 forward channels of the US cellular network (870.030 MHz to 870.360 MHz). Use a 10 ms time period for each single power measurement.

- Test signal configuration**
1. In the *Menu Select* menu, select the CDMA2000 Cellular network and the measurement menu *Non Signalling – Power – Smart Alignment*. Press *RESET* to set the instrument to a defined state. Verify that the measurement is switched on (*RUN*).
 2. Press *Analyzer Level / Trg* twice and select *Trigger Source – IF Power*.
 3. Open the *Generator* tab of the *Connection Control* menu. Switch the generator on and select an initial *CDMA Power*) of –50 dBm:



4. Close the Connection Control menu.
5. Press the measurement control softkey *Smart Alignment* twice to open the *Power Configuration* menu. In the *Control* tab, expand the *Smart Alignment* section and define the *Step Width*, the *Step Count*, and then the list of *Output Powers* as shown below:

▼Power		
Step Width	20.000 ms	
Step Count	11	
▼Power List		
	Output Power	RF Analyzer Max. Level
Step 1	- 50.0 dBm	+ 0.0 dBm
Step 2	- 48.0 dBm	- 10.0 dBm
Step 3	- 46.0 dBm	- 10.0 dBm
Step 4	- 44.0 dBm	- 10.0 dBm
Step 5	- 42.0 dBm	- 10.0 dBm
Step 6	- 40.0 dBm	- 20.0 dBm
Step 7	- 38.0 dBm	- 20.0 dBm
Step 8	- 36.0 dBm	- 20.0 dBm
Step 9	- 34.0 dBm	- 20.0 dBm

The first, non-editable *Output Power* is given by the *Output Ch. Power (TX)* defined in step 2.

6. Press *Generator Set. – RF Frequency* and select 870.030 MHz as the initial frequency of the generator signal.
7. Expand the *Frequency* section, select a *Sequence Count* of 12, and verify that the *RF Generator* frequencies correspond to the first 12 forward link channels.

▼Frequency List		
	RF Generator	RF Analyzer
Sequence 1	870.030 MHz	825.030 MHz
Sequence 2	870.060 MHz	825.060 MHz
Sequence 3	870.090 MHz	825.090 MHz
Sequence 4	870.120 MHz	825.120 MHz
Sequence 5	870.150 MHz	825.150 MHz
Sequence 6	870.180 MHz	825.180 MHz
Sequence 7	870.210 MHz	825.210 MHz
Sequence 8	870.240 MHz	825.240 MHz
Sequence 9	870.270 MHz	825.270 MHz
Sequence 10	870.300 MHz	825.300 MHz
Sequence 11	870.330 MHz	825.330 MHz
Sequence 12	870.360 MHz	825.360 MHz

The first, non-editable *RF Generator* frequency is given by the common generator frequency defined via *Generator Settings – RF (TX) Frequency*. The generated power step sequence is analogous to Fig. 1 on p. 3 ff.

8. Connect the mobile to the RF2 connector of the R&S CMU and switch it on.

After the mobile has received the entire power step sequence you can perform the receiver calibration by comparing the RF generator powers to the received power spectral density \hat{I}_{or} measured by the mobile.



Define an external output attenuation (Connection Control – Ext. Att. Output for RF2 or Frequency Dependent Attenuation) to increase the RF generator level in order to compensate for a known attenuation in the signal path from the R&S CMU output to the mobile receiver input.

TX Calibration Results

While the *Smart Alignment* application is running, the table in the *Power* menu shows a sequence of reverse link signal powers measured according to the analyzer settings in the *Power Configuration* menu (see section *Smart Alignment Configuration* on p. 7 ff.).

Sequence ↓ / Step →	Step (RF Max. Level) * RF Max. Level Deviation Step				
	1 (0.0 dBm)	2 (0.0 dBm)	3 (15.0 dBm)	4 (15.0 dBm)	5 (15.0 dBm)
1 (825.030 MHz)	-20.1	-15.1	-10.1	-5.0	0.0
2 (825.060 MHz)	-20.1	-15.1	-10.1	-5.0	0.1
3 (825.090 MHz)	-20.0	-15.1	-10.1	-5.0	0.1
4 (825.120 MHz)	-20.1	-15.1	-10.1	-5.0	0.1
5 (825.150 MHz)	-20.0	-15.0	-10.1	-5.0	0.1
6 (825.180 MHz)	-20.0	-15.0	-10.1	-4.9	0.1
7 (825.210 MHz)	-20.0	-15.0	-10.1	-4.9	0.1
8 (825.240 MHz)	-20.0	-15.0	-10.0	-4.9	0.1
9 (825.270 MHz)	-19.9	-14.9	-10.0	-4.9	0.1
10 (825.300 MHz)	-19.9	-14.9	-10.0	-4.9	0.1
11 (825.330 MHz)	---	---	---	---	---
12 (825.360 MHz)	---	---	---	---	---
13 (825.390 MHz)	---	---	---	---	---

Fig. 2 Display of results (Power – Smart Alignment)

Power results

The *Smart Alignment* application measures the average burst power in up to 20 consecutive power steps of configurable width and at up to 16 different frequencies, so that up to 320 results are obtained in each measurement cycle. The average is always taken over the central section of the power step. The averaging length is always half the step width.




Fig. 3 Averaging length

The table size depends on the RF analyzer settings:

- Each table row contains a series of different power steps at constant frequency. The number of columns is equal to the *Step Count* defined in the configuration menu.
- Each table column contains a definite power step at different frequencies. The number of rows is equal to the *Sequence Count* defined in the configuration menu. A blue asterisk on top of a column indicates a change of the RF max. level setting¹.

¹ The level uncertainty of the RF analyzer quoted in the data sheet is valid irrespective of a change of the RF max. level. At constant RF max. level settings, the relative power steps can be measured much more accurately, so it is advantageous to avoid frequent changes of the RF max. level (see also *Example for TX Calibration* on p. 2 ff.).

The measurement results are obtained row by row. The time period after the last power step in each series of power steps is skipped; it provides the necessary settling time after the mobile transmitter hops to the next frequency.

In continuous measurements, the results are only updated after a new set of valid results is available. “---“ indicates an invalid result, “Off” an overflow, which can be avoided by adjusting the maximum expected input level (*Analyzer Level – RF Max. Level* and max. level settings in the configuration menu). *Off* indicates that no result is available because the step count or sequence count is below its maximum value.

For more than 5 power steps or more than 13 different measured frequencies, the table can be scrolled using the cursor keys. No limit check is performed.

Remote control

```
READ[ :SCALar ]:POWer:SALignment?
FETCh[ :SCALar ]:POWer:SALignment?
SAMPle[ :SCALar ]:POWer:SALignment?
```

Smart Alignment Configuration

The power steps and frequencies for the *Smart Alignment* measurement are defined in the *Control* tab of the *Connection Control* menu.




Fig. 4 Power Configuration – Control

Smart Alignment The *Repetition* parameter defines how often the measurement is repeated:

- **Repetition**
 - Single Shot* The measurement is stopped (*HLT*) after the entire frequency list has been measured.
 - Continuous* The measurement is repeated until it is terminated explicitly using the *ON/OFF* key. In the measurement menu, the results are only updated after a new set of valid results is available.

Remote control

```
CONFigure:POWer:SALignment:CONTRol:REPetition
CONTinuous | SINGleshot | 1 ... 10000, NONE, <Stepmode>
```

The parameters for TX and RX calibration are located in common sections. The meaning of the power and frequency settings for a typical sequence of test steps is described in Fig. 5 below. The total measurement time is equal to $T = \langle \text{Step Width} \rangle * (\langle \text{Step Count} \rangle + 1) * \langle \text{Sequence Count} \rangle$.




Fig. 5 Smart Alignment – power and frequency settings

Smart Alignment – **Power** The *Power* section provides the settings for a single power step cycle at fixed frequency.

- Step Width** Duration of each TX or RX power step. The step width has an impact on the averaging length for the TX calibration measurement; see Fig. 3 on p. 6.
- Step Count** Number of power steps per cycle. The length of the power list is automatically adjusted to the step count.
- Power List** Total RF generator power (*Output Power*) for each power step and expected Max. Level from the mobile. The first, non-editable values are given by the common total generator output power (*Generator Level – CDMA Power*) and the common maximum RF level (*Analyzer Level – RF Max. Level*), respectively. Auto-ranging (*Analyzer Level – RF Mode: Auto*) should be disabled while a *Smart Alignment* measurement is running.



A reduction of the RF Analyzer Max. Level across -10 dBm (RF1), -24 dBm (RF2), or -49 dBm (RF4 IN) is likely to cause an invalid result in the following power step. A fixed (not frequency-dependent) external attenuation shifts the limits quoted above (e.g. RF2 and +14 dB external attenuation → limit at -24 dBm + 14 dB = -10 dBm).

Remote control

```
CONFigure:POWer:SALignment:CONTRol:SWIDth
CONFigure:POWer:SALignment:CONTRol:SCOUNt
CONFigure:POWer:SALignment:CONTRol:STEP<nr>
```

Smart Alignment – **Frequency** The *Frequency* section defines the frequencies of the repeated power step cycles. The frequencies can be set in multiples of 1 kHz; they don't have to coincide with CDMA2000 channel frequencies.

- Sequence Count** Number of power step cycles per single shot measurement. The length of the frequency list is automatically adjusted to the sequence count.
- Frequency Unit** Entry of RF frequencies in MHz or CDMA2000 channel numbers.
- Frequency List** RF frequency or channel for the generated DL signal (*RF Generator*) and expected RF frequency or channel from the mobile (*RF Analyzer*). The first, non-editable values are given by the common generator frequency (*Generator Set. – RF Frequency*)

and the common analyzer frequency (*Analyzer Settings – RF Frequency*), respectively.

Remote control

CONFigure:POWer:SALignment:CONTrol:SQCOunt
 CONFigure:POWer:SALignment:CONTrol:SQUence:UNIT
 CONFigure:POWer:SALignment:CONTrol:SQUence

Remote Control Commands

The following sections describe the remote control commands for option R&S CMU-K47; *Smart Alignment*.

Measurement Control

The following commands control the *Smart Alignment* measurement. They correspond to the measurement control softkey *Smart Alignment* in the *Power* menu.

Note: The *POWer:SALignment...* measurement is typically performed with an RF Power or IF Power trigger. Free Run is not a suitable trigger configuration for this measurement (see *TRIGger[:SEquence]:SOURCE*).

INITiate:POWer:SALignment	Start new measurement	⇒ <i>RUN</i>
ABORt:POWer:SALignment	Abort running measurement and switch off	⇒ <i>OFF</i>
STOP:POWer:SALignment	Stop measurement after current stat. cycle	⇒ <i>STOP</i>
CONTinue:POWer:SALignment	Next measurement step (only <i>stepping mode</i>)	⇒ <i>RUN</i>
Description of command		FW vers.
These commands have no query form. They start or stop the measurement, setting it to the status indicated in the top right column.		V3.85

CONFigure:POWer:SALignment:EREPorting <Mode>		Event Reporting		
<Mode>	Description of parameters	Def. value	Def. unit	FW vers.
SRQ 	Service request	OFF	–	V3.85
SOPC 	Single operation complete			
SRSQ 	SRQ and SOPC			
OFF	No reporting			
Description of command				
This command defines the events generated when the measurement is terminated or stopped (<i>event reporting</i> , see chapter 5 of CMU operating manual).				

FETCh[:SCALAr]:POWer:SALignment:STATus?		Measurement Status		
Return	Description of parameters	Def. value	Def. unit	FW vers.
OFF 	Measurement in the <i>OFF</i> state (*RST or ABORT)	OFF	–	V3.85
RUN 	Running (after INITiate, CONTinue or READ)			
STOP 	Stopped (STOP)			
ERR 	<i>OFF</i> (could not be started)			
STEP 	Stepping mode (<stepmode>=STEP)	NONE	–	
RDY,	Stopped according to repetition mode and stop condition			
1 to 10000 	Counter for current statistics cycle			
NONE	No counting mode set			
Description of command				
This command is always a query. It returns the status of the measurement (see chapters 3 and 5 of the CMU 200/300 manual).				

Subsystem POWer:SALignment:CONTrol

The subsystem *POWer:SALignment:CONTrol* defines the scope of the measurement, the generated and the measured power steps and frequencies. The settings are located in the *Control* tab of the *Power Configuration* menu.

DEFault:POWer:SALignment:CONTrol <Enable>		Default Settings		
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON 	The parameters are set to their default values	ON	–	V3.85
OFF	Some or all parameters are not set to default			
Description of command				
If used as a setting command with the parameter <i>ON</i> this command sets all parameters of the subsystem to their default values (the setting <i>OFF</i> causes an error message). If used as a query the command returns whether all parameters are set to their default values (<i>ON</i>) or not (<i>OFF</i>).				

CONFigure:POWer:SALignment:CONTRol:REPetition <Repetition>,<StopCondition>,<Stepmode>				Test Cycle
<Repetition>	Description of parameters	Def. value	Def. unit	
CONTInuous 	Continuous measurement (continuous, until STOP or ABORT)	SING	–	
SINGleshot 	Single measurement (single shot, until Status = RDY)			
1 to 10000,	Multiple measurement (counting, until Status = STEP RDY)			
<StopCond>	Description of parameters	Def. value	Def. unit	
NONE,	No limit check, no stop condition available	NONE	–	
<Stepmode>	Description of parameters	Def. value	Def. unit	FW vers.
STEP 	Interrupt measurement after each statistics cycle	NONE	–	V3.85
NONE	Continue measurement according to its rep. mode			
Description of command				
This command determines the number of statistics cycles and the stepping mode for the measurement.				
Note: The <Repetition> parameter has no effect on READ: ... commands, where the measurement is always stopped after a single shot.				

CONFigure:POWer:SALignment:CONTRol:SWIDth <Step Width>				Step Width
<Step Width>	Description of parameters	Def. value	Def. unit	FW vers.
0.002 s to 0.040 s	Step width	0.020	s	V3.85
Description of command				
This command defines the duration of each TX or RX power step.				

CONFigure:POWer:SALignment:CONTRol:SCOut <Step Count>				Step Count
<Step Count>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 20	Step count	5	–	V3.85
Description of command				
This command defines the number of power steps per cycle.				

CONFigure:POWer:SALignment:CONTRol:STEP<nr> <Output Power>, <Max. Level>		Power List		
<Output Power>	Description of parameters	Def. value	Def. unit	FW vers.
-120.0 dBm to -33.0 dBm -120.0 dBm to -16.0 dBm -100.0 dBm to 7.0 dBm	Output power <nr> if RF 1 is used Output power <nr> if RF 2 is used Output power <nr> if RF 3 OUT is used	See below	dBm	V3.85
<Max. Level>	Description of parameters	Def. value	Def. unit	FW vers.
-43.0 dBm to +44.0 dBm -57.0 dBm to +30.0 dBm -80.0 dBm to +9.0 dBm	Maximum input level <nr> for RF 1 Maximum input level <nr> for RF 2 Maximum input level <nr> for RF 4 IN	See below	dBm	V3.85
Description of command				
<p>This command defines a pair of generator power and max. level values numbered by the numeric suffix <nr> (<nr> = 2 to 20). The first power pair (<nr> = 1) is given by the common generator power and maximum input level (SOURce:RFGenerator:OPower, [SENSe:]LEVel:MAXimum) and can be queried only. Powers with a numeric suffix that exceeds the step count (CONFigure:POWer:SALignment:CONTRol:SCount) are configurable but not measured.</p> <p>The powers must be multiples of 0.1 dB. The default generator powers read</p> $p_{1, def}^{Gen} = -70 \text{ dBm}; \quad p_{<nr>, def}^{Gen} = -27 \text{ dBm} - 3 \cdot <nr> \text{ dB}; \quad <nr> = 2 \text{ to } 20.$ <p>The default max. levels read</p> $p_{1, def}^{An} = 0 \text{ dBm}; \quad p_{<nr>, def}^{An} = 10 \cdot \text{Int}\left(\frac{<nr> + 4}{5}\right) \text{ dBm}; \quad <nr> = 2 \text{ to } 20.$				

CONFigure:POWer:SALignment:CONTRol:SQCount <Sequence Count>		Sequence Count		
<Step Count>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 16	Sequence count	10	-	V3.85
Description of command				
This command defines the number of power step cycles per single shot measurement.				

CONFigure:POWer:SALignment:CONTRol:SQUence:UNIT <Frequency Unit>		Frequency Unit		
<Step Count>	Description of parameters	Def. value	Def. unit	FW vers.
MHZ CH	Entry of frequencies in MHz Entry of CDMA2000 channel numbers	MHZ	-	V3.85
Description of command				
This command defines the unit for the values in the frequency list (CONFigure:POWer:SALignment:CONTRol :SQUence).				

CONFigure:POWer:SALignment:CONTRol:SQUence<nr> <Generator Freq.>, <Analyzer Freq.>		Frequency List		
<Generator Freq.>	Description of parameters	Def. value	Def. unit	FW vers.
10.000 MHz to 2700.000 MHz,	Generator frequency <nr>	See below	MHz	V3.85
<Analyzer Freq.>	Description of parameters	Def. value	Def. unit	FW vers.
15.000 MHz to 2700.000 MHz	Analyzer frequency <nr>	See below	MHz	V3.85
Description of command				
<p>This command defines a pair of generator and analyzer frequencies numbered by the numeric suffix <nr> (<nr> = 2 to 16). The first frequency pair (<nr> = 1) is given by the common generator and analyzer frequencies (SOURCE:RFGenerator:FREQUENCY[:RF], [SENSe:]RFANalyzer:FREQUENCY) and can be queried only. Frequencies with a numeric suffix that exceeds the sequence count (CONFigure:POWer:SALignment :CONTRol:SQCount) are configurable but not measured.</p> <p>The frequencies must be multiples of 1 kHz. The default generator frequencies read</p> $f_{<nr>, def}^{Gen} = 870.030 \text{ MHz} + 5 \cdot (<nr> - 1) \text{ MHz}; \quad <nr> = 2 \text{ to } 16.$ <p>The default analyzer frequencies read</p> $f_{<nr>, def}^{An} = 825.030 \text{ MHz} + 5 \cdot (<nr> - 1) \text{ MHz}; \quad <nr> = 2 \text{ to } 16.$				

Subsystem POWER:SALignment?

The subsystem *POWER:SALignment* measures power versus slot and returns the results. The subsystem corresponds to the output table in the *Smart Alignment* measurement menu.

		Smart Alignment Results		
READ[:SCALar]:POWer:SALignment?	Start single shot measurement and return results			
FETCh[:SCALar]:POWer:SALignment?	Read out measurement results (unsynchronized)			
SAMPlE[:SCALar]:POWer:SALignment?	Read out measurement results (synchronized)			
Returned Values	Description of parameters	Def. value	Def. unit	FW vers.
-100 dBm to +60 dBm OFF	Avg. power in time period no. 1	NAN	dBm	V3.85
...	...			
-100 dBm to +60 dBm OFF	Avg. power in time period no. N	NAN	dBm	
Description of command				
<p>These commands are always queries. They start a measurement (READ...) and/or return the average power in all time periods. The number of results is $N = 20 \cdot <Sequence\ Count>$ (CONFigure:POWer:SALignment :CONTRol:SQCount). OFF indicates that no result is available because the step count is below its maximum value.</p>				

Rx/Tx Frequency Coupling

In *Non Signalling* mode, it is possible to couple the RF analyzer (Rx) and generator (Tx) frequencies of the R&S CMU. Coupling the frequencies means that the *RF Channel [BC0]* numbers in the *Analyzer* and in the *Generator* tab of the *Connection Control* menu are always equal.

Rx/Tx Frequency Coupling is controlled in the *Misc.* tab of the *Connection Control* menu. If coupling is enabled while the Rx and Tx channels are different, the RF analyzer (Rx) channel is adjusted.




Fig. 6 Rx/Tx Frequency Coupling

CONFIGure:FREQ:COUPLing:RXTX <Enable>		Rx/Tx Frequency Coupling		
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	Enable or disable coupling	OFF	–	V3.85
Description of command				
This command enables or disables Rx/Tx Frequency Coupling. If coupling is enabled while the Rx channels ([SENSe:]RFANalyzer:FREQuency) and Tx channels (SOURce:RFGenerator:FREQuency[:RF]) are different, the RF analyzer (Rx) channel is adjusted.				

Home Agent Secret

The maximum string length for the *MS Node Home Agent Secret* has been extended to 20 characters.

CONFigure:SCONfig:SCLass1:PDAT:S33D:MIP:HASecret				MS Node Home Agent Secret
<Secret>				
<Secret>	Description of parameters	Def. value	Def. unit	FW vers.
'<max 20 characters>'	0 to 255	'cmu'	–	V3.60
Description of command				Sig. State
This command defines the secret used by the R&S CMU to do Mobile IP MD5 authentication in MIP stand alone mode.				All

Contents

1	Introduction	1.1
	Installation Instructions	1.1
	Software Installation or Update	1.2
	Creating a new Software Configuration	1.5
	Enabling Software Options	1.7

1 Introduction

This chapter describes the installation and update of software options for the Universal Radio Communication Tester R&S CMU 200.

Table 1-1 lists the CDMA2000 networks supported when the hardware and software options are installed to support CDMA2000 functionality.

Table 1-1 CDMA networks supported

CMU Options for CDMA	Band Class	Network
CMU-K83 450 MHz	Band Class 5	NMT-450
CMU-K84 Cellular	Band Class 0	US and Korean Cellular
	Band Class 2	TACS
	Band Class 3	JTACS
	Band Class 7	North American 700 MHz
	Band Class 9	900 MHz
CMU-K85 PCS	Band Class 10	Secondary 800 MHz
	Band Class 1	North American PCS
	Band Class 4	Korean PCS
CMU-K86 IMT-2000	Band Class 8	1800 MHz
	Band Class 6	IMT-2000

Installation Instructions

Before performing any of the steps described in this manual, please make sure that the instrument is properly connected and put into operation according to the instructions given in chapter 1 of the CMU Operating manual. The hardware and software options available are shown in the *Startup* menu. The Hardware Option entry "CMU-B83" indicates the status of the hardware option required for CDMA2000 (Code Division Multiple Access) mobile tests. The Software Options entry CMU-K83, CMU-K84, CMU-K85, and/or CMU-K86 indicates the status of the software option required for CDMA2000 mobile tests.

- If version number is indicated, the CMU is ready to perform CDMA2000 mobile tests. In this case you may skip this chapter, except if you wish to update the current software version.
- If disabled is indicated, the software option must be enabled using a key code; see section [Creating a new Software Configuration](#) on page 1.5.
- If not installed is indicated, the software must be installed via the PCMCIA interface or the floppy disk drive.




Figure 1-1 Setup – Options menu

Software Installation or Update


The CMU is always delivered with the latest software version available. New CMU software versions are available for download on the R&S Lotus Notes Service board. To be loaded via the CMU's PCMCIA interface, the software must be copied to one or several flash disks/memory cards or PCMCIA hard disks as explained in the instructions supplied with the software download version. An appropriate memory card CMU-Z1, order no. 1100.7490.02, can be obtained from Rohde & Schwarz.

Note: *If your CMU is equipped with a floppy disk drive (option CMU-U61), a set of installation floppy disks must be generated instead of a flash disk. All other steps do not depend on the storage medium.*

To install the software proceed as follows:

- Switch off the CMU.
- Insert the flash disk into one of the two slots of the PCMCIA interface.
- Switch on the CMU.


The installation is started automatically while the CMU performs its start-up procedure. When ready to proceed, the *VersionManager* is displayed (for a detailed description of the *VersionManager* refer to chapter 1 of the CMU operating manual or to the on-line help accessible via *Info*):



Softkey no. 5 on the left softkey bar, *Install software...*, is used to install new software from an external storage medium. The CMU automatically recognizes the storage medium and indicates the corresponding slot number: Slot 0 or 1 denotes the left or right slot of the PCMCIA interface. If a floppy disk is used, the menu option reads *Install software version <version> from floppy*.


- Press left softkey no. 5 (*Install software...*) to start the installation.

If your storage medium contains several installation versions, the software version selection dialog is opened:



- Use the rotary knob or the cursor keys to scroll the list and select the *Measurements* version you intend to install.
- Press *Install* to start the installation.


The installation is started. To be operable on your instrument, a network option must be combined with a compatible version of the CMU base software. Any base software version installed on the CMU hard disk can be combined with one or several network options to form an independent software configuration. If none of the configurations is compatible to the new *Measurements* option, the *VersionManager* displays an error message and takes you back to the software selection dialog; see section [Creating a new Software Configuration](#) on page 1.5. Otherwise, the following upgrade selection dialog is opened:



The upgrade selection dialog displays a list of base software versions that can be combined with the new *Measurements* software.


- Select the appropriate base version and press *Upgrade*.

The new *Measurements* option is added to the configuration or updates the previous *Measurements* version of the configuration. To indicate that the storage medium must be changed the CMU issues the *Change volume* message:



- Replace the current disk with the disk requested.
- Use the cursor up/down keys to select "Process next volume" (default setting).
- Press *ENTER* to confirm that the new disk has been inserted and to continue the installation.

After processing the last disk the CMU displays the following screen:




- If you wish to install or upgrade other software versions, press left softkey no 4 or 5 (*Install next software...*) or insert new storage medium into the PCMCIA slot or floppy disk drive and press *Change disks*.
- To finish the installation, remove all disks from the drive and press *Finish installation*.

The *VersionManager* is closed and the CMU is rebooted. The new firmware options are now operational and listed in the *Menu Select* menu together with their version number. Besides, the last software configuration installed is automatically taken as the active one in the next measurement session.


Creating a new Software Configuration

The CMU handles base software versions and network options on a separate basis. Different versions of the base software can be combined with different options to create new firmware configurations. For example, it is possible to update the base software without affecting the associated network options or vice versa. Moreover, the same base software version can be installed several times and combined with different network options (and vice versa), so it may enter into several firmware configurations.

If no compatible base software version can be found on the hard disk, then the CMU will refuse to install a new *Measurements* software option selected in the software selection dialog (see previous section). Instead, it displays the following error message:




- Press *Back to installation* to return to the software version selection dialog.



- Select a base software version that is compatible to your *Measurements* software option and press *Install*.

Note: As a rule, firmware versions for the base system and for network options are compatible if they differ only in the last digit. CDMA2000 firmware versions 3.10 to 3.19 (if available) can be run together with base system version 3.10 to 3.19 (if available).


With a new base software version, it is possible to either update an existing configuration or create a new one. A dialog selecting between the two alternatives is opened:



Note: This dialog is skipped if the new base software version is not compatible with any of the existing configurations. An incompatible new base software must be installed as a new base software.

- If you wish to add a new configuration to your hard disk, press *Install as new base*.
- To upgrade an existing configuration with the selected base software version in order to make it compatible to the new *Measurements* software option, press *Upgrade existing version*. The existing version to be upgraded must be selected in an additional dialog.

The installation is performed as described in section [Software Installation or Update](#) on p. 1.1. After adding the new base software as a new configuration or updating the existing configuration, the CMU displays the following screen:



- Press left softkey no 4 or 5 (*Install next software...*) and proceed as described in section [Software Installation or Update](#) on p.1.2. to install the new *Measurements* version and assign it to the new configuration.

Enabling Software Options

A new CMU software option purchased is ready to operate after it is enabled by means of a key code supplied with the option. This key code is to be entered into the *Option Enable* popup window which in turn can be opened via from the *Setup – Options* menu. For details refer to Chapter 4 of the CMU Operating manual.

Note: *The CMU software is delivered in complete versions containing all software options available. Software installation and enabling of software options are completely independent from each other.*

Contents

2 Getting Started	2.1
Connecting a Mobile Phone	2.2
Non-Signalling Mode.....	2.6
Signalling Mode	2.10
Call Setup and Signalling Parameters	2.10
Power Measurements	2.18
Modulation Measurements.....	2.24
Application Example for Power vs Frame	2.26

2 Getting Started

This chapter provides examples of using the CMU Universal Radio Communication Tester to perform tests on an PCS mobile station (CDMA2000). It is intended to provide a quick overview of the CDMA2000 function groups *Non-Signalling* and *Signalling* and their functionality.

NOTE: *The tests and screen shots provided in the manual are based on the CDMA2000 450 function group.*

Before starting any measurements with the CMU, please note the instructions given in Chapter 1 of the CMU Operating manual for putting the instrument into operation. Chapters 2 through 4 of the CMU Operating manual contain information on customizing the instrument and display according to your personal preferences. For instructions about activating the CDMA2000 option, refer to Chapter 1 of this manual.

The procedures in this chapter include:




- Analyzer/Generator operation in *Non-Signalling* mode,
- Connection of the phone and selection of signalling parameters
- Power and modulation measurements in *Signalling* mode.

The left side of each double column page illustrates the steps and results obtained on the CMU screen. The right column of the page provides additional information on each step. If available, alternative settings and related measurements are provided.

Manual operation principles are discussed in Chapter 3. All menus, functions, and parameters (including CDMA background information) are discussed in Chapter 4.

Connecting a Mobile Phone

This chapter describes how to use the CMU to perform CDMA2000 mobile phone tests. Prior to starting any tests, the CMU must be correctly set up and connected to the AC power supply as described in the CMU operating manual. The CDMA option must be enabled as described in chapter 1 of this manual.



Step 1

- Switch on the CMU using the mains switch on the rear panel.
- Check the status of the ON/STANDBY key on the front panel. The yellow LED should be illuminated indicating the CMU is in the standby operating mode.

Step 2

- Connect the bi-directional RF connector RF 2 of the CMU to the antenna connector of the mobile phone (operating in the CDMA cellular network).
- Supply the mobile phone with the correct operating voltage (battery or power supply).
- Turn the mobile phone on.

Step 3

- Press the ON/STANDBY front panel key on the CMU.

The startup menu displays while the CMU performs the power-up tests (see also additional information on p. 2.5).

After the power-up tests are complete, the CMU returns to the last menu used in the previous session.

Additional Information...

... on Step 1

Mains switch on the rear panel

When the mains switch at the rear is set to *OFF*, the instrument is disconnected from the power supply. When the mains switch is set to *ON*, the instrument is in standby mode or in operation, depending on the *ON/STANDBY* key.

ON/STANDBY key on the front panel

The *ON/STANDBY* key determines whether the instrument is in standby mode or in operation.

Standby mode:

Only the reference frequency oscillator is supplied with operating voltage, and the orange LED (*STANDBY*) is illuminated.

Operation:

The green LED (*ON*) is illuminated and all modules of the instrument are supplied with operating voltage.

... on Step 2

RF connection of the mobile phone

A high-quality cable should be used for this connection, ideally with an attenuation of less than 0.5 dB.

Input and output connectors can be selected in the *AF/RF* ↻ tab of the *Connect. Control* menu. The tab is also used to report an external input and output attenuation to the CMU.

Ensure that the attenuation of any antenna coupler and/or cables used is being taken into account by the CMU. During the test, the mobile receiver is being tested with very low RF signal levels, and even a small attenuation can cause the CMU to show a fail indication.


An external signal from a real network may interfere with the signal sent from the CMU to the mobile. The tests should ideally be performed in a shielded room, however, if this is not possible, the channel(s) used for the test should be changed. If different results are obtained on neighboring channels, the problem is likely to be due to external interference.

Alternative Settings and Measurements

☞ Chapter 1 of the CMU operating manual

The CMU provides two bi-directional RF connectors (RF1 and RF2) differing by their input and output levels. RF2 is the recommended connector for CDMA mobile phones.


The unidirectional connectors RF4 IN and RF3 OUT are intended for connecting modules requiring high input levels or modules with low RF output levels. RF4 IN and RF3 OUT can also be used to connect CDMA mobiles off the air via antennas.



Step 4

- Press the *RESET* key to open the *Reset* popup menu.
- Proceed as described in Chapter 4, section *Reset of Instrument Settings*, of the CMU 200/300 operating manual to expand the tree of function groups.
- Select the CDMA2000 function groups corresponding to your mobile type (here: PCS) to be reset. The corresponding nodes must be black.
- Use the cursor keys to activate the *Reset* button and press *ENTER*.
- In the popup window opened (*Are you sure?*), select *Yes* to confirm the instrument reset.

The CMU indicates that it performs a partial reset of the two selected function groups and is then ready to carry out the following steps. The *Reset* popup menu is closed automatically.



Step 5

- Press the *Menu Select* key to open the *Menu Select* menu.

The *Menu Select* menu indicates the function groups available. If a function group is selected, the corresponding modes and measurement menus are indicated.

From this menu, you can choose to operate in either the *Non Signalling* mode or the *Signalling* mode.

The remainder of the chapter is divided into each of these modes.

Additional Information...

... on Step 3

Startup menu

The startup menu displays the following information:

- the status of the startup test (*Process*),
- the device name, serial number and software version (*Info*),
- the options and equipment installed (*Options*),
- the progress of the startup test (*Startup* bar graph).

Before starting a measurement, a reset is recommended to put the CMU in a known operating mode.

... on Step 4


The CMU indicates that it performs a reset of all settings in the selected function group(s). After finishing, the CMU is ready to carry out the remaining steps. The *Reset* popup menu closes automatically.

... on Step 5


Menu Select menu

The *Menu Select* menu shows all function groups installed and enabled on the CMU. Each of the the function groups under the PCS Mobile Station function group is subdivided in the two measurement modes *Non-Signalling* and *Signalling*, each containing measurement menus.

Alternative Settings and Measurements

 Chapter 4 of CMU operating manual


Chapter 4 also contains information on customizing the CMU.

 Chapter 3

Non-Signalling Mode


In the *Non-Signalling* mode, a specific RF signal can be generated and an RF signal with CDMA characteristics analyzed. Compared to the *Signalling* mode test times may be reduced considerably. Moreover, the measurements are not restricted to the specified channel and MS output power ranges of the network. The most common application is module test and test of mobiles in a special *test mode*.

In our example we use the CDMA2000 signal generated by the CMU itself to demonstrate the main features of the *Non Signalling* mode. This is analogous to the *RF* measurement example in the CMU operating manual.



Step 1

- Select a CDMA2000 function group, e.g. *CDMA2000 PCS*.
- Select the *Non-Signalling* mode and expand the list.
- Scroll down to *Analyzer/Generator* and expand the list.
- Scroll down to *ModQual O-QPSK* and press ENTER.
- This displays the *Analyzer/Generator* screen and starts the O-QPSK modulation quality measurement.



Step 2

The *Analyzer/Generator* screen displays the current power and modulation measurement results and the RF generator and analyzer settings of the CMU.

Output fields displaying “---” indicate that no valid measurement results are available. At present no results are available because the CMU receives no RF signal. A yellow message box *Signal too low at connector RF 2* displays across the top of the menu.

- Proceed as outlined in section *RF Non Signalling Measurements*, chapter 2 of CMU200 operating manual to connect RF1 to RF2 via a coax cable. Open the *Connection Control* menu and perform the appropriate RF input and output settings.

Additional Information...

... on Step 2**Analyzer/Generator screen**

The *Analyzer/Generator* screen contains two panels of information:


- Measurement results
- Settings

The status of the *Modulation* measurement is included in the softkey. For ongoing measurements, the results in the output fields are constantly updated.

Changing the RF Channel number automatically adjusts the base station's transmit and receive frequencies (BS Tx Frequency and BS Rx Frequency) to the corresponding RF Channel number.

The *Audio* hotkey displays the measurement screen for making audio measurements. These functions and settings are described in the CMU Operating manual.

Alternative Settings and Measurements


 Chapter 4

The section *CDMA Module Tests* in Chapter 4 of this manual provides detailed information about all measurement settings, measurement results, and a description of all softkey/hotkey menu buttons.

The current options for the measurement state are *RUN* (default) and *OFF*. A third state, *HLT*, occurs after a single-shot measurement.

Once selected, the Generator or Modulation measurement is switched off and on again by means of the toggle key *ON/OFF*.

 CMU Operating manual




Step 3

- Press the *Connect Control* softkey. This displays the Connection Control screen.
- Select the *Generator* tab at the bottom of the display.

The Generator settings allow you to adjust all generator settings and turn the RF Generator on or off.

- Select (press) the *Generator* softkey and press *ON/OFF* to turn on the RF generator.
- Press the *Connect Control* softkey again to return to the measurement screen.



Step 4


- Press the *Analyzer Settings* softkey. This displays a set of hotkeys at the bottom of the screen.

The hotkeys at the bottom of the screen allow you to directly adjust the measurement control settings without opening an additional configuration menu.

- Press the *RF Frequency* softkey and adjust the analyzer frequency to the default generator frequency of 1937.5 MHz.
- If the input signal level at RF2 is still too low, press *Generator Level – CDMA Power* and increase the RF generator level.

Additional Information...**Alternative Settings
and Measurements****... on Step 3**


The *Generator* tab has two screens of settings. Pressing the hotkey toggles the display between the two screens.

 Chapter 4

Additional tabs of the *Connection Control* screen allow the setup and control of other aspects of the CMU. These settings are described in Chapter 4 of this manual.

... on Step 4

After *Reset*, all parameters are set to their default values. The parameters are displayed in the *Settings* window.

 Chapter 4

Additional measurement settings are provided in the *Modulation Configuration* pop-up window. The *Modulation Configuration* pop-up window is accessed by pressing the measurement softkey twice (or once if already selected). In this example, the measurement softkey is labeled *Mod.Qual. O-QPSK*.


User-defined parameters are saved for later sessions when the CMU is switched off.

Signalling Mode

In the Signalling mode the CMU transmits a pilot, sync, and paging channel signal to which the mobile is able to synchronize. A call can then be established from either the CMU or the mobile.



Call Setup and Signalling Parameters

The signalling processes and configurations are controlled via the *Connection Control* popup menu. The *Connection Control* popup menu is automatically displayed when the *Signalling Mode* is selected.



Step 1

- Make sure that your mobile phone is connected to the CMU as described in section Connecting a Mobile Phone on p. 2.2 ff.
- Press the *Menu Select* key to open the *Menu Select* menu.
- Select the function group appropriate for your mobile phone, e.g. CMDA2000 PCS.
- Select the *Signalling* test mode and expand the list.
- Scroll to *Overview* and expand the list.
- Scroll to *Overview O-QPSK*.
- Press the *Enter* key to activate the measurement and display the measurement screen.



The CMU immediately displays the *Connection Control* menu and turns on the registration signal.

Wait for the mobile station to register with the CMU.

Additional Information...**... on Step 1**

Since making measurements requires a connection to a mobile station, the CMU immediately displays the *Connection Control* screen if a connection is not established prior to starting a measurement.

If the automatic display of the Connection Control screen is disabled, the measurement screen is displayed with or without a connection to the mobile. A connection must be established for any measurements to return results.

The default settings are usually appropriate for registration to occur with a properly connected mobile station.


Parameters most likely needing to be set (to match the mobile station) are:


- Network Standard
- BS RF channel
- System ID
- The CDMA power of the BS Signal or the external attenuation, especially if the mobile is connected via antenna.

Refer to Step 2 on the following pages.

Alternative Settings and Measurements

The immediate display of the connection control screen can be disabled by deselecting *Auto Open if not connected* under *Connection Control Behavior* in the *Misc.* tab of the *Connection Control* menu.

 Chapter 4



Step 2

After registration, the MS Information area now contains the important parameters characterizing the mobile station.

If the mobile doesn't register with the CMU, there may be configuration settings that don't match the mobile station. Check the requirements of the mobile station, signal settings, channels, and connections.

Additional Information...

... on Step 2

Connection Control is divided into pages accessed by the tabs at the bottom of the screen.

The tabbed pages provide access to all signalling parameters. Typically the default settings allow a call to be established. The *Connection Control* parameter settings are global settings. Individual measurement settings override these global parameters.

Connection

The *Connection* tab displays the most important parameters characterizing the signals generated by the CMU.

Handoff

The *Handoff* tab displays the handoff capabilities of the CMU. In this instance, the tab is gray since there are no handoffs to be made.

Service Cfg.

The *Service Cfg.* tab displays the parameters of the fundamental channel.

BS Signal


The *BS Signal* tab displays the configuration settings to simulate a base station. From the *BS Signal* tab you can access the parameters set in the *Signalling* tab. In addition you can set the CDMA Levels and Handoff Parameters.


Network

The *Network* tab displays the configuration of the network identity and other parameters characterizing the network.

AF/RF

Input/output connectors suitable for the type of measurements and signal levels must be chosen. An external input/output attenuation value can be specified in order to compensate for known attenuation of the input/output signal like those caused by cables.

 Chapter 4.

Input/output connectors and external attenuation are configured in the AF/RF  tab.


Sync.

The *Sync.* tab defines the reference frequency and sync signal used by the CMU.


1 / 2

The 1 / 2 hotkey toggles between the first hotkey bar and a second bar providing the tabs for the I/Q-IF board settings, the trigger source, the analyzer configuration and control of the connection control behavior.

1st Service Class



Connect MS



Step 3

- Press the 1st Service Class softkey and select the *Loopback Service*.
- To select the H-PSK modulation scheme set the radio configuration in the forward and reverse Fundamental Channel (*F-FCH-RC* and *R-FCH-RC*) to 3.

Step 4

- Return to the *Connection* tab and press the *Connect MS* softkey to establish a call with the mobile station.

Step 5

After the call is established, the CMU displays the Overview O-QPSK measurement screen. This was the selection made in the function menu starting the connect procedure.

The Overview O-QPSK displays the current O-QPSK measurements.

The *Application* softkey displays a set of hotkeys of available applications while in the *Overview* measurement.

From this screen, you can adjust the base station signal levels or impairments.

The *Menus* softkey displays a set of hotkeys to switch to other measurement types.

Additional Information...**... on Step 3**


The *1st Service Class* softkey displays the call mode method to use when connecting to the mobile station. *Loopback Service* is generally used for testing. *Speech Service* is used to place a voice call to the mobile.

CDMA2000 receiver quality measurements require that a Loopback Service call be established with the mobile station. The Speech Service mode is used to place a voice call to the mobile. Modulation measurements may run slower in Speech Service since the mobile station signal may not be using Full Rate.

The parameters for the service types are configured in the *Service Config.* tab.

Alternative Settings and Measurements

☞ Chapter 4.



Step 6

- Press the measurement softkey twice (once if already highlighted).

This displays the *Overview Configuration* screen to adjust control of the measurement and its limits.

Connect Control




Step 7

- Press the Connect Control softkey to display the Connection Control screen.

The *Connection Control* screen now indicates it is connected to the mobile.

Closing the *Connection Control* screen returns the CMU to the last measurement menu accessed. In this case the CMU returns to the *Overview* menu by default since no measurement menu has been displayed.



Connect Control



Step 8

- Press the *Connect Control* softkey again to return to the measurement screen.

Additional Information...**... on Step 6**

The *Overview Configuration* screen displays two tabs, Control and Levels. The Control tab contains all the settings that affect control of the measurement and the Limits tab contains all the settings to define the limits of the measurement.

Softkeys and hotkeys

To enlarge the diagram area of the graphical measurement menus, the left softkey column is suppressed. The functionality of each softkey on the right side is extended by hotkeys. These hotkeys are displayed in the hotkey bar below the diagram when the softkey is selected.

Configuration settings

Some of the softkey/hotkey combinations offer settings that can also be accessed via configuration menus. For example, the settings offered by the *CDMA Levels* softkey (for Gated Output) is equivalent to *Levels* in the *Control* tab (for Gated Output) of the *Power Configuration* menu. Identical settings overwrite each other.

Each measurement group and each application (within the group) stores its own configuration settings. For example, the *Pilot Level* setting for the *Gated Output* application is separate from the *Pilot Level* setting for the *Open Loop Time Resp.* application.

... on Step 8

Closing the *Connection Control* screen returns the CMU to the last measurement menu accessed. In this case the CMU returns to the *Overview* menu by default since no measurement menu has been displayed.



Alternative Settings and Measurements

☞ Chapter 4.

☞ Chapter 4.

Power Measurements

The Power measurement menu provides information about the mobile station's power levels and performance. The CMU provides six applications to measure and display power measurements. In this signalling example, only the *Gated Output* application is selected.





Step 1

- Press the *Menu Select* key to open the *Menu Select* menu.
- Press the *Power* hotkey to switch to one of the *Power* measurement applications.

The last power application accessed is displayed. Most likely no measurement results are available with the current service configuration settings.

- Open the *Connection Control* menu, press the *Service Cfg.* softkey and select the *Speech Service* as the *Primary Service Class*.
- Select *Service Option 1* as shown in the figure.
- Close the *Connection Control* menu.



Step 2

- Press the *Application* softkey. The available power applications are displayed in the hotkey bar.
- Press the *Gated Output* hotkey to change to the *Gated Output* application.

The *Gated Output* power application shows the gated output power as a function of time.

A tolerance template is displayed. The settings (default at this time) and scalar results are displayed in the parameter line above the diagram and in a message box positioned in the diagram area.

Additional Information...

... on Step 1

If the *Power* hotkey is not displayed, press the *MENU SELECT* key. The menu group *Power* contains the functions to measure the received signal power. The *Power Configuration* popup menu configures all power measurements.

Softkeys and hotkeys

To enlarge the diagram area of the graphical measurement menus, the left softkey column is suppressed. The functionality of each softkey on the right side is extended by hotkeys. These hotkeys are displayed across the hotkey bar below the diagram when the softkey is selected.

... on Step 2

There are six power applications (in the hotkey bar).

- *Minimum Output O-QPSK* measures the mobile station's minimum output power.
- *Maximum Output O-QPSK* measures the mobile station's maximum output power.
- *Open Loop Time Response* measures the open loop power control time response to an increase or decrease of the total base station power.
- *Gated Output* displays the time response of the mean output power for isolated gated-on power control groups.
- *Minimum Output H-PSK* measures the mobile station's minimum output power.
- *Maximum Output H-PSK* measures the mobile station's maximum output power.

Alternative Settings and Measurements

The *Application* softkey switches between the applications of the *Power* measurement.

The *Analyzer Level* softkey adjusts the RF input signal path.


The *BS Signal Level/Impairments* softkey displays a set of hotkeys to adjust the total power and channel levels of the CMU's CDMA signal and add impairments.

The *BS Signal Settings* softkey defines the frequency and frames rate of the CMU's CDMA signal.

The *Marker/Display* softkey sets markers and a D-line and rescales the diagram. (A D-line is used to mark levels and a reference point for markers.)

The *Menus* softkey changes between the individual measurement menus.


☞ Chapter 4.



Step 3

- Press the measurement softkey twice to open the *Power Configuration* menu. In this example, the measurement softkey is labeled *Gated Output*.


The *Power Configuration* menu defines each of the power measurement applications. In this example, we will adjust a parameter of the *Gated Output* application.



- Press the *Control* hotkey to display the *Control* tab.
- Scroll down to view the *Gated Output* parameters.
- Press the *EXP/CMP* key to expand the menu table.
- Scroll to the *Repetition* parameter, press *Enter*, and set it to *Single Shot*.



- Press the *ESCAPE* key to close the *Power Configuration* menu and return to the main menu.



The power measurement is stopped after one statistic cycle. The status indication next to the *Gated Power* softkey is set to *HLT*.

Additional Information...

... on Step 3

Repetition mode

Repetition determines the repetition mode of the measurement (single shot or continuous).

Single Shot: The measurement is stopped after a statistic cycle, i.e. after the number of waveform intervals/evaluation periods set in the configuration menu *Statistics*.

Continuous: The CMU continues the measurement until it is terminated explicitly or until the stop condition is met.

The *Stop Condition* setting can affect the Single Shot and Continuous repetition modes.

Softkeys and hotkeys

To enlarge the diagram area of the graphical measurement menus, the left softkey column is suppressed. The functionality of each softkey on the right side is extended by hotkeys. These hotkeys are displayed in the hotkey bar below the diagram when the softkey is selected.

Configuration settings

Some of the softkey/hotkey combinations offer settings that can also be accessed via configuration menus. For example, the settings offered by the *BS Signal Level* softkey (for Gated Output) is equivalent to *Levels* in the *Control* tab (for Gated Output) of the *Power Configuration* menu. Identical settings overwrite each other.

Each measurement group and each application (within the group) stores its own configuration settings. For example, the *Pilot Level* setting for the Gated Output application is separate from the *Pilot Level* setting for the *Open Loop time Resp.* application.


Alternative Settings and Measurements

☞ Chapter 4, section *Measurement Environment*.

Settings made in the *Power Configuration* menu apply only to the power measurements.


Settings made in the *Connection Control* menu apply to the entire CDMA2000 function group. Individual measurements settings override these settings while the measurement is active.

☞ Chapter 4.



Step 4

- Press the *Marker* softkey.
- Press the *Ref R* hotkey and enter a value to position the reference marker onto the trace.




The reference marker is positioned on the trace and the coordinates are displayed in the parameter line.

Additional Information...**... on Step 4****Markers**

Markers are a graphical tool used to locate points on a trace and read out their coordinates. A reference marker and two delta markers may be defined in the *Power* menu.

The reference marker measures the absolute level of the trace. The delta markers either measure the distance between their position and the reference marker (relative mode) or the absolute level (absolute mode).


Alternative Settings and Measurements

 Chapter 4.

In addition to markers, a D-line can be used to measure a particular level in the diagram and used as a reference point for markers.


Modulation Measurements

We can use the hotkey bar to switch over to the Modulation measurement.




Step 1

- Press the *Menus* softkey to display the measurement groups in the hotkey bar.
- Press the *Modulation* hotkey to switch to the *Modulation* measurements.
- Press *Application* and select the *Overview O-QPSK* application (corresponding to the current service configuration).




The *Modulation - Overview* menu displays the main results of the *Modulation* measurement.

If a result exceeds the tolerances, the corresponding output field is red and an arrow pointing upwards or downwards indicates that the result is above or below the limit.



Step 2

- Press the *Application* hotkey again to display the available Modulation applications in the hotkey bar.
- Press the *EVM* hotkey to change to the *Error Vector Magnitude* application.



The *Modulation – Error Vector Magnitude* menu displays a graph of the *Error Vector Magnitude* as percentage vs. time.

The output fields below the graph correspond to the ones shown in the *Overview* application. Since we are viewing the *Error Vector Magnitude* application, the *Magnitude Error* and *Phase Error* are not shown.

Additional Information...

Alternative Settings
and Measurements**... on Step 1****Statistical quantities**

The table in the *Overview* menu reports peak and RMS-averaged values of quantities characterizing the errors of the modulation vector. In addition, the scalar modulation results *Carrier Feedthrough*, *I/Q Imbalance*, *Carrier Frequency Error*, *Transmission Time Error*, *Waveform Quality*, and *MS Power* are indicated.

The values in the three columns of the table are calculated as follows:

- The *Current* column contains the results for the current measurement.
- The *Average* column contains the current results averaged over the last statistic cycle.
- The *Max./Min.* column contains the extreme values of the current results for all measurements.

... on Step 2**Applications**

Applications are different measurements belonging to the same measurement group. Each application is assigned its own set of configuration parameters allowing configuration of each application individually.

The *Modulation* menu comprises the four applications *Overview O-QPSK*, *Error Vector Magnitude*, *Magnitude Error*, and *Phase Error*.

Measured values and limits

The limits may be modified in the *Limits* tab of the *Modulation Configuration* menu which is opened by pressing the measurement softkey twice. The *Modulation Configuration* menu is similar to the *Power Configuration* menu explained on the previous pages.

The absolute values are given for modulation measurements. This is why the display modes *Minimum* and *Maximum* can not be selected separately. The CMU displays the extreme values with the correct sign.

 Chapter 4.

The measurement principle for phase and frequency errors is explained at the beginning of section *Modulation Measurement Menu*.

Application Example for Power vs. Frame

Power vs. Frame is a real-time measurement that was primarily designed for fast and accurate evaluation of defined power steps of a transmitter over a wide dynamic range. The following example illustrates which steps are required to carry out a general *Power vs. Frame* measurement and how the test settings are adapted to a typical test scenario.

Measurement task Suppose that a CDMA2000 mobile starts transmitting at its maximum output power of +23 dBm and reduces its power in 20 ms steps until it reaches its minimum power of -60 dBm. The average power in each step shall be measured as quickly as possible.

Solution *Power vs. Frame* is an appropriate application to measure up to 100 power steps in real time. The measurement is performed in *Non Signalling* mode and with manual *RF Max. Level* setting. Moreover, an appropriate trigger setting is required.

Procedure

1. Switch on the mobile transmitter and feed the signal to the RF input connector RF 2.
2. From the *Menu Select* menu, open the *Power* measurement menu in the *Non Signalling* test mode.
3. In the *Power* menu, press the *Application* softkey and select *Power vs. Frame*.
4. Press *Trigger/Analyzer Level – Trigger Source* to select *IF Power* trigger. If necessary, adjust the *Trigger Level (IF)* to the expected characteristics of the power ramp.
5. Press *Analyzer Level/Trigger – RF Max. Level* and set the maximum input level to +25 dBm.
6. Press *Analyzer Level/Trigger – RF Mode* and select *Manual* to de-activate autoranging.

In the default configuration of the *Power vs. Frame* measurement application, the CMU measures 50 power steps using two different *RF Max. Level* settings. The remaining 50 entries in the table read *Off*.

7. If necessary, press the measurement control softkey labeled *Power vs. Frame* twice to open the *Power Configuration* menu and modify the default configuration: Use the *Step Count* to change the number of results in the table. Use the settings in the *RF Max. Level Deviation* section to optimize the maximum input level settings.

Contents

3 Manual Control	3.1
Menu Structure	3.1
Test Modes.....	3.1
Signalling Symbols.....	3.2
Configurations	3.3
Measurement Environments.....	3.4
Measurement Groups	3.5
General Settings	3.6

3 Manual Control

This chapter gives a brief overview of the operating concept and structure of the user interface for CDMA mobile phone tests. The CMU is designed for maximum operating convenience and flexibility. All instrument functions are grouped together in menus. Each menu provides configuration settings, displays a group of measured quantities, or a combination of both. Switching between the different menu groups and signalling modes is possible at any time.

In the following sections, the different measurement modes and measured quantities are discussed. Settings and measurement parameters frequently encountered are explained from a general point of view.

The formal aspects of measurement control are discussed in more detail in Chapter 5 (*Remote Control – Basics*). For information about the CMU's control elements, menu types and dialog elements within the menus refer to Chapter 3 of the CMU Operating manual.

Menu Structure

The menus used to control CDMA2000 measurements can be arranged in different ways. From a functional point of view, they form the following groups:

- The CDMA2000 function groups:
 - CDMA2000 450
 - CDMA2000 Cellular
 - CDMA2000 PCS
 - CDMA2000 IMT-2000
- The two tests modes:
 - Signalling
 - Non-Signalling
- General configurations (Connection Control)
- Measurement groups (*Analyzer/ Generator, Overview, Power, Modulation, Spectrum, Code Domain Power, Receiver Quality*)
- Configurations specific to the measurement groups

The CMU uses main menus, popup menus, graphical measurement menus and dialog windows of various size. Refer to Chapter 3 of the CMU Operating manual for discussions about menus.

Test Modes

CDMA2000 measurements are performed in one of the two modes *Signalling* or *Non Signalling*. The *Non Signalling* mode is typically used for module tests or test of mobiles in a special "test mode". The *Signalling* mode measures the mobile phone performance under realistic operating conditions where the CMU mimics a CDMA2000 base transceiver station.

Definition The term signalling denotes all actions necessary to establish, control and terminate a communication between the base station (CMU) and the mobile phone. The signalling messages conveyed allow the mobile station and the

network to discuss the management of issues either related to the user or concerning technical aspects of the communication.







Non-Signalling Mode In the *Non Signalling* mode, the CMU generates an RF signal conforming to CDMA2000 specifications and analyzes the signal transmitted by the device under test (DUT).

Signalling Mode In the *Signalling* mode, the CMU first transmits a signal consisting of a pilot, sync, and paging channel. In subsequent steps, the mobile synchronizes to the channels, decodes the information transmitted, and performs a location update so that a call can be established from either the mobile or the CMU.

The signalling mode measures the mobile phone performance under realistic operating conditions where the CMU mimics a CDMA2000 base transceiver station. The CMU is able to configure a broad range of network parameters and to determine the parameters characterizing the mobile. Measurements of the power versus time, modulation parameters, and receiver quality can be performed.

Signalling Symbols

The signalling mode and state is indicated to the left of the operating mode in each main menu and measurement menu. The following icons (mobile station) represent each signalling mode and state:

Non-Signalling Mode		Non-Signalling Mode – Icon split
Signalling Mode		Signal Off – Icon has gray background
		Signal On – No Icon
		Registered – Icon has green background
		Alerting (Speech)
		Connected

To the left of the signaling state icon, the CMU indicates the forward and reverse radio configuration (*RC <F-RC>/<R-RC>*), the modulation scheme (*O-QPSK* or *HPSK*), and the selected service option (SO). If the radio configuration is incompatible with the selected modulation scheme, or if a modulation scheme is not supported by the mobile under test, it appears on a red background.

Configurations

The CMU offers a wide range of settings for the signal generator and analyzer, the signalling procedures, and the individual measurements. Configurations may apply to a whole function group (*Connection Control*) or to a particular measurement; see [Measurement Environments](#) on p. 3.4 ff.

Connection Control The *Connection Control* softkey is located on the right side of the title bar of each main and measurement menu. Depending on the mode (non-signalling or signalling), it opens a popup menu with tabs configuring the following:

- The signal generators and analyzers of the instrument (*Analyzer* and *Generator* in Non Signalling, *MS Signal* and *BS Signal* in Signalling mode)
- The CMU receiver settings and input path configuration (included in *Analyzer*, *MS Signal*)
- The trigger settings (included in *Analyzer*, *MS Signal*)
- The RF connectors to be used and the external attenuation (*RF Input/Output*)
- The reference signal and the system clock (*Sync.*)
- In *Signalling* mode, all actions changing the CMU's signalling state (*Connection*)
- In *Signalling* mode, a handover (*Handover*) to another network
- In *Signalling* mode, parameters of the network and the mobile station under test (*Network*)

All settings made in the *Connection Control* menu apply to the whole function group. Many of them are suspended, however, by measurement-specific parameters while a measurement is active (see section *Measurement Environment* in Chapter 4).

Configurations of measurements A popup menu offering specific settings is assigned to each measurement group (*Power*, *Modulation*, *Code Domain Power*, and *Receiver Quality*). The following parameters can be defined for many measurements:

- The repetition mode, the stop condition, the statistic count and the display mode for the measurement (*Control*)
- Tolerances for the measured quantities (*Limits*, *Limit Lines*)

These settings are explained in more detail section [General Settings](#) on page 3.6).

Configuration hotkeys via The softkeys and associated hotkeys in the graphical measurement menus provide the most important configurations for the current measurement (refer to Chapters 3 and 4 of the CMU Operating manual). Settings made via hotkeys supersede the corresponding settings found in the measurement configuration menu.

Measurement Environments

In *Signalling* mode, an independent set of measurement parameters can be defined for most CDMA2000 measurement applications (examples for applications with no environment: *Power – NPower*, *Spectrum – ACP*). The parameter sets form measurement *environments* that are activated as soon as a connection is established and the measurement application is switched on. Only one measurement environment is active at any given time. When the connection is released, or when no measurement is active, the environment defined by the *Connection Control* parameters is used.

If all measurements contained in one environment (for example in the *Overview* menu, *Overview H-PSK* and *Channel Quality*), are turned off while the connection is still established with a mobile station, the CMU reverts to using the *Connection Control* parameters. The *Output Power* displayed in *Connection Control* always reflects the current status of the total CMU output power. The measurement environment (and available measurements) is dependent on several settings in the *Connection Control* environment.

It is possible to partially or completely disable the mechanism of swapping environments:

- In the *Control* tab of the measurement configuration menus, *Environment Enable* enables or disables the environment of the corresponding measurement or measurement application.
- In the *Misc.* tab of the *Connection Control* menu, setting the *Use Measurement Environment* parameter to *All Off* disables all measurement environments so that the *Connection Control* parameters are used permanently. *Some On* is indicated if some but not all of the individual measurement environments have been enabled.

Measurement Groups

Measurement results are indicated in two different ways:

- Discrete values and parameters are displayed in output fields, lists and tables. In remote control, these results are referred to as scalars.
- Measurement curves (traces) are displayed in a Cartesian coordinate system, the time forming the x-axis scale. Relatively small sets of test points are generally viewed in a bar graph. In remote control, results of this type are referred to as arrays.

While the measurement is running in repetition mode *continuous* (see page 3.6), the indicated results are constantly updated. As shown in the table below, some of the measurement groups are different for the two test modes.

Table 3-1 Measurement Groups in the Signalling and Non-Signalling Mode

Non-Signalling	Signalling
<p>Analyzer/Generator Shows the settings for the signals generated and analyzed by the instrument and presents an overview of the basic scalar power and modulation results.</p>	<p>Overview Shows the settings for the traffic channel and speech mode and presents an overview of the basic scalar power and modulation results. The receiver parameters and various signalling parameters reported by the mobile station are displayed.</p>
<p>Power Provides the power in a measurement interval of configurable length plus a statistical evaluation. In addition the average power of the RF input signal can be measured in up to 100 equidistant evaluation periods (frames) of variable length.</p>	<p>Power The open loop time response and gated output are shown as a trace plotted over time. Single points of the trace may be evaluated by means of graphical tools (markers and display line). The power output (minimum and maximum) of the mobile station is measured. <i>NPower</i> provides the power in a measurement interval of configurable length plus a statistical evaluation.</p>
	<p>Modulation Shows the error vector magnitude, magnitude error and phase error of the transmitted waveform interval as a function of time. The carrier feedthrough, I/Q imbalance, frequency error, transmission time error, waveform quality and MS power error are displayed.</p>
	<p>Spectrum Shows the off-carrier power at four symmetrical pairs of offset frequencies and provides a limit check.</p>
	<p>Code Domain Power The CMU measures the power of the mobile station's channels. In addition the phase and timing error between the Reverse Pilot Channel and the other code channels radiated by the mobile station can be measured.</p>
	<p>Receiver Quality Shows the settings and results of the frame error rate test and forward power control reported by the mobile station.</p>

General Settings

A number of settings can be made in several of the configuration menus assigned to the measurement groups *Analyzer/Generator*, *Overview*, *Power*, *Modulation*, *Code Domain Power* and *Receiver Quality*. In combination, these settings define the scope of the measurement, i.e. the number of waveform intervals measured and the results displayed. The following brief overview is intended to avoid confusion of terms.

Application *Applications* are different measurements belonging to the same measurement group. They effectively split up a measurement group into various related subgroups which can be configured separately.

They are selected via the *Application* softkey in the measurement menus.

Statistic Count / Statistics Cycle The statistic count is equal to the integer number of evaluation periods which form one statistics cycle. An evaluation period corresponds to the duration of a waveform interval (all TX measurements) or a frame (measurement group *Receiver Quality*). Depending on the *repetition mode* (see below), a measurement may extend over one or several statistics cycles.

The *statistic count* is set in the *Control* tab of the configuration popup menus assigned to each measurement group.

Repetition Mode The *repetition mode* defines how many statistics cycles are measured if the measurement is not stopped by a limit failure (see stop condition *On Limit Failure* below). Two modes are available for all measurements:

Single Shot The measurement is stopped after one statistics cycle

Continuous The measurement is continued until explicitly terminated by the user; the results are periodically updated

A third repetition mode is available in remote control:

Counting Repeated single shot measurement with a fixed number of statistics cycles

The *repetition mode* is set in the *Control* tab of the configuration popup-menus assigned to the individual measurement groups.

Note: *In contrast to other measurement settings, these repetition modes in manual and remote control are independent and do not overwrite each other. In most measurements, the default repetition mode in manual control is Continuous (observe results over an extended period of time), the default mode in remote control is Single Shot (perform one measurement and retrieve results).*

Stop Condition For all TX measurements, two stop conditions can be selected:

None The measurement is performed according to its repetition mode, regardless of the measurement results,

On Limit Failure The measurement is stopped as soon as one of the limits is exceeded, regardless of the repetition mode set. If no limit failure occurs, it is performed according to its repetition mode.

For *Receiver Quality* measurements, the stop condition *None* (see above) and three further conditions can be selected:

Confidence Limit exceed.

The measurement is stopped as soon as the limit for the confidence level is exceeded

Frame Limit exceed. The measurement is stopped as soon as the limit for the frame errors is exceeded

Any Limit exceed. The measurement is stopped if either the confidence limit or the frame limit is exceeded.

The *Stop Condition* is set in the *Control* tab of the configuration popup-menus assigned to each measurement group.

Display Mode

In graphical measurement diagrams, the *Display Mode* defines which of the measured and calculated traces is displayed if the measurement extends over several waveform intervals. In general, traces are evaluated at a set of fixed, equidistant test points (samples). After n waveform intervals, n measurement results per test point have been taken. After a single shot measurement extending over c waveform intervals, c measurement results per test point have been taken.

Current The current waveform interval, i.e. the last result for all test points, is displayed.

Minimum At each test point, the minimum value of all waveform intervals measured is displayed.

Maximum At each test point, the maximum value of all waveform intervals measured is displayed.

Max./Min. At each test point, the extreme value of all waveform intervals measured is displayed, i.e. the maximum or minimum, whichever has a larger absolute value.

Average At each test point, a suitably defined average over all waveform intervals measured is displayed; see paragraph on *Calculation of average quantities* below.

Note the difference in the calculation of *Average* on one hand, *Minimum*, *Maximum* and *Max./Min.* on the other hand, if the measurement extends over more than one statistic count (repetition mode *Continuous*, measurement time longer than one statistic count).

After evaluation of the different traces, the waveform interval power is logarithmized and plotted in a semi-logarithmic diagram.

The *Display Mode* is set in the *Control* tab of the configuration popup-menus assigned to the individual measurement groups.

Calculation of average quantities

The *Average* traces in the *Power*, *Modulation*, and *Spectrum* menus are obtained as follows:

Let c be the number of waveform intervals forming one statistics cycle (one *Statistic Count*) and assume that n waveform intervals have been measured since the start of the measurement. In calculating the *Average* trace, the following two situations are distinguished:

n ≤ c Single shot measurement or continuous measurement during the first statistics cycle: At each test point, *Average* trace no. n is calculated from *Average* trace no. n – 1 and *Current* trace no. n according to the following recurrence:

$$Avg(n) = \frac{n-1}{n} Avg(n-1) + \frac{1}{n} Curr(n) \quad (n = 1, \dots, c)$$

The *Average* trace represents the arithmetic mean value over all n waveform intervals measured.

$n > c$ Continuous measurement after the first statistics cycle: At each test point, *Average* trace no. n is calculated from *Average* trace no. $n - 1$ and *Current* trace no. n according to:

$$Avg(n) = \frac{c-1}{c} Avg(n-1) + \frac{1}{c} Curr(n) \quad (n > c)$$

Scalar quantities are averaged in analogy to *Average* traces. The formulas hold for $n = 1$ where the average trace becomes equal to the current trace (statistics off).

Calculation of statistical quantities

In *Power* and *Modulation* measurements the statistical functions *Average*, *Minimum*, *Maximum* and *Minimum/Maximum* are applied to a set of test points depending on two independent parameters:

- The time, i.e. the abscissa values t_i , i ranging from 1 to the total number of test points comprising the trace.
- The waveform interval number ranging from 1 to the number n of the current waveform interval.

The result of the statistical operations depends on the parameter range considered and – in the case of statistics functions evaluated over several parameters – on the order of evaluations. This is why the definition of statistical quantities deserves some attention and is explained in the relevant sections in chapter 4. Some particular examples are:

1. In the *Power* menu, application *Gated Output*, the quantity *Mean Output* denotes the average power of the current power control group. i.e. the arithmetical mean value of all test points t_i located in the power control group.
2. In the *Modulation* menu quantities such as the *Frequency Error*, *Phase Error RMS*, *Phase Error Peak* etc. are first calculated for the current waveform interval and entered in the *Current* column of the output table. The results in the *Minimum/Maximum* column correspond to the extreme value of the *Current* results calculated over all waveform intervals measured. The results in the *Average* column correspond to the average of the *Current* results calculated according to the prescription in paragraph *Calculation of average quantities* above.

Contents

4	Functions and their Application	4.1
	CDMA Module Tests (Non-Signalling Mode)	4.2
	Analyzer/Generator	4.2
	Softkey Selections	4.4
	Measurement Control	4.4
	Selecting the Application.....	4.5
	Common settings	4.5
	Measurement Results	4.6
	Measurement Configurations (Modulation Configuration).....	4.7
	Measurement Control (Modulation Configuration – Control)	4.8
	Modulation Configuration – Limits	4.10
	Power Measurements.....	4.12
	Test Settings	4.12
	Measurement Results	4.13
	NPower 4.13	
	Power vs. Frame.....	4.14
	Power Configuration	4.15
	IQ Access	4.18
	Audio Measurements.....	4.18
	Modulation / Spectrum / Code Domain Power Measurements	4.18
	Connection Control.....	4.19
	Network Standard (Connection Control – Standard).....	4.19
	Analyzer Control (Connection Control – Analyzer).....	4.20
	Generator Control (Connection Control – Generator)	4.21
	Softkey-Oriented Version.....	4.21
	Table-Oriented Version.....	4.24
	AF/RF Connectors (Connection Control – AF/RF)	4.28
	Frequency-Dependent External Attenuation.....	4.31
	Reference Frequency (Connection Control – Sync.).....	4.33
	Trigger (Connection Control – Trigger).....	4.35
	I/Q-IF Interface (Connection Control – I/Q-IF)	4.39
	CDMA Measurements	4.41
	Call Setup (Connection Control).....	4.43
	Connection Control (Signal Off State)	4.44
	Connection Control (Signal On State)	4.46
	Connection Control (Registered State).....	4.48
	Connection Control (Alerting State).....	4.50
	SMS Tests with the CMU.....	4.51
	Overview	4.52
	Softkey Selections	4.53
	Measurement Results	4.54
	Overview Configuration	4.56
	Overview Configuration – Control	4.56
	Overview Configuration – Limits	4.60
	Power Measurements.....	4.62

Softkey Selections	4.63
Measurement Results	4.66
Minimum Output.....	4.66
Maximum Output.....	4.67
Open Loop Time Response	4.68
Gated Output	4.70
Power Configuration	4.71
Power Configuration – Control.....	4.71
Power Configuration – Limits.....	4.74
Modulation Measurements	4.77
Softkey Selections	4.79
Measurement Results	4.81
Test Diagrams (EVM, Phase Error, Magn. Error).....	4.81
Overview 4.83	
Display of the Modulation Vector (I/Q Analyzer).....	4.83
Representation in the I/Q Plane: O-QPSK.....	4.84
Representation of the Amplitudes vs. Time: O-QPSK	4.85
Representation in the I/Q Plane: H-PSK.....	4.86
Representation of the Amplitudes vs. Time: H-PSK	4.87
Modulation Configuration.....	4.87
Modulation Configuration – Control	4.87
Modulation Configuration – Limits	4.89
Spectrum Measurements	4.91
Softkey Selections	4.92
Measurement Results	4.93
Spectrum Configuration	4.94
Spectrum Configuration – Control	4.95
Spectrum Configuration – Limits.....	4.96
Code Domain Power Measurements.....	4.97
Softkey Selections	4.98
Measurement Results	4.100
Code Domain Power.....	4.100
Peak Code Domain Error Power	4.103
Channel Power	4.103
Phase Offset	4.104
Time Offset	4.106
Code Domain Power Configuration	4.107
Code Domain Power Configuration – Control.....	4.107
Code Domain Power Configuration – Limits.....	4.110
Receiver Quality Measurements	4.113
Softkey Selections	4.114
Measurement Results	4.115
Frame Error Rate (FCH and SCH/SCCH)	4.116
Forward Power Control	4.116
Receiver Quality Configurations	4.117
Receiver Quality Configuration – Control	4.118
Receiver Quality Configuration – Limits.....	4.121
Connection Control Menu	4.122
Connection Control with Connection Established.....	4.122
Handoff to Another Network (Connection Control – Handoff)	4.124
Service Configuration of the CMU (Connection Control – Service Cfg.).....	4.126
General Settings	4.126

Loopback Service	4.128
Speech Service	4.131
Test Data Service	4.134
Packet Data Service	4.139
Messaging Teleservice (WMT)	4.142
Supplemental Channel Configuration and Dependencies for TDSD	4.145
Connected Service Option Configuration	4.146
Signals of the CMU (Connection Control – BS Signal).....	4.147
Network Parameters (Connection Control – Network)	4.154
AF/RF Connectors (Connection Control – AF/RF)	4.161
Reference Frequency (Connection Control – Sync.).....	4.163
Trigger (Connection Control – Trigger).....	4.163
I/Q-IF Interface (Connection Control – I/Q-IF)	4.165
Analyzer Control (Connection Control – Analyzer).....	4.165
Miscellaneous User Settings (Connection Control – Misc.)	4.167
Marker Control	4.170
Audio Measurements and Setup	4.172

4 Functions and their Application

This chapter explains in detail all functions for the measurement of mobile stations supporting the CDMA2000 standard. The CMU 200 with Options K83, K84, K85, and/or K86 support the networks listed in Table 1-1 (see Chapter 1).

Note: *The menus for all CDMA2000 options and function groups are analogous. The tests and screen shots presented in the manual are valid for all function groups.*

The chapter is divided in two sections corresponding to the two function groups for module tests (*Non-Signalling*) and for mobile tests (*Signalling*). Within the two sections, the discussion is structured according to the provided measurements and configurations. In contrast to chapter 6, *Remote Control – Commands*, general measurement configurations are relegated to the end of each section.

The description of each softkey, select or input field is followed by the corresponding remote-control command(s). Similarly, the description of the commands in chapter 6 also contains the corresponding menus of the user interface.

Each menu and each panel is briefly described first and then illustrated together with its call button. The menu functions are explained according to the following scheme:

Softkey	Short function definition
Designation of select/input field	Definition of function.
	Further description of the function: purpose, interaction with other settings, notes...
	<i>Parameter 1</i> Description of parameter 1
	<i>Parameter 2</i> Description of parameter 2
	Further description of the parameters: purpose, interaction with other settings, notes...
	Remote control
	Remote-control command (long form) Parameter1 Parameter2
	...

Note: *For all numerical values, including their ranges and default settings, please refer to the description of the remote-control commands in Chapter 6. The description of the operating concept is found in Chapter 3 of the CMU200 operating manual.*

CDMA Module Tests (Non-Signalling Mode)

The structure of this section is based on the configuration and measurement groups defined in the function group *IMT-2000 Mobile Station, Non-Signalling* mode. The menus are described in the following order:

- Measurement menu (*Analyzer/Generator*): Description of measurement menu, results, and specific measurement settings
- Common settings for the function group (*Connection Control*)




Figure 4-1 Menu Select

Analyzer/Generator

The *Analyzer/Generator* menu configures the signals of the RF generator and analyzer. At the same time, it controls the *Modulation* measurement and displays the current results.

To remain compatible with multiple mobile stations, the CMU200 supports several modulation schemes, to be selected as *Applications*.

- O-QPSK** Supports cdmaOne connections (radio configurations 1 and 2)
- H-PSK** Supports CDMA2000 connections (radio configurations 3 and 4)
- QPSK** Supports CDMA2000 connections with only a Pilot channel.

Note: The screen shots provided for the *Analyzer/Generator Non Signalling* mode were taken with the CMU 200 set to the O-QPSK modulation scheme. The menus for the modulation schemes H-PSK and QPSK are analogous.



The trigger conditions for the measurements are described in [Table 4-3](#) on p. 4.37.

In the softkey bar on the right side, the *Analyzer/Generator* menu provides different types of softkeys:

- The measurement control softkey *Mod. Qual. O-QPSK* changes to *Mod. Qual. H-PSK* or *Mod. Qual. QPSK*, depending on the application selected. This softkey controls the measurement, indicates its status (*RUN | HLT | OFF*) and opens the configuration menu *Modulation Quality Configuration*. The hotkeys associated to the measurement control softkey define the scope of the *Modulation* measurement.
- The other softkeys on the right side are combined with various hotkeys (e.g. the hotkeys *RF Max. Level* and *RF Mode* belong to the softkey *Analyzer Level*). The softkey/hotkey combinations provide test settings and switch over between different measurements.

Types of settings The purpose of the *Analyzer/Generator* menu is to provide quick access to the most common *Modulation* measurements and to present the basic measurement results at a glance. The three measurement applications *Mod. Qual. O-QPSK*, *Mod. Qual. H-PSK* and *Mod. Qual. QPSK* can be selected with the *Application* softkey. The remaining softkeys/hotkey combinations provide two different types of settings:

- Common settings are valid for all applications of function group *CDMA2000 Non Signalling*. Changing common settings in any application will have an impact on all measurements and applications of the function group. All common settings are also provided in the *Connection Control* menu (see p. 4.19 ff.). Examples of common settings are the RF input level and trigger settings (softkey *Analyzer Level*) and the configuration of the RF generator (softkey *Generator*).
- Specific settings are relevant for one application only, or they can be set independently for several applications. Changing specific settings in an application will not affect the other measurements and applications of the function group. No specific settings are provided in the *Connection Control* menu (see p. 4.19 ff.). Examples of specific settings are the *Repetition* mode (to be set independently for all applications providing this mode).
- In *Signalling* mode each measurements has its own test setup environment. The parameters in the *Connection Control* menu do not provide common settings in the sense described above. Refer to section *Measurement Environment (Parameter Settings)* and to the introduction to each measurement.

Measurement results The output fields in the left half of the *Analyzer/Generator* menu show the current measurement results. The results depend on the selected application. They are described in detail in section *Measurement Results* on p. 4.6 f.

The results displayed in the *Analyzer/Generator* menu represent only a fraction of the modulation results that the CMU is able to acquire. A comprehensive set of test results is displayed in the *Modulation* measurement menus provided in *Signalling* test mode. In particular, the *Modulation* menus show many quantities as functions of time.

The *Analyzer/Generator* menu is opened from the *Menu Select* menu (with associated key at the front of the instrument). The hotkeys associated to the *Menus* softkey switch over between the *Analyzer/Generator* menu and the remaining measurement menus of function group *CDMA2000 Non Signalling*.

Selecting the Application

Appli- cation

The *Application* softkey selects the measurement application. The measurement control softkey (second softkey below *Connect. Control*) indicates the current application. The corresponding measurement results are explained in section [Measurement Results](#) on page 4.6 ff.

Mod. Qual. O-QPSK

The *Mod. Qual. O-QPSK* hotkey selects the modulation measurement on O-QPSK (Offset Quadrature Phase Shift Keying) modulated signals. This modulation scheme is used for cdmaOne connections (radio configurations 1 and 2).

Remote control

The *Mod. Qual. O-QPSK* application is selected by the keyword `OQPSK` in the 4th level of the `MODulation` commands, e.g.

```
CONFigure:MODulation:MQuality:OQPSK...
```

Mod. Qual. H-PSK

The *Mod. Qual. H-PSK* hotkey selects the modulation measurement on H-PSK (Hybrid Phase Shift Keying) modulated signals. This modulation scheme is used for CDMA2000 connections (radio configurations 3 and 4).

Remote control

The *Mod. Qual. H-PSK* application is selected by the keyword `HPSK` in the 4th level of the `MODulation` commands, e.g.

```
CONFigure:MODulation:MQuality:HPSK...
```

Mod. Qual. QPSK

The *Mod. Qual. QPSK* hotkey selects the modulation measurement on QPSK (Quadrature Phase Shift Keying) modulated signals. This modulation scheme is used for CDMA2000 connections with only a pilot channel.

Remote control

The *Mod. Qual. QPSK* application is selected by the keyword `QPSK` in the 4th level of the `MODulation` commands, e.g.

```
CONFigure:MODulation:MQuality:QPSK...
```

Common settings

As outlined in section [Analyzer/Generator](#) on p. 4.2 ff., some of the hotkey/softkey combinations in the *Analyzer/Generator* menu are valid irrespective of the application. These common settings are also provided in the [Connection Control](#) menu; for a detailed description refer to p. 4.19 ff.

Softkeys

- The *Trigger/Analyzer Level* softkey defines the trigger settings for the measurements and controls the level in the RF signal path. The settings are provided in the *Trigger* and *Analyzer* tabs of the *Connection Control* menu; see sections [Trigger \(Connection Control – Trigger\)](#) on p. 4.35 ff. and [Analyzer Control \(Connection Control – Analyzer\)](#) on p. 4.20 ff.
- The *Analyzer Settings* softkey defines the center frequency of the RF analyzer. The settings are provided in the *Analyzer* tab of the *Connection Control* menu; see section [Analyzer Control \(Connection Control – Analyzer\)](#) on p. 4.20 ff.
- The *Impairment/Generator Level* softkey defines the levels in all physical channels of the generated forward CDMA signal and configures an additive noise signal. The settings are provided in the *Generator* tab of the *Connection Control* menu; see section [Generator Control \(Connection Control – Generator\)](#) on p. 4.21 ff.

- The *Generator Set./P. Ctrl* softkey defines the frequency of the generated forward CDMA signal, its modulation and an offset of the PN sequence. In addition, it defines the power control bits sent to the MS to control its output power (*Power Control*). The settings are provided in the *Generator* tab of the *Connection Control* menu; see section [Generator Control \(Connection Control – Generator\)](#) on p. 4.21 ff.

Settings table The *Settings* table in the right half of the *Analyzer/Generator* menu gives an overview of the measurement settings of the current application as defined by means of the softkey/hotkey combinations or in the configuration menus. It changes when a different application is selected. The roll-key scrolls and expands the *Setup* table.

Measurement Results

The results displayed in the *Analyzer/Generator* menu are analogous in all three applications. They are displayed in various output fields in the left half of the measurement menu. The display mode (*Current*, *Min./Max.* or *Average*) is displayed above the output fields.

Display mode

Output fields




Figure 4-3 Display of results (Analyzer/Generator)

Filter settings for power measurements

The CMU measures and displays different power results, acquired with different measurement methods.

Most of the power measurements are performed using the baseband receiver filter specified in standard TIA/EIA/IS-2000.2-A. In particular, this holds for *MS Power* displayed in the *Analyzer/Generator* menu. In *Non Signalling* mode, the power results listed in the table below are obtained with different measurement filters.

Table 4-1 Filer settings for power measurements (Non Signalling)

Value	Menu	Filter
Wideband Power	Connection Control, AF/RF \oplus (see p. 4.31)	Wideband measurement
Sideband Suppression	Analyzer/Generator, see below.	30 kHz (Gaussian) spectrum analyzer filter

MS Power	<p><i>MS Power</i> is the total transmitted power level from the mobile station. The MS power is measured at the analyzer frequency (<i>RF Frequency</i>, typically set to the carrier frequency) using the receiver filter specified in standard TIA/EIA/IS-2000.2-A.</p> <p>In addition the <i>MS Power</i>, the CMU measures the power at an offset frequency from the carrier; see <i>Sideband Suppression</i> below.</p>
Waveform Quality	<p><i>Waveform Quality</i> is the modulation accuracy of the transmitted signal. The waveform quality is obtained by comparing the transmitted signal to an ideal signal as defined in standard TIA/EIA-98.</p>
Carrier Frequency Error	<p><i>Carrier Frequency Error</i> is the difference between the nominal frequency of the selected channel and the measured frequency.</p>
Transmit Time Err.	<p><i>Transmission Time Error</i> is the time offset between the mobile station's signal and the CMU's signal.</p>
Carrier Feedthrough	<p>Carrier Feedthrough refers to the origin offset, which is the magnitude of the RF carrier relative to the magnitude of the modulated carrier.</p>
Sideband Suppression	<p><i>Sideband Suppression</i> is a power measurement at a user-configurable offset frequency used for spurious measurements. In contrast to the <i>MS Power</i> the sideband suppression is measured with a 30 kHz (Gaussian) spectrum analyzer filter. The frequency offset is set via the <i>Side Band Freq. Offset</i> hotkey associated to the measurement control softkey.</p> <p><i>Lower Sideband Suppr.</i> Ratio of the sideband power at <i>RF Frequency – Side Band Freq. Offset</i> to the <i>MS Power</i> in dB</p> <p><i>Upper Sideband Suppr.</i> Ratio of the sideband power at <i>RF Frequency + Side Band Freq. Offset</i> to the <i>MS Power</i> in dB</p> <p>Note: <i>In remote control the lower and upper sideband suppression can be measured at up to 4 different frequencies; see keywords . . . ACP1 to . . . ACP4.</i></p>
Statistic Count	<p>Number of waveform intervals per statistics cycle. The colored bar indicates the relative measurement progress in the statistics cycle.</p>
Out of Tolerance	<p><i>Out of Tolerance</i> is the percentage of waveform intervals that exceed the defined limits.</p> <p>Remote control READ[:SCALar]:MODulation:MQuality:<Application> FETCh[:SCALar]:MODulation:MQuality:<Application> SAMPlE[:SCALar]:MODulation:MQuality:<Application></p>

Measurement Configurations (Modulation Configuration)

The popup menu *Modulation Configuration* contains three tabs to determine the parameters controlling the Modulation measurement including the error tolerances.

The popup menu *Modulation Configuration* is activated by pressing the measurement control softkey at the top right in the graphical measurement menu *Modulation* twice. It is possible to change between the tabs by pressing the associated hotkeys.

Measurement Control (Modulation Configuration – Control)

The *Control* tab controls the Modulation measurement by determining

- The *Repetition* mode
- The *Stop Condition* for the measurement
- The type of result displayed (*Display Mode*)
- The number of waveform intervals/evaluation periods forming a statistics cycle (*Statistic Count*)
- The frequency offset used for the sideband suppress power measurement (*Sideband Freq. Offset*)

Besides, it configures the graphical diagrams by adding or removing the *Grid*.




Fig. 4-4 Modulation Configuration – Control

The power control settings are valid for all measurements. The remaining settings can be defined independently for the different applications of the *Analyzer/Generator* measurement group (*Modulation Quality O-QPSK, Modulation Quality H-PSK, Modulation Quality QPSK*).

Default Settings The *Default All Settings* switch assigns default values to all settings in the *Control* tab (the default values are quoted in the command description in chapter 6 of this manual). In addition, default switches for the individual applications are provided.

Remote control

```
DEFAult:Modulation:MQuality:CONTRol ON | OFF
DEFAult:Modulation:MQuality[:OQPSk]:CONTRol ON | OFF etc.
```

Repetition The *Repetition* parameter defines how often the measurement is repeated:

Single Shot Single-shot measurement: the measurement is stopped after a statistics cycle (or after a stop condition is met, see below). A stopped measurement is indicated by the status display *HLT* in the *Modulation* softkey.

Unless otherwise stated, a statistics cycle corresponds to the number of waveform intervals/evaluation periods set under *Statistic Count*.

Continuous Continuous measurement: The CMU continues the measurement until it is terminated explicitly (or until the stop condition for the measurement is met, see below). The measurement results are valid after one statistics cycle; however, the measurement is

continued, and the output is continuously updated. An ongoing measurement is indicated by the status display *RUN* in the softkey *Modulation*.

Single shot should be selected if only a single measurement result is required under fixed conditions. The continuous measurement is suitable for monitoring the evolution of a measured quantity in time, for example for adjustments.

Note: *In remote mode, the counting measurement (counting mode) is available as a further measurement mode with a defined number of measurement cycles to be performed, see chapter 6 of this manual. The Stop Condition setting can affect the Single Shot and Continuous repetition modes.*

Remote control

```
CONFigure:MODulation:MQuality[:OQPSk]:CONTrol
CONFigure:MODulation:MQuality:HPSK:CONTrol
CONFigure:MODulation:MQuality:QPSK:CONTrol
    CONTinuous | SINGleshot | 1 ... 10000,<StopCondition>,
    <Stepmode> etc.
```

Stop Condition

The *Stop Condition* field defines a stop condition for the measurement:

- NONE* Continue measurement irrespective of the results of the limit check
- On Limit Failure* Stop measurement as soon as the limit check fails (one of the tolerances is exceeded)

The *Stop Condition* setting is valid for both the *Single Shot* and *Continuous* repetition modes.

Remote control

```
CONFigure:MODulation:MQuality[:OQPSk]:CONTrol
CONFigure:MODulation:MQuality:HPSK:CONTrol
CONFigure:MODulation:MQuality:QPSK:CONTrol
    <Repetition>,<SONerror | NONE, <Stepmode> etc.
```

Display Mode

The *Display Mode* field defines which of the four measured and calculated statistical measurement results is displayed. The measurement results differ in the way the waveform interval Modulation $p(t)$ at a fixed point in time t is calculated if the measurement extends over several waveform intervals; see section *Common Settings* in Chapter 3:

- Current* Measured value for current waveform interval
- Minimum/Maximum* Extreme value of a number of waveform intervals
- Average* Average value over a number of waveform intervals

The number of waveform intervals for calculation of the statistical values *Minimum/Maximum* and *Average* – and thus the result – depends on the repetition mode set. In detail, this implies:

- Single shot* Display of minimum/maximum and average value from the performed statistics cycle.
- Continuous* Display of minimum/maximum from all waveform intervals already measured. The **average value**, however, is calculated according to the rule in Chapter 3, section *General Settings*.

Remote control

no display mode set, the READ..., FETCh... and SAMPlE commands retrieve all values.

Statistic Count The input field *Statistic Count* defines the length of the statistics cycles in waveform intervals.

The settings *1* and *OFF* (press *ON/OFF* key) are equivalent. A statistics cycle determines the duration of single-shot measurements.

Remote control

```
CONFigure:MODulation:MQuality[:OQPSk]:CONTrol
CONFigure:MODulation:MQuality:HPSK:CONTrol
CONFigure:MODulation:MQuality:QPSK:CONTrol
<Statistics>, <Repetition>, <Stop Cond>, <Step Mode>
```

Side Band Freq. Offset The *Side Band Freq. Offset* input field sets the frequency offset used for the *Sideband Suppression* power measurement; see section [Measurement Results](#) on p. 4.1 ff. The sideband suppression is measured at the two offset frequencies symmetrical to the *RF Frequency* (lower and upper sideband suppression).

In remote control up to 4 different frequency offsets can be defined so that up to 8 symmetrical sideband suppression values are available:

```
CONFigure:MODulation:MQuality:<Application>:CONTrol:FOFFset:
SBSuppress:ACP<nr>, where <nr> = 1 to 4
```

Modulation Configuration – Limits

The *Limits* tab defines upper and lower error limits for the measured values of all three *Modulation* measurement applications. The limits are set independently for the display modes *Current* and *Max./Min.* on one hand, *Average* on the other hand; see section [Measurement Control \(Modulation Configuration – Control\)](#) on p. 4.8 ff. All measured values are described in section [Measurement Results](#) on p. 4.6 ff.




Figure 4-5 Modulation Configuration – Limits

Default All Settings The *Default All Settings* switch assigns default values to all parameters of the *Limits* tab. The default values are quoted in the command description in chapter 6 of this manual. In addition, default switches for the individual applications and statistical modes are provided.

Remote control

```
DEFAult:MODulation:MQuality:LIMit  ON | OFF  
DEFAult:MODulation:MQuality:<Application>:CMMax:LIMit  
DEFAult:MODulation:MQuality:<Application>:AVERAge:LIMit
```

**Current &
Max/Min**

Current and Max/Min sets the limits for the measured values in the current waveform interval or of the extreme values of all measured waveform intervals (*Min/Max*).

Remote control

```
CONFIgure:MODulation:MQuality:<Application>:CMMax:LIMit
```

Average

Average sets the limits for the average value of the measured values obtained according to the averaging rules of Chapter 3, section *General Settings*.

Remote control

```
CONFIgure:MODulation:MQuality:<Application>:AVERAge:LIMit
```

Power Measurements

The main menu *Power* determines the power of the received RF signal.

- The measurement control softkey *NPower* controls the measurement, indicates its status (*RUN* | *HLT* | *OFF*) and opens the configuration menu *Power Configuration*. The hotkeys associated to the measurement control softkey define the scope of the *Power* measurement.
- The other softkeys on the right side are combined with various hotkeys (e.g. the hotkeys *RF Frequency* and *Frequency Offset* belong to the softkey *Analyzer Settings*). The softkey/hotkey combinations provide test settings and switch over between different measurements.

Narrow band power

The *NPower* (*Narrow band power*) measurement yields the average, minimum and maximum power of an RF input signal in an evaluation period of variable length plus a statistical evaluation over several periods; see section [Measurement Results](#) on p. 4.13 ff. A fixed oversampling rate of 4 is used.

The measurement is performed with the receiver filter specified for CDMA conformance tests and at the frequency specified in the *Analyzer Settings*.

Power vs. Frame

In the *Power vs. Frame* application, the average power of the RF input signal can be measured in up to 100 equidistant evaluation periods (frames) of variable length. The test cycle can be subdivided into several intervals with specific analyzer settings (*RF Max. Level*) so that the entire dynamic range of the CMU is available. *Power vs. Frame* is a real-time measurement that was primarily designed for fast and accurate evaluation of defined power steps of a transmitter over a wide dynamic range.

The measurement is performed with the receiver filter specified for CDMA conformance tests and at the frequency specified in the *Analyzer Settings*. A measurement example is reported in Chapter 2.

The main menu *Power* is opened from the main menu *Menu Select* (with associated key at front of instrument). It can also be accessed from the other measurement menus of the function group *RF* via the *Power* hotkey.




Fig. 4-6 Measurement menu Power

Test Settings

The *Power – NPower* measurement is controlled by means of the measurement control softkey below the *Connect. Control* softkey and the associated hotkeys. The properties of the measurement control

softkeys are analogous in all measurements; see section [Measurement Control](#) on p. 4.4 ff; the hotkey functions are also provided in the *Control* tab of the *Power Configuration* menu; see section [Power Configuration](#) on p. 4.15 ff. The remaining softkeys provide common settings; see section [Common settings](#) on p. 4.5 ff.

**Appli-
cation**

The *Application* softkey selects the measurement application. The measurement control softkey (second softkey below *Connect. Control*) indicates the current application. The corresponding measurement results are explained in section [Measurement Results](#) on p. 4.13 ff.

NPower

The *NPower* hotkey selects the measurement of the peak and average power including a statistical evaluation (narrow band power).

Remote control

The *NPower* application corresponds to the `NPOWer` subsystem.

**Power
vs. Frame**

The *Power vs. Frame* hotkey selects the measurement of the average power in up to 100 equidistant evaluation periods (frames).

Remote control

The *Power vs. Frame* application is selected by the keyword `XSLot` in the 3rd level of the `POWer` commands, e.g. `CONFigure:POWer:XSLot...`

Measurement Results

The results displayed in the *Power* menu depend on the selected application. All results are obtained with the receiver filter specified for CDMA conformance tests and at the frequency specified in the *Analyzer Settings*.

NPower

The *Power – NPower* results are displayed in several groups of output fields. The statistical evaluation is based on a basic evaluation period which is given by the *Capture Buffer Size* and a fixed oversampling factor of 4 and on the statistics cycle (*Statistic Count*) defined in the configuration menu (see section [Power Configuration](#) on p. 4.15 ff.; for a general description of statistical evaluations in the CMU refer to Chapter 3, section *General Settings*).

10.50	dBm	Maximum	Power (Current)
10.35	dBm	Average	
10.61	dBm	Minimum	
10.48	dBm	Maximum	Power (Statistic)
10.45	dBm	Average	
10.51	dBm	Minimum	
2000		Statistic Count	

Power (Current) Average, minimum and maximum power of the RF input signal in the current evaluation period.

Power (Statistic) Average, minimum and maximum of the *Power (Current)* values: The *Maximum (Minimum)* value is the largest (smallest) power ever measured in the current measurement. *Average* is the average over all *Average – Power (Curr.)* values in the current measurement, obtained according to the averaging rules described in Chapter 3, section *General Settings*.

Statistic Count Number of evaluation periods per statistics cycle. The colored bar indicates the relative measurement progress in the statistics cycle

Power vs. Frame

The *Power vs. Frame* results are displayed in a table with up to 100 entries.




Fig. 4-7 Display of measurement results (Power vs. Frame)

Results

The *Power vs. Frame* application measures the average power of the RF input signal in up to 100 equidistant evaluation periods (frames) of variable length. The length and distance of the individual frames and the *RF Max. Level* settings are defined in the *Power Configuration* menu; see p. 4.15 ff.

The table displays up to 100 results (numbered 0 to 99) at the same time (see *Step Count* parameter in section *Power Configuration* on p. 4.15 ff.). If the *Step Count* is set to a number < 100, the table shows (" - -") for all results that are not measured. No limit check is performed.

A blue asterisk in the table denotes the beginning of a new step interval where the *RF Max. Level* is changed. The step intervals are also defined in the *Power Configuration* menu.

The CMU RF input path configuration (*RF Max. Level*) must be set in accordance with the expected RF input power. The *Power vs. Frame* table shows invalid results (" - -") for slots where the *Max. Level* is exceeded.

Note: *The measurement results are obtained and displayed in real time. With a default Step Width of 20 ms, the time to measure 50 consecutive slots is 1 second. In Continuous measurements (Repetition = Continuous), this results in a high update rate of the table.*

Remote control

```
READ[:SCALar]:POWER:XSLOT:CURRENT?
FETCH[:SCALar]:POWER:XSLOT:CURRENT?
SAMPLE[:SCALar]:POWER:XSLOT:CURRENT?
```

Test settings

The essential trigger, analyzer and generator settings (as set via the *Trigger/Analyzer Level* and *Generator Level* softkeys or in the corresponding tabs of the *Connection Control* menu) are indicated in the *Settings* table. A message *RF Max. Level Deviation Step* is displayed if intervals with different *RF Max. Level* settings are used.

Power Configuration

The popup menu *Power Configuration* configures the *Power* measurement. It is opened by pressing the *NPower* measurement control softkey in the *Power* menu twice.

The settings can be defined separately for the different applications of the *Power* measurement group.

The *Control* tab of the *Power Configuration* menu defines the scope of the measurement:

- The *Repetition* mode
- The *Statistic Count* for the *Narrow Band Power* measurement, the *Step Count* for *Power vs. Frame*
- The number of samples per single shot *Narrow Band Power* measurement (*Capture Buffer Size*), the *Power Meas. Width* for *Power vs. Frame*

The following settings configure the *Power vs. Frame* measurement:

- The duration of the power steps (*Step Width*) and of the evaluation period (*Power Meas Width*)
- Up to 5 independent input level settings (*RF Max. Level Deviation*)




Fig. 4-8 Power Configuration – Control

The *Repetition* and *Statistic Count* settings are analogous to the *Analyzer/Generator* menu; see section [Measurement Control \(Modulation Configuration – Control\)](#) on p. 4.8 ff. Note that the basic evaluation period for a single-shot narrow band power measurement is given by the number of samples defined via *Capture Buffer Size*.

Default Settings The *Default All Settings* switch assigns default values to all settings in the *Control* tab (the default values are quoted in the command description in chapter 6 of this manual).

Remote control
–

Capture Buffer Size *Capture Buffer Size* specifies the number of samples acquired to calculate a single shot narrow band power result (*Power (Current)* values in the measurement menu). A fixed oversampling factor of 4 is used so that the duration of the measurement interval (evaluation period) is proportional to the capture buffer size. The start of the measurement is determined by the trigger settings; with *Free Run* trigger, it is unsynchronized.

Increasing the number of samples slows down the measurement but may be necessary to obtain meaningful results, because CDMA2000 signals typically show rapid variations in time and a large crest factor.

Remote control
 CONFigure:NPOWer:CONTRol:CBSize

The remaining settings configure the *Power vs. Frame* measurement. The parameters are shown in Fig. 4-9 below where a signal with decreasing power steps is measured with two different *RF Max. Level* settings. The shaded rectangles denote the actual measurement intervals.




Fig. 4-9 Power vs. Frame test cycle

Note: Trigger Settings for Power vs. Frame

The Power vs. Frame measurement requires a trigger event synchronized with the power steps. The easiest way of providing this is to use an IF Trigger with appropriate trigger level. Use of an external trigger signal is possible. Use of free run mode only makes sense in very special applications.

Step Count Step Count defines the number of measurement intervals where the CMU acquires data. Each *Power vs. Frame* result is the average of all samples in a measurement interval, so Step Count is equal to the number of results in the output table.

Remote control
 CONFigure:POWer:XSLot:CONTRol:SCount

Step Delay Integer number of steps between the trigger event and the beginning of the first measurement interval. This parameter can be used to skip a time period where no result is needed instead of adapting the *RF Max. Level Deviation* configuration to the expected input power.

Remote control
 CONFigure:POWer:XSLot:CONTRol:SDElay

Step Width Time difference between the beginning of two consecutive measurement intervals. Typically this value is set to the duration of a power step of the transmitter (frame length) so that the measurement yields the RMS power in each of the consecutive steps.

The allowed range for the step width and the *Power Meas. Width* ensures that the CMU is able to acquire a result in each of a series of consecutive steps, even though the *RF Max. Level* may be changed.

Remote control

CONFigure:POWer:XSLot:CONTRol:SWIDth

Power Meas. Width

Duration of the measurement interval in ms. The power meas. width must not exceed half of the step width. The measurement interval is always centered on the power step.

Remote control

CONFigure:POWer:XSLot:CONTRol:PMWidth

RF Max. Level Deviation

Defines the *RF Max. Level* to be used for each of the measured power steps. All levels are relative to the *RF Max. Level* defined by means of the *Analyzer Level* softkey or in the *Connection Control* menu (see section [Analyzer Control \(Connection Control – Analyzer\)](#) on p. 4.20 ff.). It is possible to define up to 5 continuous ranges of power steps with a maximum RF level different from the analyzer *RF Max Level*.

Analyzer RF Max. Level Maximum RF input level *RF Max. Level* and *RF Mode* defined in the *Connection Control* menu. The values can not be edited here. To perform a *Power vs. Frame* measurement, the RF Mode must be set to *Manual*.

Step Interval 1 to 5 RF Max. Level to be used in a continuous range of power steps relative to the indicated *Analyzer RF Max. Level. @ Step Number* denotes the first step in the interval. As each interval ranges up to the beginning of the next interval, the step numbers must be in ascending order.

Example 1: *Analyzer Max. Level setting: 0 dBm*

Step Count: 50

Step Interval 1: –30 dBm at step number 25, all other step intervals off.

→ *The maximum RF level in steps 0 to 24 is 0.0 dBm.*

In steps 25 to 49 it is –30 dBm.

Example 2: *Analyzer Max. Level and Step Count setting as in example 1.*

Step Interval 5: –30 dBm at step number 1.

→ *As the step number must be ascending, the RF Max Level Deviation is set to OFF in step intervals 1 to 4.*

The maximum RF level for all steps is –30 dB.

Note: *The purpose of the step intervals is to make use of the complete dynamic range of the CMU while keeping the switching points for the RF Max. Level at definite positions. To ensure a maximum accuracy of the measurement, the number of step intervals should be reduced to a minimum. If the Analyzer RF Max. Level is adjusted to the maximum transmitter output power of the DUT, 2 intervals like in the example above are usually sufficient to measure the entire output power range.*

Remote control

CONFigure:POWer:XSLot:CONTRol:SINterval

CONFigure:POWer:XSLot:CONTRol:SINterval:DEVIation

CONFigure:POWer:XSLot:CONTRol:SINterval:SNUMber

IQ Access

The *IQ Access* menu controls the IQ Access Board and configures the RF generator signal while the board is used for measurements. The menu is available with option CMU-B82, *Access Board for CDMA Signalling Units CMU-B81 and CMU-B83*. The access board provides an interface to the CMU-B83 CDMA Signalling Unit. It can be used to

- Access the baseband digital Rx and Tx I/Q data and timing signals
- Use all of the CMU200's calibrated front end, attenuators, and measurement capabilities

For more information refer to the separate CMU-B82 operating manual, stock no. 1150.0299.32.

The *IQ Access* menu can be opened from the *Menu Select* menu (with associated key at the front of the instrument) or using the *IQ Access* hotkey associated to the *Menus* softkey in the other measurement menus of function group *CDMA2000 Non Signalling*. While *IQ Access* is active the CMU's RX and TX resources are reserved for access board applications so that the other measurements are suspended.

The access board can not be used in *Signalling* mode.

Audio Measurements

The menu group *Audio* comprises the functions for generating and measuring single or multitone audio signals. The menu group is available with option CMU-B41, *Audio Generator and Analyzer*. All *Audio* menus and remote-control commands are described in the CMU 200/300 operating manual.

The *Audio* option supports two independent test circuits. In *Non Signalling* mode the input and output connectors for both circuits are fixed; they are indicated in the *Audio* measurement menu. This test mode corresponds to the standalone audio tests described in the CMU 200/300 operating manual.

In *Signalling* mode, it is possible to send and receive audio data modulated onto the RF carrier and thus test the audio circuit of a connected mobile phone (see section *CDMA Measurements – AF/RF Connectors (Connection Control – AF/RF)*).

Modulation / Spectrum / Code Domain Power Measurements

The *Modulation*, *Spectrum*, and *Code Domain Power* measurements are described in section *CDMA Measurements (Signalling mode)* below. The *Non Signalling* measurements provide the same test settings and measurement results than the corresponding *Signalling* measurements.



The environment settings for the individual measurements are not available in Non Signalling mode: The measurement is always performed with the general Connection Control parameters.

The trigger conditions for the measurements are described in [Table 4-3](#) on p. 4.37.

Connection Control

In *Non Signalling* mode, the *Connection Control* menu consists of tabs to configure the inputs and outputs of the CMU and the respective signals in the function group *CDMA2000 Non-Signalling*, define the network standard, the trigger settings and the routing of I/Q and IF signals.

The menu group is activated using the softkey *Connect Control* to the right of the header of the measurement menu. The individual tabs (*Standard*, *Analyzer*, *Generator*, *AF/RF* \odot , *Sync.*, *Trigger*, *I/Q-IF*) can be accessed using the hotkeys at the bottom of the screen.

Network Standard (Connection Control – Standard)

The popup menu *Standard* defines which network and standard is used for testing.




Figure 4-10 Connection Control – Standard

Refer to Table 1-1 in Chapter 1 for a list of the supported CDMA2000 networks.

Analyzer Control (Connection Control – Analyzer)

The *Analyzer* tab configures the RF input path by defining the analyzer level and frequency.




Figure 4-11 Connection Control – Analyzer Settings

Default All Settings The *Default All Settings* switch assigns default values to all settings in the *Analyzer* tab (the default values are quoted in the command description in chapter 6 of this manual).

Remote control
`DEFault:RFANalyer`

Analyzer Level – RF Mode The *Analyzer Level* table section sets the maximum input level that can be measured. Two alternative *RF Modes* for defining this value are provided:

- Manual* Manual input of maximum input level in the *RF Max. Level* field
- Auto* Automatic setting of maximum input level (*autoranging*) according to the peak power (PEP) of applied signal

Remote control
`[SENSe:]LEVel:MODE MANual | AUTomatic`

Analyzer Level – RF Max. Level The maximum expected input level can be entered in the *RF Max. Level* input field. Input levels exceeding the *RF Max. Level* overdrive the input path and cause invalid results (“---”).

Remote control
`[SENSe:]LEVel:MAXimum <Level>`

External input attenuation The range of *RF Max. Level* values depends on the RF input used. If an external input attenuation is reported to the instrument to compensate for a known path loss (see section *AF/RF Connectors (Connection Control – AF/RF)* on page 4.28), all levels measured are referenced to the output of the DUT and therefore shifted with respect to the actual level at the input connectors of the CMU. The level ranges for the input connectors are shifted as well.

Error messages If the *RF Max. Level* is too high or too low, a window with the error message "*<Max_Level> is out of range. <permissible max. value> is limit.*" and three fields will appear:

Accept The permissible max. value is accepted as *RF Max. Level*,
Re-edit *RF Max. Level* is entered once again,
Cancel The last valid input value is maintained.

When switching over to another input, the current value of *RF Max. Level* is automatically adapted, if required:

- Towards lower values to the maximum value of the new input,
- Towards upper values to the minimum value of the new input.

Note: *A maximum input level can be entered even if automatic level setting (autoranging) is selected. The entered level is used as a start value for the autoranging routine and is also important to ensure safe switchover to manual setting.*

Analyzer Settings – RF Channel [<>]

RF Channel defines the base station channel number (and frequency) of the generated RF signal. The brackets contain the current bandclass of the selected network.

The default settings for the channel numbers depend on the network selected. Changing the *RF Channel* also changes the *RF Frequency* setting.

Table 1-1 in Chapter 1 lists the networks and standards supported by the CMU with the CDMA2000 options.

Remote control

```
[SENSe:]RFANalyzer:FREQuency <Frequency>
```

Frequency Offset

Frequency Offset determines a frequency offset to impair the RF analyzer signal.

Remote control

```
[SENSe:]RFANalyzer:FOFFset <Analyzer Freq. Offset>
```

Generator Control (Connection Control – Generator)

The popup menu *Generator* configures the signals generated by the CMU. The CMU provides a softkey-oriented version of the *Generator* tab and a table-oriented version with extended functionality. The *Generator* hotkey toggles between the two versions if it is pressed repeatedly.

Softkey-Oriented Version

The softkey-oriented version of the *Generator* tab controls the RF generator and defines the level in all physical channels contributing to the generated forward CDMA signal.




Figure 4-12 Connection Control – Generator (softkey)

Generator

The *Generator* softkey defines the generator level and indicates the operating status of the RF generator (ON or OFF). Pressing the *Generator* softkey and the ON/OFF key switches the generator on or off.

The input field associated to the *Generator* softkey adjusts the total CDMA output power. The *CDMA Power* does not include the AWGN power. The total output power including the AWGN power is displayed in the table-oriented version of the *Generator* tab.

Remote control

```
INITiate:RFGenerator
ABORT:RFGenerator
FETCh:RFGenerator:STATus?
SOURce:RFGenerator:POWer:CDMA <CDMA Power>
```

F-FCH Level

The *F-FCH Level* softkey adjusts the signal level of the Fundamental Channel in the forward CDMA channel.

F-FCH Level specifies the FULL frame rate traffic channel level. If a frame rate other than FULL is used, the actual test traffic level is lower:

$$\text{Test traffic level} = \text{F-FCH Level} + \text{Corr.}$$

The level definition for FULL frame rate has been chosen because it is always valid, even for speech connections where the frame rate varies according to the voice activity.

The level correction values *Corr.* are listed in the table below.

	RC 1		RC 2		RC 3, 4		RC 5	
	bps	Corr./ dB	bps	Corr./ dB	bps	Corr./ dB	bps	Corr./ dB
Full	9600	0	14400	0	9600	0	14400	0
Half	4800	-3	7200	-3	4800	-3	7200	-3
Quarter	2400	-6	3600	-6	2700	-5.5	3600	-6
Eighth	1200	-9	1800	-9	1500	-8	1800	-9

Remote control

```
SOURce:RFGenerator:LEVel:FFCH <FFCH Level>
```

**F-PCH
Level**

The *F-PCH Level* softkey adjusts signal level of the Paging Channel in the forward CDMA channel relative to the total output power.

Remote control

```
SOURce:RFGenerator:LEVel:FPCH <FPCH Level>
```

**F-Sync
Level**

The *F-Sync Level* softkey adjusts the signal level of the Sync Channel in the forward CDMA channel.

Remote control

```
SOURce:RFGenerator:LEVel:FSYnc <FSYnc Level>
```

**F-PICH
Level**

The *F-PICH Level* softkey adjusts the signal level of the Pilot Channel in the forward CDMA channel.

Remote control

```
SOURce:RFGenerator:LEVel:FPICH <FPICH Level>
```

**F-OCNS
Level**

The *OCNS* softkey displays a popup window to turn the Orthogonal Channel Noise Simulator. Setting this to *ON* ensures a defined Output Power level.

Remote control

```
SOURce:RFGenerator:LEVel:OCNS:ENABle ON | OFF
```

Table-Oriented Version

The table-oriented version of the *Generator* tab provides all settings described in section [Table-Oriented Version](#) on p. 4.24 ff. In addition, it defines the power control bits sent to the MS to control its output power (*Power Control*).




Figure 4-13 Connection Control – Generator (table)

The following settings are not provided in the table-oriented version of the *Generator* tab:

Default All Settings The *Default All Settings* switch assigns default values to all settings in the *Analyzer* tab (the default values are quoted in the command description in chapter 6 of this manual).

Remote control
 DEFault:RFGenerator ON | OFF

Generator Level – Output Power *Output Power* displays the total output power. The total *Output Power* level includes the AWGN power level. In contrast the *CDMA Power* can be set and does not include the AWGN power.

Remote control
 SOURce:RFGenerator:POWER:OUTput?

Impairments–AWGN Level *AWGN Level* turns on or off the Additive White Gaussian Noise generator and sets the level for modulation. This provides noise to more closely simulate actual operating conditions in the network.

Note: The total output power of the CMU is the sum of the Forward CDMA signal plus the AWGN signal. The CMU automatically limits the AWGN signal level so that the maximum possible total output power of the CMU's RF connector is not exceeded.

	<p>Remote control <code>SOURCE:IMPAIRMENTS:LEVEL:AWGN <AWGN Level></code></p>
Impairments– BS Freq. Offset	<p><i>BS Freq. Offset</i> adjusts the carrier frequency of the CMU/base station. This setting is disabled if the <i>RF Frequency</i> is adjusted away from a standard <i>RF Channel</i> frequency.</p> <p>Remote control <code>SOURCE:IMPAIRMENTS:FOFFSET[:RF] <Freq. Offset></code></p>
Generator Settings – Gen. Modulation	<p><i>Generator Modulation</i> selects the method used to modulate the generated RF signal. <i>AUTomatic</i> generates a CDMA2000 signal according to channel configuration. <i>OFF</i> generates an empty carrier signal (continuous wave).</p> <p>Remote control <code>SOURCE:RFGENERATOR:MODULATION:MODE AUTOMATIC OFF</code></p>
RF Channel	<p>The <i>RF Channel</i> sets the base station channel number (and frequency) of the generated RF signal. Changing the RF Channel resets the RF Frequency setting. The default settings for the channel numbers are dependent on the network selected.</p> <p>Table 1-1 in Chapter 1 lists the networks and standards supported by the CMU with the CDMA options.</p> <p>Remote control <code>SOURCE:RFGENERATOR:CHANNEL:FFCH <FFCH Channel></code></p>
F-FCH Channel	<p><i>F-FCH Channel</i> sets the fundamental channel to use in the forward CDMA channel. The CMU automatically shifts an OCNS channel if channel conflicts occur. Changing this value causes a hard handoff to be performed (if a call is established). Refer to page 4.23 for more information on OCNS channels.</p> <p>Remote control <code>SOURCE:RFGENERATOR:CHANNEL:FFCH <FFCH Channel></code></p>
F-FCH QOF	<p><i>F-FCH QOF</i> selects the Quasi-Orthogonal Function of the Forward Fundamental Channel. A fixed QOF of 0 is used if the forward radio configuration (<i>F-RC</i>) is set to 1 or 2. Radio configurations 3, 4, and 5 can take QOF 0, 1, 2, and 3.</p> <p>Remote control <code>SOURCE:RFGENERATOR:QOF:FFCH</code></p>
F-FCH Frame Offset	<p><i>F-FCH Frame Offset</i> sets the frame offset in the forward fundamental channel. Changing the frame offset immediately changes the traffic channel timing.</p> <p>Remote control <code>SOURCE:RFGENERATOR:FROFFSET:FFCH <Frame Offs></code></p>
F-FCH Frame Rate	<p><i>F-FCH Frame Rate</i> sets the frame rate to Full, Half, Quarter, or Eighth.</p> <p>Remote control <code>SOURCE:RFGENERATOR:FRATE:FFCH <Frame Rate></code></p>
PN Offset	<p><i>PN Offset</i> sets the offset of the PN sequence. Changing the PN offset changes the timing of the pilot channel, the timing and contents of the sync channel message, and the long code mask of the paging channel.</p>

Remote control

SOURCE:RFGenerator:PROPERTY:PNOFFset <PN Offset>

The following parameters can be sent to the mobile so that it can synchronize to the forward CDMA2000 signal and enter the test mode.

Radio Config. / F-RC F-RC sets Radio Configuration to use for the Forward Fundamental Channel. With radio configuration 1 or 2, the F-FCH QOF is fixed to 0.

The forward transmission format (*Rate Set*) is not selectable; it is 1 for radio configurations 1, 3, and 4; it is 2 for radio configurations 2 and 5. Rate Set 1 comprises the set of data rates 9.6, 4.8, 2.7/2.4, 1.5/1.2, and all integral multiples of 9.6 kbps. Rate Set 2 comprises the set of data rates 14.4, 7.2, 3.6, 1.8, and all integral multiples of 14.4 kbps.

Remote control

SOURCE:RFGenerator:RC

SOURCE:RFGenerator:RSET?

System ID Number Sets the System Identification communicated to the mobile under test.

Remote control

SOURCE:RFGenerator:SID

Protocol Revision Sets the preferred version of the protocol for the CMU to use.

Remote control

SOURCE:RFGenerator:PREVIsion

Min. Protocol Revision Sets the minimum protocol revision capability of the mobile station.

Remote control

SOURCE:RFGenerator:MPRevision

Network ID Number Sets the 16-bit Network Identification communicated to the mobile under test.

Remote control

SOURCE:RFGenerator:NID

Paging Channel Rate Sets the data rate of the base station's paging channel.

Remote control

SOURCE:RFGenerator:PCHannel:RATE

ESN Sets the Electronic Serial Number of the mobile station; 32-bit number entered as an 8-digit hex string. The ESN is used to generate the long code mask of the R&S CMU unless *Zero Long Code Mask* is disabled.

Remote control

SOURCE:RFGenerator:ESN

Zero Long Code Mask Enables or disables the long code mask calculated from the mobile's ESN (public long code mask).

Off The calculated long code mask is used to scramble the forward CDMA2000 signal. If the mobile can synchronize to the signal, the reverse channels will be scrambled as well. The R&S CMU can use the

information about the long code mask in order to demodulate the reverse signal.

On A long code mask consisting of all zeros is used so that the data transmitted on the forward and reverse link is unscrambled. The unscrambled data can be demodulated even though the mobile may not be able to synchronize to the forward CDMA2000 signal. The state of the long code is irrelevant.

Remote control

SOURCE:RFGenerator:ZLCM ON | OFF

Power Control *Power Ctl. Bits* defines the Power Control Bit (PCB) sequence that the CMU sends to the mobile station to control its total output power (closed loop power control).

Note: *The power control bits must be compatible with the measurement task. All PCB modes except Auto can drive the MS transmitter outside the power range necessary for a particular measurement.*

Auto Active closed loop power control: the CMU sends the power control bits needed to control the MS transmitter output power to the expected value (equal to the *RF Max. Level*, see section [Analyzer Control \(Connection Control – Analyzer\)](#) on p. 4.20 ff.). The *RF Max. Level* is also indicated in the *Settings* table of the *Analyzer/Generator* menu.

Hold The CMU sends alternating *up/down* power control bits.

All Down The CMU sends only *down* power control bits. This will cause the mobile station’s power level to decrease to a level too low for measurements to be made.

All Up The CMU sends only *up* power control bits.

Range Test The CMU sends a sequence of 128 *up* power bits (= 8 frames) followed by a sequence of 128 *down* power bits.

Pattern Use the bit sequence defined in the *Pattern* section.

Off No bits are sent to the mobile station.

Remote control

CONFIGure:RFGenerator:PCBits <Power Control Bits>

Pattern – Sequence Mode *Sequence Mode* selects an algorithm to construct the complete user-defined pattern from the single bit pattern <*Pattern*> defined in *Area 1* to *Area 4*; see [Table 4-2](#) below.

Remote Control

CONFIGure:RFGenerator:PCBits:PATTERN:SQMode
PREP | PFBA | PFBH

Table 4-2 Single pattern and Sequence Mode

Sequence Mode	Complete transferred pattern for a single pattern <Pattern>
Pattern Repeated	<Pattern><Pattern><Pattern>...
Pattern followed by Auto	<Pattern>, then active closed loop power control
Pattern followed by Hold	<Pattern>01010101....

Pattern – Area 1 / ... / Area 4 Area 1, ..., Area 4 contains the parameters to define the single bit pattern <Pattern>. <Pattern> is composed of 4 areas with variable length ≥ 1 (Number of Bits) but constant Polarity.

Example: 000011110 is valid <Pattern>. The following combination of parameters can be used to define this pattern:

Area 1,	Number of Bits	4
	Last Hold Bit	Down
Area 2,	Number of Bits	1
	Polarity	Up
Area 3,	Number of Bits	3
	Polarity	Up
Area 4,	Number of Bits	1
	Polarity	Down

Remote Control CONFIGure:RFGenerator:PCBits:PATtern:AREA<nr>:NOBits
 CONFIGure:RFGenerator:PCBits:PATtern:AREA1:LHBit
 CONFIGure:RFGenerator:PCBits:PATtern:AREA<nr>:POLarity

AF/RF Connectors (Connection Control – AF/RF)

The AF/RF  tab configures the connectors for RF signals. This includes defining:

- The RF input and output of the CMU (RF Output, RF Input).
- External attenuation at the connectors (Ext. Att. Output, Ext. Att. Input) including a possible Frequency-Dependent attenuation.

The tab also controls the wideband peak power measurement (Wideband Power) and indicates the result.




Figure 4-14 Connection Control – RF connectors

RF Output

The *RF Output* softkey defines which of the three connectors RF 1, RF 2 and RF 3 OUT is to be used as the RF output connector. The symbol \odot indicates the selected RF output.

Note: Input and output connectors can be arbitrarily combined. The bi-directional connectors RF 1 and RF 2 can be selected as RF inputs and outputs at the same time. The front panel LEDs are on (lit) if the generator is switched on or the modulation test is started.

Remote control


```
OUTPut[:STATe] RF1 | RF2 | RF3
```

Ext. Att. Output

The *Ext. Att. Output* softkey defines an external attenuation (or gain, if the value is negative) at the selected RF output.

External attenuation is required if attenuation (such as a cable) is included in the test setup path, which is to be corrected by an increased signal level.

If an external attenuation is defined, the output signal level is referenced to the input of the device under test (DUT), the generator level is therefore shifted with respect to the actual level at the output connector of the CMU. The default value for the generator power and the level ranges for the RF outputs are also shifted provided that the generator can output the required power, compensating for the external attenuation or gain. Otherwise it is adapted to the level closest to the shifted default value.



Pressing *Ext. Att. Output* twice opens a popup menu to define the external output attenuation factors as a function of the RF output (generator) frequency. See section [Frequency-Dependent External Attenuation](#) on p. 4.31 ff.

Remote control

```
[SENSe:]CORRection:LOSS:OUTPut<nr>[:MAGNitude]
SOURce:CORRection:LOSS:OUTPut<nr>[:MAGNitude]
```

RF Input

The *RF Input* softkey defines which of the three connectors RF 1, RF 2, or RF 4 IN is to be used as the RF input connector. The symbol \odot indicates the selected RF input.

Note: *Input and output connectors can be arbitrarily combined. The bi-directional connectors RF 1 and RF 2 can be selected as RF inputs and outputs at the same time. The front panel LEDs are on (lit) if a measurement is active.*

Remote control


```
INPut[:STATe] RF1 | RF2 | RF4
```

Ext. Att. Input

The *Ext. Att. Input* softkey sets the value of the external attenuation (or gain) at the selected RF input.

Input of an external attenuation is required if, for example, external attenuator pads are used for protection of the sensitive RF inputs of the CMU or if path attenuation is included in the test setup.

If an external input attenuation is reported to the instrument, all levels measured are referenced to the output of the DUT and therefore shifted with respect to the actual level at the input connectors of the CMU. The level ranges for the input connectors are shifted as well.



Pressing *Ext. Att. Input* twice opens a popup menu to define the external input attenuation factors as a function of the RF input (analyzer) frequency. See section [Frequency-Dependent External Attenuation](#) on p. 4.31 ff.

Remote control

```
[SENSe:]CORRection:LOSS:INPut<nr>[:MAGNitude]
SOURce:CORRection:LOSS:INPut<nr>[:MAGNitude]
```

Wideband Power

The *Wideband Power* softkey controls the wideband power measurement and indicates its status (*RUN* | *HLT* | *OFF*). The status can be changed after softkey selection (pressing once) by means of the *ON/OFF* key or the *CONT/HALT* key. The measurement result is in units of dBm. The analog bar to the right of the softkey shows the measured power relative to the *RF Max. Level* (see section [AF/RF Connectors \(Connection Control – AF/RF\)](#) on page 4.28): The display range is between *RF Max. Level – 10 dB* and *RF Max. Level + 10 dB*.


The wideband power measurement is performed at the RF Frontend of the CMU and yields the peak power of the input signal inside a wide frequency range. It is most accurate in the input level range around 0 dBm (typically –10 dBm to +30 dBm on RF2). The main purpose of the wideband power measurement is to indicate whether an input signal is available and whether it is advisable to change the *Max Level* settings.

Note: *An additional quick and precise power measurement is available in remote control (keyword `NPOWER`).*

Remote control

```
INITiate:WPOWER
FETCh:WPOWER:STATus?
READ[:SCALar]:WPOWER?
FETCh[:SCALar]:WPOWER?
SAMPle[:SCALar]:WPOWER?
```

Frequency-Dependent External Attenuation

The *Freq. Dep. Att.* softkey in the *RF*  tab of the *Connection Control* menu opens a popup menu to define the external input and output attenuation factors as a function of the RF input (analyzer) and output (generator) frequency. The frequency-dependent attenuations have the same meaning and effect as the global (frequency-independent) attenuations *Ext. Att. Input* and *Ext. Att. Output*:

- A positive (negative) output attenuation increases (decreases) the RF generator level so that the generator compensates for the external attenuation or gain.
- A positive (negative) input attenuation increases (decreases) the displayed RF analyzer level so that the displayed result corresponds to the output transmit power of the DUT.

Frequency-dependent attenuations replace the global (frequency-independent) attenuations *Ext. Att. Input* and *Ext. Att. Output*. In contrast to the global attenuations, they are valid for all function groups (in remote control, the commands must be addressed in the R&S CMU base system).




Fig. 1 Frequency-dependent attenuation

Default Settings Disables the frequency-dependent correction and sets all frequency values and all external attenuation factors to *Off*.

Correction Enable Enables the frequency-dependent attenuations, causing the global input and output attenuation to be replaced. A red status message in the *RF* \odot tab indicates that the frequency-dependent attenuations are enabled.

f₁ to f₅₀ List of 50 frequency values, to be set to a specific frequency in the RF input/output frequency range of the R&S CMU (see data sheet) or to *Off*, if the frequency point is not used.

Attenuation External input and output attenuation factors at the frequency point f_n assigned to the four RF connectors *RF1*, *RF2*, *RF3 Out* and *RF4 In*. The values for the bidirectional connectors *RF1* and *RF2* are used as input **and** output attenuations, affecting both the analyzer and the generator. Note that, due to the duplex spacing between forward and reverse channels, the input and output attenuation for mobile tests can still be different. The *RF3 Out* value is an output attenuation, the *RF4 In* value is an input attenuation.

The frequency points don't have to be defined in ascending order. Off the specified frequency points the attenuation factors are calculated as follows:

- In and interval between two adjacent frequency points, the attenuations are linearly interpolated.
- The attenuation *a* the lowest frequency point is valid for all analyzer and generator frequencies below and up to this frequency.
- The attenuation *a* the highest frequency point is valid for all analyzer and generator frequencies above this frequency.

Following these rules, it is possible to define attenuation factors for the entire frequency range using an arbitrary number of frequency points between zero (no attenuation) and 50. Using a single frequency point is equivalent to the global (frequency-independent) attenuations *Ext. Att. Input* and *Ext. Att. Output*.

Generator *RF Level* and analyzer *Max. Level* ranges

In analogy to the global attenuation factors *Ext. Att. Input* and *Ext. Att. Output*, the frequency-dependent attenuation factors modify the setting ranges for the generator and analyzer level.

- A positive (negative) output attenuation decreases (increases) the setting range of the RF generator level because the actual generator level must be larger (smaller) than the setting value.
- A positive (negative) input attenuation increases (decreases) the maximum analyzer level (RF Max. Level) because the displayed analyzer level result is larger (smaller) than the actual level at the input connectors of the R&S CMU.

To avoid conflicting level settings at varying input and output frequencies, the R&S CMU restricts the generator and analyzer setting ranges according to the maximum and minimum attenuation in the entire forward and reverse frequency range of the selected operating band. The attenuations in the forward frequency band define the modification of the generator level, the attenuations in the reverse frequency band define the modification of the maximum analyzer level.

In *Non Signalling* mode the RF generator and analyzer can be set to frequencies outside the forward and reverse frequency ranges so that conflicting level settings may still occur. If this happens, the R&S CMU displays a notice box:

Some level settings failed due to external attenuation!

Bit 4 of the `STATUS:OPERation:CMU:SUM1|2:CMU<nr>` register (*Measurement Invalid, MINV*) is set at the same time.

Remote control: The commands for the frequency-dependent attenuation are part of the CMU base system (see CMU200/300 operating manual):

```
DEfAult:USER:CORRection:LOSS
CONFigure:USER:CORRection:LOSS:TABLE:ENABle
CONFigure:USER:CORRection:LOSS:TABLE:LINE<nr>
CONFigure:USER:CORRection:LOSS:TABLE?
SORT:USER:CORRection:LOSS:TABLE
```

Reference Frequency (Connection Control – Sync.)

The popup menu *Sync.* defines the reference signals for synchronization. This includes:

- The internal or external Reference Frequency
- The output mode for the network-specific system clock (REF OUT 2)




Figure 4-15 Connection Control – Synchronization

Reference Frequency

The *Reference Frequency* softkey determines the source and the frequency of the reference signal. Two selections are available.

- Int. (10 MHz)* The internal 10 MHz clock signal (TCXO or OCXO, CMU-B11-B12) is used for synchronization. This signal is available at the REF OUT 1 connector at the rear of the instrument.
- Ext. (at REF IN)* An external reference signal is to be supplied to the REF IN connector. The frequency of the external reference signal must be entered in the input field.

The reference signal used is available at the REF OUT 1 output connector at the rear of the instrument making it available for use by other instruments.

Notes:

With external synchronization selected, a warning message cycles on and off if no synchronization has been performed e.g. because of missing or faulty input signal. At the same time, bit no. 6 (RFNL, Reference Frequency Not Locked) is set in the STATUS:OPERation:CMU:SUM1:CMU1 sub-register associated to the CMU base system and the query [SENSe:]SYNChronize:FREQuency:REFerence:LOCKed? returns the value ON.

In the case of external synchronization with squarewave signals (TTL) ensure correct signal matching to avoid reflections. Otherwise, resulting overshoots may cause trigger problems at the CMU input. A possible remedy is to use a lowpass filter or an attenuator pad directly at the CMU input. Correct synchronization may be checked by comparing the signal REF OUT 1 or REF OUT 2 with the input signal.

This configuration is valid in all CMU function groups.

Remote control

The commands for the reference frequency are part of the CMU base system (see CMU200/300 operating manual):

```
CONFigure:SYNChronize:FREQuency:REFerence:MODE
    INTernal | EXTernal
CONFigure:SYNChronize:FREQuency:REFerence <Frequency>
[SENSe:]SYNChronize:FREQuency:REFerence:LOCKed?
```

REF OUT 2

The *REF OUT 2* softkey configures a network-specific system clock available at the *REF OUT 2* output connector at the rear of the instrument. The associated field allows selection between two settings:

OFF (other network) The clock frequency of another active function group is made available at the REF OUT 2 connector instead of the current function group. The REF OUT 2 must be switched on in the other function group.

On (current network) The network-specific system clock of the current function group is available at the REF OUT 2 output connector.

The clock frequency can be used to synchronize other instruments.

Remote control

```
SOURce:DM:CLOCK:STATE ON | OFF
SOURce:DM:CLOCK:FREQuency <Frequency>
```

Trigger (Connection Control – Trigger)

The *Trigger* tab is part of the second group of tabs in the *Connection Control* menu. It is accessible after pressing the 1 / 2 toggle hotkey once. Pressing 1 / 2 again switches back to the first group of tabs described above.

The *Trigger* tab defines the trigger condition for the measurement and the routing of output trigger signals.




Fig. 4-16 Connection Control – Trigger

Default Settings The *Default Settings* checkbox assigns the default setting to all functions in the *Trigger* tab (the default values are quoted in the command description in chapter 6 of this manual).

Remote control DEFault:TRIGger[:SEquence]
 DEFault:TRIGger[:SEquence]:SOURce

Input – Source *Source* selects the source for the trigger event:

- Free Run* No trigger. Measurement is repeated without delay.
- RF Power* The measurement is triggered by the burst level (rising or falling edge; see *Slope* setting below) of the RF input signal, at a selectable *Trigger Level*. Wideband power trigger at the RF Front End of the R&S CMU.
- IF Power* The measurement is triggered by the level of the IF signal (rising or falling edge; see *Slope* setting below), at a selectable *Trigger Level*. Narrow band IF power trigger.
- External* External trigger signal fed in via pin 8 of the AUX connector at the front of the instrument.
- Internal* 20 ms frame trigger signal provided by the RF generator of the R&S CMU. The internal trigger signal is synchronized to the generated forward CDMA signal and can be routed to AUX 3; see *Output – Routing* below.

For the *RF Power* and *IF Power* settings the RF input signal must be ramping (e.g. a CDMA2000 signal with a FCH frame rate ≠Full). *RF Power* trigger signals have a small dynamic range which may not be sufficient for triggering. It is recommended to trigger by the *IF Power* instead.

Note: *The Internal trigger signal and the output frame trigger is only available while the RF generator is switched on.*

Special trigger conditions The selected trigger source is valid for all three modulation schemes 0-QPSK, H-PSK and QPSK (see section [Analyzer/Generator](#) on p. 4.2 ff.). The R&S CMU places no restrictions on the trigger source selection, however, some measurements may fail with an inappropriate trigger setting. The following rules apply (see also [Table 4-3](#) below):

1. 0-QPSK and QPSK measurements can be made with all trigger settings.
2. All H-PSK measurement applications require a synchronization between the DUT and the *Internal* or *External* trigger signal. No measurements can be made with *RF Power* and *IF Power* trigger or in the *Free Run* mode. In *Signalling* mode, the DUT is automatically synchronized to the *Internal (Signalling)* trigger signal.
3. Similar restrictions apply to *Transmit Time Error* measurements; see below.
4. The *Power vs. Frame* measurement is most easily performed with an *IF Power* trigger; see [Fig. 4-9](#) on p. 4.16 ff.

Remote control TRIGger[:SEquence]:SOURce
 INTernal | EXTernal | FRUN | RFPower | IFPower

Table 4-3 Trigger conditions for Non Signalling measurements

Measurement	Trigger Source	Remarks
Power Spectrum	all	Valid results irrespective of the trigger sources
Analyzer/Generator Modulation Quality O-QPSK Modulation O-QPSK applications <i>Transmit Time Error</i>	all External / Internal Other	Correct synchronization with O-QPSK signal required; this works with any trigger including <i>Free Run</i> . If no O-QPSK signal is applied, the measurement will still display results, but with high modulation errors. Valid results if the CMU is synchronized with the DUT. The mobile / signal generator must be synchronized with the CMU via the output trigger signal at AUX 3 (see <i>Output Routing</i> below). No transmit time error results available If the transmit time error cannot be calculated, the CMU displays a <i>PN Sync. Failed !!</i> message. The other O-QPSK modulation results are still valid.
Analyzer/Generator Modulation Quality H-PSK Modulation HPSK applications Code Domain Power HPSK applications	External / Free Run Internal	Requires a mobile / signal generator with long code mask set to zero. For <i>Internal</i> trigger, the CMU will transmit a BS signal with valid long code (calculated based on configured ESN), this will allow the mobile to synchronize with the CMU. For the measurement of the mobile signal, the CMU assumes that the MS is transmitting with the correct long code mask. If the MS is correctly synchronized with the CMU, HPSK measurement results will be displayed. If no HPSK signal is applied, no measurement results will be displayed.
Analyzer/Generator Modulation Quality QPSK	all	Correct synchronization with QPSK signal (pilot only) required. No <i>Transmit Time Error</i> measurement is available.

Slope

Slope qualifies whether the trigger event occurs on the *Rising Edge* or on the *Falling Edge* of the trigger signal. The setting has an influence on *RF Power* or *IF Power* trigger only.

Remote control

TRIGger[:SEquence]:SLOPe POSitive | NEGative

RF Power / IF Power The *Trigger Level* parameters define the trigger thresholds if the measurement is triggered by the *RF Power* or *IF Power* (see *Source* function above), respectively. Both thresholds are defined relative to the maximum input level set in the *Analyzer* tab (see *RF Max. Level* softkey on p. 4.20). The *Level* settings have no influence on *Free Run*, *Internal* or *External* trigger measurements.

...Trigger Level

Note: *The trigger levels are always relative to the **current** maximum input level. If RF Manual Max. Level is used (RF Mode = Manual), the current input level is constant and equal to the defined value. In autoranging mode (RF Mode = Auto), the current maximum input level is dynamically adapted to the measured RF input level; the trigger levels change accordingly.*

The **RF Power** trigger threshold is the RF input signal level (*Wideband Power*, see p. 4.31) beyond which the trigger condition is satisfied and a measurement is initiated.

- Low* Low trigger threshold, equal to approx. the maximum input level -26 dB.
- Medium* Medium trigger threshold, equal to approx. the maximum input level -16 dB.
- High* High trigger threshold, equal to approx. the maximum input level -6 dB.

The **IF Power** trigger threshold is the IF trigger signal level beyond which the trigger condition is satisfied and a measurement is initiated. The *IF Power* input value defines the trigger threshold relative to the maximum input level:

$$IF\ power\ trigger\ threshold = <max.\ input\ level> + <IF\ Power>$$

Remote control

```
TRIGger[:SEquence]:THReshold:RFPower LOW | MEdium | HIGH
TRIGger[:SEquence]:THReshold:IFPower <Power>
```

Output – Routing

The *Routing* functions select the type of periodic pulse signal (or no signal, setting *NONE*) to be applied to pins 2, 3, 4, and 5 of the AUX 3 connector. The output frame trigger is available if the *Internal* trigger source is selected and the RF generator is switched on. It consists of a high-pulse TTL signal with its rising edge at the beginning of the frames of the forward signal.

The CMU provides output trigger signals with the following periodicity:

- Power Ctrl. Frame* 1.25 ms
- Paging Frame* 20 ms
- Sync Frame* 26.67 ms
- Super Frame* 80 ms
- PP2S* 2 s

All signals can be selected for each of the pins 2 to 5. The current AUX 3 pin assignment (including the external trigger input at pin 8) is shown in the diagram to the left of the trigger *Setup* table.

Remote control

```
TRIGger:OUTPut:PIN<nr>:SIGNal <Frame_Period>
```

I/Q-IF Interface (Connection Control – I/Q-IF)

The *I/Q-IF* tab is part of the second group of tabs in the *Connection Control* menu. It is accessible after pressing the 1 / 2 toggle hotkey once. Pressing 1 / 2 again switches back to the first group of tabs described above.

The *I/Q-IF* tab configures the signal paths for I/Q and IF signals. With option CMU-B17, *I/Q and IF Interfaces*, I/Q and IF signals can be used in the framework of *RF* measurements and in many network tests. For a detailed description of rear panel connectors for I/Q and IF input/output signals, test scenarios and application examples refer to the CMU200/300 operating manual.




Fig. 4-17 Connection Control – I/Q-IF

Default Settings The *Default Settings* checkbox assigns the default setting to all functions in the *I/Q-IF* tab.

Remote control –

I/Q-IF Selects the *I/Q-IF* test scenario, overwriting the current *RX Path* and *TX Path* settings. Six different predefined test scenarios with fixed RX and TX path are provided; see [Table 4-4](#) below.

Additional scenarios may be defined by selecting any other combination of RX and TX paths. When this is done *I/Q-IF* is set to *User-defined*. The circuit diagram to the left of the *Setup* table shows the current RX and TX signal paths.

Remote control `CONFigure:IQIF:RXTXcombined`
`BYP | BYIQ | XOIO | IOIO | IOXO | FPAT | UDEF`

RX Path Selects the RX signal path, leaving the *TX Path* unchanged but adapting the *I/Q-IF* test scenario to the new RX/TX path combination: If the combination corresponds to a predefined scenario, then *I/Q-IF* is set to the predefined scenario; otherwise it is set to *User-defined*.

The circuit diagram to the left of the *Setup* table shows the current RX and TX signal paths.

Remote control `CONFigure:IQIF:RXPath`
`BYP | BYIQ | XOIO | IOIO | IOXO | FPAT | UDEF`

RX Path Selects the TX signal path, leaving the *RX Path* unchanged but adapting the I/Q-IF test scenario to the new RX/TX path combination: If the combination corresponds to a predefined scenario, then *I/Q-IF* is set to the predefined scenario; otherwise it is set to *User-defined*.

The circuit diagram to the left of the *Setup* table shows the current RX and TX signal paths.

Remote control `CONFigure:IQIF:TXPath`
`BYP | BYIQ | XOIO | IOIO | IOXO | FPAT | UDEF`

IF Level Indicates the IF output level in the TX path relative to the maximum IF input/output level (PEP) cited in the data sheet. The value is equal to the I/Q output level in the TX path relative to the maximum I/Q input voltage cited in the data sheet. The result is in dBFS units (dB Full Scale).

Remote control `[SENSe:]IQIF:IFLevel?`

Table 4-4 I/Q-IF scenarios and path settings

I/Q-IF	RX Path	TX Path	Remark/Application (see also CMU manual)
RX/TX Bypass	Bypass	Bypass	No I/Q or IF inputs/outputs connected Direct signal analysis and transmission with full measurement accuracy
Byp. w. I/Q-OF OUT	Bypass w. I/Q-IF OUT	Bypass w. I/Q-IF OUT	No I/Q or IF inputs connected Analysis of received and transmitted signal via I/Q or IF
I/Q IN/OUT	I/Q IN/OUT	I/Q IN/OUT	Insertion of signal to be analyzed and transmitted on I/Q level
IF IN_I/Q IN/OUT	IF IN_I/Q IN/OUT	IF IN_I/Q IN/OUT	Additional processing of received and transmitted signal on IF level (filters etc.) and analysis via I/Q
IF IN/OUT	IF IN/OUT	IF IN/OUT	Insertion of signal to be analyzed and transmitted on IF level
Fading	Bypass	I/Q IN/OUT	Direct analysis of received signal Modification (fading) of transmitted signal by means of an external fading simulator (SMIQ, ABFS)
User-defined	Any combination of RX Path and TX Path not listed above		Any combination of RX and TX test cases listed above

CDMA Measurements (Signalling Mode)

The structure of this section is based on the configuration and measurement groups defined in CDMA2000 *Signalling* function group. In the screen shots signalling states may change (such as function group and radio configurations) to illustrate measurements and settings.

The menus are described in the following order:

1. Call setup to the mobile station (*Connection Control – Connection (Signal Off / Signal On / Registered)*)
2. Overview of measurements and general settings (*Overview*)
3. Application menus (*Overview, Power, Modulation, Code Domain Power, Receiver Quality*): Purpose of the measurements and relation to the test specifications and conformance requirements, description of measurement results, specific measurement configurations
4. General device configurations (*Connection Control*)

The *Signalling* mode is activated in the *Menu Select* menu (with associated key at the front panel).




Figure 4-18 CDMA applications in Signalling mode

Since making measurements requires a connection to a mobile station, the CMU200 immediately displays the *Connect Control* menu when selecting a CDMA2000 Signalling Mode.

Table 1-1 in Chapter 1 provides a list of the available CDMA networks supported.

The TX measurements depend on the Reverse Radio Configuration (R-RC) of the mobile station which can be set in the *Service Cfg.* tab of the *Connection Control* menu (see section [Service Configuration of the CMU \(Connection Control – Service Cfg.\)](#) on p. 4.126 ff.). [Table 4-5](#) provides a list of the measurements available per radio configuration.

Table 4-5 Radio Configuration and Available Measurements

Reverse-Radio Configurations 1 & 2		Reverse-Radio Configurations 3 & 4	
O-QPSK Measurements		H-PSK Measurements	
Overview	Yes	Overview	Yes
Minimum Power	Yes	Minimum Power	Yes
Maximum Power	Yes	Maximum Power	Yes
Modulation Measurements	Yes	Modulation Measurements	Yes
H-PSK measurements	No Results	O-QPSK measurements	Invalid Results
Gated Output Power	Yes	Gated Output Power	No
Open Loop Time Response	Yes	Open Loop Time Response	Yes
Code Domain Power	No	Code Domain Power	Yes
Receiver Quality (Loopback or Test Data Service only)	Yes	Receiver Quality (Loopback or Test Data Service only)	Yes

Call Setup (Connection Control)

The *Connection Control* popup menu controls the signalling (call setup and release, services, signalling parameters) and configures the inputs and outputs with the external attenuation values and the reference frequency.

The term signalling summarizes all procedures necessary for call setup and release and for control of a connection in the mobile radio network. In the case of the CMU, a distinction is made between four different signalling states:

<i>Signal Off</i>	CMU transmits no signal
<i>Signal On/MS Unregistered</i>	CMU outputs a control channel signal (<i>BS Signal</i>) to which a mobile station can synchronize
<i>Registered</i>	Registration with the mobile station and location update performed
<i>Connected</i>	Call established with a mobile station

A number of control commands which can be initiated both by the CMU (*Call initiated from the CMU*) and by the mobile station (*Call initiated from MS*) switch between these states.

Most applications within the function group *CDMA2000 Signalling* are only possible (or useful) in a particular signalling state (for example, handoff between various networks requires an existing connection between the CMU and mobile station, i.e. it is only possible in the *Connected* state). Functionality of some menus vary depending on the signalling state.

Note: A fifth, transitory signalling state (*Alerting*) exists if the *Service Class* is set to *Speech Service*; see [Figure 4-19 below](#). Moreover, additional transitory states (not shown in [Figure 4-19](#)) occur during handoff and *Send SMS* procedures; see section [Handoff to Another Network \(Connection Control – Handoff\)](#) on p. 4.124 ff. and [Send SMS softkey](#) on p. 4.49.

Since the measurements in signalling mode require an existing connection to a mobile station, the menus for setting up the call (*Connection Control - Connection*) appear immediately after selecting a signalling mode (unless this feature is disabled). The connection control menus can be accessed any time by pressing the *Connect Control* softkey at the top right corner in any measurement menu. The hotkey bar (at the bottom the screen) links the measurement menus together. Pressing the *Escape* key or the *Connect Control* softkey closes the connection control menu and the CMU changes to the measurement mode.




Figure 4-19 Signalling states of the CMU

Corresponding to the five possible signalling states, five different *Connection* tabs are available. When one of the signalling states *Signal Off*, *Signal On*, *Registered* or *Alerting* is reached, the corresponding tab is opened automatically. On the other hand the *Connected* tab is closed immediately after the CMU reaches the *Connected* state so that a measurement can be started.

Note: *The automatic display or close of the Connection Control menu is controlled within the User Guidance section of the Misc. tab of the Connection Control menus. See page 4.167.*

For a complete overview of signalling states including the Handoff process see Fig. 6.1 in Chapter 6 of this manual. A modified state machine is used for packet data connections; see description of the connection setup in Chapter 8.

In the following, the tab *Connection Control – Connection* displayed during the call setup is described. The other tabs of the *Connection Control* menu are described at the end of this chapter beginning on page 4.122.

Connection Control (Signal Off State)

In the *Signal Off* state, the CMU does not output any RF signals. In addition to the parameter overview described in section *Connection Control with Connection Established* on p. 4.122 ff. the popup menu *Connection (Signal Off)* activates the RF channel signal for the call setup to the mobile station (*Signal On*, see *Figure 4-19* on p. 4.43), selects the Primary Service Class (*1st Service Class*) and the *Network Standard* and controls the standby and access probe power measurement (*Power*).




Figure 4-20 Connect Control – Connection (Signal Off)

The parameter overview in the left half of the menu is also indicated in the other *Connection* tabs and is described in section *Connection Control with Connection Established* on p. 4.122 ff. Some parameters are not always available, depending on the current and previous signalling states and settings. In this case the table shows invalid or unavailable settings ("---"). In the *Signal Off* state, the parameter overview contains the current conditions of the connection to be set up to the mobile station.

Message box A message displayed in each *Connection* tab provides the current instrument state or indicates how to proceed to get to other signalling states. In this instance, the message Press the Signal On key to enable the registration signal is displayed.

Signal On

The *Signal On* softkey switches on the RF generator. Switching the RF generator on changes the Signalling state from the *Signal Off* state to the *Signal On* state and the CMU waits for the mobile station to register.

Remote Control PROCedure:SIGNalling:ACTion
SON

1st Service Class

The *1st Service Class* softkey selects the Primary Service Class, i.e. the call mode method to use when connecting to the mobile station.

Loopback Service Is generally used for testing. In particular, CDMA2000 receiver quality measurements require that a *Loopback Service* call be established with the mobile station.

Speech Service Is used to place a voice call to the mobile. *Modulation* measurements and the other TX tests may run slower in *Speech Service* since the mobile station signal may not be using Full Rate. *Receiver Quality* tests are not possible.

Test Data Service Is used for testing the high data rates using the supplemental channels (SCH0 and SCH1).

Packet Data Service Is used to request packet data service through a serving node supporting an Internet standard Point-to-Point Protocol (PPP) interface to network layer protocols. For details and applications refer to Chapter 8.

Messaging Teleservice (WMT) Is used to set up an intermediate connection using service option 6 or 14 at variable FCH configuration in order to test the Short Message Service (SMS) capability of the mobile station; see section [SMS Tests with the CMU](#) on p. 4.51 ff. When the Wireless Messaging Teleservice (WMT) is active it is not possible to enter the *Connected* signalling state. Instead the *Send SMS* softkey in the *Connection (Signal On)* or *Connection (Registered)* tab (see p. 4.49) sets up the connection and sends the short message.

The parameters for the service types (including the short message text) are configured in the *Service Cfg.* tab; see p. 4.126 ff.

Remote Control CONFigure:SCONfig:SClass<nr>:SERVice
LOOP | SPEech | TDAT | PDAT | WMT
PROCedure:SCONfig:SClass<nr>:SERVice LOOP | SPEech | TDAT | PDAT

Network Standard

The *Network Standard* softkey displays the network selected from the *Menu Select* menu.

Pressing the *Network Standard* softkey allows you to change between the supported band classes for the network. Refer to [Figure 4-18](#) on page 4.41 for a list of the supported CDMA2000 networks.

Remote Control CONFigure:NETWork:STANdard
N45T | USC | KCEL | TACS | JTAC | NA7C | NA9C | NAS8 | NACP | KPCS | B18M | IM2K

Power

The *Power* softkey controls the standby and access probe power measurement and indicates its status (*RUN* | *HLT* | *OFF*). The status can be changed after softkey selection (pressing once) by means of the *ON/OFF* key or the *CONT/HALT* key. The measurement result is in units of dBm. The *Standby Power* and *Access Probe Power* fields are blank until the mobile station registers.

Standby Power Power of the mobile station while it is not transmitting. The *Standby Power* is measured using a 1 MHz filter (see also standard IS-98-D).

Access Probe Power Power of the mobile station's access probes during its registration. A mobile station transmits access probes during its power on cycle, at the CMU's timer based registration setting and when the mobile initiates a call. The *Access Probe Power* is measured using the receiver filter specified in standard TIA/EIA/IS-2000.2-A.

Note: *The Standby Power and Access Probe Power measurements only run if the underlying measurement is turned off. Press the Connect Control softkey to see the status of the current underlying measurement.*

Remote control of the Standby Power and Access Probe Power measurements are not typically affected by the status of the underlying measurement since remote control measurements are run in single shot mode.

```
Remote INITiate:SAPPower
Control FETCh:SAPPower:STATus?
        READ[:SCALar]:SAPPower?
        FETCh[:SCALar]:SAPPower?
        SAMPlE[:SCALar]:SAPPower?
```

Connection Control (Signal On State)

In addition to the parameter overview described in section [Connection Control with Connection Established](#) on p. 4.122 ff., the 1st *Service Class* and *Network Standard* softkeys, and the standby and access probe power measurement described in section [Connection Control \(Signal Off State\)](#) on p. 4.44 ff., the *Connection (Signal On)* tab contains the following softkeys which lead to other services or signalling states (see [Figure 4-19](#) on p. 4.43):

- Deactivating the CMU's CDMA signal (*Signal Off*)
- Establishing a call to the mobile station if registration has taken place (*Connect MS* ⇒ state *Connected*)




Figure 4-21 Connect Control – Connection (Signal On)

The parameter overview in the left half of the menu is also indicated in the other *Connection* tabs and is described in section [Connection Control with Connection Established](#) on p. 4.122 ff. Some parameters are not always available, depending on the current and previous signalling states and settings. In this case the table shows invalid or unavailable settings ("---").

Message box

A message displayed in each *Connection* tab provides the current instrument state or indicates how to proceed to get to other signalling states. In this instance, the message *Waiting for MS Registration or for MS to originate call* is displayed.



The *Signal Off* softkey switches off the CMU's RF signal. Switching the signal off causes the CMU to change to the *Signal Off* state.

Remote Control PROCEDURE:Signalling:ACTion SOFF



The *Connect MS* softkey attempts to set up a call to the mobile station using the mobile ID from the previous registration or the mobile ID entered in the *Network* tab (see [Mobile ID \(MIN/MSI\)](#) function on p. 4.157). The type of call is dependent on the Primary Service Class selected. If the mobile ID does not match, a call will not be established.

- Once the call is established, the CMU displays the *Connected* state. Refer to page 4.122. If *Speech Service* is selected as Primary Service Class (see [1st Service Class](#) softkey on p. 4.45), the CMU pauses in the *Alerting* state while the phone is ringing and the call needs to be answered to reach the *Connected* state.
- If the mobile registers but fails to establish a call with the CMU, the CMU will display the *Connection Control Registered* screen. Refer to page 4.48.

Connect MS is available only for the Primary Service Classes *Loopback Service*, *Speech Service*, *Test Data Service* and *Packet Data Service*. If *Messaging (WMT)* is selected, the softkey is replaced by *Send SMS*, see below.

Remote PROCedure:SIGNalling:ACTion CTM
Control

Send SMS

The *Send SMS* softkey intermediately sets up a call to the mobile station using service option 6 or 14 at variable FCH configuration and the mobile ID from the previous registration. Afterwards the CMU delivers a short message to the mobile station and returns to the *Registered* state; see section [SMS Tests with the CMU](#) on p. 4.51 ff.

Send SMS is available only for the Primary Service Class *Messaging (WMT)*; see [1st Service Class](#) softkey on p. 4.45. If one of the other service classes is selected, the softkey is replaced by *Connect MS*, see above. With this configuration, it is possible to deliver an SMS in the *Connected* state.

Remote control
PROCedure:SIGNalling:ACTion SMESage

Connection Control (Registered State)

In addition to the parameter overview described in section [Connection Control with Connection Established](#) on p. 4.122 ff., the *1st Service Class* and *Network Standard* softkeys, and the standby and access probe power measurement described in section [Connection Control \(Signal Off State\)](#) on p. 4.44 ff., the *Connection (Registered)* tab contains the following softkeys which lead to other services or signalling states (see [Figure 4-19](#) on p. 4.43):

- Deactivating the CMU's CDMA signal (*Signal Off*)
- Returning to the *Signal On* state where the UE can attempt a new registration (*Unregister* -> return to state *Signal On*)
- Establishing a connection to the mobile station (*Connect MS* => state *Connected*) or send a short message (*Send SMS*)




Figure 4-22 Connect Control – Connection (Registered)

The softkey *Signal Off* is described in section [Connection Control \(Signal On State\)](#) on p. 4.46 ff.

The parameter overview in the left half of the menu is also indicated in the other *Connection* tabs and is described in section [Connection Control with Connection Established](#) on p. 4.122 ff. Some parameters are not always available, depending on the current and previous signalling states and settings. In this case the table shows invalid or unavailable settings ("---"). In the *Registered* state, the parameter overview contains the MS information provided during registration.

Message box A message displayed in each *Connection* tab provides the current instrument state or indicates how to proceed to get to other signalling states. In this instance, the message Make a call from the mobile or press the "Connect MS" key is displayed.

Unregister

The *Unregister* softkey unregisters the CMU from the mobile station and returns the CMU to the MS Unregistered state (refer to page 4.46). This feature can be useful if the MS is replaced without switching the CDMA signal (*BS signal*) off.

Remote PROCedure:Signalling:ACTion
Control UNRegister

Connect MS

The *Connect MS* softkey attempts to set up a call to the registered mobile station.

- Once the call is established, the CMU displays the *Connected* State. Refer to page 4.122. If *Speech Service* is selected as Primary Service Class (see [1st Service Class](#) softkey on p. 4.45), the CMU pauses in the *Alerting* state while the phone is ringing and the call needs to be answered to reach the *Connected* state.
- If the mobile fails to establish a call with the CMU, the CMU remains in the *Registered* screen.

Connect MS is available only for the Primary Service Classes *Loopback Service*, *Speech Service*, and *Test Data Service*. If *Messaging (WMT)* is selected, the softkey is replaced by *Send SMS*, see below.

Remote PROCedure:SIGNalling:ACTion
Control CTM

Send SMS

The *Send SMS* softkey intermediately sets up a call to the mobile station using service option 6 or 14 at variable FCH configuration and delivers a short message to the mobile station. Afterwards the CMU returns to the *Registered* state; see section [SMS Tests with the CMU](#) on p. 4.51 ff.

Send SMS is available only for the Primary Service Class *Messaging (WMT)*; see [1st Service Class](#) softkey on p. 4.45. If one of the other service classes is selected, the softkey is replaced by *Connect MS*, see above. With this configuration, it is possible to deliver an SMS in the *Connected* state.

Remote control
PROCedure:SIGNalling:ACTion SMESsage

Connection Control (Alerting State)

The Alerting state is reached if the 1st Service Class is set to *Speech Service* to establish a voice call to the mobile station. In this state, the mobile station is ringing and the call needs to be answered to connect to the mobile station.

In addition to the parameter overview described in section *Connection Control with Connection Established* on p. 4.122 ff., the 1st Service Class and Network Standard softkeys, and the standby and access probe power measurement described in section *Connection Control (Signal Off State)* on p. 4.44 ff., the *Connection (Alerting)* tab contains the following softkeys which lead to other services or signalling states (see *Figure 4-19* on p. 4.43):

- Deactivating the CMU's CDMA signal (*Signal Off*)
- Disconnect MS while keeping the CDMA signal (*BS Signal*) switched on (→ *Registered*)




Figure 4-23 Connect Control – Connection (Alerting)

The softkey *Signal Off* is described in section *Connection Control (Signal On State)* on p. 4.46 ff.

The parameter overview in the left half of the menu is also indicated in the other *Connection* tabs and is described in section *Connection Control with Connection Established* on p. 4.122 ff. Some parameters are not always available, depending on the current and previous signalling states and settings. In this case the table shows invalid or unavailable settings ("---").

Message box

A message displayed in each *Connection* tab provides the current instrument state or indicates how to proceed to get to other signalling states. In this instance, the message *The mobile is alerting. Please accept the call at the mobile.* is displayed.

Disconnect UE

The *Disconnect UE* softkey releases the connection to the UE. The CMU changes to the signalling state *Registered*.

Remote control

PROCedure:SIGNalling[CSwitched]:ACTion CREL

SMS Tests with the CMU

The CMU can test the Short Message Service (SMS) capability of the mobile station by sending and receiving short messages.

Send SMS

A short message to be sent is a text of a maximum of 162 + 8 characters that is defined, together with other SMS parameters, in the *Service Cfg.* tab (see section *Messaging Teleservice (WMT)* on p. 4.142 ff.). The current short message is also displayed in the parameter overview in the *Connection* tabs of the *Connection Control* menu, section *Messaging (WMT) Information*.

There are two different ways of sending a short message to the mobile:

- In the *Signal On* or *Registered* state using *Messaging (WMT)* as 1st Service Class and service option 6 or 14 at variable FCH configuration.
- In the *Connected* state using any other 1st Service Class and a fixed FCH configuration (*SMS @ Current Connection*).

Messaging (WMT)

To send an short message using the *Messaging (WMS)* service:

1. Open the *Connection Control* menu and make sure the CMU is in the *Registered* state.
2. In the *Connection* tab, select *Messaging (WMT)* as 1st service class.
3. Open the *Service Cfg.* Tab, expand the *Messaging Teleservice (WMT)* section and select one of the service options 6 or 14 together with the desired FCH configuration.
4. In the same section, type in the short message to be sent. Select *Acknowledgement* and *Add Time Stamp*, if so desired.
5. Go back to the *Connection* tab and press *Send SMS*.

SMS @ Current Connection

Suppose that the SMS text and parameters have been defined previously. To send a short message using the current connection:

6. Open the *Connection* tab of the *Connection Control* menu select any 1st service class except *Messaging (WMT)*.
7. Establish a connection with the mobile station.
8. Press *Send SMS* as soon as the CMU enters the *Connected* state.

Receive SMS

A short message can be received while the CMU is in the *Registered* or in the *Connected* state. The received SMS is indicated as follows:

- A window showing the short message pops up:



- The message is displayed in the parameter overview in the *Connection* tabs of the *Connection Control* menu, section *Messaging (WMT) Information*.
- Bit no. 8 in the *EVENT* part of the *STATUS:OPERATION:SUM1|2:CMU<nr>* sub-register is set (see Chapter 5).

Overview

The *Overview* main menu provides an overview of the function group *CDMA2000 Signalling*, the current measurement status, and the most important scalar parameters and measurement results.

Note: *The configuration settings made in the Overview application (with either the softkeys or the Configuration menus) apply only to the measurements presented here. For example, configuration settings made here do not affect the configuration settings made within the Power or Modulation applications.*

The Overview measurement has its own environment (see Chapter 3, section Measurement Environments). If the measurement environment is enabled (see section [Overview Configuration – Control](#) on p. 4.56 ff.), it overrides the Connection Control parameters as long as the measurement is switched on (RUN) and a connection is established. All Overview measurement results are always obtained with the same parameter set.

Refer to [Table 4-5](#) on page 4.42 for a list of measurements and their radio configuration requirements.

Note: *The Overview measurement is available for both O-QPSK and H-PSK modulation schemes. The CMU automatically selects the correct modulation scheme unless this feature is disabled in the Misc. tab of the Connection Control menu. Refer to section [Miscellaneous User Settings \(Connection Control – Misc.\)](#) on p. 4.167 ff.*

O-QPSK measurements require a reverse radio configuration setting of 1 or 2. H-PSK measurements require a reverse radio configuration setting of 2 or 3. Refer to [Table 4-5](#) on page 4.42 for a list of measurements and their radio configuration requirements.

The screen shots and discussions in this chapter refer to O-QPSK but apply to both modulation schemes.

In the softkey bar on the right side, the *Analyzer/Generator* menu provides different types of softkeys:

- The measurement control softkey *Overview O-QPSK* changes to *Pilot Power Report*, *Channel Quality* or *Overview H-PSK*, depending on the application selected. This softkey controls the measurement, indicates its status (*RUN* | *HLT* | *OFF*) and opens the configuration menu *Overview Configuration*. The hotkeys associated to the measurement control softkey define the scope of the *Modulation* measurement.
- The other softkeys on the right side are combined with various hotkeys (e.g. the hotkeys *RF Max. Level* and *RF Mode* belong to the softkey *Analyzer Level*). The softkey/hotkey combinations provide test settings and switch over between different measurements.

The *Overview* menu is opened from the main menu *Menu Select* (with associated key at the front of the instrument). The hotkeys associated to the *Menus* softkey switch over between the *Overview* menu and the remaining measurement menus of function group *CDMA2000 Signalling*.




Figure 4-24 Overview menu

Softkey Selections

Each *Overview* application is controlled by means of the measurement control softkey below the *Connect. Control* softkey and the associated hotkeys. The properties of the measurement control softkey are analogous in all measurements; see section *Analyzer/Generator – Measurement Control* in the *Non Signalling* section. The remaining softkeys select the application and provide application-specific settings.

Application

The *Application* softkey displays the available measurement functions.



Each measurement type can be turned on or off by selecting the hotkey and pressing the *ON/OFF* key or halted by pressing the *CONT/HALT* key.

Remote Control The four applications of the *Overview* menu are is selected by the keywords OVERview[:OQPSk], PPOwer, CQQuality and OVERview:HPSK in the 4th level of the MODulation commands, e.g. CONFigure:OVERview:PPOwer...

Note: The *Overview O-QPSK* measurements require a reverse *Radio Configuration 1* or *2*, *H-PSK* measurements a reverse *Radio Configuration 3* or *4* see [Table 4-5](#) on p. 4.42.

Analyzer Level Trg.

The *Analyzer Level/Trigger* softkey toggles between two sets of hotkeys to control the level in the RF signal path and define the trigger settings. These general settings are provided in the *Analyzer* and *Trigger* tabs of the *Connection Control* menu; see section [Analyzer Control \(Connection Control – Analyzer\)](#) on p. 4.165 ff and [Trigger \(Connection Control – Trigger\)](#) on p. 4.163 ff.

BS Signal Level Imp.

The *BS Signal Level / Imp.* softkey toggles between two sets of hotkeys to adjust the signal impairments and the base station signal levels.

All settings belong to the *Overview* measurement environment. They are also provided in the *Overview Configuration* menu and described in section [Overview Configuration – Control](#) on p. 4.56 ff.

BS Signal Set. P. Ctrl

The *BS Signal Set. /P. Ctrl* softkey displays a set of hotkeys to adjust the RF channel and frame rate and the power control bits that the CMU sends to the mobile station to control its output power. *Frame Rate* and *Power Control Bits* belong to the *Overview* measurement environment and are also provided in the *Overview Configuration* menu (refer to section [Overview Configuration – Control](#) on p. 4.56 ff.). *RF Channel* is a general parameter; see p. 4.147.

Measurement Results

The *Overview* menu contains three groups of output fields reporting the measurements results and an overview of the current measurement settings.




Figure 4-25 Overview menu

The left side of the *Overview* menu reports the results of all *Overview* measurement applications:

Overview... *Overview O-QPSK (or H-PSK) Current (or Average, depending on the the Display Mode set in the Control tab of the Overview Configuration menu) displays the following power and modulation parameters:*

- MS Power
- Carrier Frequency Error
- Transmit Time Error
- Waveform Quality
- Sideband Suppression
- Statistic Count

The *Overview...* measurement results are discussed under [Modulation Measurements](#) beginning on page 4.77.

The following values are not provided in the *Modulation* measurement:

Sideband Suppression *Sideband Suppression is a power measurement at a user-configurable offset frequency used for spurious measurements. In contrast to the MS Power the sideband suppression is measured with a 30 kHz (Gaussian) spectrum analyzer filter. The frequency offset is set via the Side Band Freq. Offset hotkey associated to the measurement control softkey.*

Lower Sideband Suppr. Ratio of the sideband power at *RF Frequency – Side Band Freq. Offset* to the *MS Power* in dB

Upper Sideband Suppr. Ratio of the sideband power at *RF Frequency + Side Band Freq. Offset* to the *MS Power* in dB

Note: *In remote control the lower and upper sideband suppression can be measured at up to 4 different frequencies; see keywords ...ACP1 to ...ACP4.*

Remote Control READ[:SCALar]:OVERview:OVERview:<Modulation>?
 FETCh[:SCALar]:OVERview:OVERview:<Modulation>?
 SAMPlE[:SCALar]:OVERview:OVERview:<Modulation>?

Pilot Power Report *Pilot Power Report displays the current F-PICH pilot power reported from the mobile*

The *Pilot Power Report* measurement results are discussed under [Power Measurements](#) beginning on page 4.61.

Remote Control READ[:SCALar]:OVERview:OVERview:<Modulation>?
 FETCh[:SCALar]:OVERview:OVERview:<Modulation>?
 SAMPlE[:SCALar]:OVERview:OVERview:<Modulation>?

Channel Quality *Channel Quality starts the Receiver Quality measurement and displays the frame error rate and the number of frames transmitted in the current measurement.*

The *Channel Quality* measurement results are discussed under [Receiver Quality Measurements](#) beginning on page 4.113.

Remote Control READ[:SCALar]:OVERview:OVERview:<Modulation>?
 FETCh[:SCALar]:OVERview:OVERview:<Modulation>?
 SAMPlE[:SCALar]:OVERview:OVERview:<Modulation>?

Settings The *Settings* table displays the current configuration settings as defined in the *Overview Configuration* menu (see section [Overview Configuration](#) on p. 4.56 ff.).

Remote Settings are retrieved using the query corresponding to the setting command
Control (setting command with appended question mark).

Limit Check A red output field and an arrow pointing upwards or downwards indicates that the measurement result exceeds the upper or lower limit set in the *Limits* tab of the *Power Configuration* menu; see section [Overview Configuration – Limits](#) on p. 4.60 ff. No limit check is provided for the *Pilot Power Report*.

Remote CALCulate[:SCALar]:<Application>:MATChing:LIMit?
Control

Overview Configuration

The popup menu *Overview Configuration* contains tabs to define the parameters of the modulation measurements and the limits (error tolerances).

Pressing the measurement softkey twice (once if already selected) opens the popup menu *Overview Configuration*. Press the associated hotkeys to change between tabs. Use the roll-key to expand or compress the list of settings displayed.

Note: *The Overview application is available for both O-QPSK and H-PSK modulation schemes. The CMU automatically selects the correct modulation scheme unless this feature is disabled in the Misc. tab of the Connection Control menu. Refer to section [Miscellaneous User Settings \(Connection Control – Misc.\)](#) on p. 4.167 ff.*

The screen shots and discussions in this chapter refer to O-QPSK but apply to both modulation schemes.

Overview Configuration – Control

The *Control* tab controls the modulation measurement applications. The menus contain configurations that affect all *Overview* applications (i.e. the measurement environment settings) and settings for individual *Overview* applications.




Figure 4-26 Overview Configuration – Control

Default All Settings The *Default All Settings* switch assigns default values to all settings in the *Control* tab (the default values are quoted in the command description in chapter 6 of this manual). In addition, default switches for the individual applications are provided.

Remote control

DEfault:OVERview:<Application>:CONTRol ON | OFF

Environment Enable

Environment Enable enables or disables the *Overview* environment:

On (box checked) The parameters listed in the *Measurement Environment* section are used as soon as a connection is established and an *Overview* measurement application is switched on.

Off (box unchecked) The *Measurement Environment* settings are ignored; the CMU always uses the corresponding *Connection Control* settings.

Note: In the *Misc. tab* of the *Connection Control* menu, it is possible to enable or disable all measurement environments; see section [Miscellaneous User Settings \(Connection Control – Misc.\)](#) on p. 4.167 ff.

Remote control

CONfFigure:OVERview:MCQuality:ENVironment:ENABLE ON | OFF

Measurement Environment

The *Measurement Environment* section contains all parameters that affect all *Overview* applications and form the measurement environment. The settings take effect if the environment is enabled (see above). All settings have an equivalent in the *BS Signal* or *Service Cfg.* tab of the *Connection Control* menu; see section [Signals of the CMU \(Connection Control – BS Signal\)](#) on p. 4.147 ff.

Remote Control The commands of the *Overview* measurement application are analogous to the corresponding *BS Signal* commands. The keyword `:BSSignal` is replaced by

OVERview:MCQuality:ENVironment, e.g.:
CONfFigure:OVERview:MCQuality: ENVironment:POWer:CDMA
<CDMA Power>

BS Signal Level Sets the levels of the forward CDMA2000 signal of the CMU.

Impairments	Sets parameters to impair the forward CDMA2000 signal of the CMU in order to simulate realistic propagation conditions and test the MS receiver.
BS Signal Settings	Sets the <i>F-FCH Frame Rate</i> to Full, Half, Quarter, or Eighths. The frame rate has an equivalent in the <i>Service Cfg.</i> tab of the <i>Connection Control</i> menu; see section Service Configuration of the CMU (Connection Control – Service Cfg.) on p. 4.126 ff.
Power Control	<i>Power Control Bits</i> defines the power control bit sequence that the CMU sends to the mobile station to control its output power.

O-QPSK Overview Meas.

Repetition *Repetition* determines the repetition mode as described below.

Single Shot: The measurement is stopped after a statistic cycle, i.e. after the number of waveform intervals/evaluation periods set in the configuration menu *Statistics*. The *Stop Condition* setting may stop the measurement before completion of a cycle. A stopped measurement is indicated by the status display *HLT* in the measurement softkey.

Single shot should be selected only if a single measurement result is required under fixed conditions.

Continuous: The CMU continues the measurement until it is terminated explicitly or until the stop condition is met. The measurement results are valid after one statistic cycle; however, the measurement is continued, and the output is continuously updated. An ongoing measurement is indicated by the status display *RUN* in the measurement softkey.

The continuous measurement is suitable for monitoring the evolution of a measured quantity in time, for example when performing adjustments.

Note: *In remote mode, the counting measurement (counting mode) is available as a further measurement mode with a defined number of measurement cycles to be performed, refer to Chapter 6 of this manual.*

The Stop Condition setting can affect the Single Shot and Continuous repetition modes.

Remote Control `CONFigure:OVERview:OVERview[:QPSk]:CONTrol:REPetition`
`CONFigure:OVERview:OVERview:HPSK:CONTrol:REPetition`
`<Repetition>, <Stop Cond>, <Step Mode>`

Stop Condition *Stop Condition* selects one of two stop conditions for the measurement:

NONE The measurement continues even if tolerances are exceeded.

On Limit Failure The measurement is stopped when a tolerance is exceeded.

Note: *The Stop Condition setting can affect the Single Shot and Continuous repetition modes.*

Remote Control	See <i>Repetition</i> above.
Statistic Count	<p><i>Statistic Count</i> defines the length of the statistic cycles in waveform intervals/evaluation periods.</p> <p style="padding-left: 40px;"><i>1 to 1000</i> Number of intervals per statistic cycle.</p>
Remote Control	<p>CONFigure:OVERview:OVERview[:OQPSk]:CONTRol:STATistics CONFigure:OVERview:OVERview:HPSK:CONTRol:STATistics <Statistic Count></p>
Display Mode	<p>The <i>Display Mode</i> field defines which of the four measured and calculated statistical measurement results is displayed. The measurement results differ in the way the waveform interval Modulation $p(t)$ at a fixed point in time t is calculated if the measurement extends over several waveform intervals; see also Chapter 3, section <i>General Settings</i>:</p> <p><i>Current</i> Measured value for current waveform interval <i>Minimum/Maximum</i> Extreme value of a number of waveform intervals <i>Average</i> Average value over a number of waveform intervals</p> <p>The number of waveform intervals for calculation of the statistical values <i>Minimum/Maximum</i> and <i>Average</i> – and thus the result – depends on the repetition mode set. In detail, this implies:</p> <p><i>Single shot</i> Display of minimum/maximum and average value from the performed statistics cycle.</p> <p><i>Continuous</i> Display of minimum/maximum from all waveform intervals already measured. The average value, however, is calculated according to the rule in Chapter 3, section <i>General Settings</i>.</p>
Remote Control	No display mode set, the READ..., FETCH... and SAMPLE commands retrieve all values.
Sideband Freq Offset	<p>The <i>Side Band Freq. Offset</i> input field sets the frequency offset used for the <i>Sideband Suppression</i> power measurement; see section Measurement Results on p. 4.54 ff. The sideband suppression is measured at the two offset frequencies symmetrical to the <i>RF Frequency</i> (lower and upper sideband suppression).</p> <p>In remote control up to 4 different frequency offsets can be defined so that up to 8 symmetrical sideband suppression values are available: CONFigure:OVERview:OVERview:<Application>:CONTRol:FOFFset: SBSuppress:ACP<nr>, where <nr> = 1 to 4</p>
H-PSK Overview Meas	Refer to O-QPSK above for a description of the available settings.
Channel Quality	Refer to O-QPSK above for a description of the <i>Repetition</i> mode.

Stop Condition *Stop Condition* selects one of several stop conditions for the measurement:

<i>NONE</i>	Continue the measurement even in the event of errors.
<i>Confidence Limit Exceeded:</i>	Stop the measurement when the confidence level exceeds the set limit. This indicates the probability that the true FER is less than the set FER limit.
<i>Frame Limit Exceeded:</i>	Stop the measurement when the number of frame errors exceed the set limit.
<i>Any Limit Exceeded:</i>	Stop the measurement if either the <i>Confidence Limit</i> or <i>Frame Limit</i> is exceeded.

The stop conditions may affect single-shot and continuous measurement settings.

Remote Control CONFigure:OVERview:CQQuality:CONTRol:REPetition
<Repetition>, <Stop Cond>, <Step Mode>

Max Frames The *Max Frames* sets the maximum number of frames used to calculate the frame error rate.

Remote Control CONFigure:OVERview:CQQuality:CONTRol:FRAMES
<Max Frames>

Overview Configuration – Limits

The *Limits* tab allows you to set the limits for the *Overview* applications. Two sets of limits are configurable for the *O-QPSK Overview* and *H-PSK Overview* application: the *Current and Maximum/Minimum* measurement limits and the *Average* measurement limits. In addition the *Limits* tab provides the limits for the *Channel Quality* application. No limit check is available for the *Pilot Power Report*.

Note: *The Overview application is available for both O-QPSK and H-PSK modulation schemes. The CMU automatically selects the correct modulation scheme unless this feature is disabled in the Misc. tab of the Connection Control menu. Refer to section [Miscellaneous User Settings \(Connection Control – Misc.\)](#) on p. 4.167 ff.*

The screen shots and discussions in this chapter refer to O-QPSK but apply to both modulation schemes.




Figure 4-27 Overview Configuration – Limits

Default All Settings The *Default All Settings* switch assigns default values to all parameters of the *Limits* tab. The default values are quoted in the command description in chapter 6 of this manual. In addition, default switches for the individual applications (except the *Pilot Power Report*) are provided.

Remote control

DEFAult:OVERview:<Application>:LIMit ON | OFF

The following limits are provided for the **O-QPSK Overview** and **H-PSK Overview** applications:

Current & Min/Max *Current and Max/Min* sets the limits for the measured values in the current waveform interval or of the extreme values of all measured waveform intervals (*Min/Max*).

Remote control

CONFigure:OVERview:<Application>:CMMax:LIMit[:SCALar]:SYMMetric[:COMBined]:VALue

CONFigure:OVERview:<Application>:CMMax:LIMit[:SCALar]:SYMMetric[:COMBined]:ENABle

CONFigure:OVERview:<Application>:CMMax:LIMit[:SCALar]:SYMMetric[:COMBined]

Average *Average* sets the limits are for the average value of the measured values obtained according to the averaging rules of Chapter 3, section *General Settings*.

Remote control

CONFigure:OVERview:<Application>:AVERAge:LIMit[:SCALar]:SYMMetric[:COMBined]:VALue

CONFigure:OVERview:<Application>:AVERAge:LIMit[:SCALar]:SYMMetric[:COMBined]:ENABle

CONFigure:OVERview:<Application>:AVERAge:LIMit[:SCALar]:SYMMetric[:COMBined]

Channel Quality The results of the **Channel Quality** application are always *Current* results, so only one set of limits parameters is provided:

Remote control

CONFigure:OVERview:CQQuality:CAMMax:LIMit:MFER

CONFigure:OVERview:CQQuality:CAMMax:LIMit:CLEVel

Power Measurements

The menu group *Power* contains the functions to measure the received signal power. The *Power Configuration* popup menu configures all power measurements.

The *Power* menu is opened from the *Menu Select* menu or from any other measurement menu in *CDMA2000 Signalling* using the hotkey *Menu – Power* (see Figure 4-28). The initial screen returns to the power application last accessed.

In the softkey bar on the right side, the *Power* menu provides different types of softkeys:

- The measurement control softkey *Mod. Qual. O-QPSK* changes to *Mod. Qual. H-PSK* or *Mod. Qual. QPSK*, depending on the application selected. This softkey controls the measurement, indicates its status (*RUN* | *HLT* | *OFF*) and opens the configuration menu *Modulation Configuration*. The hotkeys associated to the measurement control softkey define the scope of the *Modulation* measurement.
- The other softkeys on the right side are combined with various hotkeys (e.g. the hotkeys *RF Max. Level* and *RF Mode* belong to the softkey *Analyzer Level*). The softkey/hotkey combinations provide test settings and switch over between different measurements.

Note: *The configuration settings made in the Power applications (with either the softkeys or the Configuration menus) apply only to the measurements presented here. For example, configuration settings made here do not affect the configuration settings made within the Overview or Modulation applications.*

*All applications in the Power measurement except NPower have their own environment (see Chapter 3, section Measurement Environments). If the measurement environment is enabled in the configuration menu (see description in section [Power Configuration – Control](#) on p. 4.71 ff.), it overrides the Connection Control parameters as long as the measurement is switched on (*RUN*) and a connection is established. All Power measurement results are always obtained with the same parameter set.*

The Power Control Bits for the Min. Power and Max. applications are fixed, so that the mobile transmits at its minimum or maximum output power. Disabling the environments for these applications causes the fixed Power Control Bits to be overwritten. This may change the mobile transmitter output power and cause misleading results.

Refer to [Table 4-5](#) on page 4.42 for a list of measurements and their radio configuration requirements.

Filter settings for power measurements	The CMU measures and displays different MS transmitter output power results, acquired with different MS operating conditions and different measurement methods.
--	---

Most of the power measurements are performed using the baseband receiver filter specified in standard TIA/EIA/IS-2000.2-A. In particular, this holds for all results displayed in the *Power* menu. In *Signalling* mode, the power results listed in the table below are obtained with different measurement filters.

Table 4-6 Filer settings for power measurements (Signalling)

Value	Menu	Filter
Wideband Power	Connection Control, AF/RF \odot (see p. 4.46)	Wideband measurement
Sideband Suppression	Overview, see section Measurement Results on p. 4.54 ff.	30 kHz (Gaussian) spectrum analyzer filter
ACP	Spectrum, see section Measurement Results on p. 4.93 ff.	30 kHz (Gaussian) spectrum analyzer filter
Standby power	Connection Control, Connection see section Connection Control (Signal On State) on p. 4.46 ff.	1 MHz filter according to standard IS-98-D




Figure 4-28 Power measurement menu (Gated Output displayed)

Softkey Selections

Each *Power* application is controlled by means of the measurement control softkey below the *Connect*. *Control* softkey and the associated hotkeys. The properties of the measurement control softkey are analogous in all measurements; see section *Analyzer/Generator – Measurement Control* in the *Non Signalling* section. The remaining softkeys select the application and provide application-specific settings.

**Appli-
cation**

The *Application* softkey activates a set of hotkeys to select a power measurement. When an application is selected, the corresponding measurement screen is displayed.



Note: The *Power O-QPSK* measurements require a reverse *Radio Configuration 1* or *2*, *H-PSK* measurements a reverse *Radio Configuration 3* or *4*; see [Table 4-5](#) on p. 4.42. The *Gated Output Power* can be measured with reverse *Radio Configuration 1* or *2*, the *Open Loop Time Response* with reverse *Radio Configuration 1, 2, 3* or *4*.

**Min. Output
O-QPSK**

The *Minimum Output O-QPSK* hotkey changes the power measurement application to measure the minimum power output of the mobile station for the Offset Quadrature Phase Shift Keying modulation scheme.

Remote Control The *Min. Output QPSK* application is selected by the keywords `MIOutput[:OQPSk]` in the 3rd and 4th level of the `POWer` commands, e.g. `CONFigure:POWer:MIOutput[:OQPSk]...`

**Max. Output
O-QPSK**

The *Maximum Output O-QPSK* hotkey changes the power measurement application to measure the maximum power output of the mobile station for the Offset Quadrature Phase Shift Keying modulation scheme.

Remote Control The *Min. Output O-QPSK* application is selected by the keywords `MAOutput[:OQPSk]` in the 3rd and 4th level of the `POWer` commands, e.g. `CONFigure:POWer:MAOutput[:OQPSk]...`

**Open Loop
Time Resp.**

The *Open Loop Time Resp.* hotkey changes the power measurement application to measure the open loop power control time response to an increase or decrease of the total base station power.

Remote Control The *Open Loop Time Resp.* application is selected by the keywords `OLTResponse` in the 3rd level of the `POWer` commands, e.g. `CONFigure:POWer:OLTResponse...`

**Gated
Output**

The *Gated Output* hotkey changes the power measurement to display the time response of the mean output power for isolated gated-on power control groups.

Remote Control The *Gated Output* application is selected by the keywords `GOUTput` in the 3rd level of the `POWer` commands, e.g. `CONFigure:POWer:GOUTput...`

NPower

The *NPower* hotkey changes the power measurement to display the average, minimum and maximum power of an RF input signal in an evaluation period of variable length plus a statistical evaluation over several periods. *NPower* is identical to the *Power* measurement in *Non Signalling* mode.

Remote Control The *NPower* application is selected by the keyword `NPOWer` in the 2nd level of the commands, e.g. `CONFigure:NPOWer...` **No additional `POWer` keyword is needed.**

**Min. Output
H-PSK**

The *Minimum Output H-PSK* hotkey changes the power measurement application to measure the minimum power output of the mobile station for the Hybrid Phase Shift Keying modulation scheme.

Remote Control The *Min. Output H-PSK* application is selected by the keywords `MIOutput:HPSK`

in the 3rd and 4th level of the `POWER` commands, e.g.
`CONFigure:POWER:MIOutput:HPSK...`

**Max. Output
H-PSK**

The *Maximum Output H-PSK* hotkey changes the power measurement application to measure the maximum power output of the mobile station for the Hybrid Phase Shift Keying modulation scheme.

Remote Control The *Max. Output H-PSK* application is selected by the keywords `MAOutput:HPSK` in the 3rd and 4th level of the `POWER` commands, e.g.
`CONFigure:POWER:MAOutput:HPSK...`

**Analyzer
Level Trg.**

The *Analyzer Level/Trigger* softkey toggles between two sets of hotkeys to control the level in the RF signal path and define the trigger settings. These general settings are provided in the *Analyzer* and *Trigger* tabs of the *Connection Control* menu; see section [Analyzer Control \(Connection Control – Analyzer\)](#) on p. 4.165 ff and [Trigger \(Connection Control – Trigger\)](#) on p. 4.163 ff.

**BS Signal
Level Imp.**

The *BS Signal Level / Imp.* softkey toggles between two sets of hotkeys to adjust the signal impairments and the base station signal levels.

All settings belong to the *Power* measurement environment. They are also provided in the *Power Configuration* menu and described in section [Power Configuration – Control](#) on p. 4.71 ff.

**BS Signal
Set. P. Ctrl**

The *BS Signal Set. /P. Ctrl* softkey displays a set of hotkeys to adjust the RF channel and frame rate and the power control bits that the CMU sends to the mobile station to control its output power. *Frame Rate* and *Power Control Bits* belong to the *Power* measurement environment and are also provided in the *Power Configuration* menu (refer to section [Power Configuration – Control](#) on p. 4.71 ff.). *RF Channel* is a general parameter; see p. 4.147.

**Marker
Display**

The *Marker/Display* softkey positions up to three markers and a baseline (D-Line) in the test diagram and outputs their values. Refer to page 4.170 for detailed information about markers.

The softkey is only available for applications providing a graphical diagram, i.e. for *Open Loop Time Resp.* and *Gated Output*. The following hotkeys are associated to the *Display/Marker* version of the softkey (press twice) and configure the diagram in the *Gated Output* application.

**Display
Area**

The *Display Area* hotkey selects the full diagram width for display or zooms in on a particular section.

Full Display Show full diagram width: –100 µs to +1400 µs relative to the start of the gated-on time interval.

Rising Edge Zoom in on the rising edge: –50 µs to +50 µs relative to the start of the gated-on time interval.

Falling Edge Zoom in on the falling edge: +1200 µs to +1300 µs relative to the start of the gated-on time interval.

**Limit
Ref. Lines**

Limit Ref. Lines switches the limit reference lines (green, vertical, dotted lines) in the diagram on or off. The limit reference lines can be used to change the 0-µs time reference of the x-axis; see section [Modulation Configuration – Limits](#) on p. 4.89 ff.

Remote No commands; display configuration only.
Control

Menus

The *Menus* softkey displays the hotkey bar for switching to the other measurement menus.

Measurement Results

The CMU measures power by calculating the average power over a measurement interval. The measurement interval is 1229.5 chip intervals (0.5 ms).

- The *Minimum Output* application measures the mobile station's minimum output power. The screen displays a table of the measured values of the total channel power and the waveform quality of the signal.
- The *Maximum Output* application measures the mobile station's maximum output power. The screen displays a table of the measured values of the total channel power and the waveform quality of the signal.
- The *Open Loop Time Response* application measures the open loop power control time response to an increase or decrease of the total base station power.
- The *Gated Output* application measures the time response of the mean output power for isolated gated-on power control groups.
- The *NPower* application provides the average, minimum and maximum power of an RF input signal in an evaluation period of variable length plus a statistical evaluation over several periods. It is identical to the *Power* measurement in Non Signalling mode.

Measurement results are explained for each application. For the *NPower* results refer to section *Non Signalling – Power Measurements*.

Minimum Output

The *Minimum Output* application is available for both O-QPSK and H-PSK modulation schemes. The screen shots and discussions refer to O-QPSK but apply to both modulation schemes.

The *Minimum Output* application instructs the mobile station to reduce its output power to its minimum level. (This is in part done by setting the power control bits to the All Down mode.) The screen displays four measured values of the total channel power and the waveform quality of the signal. The application uses the values selected for CDMA Power, Traffic Level, and Pilot Level accessed either by the *BS Signal Level* softkey or in the *Control* tab of the *Power Configuration* menu.

The following values are returned for Total Power and Waveform Quality:

- Current is the current values of the measurement interval.
- Maximum and Minimum are the extreme values (and their polarity) of the power of all measurement intervals since the measurement started. Waveform quality measurements of the minimum and maximum power measurements are made at the time of the extreme values.
- Average is the value of a number of measurement intervals averaged together (defined by the *Statistic Count* setting).
- Waveform Quality is the modulation accuracy of the transmitted signal. The waveform quality is obtained by comparing the transmitted signal to an ideal O-QPSK/H-PSK signal as defined in standard TIA/EIA-98.




Figure 4-29 Measurement menu Power – Minimum Output

Maximum Output

The *Maximum Output* application is available for both O-QPSK and H-PSK modulation schemes. The screen shots and discussions refer to O-QPSK but apply to both modulation schemes.

The *Maximum Output* application instructs the mobile station to increase its output power to its maximum level. The screen displays four measured values of the total channel power and the waveform quality of the signal. The application uses the values selected for CDMA Power, Traffic Level, and Pilot Level accessed either by the *BS Signal Level* softkey or in the *Control* tab of the *Power Configuration* menu.

The following values are returned for Total Power and Waveform Quality:

- Current is the current values of the measurement interval.
- Maximum and Minimum are the extreme values (and their polarity) of the power of all measurement intervals since the measurement started. Waveform quality measurements of the minimum and maximum power measurements are made at the time of the extreme values.
- Average is the value of a number of measurement intervals averaged together (defined by the *Statistic Count* setting).
- Waveform Quality is the modulation accuracy of the transmitted signal. The waveform quality is obtained by comparing the transmitted signal to an ideal O-QPSK/H-PSK signal as defined in standard TIA/EIA IS-2000.




Figure 4-30 Measurement menu Power – Maximum Output

Open Loop Time Response

The *Open Loop Time Response* application is available for both O-QPSK and H-PSK modulation schemes. The screen shots and discussions refer to O-QPSK but apply to both modulation schemes.

The Open Loop Time Response application measures the open loop power control time response to an increase or decrease of the total base station power. The power step direction is set with either the *Power Stepping* softkey or in the *Power Configuration* menu in the *Control* tab. The template used for this measurement meets the requirements set in Standard TIA/EIA-98-D for Open Loop Time Response measurements.

Pressing the *ENTER (CONT/HALT)* starts the measurement. The measurement begins using the Initial BS Power setting then steps the power (up or down, depending on the configuration) using the defined BS Power Step parameter. When the measurement is done, the measurement halts and the BS Power is returned to the Initial BS Power setting.

The measurement screen for Open Loop can be divided into three groups:

- Scalar measurement results (parameter lines)
- Graph (a trace plotted as a function of time)
- Info Box (displaying measurements)




Figure 4-31 Measurement results (Open Loop)

Parameter Lines Scalar measurement results and settings are indicated in the two parameter lines above the test diagram and in the info box (a popup window in the middle of the graphical screen).

1st Line The first parameter line contains the following settings:

Output Power Total output power of the CMU, calculated as the sum of the forward CDMA power and the AWGN Level; see

FCH Level FCH level as set by means of the *BS Signal Level* softkey

PICH Level PICH level as set by means of the *BS Signal Level* softkey

2nd Line The second parameter line contains the following marker values:

R Level and time of reference marker

1 Level and time of marker 1 (setting *absolute*) and/or difference from reference marker (setting *relative*)

2 Level and time of marker 2 (setting *absolute*) and/or difference from reference marker (setting *relative*)

Info Box

The info box contains measurements concerning the open loop time response application. The arrow indicates the direction of the next power step. If a parameter exceeds its set limits, the info box turns red and displays the parameter exceeded and the current setting of that parameter.

Remote control Settings are read out using the query form of the setting command.

Measurement Graph The Measurement graph is displayed as a continuous curve together with the limit lines and all active markers. The template used for this measurement meets the requirements set in Standard TIA/EIA-98-D for Open Loop Time Response measurements.

The graph in each measurement shows the current power as a function of time.

Gated Output

The *Gated Output* application measures the time response of the mean output power for isolated gated-on power control groups.

Note: To ensure that the mobile station's output signal is gated, establish a connection with Reverse Radio Configuration 1 or 2.

The measurement screen for Gated Output can be divided into two groups:

- Scalar measurement results (parameter lines)
- Graph (a trace plotted as a function of time)

Parameter lines
1 and 2

Measurement graph

Info box





Figure 4-32 Display of measurement results (Gated Output screen)

Parameter Lines Scalar measurement results and settings are indicated in the two parameter lines above the test diagram and in the info box (a popup window in the middle of the graphical screen). The parameter lines show the same results as the *Open Loop Time Response* on p. 4.68 ff.

Info Box



The info box displays measurements concerning the gated output application. If any parameter exceeds the set limits, the info box turns red.

```
Remote READ[:SCALar]:POWer:GOUTput?
Control FETCh[:SCALar]:POWer:GOUTput?
        SAMPlE[:SCALar]:POWer:GOUTput?
```

Measurement Graph

The *Measurement graph* is displayed as a continuous curve together with the limit lines, the reference lines and all active markers. The reference lines can be switched off in the *Limits* tab of the *Power Control* menu. They are also used to

modify the time reference of the diagram; see section *Power Configuration – Limits* on p. 4.74 ff.

The graph in each measurement shows the respective measured power as a function of time.

The measured power is evaluated with 64 chips (i.e. 52 µs) before and after the actual isolated Power Control Group (PCG). Considering an oversampling factor of 1, a total of 64 + 1536 + 64 = 1664 valid samples is returned.

```

Remote READ:ARRays:POWer:GOUTput:CURRent?
Control READ:ARRays:POWer:GOUTput:AVErAge?
        READ:ARRays:POWer:GOUTput:MINimum?
        READ:ARRays:POWer:GOUTput:MAXimum?
        FETCh:ARRays:POWer:GOUTput:CURRent?
        FETCh:ARRays:POWer:GOUTput:AVErAge?
        FETCh:ARRays:POWer:GOUTput:MINimum?
        FETCh:ARRays:POWer:GOUTput:MAXimum?
        SAMPlE:ARRays:POWer:GOUTput:CURRent?
        SAMPlE:ARRays:POWer:GOUTput:AVErAge?
        SAMPlE:ARRays:POWer:GOUTput:MINimum?
        SAMPlE:ARRays:POWer:GOUTput:MAXimum?
    
```

Power Configuration

The popup menu *Power Configuration* contains tabs to define the parameters of each power measurement.

Pressing the power measurement softkey twice (once if already selected) opens the popup menu *Power Configuration*. Use the hotkeys at the bottom of the screen to change between the tabs. Use the roll-key to expand or compress the list of displayed settings.

Power Configuration – Control

The *Control* tab controls each of the power measurement applications. Each application lists the available settings for controlling the measurement.




Figure 4-33 Power Configuration – Control

All settings may not be available for all power measurement applications. The statistical settings *Repetition*, *Stop Condition*, *Statistic Count*, and *Display Mode* have the same meaning in all measurements (except the *Stop Condition* in *Receiver Quality*; see section [Receiver Quality Configuration – Control](#) on p. 4.118 ff.); they are described in section [Overview Configuration – Control](#) on p. 4.56 ff. The *Display Mode* is available for measurement curves only.

Default Settings The *Default Settings* switches assign default values to all settings in the *Control* tab (the default values are quoted in the command description in chapter 6 of this manual). Each default switch applies to an individual application.

Remote control

DEFault:POWer:<Application>:CONTrol ON | OFF

Power Step *Power Step* sets the power step size for the *Open Loop Time Response* application. The *Initial BS Power* setting is the reference level for the power step.

Remote Control CONFigure:POWer:OLTResponse:PSTep
<Power Step>

Begin Power Step *Begin Power Step* sets the direction of the initial power step for the *Open Loop Time Response* measurement. The *Initial BS Power* setting is the reference level for the power step.

Remote Control CONFigure:POWer:OLTResponse:PSDirection
UP | DOWN

Environment Enable *Environment Enable* enables or disables the environments for the individual *Power* applications:

On (box checked) The parameters listed in the *Measurement Environment* section are used as soon as a connection is established and the application is switched on.

Off (box unchecked) The *Measurement Environment* settings are ignored; the CMU always uses the corresponding *Connection Control* settings.

Note: *In the Misc. tab of the Connection Control menu, it is possible to enable or disable all measurement environments; see section [Miscellaneous User Settings \(Connection Control – Misc.\)](#) on p. 4.167 ff.*

The Power Control Bits for the Min. Power and Max. Power applications are fixed, so that the mobile transmits at its minimum or maximum output power. Disabling the environments for these applications causes the fixed Power Control Bits to be overwritten. This may change the mobile transmitter output power and cause misleading results.

In the Open Loop Time Response (OLTR) application, the CMU has to perform a power jump and record the mobile's answer. The appropriate BS Signal settings are defined in the measurement environment, therefore OLTR measurements will only run with the environment enabled. The CMU displays a warning if an OLTR measurement is started while the environment is disabled.

Remote control

CONFigure:POWer:<Application>:ENVironment:ENABle ON | OFF

Measurement Environment	<p>The <i>Measurement Environment</i> sections contain all parameters that form the measurement environments for the individual <i>Power</i> applications. The settings take effect if the environment is enabled (see above). All settings have an equivalent in the <i>BS Signal</i> or <i>Service Cfg.</i> tab of the <i>Connection Control</i> menu; see section Signals of the CMU (Connection Control – BS Signal) on p. 4.147 ff.</p>
Remote Control	<p>The commands of the <i>Power</i> measurement applications are analogous to the corresponding <i>BS Signal</i> commands. The keyword <code>:BSSignal</code> is replaced by <code>Power:<Application>:ENVIRONMENT</code>, e.g.:</p> <pre>CONFigure:POWer:MIOutput[:OQPSk]:ENVIRONMENT:POWer:CDMA <CDMA Power></pre>
BS Signal Level	<p>Sets the levels of the forward CDMA2000 signal of the CMU. In the <i>Open Loop Time Response</i> application, the <i>Initial CDMA Power</i> sets the CDMA power prior to the initial power step of the measurement.</p>
Impairments	<p>Sets parameters to impair the forward CDMA2000 signal of the CMU in order to simulate realistic propagation conditions and test the MS receiver.</p>
BS Signal Settings	<p>Sets the <i>F-FCH Frame Rate</i> to Half, Quarter, or Eighths. The frame rate has an equivalent in the <i>Service Cfg.</i> tab of the <i>Connection Control</i> menu; see section Service Configuration of the CMU (Connection Control – Service Cfg.) on p. 4.126 ff.</p> <p>Note: <i>The frame rate for the Open Loop Time Response measurement is always FULL. This ensures that the measured reverse CDMA2000 signal is a continuous signal.</i></p>
Power Control	<p><i>Power Control Bits</i> indicates the power control bit sequence that the CMU sends to the mobile station to control its output power.</p> <p>The applications of the <i>Power</i> menu command the mobile station to transmit at specific output power levels, so the <i>Power Control Bit</i> settings are always fixed. In the <i>Min. Power</i> and <i>Max. Power</i> applications, the CMU uses <i>All Down</i> and <i>All Up</i>, respectively; see note under <i>Measurement Enable</i> above. In the <i>Gated Output</i> and <i>Open Loop</i> applications, the power control bit modes <i>Hold</i> and <i>Auto</i> are used.</p>
PCG Count	<p><i>PCG Count</i> defines how many power control groups are used for a single trace in the <i>Gated Output</i> measurement.</p>
Remote Control	<pre>CONFigure:POWer:GOUTput:CONTRol:PCGcount <PCG Count></pre>

Power Configuration – Limits

The *Limits* tab defines tolerance limits for each of the Power measurement applications. This limits discussion is divided into two groups, Gated Power Limits and Minimum/Maximum Limits.

Gated Output Power Limits

The limits for the *Gated Output* application consist of a graphical tool for defining and monitoring tolerance values.




Figure 4-34 Power Configuration – Gated Output power limits

Default Settings The *Default Settings* switches assign default values to all settings in the *Limits* tab (the default values are quoted in the command description in chapter 6 of this manual). Each default switch applies to an individual application.

Remote control

DEFault:POWer:<Application>:LIMit ON | OFF

Display Limit Ref. Lines

Display Limit Ref. Lines switches the limit reference lines (green, vertical, dotted lines) in the diagram on or off.

By default, the limit reference lines show the start and end of the gated-on time interval. The left limit ref. line represents the 0- μ s time reference of the x-axis. The lower and right template part can be shifted relative to the left limit ref. line. In addition the right limit ref. line and the right template part can be shifted relative to the remaining part of the template. See also *B Limit (Reference Time)* and *E Limit (Reference Time)* parameters below.

Remote Control No commands; display configuration only.

Area Info (Limit Definitions)

The remaining part of the *Gated Output* section defines the limits and reference times for the GOP measurement. The meaning of the different parameters is sketched in the *Area Info* diagram showing the left, lower, and right part of the power template (red lines), the two limit reference lines (green) and the different parameters to modify the limits.

A Limit (Rise Time) Maximum rise time

B Limit (Reference Time) Offset time for the right limit reference line and the right

part of the power template relative to the upper end of the lower part of the power template. Increasing the offset time effectively increases the maximum fall time. This parameter must be larger than the sum of the *E Limit (Reference Time)* and the gated-on time (see below) so that the right limit reference is larger or equal than the upper end of the lower part of the power template.

<i>B Limit (Fall Time)</i>	Maximum fall time
<i>C Limit</i>	Minimum level of the gated-on power relative to the mean output power
<i>D Limit (relative)</i>	Maximum level of the gated-off power relative to the mean output power
<i>D Limit (absolute)</i>	Absolute maximum level of the gated-off power
<i>E Limit (Reference Time)</i>	Offset time for the lower and right part of the power template relative to the 0-μs time reference of the x-axis and the measurement curve. A positive offset time effectively increases the maximum rise time, shifting the lower part of the template to the right. The parameter can be used to modify or correct the time reference of the <i>Gated Output Power</i> diagram. Increasing this parameter also increases <i>B Limit (Reference Time)</i> so that: $B\ Limit\ (Ref.\ Time) \geq E\ Limit\ (Ref.\ Time) + E\ Limit\ (Gated\ On)$
<i>E Limit (Gated On)</i>	Minimum gated-on time. Increasing this parameter also increases <i>B Limit (Reference Time)</i> so that: $B\ Limit\ (Ref.\ Time) \geq E\ Limit\ (Ref.\ Time) + E\ Limit\ (Gated\ On)$

```
Remote Control CONFIGure:POWER:GOUTput:CAMMax:LIMit:<Area>:VALue
where <Area> = A | B | C | E
CONFIGure:POWER:GOUTput:CAMMax:LIMit:D:RELative:VALue
CONFIGure:POWER:GOUTput:CAMMax:LIMit:D:ABS:VALue
CONFIGure:POWER:GOUTput:CAMMax:LIMit:BREReference:VALue
CONFIGure:POWER:GOUTput:CAMMax:LIMit:EREReference:VALue
```

Minimum/Maximum Power Limits




Figure 4-35 Power Configuration – Minimum/Maximum Power Limits

**Minimum Power
(O-QPSK and H-
PSK)**

Absolute Min Power *Absolute Minimum Power* sets the minimum power level of the mean output power.

Waveform Quality *Waveform Quality* sets the minimum value acceptable for the calculated waveform quality.

Remote Control CONFigure:POWer:MIOutput[:OQPSk]:CAMMax:LIMit[:SCALar]:ASYMmetric[:COMBined]:VALue
CONFigure:POWer:MIOutput:HPSK:CAMMax:LIMit[:SCALar]:ASYMmetric[:COMBined]:VALue
<Absolute Min Power>, <Waveform Quality>

**Maximum Output
(O-QPSK and H-
PSK)**

Absolute Max Power *Absolute Maximum Power* sets the maximum power level of the mean output power.

Upper Limit *Upper Limit* sets the maximum level of the mean output power relative to the MS nominal maximum output power.

Lower Limit *Lower Limit* sets the minimum level of the mean output power relative to the MS nominal maximum output power.

Waveform Quality *Waveform Quality* sets the minimum value acceptable for the calculated waveform quality.

Remote Control CONFigure:POWer:MAOutput[:OQPSk]:CAMMax:LIMit[:SCALar]:ASYMmetric[:COMBined]:VALue
CONFigure:POWer:MAOutput:HPSK:CAMMax:LIMit[:SCALar]:ASYMmetric[:COMBined]:VALue
<Absolute Max Power>, <Upper Limit>, <Lower Limit>, <Waveform Quality>

Modulation Measurements

The menu group *Modulation* contains several applications to measure the modulation parameters such as frequency error, waveform quality of the mobile station, and matching of the respective tolerance limits. Measurement results are displayed with a graph and a table of measurement results. The popup menu *Modulation Configuration* configures the parameters of the modulation measurements.

The *Modulation* menu is opened from the *Menu Select* menu or from any other measurement menu in *CDMA2000 Signalling* using the hotkey *Menu – Modulation* (see [Figure 4-37](#)). The initial screen returns to the modulation application last accessed.

In the softkey bar on the right side, the *Modulation* menu provides different types of softkeys:

- The measurement control softkey *Overview O-QPSK* changes to *EVM O-QPSK* etc., depending on the application selected. This softkey controls the measurement, indicates its status (*RUN | HLT | OFF*) and opens the configuration menu *Modulation Configuration*. The hotkeys associated to the measurement control softkey define the scope of the *Modulation* measurement.
- The other softkeys on the right side are combined with various hotkeys (e.g. the hotkeys *RF Max. Level* and *RF Mode* belong to the softkey *Analyzer Level*). The softkey/hotkey combinations provide test settings and switch over between different measurements.

Note: *The CMU supports both O-QPSK and H-PSK modulation schemes. The CMU automatically selects the correct modulation scheme unless this feature is disabled in the Misc. tab of the Connection Control menu. Refer to section [Miscellaneous User Settings \(Connection Control – Misc.\)](#) on p. 4.167 ff.*

O-QPSK measurements require a reverse radio configuration setting of 1 or 2. H-PSK measurements require a reverse radio configuration setting of 2 or 3. Refer to [Table 4-5](#) on page 4.42 for a list of measurements and their radio configuration requirements.

Note: *The configuration settings made in the Modulation applications (with either the softkeys or the Configuration menus) apply only to the measurements presented here. For example, configuration settings made here do not affect the configuration settings made within the Overview or Power applications.*

The O-QPSK and H-PSK applications of the Modulation measurement have their own environments (see Chapter 3, section Measurement Environments). If the measurement environment is enabled in the configuration menu (see description in section [Overview Configuration – Control](#) on p. 4.56 ff.), it overrides the Connection Control parameters as long as the measurement is switched on (RUN) and a connection is established. All Modulation measurement results are always obtained with the same parameter set.

Refer to [Table 4-5](#) on page 4.42 for a list of measurements and their radio configuration requirements.

The CMU measures the O-QPSK / H-PSK modulation accuracy by calculating the Phase Error, Magnitude Error, and Error Vector Magnitude of the modulated signal from the mobile station. [Figure 4-36](#) shows a representation of these signal errors compared to an ideal signal.

- *Phase Error (PE)* is the measured phase difference of the I/Q components of the signal received (from the mobile station) and an ideal reference signal at the detection points.
- *Magnitude Error (ME)* is the normalized magnitude (amplitude) difference of the I/Q components of the signal received from the mobile station and an ideal reference signal at the detection points.
- *Error Vector Magnitude (EVM)* is the normalized magnitude of the calculated vector linking the measured I/Q values to the ideal signal's I/Q components at the detection points.

The In-phase and Quadrature reference components are based on an O-QPSK / H-PSK waveform as specified in the IS-2000 standards publication.

For a CDMA2000 signal (H-PSK in RC3, 4) the composite Phase Error (PE), Magnitude Error (ME), Error Vector Magnitude (EVM), and Waveform Quality are calculated.

The measurement interval for O-QPSK / H-PSK is 616 chip intervals (≈ 0.5 ms). The graphical displays represents 500 chips for O-QPSK and 616 chips for H-PSK..

Note: The screen shots and discussions in this chapter refer to O-QPSK but apply to both modulation schemes.




Figure 4-36 Modulation errors




Figure 4-37 Modulation measurement menu


Softkey Selections

Each *Modulation* application is controlled by means of the measurement control softkey below the *Connect. Control* softkey and the associated hotkeys. The properties of the measurement control softkey are analogous in all measurements; see section *Analyzer/Generator – Measurement Control* in the *Non Signalling* section. The remaining softkeys select the application and provide application-specific settings.

**Appli-
cation**

The *Application* softkey activates a set of hotkeys to select a modulation application. This softkey toggles the application hotkeys between the O-QPSK and H-PSK modulation schemes (*Applic. 1* and *Applic. 2*). When an application is selected, the corresponding measurement screen is displayed.

Only O-QPSK keys and menus are shown and described but the information also applies to H-PSK.



Note: The O-QPSK modulation measurements require a reverse Radio Configuration 1 or 2, H-PSK measurements a reverse Radio Configuration 3 or 4; see [Table 4-5](#) on p. 4.42.

**Overview
O-QPSK**

The *Overview O-QPSK* hotkey displays the statistics for all modulation measurements. No graphical display is provided.

Remote Control The *Overview O-QPSK* and *Overview H-PSK* applications are selected by the keywords `OVERview[:OQPSk]` and `OVERview:HPSK` in the 3rd and 4th level of the `POWer` commands, e.g.

```
CONFigure:MODulation:OVERview[:OQPSk]...
CONFigure:MODulation:OVERview:HPSK...
```

**EVM
O-QPSK**

The *Error Vector Magnitude* hotkey displays the Error Vector Magnitude. The Error Vector Magnitude measurement is described in section [Measurement Results](#) on p. 4.81 ff.

Remote Control The *EVM O-QPSK* and *EVM H-PSK* applications are selected by the keywords `EVMagnitude[:OQPSk]` and `EVMagnitude:HPSK` in the 3rd and 4th level of the `POWer` commands, e.g.

```
CONFigure:MODulation:EVMagnitude[:OQPSk]...
CONFigure:MODulation:EVMagnitude:HPSK...
```

**Magn. Err.
O-QPSK**

The *Magnitude Error* hotkey displays the Magnitude Error measurement. The Magnitude Error measurement is described in section [Measurement Results](#) on p. 4.81 ff.

Remote Control The *Magn. Err. O-QPSK* and *Magn. Err. H-PSK* applications are selected by the keywords `MERRor[:OQPSk]` and `MERRor:HPSK` in the 3rd and 4th level of the `POWer` commands, e.g.

```
CONFigure:MODulation:MERRor[:OQPSk]...
CONFigure:MODulation:MERRor:HPSK...
```

**Phase Err.
O-QPSK**

The *Phase Error* hotkey displays the Phase Error measurement. The Phase Error measurement is described in section [Measurement Results](#) on p. 4.81 ff.

Remote Control The *Phase Err. O-QPSK* and *Phase Err. H-PSK* applications are selected by the keywords `PERRor[:OQPSk]` and `PERRor:HPSK` in the 3rd and 4th level of the `POWer` commands, e.g.
`CONFigure:MODulation:PERRor[:OQPSk]...`
`CONFigure:MODulation:PERRor:HPSK...`

**I/Q Analyz.
O-QPSK**

The *I/Q Analyz. O-QPSK* hotkey selects the diagrams to display the modulation vector in the I/Q plane (constellation diagram, vector diagram) and the I and Q amplitude vs. time (*I Phase, Q Phase, I Phase & Q Phase*).

The diagram type is selected via *Display – Waveform* or in the configuration menu; see section *Modulation Configuration – Control* on p. 4.87 ff.

Remote Control The *I/Q Analyz. O-QPSK* and *I/Q Analyz. H-PSK* applications are selected by the keywords `IQANalyzer[:OQPSk]` and `IQANalyzer:HPSK` in the 3rd and 4th level of the `POWer` commands, e.g.
`CONFigure:MODulation:IQANalyzer[:OQPSk]...`
`CONFigure:MODulation:IQANalyzer:HPSK...`

**Analyzer
Level Trg.**

The *Analyzer Level/Trigger* softkey toggles between two sets of hotkeys to control the level in the RF signal path and define the trigger settings. These general settings are provided in the *Analyzer* and *Trigger* tabs of the *Connection Control* menu; see section *Analyzer Control (Connection Control – Analyzer)* on p. 4.165 ff and *Trigger (Connection Control – Trigger)* on p. 4.163 ff.

**BS Signal
Level Imp.**

The *BS Signal Level / Imp.* softkey toggles between two sets of hotkeys to adjust the signal impairments and the base station signal levels.

All settings belong to the *Modulation* measurement environment. They are also provided in the *Modulation Configuration* menu and described in section *Power Configuration – Control* on p. 4.71 ff.

**BS Signal
Set. P. Ctrl**

The *BS Signal Set. /P. Ctrl* softkey displays a set of hotkeys to adjust the RF channel and frame rate and the power control bits that the CMU sends to the mobile station to control its output power. *Frame Rate* and *Power Control Bits* belong to the *Overview* measurement environment and are also provided in the *Overview Configuration* menu (refer to section *Power Configuration – Control* on p. 4.71 ff.). *RF Channel* is a general parameter; see p. 4.147.

**Marker
Display**

The *Marker/Display* softkey positions up to three markers and a baseline (D-Line) in the test diagram and outputs their values. Refer to page 4.170 for detailed information about markers.

The softkey is only available for applications providing a graphical diagram, i.e. for the *EVM...*, *Magn. Err...* and *Phase Err...* applications. In the *I/Q Analyz...* applications, it is replaced by the *Display* softkey providing display options for the diagrams; see section *Modulation Configuration – Control* on p. 4.87 ff.

Menus

The *Menus* softkey displays the hotkey bar for switching to the other measurement menus.

Measurement Results

The values shown in the *Modulation* measurement menus can be divided into three groups:

- Setting values
- Scalar measurement results (single values)
- Arrays (curves plotted as a function of time)

The measurement menu for the *Overview* application shows all scalar results but no curve. The measurement menus for the *EVM*, *Magn. Err.* and *Phase Err.* applications show the phase error, the (relative) magnitude error or the (relative) error vector magnitude as a function of time and the corresponding peak and effective values. The range and unit of the y-axis is adjusted to the measured quantity. The *I/Q Analyzer* application provides a graphical analysis of the modulation vector in the I/Q plane.

Test Diagrams (EVM, Phase Error, Magn. Error)

The graphical measurement menus for the *EVM*, *Magn. Err.* and *Phase Err.* applications are analogous. The results are indicated in a parameter line, the test diagram, and a tabular overview below:




Figure 4-38 Modulation results display

Parameter Lines Scalar measurement results and settings are indicated in the two parameter lines above the test diagram and in the *Settings* table below.

1st Line The first parameter line contains the following settings:

- Output Power* Total output power of the CMU, calculated as the sum of the forward CDMA power and the AWGN Level; see
- PICH Level* PICH level as set by means of the *BS Signal Level* softkey
- Channel* *RF Channel* set for the BS Signal

2nd Line The second parameter line contains the following marker values:

- Level and time of reference marker
- Level and time of marker 1 (setting *absolute*) and/or difference from reference marker (setting *relative*)
- Level and time of marker 2 (setting *absolute*) and/or difference from reference marker (setting *relative*)

Settings	The values shown in the <i>Settings</i> table are defined in the <i>Control</i> tab of the <i>Connection Control</i> menu; see section Modulation Configuration – Control on p. 4.87 ff.						
Measurement Graph	<p>The <i>Measurement Graph</i> is displayed as a continuous curve together with the limit lines and all active markers.</p> <p>The graph in each measurement shows the respective measurement error as a function of time. The display mode for the graph (<i>Current, Average, Max/Min</i>) is indicated in the upper right corner of the screen.</p>						
Statistic Count	The <i>Statistic Count</i> is the number of intervals since the start of the measurement. The bar graph represents a percentage of intervals measured based on the number of intervals (<i>Statistic Count</i>) set in the configuration menu.						
Output Table	<p>The output table contains a tabular overview of modulation related measurements. The first rows of data are specific to the selected modulation measurement. The remaining rows are identical for each modulation measurement.</p> <p>Three values are given for each row:</p> <table border="0" style="margin-left: 40px;"> <tr> <td style="padding-right: 20px;"><i>Current</i></td> <td>These are the current values of the measurement interval.</td> </tr> <tr> <td><i>Max/Min</i></td> <td>These are the extreme values (and their polarity) of all measurement intervals since the measurement started.</td> </tr> <tr> <td><i>Average</i></td> <td>These are the average values of a number of measurement intervals (defined by the <i>Statistic Count</i> setting; see section <i>General Settings</i> in Chapter 3).</td> </tr> </table> <p>Any values exceeding the defined limits appear with a red background. Limit values are set in the Limit tab of the <i>Modulation Configuration</i> menu.</p>	<i>Current</i>	These are the current values of the measurement interval.	<i>Max/Min</i>	These are the extreme values (and their polarity) of all measurement intervals since the measurement started.	<i>Average</i>	These are the average values of a number of measurement intervals (defined by the <i>Statistic Count</i> setting; see section <i>General Settings</i> in Chapter 3).
<i>Current</i>	These are the current values of the measurement interval.						
<i>Max/Min</i>	These are the extreme values (and their polarity) of all measurement intervals since the measurement started.						
<i>Average</i>	These are the average values of a number of measurement intervals (defined by the <i>Statistic Count</i> setting; see section <i>General Settings</i> in Chapter 3).						
Modulation Error	<p>Refer to the respective measurement type for information about the data reported in these first two rows.</p> <table border="0" style="margin-left: 40px;"> <tr> <td style="padding-right: 20px;"><i>Phase Error</i></td> <td>Measured phase difference of the I/Q components of the signal received (from the mobile station) and an ideal reference signal at the detection points.</td> </tr> <tr> <td><i>Magnitude Error</i></td> <td>Difference in magnitude (in percent) between the received signal waveform and an ideal O-QPSK signal waveform. The magnitude error is the difference in amplitude between the measured signal from the mobile station transmitter and an ideal signal waveform at the detection points.</td> </tr> <tr> <td><i>Error Vector Magnitude</i></td> <td>Calculated percentage of vector error (at the detection points) between the received signal and an ideal signal.</td> </tr> </table>	<i>Phase Error</i>	Measured phase difference of the I/Q components of the signal received (from the mobile station) and an ideal reference signal at the detection points.	<i>Magnitude Error</i>	Difference in magnitude (in percent) between the received signal waveform and an ideal O-QPSK signal waveform. The magnitude error is the difference in amplitude between the measured signal from the mobile station transmitter and an ideal signal waveform at the detection points.	<i>Error Vector Magnitude</i>	Calculated percentage of vector error (at the detection points) between the received signal and an ideal signal.
<i>Phase Error</i>	Measured phase difference of the I/Q components of the signal received (from the mobile station) and an ideal reference signal at the detection points.						
<i>Magnitude Error</i>	Difference in magnitude (in percent) between the received signal waveform and an ideal O-QPSK signal waveform. The magnitude error is the difference in amplitude between the measured signal from the mobile station transmitter and an ideal signal waveform at the detection points.						
<i>Error Vector Magnitude</i>	Calculated percentage of vector error (at the detection points) between the received signal and an ideal signal.						
Carrier Feedthrough	<i>Carrier Feedthrough</i> refers to the origin offset, which is the magnitude of the RF carrier relative to the magnitude of the modulated carrier.						
I/Q Imbalance	<i>I/Q Imbalance</i> is the amplitude ratio between the in-phase (I) and quadrature (Q) components of the signal.						
Carrier Freq Error	<i>Carrier Frequency Error</i> is the difference between the nominal frequency of the selected channel and the measured frequency.						
Transmit Time Error	<i>Transmission Time Error</i> is the time offset between the mobile station's signal and the CMU's signal.						

Waveform Quality *Waveform Quality* is the modulation accuracy of the transmitted signal. The waveform quality is obtained by comparing the transmitted signal to an ideal O-QPSK signal as defined in standard TIA/EIA-98.

MS Power *MS Power* is the total transmitted power level from the mobile station.

```
Remote READ[:SCALar]:MODulation:<Application>?
Control FETCh[:SCALar]:MODulation:<Application>?
        SAMPlE[:SCALar]:MODulation:<Application>?
```

Overview

The Overview application allows you to view all modulation measurements in a single output table (no graph of the measurements is provided).

The peak and the RMS values of the current measurement interval are displayed for each modulation application. The average values (positive or negative) are calculated over a user definable number of *Statistic Counts*. The Min/Max. values are the extreme values from the start of the measurement.




Figure 4-39 Overview display

Display of the Modulation Vector (I/Q Analyzer)

The *I/Q Analyz. O-QPSK* and *I/Q Analyz. H-PSK* each provide five different graphical menus to display and analyze the modulation vector of the received O-QPSK and H-PSK modulated signal. The diagram type is selected via *Display – Waveform* or in the configuration menu; see section [Modulation Configuration – Control](#) on p. 4.87 ff.

Representation in the I/Q Plane: O-QPSK

The *Constellation* and the *Vector* diagram both show the basic properties of the O-QPSK modulation vector in the I/Q plane. The menus display the actual test diagram and several output fields for the basic power and modulation parameters.




Figure 4-40 Display of results (Modulation – I/Q Analyzer – Constellation/Vector)

Diagrams

The constellation and vector diagrams trace the O-QPSK modulation vector in the normalized I/Q plane over a definite time interval. The normalized I amplitude $\langle I \rangle$ scales the horizontal axis, the normalized Q amplitude $\langle Q \rangle$ scales the vertical axis. The phase angle is given by

$$\phi = \arctan(\langle Q \rangle / \langle I \rangle),$$

and the normalization is chosen so that the signal amplitude at the constellation points averaged over the measurement length is equal to 1.

The two diagrams differ in the way the result is displayed.

Constellation diagram In the *Constellation* diagram the **offset-compensated** modulation vector is traced at the constellation points; the diagram shows a dot for each chip symbol. The constellation diagram of an ideal, offset-compensated O-QPSK signal contains 4 constellation points with distance 1 from the origin and relative angles of $\pi/2$. Large variations of the symbol point positions in the constellation diagram indicate a poor signal quality; see Figure 4-36 on p. 4.78.

Note: Offset Compensation

“Offset QPSK” (O-QPSK) modulation means that the Q amplitude is shifted relative to the I amplitude by half a chip period. To obtain fixed constellation points the two amplitudes must be measured with a time offset of 1/2 chip. This is done in the constellation diagram which looks like a constellation diagram for an ordinary QPSK modulated signal.

In the vector diagram offset compensation is not applied. The ideal constellation points are located at fixed I amplitude values $\pm 1/\sqrt{2}$. The corresponding Q amplitudes are measured between two consecutive fixed positions. They vary because the modulation scheme allows transitions between each pair of constellation points.

Vector diagram In the *Vector* diagram the modulation vector is traced with an oversampling factor of 8; the diagram shows a continuous curve.

The vector diagram is not offset-corrected (see note on offset compensation above): The light blue points correspond to the constellation points of the I

amplitude, so their I coordinates vary around the ideal value $\pm 1/\sqrt{2}$. The Q values are smeared out so that the blue points form two vertical bands, centered around $\pm 1/\sqrt{2}$.

Settings To customize the graphical representation it is possible to zoom the diagrams, move the origin in I and Q directions, and to display or remove the grid. See section [Modulation Configuration – Control](#) on p. 4.87 ff.

Remote control

READ:ARRay:MODulation:IQANalyzer[:OQPSk]? etc.

Output fields

The output fields to the right of the diagrams show the most important scalar modulation parameters; see section [Test Diagrams \(EVM, Phase Error, Magn. Error\)](#) on p. 4.81 ff.

Remote control

READ[:SCALar]:MODulation:IQANalyzer[:OQPSk]? etc.

Representation of the Amplitudes vs. Time: O-QPSK

The *I Phase*, the *Q Phase*, and the *I Phase & Q Phase* diagrams show the normalized amplitudes of the I and Q components of the modulation vector as a function of time (eye diagrams). All diagrams are Cartesian diagrams, the time forming the x-axis.




Figure 4-41 Display of results (Modulation – I/Q Analyzer – I Phase & Q Phase)

Diagram

The *I Phase*, the *Q Phase*, and the *I Phase & Q Phase* diagrams trace the normalized I and Q amplitudes as a function of time. Diagrams of this type are often referred to as eye diagrams. The horizontal axis covers a fixed 2-chip time interval, starting at the time of an I constellation point. The measurement curve restarts at the left diagram edge after each 2-chip period so that the complete diagram with a measurement length of 616 chips contains 308 superimposed curves.

The number of nodes on the vertical axis of the I or Q eye diagram is equal to the number of different I or Q amplitudes in the constellation diagram. The number of eyes is equal to the number of nodes minus one. Smeared-out nodes and small eye apertures indicate a poor signal quality.

The *I Phase* and *Q Phase* diagrams are analogous, however, the eye patterns of both diagrams are shifted relative to each other by half a chip period (see note on offset compensation in section [Representation in the I/Q Plane: O-QPSK](#) on p. 4.84

ff.). This can be observed in the combined *I Phase & Q Phase* diagram where the *I Phase* diagram is displayed on top of the *Q Phase* diagram.

Settings To customize the graphical representation it is possible to zoom the diagrams in vertical direction, keeping the zero-amplitude reference at fixed position, and to display or remove the grid.

Remote control

READ:ARRay:MODulation:IQANalyzer[:OQPSk]? etc.

Representation in the I/Q Plane: H-PSK

The *Constellation* and the *Vector* diagram both show the basic properties of the H-PSK modulation vector in the I/Q plane. The menus display the actual test diagram and seven output fields for the slot number and the standard modulation parameters.




Figure 4-42 Display of results (Modulation – I/Q Analyzer – I Phase & Q Phase, H-PSK)

Diagram

The constellation and vector diagrams are analogous to the diagrams for single QPSK-modulated signals, however, more constellation points occur if several channels with different power contribute to the analyzed H-PSK signal. Moreover, the H-PSK signal contains no time offset so that both the constellation and the vector diagram show distinct constellation points (see note on offset compensation in section [Representation in the I/Q Plane: O-QPSK](#) on p. 4.84 ff.).

Remote control

READ:ARRay:MODulation:IQANalyzer:HPSK? etc.

Settings/ Scalar results

The output fields show the most important scalar modulation parameters. The results are equal to the results in the other *Modulation* applications.

Remote control

READ[:SCALar]:MODulation:IQANalyzer:HPSK? etc.

Representation of the Amplitudes vs. Time: H-PSK

The *I Phase*, the *Q Phase*, and the *I Phase & Q Phase* diagrams show the normalized amplitudes of the I and Q components of the modulation vector as a function of time (eye diagrams). All diagrams are Cartesian diagrams, the time forming the x-axis.




Figure 4-43 Display of results (Modulation – I/Q Analyzer – I Phase & Q Phase, H-PSK)

Diagram

The *I Phase*, the *Q Phase*, and the *I Phase & Q Phase* diagrams are analogous to the diagrams for O-QPSK-modulated signals, however, more nodes and eyes occur as several signals with different power contribute to the analyzed H-PSK signal and the constellation diagram becomes more complex. Moreover, the H-PSK signal contains no time offset so that the eye patterns of the I and Q amplitudes are synchronous (see note on offset compensation in section [Representation in the I/Q Plane: O-QPSK](#) on p. 4.84 ff.).

Remote control

READ:ARRay:MODulation:IQANalyzer:HPSK? etc.

Modulation Configuration

The popup menu *Modulation Configuration* contains two tabs to define the parameters of the modulation measurements including the error tolerances.

Pressing the measurement softkey twice opens the popup menu *Modulation Configuration*. Press the associated hotkeys to change between tabs. Use the roll-key to expand or compress the list of settings displayed.

Modulation Configuration – Control

The *Control* tab controls the modulation measurement applications. The control configuration is first divided into settings for O-QPSK and H-PSK. Within these categories, there are both configurations that affect all modulation measurements and settings for each individual modulation measurement.

Since the settings for O-QPSK and H-PSK are identical, only the O-QPSK menus are shown and described.




Figure 4-44 Modulation Configuration – Control

All settings may not be available for all modulation measurement applications. The statistical settings *Repetition*, *Stop Condition*, *Statistic Count*, and *Display Mode* have the same meaning in all measurements (except the *Stop Condition* in *Receiver Quality Configuration – Control* on p. 4.118 ff.); they are described in section *Overview Configuration – Control* on p. 4.56 ff. The *Display Mode* is available for measurement curves only.

Most of the parameters are analogous to the corresponding *Power* settings and described in section *Power Configuration – Control* on p. 4.71 ff. The following *I/Q Analyzer* settings are specific to the *Modulation* measurement:

Note: *The I/Q analyzer can be operated in Single Shot or Continuous mode. A single shot measurement extends over 616 chip periods.*

Zoom *Zoom* magnifies the diagram with an equal factor in horizontal and vertical direction, leaving the center (i.e. the intersection between the I and Q axis) at fixed position:
Normal The normalized I and Q amplitudes range between –2 and +2.
Factor n The normalized I and Q amplitudes range between –2/n and +2/n, where n = 2, 5, 10, 20.

Note: *The Zoom and Waveform Type functions are also accessible via softkey/hotkey combinations in the measurement menu (the hotkeys are associated to the Display softkey). The Zoom hotkey also shifts the center in the vector and constellation diagrams.*

Remote control
 no command, display configuration only.

Waveform Type *Waveform Type* selects the diagram type:
Correlation Correlation diagram; see section *Representation in the I/Q Plane* on p. 4.84 ff.
Vector Vector diagram; see section *Representation in the I/Q Plane* on p. 4.84 ff.
I Phase Eye diagram of the I amplitude; see section *Representation of the Amplitudes vs. Time* on p. 4.85 ff.
Q Phase Eye diagram of the Q amplitude; see section *Representation of the Amplitudes vs. Time* on p. 4.85 ff.
I Phase & Q Ph. Eye diagrams of the I and Q amplitude in a single diagram; see section *Representation of the Amplitudes vs. Time* on p. 4.85 ff.

Remote control
no command, display configuration only.

Modulation Configuration – Limits

The *Limits* tab defines the tolerance limits for each of the *Modulation* measurement applications. Two sets of limits are configurable for each measurement: the *Current* and *Maximum/Minimum* measurement limits and the *Average* measurement limits.




Figure 4-45 Modulation Configuration – Limits

Default All Settings

The *Default All Settings* switch assigns default values to all parameters of the modulation *Limits* tab (the default values are quoted in the command description in chapter 6 of this manual). Additional default switches are provided for the individual applications.

Remote control

DEFault:MODulation:<Application>:LIMit ON | OFF

Current & Max/Min

Current and Max/Min sets the limits for the measured values in the current waveform interval or of the extreme values of all measured waveform intervals (Min/Max).

Remote control

```
CONFigure:MODulation:OEMP[:OQPSk]:CMMax:LIMit[:SCALar]:
SYMMetric[:COMBined]:VALue
CONFigure:MODulation:OEMP[:OQPSk]:CMMax:LIMit[:SCALar]:
SYMMetric[:COMBined]:ENABLE
CONFigure:MODulation:OEMP[:OQPSk]:CMMax:LIMit[:SCALar]:
SYMMetric[:COMBined]
CONFigure:MODulation:OEMP:HPSK:CMMax:LIMit[:SCALar]:
SYMMetric[:COMBined]:VALue
CONFigure:MODulation:OEMP:HPSK:CMMax:LIMit[:SCALar]:
SYMMetric[:COMBined]:ENABLE
CONFigure:MODulation:OEMP:HPSK:CMMax:LIMit[:SCALar]:
SYMMetric[:COMBined]
```

Average

Average sets the limits are for the average value of the measured values derived from the last statistic cycle.

Remote control

```
CONFigure:MODulation:OEMP[:OQPSk]:AVERage:LIMit[:SCALar]:  
SYMMetric[:COMBined]:VALue  
CONFigure:MODulation:OEMP[:OQPSk]:AVERage:LIMit[:SCALar]:  
SYMMetric[:COMBined]:ENABle  
CONFigure:MODulation:OEMP[:OQPSk]:AVERage:LIMit[:SCALar]:  
SYMMetric[:COMBined]  
CONFigure:MODulation:OEMP:HPSK:AVERage:LIMit[:SCALar]:  
SYMMetric[:COMBined]:VALue  
CONFigure:MODulation:OEMP:HPSK:AVERage:LIMit[:SCALar]:  
SYMMetric[:COMBined]:ENABle  
CONFigure:MODulation:OEMP:HPSK:AVERage:LIMit[:SCALar]:  
SYMMetric[:COMBined]
```


Spectrum Measurements

The *Spectrum* menu provides access to the ACP spectrum measurement. The *Spectrum* menu is opened from the *Menu Select* menu (with associated key at the front of the instrument). The hotkeys associated to the *Menus* softkey switch over between the *Spectrum* menu and the remaining measurement menus of the CDMA2000 function group.

The *Spectrum* measurement serves to measure the strength of spurious emissions in the vicinity of the designated channel frequency (carrier frequency). An excess amount of off-carrier power increases the interference with adjacent channels and decreases the system capacity.

ACP The off-carrier power is measured at four configurable, symmetrical pairs of offset frequencies from the nominal carrier frequency and displayed as an Adjacent Channel Power (ACP) relative to the carrier power. In contrast to other power measurements, the ACP is measured with a 30 kHz spectrum analyzer filter; see also Table 4-6 on p. 4.63.

The ACP at a single pair of offset frequencies is also available in the *Overview* menu; see *Sideband Suppression* on p. 4.55.

In the softkey bar on the right side, the *Spectrum* menu provides different types of softkeys:

- The measurement control softkey *ACP* controls the measurement, indicates its status (*RUN* | *HLT* | *OFF*) and opens the configuration menu *Spectrum Configuration*. The hotkeys associated to the measurement control softkey define the scope of the *Spectrum* measurement.
- The other softkeys on the right side are combined with various hotkeys (e.g. the hotkeys *RF Max. Level* and *RF Mode* belong to the softkey *Analyzer Level*). The softkey/hotkey combinations provide test settings and switch over between different measurements.

Note: In contrast to most other measurement applications, *Spectrum – ACP* does not have its own environment (see Chapter 3, section Measurement Environments). All settings are either common settings or measurement-specific settings that are also provided in the *Spectrum Configuration* menu.




Figure 4-46 Measurement menu Spectrum

Softkey Selections

The *Spectrum* application is controlled by means of the measurement control softkey below the *Connect. Control* softkey and the associated hotkeys. The properties of the measurement control softkey are analogous in all measurements; see section *Analyzer/Generator – Measurement Control* in the *Non Signalling* section. The remaining softkeys and hotkeys provide common settings.

Analyzer Level Trg.

The *Analyzer Level/Trigger* softkey toggles between two sets of hotkeys to control the level in the RF signal path and define the trigger settings.

These general settings are provided in the *Analyzer* and *Trigger* tabs of the *Connection Control* menu; see section *Analyzer Control (Connection Control – Analyzer)* on p. 4.165 ff and *Trigger (Connection Control – Trigger)* on p. 4.163 ff.

BS Signal Level Imp.

The *BS Signal Level / Imp.* softkey toggles between two sets of hotkeys to adjust the signal impairments and the base station signal levels.

These general settings are provided in the *BS Signal* tab of the *Connection Control* menu and described in section *Signals of the CMU (Connection Control – BS Signal)* on p. 4.147 ff.

BS Signal Set. P. Ctrl

The *BS Signal Set. /P. Ctrl* softkey toggles between two sets of hotkeys to adjust the RF channel and frame rate and configure the power control bits that the CMU sends to the mobile station to control its output power.

These general settings are provided in the *Generator* tab of the *Connection Control* menu and described in section *Signals of the CMU (Connection Control – BS Signal)* on p. 4.147 ff.

Marker Display

The *Marker* softkey positions up to three markers in the test diagram and indicates their values. Refer to page 4.170 for detailed information about markers.

Menus

The *Menus* softkey displays the hotkey bar for switching to the other measurement menus.

Measurement Results

The results are displayed in a bar graph and an output table plus various output fields below.




Figure 4-47 Display of results (Analyzer/Generator)

Parameter Lines Scalar measurement results and settings are indicated in the two parameter lines above the test diagram and in the *Settings* table below.

1st Line The first parameter line contains the following settings:
RF Max. Level The total output power, either calculated in adaptation to the signal level (Auto) or set manually.

2nd Line The second parameter line contains the following marker values:

- R** Level and time of reference marker
- 1** Level and time of marker 1 (setting *absolute*) and/or difference from reference marker (setting *relative*)
- 2** Level and time of marker 2 (setting *absolute*) and/or difference from reference marker (setting *relative*)

Bar Graph The bar graph represents the Adjacent Channel Power (ACP) for the given *ACP Frequency Offset* values. The ACP is the ratio of the power at the frequency offset to the channel power. The y-axis of the diagram uses a fixed dB-scale.

The channel power is displayed in the center of the diagram. The offset values can be selected in the [Spectrum Configuration – Control](#) tab described on p. 4.95. All powers are measured with a 30 kHz spectrum analyzer filter and averaged over a basic evaluation period of one waveform interval.

The red lines in the diagram indicate the upper limits for the ACP as set in the [Spectrum Configuration – Limits](#) tab (see p. 4.96).

The display mode for the graph (*Current, Average, Max/Min*) is indicated in the upper right corner of the screen. It can be selected with the softkey *Display Mode* that is visible when the measurement control softkey has been selected.

Output Table	The output table displays the values in the bar graph for the three possible display modes. Each display mode corresponds to a separate line:						
	<table border="0"> <tr> <td style="padding-right: 20px;"><i>Current (C.)</i></td> <td>Average ACP and channel power (central dBm-value) the measurement interval.</td> </tr> <tr> <td><i>Average (A.)</i></td> <td>Average of the <i>Current</i> results referenced to the last statistics cycle; see description of averaging in Chapter 3, section <i>General Settings</i>.</td> </tr> <tr> <td><i>Maximum (M.)</i></td> <td>Maximum of all <i>Current</i> results since the measurement was started.</td> </tr> </table>	<i>Current (C.)</i>	Average ACP and channel power (central dBm-value) the measurement interval.	<i>Average (A.)</i>	Average of the <i>Current</i> results referenced to the last statistics cycle; see description of averaging in Chapter 3, section <i>General Settings</i> .	<i>Maximum (M.)</i>	Maximum of all <i>Current</i> results since the measurement was started.
<i>Current (C.)</i>	Average ACP and channel power (central dBm-value) the measurement interval.						
<i>Average (A.)</i>	Average of the <i>Current</i> results referenced to the last statistics cycle; see description of averaging in Chapter 3, section <i>General Settings</i> .						
<i>Maximum (M.)</i>	Maximum of all <i>Current</i> results since the measurement was started.						
Remote Control	<pre>READ[:SCALar]:SPECTrum:ACP? FETCh[:SCALar]:SPECTrum:ACP? SAMPlE[:SCALar]:SPECTrum:ACP?</pre>						

Additional output fields	Below the output table, the following results are displayed:				
	<table border="0"> <tr> <td style="padding-right: 20px;"><i>Statistic Count</i></td> <td>Number of waveform intervals per statistics cycle. The colored bar indicates the relative measurement progress in the statistics cycle.</td> </tr> <tr> <td><i>Out of Tolerance</i></td> <td>Percentage of waveform intervals measured where the tolerances are exceeded.</td> </tr> </table>	<i>Statistic Count</i>	Number of waveform intervals per statistics cycle. The colored bar indicates the relative measurement progress in the statistics cycle.	<i>Out of Tolerance</i>	Percentage of waveform intervals measured where the tolerances are exceeded.
<i>Statistic Count</i>	Number of waveform intervals per statistics cycle. The colored bar indicates the relative measurement progress in the statistics cycle.				
<i>Out of Tolerance</i>	Percentage of waveform intervals measured where the tolerances are exceeded.				
Remote Control	<pre>XTND:SPECTrum:ACP:STATistics ON READ[:SCALar]:SPECTrum:ACP? etc.</pre>				

Limit Check	A red output field indicates that the measurement result exceeds the upper relative limits set in the Spectrum Configuration – Limits tab (see p. 4.96). If a limit is exceeded in the diagram, the blue bar crosses the red limit line, and the corresponding section of the horizontal limit bar below the diagram turns red.
	<p>Remote control</p> <pre>CALCulate[:SCALar]:SPECTrum:ACP:MATChing:LIMits?</pre>

Settings table	The <i>Settings</i> table on the lower right side of the <i>Spectrum</i> menu gives an overview of the measurement settings of the current application as defined by means of the softkey/hotkey combinations or in the configuration menus. The roll-key scrolls and expands the <i>Setup</i> table.
-----------------------	---

Spectrum Configuration

The popup menu *Spectrum Configuration* contains two tabs to define the parameters of the spectrum measurements including the error tolerances.

Pressing the measurement softkey twice opens the popup menu *Spectrum Configuration*. Press the associated hotkeys to change between tabs. Use the roll-key to expand or compress the list of settings displayed.

Spectrum Configuration – Control

The *Control* tab controls the spectrum measurement applications by defining the statistical settings and the four offset frequencies for the ACP measurement.




Figure 4-48 Spectrum Configuration – Control

The statistical settings *Repetition*, *Stop Condition*, *Statistic Count*, and *Display Mode* have the same meaning in all measurements (except the *Stop Condition* in *Receiver Quality*; see section [Receiver Quality Configuration – Control](#) on p. 4.118 ff.); they are described in section [Overview Configuration – Control](#) on p. 4.56 ff.

ACP Frequency Offset *ACP Frequency Offset* selects the frequency offset from the selected Channel/Frequency where the ACP is measured. The selected offset values will be displayed in the diagram under the measurement bars.

ACP1...4 *ACP 1..4* are pairs of symmetrical offsets: The ACP is measured at the carrier frequency plus and minus the selected frequency offset. The measurement supports up to 4 different offset pairs; setting *OFF* for a pair disables the ACP measurement.

The default values for the frequency offsets depend on the selected band class (BC 0 to BC 10; see Table 1-1 in Chapter 1).

Remote Control `CONFigure:SPECTrum:ACP:CONTrol:FOFFset:ACP1[?]`
`CONFigure:SPECTrum:ACP:CONTrol:FOFFset:ACP2[?]`
`CONFigure:SPECTrum:ACP:CONTrol:FOFFset:ACP3[?]`
`CONFigure:SPECTrum:ACP:CONTrol:FOFFset:ACP4[?]`

Spectrum Configuration – Limits

The *Limits* tab defines the tolerance limits for each of the *Spectrum* measurement application.




Figure 4-49 Modulation Configuration – Limits

ACP 1..4 Limit *ACP 1..4 Limit* sets the limit for each pair of symmetrical ACP frequency offsets. The limits are used for the measurement at the positive and the negative offset.

Remote control `CONFigure:SPECTrum:ACP:LIMit:ACP1 [?]`
`CONFigure:SPECTrum:ACP:LIMit:ACP2 [?]`
`CONFigure:SPECTrum:ACP:LIMit:ACP3 [?]`
`CONFigure:SPECTrum:ACP:LIMit:ACP4 [?]`

Code Domain Power Measurements

The menu group *Code Domain Power* (CDP H-PSK) measures the Code Domain Power (*CDP H-PSK*), Peak Code Domain Error Power (*PCDEP H-PSK*), the Channel Power (*Ch. Power H-PSK*), and the phase and timing error between the Reverse Pilot Channel and the other code channels (*Phase Offs. H-PSK, Time Offs. H-PSK*).

The *Modulation* menu is opened from the *Menu Select* menu or from any other measurement menu in *CDMA2000 Signalling* using the hotkey *Menu – Modulation* (see [Figure 4-50](#)). The initial screen returns to the modulation application last accessed.

In the softkey bar on the right side, the *Code Domain Power* menu provides different types of softkeys:

- The measurement control softkey *CDP H-PSK* changes to *PCDEP H-PSK, Ch. Power H-PSK* etc., depending on the application selected. This softkey controls the measurement, indicates its status (*RUN | HLT | OFF*) and opens the configuration menu *Code Dom. Power Configuration*. The hotkeys associated to the measurement control softkey define the scope of the *Code Domain Power* measurement.
- The other softkeys on the right side are combined with various hotkeys (e.g. the hotkeys *RF Max. Level* and *RF Mode* belong to the softkey *Analyzer Level*). The softkey/hotkey combinations provide test settings and switch over between different measurements.

Note: *The configuration settings made in the Code Domain Power applications (with either the softkeys or the Configuration menus) apply only to the measurements presented here. For example, configuration settings made here do not affect the configuration settings made within the Power or Modulation applications.*

The CDP measurement has its own environment (see Chapter 3, section Measurement Environments). If the measurement environment is enabled in the configuration menu (see description in section [Overview Configuration – Control](#) on p. 4.56 ff.), it overrides the Connection Control parameters as long as the measurement is switched on (RUN) and a connection is established. All CPP measurement results are always obtained with the same parameter set.

Refer to [Table 4-5](#) on page 4.42 for a list of measurements and their radio configuration requirements.

All Code Domain Power measurements require a Reverse Radio Configuration 3 or 4.




Figure 4-50 Code Domain Power measurement menu

Softkey Selections

Each *Code Domain Power* application is controlled by means of the measurement control softkey below the *Connect*. *Control* softkey and the associated hotkeys. The properties of the measurement control softkey are analogous in all measurements; see section *Analyzer/Generator – Measurement Control* in the *Non Signalling* section. The remaining softkeys select the application and provide application-specific settings.

The *Result Order* and *Spreading Factor* hotkeys associated to the measurement control softkey are only provided for the *CDP H-PSK* and *PCDEP H-PSK* measurement applications. See description on p. 4.108.

Application

The *Application* softkey activates a set of hotkeys to select a code domain power measurement application. When an application is selected, the corresponding measurement screen is displayed.



Note: All Code Domain Power measurements require a reverse Radio Configuration 3 or 4; see Table 4-5 on p. 4.42.

CDP H-PSK

The *CDP H-PSK* hotkey changes the CDP measurement application to measure the Code Domain Power of the mobile station.

Remote Control The *CDP H-PSK* application is selected by the keyword `CDPW` in the 3rd level of the `CDPower` commands, e.g.
`CONFigure:CDPower:CDPW...`

PCDEP H-PSK

The *PCDEP H-PSK* hotkey changes the CDP measurement application to measure the Peak Code Domain Error Power of the mobile station.

Remote Control The *PCDEP H-PSK* application is selected by the keyword `PCDep` in the 3rd level of the `CDPower` commands, e.g.
`CONFigure:CDPower:PCDep...`

**Ch. Power
H-PSK**

The *Ch. Power H-PSK* hotkey changes the CDP measurement application to measure the Channel Power of the mobile station.

Remote Control The *PCDEP H-PSK* application is selected by the keyword `CHPW` in the 3rd level of the `CDPower` commands, e.g.
`CONFigure:CDPower:CHPW...`

**Phase Offs.
H-PSK**

The *Phase Offs. H-PSK* hotkey changes the CDP measurement application to measure the phase error between the Reverse Pilot Channel and the other code channels radiated by the mobile station.

Remote Control The *Phase Offs. H-PSK* application is selected by the keyword `POFFset` in the 3rd level of the `CDPower` commands, e.g.
`CONFigure:CDPower:POFFset...`

**Time Offs.
H-PSK**

The *Time Offs. H-PSK* hotkey changes the CDP measurement application to measure the timing error between the Reverse Pilot Channel and the other code channels radiated by the mobile station.

Remote Control The *Time Offs. H-PSK* application is selected by the keyword `TOFFset` in the 3rd level of the `CDPower` commands, e.g.
`CONFigure:CDPower:TOFFset...`

**Analyzer
Level Trg.**

The *Analyzer Level/Trigger* softkey toggles between two sets of hotkeys to control the level in the RF signal path and define the trigger settings. These general settings are provided in the *Analyzer* and *Trigger* tabs of the *Connection Control* menu; see section [Analyzer Control \(Connection Control – Analyzer\)](#) on p. 4.165 ff and [Trigger \(Connection Control – Trigger\)](#) on p. 4.163 ff.

**BS Signal
Level Imp.**

The *BS Signal Level / Imp.* softkey toggles between two sets of hotkeys to adjust the signal impairments and the base station signal levels.

All settings belong to the *Code Domain Power* measurement environment but are common to all CDP applications. They are also provided in the *Code Domain Power Configuration* menu and described in section [Power Configuration – Control](#) on p. 4.71 ff.

**BS Signal
Set. P. Ctrl**


The *BS Signal Set. /P. Ctrl* softkey displays a set of hotkeys to adjust the RF channel and frame rate and the power control bits that the CMU sends to the mobile station to control its output power. *Frame Rate* and *Power Control Bits* belong to the *Overview* measurement environment and are also provided in the *Overview Configuration* menu (refer to section [Power Configuration – Control](#) on p. 4.71 ff.). *RF Channel* is a general parameter; see p. 4.147.

Marker

The *Marker* softkey positions up to three markers and a baseline (D-Line) in the *CDP H-PSK* and *PCDEP H-PSK* test diagram and outputs their values. Refer to page 4.170 for detailed information about markers.

Display

The *Display* softkey sets the diagram scale in the *Phase Offs. H-PSK* and *Time Offs. H-PSK* applications.



The *Menus* softkey displays the hotkey bar for switching to the other measurement menus.

Measurement Results

The CMU measures the code power of the mobile station's physical channels, resulting in the Code Domain Power measurement. Five applications are available for Code Domain Power measurements.

- *Code Domain Power* (CDP) is the power of the individual Walsh code channels of the mobile station. The screen displays a bar graph of the power level of the individual channels. Both I and Q signal power is displayed. The evaluation can be done in code class 32 or 16, depending on the *Spreading Factor* setting (see p. 4.110). Moreover it is possible to change the order of the code channels in the bar graph (*Result Order*).
- *Peak Code Domain Error Power* (PCDEP) is the measured I/Q signal compared to an ideal reference signal.
- *Channel Power* (*Ch. Power H-PSK*) is the power of the reverse physical channels of both the I and Q signal.
- *Phase Offset* (*Phase Offs. H-PSK*) is the phase error between the Reverse Pilot Channel and the other code channels radiated by the mobile station. The I and Q signals are displayed separately.
- *Time Offset* (*Time Offs. H-PSK*) is the timing error between the Reverse Pilot Channel and the other code channels radiated by the mobile station. The I and Q signals are displayed separately.

Measurement results are explained in detail for each application.

Code Domain Power

Code Domain Power measures the individual power level of each code channel and presents the results as bar graphs. Both the I-Signal and Q-Signal power levels are displayed.

The measurement screen for Code Domain Power can be divided into three groups:

- Scalar measurement results (parameter lines)
- Bar graph
- Measurements and settings

Parameter lines
1 and 2

Measurement bar
graphs

Measurements and
Settings







Figure 4-51 Display of measurement results (Code Domain Power screen)

Parameter Lines Scalar measurement results and settings are indicated in the two parameter lines above the test diagram and in the *Settings* table below.

1st Line The first parameter line contains the following settings:

- CDMA Power* Total output power of the CMU, calculated as the sum of the forward CDMA power and the AWGN Level; see
- PICH Level* PICH level as set by means of the *BS Signal Level* softkey
- Channel* *RF Channel* set for the BS Signal


2nd Line The second parameter line contains the following marker values:

-  Level and time of reference marker
-  Level and time of marker 1 (setting *absolute*) and/or difference from reference marker (setting *relative*)
-  Level and time of marker 2 (setting *absolute*) and/or difference from reference marker (setting *relative*)

Measurement Bar Graphs The *Measurement bar graph* displays the power of each channel together with the limit lines and all active markers.

- The bar graph either shows the current, average, or maximum levels as set in the configuration menu.
- The limit lines provide a quick reference point to view inactive channels exceeding set limits; see *Limit Check* below.
- The *active* channels are indicated with a solid bar graph while the *inactive* are outlined (see the legend below the diagrams).

The number of bars in the graphs and their order can be customized by means of the *Spreading Factor* and *Bit Reverse* parameters; see section [Code Domain Power Configuration – Control](#) on p. 4.107 ff.



Remote READ:ARRAY:CDPower:CDPW:ISIGNAL[:VALUE]:CURRENT?
 Control READ:ARRAY:CDPower:CDPW:QSIGNAL[:VALUE]:CURRENT? etc.
 FETCh:ARRAY:CDPower:CDPW:ISIGNAL:STATE?
 FETCh:ARRAY:CDPower:CDPW:QSIGNAL:STATE?

Measurements and Settings

The area below the bar graphs displays the results of power and waveform quality measurements. Measurements in red indicate they exceed the limit set in the configuration menu.

MS Power *MS Power* is the total transmitted power level from the mobile station.

Carrier Feedthrough *Carrier Feedthrough* refers to the origin offset, which is the magnitude of the RF carrier relative to the magnitude of the modulated carrier.

Frequency Error *Frequency Error* is the difference between the nominal frequency of the selected channel and the measured frequency.

Rho Rho is the ratio of the correlated power to the total power.
 The correlated power is a calculated vector between a corrected signal and an ideal reference. The corrected signal is created by removing phase, frequency, and timing offsets.

Statistic Count *Statistic Count* defines the length of the statistic cycles in waveform intervals/evaluation periods.

Out of Tolerance *Out of Tolerance* is the percentage of waveform intervals that exceed the defined limits.

Settings The Settings window lists the most important settings made in either the Configuration Menu or the hotkeys.

Remote READ[:SCALAR]:CDPower:CDPW?
 Control FETCh[:SCALAR]:CDPower:CDPW?
 SAMPLE[:SCALAR]:CDPower:CDPW?

Limit Check

The limit lines visualize the upper limits for the CDP in all inactive I and Q channel contributions as set in the *Limits tab* of the configuration menu. When an inactive channel contribution exceeds the limit, the corresponding section of the limit check bar below the diagram turns red.

The *IQ Leakage Check* parameter (see p. 4.111) can be used to restrict the limit check to restricts the limit check to code channels with inactive I and Q contributions.

Peak Code Domain Error Power

Peak Code Domain Error Power (PCDEP) displays the error signal over the code domain channels. The error is the difference between the measured signal and the ideal reference signal.

Besides all settings and results are analogous the Code Domain Power results described in section Code Domain Power on p. 4.100 ff.

Parameter lines 1 and 2

Measurement bar graphs

Measurements and Settings



Figure 4-52 Display of measurement results (Code Domain Error Power screen)

Channel Power

Channel Power (Ch. Power H-PSK) is the power of the reverse physical channels of both the I and Q signal.

The measurement screen for Code Domain Channel Power can be divided into three groups:

- Scalar measurement results (parameter lines)
- Bar Graph
- Measurements and Settings

Parameter line

Measurement bar graph 1

Bar graph 2

Measurements and settings




Figure 4-53 Display of measurement results (Channel Power screen)

Parameter Lines and Settings Scalar measurement results and settings are indicated in the parameter line above the test diagram and in the *Settings* table on the left side.

The first parameter line and the *Settings* table is identical to the *Code Domain Power* application; see section [Code Domain Power](#) on p. 4.100 ff. The second parameter line is omitted as no markers are available.


Measurement Bar Graphs

The *Measurement bar graphs* display the power of each channel together with the limit lines. The I signal levels are displayed in the upper bar graph, the Q signal levels are displayed in the lower bar graph.

The bar graphs either show the current, average, or maximum levels as set in the configuration menu. The limit lines provide a quick reference point to view channels exceeding set limits. The limit line level is set in the Configuration Menu.

The *active* channels are indicated with a solid bar graph while the *inactive* are outlined (see the legend below the diagrams). Aliased channels are indicated with a lined bar graph. An aliased channel is a code channel that is not active in the current radio configuration but assigned to a different physical channel so that it receives power (e.g. the R-EACH is aliased if the R-SCH0 is active).

Below each bar is its measured value.



Remote Control
 READ:ARRAY:CDPower:CHPW:ISIGNAL[:VALUE]:CURRENT?
 READ:ARRAY:CDPower:CHPW:QSIGNAL[:VALUE]:CURRENT? etc.
 FETCH:ARRAY:CDPower:CHPW:ISIGNAL:STATE?
 FETCH:ARRAY:CDPower:CHPW:QSIGNAL:STATE?

Measurements and Settings

This area displays the results of power and waveform quality measurements. Measurements in red indicate they exceed the limit set in the Configuration Menu.

The values are identical to the *Code Domain Power* application; see section [Code Domain Power](#) on p. 4.100 ff.

Remote Control
 READ[:SCALAR]:CDPower:CHPW?
 FETCH[:SCALAR]:CDPower:CHPW?
 SAMPLE[:SCALAR]:CDPower:CHPW?

Phase Offset

Phase Offset (Phase Offs. H-PSK) is the phase error between the Reverse Pilot Channel and the other code channels radiated by the mobile station.

The measurement screen for *Phase Offs. H-PSK* is divided into several groups of display elements:

- A parameter lines shows the most important *BS Signal* settings.
- Two bar graphs display the phase offset of I and Q signal channels, respectively.
- Additional measurement results and settings are shown in the tables to the right of the diagrams.




Figure 4-54 Display of measurement results (Phase Offset screen)

Parameter Lines and Settings

Measurement settings are indicated in the parameter line above the test diagram and in the *Settings* table on the right side.

The parameter line and the *Settings* table is identical to the *Code Domain Power* application; see section [Code Domain Power](#) on p. 4.100 ff.

Measurement Bar Graphs

The two bar graphs display the phase offset of each channel together with the limit lines. Results are only available for active channels so that some bars may be missing.

Depending on the *Display Mode* set in the *Control* tab of the configuration menu, the bar graphs either show the current, average, or maximum phase errors. All phase errors are relative to the Reverse Pilot Channel (*R_PICH W032*, the first channel in the *I-Signal* diagram) which is consequently displayed with zero phase error. The y-axis covers a symmetric phase error interval around zero; the scale can be changed using *Display – Phase Span*.

Below each bar is its numeric value. The display elements in the diagrams and the indication of *active*, *inactive* and *aliased* channels is analogous to the *Channel Power* diagrams; see section [Channel Power](#) on p. 4.103 ff.

```
Remote Control READ:ARRay:CDPower:POFFset:ISIGNAL[:VALue]:CURRent?
Remote Control READ:ARRay:CDPower:POFFset:QSIGnal[:VALue]:CURRent? etc.
Remote Control FETCh:ARRay:CDPower:POFFset:ISIGNAL:STATE?
Remote Control FETCh:ARRay:CDPower:POFFset:QSIGnal:STATE?
```

Limit Check

The limit lines provide a quick reference point to view channels exceeding the limit defined in the *Limits* tab of the configuration menu. Numeric measurement results in red indicate they exceed the limit set in the *Limit* tab of the *Code Domain Power Configuration* menu.

A limit check is also provided for the power and waveform quality measurements.

```
Remote Control CALCulate:ARRay:CDPower:POFFset:ISIGNAL:CURRent[:RESult]
Remote Control :MATChing:LIMit? etc.
```

Measurements and Settings

The tables to the right of the diagrams display the results of power and waveform quality measurements. The values are identical to the *Code Domain Power* application; see section [Code Domain Power](#) on p. 4.100 ff.

Remote READ[:SCALar]:CDPower:POFFset?
 Control FETCh[:SCALar]:CDPower:POFFset?
 SAMPlE[:SCALar]:CDPower:POFFset?

Limit Check The limit lines provide a quick reference point to view channels exceeding the limit defined in the *Limits* tab of the configuration menu. Numeric measurement results in red indicate they exceed the limit set in the *Limit* tab of the *Code Domain Power Configuration* menu.

A limit check is also provided for the power and waveform quality measurements.

Remote CALCulate:ARRay:CDPower:POFFset:ISIGNAL:CURRENT[:RESult]
 Control :MATChing:LIMit? etc.
 CALCulate[:SCALar]:CDPower:POFFset:MATChing:LIMit?

Time Offset

Time Offset (Time Offs. H-PSK) is the timing error between the Reverse Pilot Channel and the other code channels radiated by the mobile station.

The measurement screen for *Time Offs. H-PSK* is divided into several groups of display elements:

- A parameter lines shows the most important *BS Signal* settings.
- Two bar graphs display the Time Offset of I and Q signal channels, respectively.
- Additional measurement results and settings are shown in the tables to the right of the diagrams.

Parameter line

I Signal diagram

Q Signal diagram




Figure 4-55 Display of measurement results (Channel Power screen)

Parameter Lines and Settings

Measurement settings are indicated in the parameter line above the test diagram and in the *Settings* table on the right side.

The parameter line and the *Settings* table is identical to the *Code Domain Power* application; see section [Code Domain Power](#) on p. 4.100 ff.

Measurement Bar Graphs

The two bar graphs display the time offset of each channel together with the limit lines. Results are only available for active channels so that some bars may be missing.

Depending on the *Display Mode* set in the *Control* tab of the configuration menu,

the bar graphs either show the current, average, or maximum timing errors. All timing errors are relative to the Reverse Pilot Channel (*R_PICH W032*, the first channel in the *I-Signal* diagram) which is therefore displayed with zero timing error. The y-axis covers a symmetric time offset interval around zero; the scale can be changed using *Display – Phase Span*.

Below each bar is its numeric value. The display elements in the diagrams and the indication of *active*, *inactive* and *aliased* channels is analogous to the *Channel Power* diagrams; see section *Channel Power* on p. 4.103 ff.

Remote READ:ARRAY:CDPower:TOffset:ISignal[:Value]:Current?
 Control READ:ARRAY:CDPower:TOffset:QSignal[:Value]:Current? etc.
 FETCh:ARRAY:CDPower:TOffset:ISignal:State?
 FETCh:ARRAY:CDPower:TOffset:QSignal:State?

Measurements and Settings

The tables to the right of the diagrams display the results of power and waveform quality measurements. The values are identical to the *Code Domain Power* application; see section *Code Domain Power* on p. 4.100 ff.

Remote READ[:SCALar]:CDPower:TOffset?
 Control FETCh[:SCALar]:CDPower:TOffset?
 SAMPlE[:SCALar]:CDPower:TOffset?

Limit Check

The limit lines provide a quick reference point to view channels exceeding the limit defined in the *Limits* tab of the configuration menu. Numeric measurement results in red indicate they exceed the limit set in the *Limit* tab of the *Code Domain Power Configuration* menu.

A limit check is also provided for the power and waveform quality measurements.

Remote CALCulate:ARRAY:CDPower:TOffset:ISignal:Current[:Result]
 Control :MAtChing:LIMit? etc.
 CALCulate[:SCALar]:CDPower:POFFset:MAtChing:LIMit?

Code Domain Power Configuration

The popup menu *Code Domain Power Configuration* contains tabs to define the parameters of each code domain power application including the error tolerances.

Pressing the measurement softkey twice (once if already selected) opens the popup menu *Code Domain Power Configuration*. Use the hotkeys at the bottom of the screen to change between the tabs. Use the roll-key to expand or compress the list of displayed settings.

Code Domain Power Configuration – Control

The *Control* tab controls each of the measurement applications. Each application lists the available settings for controlling the measurement.

The control settings consist of *Common Settings* (settings that affect all code domain power applications) followed by settings specific to an application.




Figure 4-56 Code Domain Power Configuration – Control

All settings may not be available for all CDP measurement applications. The statistical settings *Repetition*, *Stop Condition*, *Statistic Count*, and *Display Mode* have the same meaning in all measurements (except the *Stop Condition* in *Receiver Quality*; see section [Receiver Quality Configuration – Control](#) on p. 4.118 ff.); they are described in section [Overview Configuration – Control](#) on p. 4.56 ff. The *Display Mode* applies to the values in the bar graphs only.

Most other parameters are analogous to the corresponding *Power* settings and described in section [Power Configuration – Control](#) on p. 4.71 ff. The following parameters are not provided in the *Power Configuration* menu:

**Code Domain Power/
Peak C.D. Error Power/**

Result Order

Result Order defines the method used to display the code channels; see background information below. This setting is only available for *Code Domain Power* and *Peak Code Domain Error* measurement applications.

Hadamard

The code channels are displayed in the order determined by the Hadamard matrix. The codes are numbered as Walsh codes W_n^{SF} , where SF is the *Spreading Factor*; see below.

The reverse CDMA2000 channels use fixed Walsh codes with SFs ranging from 2 to 32; see standard TIA/EIA/IS-2000.2-A and [Table 4-7](#) below. The Walsh code numbers n can be read directly from the measurement bar graphs. Channels with a SF < 32 (<16, if a *Spreading Factor* of 16 is selected) and therefore higher data rate are displayed with several active bars. .

Bit reverse

The code channels are displayed in the order defined by the Orthogonal Variable Spreading Factor (OVSF) code tree so that related code channels are adjacent to each other. This ensures that high data rate channels with smaller SF are always displayed as one contiguous block.

Remote CONFIGure:CDPower:CDPW:CONTrol:RORDER
Control CONFIGure:CDPower:PCDEP:CONTrol:RORDER
HADamard | BITReverse

Table 4-7 Walsh codes for reverse CDMA2000 channels

Channel Type	Walsh Function
Reverse Pilot Channel	W_0^{32}
Enhanced Access Channel	W_2^8
Reverse Common Control Channel	W_2^8
Reverse Dedicated Control Channel	W_8^{16}
Reverse Fundamental Channel	W_4^{16}
Reverse Supplemental Channel 1	W_1^2 or W_2^4
Reverse Supplemental Channel 2	W_2^4 or W_6^8


Walsh codes and OVSF codes

According to standard TIA/EIA/IS-2000.2-A, CDMA2000 channels are spread using orthogonal Walsh functions W_n^{SF} that are serially constructed from a SF x SF Hadamard matrix. Hadamard matrices can be generated by means of the following recursive procedure:

$$H_1 = 0, \quad H_2 = \begin{matrix} 0 & 0 \\ 0 & 1 \end{matrix}, \quad H_{2N} = \begin{matrix} H_N & H_N \\ H_N & \overline{H_N} \end{matrix};$$

where N is a power of 2 and $\overline{H_N}$ denotes the binary complement of H_N .

Orthogonal Variable Spreading Factor codes provide an alternative scheme of generating codes that preserve orthogonality between channels with different rates and spreading factors. According to standard 3GPP TS 25.213, they are generated using the following code tree:



For a given spreading factor SF, Walsh codes and OVFS codes can be derived from each other by assigning code numbers in binary format. The Walsh code no. n is equal to the OVFS code number m and vice versa, provided that m and n have inverse binary representation (n is converted into m by reversing the order of bits in the binary representation of n). For numbers with symmetrical binary representation (e.g 00 or 1001), the Walsh code and OVFS code numbers are equal.

E.g. for spreading factor SF = 4, the two schemes provide the following codes:

Hadamard (Walsh codes)			Bit reverse (OVFS codes)		
Code (SF = 4)	Code number Dec.	Code number Binary	Code (SF = 4)	Code number Dec.	Code number Binary
0 0 0 0	0	00	0 0 0 0	0	00
0 1 0 1	1	01	0 0 1 1	1	01
0 0 1 1	2	10	0 1 0 1	2	10
0 1 1 0	3	11	0 1 1 0	3	11

To obtain the *Bit reverse* representation from the *Hadamard* representation, the codes no. 01 and 10 (binary) must be interchanged.

Spreading Factor *Spreading Factor* selects the code class in which the forward CDMA signal is evaluated and is equal to the number of bars displayed in the CDP H-PSK and PCDEP H-PSK applications. Together with the *Result Order* parameter, it can be used to optimize the evaluation and the screen display. Spreading factors of 32 or 16 are provided.

Remote `CONFigure:CDPower:CDPW:CONTRol:SFACTOR`
 Control `CONFigure:CDPower:PCDEP:CONTRol:SFACTOR`

Code Domain Power Configuration – Limits

The *Limits* tab defines tolerance limits for each of the Code Domain Power measurement applications.

The limits settings consist of both *Common Settings* (settings that affect all code domain power applications) and then settings specific to an application.




Figure 4-57 Code Domain Power Configuration – Limits

Default All Settings The *Default All Settings* switch assigns default values to all parameters of the modulation *Limits* tab (the default values are quoted in the command description in chapter 6 of this manual). Additional default switches are provided for common limit settings and for the individual applications.

Remote control
 DEFault:CDPower:<Application>:LIMit ON | OFF

Common Settings *Common Settings* are settings that affect all code domain power applications.

Current & Max Sets the limits used when the display is set to the *Current* or *Min/Max* display mode.

Carrier Feedthr. Upper limit for the difference between magnitude of the RF carrier and the modulated carrier.

Frequency Error Upper limit for the difference between the measured and the expected frequency of the signal.

Rho Upper limit of the ratio of the correlated power and the total power.

Remote Control CONFigure:CDPower:CPCCommon:CMAx:LIMit:ASYMmetric [:COMBined] <Carrier Feedthrough Limit>, <Freq Error Limit>, <Rho Limit>

Average Sets the limits used when the display is set to the *Average* display mode. The available settings are the same as described for the *Current & Max* display mode.

Remote Control CONFigure:CDPower:CPCCommon:AVErAge:LIMit:ASYMmetric [:COMBined] <Carrier Feedthrough Limit>, <Freq Error Limit>, <Rho Limit>

Code Domain Power Contains the limit settings applicable to the *Code Domain Power* measurement.

IQ Leakage Check Decouples the limit check in the I and Q branches.

On (box checked) The limit check fails if any of the inactive I and Q channel contributions exceeds the (upper) limit for the code domain power.

Off (box unchecked) The limit check is restricted to inactive code channels. Each code channel with an active I or Q contribution is considered to meet the specifications, irrespective of the code domain power in the inactive branch.

Remote Control CONFigure:CDPower:CDPW:LIMit:IQLCheck ON | OFF

Current & Max Sets the limits used when the display is set to the *Current* or *Min/Max* display mode.

CDP Limit Value (and placement) of the limit line displayed on the measurement screen. The limit line indicates the upper limit for the CDP in all inactive I and Q channel contributions. See also *Leakage Check* parameter above.

Remote Control CONFigure:CDPower:CDPW:CMAx:LIMit:ASYMmetric [:COMBined] <CDP Limit Y>

Average	<p>Sets the limits used when the display is set to the Average display mode. The available settings are the same as described for the Current & Max display mode.</p> <p>Remote Control <code>CONFigure:CDPower:CDPW:AVERage:LIMit:ASYMmetric [:COMBined] <CDP Limit Y></code></p>
Peak CD. Error Power	<p>Contains the upper limit settings applicable to the <i>Peak Code Domain Error Power</i> measurement. The upper PCDEP limit check is done for all active and inactive channels.</p> <p>Remote Control <code>CONFigure:CDPower:PCDEP:CMax:LIMit:ASYMmetric [:COMBined] CONFigure:CDPower:PCDEP:AVERage:LIMit:ASYMmetric [:COMBined] <CDP Limit Y></code></p>
Channel Power	<p>Contains the limit settings applicable to the <i>Channel Power</i> measurement. The available settings are the same as described for the <i>Code Domain Power</i>.</p> <p>Remote Control <code>CONFigure:CDPower:CHPW:CMax:LIMit:ASYMmetric [:COMBined] CONFigure:CDPower:CHPW:AVERage:LIMit:ASYMmetric [:COMBined] <CDP Limit Y></code></p>
Phase Offset	<p>Contains the limit settings applicable to the <i>Phase Offset</i> measurement. The limits for the measured phase offset can be set independently for the <i>Current / Maximum</i> and for the <i>Average</i> measurement but apply to all channels.</p> <p>The CDMA2000 standard specifies an upper limit of ± 50 mRad.</p> <p>Remote Control <code>CONFigure:CDPower:POFFset:CMax:LIMit CONFigure:CDPower:POFFset:AVERage:LIMit</code></p>
Time Offset	<p>Contains the limit settings applicable to the <i>Time Offset</i> measurement. The limits for the measured timing error can be set independently for the <i>Current / Maximum</i> and for the <i>Average</i> measurement but apply to all channels.</p> <p>The CDMA2000 standard specifies an upper limit of ± 10 ns.</p> <p>Remote Control <code>CONFigure:CDPower:POFFset:CMax:LIMit CONFigure:CDPower:POFFset:AVERage:LIMit</code></p>

Receiver Quality Measurements

The menu group *Receiver Quality* measures parameters that characterize the transmission quality of the complete transmission path from the CMU to the device under test (mobile station) and back. Assuming no transmitter errors, this allows assessment of the mobile station's receiver performance at various RF power levels.

The *Receiver Quality* menu is opened from the *Menu Select* menu or from any other measurement menu in *CDMA2000 Signalling* using the hotkey *Menu – Receiver Quality* (see [Figure 4-58](#)). The initial screen returns to the modulation application last accessed.

Note: *The configuration settings made in the Receiver Quality applications (with either the softkeys or the Configuration menus) apply only to the measurements presented here. For example, configuration settings made here do not affect the configuration settings made within the Power or Modulation applications.*

The Receiver Quality measurement has its own environment (see Chapter 3, section Measurement Environments). If the measurement environment is enabled in the configuration menu (see description in section [Overview Configuration – Control](#) on p. 4.56 ff.), it overrides the Connection Control parameters as long as the measurement is switched on (RUN) and a connection is established. All Receiver Quality measurement results are always obtained with the same parameter set.

Refer to [Table 4-5](#) on page 4.42 for a list of measurements and their radio configuration requirements.

Receiver Quality measurements require either a connection with Loopback Service or Test Data Service Option.

The measurements in the menu group *Receiver Quality* require an established call (signalling state *Connected*) in the *Loopback Service* or the *Test Data Service* mode (see [1st Service Class](#) softkey on p. 4.45). Receiver Quality measurements cannot be performed in the *Speech Service* mode.




Figure 4-58 Receiver Quality Measurement menu


Softkey Selections

Each *Receiver Quality* application is controlled by means of the measurement control softkey below the *Connect. Control* softkey and the associated hotkeys. The properties of the measurement control softkey are analogous in all measurements; see section *Analyzer/Generator – Measurement Control* in the *Non Signalling* section. The remaining softkeys select the application and provide application-specific settings.

The *Max Frames* hotkey associated to the measurement control softkey is only provided for the *CDP H-PSK* and *PCDEP H-PSK* measurement applications. See description on p. 4.119

Applic.
Test Setup

The *Application* softkey activates a set of hotkeys to select a receiver quality measurement application. When an application is selected, the corresponding measurement screen is displayed.



FER FCH

The *FER FCH* hotkey selects the FCH frame error measurement as the measurement under control allowing you to control and make adjustments to the FCH frame error measurement.

Remote Control The *FER FCH* application is selected by the keywords `FER:FCH` in the 3rd and 4th level of the *RXQuality* commands, e.g.
`CONFigure:RXQuality:FER:FCH...`

FER SCH/SCCH

The *FER SCH/SCCH* hotkey selects the SCH/SCCH frame error measurement as the measurement under control allowing you to control and make adjustments to the FCH frame error measurement.

Remote Control The *FER SCH/SCCH* application is selected by the keywords `FER:SCHScch` in the 3rd and 4th level of the *RXQuality* commands, e.g.
`CONFigure:RXQuality:FER:SCHScch...`

Fwd. Power Control

The *Fwd. Power Control* hotkey displays the forward power control measurement.

Remote Control The *Fwd. Power Control* application is selected by the keywords `FPControl` in the 3rd and 4th level of the *RXQuality* commands, e.g.
`CONFigure:RXQuality:FPControls...`

Test Setup Applic.

The *Test Setup* softkey displays a set of hotkeys to select one of the test setups to use as the parameters for the receiver quality test.



Remote Control `CONFigure:RXQuality:FER:FSSCommon:TSETup`
`<Test Setup>`

Sensitivity

The *Sensitivity* hotkey contains predefined parameter settings to test the receiver quality as defined in standard TIA/EIA IS-2000 for sensitivity testing.

Dyn. Range

The *Dynamic Range* hotkey contains predefined parameter settings to test the receiver quality as defined in standard TIA/EIA IS-2000 for dynamic range testing.

TCH Demod.

The *Traffic Channel Demodulation* hotkey contains predefined parameter settings to test the receiver quality as defined in standard TIA/EIA IS-2000 for traffic channel demodulation testing.

User 1

The *User 1* hotkey is available to store user defined parameters to test receiver quality.

User 2

The *User 2* hotkey is available to store user defined parameters to test receiver quality.

Analyzer
Level Trg.

The *Analyzer Level/Trigger* softkey toggles between two sets of hotkeys to control the level in the RF signal path and define the trigger settings. These general settings are provided in the *Analyzer* and *Trigger* tabs of the *Connection Control* menu; see section [Analyzer Control \(Connection Control – Analyzer\)](#) on p. 4.165 ff and [Trigger \(Connection Control – Trigger\)](#) on p. 4.163 ff.

BS Signal
Level Imp.

The *BS Signal Level / Imp.* softkey toggles between two sets of hotkeys to adjust the signal impairments and the base station signal levels.

All settings belong to the *Receiver Quality* measurement environment but are common to all *Receiver Quality* test setups. They are also provided in the *Receiver Quality Configuration* menu and described in section [Power Configuration – Control](#) on p. 4.71 ff.

BS Signal
Set. P. Ctrl

The *BS Signal Set. /P. Ctrl* softkey displays a set of hotkeys to adjust the RF channel and frame rate and the power control bits that the CMU sends to the mobile station to control its output power.

Frame Rate and *Power Control Bits* belong to the *Receiver Quality* measurement environment. They are also provided in the *Receiver Quality Configuration* menu and described in section [Power Configuration – Control](#) on p. 4.71 ff.

Menus

The *Menus* softkey displays the hotkey bar for switching to the other measurement menus.

Measurement Results

The Receiver Quality measurements are based on the comparison of the output signal sent by the CMU with the signal received and decoded by the device under test (mobile station).

The mobile station must return the received signal to the CMU in loop back mode.

Because of the higher signal level, the transmission errors produced on the way back (from the mobile station to the CMU) can usually be neglected. However, frames destroyed on the way back are detected in a cyclic redundancy check (CRC) and counted. They are not taken into account in the calculation of transmission errors.

The quality of the mobile station transmitter can be tested separately in the *Modulation* measurement.

Frame Error Rate (FCH and SCH/SCCH)

Frame Error Rate measures the percentage of frame errors over the total number of frames received. Both the fundamental channel (FCH) and supplemental channels (SCH0 and 1/SCCH) can be monitored with the same measurement screen.




Figure 4-59 Frame error rate measurement (Receiver Quality)

- FER** FER displays the percentage of the Frame Error Rate over the total number of received frames.
- Frame Errors** Frame Errors lists the total number of frame errors.
- Frames Received** Frames Received lists the total number of frames received. This number is used for the calculation of the FER.
- Confidence Level** Confidence Level indicates the statistical probability that the true FER is within limits based on the current number of frame errors compared to the number of frames received.
- Frames** Frames is a bar graph indicating the measurement progress.

Forward Power Control

Forward Power Control (FPC) displays the receiver quality measurements of the Fundamental channels and Supplemental channels reported from the mobile station. FPC allows the mobile station to direct the power level for the forward fundamental channel using the reverse power control subchannel. This is achieved by the mobile station comparing the E_b/N_t (dB) value provided by the inner power control loop with the corresponding outer power control loop setpoint to determine the power control bits ('0' or '1') to be sent on the Reverse Power Control Subchannel.

Periodic reporting is enabled to receive the mobile station's achieved E_b/N_t and the frame error rate statistics from the PMRM (Power Measurement Report Message).

The Forward Power Control screen displays four columns for each measurement: Fundamental Channel, Dedicated Control Channel, Supplemental Channel 0, and Supplemental Channel 1. At this time, no values are returned for the Dedicated Control Channel and Supplemental Channel 1.




Figure 4-60 Forward power control measurement (Receiver Quality)

- MS Reported FER** *MS Reported FER* displays the percentage of the Frame Error Rate over the total number of received frames reported by the mobile station.

- MS Reported Frame Errors** *MS Reported Frame Errors* displays the total number of frame errors reported by the mobile station.

- MS Reported Transm. Frames** *MS Reported Transm* displays the total number of frames the mobile station has transmitted. This number is used for the calculation of the FER.

- MS Reported Confidence Level** *MS Reported Confidence Level* displays the statistical probability that the FER is within limits based on the current number of frame errors compared to the number of frames received.

- MS Adjusted Level** *MS Adjusted Level* displays the mobile station’s reported channel power level.

- Fwd. Channel Level** *Fwd. Channel Level* displays the forward channel power level.

- MS Current Setpoint** *MS Current Setpoint* displays the mobile station’s setpoint. The setpoint is confined within the settings of the minimum and maximum setpoint settings.

- BS Calculated Eb/Nt** *BS Calculated Eb/Nt* displays the calculated bit energy.

- Actual Output Power** *Actual Output Power* displays the output power of the CMU.

Receiver Quality Configurations

The popup menu *Receiver Quality Configuration* contains three tabs to set the parameters of the receiver quality measurements.

Pressing the measurement softkey at the top right in the measurement menu twice (once if already selected) activates the popup menu *Receiver Quality Configuration*. It is possible to change between the tabs by pressing the associated hotkeys. Use the roll-key to expand or compress the list of settings displayed.

Receiver Quality Configuration – Control

The *Control* tab contains all user adjustable configuration parameters to control each receiver quality measurement. The *Control* tab has three major divisions:

- The *Common Settings* division adjust signal levels for each FER test setup and allows the user to create and name new test setups.
- *FER FCH* defines how the FER tests are performed.
- *Fwd. Power Control* configures the *Forward Power Control* application.




Figure 4-61 Receiver Quality Configuration Control

All settings may not be available for all *Receiver Quality* measurement applications. The statistical setting *Repetition* has the same meaning in all measurements; it is described in section [Overview Configuration – Control](#) on p. 4.56 ff.

Most other parameters are analogous to the corresponding *Power* settings and described in section [Power Configuration – Control](#) on p. 4.71 ff. The following parameters are not provided in the *Power Configuration* menu or have a different function:

Test Name The *Test Name* allows you to enter a descriptive name for the test based on the parameters you set. The default test names can be renamed to more accurately describe your tests or you can create two new tests using the User1 and User2 selections. The name entered here displays in the hotkey bar of the *Test Setup* softkey.

Default Settings *Default Settings* (located below each *Test Name*) assigns default values to the parameters of the test setup.

```
Remote Control DEFault:RXQuality:FER:FSSCommon:TSETup<nr> ON | OFF
DEFault:RXQuality:FER:FCH:CONTRol:TSETup<nr> ON | OFF
DEFault:RXQuality:FER:SCHScch:CONTRol:TSETup<nr> ON | OFF
```

BS Signal Level

F-SCH0 Level The *F-SCH0 Level* adjusts the signal level of the Supplemental Channel 0 in the forward CDMA channel. This is a common setting used for each of the Code Domain Power applications.

F-SCH1 Level The forward supplemental channel 1 is not supported at this time.

Stop Condition *Stop Condition* selects one of several stop conditions for the measurement:

<i>NONE</i>	Continue the measurement even in the event of errors.
<i>Confidence Limit Exceeded:</i>	Stop the measurement when the confidence level exceeds the set limit. This indicates the probability that the true FER is less than the set FER limit.
<i>Frame Limit Exceeded:</i>	Stop the measurement when the number of frame errors exceed the set limit.
<i>Any Limit Exceeded:</i>	Stop the measurement if either the <i>Confidence Limit</i> or <i>Frame Limit</i> is exceeded.

The stop conditions may affect single-shot and continuous measurement settings.

Remote Control CONFigure:RXQuality:FER:FCH:CONTRol:TSETup<nr>:REPetition
 CONFigure:RXQuality:FER:SCHScch:CONTRol:TSETup<nr>:REPetition
 <Repetition>, <Stop Cond>, <Step Mode>

Max Frames The *Max Frames* sets the number of frames used to calculate the frame error rate.

Remote Control CONFigure:RXQuality:FER:FCH:CONTRol:TSETup<nr>:FRAMES
 CONFigure:RXQuality:FER:SCHScch:CONTRol:TSETup<nr>:FRAMES
 <Frame Count>

The following additional settings apply to application **Forward Power Control**:

FPC Mode *FPC Mode* defines the forward power control operating mode. The different modes control the number of power control bits used to monitor the traffic channels. A total of 800 control bits are available. The mode can be set between 0 and 2 (binary format).

<i>000</i>	All 800 bits are used to monitor the FCH channel
<i>001</i>	400 bits are used to monitor the FCH, 400 bits to monitor the SCH0
<i>010</i>	200 bits are used to monitor the FCH, 600 bits used to monitor the SCH0

Remote Control CONFigure:RXQuality:FPControl:CONTRol:FPCMode
 <Mode>

Report Frames *Report Frames* is the number of frames for the mobile station to use to compile the PMRM (Power Measurement Report Message) data.

Remote Control CONFigure:RXQuality:FPControl:CONTRol:RFRames
 <Frames>

Report Delay Number of frames to delay before restarting the error statistics collection.

Remote Control CONFigure:RXQuality:FPControl:CONTRol:RDELay
 <Delay>

Primary Channel Primary fundamental traffic channel. FCH is the only available selection.

Remote Control CONFigure:RXQuality:FPControl:CONTRol:CPRimary
 <Primary>

Secondary Channel Supplemental traffic channel SCH0 is the only available selection.

Remote Control CONFigure:RXQuality:FPControl:CONTRol:CSECondary
 <Secondary>

FCH Control

Target FER *Target FER* sets a Frame Error Rate target (percentage of error) for the mobile station to achieve. The mobile station continually adjusts its outerloop E_b/N_t setpoint to achieve and maintain the *Target FER* setting. The range of the outerloop setpoint is bound by the minimum and maximum setpoint settings.

Remote Control `CONFigure:RXQuality:FPControl:CONTrol:FCH:TFER`
`<Target FER>`

Setpoints *Setpoints* define the outer loop E_b/N_t setpoints of the forward fundamental channel.

Lower Setpoint Sets the minimum value that the mobile station is allowed to move the E_b/N_t setpoint (FPC_FCH_MIN_SETPT). If the static value is used, the setting can be adjusted between 0 to the current *Upper Setpoint* level. If the dynamic value is used, the minimum level is automatically set to the current mobile station's setpoint.

Note: *Setting the lower and upper setpoint to the same values freezes the setpoint to that value, not allowing the mobile to adjust the level. Setting both the lower and upper levels to Dynamic also freezes the setpoint.*

Remote Control `CONFigure:RXQuality:FPControl:CONTrol:FCH:LSPoint:STTic:LOWer`
`CONFigure:RXQuality:FPControl:CONTrol:FCH:LSPoint:DYNamic:LOWer`

Upper Setpoint Sets the maximum value that the mobile station is allowed to move the E_b/N_t setpoint (FPC_FCH_MAX_SETPT). If the static value is used, the setting can be adjusted between 31.750 to the current *Lower Setpoint* level. If the dynamic value is used, the maximum level is automatically set to the current mobile station's setpoint.

Note: *Setting the lower and upper setpoint to the same values freezes the setpoint to that value, not allowing the mobile to adjust the level. Setting both the lower and upper levels to Dynamic also freezes the setpoint.*

Remote Control `CONFigure:RXQuality:FPControl:CONTrol:FCH:LSPoint:STTic:UPPer`
`CONFigure:RXQuality:FPControl:CONTrol:FCH:LSPoint:DYNamic:UPPer`

Initial Setpoint Sets the the starting point for the mobile's E_b/N_t outer loop algorithm (FPC_FCH_INIT_SETPT).

Remote Control `CONFigure:RXQuality:FPControl:CONTrol:FCH:LSPoint:INITial[?]`

Setpoint Threshold Sets the E_b/N_t setpoint report threshold (FPC_SETPT_THRESH) above which the mobile station will send the outer loop report message. In the *OFF* setting, the R&S CMU omits this field (FPC_THRESH_INCL is zero).

Remote Control `CONFigure:RXQuality:FPControl:CONTrol:FCH:LSPoint:THReshold[?]`

- DCCH Control** The Dedicated Control Channel is not monitored by the CMU in this release.
- SCH0 Control** The Supplemental Channel 0 settings and controls are identical to those described for the *FCH Control* above. The CMU sets the following setpoint parameters:
 FPC_SCH_MIN_SETPT, FPC_SCH_MAX_SETPT,
 FPC_SCH_INIT_SETPT, FPC_SETPT_THRESH, FPC_THRESH_SCH_INCL
- SCH1 Control** The Supplemental Channel 1 settings and controls are identical to those described for the *FCH Control* above. The CMU sets the following setpoint parameters:
 FPC_SCH_MIN_SETPT, FPC_SCH_MAX_SETPT,
 FPC_SCH_INIT_SETPT, FPC_SETPT_THRESH, FPC_THRESH_SCH_INCL

Receiver Quality Configuration – Limits

The *Limits* tab defines tolerance limits for the maximum frame error allowed and the confidence level of the error rate




Figure 4-62 Receiver Quality Configuration – Limits

Max FER The *Max FER* sets the maximum frame error rate allowed before indicating an error.

Remote CONFigure:RXQuality:FER:FCH:LIMit:TSETup<nr>:MFER
 Control <Max FER Limit>

Min Confidence Level The *Min Confidence Level* sets the minimum confidence level of the error rate that must be met without indicating an error.

Remote CONFigure:RXQuality:FER:FCH:LIMit:TSETup<nr>:CLEVel
 Control <Min Confidence Level>

Connection Control Menu

The menu group *Connection Control* controls the signalling procedures (call setup and release, services, signalling parameters) and determines the inputs and outputs with the external attenuation values and the reference frequency.

Since the measurements in signalling mode require an existing connection to a mobile station, the menus for setting up the call (*Connection Control - Connection*) appear immediately after selecting a signalling mode (unless the auto popup is disabled). The connection control menus can be accessed any time by pressing the *Connect Control* softkey at the top right corner in every measurement menu. The hotkey bar (at the bottom the screen) links the measurement menus together. Pressing the *Escape* key or the *Connect Control* softkey closes the connection control menu and the CMU changes to the measurement mode.

The tab *Connection Control - Connection* displayed during registration is described in section [Connection Control \(Registered State\)](#) beginning on page 4.48. The remaining tabs of the *Connection Control* menu are described here.

Connection Control with Connection Established (Connection Control – Connected)

In its left half the *Connection (Connected)* tab displays a list of signalling parameters describing the capabilities of the UE. The right half contains, in addition to the 1st *Service Class* and *Network Standard* softkeys, and the standby and access probe power measurement described in section [Connection Control \(Signal Off State\)](#) on p. 4.44 ff., the following softkeys which lead to other services or signalling states (see [Figure 4-19](#) on p. 4.43):

- Deactivating the CMU's CDMA signal (*Signal Off*)
- *Disconnect MS* while keeping the CDMA signal (*BS Signal*) switched on (→ *Registered*)




Figure 4-63 Connection Control – Connection (Connected)

The function of the *Signal Off* softkey is described in section [Connection Control \(Signal On State\)](#) on p. 4.46 ff., the *Disconnect UE* softkey in section [Connection Control \(Alerting State\)](#) on p. 4.50 ff.

Message box A message displayed in each *Connection* tab provides the current instrument state or indicates how to proceed to get to other signalling states. In this instance, the message `Disconnect the mobile by pressing the "Disconnect MS" key` is displayed.

The parameter overview in the left half of the menu is also indicated in the other *Connection* tabs. In the *Connected* signalling state, a maximum of information is available, the table shows the settings that were used to attempt the connection and all information that could be obtained from the mobile at a given time.

Connection Information List of parameters used to attempt the call and current service configuration.

Remote control
[SENSe:]CINFo...?

Messaging (WMT) Information List of parameters describing the last short message sent to the MS.

Remote control
[SENSe:]MINFo:SMS:LOUTgoing...?

MS Information List of parameters provided by the MS and describing its properties. To speed up registration, it is possible to disable the MS information request; see [Mobile Cap. Report](#) on p. 4.157.

Remote control
[SENSe:]MSSinfo...?

Signalling Setup Current settings of the System ID, important BS Signal settings, RF connectors and external attenuation settings, and AF connectors.

Remote control
CONFigure:NETWork:SYSTem:SID?
CONFigure:BSSignal...?
INPut[:STATe]?
OUTPut[:STATe]?
[SENSe:]CORRection:LOSS...?
ROUte:SPENcoder[:INPut]?
ROUte:SPDEcoder[:OUTPut]?



The *Send SMS* softkey delivers the current short message to the mobile station. The CMU indicates *Sending Message* and then returns to the *Connected* state. See also section [SMS Tests with the CMU](#) on p. 4.51 ff.

In the *Connected* state, an SMS can be sent irrespective of the Primary Service Class, i.e. for all *Loopback Service*, *Speech Service*, *Test Data Service* and *Packet Data Service*; see [1st Service Class](#) softkey on p. 4.45.

Remote control
PROCedure:SIGNalling:ACTion SMESsage

Handoff to Another Network (Connection Control – Handoff)

The *Handoff* tab initiates a handoff of the established call to a different network. Since a call needs to be established, this menu is only available in the *Connected* signalling state. Handoff includes:

- Selection of the target network (*Destination Selection*) and the handoff parameters (*Destination Parameter* and *Destination Defaults*)
- Start of the handoff procedure (*Handoff*)
- Display and modification of the parameters of the original network (*Origin Parameter*)
- Possibly cancel handoff preparations and remain in the original network (*Cancel Prepar.*)




Figure 4-64 Connection Control – Handoff

Message box

A message displayed across the top of the *Handoff* tab provides the current instrument state or indicates how to proceed to get to other signalling states. In this instance, the message Press the "Handoff" key to perform a Handoff from the Origin to the Destination Network is displayed.

Destination Selection

The *Destination Selection* softkey selects the target network for the handoff. A handoff destination with fallback (e.g. *AMPS Fallback*) causes the CMU to return to the function group of the origin network after the call is released.

The *Destination Selection* list is automatically adapted to the connected mobile. From the CDMA network, a handoff to the analog (AMPS) network as well as handoffs to other CDMA bands (interband handoff) are supported.

Once the selection is confirmed (pressing the *Enter* key) the menu changes to the *Handoff Preparation* screen. The entire *Connection Control* menu is mapped onto the target function group making it possible to edit the *Destination* parameters, the *BS Signal*, and the *Network* parameters of the target network.

```
Remote Control STATus:HANDoff:TARGet:LIST?
CONFigure:HANDoff:TARGet
"CDMA2KCellMS" | "CDMA2KPCSMS" | "CDMA2KIMT2KMS" |
"CDMA2K450MS" | "AMPSMS" | "CDMA2KCellMSFallback" |
"CDMA2KPCSMSFallback" | "CDMA2KIMT2KMSFallback" |
"CDMA2K450MSFallback" | "AMPSMSFallback"
```




Figure 4-65 Connection Control – Handoff (destination network preparation)

Handoff

The *Handoff* softkey initiates the handoff to the target network. When a handoff is initiated, all measurements are turned off.

Remote control

PROCedure:SIGNalling:ACTion HANDoff

Destination Parameter

The *Destination Parameter* softkey sets important network parameters of the target network necessary for the handoff.

The entries depend on the target network selected with the *Destination Selection* softkey. It is possible to restore the default settings for all parameters using the *Default Settings* switch.

Remote control

The destination parameters must be set in the destination network function group.

Cancel Prepar.

The *Cancel Prepar.* softkey cancels the *Handoff* procedure and resets the CMU to the *Connected* signalling state.

The destination parameters defined in the *Call Pending* state are maintained. To drop the *Handover* procedure and return to the measurement mode, press the *ESCAPE* key or the *Connection Control* softkey.

Remote control

–

Service Configuration of the CMU (Connection Control – Service Cfg.)

The popup menu *Service Cfg.* configures the service options available for the five Primary Service Classes *Loopback Service*, *Speech Service*, *Test Data Service*, *Packet Data Service* and *Wireless Messaging Teleservice (WMT)*.

The descriptions of the *Service Configuration* tab is divided into several sections, corresponding to the different Primary Service Classes.

Note: Service Negotiation

The Service Option can be changed while a connection is established (signalling state Connected). If an attempt is made to select a Service Option that is not supported by the mobile, then the mobile may suggest another (supported) option. The CMU will accept and activate the suggested option, if possible.

Note: MOC with service option

When attempting a call to the base station/CMU (MOC), the mobile station can request a particular service option and service configuration. The CMU can be set to accept all calls or only calls requesting a particular service option; see Accept MS Originated Call below.

General Settings

The *Service Cfg.* tab provides parameters to select the *Primary Service Class* and select the calls from the mobile that the CMU will accept.




Figure 4-66 Connection Control – Service Configuration (General)

The service selection (*Selected Service*) is equivalent to the *1st Service Class* softkey in the *Connection* tab described on p. 4.45. The *Primary Service Class* currently selected is highlighted along with the selected Service Option.

Accept MS Originated Call	Selects the types of Mobile Station Originated Calls (MOC) that the CMU will accept and specifies how it will respond to an accepted or rejected MOC.
<i>Accept All Calls</i>	Accept all MOCs, irrespective of the configured service option at the CMU.
<i>Accept only Selected Primary Service</i>	Accept only MOCs requesting the service option currently selected at the CMU.
<i>Force to Selected Primary Service</i>	CMU tries to negotiate MOC to the service option which is selected at the CMU. If service negotiation is not successful, the MOC fails.
<i>Accept No Calls – Intercept...</i>	Do not accept any MOCs but communicate an intercept condition when the mobile attempts a call. The intercept condition can be communicated via an AWIM (<i>Alert With Information Message</i>), FWIM (<i>Flash With Information Message</i>), or an <i>Order</i> message; see background information in the shaded box below.
<i>Accept No Calls – Reorder</i>	Do not accept any MOCs but communicate a reorder condition when the mobile attempts a call. The reorder condition can be communicated via an AWIM, FWIM, or an <i>Order</i> message.
<i>Accept No Calls – Busy</i>	Do not accept any MOCs but communicate a busy condition when the mobile attempts a call. The busy condition can be communicated via an AWIM or an FWIM, but not with an <i>Order</i> message.
<i>Ignore MS</i>	Do not accept any MOCs; discard the mobile's Origination Message (ORM). This provides a simple way to simulate extreme loading or fading conditions which prohibit the BS from delivering a response to a mobile ORM. The setting causes the mobile to time out.
	Call setup from the CMU (MTC, Call to Mobile) is possible while one of the <i>Do not accept any MOCs...</i> options is selected.

Remote control

```
CONFigure:SCONfig:AMOC ALL | SCL1 | FSC1 | ICAW | ICFW |
ICOR | ROAW | ROFW | ROOR | BUAW | BUFW | IGNR
```

Properties and use of Accept No Call... features

The *Accept No Calls – Intercept / Reorder / Busy...* settings can be used to perform MOC tests according to the signalling conformance test specification C.S0031-0. The different call conditions have the following meaning and consequences:

- An intercept condition informs the user of a procedural error made in placing the call. The mobile station plays an intercept tone, consisting of alternating 440 Hz and 620 Hz tones, each for 250 ms.
- A reorder condition informs the user that all facilities are in use (network congestion) and the call should be paced again. The mobile station plays a reorder tone, consisting of a 480 Hz tone added to a 620 Hz tone, repeated in a 250 ms on, 250 ms off cycle. A busy condition communicated via an *Order* message causes the mobile to enter the Mobile Station Idle state.
- A busy condition informs the user that the called party is busy. The mobile station plays a busy tone, consisting of a 480 Hz tone added to a 620 Hz tone, repeated in a 500 ms on, 500 ms off cycle.

When the receives a MOC, the current call condition (*Intercept*, *Reorder*, *Busy*, or *Ignore MS*, according to the *Accept MS Originated Call* settings) is displayed in the title bar of the *Connection Control* menu.

Note: Order messages can only be sent over the Forward Common Signalling Channel (F-CSCH). This means that they must be sent prior to the establishment of the MS/BS connection. In contrast, AWIMs and FWIMs can only be sent over the Forward Dedicated Signalling Channel (F-DSCH). This means that they must be sent after the MS/BS connection has been established.

The CMU sends order messages while it is in the Registered signalling state. AWIMs and FWIMs are sent in the Connected signalling state.

MOC Tests

To test the mobile’s response to a rejected MOC proceed as follows:

1. Connect the mobile to the CMU.
2. Press *Menu Select*, activate *Signalling* test mode and wait until the CMU has reached the *Registered* state.
3. Open the *Service Cfg.* tab of the *Connection Control* menu, go to the *Accept MS Originated Call* parameter and select the *Accept No Calls...* option you want to test.
4. Open the *Connection* tab of the *Connection Control* menu and initiate a MOC, observing the title bar and signalling state message of the *Connection Control* menu and listening to the tone generated by your mobile phone.

The CMU remains in the *Registered* state if you selected an order message for communicating the call condition, or if the CMU shall *Ignore (the) MS*. It reaches the *Connected* state if the call condition is communicated via a AWIM or FWIM.

The phone’s display may also give an indication of the call condition. Besides you may be able to monitor the phone’s response via a “butt-plug” interface.

Loopback Service

Three different service options can be selected and configured for *Loopback Service*.




Figure 4-67 Connection Control – Service Configuration (Loopback Service)

Default Settings The *Default Settings* switch assigns default values to all settings in the *Service Cfg.* tab (the default values are quoted in the command description in chapter 6 of this manual).

Remote control
 DEFault:SCONfig ON | OFF

Selected Service Option This displays and changes the service option selected for the loopback service. The CMU supports Service Options 2, 9, and 55. All service options meet the requirements described in standard TIA/EIA-126-D.

Remote control
 CONFigure:SCONfig:SClass<nr>:LOOP:SOPTion
 PROCEDURE:SCONfig:SClass<nr>:LOOP:SOPTion
 S02D | S09D | S55D

Service Option 2 / Service Option 9 *Service Option 2* and *Service Option 9* apply to systems with Protocol Revision (P_REV) equal to 5 or lower. They provide a loopback of primary traffic information bits through the mobile station using the Forward Fundamental Code Channel with Multiplex Option 1 and 2, respectively. The FCH can be configured as follows:

FCH Sets the Radio Configuration to use for the Forward and Reverse Fundamental Channel (*F-FCH-RC* and *R-FCH-RC*). The Multiplex Options (*F-FCH-MO* and *R-FCH-MO*) are not selectable; they are set to 1 by the Service Option 2 selection and to 2 by the Service Option 9 selection. Refer to [Connected Service Option Configuration](#) on page 4.146 about changing Radio Configurations in the Connected signalling state.

Note: *TX measurements depend on the Reverse Radio Configuration (R-RC) of the mobile station. In general O-QPSK measurements require a R-RC 1 or 2, whereas H-PSK measurements require a R-RC 3 or 4. For an overview see Table 4-5 on p. 4.42 ff.*

Frame Rate *Frame Rate* sets the frame rate of the F-FCH to Full, Half, Quarter, or Eighth.

Pattern Generation Sets the type of pattern the base station generates and sends to the mobile station. RANDOM sends a random pattern to the mobile station and is the preferred method to obtain the best measurement performance. FIXED sends the bit pattern defined in the *Pattern* field.

The base station generates one fundamental data block to the mobile station. After a delay to allow for processing, the mobile station sends one reverse fundamental data block back to the base station. The base station can set the bits within a data block to a random pattern or any desired value (fixed).

Pattern Defines the bit pattern that the pattern generator uses to send to the mobile station for measurements. This pattern is used if *Pattern Generation* is set to *FIXED*.

Service Option 55 *Service Option 55* applies to systems with Protocol Revision (P_REV) equal to 6 or higher. The option provides a loopback of primary traffic information bits through the mobile station; the Multiplex Option can be either 1 or 2. The FCH can be configured as follows:

FCH Sets the Radio Configuration to use for the Forward and Reverse Fundamental Channel (*F-FCH-RC* and *R-FCH-RC*). The Multiplex Options (*F-FCH-MO* and *R-FCH-MO*) are either 1 or 2 but equal for the forward and reverse channel. The range of possible radio configurations depends on the multiplex option; see [Table 4-8 below](#). Refer to [Connected Service Option Configuration](#) on page 4.146 about changing Radio Configurations in the Connected signalling state.

The *Frame Rate* and *Pattern* settings are the same as described under Service Option 2.

Note: *TX measurements depend on the Reverse Radio Configuration (R-RC) of the mobile station. In general O-QPSK measurements require a R-RC 1 or 2, whereas H-PSK measurements require a R-RC 3 or 4. For an overview see Table 4-5 on p. 4.42 ff.*

Table 4-8 Multiplex options and radio configurations for Service Option 55

Multiplex option in use	F-FCH-RC	R-FCH-RC
1	1, 3, 4	1, 3
2	2, 5	2, 4

Remote control

```
CONFigure:SCONfig:SClass<nr>:LOOP:S<opt_no>D:FCH:RC
PROCEDURE:SCONfig:SClass<nr>:LOOP:S<opt_no>D:FCH:RC
<F_RC>, <R_RC>
CONFigure:SCONfig:SClass<nr>:LOOP:S<opt_no>D:FCH:FRAT
PROCEDURE:SCONfig:SClass<nr>:LOOP:S<opt_no>D:FCH:FRAT
EIGHth | QUARter | HALF | FULL | DEFault
```

```
CONFigure:SCONfig:SClass<nr>:LOOP:S<opt_no>:FCH:PGEN
PROCEDURE:SCONfig:SClass<nr>:LOOP:S<opt_no>:FCH:PGEN
RANDOM | FIXed | DEFault
CONFigure:SCONfig:SClass<nr>:LOOP:S<opt_no>D:FCH:PATtern
PROCEDURE:SCONfig:SClass<nr>:LOOP:S<opt_no>D:FCH:PATtern
<Pattern>
```

where <opt_no> denotes the 2-digit number of the service option (02, 09 or 66).

In addition:

```
CONFigure:SCONfig:SClass<1>:LOOP:S55D:FCH:FORward:MO?
CONFigure:SCONfig:SClass<1>:LOOP:S55D:FCH:REVerse:MO?
```


Speech Service

Four different service options can be selected and configured for *Speech Service*.




Figure 4-68 Connection Control – Service Configuration (Speech Service)

Selected Service Option This displays and changes the service option selected for the speech service. The CMU supports Service Options 1, 3, 17, and 0x8000.

Remote control

```
CONFigure:SCONfig:SClass<nr>:SPeEch:SOPTion
PROCedure:SCONfig:SClass<nr>:SPeEch:SOPTion
S01D | S03D | S17D | SX8T
```

Service Option 1 *Service Option 1* provides a variable rate, two-way speech service to the mobile station using the Forward Fundamental Code Channel with Multiplex Option 1. Service Option 1 meets the requirements described in standard TIA/EIA-96-C.

FCH Config
FCH

FCH sets the Radio Configuration to use for the Forward and Reverse Fundamental Channel (*F-FCH-RC* and *R-FCH-RC*).

The Multiplex Options (*F-FCH-MO* and *R-FCH-MO*) are not selectable; they are set to 1 by the Service Option 1 selection.

Refer to [Connected Service Option Configuration](#) on page 4.146 about changing Radio Configurations in the Connected signalling state.

Note:

TX measurements depend on the Reverse Radio Configuration (R-RC) of the mobile station. In general O-QPSK measurements require a R-RC 1 or 2, whereas H-PSK measurements require a R-RC 3 or 4. For an overview see Table 4-5 on p. 4.42 ff.

```
Remote CONFigure:SCONfig:SClass<nr>:SPeEch:S01D:FCH:RC
Control PROCedure:SCONfig:SClass<nr>:SPeEch:S01D:FCH:RC
<F_RC>, <R_RC>
```

Voice Coder *Voice Coder* configures how the CMU returns the data transmitted over the traffic channel to the mobile for service option 1.

Echo Loopback with delay. The CMU sends back all data received on the TCH after the specified *Echo Delay* (see below) without invoking the speech codec.

8k The CMU sends and receives speech data via the RF signal that are routed to the 8 kbps speech coder (option CMU-B83). Analog signals are provided at the *SPEECH* connector at the front panel of the instrument. The analog input signal at *SPEECH* is amplified by +22.5 dB. The signal flow is shown in [Figure 4-79](#) on p. 4.173.

8k (Low) Same as *8k*, however, the analog input signal is not amplified.

Decoder Cal. The speech codec (option CMU-B83) provides a 1 kHz sinewave signal at its analog output. This signal is used for external calibration of the analog output paths.

Encoder Cal. The speech codec (option CMU-B83) loops the input signal after digital/analog conversion directly to the analog output. This signal is used for external calibration of the analog input paths.

Remote Control CONFIGure:SCONfig:SClass<nr>:SPEech:S01D:VCOder
ECHO | V8 | V8Low | ECAL | DCAL | DEF

Echo Delay *Echo Delay* defines the time that the CMU waits before it loops back the received data if the *Voice Coder* is set to *Echo* mode. The setting has no effect for the other *Voice Coder* settings.

Remote Control CONFIGure:SCONfig:SClass<nr>:SPEech:S01D:EDELay
<Delay>

Service Option 3 *Service Option 3* provides an enhanced variable rate, two-way speech service to the mobile station using the Forward Fundamental Code Channel with Multiplex Option 1. Service Option 3 meets the requirements described in standard TIA/EIA/IS-127.

FCH Config
FCH *FCH* sets the Radio Configuration to use for the Forward and Reverse Fundamental Channel (*F-FCH-RC* and *R-FCH-RC*).

The Multiplex Options (*F-FCH-MO* and *R-FCH-MO*) are not selectable; they are set to 1 by the Service Option 3 selection.

Refer to [Connected Service Option Configuration](#) on page 4.146 about changing Radio Configurations in the Connected signalling state.

Note: *TX measurements depend on the Reverse Radio Configuration (R-RC) of the mobile station. In general O-QPSK measurements require a R-RC 1 or 2, whereas H-PSK measurements require a R-RC 3 or 4. For an overview see [Table 4-5](#) on p. 4.42 ff.*

Remote Control CONFIGure:SCONfig:SClass<nr>:SPEech:S03D:FCH:RC
PROCedure:SCONfig:SClass<nr>:SPEech:S03D:FCH:RC
<F_RC>, <R_RC>

Voice Coder *Voice Coder* configures how the CMU returns the data transmitted over the traffic channel to the mobile for service option 3. A *8k Enhanced* speech coder is available for service option 3. Besides all settings are analogous to service option 1; see above.

Remote Control CONFigure:SCONfig:SClass<nr>:SPEech:S03D:VCODer
ECHO | V8E | V8ELow | CCAL | ECAL | DCAL | DEF

Echo Delay *Echo Delay* defines the time that the CMU waits before it loops back the received data if the *Voice Coder* is set to *Echo* mode. The setting has no effect for the other *Voice Coder* settings.

Remote Control CONFigure:SCONfig:SClass<nr>:SPEech:S03D:EDELay
<Delay>

Service Option 17 *Service Option 17* provides an enhanced variable rate, two-way speech service to the mobile station using the Forward Fundamental Code Channel with Multiplex Option 1. Service Option 17 meets the requirements described in standard TIA/EIA/IS-733.

FCH Config
FCH

FCH sets the Radio Configuration to use for the Forward and Reverse Fundamental Channel (*F-FCH-RC* and *R-FCH-RC*).

The Multiplex Options (*F-FCH-MO* and *R-FCH-MO*) are not selectable; they are set to 2 by the Service Option 17 selection.

Refer to [Connected Service Option Configuration](#) on page 4.146 about changing Radio Configurations in the Connected signalling state.

Remote Control CONFigure:SCONfig:SClass<nr>:SPEech:S17D:FCH:RC
PROCEDURE:SCONfig:SClass<nr>:SPEech:S17D:FCH:RC
<F_RC>, <R_RC>

Voice Coder *Voice Coder* configures how the CMU returns the data transmitted over the traffic channel to the mobile for service option 3. A *13k* speech coder is available for service option 17. Besides all settings are analogous to service option 1; see above.

Remote Control CONFigure:SCONfig:SClass<nr>:SPEech:S17D:VCODer
ECHO | V13 | V13Low | CCAL | ECAL | DCAL | DEF

Echo Delay *Echo Delay* defines the time that the CMU waits before it loops back the received data if the *Voice Coder* is set to *Echo* mode. The setting has no effect for the other *Voice Coder* settings.

Remote Control CONFigure:SCONfig:SClass<nr>:SPEech:S17D:EDELay
<Delay>

Service Option 0x8000 *Service Option 0x8000* provides an enhanced variable rate, two-way speech service to the mobile station using the Forward Fundamental Code Channel with Multiplex Option 1. Service Option 0x8000 meets the requirements described in standard CDG RF 27.

FCH Config
FCH

FCH sets the Radio Configuration to use for the Forward and Reverse Fundamental Channel (F-FCH-RC and R-FCH-RC).

The Multiplex Options (F-FCH-MO and R-FCH-MO) are not selectable; they are set to 2 by the Service Option 0x8000 selection.

Refer to [Connected Service Option Configuration](#) on page 4.146 about changing Radio Configurations in the Connected signalling state.

Note: TX measurements depend on the Reverse Radio Configuration (R-RC) of the mobile station. In general O-QPSK measurements require a R-RC 1 or 2, whereas H-PSK measurements require a R-RC 3 or 4. For an overview see [Table 4-5](#) on p. 4.42 ff.

Remote Control CONFIGure:SCONfig:SClass<nr>:SPEech: SX8T:FCH:RC
PROCedure:SCONfig:SClass<nr>:SPEech: SX8T:FCH:RC
<F_RC>, <R_RC>

Voice Coder Voice Coder is not available for service option 0x8000. The CMU always operates in Loop back mode (Echo) with the specified Echo Delay (see below).

Echo Delay Echo Delay defines the time that the CMU waits before it loops back the received data.

Remote Control CONFIGure:SCONfig:SClass<nr>:SPEech: SX8T:EDELay
<Delay>

Test Data Service

Service option 32 can be configured for Test Data Service.




Figure 4-69 Connection Control – Service Configuration (Test Data Service)

Selected Service Option This displays and changes the service option selected for the Test Data Service. The CMU supports Service Option 32.

Remote control

CONFigure:SCONfig:SClass<nr>:SPEech:SOPTion
 PROCedure:SCONfig:SClass<nr>:SPEech:SOPTion
 S01D | S03D | S17D | SX8T

Service Option 32 *Service Option 32* allows verification of the physical layer performance frame error rate (FER) and PDU error rate (PER) of CDMA2000 physical channels. Service Option 32 meets the requirements described in standard TIA/EIA/IS-858 TDSO.

FCH & SCH Common Config

FCH & SCH *FCH & SCH* sets the Radio Configuration to use for the Forward and Reverse Fundamental Channel and Supplemental Channel (*F-FCH-RC* and *R-FCH-RC*).

The settings made here automatically set the forward and reverse radio configurations and multiplex options for both the Fundamental channel (FCH) and Supplemental channel (SCH).

Refer to the section [Supplemental Channel Configuration and Dependencies for TDSO](#) on page 4.139 for more information about Supplemental Channel configurations.

Refer to [Connected Service Option Configuration](#) on page 4.146 about changing Radio Configurations in the Connected signalling state.

Note: *TX measurements depend on the Reverse Radio Configuration (R-RC) of the mobile station. In general O-QPSK measurements require a R-RC 1 or 2, whereas H-PSK measurements require a R-RC 3 or 4. For an overview see [Table 4-5](#) on p. 4.42 ff.*

Remote Control CONFigure:SCONfig:SClass<nr>:TDAT:S32D:FSCCommon:RC
 PROCedure:SCONfig:SClass<nr>:TDAT:S32D:FSCCommon:RC
 <F_RC>, <R_RC>

Fundamental Channel: FCH Config

FCH *FCH* displays the Radio Configuration and Multiplex Option for the Forward and Reverse Fundamental Channel (*F-FCH-RC* and *R-FCH-RC*, *F-FCH-MO* and *R-FCH-MO*).

These are defined by the FCH & SCH Common Config. settings.

Remote Control CONFigure:SCONfig:SClass<nr>:TDAT:S32D:FCH:RC
 PROCedure:SCONfig:SClass<nr>:TDAT:S32D:FCH:RC
 <F_RC>, <R_RC>

FCH Data
Config

Pattern Generation *Pattern Generation* sets the type of pattern the base station generates and sends to the mobile station. *RANDOM* sends a random pattern to the mobile station and is the preferred method to obtain the best measurement performance. *FIXED* sends the bit pattern defined in the *Pattern* field.

The base station generates one fundamental data block to the mobile station. After a delay to allow for processing, the mobile station sends one reverse fundamental data block back to the base station. The base station can set the bits within a data block to a random pattern or any desired value (fixed).

Remote Control CONFIGure:SCONfig:SClass<nr>:TDAT:S32D:FCH:FORward:PGEN
PROCedure:SCONfig:SClass<nr>:TDAT:S32D:FCH:FORward:PGEN
CONFIGure:SCONfig:SClass<nr>:TDAT:S32D:FCH:REVerse:PGEN
PROCedure:SCONfig:SClass<nr>:TDAT:S32D:FCH:REVerse:PGEN
RANDom | FIXEd

Pattern *Pattern* defines the bit pattern that the pattern generator uses to send to the mobile station for measurements. This pattern is used if *Pattern Generation* is set to *FIXED*.

Remote Control CONFIGure:SCONfig:SClass<nr>:TDAT:S32D:FCH:FORward:PATtern
PROCedure:SCONfig:SClass<nr>:TDAT:S32D:FCH:FORward:PATtern
CONFIGure:SCONfig:SClass<nr>:TDAT:S32D:FCH:REVerse:PATtern
PROCedure:SCONfig:SClass<nr>:TDAT:S32D:FCH:REVerse:PATtern
<Pattern>

Circular Buffer Frames *Circular Buffer Frames* sets the number of frames to use in the circular buffer of the fundamental channel when the random pattern is selected.

Remote Control CONFIGure:SCONfig:SClass<nr>:TDAT:S32D:FCH:FORward:CBFRames
PROCedure:SCONfig:SClass<nr>:TDAT:S32D:FCH:FORward:CBFRames
CONFIGure:SCONfig:SClass<nr>:TDAT:S32D:FCH:REVerse:CBFRames
PROCedure:SCONfig:SClass<nr>:TDAT:S32D:FCH:REVerse:CBFRames
<Circular Buffer Frames>

Tx On Period *Tx On Period* sets the transmission on period in frames of the forward and reverse fundamental channel when the frame activity is deterministic.

Remote Control CONFIGure:SCONfig:SClass<nr>:TDAT:S32D:FCH:FORward:TXON
PROCedure:SCONfig:SClass<nr>:TDAT:S32D:FCH:FORward:TXON
CONFIGure:SCONfig:SClass<nr>:TDAT:S32D:FCH:REVerse:TXON
PROCedure:SCONfig:SClass<nr>:TDAT:S32D:FCH:REVerse:TXON
<Transmit On Period>

Tx Off Period *Tx Off Period* sets the transmission off period in frames of the forward and reverse fundamental channel when the frame activity is deterministic.

Remote Control CONFIGure:SCONfig:SClass<nr>:TDAT:S32D:FCH:FORward:TXOFF
PROCedure:SCONfig:SClass<nr>:TDAT:S32D:FCH:FORward:TXOFF
CONFIGure:SCONfig:SClass<nr>:TDAT:S32D:FCH:REVerse:TXOFF
PROCedure:SCONfig:SClass<nr>:TDAT:S32D:FCH:REVerse:TXOFF
<Transmit Off Period>

Supplemental Channels: SCH0 and SCH1

Configuration of the two supplemental channels SCH0 and SCH1 is analogous. In the remote control commands, the keywords :ZERO and :ONE are used to denote the SCH type.

SCH0/1 Enable *SCH0/1 Enable* disables or enables the forward and reverse supplemental channel 0/1. The forward and reverse channels are either both enabled or both disabled.

Remote Control
 CONFigure:SCONfig:SClass<nr>:TDAT:S32D:SCH:<TYPE>:FORward:ENABle
 PROCedure:SCONfig:SClass<nr>:TDAT:S32D:SCH:<TYPE>:FORward:ENABle
 CONFigure:SCONfig:SClass<nr>:TDAT:S32D:SCH:<TYPE>:REVerse:ENABle?
 PROCedure:SCONfig:SClass<nr>:TDAT:S32D:SCH:<TYPE>:REVerse:ENABle?
 ON | OFF (<TYPE> = ZERO | ONE)

SCH0/1 Config

SCH0/1 *SCH0/1* displays the Radio Configuration and Multiplex Option for the forward and reverse supplemental channels (*F-SCH0/1-RC* and *R-SCH0/1-MO*).
 These are defined by the FCH & SCH Common Config. settings.

SCH0/1 (Spreading = <Factor>) *SCH0/1 (Spreading = <Factor>)* indicates the spreading factor according to the selected data rate and selects the Walsh code that the Supplemental Channel uses in the forward CDMA channel.

Remote Control
 CONFigure:SCONfig:SClass<nr>:TDAT:S32D:SCH:<Type>:FORward:CHANnel
 <Walsh Code> (<TYPE> = ZERO | ONE)

SCH0/1 QOF *SCH0/1 QOF* selects the Quasi-orthogonal Function that the forward Supplemental Channel uses in the forward CDMA channel.

Remote Control
 CONFigure:SCONfig:SClass<nr>:TDAT:S32D:SCH:<Type>:FORward:QOF
 <QOF> (<TYPE> = ZERO | ONE)

SCH0/1 Data Config

Frame Type *Frame Type* selects the frame type for the forward and reverse supplemental channels.
 Together with the *MuxPDUs / Layer*, this parameter determines the data rate of the supplemental channels; see [Table 4-10](#) on p. 4.145.

Remote Control
 CONFigure:SCONfig:SClass<nr>:TDAT:S32D:SCH:<TYPE>:FORward:FRType
 CONFigure:SCONfig:SClass<nr>:TDAT:S32D:SCH:<TYPE>:REVerse:FRType
 1 | 0
 CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:<TYPE>:FORward:MPPL
 CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:<TYPE>:REVerse:MPPL
 1 | 2 | 4 | 8
 CONFigure:SCONfig:SClass<nr>:TDAT:S32D:SCH:<TYPE>:FORward:DRate?
 CONFigure:SCONfig:SClass<nr>:TDAT:S32D:SCH:<TYPE>:REVerse:DRate?
 (<TYPE> = ZERO | ONE)

Coding	<p><i>Coding</i> selects the channel encoder for the forward and reverse supplemental channels.</p> <p><i>Convolutional</i> Use convolutional encoding. This setting is available for all data rates.</p> <p><i>Turbo</i> Use turbo encoding. This setting is available for high data rates ≥ 19.2 kbps, i.e. for all combinations of <i>MuxPDUs / Layer</i> and <i>Frame Types</i> except <i>MuxPDUs / Layer = 1, Frame Types = 1</i> (see Table 4-10 on p. 4.145).</p> <p><i>Convolutional (Turbo if possible)</i> Indicates that convolutional coding is used because turbo coding is not supported for the selected data rate of beyond 9.6 kbps (<i>MuxPDUs / Layer = 1, Frame Types = 1</i>). Turbo coding will be set as soon as the data rate is increased beyond 9.6 kbps.</p>
Remote Control	<pre>CONFigure:SCONfig:SClass<nr>:PDAT:S32D:SCH:<TYPE>:FORward:CODing CONFigure:SCONfig:SClass<nr>:PDAT:S32D:SCH:<TYPE>:REVerse:CODing CONV CTIP TURBO (<TYPE> = ZERO ONE)</pre>
Pattern Generation	<p><i>Pattern Generation</i> sets the type of pattern the base station generates and sends to the mobile station. <i>RANDOM</i> sends a random pattern to the mobile station and is the preferred method to obtain the best measurement performance. <i>FIXED</i> sends the bit pattern defined in the <i>Pattern</i> field.</p> <p>The base station generates one fundamental data block to the mobile station. After a delay to allow for processing, the mobile station sends one reverse fundamental data block back to the base station. The base station can set the bits within a data block to a random pattern or any desired value (fixed).</p>
Remote Control	<pre>CONFigure:SCONfig:SClass<nr>:TDAT:S32D:SCH:<TYPE>:FORward:PGEN PROcEDURE:SCONfig:SClass<nr>:TDAT:S32D:SCH:<TYPE>:FORward:PGEN CONFigure:SCONfig:SClass<nr>:TDAT:S32D:SCH:<TYPE>:REVerse:PGEN PROcEDURE:SCONfig:SClass<nr>:TDAT:S32D:SCH:<TYPE>:REVerse:PGEN <Pattern Generation> (<TYPE> = ZERO ONE)</pre>
Pattern	<p><i>Pattern</i> defines the bit pattern that the pattern generator uses to send to the mobile station for measurements. This pattern is used if <i>Pattern Generation</i> is set to <i>FIXED</i>.</p>
Remote Control	<pre>CONFigure:SCONfig:SClass<nr>:TDAT:S32D:SCH:<TYPE>:FORward:PATtern PROcEDURE:SCONfig:SClass<nr>:TDAT:S32D:SCH:<TYPE>:FORward:PATtern CONFigure:SCONfig:SClass<nr>:TDAT:S32D:SCH:<TYPE>:REVerse:PATtern PROcEDURE:SCONfig:SClass<nr>:TDAT:S32D:SCH:<TYPE>:REVerse:PATtern <Pattern> (<TYPE> = ZERO ONE)</pre>
Circular Buffer Frames	<p><i>Circular Buffer Frames</i> sets the number of frames to use in the circular buffer of the forward and reverse supplemental channel 0/1 when the random pattern is selected.</p>
Remote Control	<pre>CONFigure:SCONfig:SClass<nr>:TDAT:S32D:SCH:<TYPE>:FORward:CBFRames PROcEDURE:SCONfig:SClass<nr>:TDAT:S32D:SCH:<TYPE>:FORward:CBFRames CONFigure:SCONfig:SClass<nr>:TDAT:S32D:SCH:<TYPE>:REVerse:CBFRames PROcEDURE:SCONfig:SClass<nr>:TDAT:S32D:SCH:<TYPE>:REVerse:CBFRames <Circular Buffer Frames> (<TYPE> = ZERO ONE)</pre>
Tx Period	<p><i>Tx On Period</i> sets the transmission on period in frames of the forward and reverse supplemental channel 0/1 when the frame activity is deterministic.</p>

Remote Control	CONFigure:SCONfig:SClass<nr>:TDAT:S32D:SCH:<TYPE>:FORward:TXON PROCedure:SCONfig:SClass<nr>:TDAT:S32D:SCH:<TYPE>:FORward:TXON CONFigure:SCONfig:SClass<nr>:TDAT:S32D:SCH:<TYPE>:REVerse:TXON PROCedure:SCONfig:SClass<nr>:TDAT:S32D:SCH:<TYPE>:REVerse:TXON <Transmit On Period> (<TYPE> = ZERO ONE)
Tx Off Period	<i>Tx Off Period</i> sets the transmission off period in frames of the forward and reverse supplemental channel 0/1 when the frame activity is deterministic.
Remote Control	CONFigure:SCONfig:SClass<nr>:TDAT:S32D:SCH:<TYPE>:FORward:TXOFF PROCedure:SCONfig:SClass<nr>:TDAT:S32D:SCH:<TYPE>:FORward:TXOFF CONFigure:SCONfig:SClass<nr>:TDAT:S32D:SCH:<TYPE>:REVerse:TXOFF PROCedure:SCONfig:SClass<nr>:TDAT:S32D:SCH:<TYPE>:REVerse:TXOFF <Transmit Off Period> (<TYPE> = ZERO ONE)

Packet Data Service

Service Option 33 can be configured for *Packet Data Service* in order to perform end-to-end data tests. In most cases, Service Option 33 must be activated at the mobile before the mobile can initiate a packet data connection. The *Service Cfg.* settings take effect after the CMU responds to a SO33 Origination Message (ORM) from the mobile.

The traffic channels for SO33 are configured in analogy to Service Option 32 (see section [Test Data Service](#) on p. 4.134 ff.), however, the definition of a transferred bit pattern is replaced by the determination of IP addresses for the CMU and for the mobile under test.

The parameters for end-to-end data tests are arranged in the *Protocol* subsection of the *Packet Data Service* settings. These parameters are described in Chapter 8, along with application examples for Service Option 33.

Note: *Before making adjustments to the SCH0/1 channel configuration, set the service class to Packet Data Service. This will enable the CMU to automatically adjust the SCH0/1 Walsh code based on the data rate setting. If the Service Class is not set to PDS prior to making SCH0/1 channel configuration changes, the SCH0/1 Walsh code must be validated by the user.*




Figure 4-70 Connection Control – Service Configuration (Packet Data Service)

Packet Data Service

Packet Data Service – Service Option 33 is highlighted if packet data service is selected as 1st Service Class.

Remote control

```
CONFigure:SCONfig:SClass<nr>:SERvice PDAT
PROCedure:SCONfig:SClass<nr>:SERvice PDAT
CONFigure:SCONfig:SClass<nr>:PDAT:SOPTion?
```

Service Option 33

Service Option 33 is used to request packet data service through a serving node supporting an Internet standard Point-to-Point Protocol (PPP) interface to network layer protocols. Service Option 33 meets the requirements described in standard 3GPP2 C.S0017-0-2.12.

FCH & SCH Config

FCH & SCH Radio Cfg.

Sets the Radio Configuration to use for the forward (*F-RC*) and reverse (*R-RC*) Fundamental Channel and the forward and reverse Supplemental Channels SCH0 and SCH1. The settings made here automatically set the Multiplex Options (*MO*) for both the Fundamental Channel and the Supplemental Channels.

Note: TX measurements depend on the Reverse Radio Configuration (*R-RC*) of the mobile station. In general O-QPSK measurements require a *R-RC* 1 or 2, whereas H-PSK measurements require a *R-RC* 3 or 4. For an overview see [Table 4-5](#) on p. 4.42 ff.

Refer to the section [Supplemental Channel Configuration and Dependencies for TDSO](#) on page 4.139 for more information about Supplemental channel configurations.

Refer to [Connected Service Option Configuration](#) on page 4.146 about changing Radio Configurations in the Connected signalling state.

Remote Control

```
CONFigure:SCONfig:SClass<nr>:TDAT:S33D:FSCCommon:RC
<F_RC>, <R_RC>
```

Fundamental Channel: FCH Config

FCH *FCH* displays the Radio Configuration and Multiplex Option for the Forward and Reverse Fundamental Channel (*F-FCH-RC* and *R-FCH-RC*, *F-FCH-MO* and *R-FCH-MO*).

These are defined by the FCH & SCH Common Config. settings.

Remote Control `CONFigure:SCONfig:SClass<nr>:TDAT:S33D:FCH:RC`
`<F_RC>, <R_RC>`

Supplemental Channels: SCH0 and SCH1

Configuration of the two supplemental channels SCH0 and SCH1 is analogous. In the remote control commands, the keywords `:ZERO` and `:ONE` are used to denote the SCH type.

SCH0/1 Enable *SCH0/1 Enable* disables or enables the forward and reverse supplemental channel 0/1. The forward and reverse channels are either both enabled or both disabled.

Remote Control `CONFigure:SCONfig:SClass<nr>:TDAT:S33D:SCH:<TYPE>:FORward:ENABle`
`CONFigure:SCONfig:SClass<nr>:TDAT:S33D:SCH:<TYPE>:REVerse:ENABle?`
`ON | OFF (<TYPE> = ZERO | ONE)`

SCH0/1 Config

SCH0/1 *SCH0/1* displays the Radio Configuration and Multiplex Option for the forward and reverse supplemental channels (*F-SCH0/1-RC* and *R-SCH0/1-MO*).

These are defined by the FCH & SCH Common Config. settings.

Remote Control `CONFigure:SCONfig:SClass<nr>:TDAT:S33D:SCH:<TYPE>`
`:FORward:CBFRames`
`CONFigure:SCONfig:SClass<nr>:TDAT:S33D:SCH:<TYPE>`
`:REVerse:CBFRames`
`<Circular Buffer Frames> (<TYPE> = ZERO | ONE)`

SCH0/1 (Spreading = <Factor>) *SCH0/1 (Spreading = <Factor>)* indicates the spreading factor according to the selected data rate and selects the Walsh code that the Supplemental Channel uses in the forward CDMA channel.

Remote Control `CONFigure:SCONfig:SClass<nr>:PDAT:S33D:SCH:<Type>:FORward:CHANnel`
`<Walsh Code> (<TYPE> = ZERO | ONE)`

SCH0/1 QOF *SCH0/1 QOF* selects the Quasi-orthogonal Function that the forward Supplemental Channel uses in the forward CDMA channel.

Remote Control `CONFigure:SCONfig:SClass<nr>:PDAT:S33D:SCH:<Type>:FORward:QOF`
`<QOF> (<TYPE> = ZERO | ONE)`

MuxPDUs / Layer *MuxPDUs / Layer* selects the number of multiplex Protocol Data Units per Physical Layer SDU for the forward and reverse supplemental channels.

Together with the *Frame Type*, this parameter determines the data rate of the supplemental channels; see [Table 4-10](#) on p. 4.145.

Remote Control `CONFigure:SCONfig:SClass<nr>:PDAT:S33D:SCH:<TYPE>:FORward:MPPL`
`CONFigure:SCONfig:SClass<nr>:PDAT:S33D:SCH:<TYPE>:REVerse:MPPL`
`1 | 2 | 4 | 8 (<TYPE> = ZERO | ONE)`

Frame Type *Frame Type* selects the frame type for the forward and reverse supplemental channels.

Together with the *MuxPDUs / Layer*, this parameter determines the data rate of the supplemental channels; see [Table 4-10](#) on p. 4.145.

Remote Control
 CONFigure:SCONfig:SClass<nr>:PDAT:S33D:SCH:<TYPE>:FORWARD:FRType
 CONFigure:SCONfig:SClass<nr>:PDAT:S33D:SCH:<TYPE>:REVERSE:FRType
 1 | 0
 CONFigure:SCONfig:SClass<nr>:PDAT:S33D:SCH:<TYPE>:FORWARD:MPPL
 CONFigure:SCONfig:SClass<nr>:PDAT:S33D:SCH:<TYPE>:REVERSE:MPPL
 1 | 2 | 4 | 8
 CONFigure:SCONfig:SClass<nr>:PDAT:S33D:SCH:<TYPE>:FORWARD:DRate?
 CONFigure:SCONfig:SClass<nr>:PDAT:S33D:SCH:<TYPE>:REVERSE:DRate?
 (<TYPE> = ZERO | ONE)

Coding *Coding* selects the channel encoder for the forward and reverse supplemental channels.

Convolutional Use convolutional encoding. This setting is available for all data rates.

Turbo Use turbo encoding. This setting is available for high data rates ≥ 19.2 kbps, i.e. for all combinations of *MuxPDUs / Layer* and *Frame Types* except *MuxPDUs / Layer = 1, Frame Types = 1* (see [Table 4-10](#) on p. 4.145).

Convolutional (Turbo if possible) Indicates that convolutional coding is used because turbo coding is not supported for the selected data rate of beyond 9.6 kbps (*MuxPDUs / Layer = 1, Frame Types = 1*). Turbo coding will be set as soon as the data rate is increased beyond 9.6 kbps.

Remote Control
 CONFigure:SCONfig:SClass<nr>:PDAT:S33D:SCH:<TYPE>:FORWARD:CODing
 CONFigure:SCONfig:SClass<nr>:PDAT:S33D:SCH:<TYPE>:REVERSE:CODing
 CONV | CTIP | TURBo (<TYPE> = ZERO | ONE)

Messaging Teleservice (WMT)

Wireless Messaging Teleservice (WMT) is used to set up an intermediate connection to the mobile station in order to test its Short Message Service (SMS) capability. An SMS can be sent in different ways and received, see section [SMS Tests with the CMU](#) on p. 4.51 ff.

It is possible to select a service option, qualify whether the MS acknowledges the received SMS, add a timestamp to each message and define the SMS text.




Figure 4-71 Connection Control – Service Configuration (Messaging Teleservice)

Selected Service Option This displays and changes the service option selected for delivery of short messages on traffic channels in the *Signal On* or *Registered* state using *Messaging (WMT)* as 1st Service Class. The CMU supports Service Options 6 and 14.

Remote control

CONFigure:SCONfig:SClass\$1\$:WMT:SOPTion S06D | S14D

SMS – Acknowledgement If the *Acknowledgement* box is checked, the CMU requests the MS to return an *SMS Acknowledge Message* after receiving the short message.

The *Messaging (WMT) Information* section of the info table in the *Connection* tab shows whether or not the last outgoing short message was acknowledged; see section [Connection Control with Connection Established](#) on p. 4.122 ff. *Not Acknowledged* can indicate that acknowledgement was either not requested or not supported by the mobile. Bit no. 5 of the STAT:OPER:SUM1|2:CMU<nr> sub-register is set when the CMU receives an *SMS Acknowledge Message*.

Remote control

CONFigure:SCONfig:SClass<nr>:WMT:SMS:ACKNOWLEDge:ENABLE

SMS – Add Time Stamp If the *Add Time Stamp* box is checked, the CMU adds a the string *CMU200* and the current time at the beginning of each short message sent, making different short messages with the same text distinguishable.

The time stamp prevent the MS from rejecting repeated identical messages.

Remote control

CONFigure:SCONfig:SClass<nr>:WMT:SMS:TSTAMP:ENABLE ON | OFF

Max. Outgoing SMS Length Restricts the maximum length of the SMS message to be sent (excluding the optional time stamp) and truncates the *Outgoing SMS* to the selected number of characters. This setting can be used to adjust the SMS to the size of the mobile display.

Remote control
 CONFigure:SCONfig:SCLass<nr>:WMT:SMS:LENGth <No. of Char.>

Outgoing SMS The *Outgoing SMS* section contains the short message text to be sent. The number of characters is limited to the *Max. Outgoing SMS Length* or 152 because 8 characters are reserved for the optional time stamp.

Remote control
 CONFigure:SCONfig:SCLass<nr>:WMT:SMS:TEXT <"Text">

Service Option 6/14 (SMS) *Service Option 6 (SMS)* and *Service Option 14 (SMS)* can both be used to set up SMS connections in the *Signal On* or *Registered* state; see [Send SMS](#) softkey on p. 4.49. Both service options meet the requirements described in standard 3GPP2 C.S0015-A.

FCH sets the radio configuration to use for the Forward and Reverse Fundamental Channel (*F-FCH-RC* and *R-FCH-RC*). The multiplex options are not selectable; Service Option 6 is used with Multiplex Option 1, Service Option 14 is used with Multiplex Option 2.

Remote control
 CONFigure:SCONfig:SCLass<nr>:WMT:S06D:FCH?
 CONFigure:SCONfig:SCLass<nr>:WMT:SMS:S06D:FCH:RC
 CONFigure:SCONfig:SCLass<nr>:WMT:S14D:FCH?
 CONFigure:SCONfig:SCLass<nr>:WMT:SMS:S14D:FCH:RC

SMS @ Current Connection The *SMS @ Current Connection* section displays the fixed FCH configuration for SMS connections set up in the *Connected* state; see section [Connection Control with Connection Established](#) on p. 4.122 ff.

Remote control
 -

Supplemental Channel Configuration and Dependencies for TDSO

The CMU200 allows configuration of the TDSO MuxPDU and Frame Type resulting in a specific Supplemental Channel (SCH) Data Rate. The SCH rate is expressed in multiples of a base rate. For example, odd multiplex options have the base rate 9600 bps; a 2x SCH rate is twice that of 9600 bps (or 19200 bps). [Table 4-9](#) shows the dependency of the Walsh Code which is used for the Supplemental Channel in dependency of the Frame Type and the Frame Size. The Data Rate of the Supplemental Channel depends on the MuxPDUs per Physical Layer SDU and the Frame Type as illustrated in [Table 4-10](#).

Table 4-9 MuxPDUs per Physical Layer per Frame Size

MuxPDUs per physical layer SDU		Frame Size		
Frame Type		RC 3	RC 4	RC 5
Rate 1	Rate 2	20 ms	20 ms	20 ms
1		W_n^{64}	W_n^{128}	W_n^{64}
2	1	W_n^{32}	W_n^{64}	W_n^{32}
4	2	W_n^{16}	W_n^{32}	W_n^{16}
8	4	W_n^8	W_n^{16}	W_n^8
	8	W_n^4	W_n^8	W_n^4

FSCs are assigned W_n^N , where N = 4, 8, 16, 32, 64, and 128 for the maximum assigned QPSK symbol rate. The maximum assigned QPSK symbol rate depends on the radio class, frame size, and multiplex option. The multiplex option depends on the frame type (Rate 1 or Rate 2) and MuxPDUs per physical layer SDU. Any QOF may be used. This table illustrates the Walsh selection versus the combinations of these parameters.

Table 4-10 MuxPDUs per Physical Layer per Data Rate

MuxPDUs per Physical Layer SDU	Data Rate (kbps)			
	F-SCH RC = 3, 4 R-SCH RC = 3		F-SCH RC = 5 R-SCH RC = 4	
	Frame Type		Frame Type	
	Rate 1	Rate 2	Rate 1	Rate 2
1	9.6	19.2	14.4	28.8
2	19.2	38.4	28.8	57.6
4	38.4	76.8	57.6	115.2
8	76.8	153.6	115.2	230.4

Connected Service Option Configuration

With the CMU, it's possible to change the forward and reverse radio configuration while connected to a mobile station (signalling state connected). When attempting to change the radio configuration of the selected service option during a call, the pop-up screen *Connected Service Option Configuration* (shown in [Figure 4-72](#)) is displayed. With this screen, you can enter the new radio configurations and apply the change.

This represents for example an intergeneration handoff between a cdmaOne connection and a CDMA2000 connection.

Note: The change only takes effect if the mobile station supports the new radio configuration.




Figure 4-72 Connection Control – Connected Service Option Configuration

Signals of the CMU (Connection Control – BS Signal)

The popup menu *BS Signal* configures the forward CDMA signal generated by the CMU including all physical channel contributions. Some signal settings must be performed before a call is sent to the mobile station. They are available in the signalling states *Signal Off*, *Signal On*, and *Registered*. For detailed information refer to the description of remote control commands in Chapter 6.




Figure 4-73 Connection Control – BS Signal

Default Settings

The *Default Settings* switch assigns default values to all settings in the *BS Signal* tab (the default values are quoted in the command description in chapter 6 of this manual).

Remote control

DEFault:BSsignal ON | OFF

RF Settings

RF Channel

The *RF Channel* sets the base station channel number (and frequency) of the generated RF signal. Changing the RF Channel resets the RF Frequency setting and vice versa.

The default settings for the channel numbers are dependent on the network selected. See Chapter 1 for a list of the networks and standards supported by the CMU with the CDMA options.

```
Remote Control CONFIGure:BSsignal:CHANnel:FFCH
PROCedure:BSsignal:CHANnel:FFCH
<FFCH Channel>
```

CDMA Power *CDMA Power* allows you to set the total CDMA output power. The CDMA Power level does not include the AWGN power level.

Note: *The levels of the individual channels are set relative to the CDMA power. If the sum of all channel level exceeds 0 dB, a banner message "Level Settings Out of Range !" indicating an over-drive condition will appear on the top of the CMU display.*

Remote Control CONFigure:BSSignal:POWer:CDMA
 PROCedure:BSSignal:POWer:CDMA
 <CDMA Power>

Output Power *Output Power* displays the total output power. The total Output Power level includes the AWGN power level.

Remote Control CONFigure:BSSignal:POWer:OUTput?

Sync Level *Sync Level* allows you to set the signal level of the sync channel in the forward CDMA channel.

Remote Control CONFigure:BSSignal:LEVel:FSYnc
 <FSYnc Level>

PICH Level *PICH Level* allows you to set the Pilot Channel level in the forward CDMA channel.

Remote Control CONFigure:BSSignal:LEVel:FPICH
 <FPICH Level>

OCNS Level *OCNS* turns the Orthogonal Channel Noise Simulator ON or OFF. Setting this to ON ensures a defined Output Power level.

Remote Control CONFigure:BSSignal:LEVel:OCNS:ENABLE
 ON | OFF

Impairments Modifies the BS Signal to simulate realistic operating propagation conditions in the cell.

AWGN Level Turns on or off the Additive White Gaussian Noise generator and sets the level for modulation. This provides noise to more closely simulate actual operating conditions.

Note: *The total output power of the CMU is the sum of the Forward CDMA signal plus the AWGN signal. The CMU automatically limits the AWGN signal level so that the maximum possible total output power of the CMU's RF connector is not exceeded.*

Remote Control CONFigure:IMPairments:LEVel:AWGN
 <AWGN Level>

Carrier Frequency Offset Adjusts the carrier frequency of the CMU's BS Signal. This setting is disabled if the RF Frequency is adjusted away from a standard RF Channel frequency.

Remote Control CONFigure:IMPairments:Foffset[:RF]
<Freq. Offset>

Injected Tx FER Defines a percentage of faulty (i.e. erasure) frames that the CMU injects into all traffic channels of its BS Signal (*F-FCH, F-SCH0, F-SCH1*). To ensure that the data flow is still considered to be valid, up to 50 % of the traffic channel frames may be erasure frames. Channels used for signalling are not affected so that the impairment will not disturb the connection.

The *Injected Tx FER* is a useful tool for a variety of tests:

- Test of the FER reported by the mobile and displayed in the *Receiver Quality* menu. At high BS Signal level, the reported FER should be equal to the *Injected Tx FER*.
- Test of the voice coder performance in a speech service connection with poor forward signal quality.
- Test of modulation accuracy or forward power control with poor forward signal quality.

Remote Control CONFigure:IMPairments:ITFer
<FER>

Power Control

Power Control Bits *Power Ctl. Bits* defines the Power Control Bit (PCB) sequence that the CMU sends to the mobile station to control its total output power (closed loop power control).

Note: *The power control bits must be compatible with the measurement task. All PCB modes except Auto can drive the MS transmitter outside the power range necessary for a particular measurement.*

Auto Active closed loop power control: the CMU sends the power control bits needed to control the MS transmitter output power to the expected value (equal to the RF Max. Level, see section [Analyzer Control \(Connection Control – Analyzer\)](#) on p. 4.165 ff.). The *Expected MS Power* is also indicated in the Overview menu.

Hold The CMU sends alternating up/down power control bits.

All Down The CMU sends only down power control bits. This will cause the mobile station's power level to decrease to a level too low for measurements to be made.

All Up The CMU sends only up power control bits.

Range Test The CMU sends a sequence of 128 up power bits (= 8 frames) followed by a sequence of 128 down power bits.

Pattern Use the bit sequence defined in the *Pattern* section.

Off No bits are sent to the mobile station.

Remote Control CONFigure:BSSignal:PCBits
OFF | AUTomatic | HOLD | ADOW | AUP | RTES | PATTern

Pattern – Step Size *Step Size* selects the step size that the mobile station is to use for closed loop power control. The step size is the nominal change of the MS transmit power per single power control bit. Some step sizes require a particular protocol revision:

Step size	0.25 dB	0.5 dB	1.0 dB
Supported by protocol revisions	1 to 6	4 to 6	6

Note: *Changing the Protocol Revision of the CMU (see p. 4.156) resets the Power Control Step Size to its default value of 1.00 dB.*

Remote Control CONFigure:BSSignal:PCBits:SSIZE
0.25 | 0.50 | 1.00

Pattern – Sequence Mode *Sequence Mode* selects an algorithm to construct the complete user-defined pattern from the single bit pattern <Pattern> defined in Area 1 to Area 4; see [Table 4-11 below](#).

Remote Control CONFigure:BSSignal:PCBits:PATtern:SQMode
PREP | PFBA | PFBH

Table 4-11 Single pattern and Sequence Mode

Sequence Mode	Complete transferred pattern for a single pattern <Pattern>
Pattern Repeated	<Pattern><Pattern><Pattern>...
Pattern followed by Auto	<Pattern>, then active closed loop power control
Pattern followed by Hold	<Pattern>01010101....

Pattern – Area1 / ... / Area 4 *Area 1, ..., Area 4* contains the parameters to define the single bit pattern <Pattern>. <Pattern> is composed of 4 areas with variable length ≥ 1 (*Number of Bits*) but constant *Polarity*.

Example: 000011110 is valid <Pattern>. The following combination of parameters can be used to define this pattern:

Area 1,	Number of Bits	4
	Last Hold Bit	Down
Area 2,	Number of Bits	1
	Polarity	Up
Area 3,	Number of Bits	3
	Polarity	Up
Area 4,	Number of Bits	1
	Polarity	Down

Remote Control CONFigure:BSSignal:PCBits:PATtern:AREA<nr>:NOBits
CONFigure:BSSignal:PCBits:PATtern:AREAL:LHBit
CONFigure:BSSignal:PCBits:PATtern:AREA<nr>:POLarity

FCH

FCH *FCH* selects the Fundamental Channel to use in the forward CDMA channel. The channel selection range is dependent on the current setting of the Forward Radio Configuration.

F-FCH Level The F-FCH Level sets the signal level of the Fundamental Channel in the forward CDMA channel.

F-FCH Level specifies the FULL frame rate traffic channel level. If a frame rate other than FULL is used, the actual test traffic level is lower:

$$\text{Test traffic level} = \text{F-FCH Level} + \text{Corr.}$$

The level definition for FULL frame rate has been chosen because it is always valid, even for speech connections where the frame rate varies according to the voice activity.

The level correction values *Corr.* are listed in the table below.

	RC 1		RC 2		RC 3, 4		RC 5	
	bps	Corr./ dB	bps	Corr./ dB	bps	Corr./ dB	bps	Corr./ dB
Full	9600	0	14400	0	9600	0	14400	0
Half	4800	-3	7200	-3	4800	-3	7200	-3
Quarter	2400	-6	3600	-6	2700	-5.5	3600	-6
Eighth	1200	-9	1800	-9	1500	-8	1800	-9

Remote Control CONFIGure:BSSignal:CHANnel:FFCH
 PROCedure:BSSignal:CHANnel:FFCH
 <FFCH Channel>

FCH Level *F-FCH Level* adjusts the signal level of the Fundamental Channel in the forward CDMA channel.

Remote Control CONFIGure:BSSignal:LEVel:FFCH
 PROCedure:BSSignal:LEVel:FFCH
 <FFCH Level>

FCH Eb/Nt *FCH Eb/Nt* displays the calculated signal to noise ratio of the Fundamental Channel in the forward CDMA channel. The value is displayed while the Additive White Gaussian Noise generator is turned on; otherwise Eb/Nt is undefined as the noise level Nt tends to zero.

Eb/Nt Calculation

The signal to noise ratio is calculated according to standard IS.98, section 1.4.2.1:

$$\frac{FCH_E_b}{N_t} = \frac{\hat{I}_{or} \cdot FCH_E_c \cdot FCH_Chip_Bit}{I_{oc}}$$

Where: *FCH_Ec* Average transmit energy per PN chip

FCH_Chip_Bit Number of PN chips per TCH bit

\hat{I}_{or} Power spectral density of the FW CDMA channel received at the MS antenna connector

I_{or} Total transmit power spectral density of FW CDMA channel at BS antenna connector

I_{oc} Power spectral density of an AWGN source, measured at the MS antenna connector

If the attenuation between the BS (CMU) and the MS under test is negligible ($\hat{I}_{or} = I_{or}$), then Eb/Nt is given by the *FCH Level*, the *AWGN Level* and the data rate in the forward channel (see [Table 4-10](#) on p. 4.145):

$$\frac{FCH_E_b}{N_t} = \left(\langle FCH Level \rangle + 10 \cdot \log \frac{1,228,800}{\langle Data Rate \rangle} + \langle AWGN Level \rangle \right) dB$$

The Eb/Nt calculation for the Supplemental Channels SCH0 and SCH1 is analogous to the FCH.

Remote CALCulate[:SCALar]:BSSignal:EBNT:FFCH?
Control <Ratio>

FCH QOF *FCH QOF* selects the Quasi-orthogonal Function that the Forward Fundamental Channel uses in the forward CDMA channel.

Remote CONFigure:BSSignal:QOF:FFCH
Control PROCedure:BSSignal:QOF:FFCH
<QOF>

FCH Frame Offset *F-FCH Frame Offset* sets the frame offset in the Fundamental Channel. Changing the frame offset immediately changes the traffic channel timing.

Remote CONFigure:BSSignal:FROffset:FFCH
Control PROCedure:BSSignal:FROffset:FFCH
<Frame Offs>

Supplemental Channels: SCH0 and SCH1

Configuration of the two supplemental channels SCH0 and SCH1 is analogous. In the remote control commands, the keywords :ZERO and :ONE are used to denote the SCH type.

SCH0/1 Channel *SCH0/1 Channel* selects the Supplemental Channel to use in the forward CDMA channel. The channel selection range is dependent on the current setting of the Forward Radio Configuration.

Remote CONFigure:BSSignal:CHANnel:FSCH:<TYPE>
Control PROCedure:BSSignal:CHANnel:FSCH:<TYPE>
<FSCH Channel> (<TYPE> = ZERO | ONE)

SCH0/1 Level *SCH0/1 Level* adjusts the signal level of the Supplemental Channel in the forward CDMA channel.

Remote CONFigure:BSSignal:LEVel:FSCH:<TYPE>
Control PROCedure:BSSignal:LEVel:FSCH:<TYPE>
<FSCH0/1 Level> (<TYPE> = ZERO | ONE)

SCH0/1 Eb/Nt *FCH Eb/Nt* displays the calculated signal to noise ratio of the Supplemental Channel in the forward CDMA channel. The value is displayed while the Additive White Gaussian Noise generator is turned on; otherwise Eb/Nt is undefined as the noise level Nt tends to <Type>.

Remote CALCulate[:SCALar]:BSSignal:EBNT:FSCH:<TYPE>?
Control <Ratio> (<TYPE> = ZERO | ONE)

SCH0/1 Frame Offset *SCH0/1 Frame Offset* sets the frame offset in the Supplemental Channel. Changing the frame offset immediately changes the traffic channel timing.

Remote CONFigure:BSSignal:FROffset:FSCH:<TYPE>
Control PROCedure:BSSignal:FROffset:FSCH:<TYPE>
<Frame Offs> (<TYPE> = ZERO | ONE)

PCH

PCH *PCH Channel* selects the Paging Channel to use in the forward CDMA channel. The channel selection range is dependent on the current setting of the Forward Radio Configuration.

Remote Control CONFIGure:BSSignal:CHANnel:FPCH
 PROCedure:BSSignal:CHANnel:FPCH
 <FPCH Channel>

PCH Level *PCH Level* adjusts the signal level of the Paging Channel in the forward CDMA channel relative to the total output power.

Remote Control CONFIGure:BSSignal:LEVel:FPCH
 PROCedure:BSSignal:LEVel:FPCH
 <FPCH Level>

QPCH

QPCH Usage *QPCH Usage* enables or disables the use of the quick paging channel. The quick paging channel performs two functions: paging and configuration change indication. Using the quick paging channel may reduce the amount of time the mobile station uses to monitor the paging channel.

Remote Control CONFIGure:BSSignal:USAGe:FQPCh
 PROCedure:BSSignal:USAGe:FQPCh
 ON | OFF

QPCH *QPCH* selects the Quick Paging Channel to use in the forward CDMA channel. The channel selection range is dependent on the current setting of the Forward Radio Configuration.

Remote Control CONFIGure:BSSignal:CHANnel:FQPCh?
 PROCedure:BSSignal:CHANnel:FQPCh?
 <Quick Paging Channel>

QPCH Level *QPCH Level* adjusts the signal level of the Quick Paging Channel in the forward CDMA channel relative to the total output power.

Remote Control CONFIGure:BSSignal:LEVel:FQPCh
 PROCedure:BSSignal:LEVel:FQPCh
 <Quick Paging Level>

Indicator Bits This command sends the quick paging channel indicator bits to the mobile station to instruct the mobile to monitor the assigned paging channel slot or go to sleep mode. Two bits are sent to increase reliability. The bits are read as follows:

Read bit 1	Bit 1 = 1: Read bit 2
	Bit 1 = 0: Mobile to sleep mode
Read bit 2	Bit 2 = 1: Mobile monitors paging channel
	Bit 2 = 0: Mobile to sleep mode

Remote Control CONFIGure:BSSignal:IBITs:FQPCh
 PROCedure:BSSignal:IBITs:FQPCh
 <I Bits>

DUT Paging *DUT Paging* enables or disables the quick paging channel of the mobile station under test.

Remote Control `CONFigure:BSSignal:DUTPaging:FQPCh`
`PROCedure:BSSignal:DUTPaging:FQPCh`
 ON | OFF

Base Station Properties

PN Offset *PN Offset* sets the offset of the PN sequence. Changing the PN offset changes the timing of the pilot channel, the timing and contents of the sync channel message, and the long code mask of the paging channel.

Remote Control `CONFigure:BSSignal:PROPerTy:PNOffset`
`PROCedure:BSSignal:PROPerTy:PNOffset`
 <PN Offs>

Call Loss Detect Time *Call Loss Detect Time* sets the value of the fade timer (in increments of 0.1 seconds) to detect when a call is lost or dropped.

Remote Control `CONFigure:BSSignal:PROPerTy:CLDTime`
 <Time>

Page Response Timeout Sets the timeout value of the page timer (in increments of 1 seconds) to define the maximum time the CMU will attempt to page the mobile. Setting this timeout to small values may save time in production tests.

Remote Control `CONFigure:BSSignal:PROPerTy:PRTIMEout[?]`
 <Time>

Network Parameters (Connection Control – Network)

The popup menu *Network* displays the current network settings to match that of the mobile station under test. Use the ROLL-key to expand or compress the list.




Figure 4-74 Connection Control – Network Parameters

Default Settings The *Default Settings* switch assigns default values to all settings in the *Network* tab (the default values are quoted in the command description in chapter 6 of this manual).

Remote control

–

System Parameters System parameters are transferred to the mobile station in order to characterize the base station/CMU or specify how the mobile interacts with the base station.

System IDNumber *SID* is the System Identification.

Remote Control `CONFigure:NETWork:SYSTem:SID`
`<System ID Number>`

The following search window sizes are sent to the MS (System Parameters Message) to configure its receiver.

Active/Candidate Window Sets the size of the search window for each pilot in the Active Set or Candidate Set. According to standard TIA-2000.5-D the size is defined as a number in the range between 0 and 15 (SRCH_WIN_A); the corresponding number of PN chips is listed in Table 4-12 below.

The Active Set comprises the pilots associated with the Forward Traffic Channels assigned to the mobile station. The Candidate Set comprises the pilots that are not currently in the Active Set but have been received by the mobile station with sufficient strength to indicate that the associated Forward Traffic Channels could be successfully demodulated.

RemoteControl `CONFigure:NETWork:SYSTem:SWA` `<Size>`

Neighbor Window Sets the size of the search window for each pilot in the Neighbor Set. The size is defined as a number in the range between 0 and 15 (SRCH_WIN_N); the corresponding number of PN chips is listed in Table 4-12 below.

The Neighbor Set comprises the pilots that are not currently in the Active Set or the Candidate Set and are likely candidates for handoff.

RemoteControl `CONFigure:NETWork:SYSTem:SWN` `<Size>`

Remaining Window Sets the size of the search window for each pilot in the Remaining Set. The size is defined as a number in the range between 0 and 15 (SRCH_WIN_R); the corresponding number of PN chips is listed in Table 4-12 below.

The Remaining Set comprises all possible pilots in the current system on the current CDMA Frequency Assignment, excluding the pilots in the Neighbor Set, the Candidate Set, and the Active Set.

RemoteControl `CONFigure:NETWork:SYSTem:SWR` `<Size>`

Table 4-12 Searcher window sizes

Value of SRCH_WIN_A / SRCH_WIN_N / SRCH_WIN_R	No. of PN chips	Value of SRCH_WIN_A / SRCH_WIN_N / SRCH_WIN_R	No. of PN chips
0	4	8	60
1	6	9	80
2	8	10	100
3	10	11	130
4	14	12	160
5	20	13	226
6	28	14	320
7	40	15	452

Protocol Revision *Protocol Revision* sets the preferred version of the protocol for the CMU to use.

Note: *Changing the Protocol Revision of the CMU resets the Power Control Step Size (see p.4.150) to its default value of 1.00 dB.*

Remote Control `CONFigure:NETWork:SYSTem:PREVision <Protocol Revision>`

Min. Protocol Revision *Min. Protocol Revision* sets the minimum protocol revision capability of the mobile station.

RemoteControl `CONFigure:NETWork:SYSTem:MPRevision <Min. Prot. Revision>`

Base Station ID *Base Station ID* sets the base station identification.

Remote Control `CONFigure:NETWork:SYSTem:BSID <Base Station ID Number>`

IMSI_11_12 *IMSI_11_12* defines an ASCII string containing two digits representing the 11th and 12th digits of the IMSI of the base station.

Remote Control `CONFigure:NETWork:SYSTem:IMSI:ETWelve <IMSI 11 12>`

Use Wildcard *Use Wildcard* indicates whether to use special values for MCC and IMSI_11_12 that indicate to the mobile that it needs to use only IMSI_S.

Remote Control `CONFigure:NETWork:SYSTem:UWCard ON | OFF`

Authentication *Authentication* switches the authentication mode on or off. Authentication is a procedure by which information is exchanged between the base station/CMU and the mobile station for the purpose of confirming the identity of the mobile station; see standard TIA/EIA/IS-2000.5-A.

The information sent to the MS is entered in the *Authentication Challenge* field; see below. If authentication fails, this is shown in the *MS Information – Authentication* section of the info table in the *Connection* tab; see section [Connection Control with Connection Established](#) on p. 4.122 ff.

Remote Control `CONFigure:NETWork:SYSTem:AUTHentic ON | OFF`

Authentication Challenge *Authentication Challenge* defines the information sent to the mobile station for authentication, i.e. the 32-bit quantity RAND_CHALLENGE in the Authentication Challenge Message (see standard TIA/EIA/IS-2000.5-A). The authentication challenge is entered as a 8-digit hex value.

Remote Control CONFigure:NETWork:SYSTem:ACHallenge <Challenge>

Network Identity

Network IDNumber *NID* is the Network Identification.

Remote Control CONFigure:NETWork:IDENtity:NID
<Network ID Number>

Mobile Country Code *Mobile Country Code* is the MCC of the network.

Remote Control CONFigure:NETWork:IDENtity:MCC
<Mobile Country Code_Network>

Mobile Settings

Mobile Country Code *Mobile Country Code* is the MCC of the mobile station.

Remote Control CONFigure:MSSignal:MCC
<Mobile Country Code>

Mobile Cap. Report Qualifies whether the mobile capabilities report is requested during registration and displayed. If this parameter is disabled, most of the *MS Information* parameters in the *Connection* tab of the *Connection Control* menu are not available; see section [Connection Control with Connection Established](#) on p. 4.122 ff.

Switching off the report ensures that Frame Error Rate measurements are not disturbed by the messaging necessary to retrieve the mobile capabilities.

Remote Control CONFigure:MSSignal:MCReport
<Mobile Country Code>

Mobile ID(MIN/IMSI) *Mobile ID (MIN/IMSI)* contains a MIN or IMSI (mobile ID) that is used to set up a connection. The mobile ID is not mandatory. However, it provides the tester with the necessary information so that the [Connect MS](#) softkey (see p. 4.47) can be used without waiting for registration. Alternatively the mobile ID can be retained from the last mobile station to register with the tester; see [Use Mobile Registration Data](#) below.

For some protocol revisions, you can choose either a MIN or an IMSI mobile ID. For other protocol revisions, a choice of mobile ID is not available.

Note: *The CMU requires either a MIN or an IMSI mobile identification type.*

Remote Control CONFigure:MSSignal:ID
<Mobile ID (MIN/IMSI)>

Use Mobile Registration Data If *Use Mobile Registration Data* is active (box checked), the mobile ID received during registration is retained and entered in the *Min/IMSI (Registration Data)* field. The received ID can be used to set up the following calls from the *Signal On* state; see above. This is useful if the same mobile is to be called repeatedly. If the option is not active, any call is attempted using the *Mobile ID (MIN/IMSI)*.

Remote Control CONFigure:MSSignal:ID:URData ON | OFF

Min/IMSI (Registration Data) *Min/IMSI (Registration Data)* indicates the mobile ID received during the last registration. The received ID is used to set up the following calls if *Use Mobile Registration Data* is enabled.

Remote Control CONFigure:MSSignal:ID:URData ON
 CONFigure:MSSignal:ID? (to be queried after registration)

Call Indicators Contains the parameters needed to perform the *Land Party to Mobile Station Caller ID* tests described in the signalling conformance test specification C.S0031.

Caller ID *Caller ID* (if specified) is the number of a (virtual) calling party (Calling Party Number, CPN) that the CMU sends to the mobile in order to test whether it is properly displayed. Unless the setting is *Off*, the *Caller ID* is transferred immediately after the *Alerting* message. In addition, it can be sent during an established call using the *Call Waiting Indicator* parameter; see application example below.

Remote Control CONFigure:NETWork:CINDicator:CID '<Caller ID>'

Caller ID Presentation Indicator Specifies how the mobile under test will display the *Caller ID* (CPN) received from the CMU:

- Presentation Allowed* Display the CPN
- Presentation Restricted* Do not display the CPN but indicate that the CPN is restricted
- Number not Available* Do not display the CPN but indicate that the CPN is not available

Remote Control CONFigure:NETWork:CINDicator:PINdicator PAL | PRES | NNA

Call Waiting Indicator Switching *On* the *Call Waiting Indicator* during an established call initiates the transfer of the *Caller ID* to the mobile. This parameter is disabled (grayed and shows *Off*) if the *Caller ID* is switched *Off* or if the mobile is not connected; see application example below. Bit no. 2 of the extended STATus:OPERation register is set when the mobile acknowledges a call waiting call (see Chapter 5).

Remote Control CONFigure:NETWork:CINDicator:CWINdicator ON | OFF

- Caller ID Tests** To perform the *Land Party to Mobile Station Caller ID* tests described in the signalling conformance test specification proceed as follows:
1. Press *Menu Select* and activate *Signalling* test mode.
 2. Open the *Network* tab of the *Connection Control* menu, go to the *Caller ID* parameter and enter a 10-digit CPN.
 3. Connect the mobile to the CMU and wait until the CMU has reached the *Registered* state.
 4. Open the *Connection* tab of the *Connection Control* menu and press *Connect MS*, verifying that the mobile phone displays the CPN after the CMU has reached the *Alerting* state.
 5. After the CMU is *Connected*, return to the *Network* tab and switch on the *Call Waiting Indicator*. Verify that the CPN is displayed again.
 6. Open the *Connection* tab and press *Disconnect MS* to disconnect the mobile.
 7. Repeat the entire procedure using a different *Caller ID Presentation Indicator* and verify that the mobile shows the proper response.

Caller ID Tests can be performed without restrictions if a voice call is set up to the mobile (*1st Service Class: Speech Service*, the default setting used in the procedure above). With *Loopback Service*, the results may be mobile-dependent.

Paging

Paging Channel Rate *Paging Channel Rate* sets the paging rate of the base station's paging channel.

Remote Control CONFIGure:NETWork:PCHannel:RATE
R4K8 | R9K6

Paging Channel Slot Cycle Index *Paging Channel Slot Cycle Index* determines the length of the slot cycle by setting the number of slots in the slot cycle. Each slot cycle equals 1.28 seconds. The number of slots in the slot cycle is determined by the formula:

$$\text{Slot cycle} = 1.28 \times 2^i \text{ (where } i \text{ equals the slot cycle index)}$$

For example: $i = 0$ Slot cycle = 1.28 seconds
 $i = 1$ Slot cycle = 2.56 seconds
 $i = 2$ Slot cycle = 5.12 seconds

The paging channel is monitored during the slot cycle when operating in the slotted mode. A mobile stations slot occurs once per slot cycle

Remote Control CONFIGure:NETWork:PCHannel:SCINdex
<Paging CH Slot Cycle Index>

Max. Slot Cycle Index *Max. Slot Cycle Index* sets the maximum slot cycle index allowed to determine the slot cycle length.

Remote Control CONFIGure:NETWork:PCHannel:MSCindex
<Max Slot Cycle Index>

Registration

Timer Based *Timer Based Registration* sets the interval that the mobile station is to use to register with the tester. You can set a range of values from 12 seconds to approximately 2 minutes.

The allowed values for the interval are calculated according to the formula:

$$Time = 0.08 \text{ seconds} \times \text{floor} (2^{**} (REG_PRD/4)) \text{ with } REG_PRD \text{ 29 ... 85}$$

If set to OFF, the mobile station discontinues periodic registration with the tester.

Remote Control CONFigure:NETWork:REGistration:TBASeD
 <Registration_Time> | OFF

Home *Home* enables the home (non-roaming) registration mode.

Remote Control CONFigure:NETWork:REGistration:HOME
 ON | OFF

Foreign SID *Foreign SID* enables the SID registration mode.

Remote Control CONFigure:NETWork:REGistration:FSID
 ON | OFF

Foreign NID *Foreign NID* enables the network ID registration mode.

Remote Control CONFigure:NETWork:REGistration:FNID
 ON | OFF

Power Up *Power Up* enables the power-up registration mode.

Remote Control CONFigure:NETWork:REGistration:PUP
 ON | OFF

Power Down *Power Down* enables the power-down registration mode.

Remote Control CONFigure:NETWork:REGistration:PDOWN
 ON | OFF

Parameter Reg. *Parameter Reg.* enables the parameter registration mode, causing re-registration after a parameter change.

Remote Control CONFigure:NETWork:REGistration:PARAMeter
 ON | OFF

Access Probes


Access Probes *Access Probes* allows you to set the CMU to ignore or acknowledge the access probes from the mobile station.

Remote Control CONFigure:NETWork:APRobes:MODE
 ON | OFF

Nominal Offset *Nominal Offset* sets the nominal transmit power offset (NOM_PWR) of the access probes. The offset range is dependent on the Network setting.

Remote Control	CONFigure:NETWork:APRobes:NOFFset <Offset>
Initial Offset	<i>Initial Offset</i> sets the value of the initial transmit power offset (INIT_PWR) of the access probes.
Remote Control	CONFigure:NETWork:APRobes:IOFFset <Offset>
Probe Increment	<i>Probe Increment</i> sets the size of the power increment (PWR_STEP) between consecutive access probes.
Remote Control	CONFigure:NETWork:APRobes:PINcrement <Increment>
Probes per sequence	<i>Probes per sequence</i> sets the number of access probes (NUM_STEP) contained in a single access probe sequence.
Remote Control	CONFigure:NETWork:APRobes:PPSquence <Probes>
Sequences per attempt	<i>Sequences per attempt</i> sets the maximum number of access probe sequences (MAX_RSP_SEQ) for an Access channel response.
Remote Control	CONFigure:NETWork:APRobes:SPATtempt <Sequences>

AF/RF Connectors (Connection Control – AF/RF)

The popup menu AF/RF  selects the connectors for RF signals. This includes defining the following.

- The RF input and output of the CMU (*RF Output, RF Input*).
- External attenuation at the connectors (*Ext. Att. Output, Ext. Att. Input*).
- The input source of the CMU speech encoder and the output destination of the speech decoder.

If the Audio Generator and Analyzer (option CMU-B41) is not installed, the *Speech Encoder* and *Speech Decoder* settings are not available. The speech codec is connected to the 9-pole SPEECH (handset) connector on the CMU front panel (refer to the CMU operating manual).




Figure 4-75 Connection Control – AF/RF Connectors

With the exception of the *Speech Encoder* and *Speech Decoder* routing, all functions of this menu are described in CDMA Non-Signalling section titled *AF/RF Connectors (Connection Control – AF/RF)*. See also the paragraph titled *Symmetric input/output attenuation* on p. 4.167.

Speech Encoder

The *Speech Encoder* softkey selects the input source for the CMU speech encoder. The following two input sources are available:

- Generator* Use the audio generator signal which is also fed to the *AF OUT* connector on the CMU front panel.
- Handset* Use the signal of the 9-pole *SPEECH* (handset) connector on the CMU front panel. The active pins are:
 - Pin 5 Analog speech input
 - Pin 6 Analog speech output
 - Pin 9 Analog ground

```
Remote ROUTe:SPENcoder[:INPut]
Control HANDset | GENerator
```

Speech Decoder

The *Speech Decoder* softkey selects the output destination for the CMU speech decoder (option CMU-B83). The following output destinations are available:

- Handset* Route speech decoder output to the 9-pole *SPEECH* (handset) connector on the CMU front panel. The analog pins are:
 - Pin 5 Analog speech input
 - Pin 6 Analog speech output
 - Pin 9 Analog ground
- Analyzer* Route speech decoder output to audio analyzer. The standard analyzer input socket *AF IN* is disabled (*Off*).
- Analyzer 2* Route speech decoder output to secondary audio analyzer. The standard secondary analyzer input socket *AUX 1* is disabled (*Off*).
- Analyzer Both* Route speech decoder output to primary audio analyzer. The standard primary and secondary analyzer input sockets *AF IN* and *AUX 1* are disabled (*Off*).

The primary and secondary audio circuits are described in detail in chapter 4 and 6 of the CMU200/300 operating manual.

Remote ROUTe:SPDecoder[:OUTPut]
Control HANDset | ANALyzer | ANA2 | ABOTH

AF Connector Overview

The *AF Connector Overview* shows the destination of the input signals fed in via AF IN and AUX 1 and the signals sources for the two audio output connectors AF OUT and AUX 2. The routing of input and output signals does not depend on the *Speech Encoder* settings but is a function of the *Speech Decoder* output destination. In the default configuration (*Speech Decoder = Handset*), the connectors AF IN and AF OUT are used as input and output for the primary audio circuit (Analyzer 1, Generator 1). AUX 1 and AUX 2 are used as input and output for the secondary audio circuit (Analyzer 2, Generator 2). If the *Speech Decoder* output is routed to one of the Analyzers, it replaces the external audio input signal. The corresponding input connector is disabled (*Off*).

Reference Frequency (Connection Control – Sync.)

The popup menu *Sync.* defines the reference signals for synchronization. This includes:

- The internal or external Reference Frequency
- The output mode for the network-specific system clock (REF OUT 2)

The functions of this menu are described in the CDMA Non-Signalling section titled *Reference Frequency (Connection Control – Sync.)*.

Trigger (Connection Control – Trigger)

The *Trigger* tab is part of the second group of tabs in the *Connection Control* menu. It is accessible after pressing the 1 / 2 toggle hotkey once. Pressing 1 / 2 again switches back to the first group of tabs described above.

The *Trigger* tab defines the trigger condition for the measurement and the routing of output trigger signals.

Most trigger settings are identical in *Non Signalling* and *Signalling* mode and described in the CDMA Non Signalling section titled *Trigger (Connection Control – Trigger)*. Differences between the two modes are pointed out below.




Figure 4-76 Connection Control – Trigger

Default Settings The *Default Settings* checkbox assigns the default setting to all functions in the *Trigger* tab (the default values are quoted in the command description in chapter 6 of this manual).

Remote control `DEFault:TRIGger[:SEquence]`

Input – Source *Source* selects the source for the trigger event. The settings are analogous to the trigger sources in *Non Signalling* mode; the *Internal (Signalling)* trigger in *Signalling* mode corresponds to the *Internal* trigger in *Non Signalling* mode.

Internal (Sign.) Trigger signal supplied by the signalling unit of the instrument, according to the expected timing of the RF signal re-transmitted by the MS under test. An output frame trigger signal can be routed to pins 2 to 5 of AUX 3; see description of the *Output Routing* parameter in the *Non Signalling* section.

Note: *The Signalling trigger signal and the output frame trigger is only available while the BS Signal is switched on (all signaling states except Signal Off).*

Remote control `TRIGger[:SEquence]:SOURce`

Table 4-13 Trigger conditions for Signalling measurements

Measurement	Trigger Source	Remarks
Power	all	Valid results irrespective of the trigger sources
Spectrum	all	Valid results irrespective of the trigger sources
Modulation O-QPSK	all	Correct synchronization with O-QPSK signal required; this works with any trigger including <i>Free Run</i> . If no O-QPSK signal is applied, the measurement will still display results, but with high modulation errors.

Measurement	Trigger Source	Remarks
<i>Transmit Time Error</i>	External / Internal (Signalling) Other	Valid results if the CMU is synchronized with the DUT. The mobile / signal generator must be synchronized with the CMU via the output trigger signal at AUX 3 (see <i>Output Routing</i> in the <i>Non Signalling</i> section). No transmit time error results available If the transmit time error ca not be calculated, the CMU displays a <i>PN Sync. Failed !!</i> message. The other O-QPSK modulation results are still valid.
Modulation H-PSK / Code Domain Meas. H-PSK	Internal (Signalling) External / Free Run	For Signalling tests with a call established: The measurement requires a synchronization with the state of the long code; the real long code mask is used by the mobile phone. For lab internal tests in Signalling mode but with no call established: Requires a mobile / signal generator with long code mask set to zero. If no HPSK signal is applied, no measurement results will be displayed.

I/Q-IF Interface (Connection Control – I/Q-IF)

The *I/Q-IF* tab is part of the second group of tabs in the *Connection Control* menu. It is accessible after pressing the 1 / 2 toggle hotkey once. Pressing 1 / 2 again switches back to the first group of tabs described above.

The *I/Q-IF* tab configures the signal paths for I/Q and IF signals. With option CMU-B17, *I/Q and IF Interfaces*, I/Q and IF signals can be used in the framework of *RF* measurements and in many network tests. The functions of this menu are described in the CDMA Non-Signalling section titled *I/Q-IF Interface (Connection Control – I/Q-IF)*.

Analyzer Control (Connection Control – Analyzer)

The *I/Q-IF* tab is part of the second group of tabs in the *Connection Control* menu. It is accessible after pressing the 1 / 2 toggle hotkey once. Pressing 1 / 2 again switches back to the first group of tabs described above.

The *Analyzer* tab configures the RF input path by defining the analyzer level.




Figure 4-77 Connection Control – Analyzer Settings

Default All Settings The *Default All Settings* switch assigns default values to all settings in the *Analyzer* tab (the default values are quoted in the command description in chapter 6 of this manual).

Remote control
 DEFault:RFANalyer

Analyzer Level – RF Mode The *Analyzer Level* table section sets the maximum input level that can be measured. Two alternative *RF Modes* for defining this value are provided:

- Manual* Manual input of maximum input level. Open loop power control of the mobile is deactivated and the mobile is commanded to transmit at the fixed output power set in the *RF Max. Level* field.
- Auto* Automatic setting of maximum input level (*autoranging*) according to the expected power of the MS transmitter output signal. The MS estimates its output power according to the open loop condition, so that the sum of the mean input power (corresponding to the *CDMA Power* set in the *BS Signal* tab) and the mean output power (the so-called *Power Offset*) remains constant. According to standard TIA/EIA/IS-2000.2-A, the *Power Offset* depends on the MS band class, the forward and reverse spreading rate, and the Radio Configuration of the reverse channels.

Remote control
 [SENSe:]LEVel:MODE MANual | AUTomatic

Analyzer Level – RF Max. Level *RF Max. Level* defines a fixed value for the mean output power of the MS. The setting takes effect as when the *RF Mode* is changed to *Manual*. *RF Max. Level* also determines the expected power at the RF Input connector.

Remote control
 [SENSe:]LEVel:MAXimum <Level>

External input attenuation The range of *RF Max. Level* values depends on the RF input used. If an external input attenuation is reported to the instrument to compensate for a known path loss (see section *AF/RF Connectors (Connection Control – AF/RF)* in the CDMA Non-Signalling section), all levels measured are referenced to the output of the DUT and therefore shifted with respect to the actual level at the input connectors of the CMU. The level ranges for the input connectors are shifted as well.


Error messages If the *RF Max. Level* is too high or too low, a window with the error message "*<Max_Level> is out of range. <permissible max. value> is limit.*" and three fields will appear:

- Accept* The permissible max. value is accepted as *RF Max. Level*,
- Re-edit* *RF Max. Level* is entered once again,
- Cancel* The last valid input value is maintained.

When switching over to another input, the current value of *RF Max. Level* is automatically adapted, if required:

- Towards lower values to the maximum value of the new input,
- Towards upper values to the minimum value of the new input.

Symmetric input/output attenuation If the MS output power is controlled according to the open loop condition (mean input power + mean output power = constant Power Offset; see *RF Mode – Auto* setting above), an additional attenuation affecting both the forward and reverse path will not change the power measured at the RF input of the CMU:



Analogously, changing the values of *Ext. Att. Output* and *Ext. Att. Input* by the same amount has no influence on the measured RF input power at the CMU. It is nevertheless recommended to set the correct external input and output attenuation factors in order to obtain well-defined levels throughout the entire test setup.

Miscellaneous User Settings (Connection Control – Misc.)

The popup menu *Misc.* assigns TCP/IP addresses to the R&S CMU and provides various general settings to control the MMI behavior and the measurements. The *TCP/IP* settings are relevant for data tests and message monitoring using the *Message Monitor* included in option CMU-B87, *Interface for CDMA2000 Data Tests*. The *TCP/IP* settings and remote control commands are described in Chapter 8.




Figure 4-78 Connection Control – Misc. Settings

User Guidance – Measurements – The *User Guidance* section provides settings to control the automatic switchover between menus of the user interface and between measurement environments.

Default Settings Returns all *User Guidance* settings to their default values.

Auto Toggle R-RC Dependent

Auto Toggle (if checked) automatically selects the correct measurement modulation scheme (O-QPSK or H-PSK) according to the Reverse Radio Configuration.

Use Measurement Environments

Specifies how the individual measurement environments are used (see Chapter 3). *All On* causes the measurement environments to be activated as soon as a connection is established and the measurement is switched on. *All Off* disables all measurement environments so that the *Connection Control* parameters are used permanently. *Some On* is indicated if some but not all of the individual measurement environments have been enabled.

Note: Some measurements only run with their environments enabled; for examples refer to the paragraph *Environment Enable* on p. 4.72.

Remote control No command for *Auto Toggle R-RC Dependent*.
 CONFIGure:ALL:ENVironment:ENABLE[?] <Enable>

User Guidance – Connection Control Behavior – Defines in what instances the *Connection Control* popup menu is automatically opened or closed:

Open autom. if not connected

In the *Open automatically* mode, the *Connection Control* menu is automatically opened each time the CDMA2000 function group is accessed in *Signalling* test mode, each time a measurement menu is opened while the DUT is not connected and each time a connection is lost. Otherwise the menu must be opened manually.

Close autom. if connected

In the *Close automatically* mode, the *Connection Control* menu is automatically closed as soon as the CMU reaches the *Connected/Call Established* state. Otherwise the menu must be closed manually.

Remote control CONFigure:MENU:CCTRL:AOPen ON | OFF
 CONFigure:MENU:CCTRL:AClose ON | OFF

RF Selectivity Selects the bandwidth of the analog receiver filter:

Wide Normal filter, appropriate for all TX measurements
Narrow Narrower filter, improves the performance of in-band TX measurements if the test set is suspected to cause interference from outside the band. The *Narrow* filter suppresses the adjacent channel power that the R&S CMU receives and therefore modifies the *Spectrum* measurement results.

Remote control CONFigure:RFSelectiv WIDE | NARROW

Marker Control

Markers are references available with any application displaying a graph of the measurement. This section gives a detailed explanation of how to control each marker type. Marker information specific to an application is located with the application.

Marker

The *Marker* softkey positions up to three markers and a D-line in the test diagram and reads their values.


Markers Graphical tools for marking points on the measurement curve and for numerical output of measured values.


The markers are turn activated by pressing the hotkey and pressing the *ON/OFF* key, or entering a value. Values can be entered directly with the keypad or with the *Variation* knob.

The coordinates of the three markers are indicated in the format *Ordinate value (level)/abscissa value (time)* in a parameter line above the test diagram. The position of the reference marker is expressed in absolute units (level in dBm or percentage and time in symbols). The delta markers are expressed as absolute or relative values (relative position from the reference marker).


D-Line The D-Line is a horizontal line that can be positioned to mark and read out an arbitrary level in the test diagram.


Ref

The *Ref*  hotkey displays the status (On | Off) of the reference marker. Pressing the hotkey displays a popup menu to switch the reference marker on or off (use the *ON/OFF* key or the *Variation* knob).

The reference marker is represented by the symbol  in the test diagram. The marker position (abscissa) is determined in the input field *Ref. Marker*. The marker can be positioned to arbitrary time values. If its position is outside the diagram area it will be invisible and its coordinates will be “- - - / <abscissa_value>”. The marker is switched off in the default setting (*OFF*). The marker level is defined by the measurement curve at the marker position.


Delta

The *Delta*  hotkey displays the status (On | Off) of delta marker 1. Pressing the hotkey displays a popup menu to switch the delta marker 1 on or off (use the *ON/OFF* key or the *Variation* knob).

Delta marker 1 is represented by the symbol  in the test diagram. The marker position (abscissa) is defined in the input field *Delta Marker 1*. The marker can be positioned to arbitrary time values. If its position is outside the diagram area it will be invisible and its coordinates will be “<abscissa_value> / - - -”. The marker is switched off in the default setting (*Off*). The marker level is defined by the trace at the marker position.

Pressing the hotkey twice displays the *Delta 1 Config* popup display. It defines whether the position of delta marker 1 is measured and indicated in absolute units (of the horizontal scale) or relative to the reference marker.

Delta

The *Delta*  hotkey switches the delta marker 2 on or off (use the *ON/OFF* key).

The functions and control are identical to delta marker 1.

D-Line

The *D-Line* hotkey activates and controls the position of the D-Line in the test diagram.

The D-line is a horizontal, colored auxiliary line in the test diagram used for marking a level value and for measuring level differences.

Press the hotkey once to turn the D-Line on or off (using the *ON/OFF* key). The level of the D-line is determined by entering an absolute or relative value with either the keypad or *Variation* knob.

Press the hotkey twice to open the *D-Line Config* popup to set the absolute or relative D-Line display.

In the Absolute setting, the D-Line is expressed in the vertical scale units and is limited to the value range of the vertical scale. In the Relative setting, the D-Line value is relative to the maximum vertical scale.

The default setting is Off.

Audio Measurements and Setup

The Audio function group provides two measurement functions:

- Analyzer measurements and Generator settings
- Multitone audio measurements

To perform Speech measurements, the *Speech Service* class must be selected and the *Voice Coder* set to 8k / 8k (Low) (Service Option 1) or 8k Enhanced / 8k Enhanced (Low) (Service Option 3) or 13k / 13k (Low) (Service Option 17). The Primary Service Class is configured in the *Connection* tab (see [1st Service Class](#) softkey on p. 4.45) and the *Voice Coder* is configured in the *Service Cfg.* tab (see section [Speech Service](#) on p. 4.131 ff.), both located in the *Connection Control* menu. The routing of the speech encoder and decoder is defined in the *AF/RF Connector* tab; see section [AF/RF Connectors \(Connection Control – AF/RF\)](#) on p. 4.161 ff.

Refer to the CMU200 operating manual for complete details of the use of the audio measurement function group and measurement setup.

The following three figures contain block diagrams illustrating the setup and signal flow when using the *Speech Coder* option CMU-B85.

- [Figure 4-79](#) illustrates signal flow through the Speech Coder.
- [Figure 4-80](#) illustrates the setup to test audio via the forward link.
Setting *Speech Encoder* to Generator
Setting *Speech Decoder* to Handset
- [Figure 4-81](#) illustrates the setup to test audio via the reverse link.
Setting *Speech Encoder* to Handset
Setting *Speech Decoder* to Analyzer




Figure 4-79 Speech Coder Signal Flow




Figure 4-80 Forward Link Audio Test Setup




Figure 4-81 Reverse Link Audio Test Setup

Contents

5 Remote Control – Basics	5.1
Structure and Order of Commands	5.1
Measurement Control	5.3
Measurement Groups	5.3
Measurement Statistics.....	5.4
Specifying Limits	5.6
Measurement Environments.....	5.6
Status Reporting System	5.7
Special Terms and Notation	5.10

5 Remote Control – Basics

This chapter gives a survey of the basic features and concepts of CDMA2000 remote control commands. Remote control can be described in terms analogous to the ones used in Chapter 3 for the classification of menus and settings for the graphical user interface. In the following, we will particularly point out the similarities and differences between manual and remote control.

Structure and Order of Commands

Chapter 6 of this manual gives a description of all CDMA2000 remote control commands, including their parameters, default values and ranges of all numerical parameters.

Function groups and test modes

Commands for the various CDMA-MS function groups are largely identical, however, the ranges of numerical values and some default settings may differ. All differences are explicitly quoted for each function group.

Commands for the two modes *Signalling* and *Non-Signalling* are listed separately although many of them have the same syntax. The commands for the measurement groups *WPOWER* and *NPOWER* and several general-purpose commands are identical in both test modes, so they are reported only once (see section *Common Measurements and Command Groups*).

Addressing

The CMU200 uses extended addressing. The instrument is assigned a primary address while each function group and test mode is identified via a secondary address. This allows the same remote commands to be used in several function groups and modes:

```
ibwrt(h_CDMA_Cell_MS_SIG, "INITiate:POWer")
ibwrt(h_CDMA_PCS_MS_SIG, "INITiate:POWer")
ibwrt(h_CDMA_PCS_MS_NSIG, "INITiate:POWer")
```

provided that the variables `h_CDMA_Cell_MS_SIG`, etc. have been appropriately defined, see program examples in Chapter 7 of the CMU Operating manual.

The remote control commands for first (`SYST:COMM:GPIB:ADDR`) and secondary (`SYST:REM:ADDR:SEC`) addressing are described in the CMU Operating manual. The `SYST:REM:ADDR:SEC` command uses the following names to address the GSM network tests described in this manual:

<code>CDMA2K450MS_NSig</code>	<code>CDMA2K450MS_Sig</code>
<code>CDMA2KCellIMS_NSig</code>	<code>CDMA2KCellIMS_Sig</code>
<code>CDMA2KPCSMS_NSig</code>	<code>CDMA2KPCSMS_Sig</code>
<code>CDMA2KIMT2KMS_NSig</code>	<code>CDMA2KIMT2KMS_Nig</code>

Order of commands The commands are arranged to form groups belonging to the same measurement or to the same type of configurations. These command groups are identified by the second-level keyword (as in `POWER`). Applications belonging to a measurement group (see Chapter 5 of the CMU200 operating manual) are identified by the third-level keyword of each command (as in `MODulation:EVMagnitude`). Chapter 6 is organized as follows:

CDMA2000 Non-Signalling:

- General configurations (second-level keywords `NStandard`, `LEVEL`, `INTERNAL`, `EXTERNAL`, `RFAnalyzer`, `RFGenerator`, `INPUT`, `OUTPUT`, `CORREction:LOSS`, `DM:CLOCK`)
- Measurement groups: `MODulation`

Common command and measurement groups (identical in Non Signalling and Signalling mode:

- General purpose commands (`OPTION`, `RESET`, `STATUS:OPERation`, `IQIF`)
- Measurement groups (`WPOWER`, `NPOWER`)

CDMA2000 Signalling:

- General configurations and signalling (`NStandard`, `LEVEL`, `INTERNAL`, `SIGNalling`, `HANDoff`, `BSSignal`, `NETWORK`, `INPUT`, `OUTPUT`, `CORREction:LOSS`, `DM:CLOCK`).
- Measurement groups: (second/third-level keywords `MSSinfo`, `SAPPower`, `OVERview:POWER`, `OVERview:MODulation`, `OVERview:CQUALity`, `POWER:OLTResponse`, `POWER:MIOutput`, `POWER:MAOutput`, `POWER:GOUTput`, `MODulation:OVERview`, `MODulation:EVMagnitude`, `MODulation:PERRor`, `MODulation:MERRor`, `SPECTrum:ACP`, `CDPower...`, `RXQuality...`).

The structure of Chapter 6 differs from Chapter 4 (*Functions and their Application*) where the measurements are presented first and configurations pertaining to the whole function group and test mode are reported at the end of each section.

The menu of the graphical user interface corresponding to a group of commands is quoted at the beginning of each section. Alphabetical lists of all commands are annexed to Chapter 6.

SCPI Conformity In view of the particular requirements of CDMA measurements not all commands could be taken from the SCPI standard. However, the syntax and structure of all commands is based on SCPI conventions. For a detailed description of the SCPI standard refer to Chapter 5 of the operating manual for the CMU basic unit.

SPCI confirmed and SPCI approved commands are explicitly marked in Chapter 6.

Remote Control All commands may be used for control of the CMU via the GPIB interface or serial (RS-232) interface.

Measurement Control

The commands in the measurement groups WPower, NPower, Power..., MODulation..., SPEctrum..., CDPower..., and RXQuality... have an analogous structure and syntax. The measurements are controlled according to common concepts which are explained in detail in Chapter 5 of the CMU operating manual. The following sections show how the general concepts are applied to CDMA measurements.

Measurement Groups

The measurement groups are referred to as *measurement objects* (keyword <meas_obj>) in remote control. Most measurement objects correspond to a measurement group or application in manual control. For CDMA2000 measurements, the following measurement objects are defined:

Table 5-1 Measurement objects in the Signalling and Non-Signalling Mode

Non Signalling		Signalling	
Meas. Object	Measurement group / Application	Meas. Object	Measurement group / Application
WPower	Wideband Power softkey (wide-band peak power measurement).	WPower	Wideband Power softkey (wide-band peak power measurement).
NPower, Power:XSlot	Narrow-band power NPower, Power vs. Frame included in the Power menu.	NPower	Narrow-band power NPower, included in the Power menu.
MODulation:MQuality[:OQPSk] MODulation:MQuality:HPSk MODulation:MQuality:QPSK	Mod. Qual. O-QPSK Mod. Qual. H-PSK Mod. Qual. QPSK MS power, waveform quality, frequency error, transmit time error, carrier feedthrough, I/Q imbalance and sideband suppression for different modulation schemes. Statistical results and the results of the limit check can be evaluated.	OVERview: OVERview[:OQPSk] OVERview: OVERview:HPSK OVERview:CQQuality OVERview:PPower	Overview QPSK Overview HPSK Channel Quality Pilot Power Report MS power, waveform quality, frequency error, transmit time error, carrier feedthrough, I/Q imbalance and sideband suppression for different modulation schemes. Statistical results and the results of the limit check can be evaluated.
		POver:MIOutput[:OQPSk] POver:MIOutput[:HPSK] POver:MAOutput[:OQPSk] POver:MAOutput[:HPSK] POver:MAOutput: OLResponse	Min. Output O-QPSK Max. Output O-QPSK Min. Output H-PSK Max. Output H-PSK Open Loop Time Resp. Gated Output Minimum and maximum MS transmitter output power and MS output power as a function of time in various MS operating modes.

Non Signalling		Signalling	
Meas. Object	Measurement group / Application	Meas. Object	Measurement group / Application
		MODulation:OVERview[:OQPSk] MODulation:OVERview:HPSK MODulation: EVMagnitude[:OQPSk] MODulation: EVMagnitude:HPSK MODulation:MERRor[:OQPSk] MODulation:MERRor:HPSK MODulation:PERRor[:OQPSk] MODulation:PERRor:HPSK	Overview O-QPSK Overview H-PSK EVM O-QPSK EVM H-PSK Magn. Err. O-QPSK Magn. Err. H-PSK Phase Err. O-QPSK Phase Err. H-PSK Modulation waveform interval as a function of time (phase error, error vector magnitude, magnitude error) of the MS transmitter output signal. The frequency error, average and RMS error, statistical results and the results of the limit check can be evaluated.
		SPECTrum:ACP	ACP Off-carrier power at four symmetrical pairs of offset frequencies and limit check.
		CDPower:CDPW CDPower:PCDep CDPower:CHPW CDPower:POFFset CDPower:TOFFset	CDP H-PSK PCDEP H-PSK Ch. Power H-PSK Phase Offs. H-PSK Time Offs. H-PSK Code domain power, peak code domain error, channel power, phase and time offset of the MS transmitter output signal. The MS power, carrier feedthrough, frequency error and rho factor, statistical results and the results of the limit check can be evaluated.
		RXQuality:FER:FCH RXQuality:FER:SCHScch RXQuality:FER:FPControls	FER FCH FER SCH/SCCH Fwd. Power Control Frame error rate and forward power control reported by the mobile station. Statistical results and the results of the limit check can be evaluated.

The measurement objects in Table 5-1 are complemented by groups of commands used to retrieve results that are automatically provided by the mobile station (e.g. the receiver parameters reported by the mobile phone). These command groups consist of queries only and do not represent real measurement objects. For an overview, see the list of remote control commands at the end of Chapter 6.

Measurement Statistics

Together with the *Statistic Count*, the *Repetition Mode* defines how many evaluation periods are measured if the measurement is not stopped explicitly (measurement control commands STOP . . . ,

ABORT...) or by a limit failure. With remote control, the two repetition modes *Single Shot* and *Continuous* are available (*Counting* is not available in manual control, see chapter 3).

Generally four different traces are determined within one measurement:

- The result in the current period
- The maximum result
- The minimum result
- The average result (evaluated over a set number of waveform intervals)

The four results can be queried independently.

Table 5-2 Repetition mode in remote control

Setting	Description	Command
Statistic Count	Integer number of evaluation periods forming one statistics cycle. An evaluation period is equal to a burst (POWER MODulation) or a frame (RXQuality). In an RXQuality:FER measurement, the STATistics parameter denotes the number of frames to be averaged per iteration step (search cycle).	CONFigure:<meas_obj>:CONTRol:STATistics 1 ... 1000 NONE (<meas_obj> = OVERview POWER... MODulation... SPECTrum... CDPower...) CONFigure:RXQuality:FER:TSETup<nr>:CONTRol:FRAMES 1 ... 10000
Repetition Mode Single Shot	The measurement is stopped after one statistics cycle. All remote control measurements default to single shot.	CONFigure:<meas_obj>:CONTRol:REPetition SINGLEshot , <StopCondition>, <Stepmode> (<meas_obj> = OVERview... POWER... MODulation... SPECTrum... CDPower... RXQuality...)
Continuous	The measurement is continued until stopped explicitly or by a limit failure. Average results are calculated according to the rules described in chapter 3.	CONFigure:<meas_obj>:CONTRol:REPetition CONTinuous , <StopCondition>, <Stepmode> (<meas_obj> = OVERview... POWER... MODulation... SPECTrum... CDPower... RXQuality...)
Counting	Repeated single shot measurement with configured statistics cycles.	CONFigure:<meas_obj>:CONTRol:REPetition 1 ... 10000 , <StopCondition>, <Stepmode> (<meas_obj> = OVERview... POWER... MODulation... SPECTrum... CDPower... RXQuality...) A counting measurement with 1 evaluation period is equivalent to a single shot measurement.
Traces	The specifiers CURRent, MMAX, and AVERage denote the traces for the current evaluation period, the extreme value, and the average of a set of evaluation periods. They correspond to the <i>Display Mode</i> set in the measurement configuration menus. In general all four traces are evaluated during the measurement. They are selected via the specifiers used as last keywords in the READ..., FETCh... or SAMPlE... queries.	Measurement results: READ:ARRAy:<meas_obj>:<disp>? READ:SUBarrays:<meas_obj>:<disp>? ... <disp> = CURRent AVERage MAXimum MINimum MMAX (not all modes are available for all measurements) <meas_obj> = POWER:GOUTput CDPower... MODulation:EVMagnitude... MODulation:PERRor... MODulation:MERRor... Limit matching: CALCULATE[:SCALAR]:<meas_obj>:<disp>: MATChing:LIMit? <Response> <Response> contains the limit matching identifiers for all three traces

Specifying Limits

The following table gives an overview of the types of limits and possible results of the limit check.

Table 5-3 Limits and limit check

Type	Description	Command
Scalar limits	Limit values for a single (scalar) measured quantity. Depending on the measured quantity, either an upper limit or upper and lower limits can be defined.	<pre> CONFigure:<meas_obj>:<disp>:LIMit [:SCALar]:<symmetry>:<Spec.>:VALue <disp> = CURRENT AVERAge MMAX CAMMax where CAMMax denotes a limit valid for all measurement curves (current and average and min/maximum) <meas_obj> = OVERview... POWer... MODulation... <symmetry> = SYMMetric ASYMMetric for symmetric or asymmetric upper and lower limits <Spec.> = UPPer LOWer [:COMBined] for upper limits, lower limits, or combined upper and lower limits. CONFigure:RXQuality:FER:TSETup<nr>:LIMit[:SCALar]:SYMMetric[:COMBined]:VALue </pre>
Limit lines	For Gated Output Power, a tolerance template consisting of several areas can be defined.	<pre> CONFigure:POWer:GOUTput:CAMMax:LIMit :<Area>:VALue </pre>
Limit check	All scalar limits belonging to the same measurement group are read out together with the command on the right side.	<pre> CALCulate:<meas_obj.>:MATChing:LIMit? </pre>
	Possible results of the scalar limit check are listed on the right side.	<pre> NMAU not matching, underflow NMAL not matching, overflow INV measured value invalid OK no limit failure </pre>
	The result of the limit check depends on the statistics settings (see section Measurement Statistics on page 5.4).	<pre> CALCULATE:ARRAy:<meas_obj>:<disp> :MATChing:LIMit? where <disp> = :CURRent :AVERAge :MMAximum :MAXimum :MINimum </pre>

Measurement Environments

The measurement environments described in Chapter 3 can be activated or deactivated by means of the following commands:

- `CONFigure:<meas_obj>:ENVIRONMENT:ENABLE ON | OFF` enables or disables the environment of the corresponding measurement or measurement application.
- `CONFigure:ALL:ENVIRONMENT:ENABLE ON | OFF` enables or disables all measurement environments. With disabled environments, the *Connection Control* parameters are used permanently.

The parameters of the individual measurement environments are set using commands of the type `CONFigure:<meas_obj>:ENVIRONMENT...`

Status Reporting System

A general description of SCPI status registers and of the status reporting system is given in Chapter 5 of the CMU operating manual. This section is devoted to the particular features concerning CDMA2000 measurements.

Cascaded status registers

The CMU offers 30 independent `STATUS:OPERation:SUM1|2:CMU<nr>` sub-registers (<nr>=1 ... 15) which are implemented in hierarchical form. The bits of the 30 `STATUS:OPERation` registers are set only after the registers are assigned to a function group and measurement mode.

In the `EVENT` part, the `STATUS:OPERation` registers contain information on which actions the instrument has executed since the last reading. The registers can be read (and at the same time cleared) using the `STATUS:OPERation:SUM1|2:CMU<nr>[:EVENT]?` commands.

Extended event registers

In the CDMA2000 function groups, the `STATUS:OPERation:SUM1|2:CMU<nr>` sub-registers (<nr>=1 ... 15) are complemented by an additional level of `STATUS:OPERation` registers termed the extended event registers. In both test modes, bit no. 13 of the `STAT:OPER:SUM1|2:CMU<nr>` sub-register is set if an event occurred in the extended event register.

The extended event registers are read via `XTND:STATUS:OPERation:FGRegister[:EVENT]?` (see Chapter 6). Their contents are listed in

[Table 5-5](#) and [Table 5-7](#) below. Extended event evaluation is enabled or disabled using `STATUS:OPERation:SUM1|2:CMU13:ENABLE ON | OFF`; the individual bits cannot be enabled or disabled separately.

Symbolic status register evaluation

Symbolic status register evaluation by means of the commands `STATUS:OPERation:SYMBOLic:ENABLE` and `STATUS:OPERation:SYMBOLic[:EVENT]?` is a convenient alternative method of retrieving status information. See also section *Symbolic Status Event Register Evaluation* in chapter 5 of the CMU operating manual and in chapter 6 of this manual.

Symbolic status register evaluation is also provided for the extended event registers; the commands read `XTND:STATUS:OPERation:SYMBOLic[:EVENT]?`.

CDMA mobile tests comprise the two signalling modes *Non-Signalling* and *Signalling* for each CDMA2000 band (corresponding to a CMU function group) so that 2 secondary addresses are used for each function group. In the two status registers for the *Non-Signalling* mode the bit assignment is as follows:

Table 5-4 Non Signalling bits used in the `STAT:OPER:SUM1|2:CMU<nr>` sub-registers

Bit-No.	Description	Symbol in <code>STAT:OPER:SYMB...</code>
4	Measurement Invalid This bit is set if the active measurement could not performed and terminated correctly (e.g. because of a low signal level) so that the measurement results are invalid. It is also set if a frequency-dependent external attenuation caused conflicting level settings.	MINV
11	RF Input Overdriven This bit is set if the RF input level at connector RF1, RF2 or RF 4 IN is larger than the specified <i>RF Max. Level</i> plus an appropriate margin.	RFIO

12	RF Input Underdriven This bit is set while the RF input level at connector RF1, RF2 or RF 4 IN falls below the measurement range controlled by the specified <i>RF Max. Level</i> .	RFIU
13	Extended Event This bit is used as a sum bit for the extended event register, to be queried via XTND:STATus:OPERation:FGRegister[:EVENT]? (see Table 5-5 below).	XTND

Table 5-5 Extended event register in Non Signalling mode

Bit-No.	Description	Symbol in XTND:STAT:OPER:SYMB...
0	Uncalibrated This event occurs if the sum of all specified RFGenerator levels (for the individual CDMA2000 channels FFCH, FSYNC, ...) exceeds the maximum allowed RF generator level.	UCAL

In the two status registers for the *Signalling* mode the bit assignment is as follows:

Table 5-6 Signalling bits used in the STAT:OPER:SUM1|2:CMU<nr> sub-registers

Bit-No.	Description	Symbol in STAT:OPER:SYMB...
0	Call from Mobile This bit is set when the CMU receives a call from the mobile under test.	CFM
1	Release from Mobile This bit is set when the connection to the mobile is being released.	RFM
2	Loss of Radio Link This bit is set if the CMU had to leave the signalling state "Connected" (because of a low signal etc.).	LORL
3	Mobile Registered This bit is set when a registration was successfully performed.	MREG
4	Measurement Invalid This bit is set if the active measurement could not performed and terminated correctly (e.g. because of a low signal level) so that the measurement results are invalid.	MINV
5	Acknowledged Message This bit is set when the MS acknowledged a short message received from the CMU.	AMES
6	Reference Frequency not synchronized This bit is set if the reference frequency is not synchronized.	RFNS
7	Mobile Deregistered This bit is set if the CMU had to leave the signalling state "Registered" (because of a low signal etc.).	MDER
8	Received Message This bit is set when the MS received a short message from the CMU.	RMES
9	FCH Active This bit is set when data is transmitted via the Fundamental Channel.	FCH

Bit-No.	Description	Symbol in STAT:OPER:SYMB...
11	RF Input overdriven This bit is set if the RF input level at connector RF1, RF2 or RF 4 IN is larger than the specified <i>RF Max. Level</i> plus an appropriate margin.	RFIO
12	RF Input underdriven This bit is set while the RF input level at connector RF1, RF2 or RF 4 IN falls below the measurement range controlled by the specified <i>RF Max. Level</i> .	RFIU
13	Extended Event This bit is used as a sum bit for the extended event register, to be queried via XTND:STATus:OPERation:FGRegister[:EVENT]? (see Table 5-7 below).	XTND

Table 5-7 Extended event register in Signalling mode

Bit-No.	Description	Symbol in XTND:STAT:OPER:SYMB...
0	Uncalibrated This event occurs if the sum of all specified BSSignal levels (for the individual CDMA2000 channels FFCH, FSYNC, ...) exceeds the maximum allowed RF generator level.	UCAL
1	Dynamic Host Error This event occurs when the dynamic host (DHCP) procedure fails.	DMER
2	Call Wait Acknowledged This event occurs when the mobile acknowledges a call waiting call (initiated by enabling the call waiting indicator).	CWAC

Special Terms and Notation

Below we list some particular features in the syntax of the CDMA commands. The general description of the SCPI command syntax can be found in Chapter 5 of the CMU Operating manual, section "Structure and Syntax of Device Messages".

Description of commands

The commands are arranged in tables; all of them are described along the same scheme. From top to bottom, the table rows contain the following entries:

1. Complete command syntax including the parameter list and a short description of the command
2. List and description of the parameters with their default values, the default units and unit rings
3. Detailed description of the command, signalling state required for command execution (in Signalling mode), required firmware version

Detailed lists of default values are annexed to the command description.

Order of commands

The commands are arranged according to their function. The general purpose of a command is described by the keyword in the second level. Lower-level keywords define the command in more detail. This means that commands with the same second-level, third-level etc. keywords are generally grouped together in the same sections.

Example: `CONFigure:POWer:MAOutput:CONTrol:STATistics`
`<Statistics>`

Commands with the keyword *POWer* in the second level belong to the power measurement. The keywords in the third, fourth and fifth level indicate that the command defines the number of bursts forming a statistics cycle in the measurement of the MS maximum output power.

Combined measurements

To limit the number of remote control commands in an application program, all scalar results of a measurement group are usually measured together and returned in a common list. Arrays (e.g. the traces for *POWer* and *MODulation* measurements) are returned as comma-separated lists of values; it is possible to retrieve either the whole list (see commands `READ:ARRay...` etc.) or the values located in a number of subranges that are part of the total measurement range (see commands `READ:SUBarrays...`; the subarrays are defined via `CONFigure:SUBarrays...`).

Parameters

Many commands are supplemented by a parameter or a list of parameters. Parameters either provide alternative options (setting a or setting b or setting c ..., see special character "|"), or they form a comma-separated list (setting x,y).

<Par_Name>

Alternative settings are described by a common name (literal) written in angle brackets (<>). This literal serves as a description of the parameters only; in an application program it must be replaced by one of the settings given in the detailed parameter description.

Example: `CONFigure:POWer:MAOutput:CONTrol:STATistics`
`<Statistics>`

with `<Statistics> = 1 ... 10000 | NONE`

possible command syntax: `CONF:POW:MAO:CONT:STAT NONE`

NAN	NAN (not a number) is generally used to represent missing data, e.g. if a portion of a trace has not been acquired yet. It is also returned after invalid mathematical operations such as division by zero. As defined in the SCPI standard, NAN is represented as 9.91 E 37.
INV	INV (invalid) is returned if a limit check is performed without defining the appropriate tolerance values.
Upper / lower case	Upper/lower case characters characterize the long and short form of the keywords in a command. The short form consists of all upper-case characters, the long form of all upper case plus all lower case characters. Either the short form or the long form are allowed; mixed forms are not generally recognized. The instrument itself does not distinguish upper case and lower case characters.
Special characters	
	A vertical stroke in the parameter list characterizes alternative parameter settings. Only one of the parameters separated by must be selected. Example: The following command has two alternative settings: <pre>DEFault:LEVel ON OFF</pre>
[]	<i>Key words</i> in square brackets can be omitted when composing the command header (see Chapter 5 of the CMU Operating manual, section "Structure of a Command"). The complete command must be recognized by the instrument for reasons of compatibility with the SCPI standard. <i>Parameters</i> in square brackets are optional as well. They may be entered in the command or omitted.
[?]	Remote control commands that can also be used as a query are indicated with [?] at the end of the command. As a query, the "?" (question mark) must be part of the command.
{ }	Braces or curly brackets enclose one or more parameters that may be included zero or more times.
<nr>	This symbol stands for a numeric suffix, e.g. an enumeration index for input and output connectors.
List of Commands	
Command:	The <i>Command</i> column of the table contains all remote control commands arranged according to their function (configurations or measurement objects). Within a section, the commands are listed by alphabetical order.
Parameters:	The <i>Parameter</i> column lists the parameters of the commands.
Remarks:	The <i>Remarks</i> column gives additional information about the commands which <ul style="list-style-type: none"> • Have no query form (no query) • Have only a query form (query only) • Can be used both as setting commands and as queries (with query, this applies to all commands belonging to one of the two preceding categories)
Alphabetical Lists	The end of Chapter 6 includes an alphabetical command list for both test modes.

Contents

6 Remote Control – Commands	6.1
CDMA Module Tests (Non-Signalling)	6.2
Connection Control	6.2
Subsystem RFANalyzer (Analyzed Input Signals)	6.2
Subsystem TRIGger (Trigger Mode)	6.4
RF Generator– RFGenerator	6.6
Generator Settings – Subsystem RFGenerator	6.6
Generator Impairments – Subsystem IMPairments	6.13
Subsystem for RF Input and Output (External Attenuation at the Connectors).....	6.13
Subsystem DM:CLOCK (Synchronization).....	6.14
MODulation Measurements	6.16
Control of Measurement – Subsystem MODulation	6.16
Test Configuration.....	6.18
Subsystem MODulation:MQUALity:CONTRol	6.18
Tolerance values – Subsystem MODulation:LIMit.....	6.21
Measured Values – Subsystem MODulation	6.24
POWER Measurements.....	6.26
POWER:XSLot	6.26
Subsystem POWER:XSLot:CONTRol	6.27
Subsystem POWER:XSLot?.....	6.29
Common Measurements and Command Groups	6.31
Option Query	6.31
Partial Reset.....	6.32
Configuration File Management – System MMEMory	6.32
I/Q-IF Interface	6.33
Symbolic Status Event Register Evaluation.....	6.34
Extended Event Register	6.35
RF Selectivity	6.35
Wideband Power – WPOWER.....	6.36
Measured Values – Subsystem WPOWER?.....	6.37
Narrow-Band Power – NPOWER	6.38
Control of measurement – Subsystem NPOWER.....	6.38
Subsystem NPOWER:CONTRol.....	6.39
Measured Values – Subsystem NPOWER.....	6.41
MODulation Measurements	6.41
Common Settings – Subsystem MODulation:OEMP (O-QPSK and H-PSK).....	6.41
Measurement Environment – Subsystem MODulation:OEMP...:ENVIRONMENT	6.41
Tolerance values – Subsystem MODulation:OEMP:LIMit	6.45
MODulation:OVERview.....	6.49
Subsystem MODulation:OVERview:CONTRol	6.50
Measured Values – Subsystem MODulation:OVERview.....	6.51
MODulation:EVMagnitude	6.53
Control of Measurement – Subsystem MODulation:EVMagnitude.....	6.53
Subsystem MODulation:EVMagnitude:CONTRol	6.55

Subsystem SUBarrays:MODulation:EVMagnitude	6.57
Measured Values – Subsystem MODulation:EVMagnitude	6.57
MODulation:PERRor	6.61
Control of Measurement – Subsystem MODulation:PERRor	6.61
Subsystem MODulation:PERRor:CONTRol	6.62
Subsystem SUBarrays:MODulation:PERRor	6.64
Measured Values – Subsystem MODulation:PERRor	6.65
MODulation:MERRor	6.69
Control of Measurement – Subsystem MODulation:MERRor	6.69
Subsystem MODulation:MERRor:CONTRol	6.70
Subsystem SUBarrays:MODulation:MERRor	6.72
Measured Values – Subsystem MODulation:MERRor	6.73
MODulation:IQANalyzer	6.76
Control of Measurement – Subsystem MODulation:IQANalyzer	6.77
Test Configuration	6.78
Measured Values – Subsystem MODulation:IQANalyzer[:OQPSk]	6.79
SPECTrum:ACP (ACP Spectrum)	6.80
Control of Measurement	6.80
Test Configuration	6.81
Subsystem CONTRol	6.82
Subsystem LIMit	6.85
Measured Values	6.85
CDPower Measurements	6.88
Common Settings – Subsystem CDPower:CPCCommon (O-QPSK and H-PSK)	6.88
Measurement Environment – Subsystem	
CDPower:CPCCommon...:ENVironment	6.88
Tolerance values – Subsystem CDPower:CPCCommon:LIMit	6.92
CDPower:CDPW	6.94
Subsystem CDPower:CDPW:CONTRol	6.96
Measured Values – Subsystem CDPower:CDPW	6.98
CDPower:PCDep	6.101
Control of measurement – Subsystem CDPower:PCDep	6.101
Subsystem CDPower:PCDep:CONTRol	6.103
Measured Values – Subsystem CDPower:PCDep	6.105
CDPower:CHPW	6.109
Control of measurement – Subsystem CDPower:CHPW	6.109
Subsystem CDPower:CHPW:CONTRol	6.111
Measured Values – Subsystem CDPower:CHPW...?	6.113
CDPower:POFFset	6.117
Control of measurement – Subsystem CDPower:POFFset	6.117
Subsystem CDPower:POFFset:CONTRol	6.118
Subsystem CDPower:POFFset:LIMit	6.119
Measured Values – Subsystem CDPower:POFFset...?	6.120
CDPower:TOFFset	6.123
Control of measurement – Subsystem CDPower:TOFFset	6.123
Subsystem CDPower:TOFFset:CONTRol	6.124
Subsystem CDPower:TOFFset:LIMit	6.125
Measured Values – Subsystem CDPower:TOFFset...?	6.126
CDMA Mobile Tests (Signalling Mode)	6.131
Network Standards – NETWork	6.131
Connection Control	6.131
Signalling – Subsystem SIGNalling (Call Setup and Cleardown)	6.132
Subsystem Mobile Information	6.133

Subsystem Connection Information.....	6.135
Subsystem Messaging (WMT) Information.....	6.137
Subsystem Service Configuration.....	6.138
Subsystem SCONfig:SCLass:LOOP	6.140
Subsystem SCONfig:SCLass:SPEech	6.146
Subsystem SCONfig:SCLass:TDAT	6.152
Subsystem SCONfig:SCLass:PDAT	6.166
Subsystem SCONfig:SCLass:WMT.....	6.173
Subsystem BSSignal... (Signal of Base Station/CMU).....	6.175
Subsystem IMPairments... (Impairments to the BS Signal).....	6.186
Subsystem HANDOff:TARGeT (Handoff Target)	6.188
Subsystem NETWork.....	6.189
Subsystem NETWork:IDENTity	6.189
Subsystem MSSignal (Mobile Settings).....	6.190
Subsystem NETWork:SYSTem (System Parameters).....	6.191
Subsystem NETWork:CINDicator (Call Indicators).....	6.193
Subsystem NETWork:PCHannel (Paging Channel).....	6.194
Subsystem NETWork:REGistration	6.196
Subsystem NETWork:APRobes	6.198
SAPPower (Standby and Access Probe Power)	6.200
AF and RF Input, Output, and External Attenuation	6.201
Subsystem DM:CLOCK (Synchronization).....	6.203
Subsystem TRIGger (Trigger Mode)	6.203
Subsystem LEVel (Input Path Settings).....	6.205
Subsystem ENVironment (Measurement Environments).....	6.206
Subsystem MENU (Connection Control Behavior).....	6.206
OVERview Measurement.....	6.207
Subsystem OVERview:MCQuality	6.207
General Configurations – Subsystem OVERview:PPOWER	6.210
OVERview:OVERview	6.211
Subsystem OVERview:OVERview:CONTRol	6.212
Subsystem OVERview:OVERview:LIMit.....	6.215
Measured Values – Subsystem OVERview:OVERview	6.219
OVERview:CQUality	6.220
Subsystem OVERview:CQUality:CONTRol	6.222
Subsystem OVERview:CQUality:LIMit.....	6.223
Measured Values – Subsystem OVERview:CQUality	6.224
Power Measurements	6.225
POWER:MIOutput	6.225
Control of measurement – Subsystem POWER:MIOutput.....	6.225
Test Configuration.....	6.228
Measured Values – Subsystem POWER:MIOutput	6.233
POWER:MAOutput.....	6.234
Control of measurement – Subsystem POWER:MAOutput	6.234
Test Configuration.....	6.237
Measured Values – Subsystem POWER	6.242
POWER:GOUTput.....	6.243
Control of measurement – Subsystem POWER:GOUTput	6.243
Test Configuration.....	6.247
Measured Values – Subsystem POWER:GOUTput.....	6.253
POWER:OLTResponse	6.256
Control of measurement – Subsystem POWER:OLTResponse	6.256
Test Configuration.....	6.257

Measured Values – Subsystem POWER:OLTResponse	6.261
Receiver Quality Measurements	6.262
RXQuality:FER (Frame Erasure Rate)	6.262
Common Settings – Subsystem RXQuality:FER:FSSCommon:TSETup<nr>	6.262
Measurement Environment – Subsystem RXQuality:FER:FSSCommon:TSETup<nr>	6.263
Control of Measurement – Subsystem RXQuality:FER	6.266
Subsystem RXQuality:FER:CONTRol.....	6.267
Subsystem RXQuality:FER:FCH:LIMit.....	6.269
Measured Values – Subsystem RXQuality:FER.....	6.270
RXQuality:FPC (Forward Power Control)	6.272
Measurement Environment – Subsystem RXQuality:FER:FSSCommon:TSETup<nr>	6.272
Control of Measurement – Subsystem RXQuality:FPC	6.274
Subsystem RXQuality:FPControl:CONTRol.....	6.275
Measured Values – Subsystem RXQuality:FPControl.....	6.283
List of Non-Signalling Commands.....	6.284
List of Signalling Commands.....	6.298

6 Remote Control – Commands

This chapter contains all remote-control commands for the CDMA function groups. The commands are presented in tabular form with their parameters and the ranges of values. The structure of this chapter is analogous to that of the reference part for manual operation (Chapter 4).

The measurement test modes *Non-Signalling* and *Signalling* are presented separately. Within the each measurement mode, the general configurations are presented first and then the individual measurement groups (test objects) are presented.

Measurement groups that are identical in both test modes (*POWer*, *MODulation...*) are presented in a separate section between the two test modes.

General notes on remote control in the CDMA function group can be found in Chapter 5. An introduction to remote control according to SCPI standard and the status registers of the CMU is given in Chapter 5 of the operating manual for the CMU basic instrument.

Note: *Remote control commands that can also be used as a query are indicated with [?] at the end of the command. As a query, the “?” (question mark) must be part of the command.*

Otherwise the command documentation follows SCPI conventions (see also Chapter 5): Keywords and parameters enclosed in square brackets are optional and can be omitted without changing the effect of the command.

CDMA Module Tests (Non-Signalling)

In the *Non-Signalling* mode, an RF test signal can be generated and an RF signal with CDMA characteristics is analyzed. No signalling parameters are transferred.

Connection Control

The remote-control commands presented in this section determine the RF analyzer settings and the signals generated by the CMU, the inputs and outputs used and the reference frequency. They correspond to the settings in the popup menu of the softkey *Connect Control*, located at the top right of each main menu.

In *Non Signalling*, the *Connection Control* settings are general (global) settings that are valid for the entire function group.

Subsystem RFANalyzer (Analyzed Input Signals)

The subsystem *RFANalyzer* configures the RF input path by defining the analyzer level and frequency. It corresponds to the tab *Analyzer* in the popup menu *Connection Control*.

DEFault:RFANalyzer[?] <RF Analyzer>		RF Analyzer		
<RF Analyzer>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	The parameters are set to their default values The parameters differ from the default values (partially or totally)	ON	–	V3.05
Description of command				
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystems <i>RFANalyzer</i> and <i>LEVEL</i> to their default values (the setting <i>OFF</i> results in an error message).				
If used as a query the command returns whether all parameters are set to their default values (<i>ON</i>) or not (<i>OFF</i>).				

[SENSe:]RFANalyzer:FREQUENCY:UNIT[?] <Analyzer Freq. Unit>		Frequency Unit		
<Analyzer Freq. Unit>	Description of parameters	Def. Value	Def. unit	FW vers.
Hz KHz MHz GHz CH	Frequency unit or Channel Number	Hz	Hz	V3.05
Description of command				
This command defines whether the frequency of the RF signal analyzed is specified in frequency units or as a CDMA channel number. Frequency units must be used to select input signals that are outside the designated channel range.				

[SENSe:]RFANalyzer:FREQUENCY[?] <Frequency>			RF Frequency	
<Frequency>	Description of parameters	Def. Value	Def. unit	FW vers.
10.000 000 MHz to 2 700 . 000 000 MHz	Input frequency Default input frequency for the following standards: 450 MHz, BC 5 Cellular, BC0/BC2/BC3/BC7/BC9/BC10 PCS – BC1/BC4/BC8 IMT2000 – BC6	450.60 MHz / CH 12 833.49 MHz / CH 283 1857.50 MHz / CH 150 1920.60 MHz / CH 12	Hz	V3.05
Description of command				
This command defines the frequency of the RF signal analyzed. With the command [SENSe:]RFANalyzer:FREQUENCY:UNIT, the default frequency unit can be changed, and even CDMA channel numbers can be entered instead of frequencies. In the latter case, the assignment of channel numbers and frequencies meets the specification for the reverse channel (signal direction from mobile to CMU). BC = Band Class.				

[SENSe:]RFANalyzer:FOFFset[?] <Analyzer Freq. Offset>			Frequency Offset	
<Analyzer Freq. Offset>	Description of parameters	Def. value	Def. unit	FW vers.
–50.0 kHz to +50.0 kHz ON OFF	Frequency offset setting Frequency offset on, last setting re-activated No frequency offset	OFF	Hz	V3.05
Description of command				
This command determines a frequency offset to the RF signal analyzed.				

[SENSe:]LEVel:MODE[?] <RF Level Mode>			RF Level Mode	
<RF Level Mode>	Description of parameters	Def. value	Def. unit	FW vers.
AUTOMATIC MANual	Maximum input level mode for RF	MAN	–	V3.05
Description of command				
This command defines the maximum expected input level mode.				

[SENSe:]LEVel:MAXimum[?] <RF Manual Max Level>			Max. RF Level	
<RF Manual Max Level>	Description of parameters	Def. value	Def. unit	FW vers.
–43 dBm to +44 dBm	Maximum input level for RF 1	0.0	dBm	V3.05
–57 dBm to +30 dBm	Maximum input level for RF 2	0.0	dBm	
–80 dBm to +9 dBm	Maximum input level for RF 4 IN	0.0	dBm	
Description of command				
This command defines the maximum expected input level. The value range depends on the RF input used and the external attenuation set (see [SENSe:]CORREction:LOSS:INPut<nr>[:MAGNitude] command). If option R&S CMU-U99 (RF 1 with RF 2 Level Range) is fitted, RF 1 takes on the level range of RF2.				

Subsystem TRIGger (Trigger Mode)

The subsystem *TRIGger* defines the trigger condition for the measurement and the routing of output trigger signals. It corresponds to the *Trigger* tab in the *Connection Control* menu.

DEFAult:TRIGger[:SEQuence][?] <Trigger Source>		Default All Settings		
<Trigger Source>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	The parameters are set to their default values Some or all parameters are not set to default	ON	–	V3.10
Description of command				
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystem <i>TRIGger</i> to their default values (the setting <i>OFF</i> results in an error message).				
If used as a query the command returns whether all parameters are set to their default values (<i>ON</i>) or not (<i>OFF</i>).				

DEFAult:TRIGger[:SEQuence]:SOURce[?] <Trigger Source>		Trigger		
<Trigger Source>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	The parameters are set to their default values Some or all parameters are not set to default	ON	–	V3.05
Description of command				
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystem <i>TRIGger:SOURce</i> to their default values (the setting <i>OFF</i> results in an error message).				
If used as a query the command returns whether all parameters are set to their default values (<i>ON</i>) or not (<i>OFF</i>).				

TRIGger[:SEQuence]:SOURce [?] <Source>		Trigger Source		
<Source>	Description of parameters	Def. Value	Def. unit	FW vers.
INTernal EXTernal FRUN RFPower IFPower	Trigger source from internal clock External Trigger source supplied Trigger set to free run Wideband RF power trigger Narrow-band IF power trigger	FRUN (EXT for HPSK)	–	V3.05 V3.40
Description of command				
This command selects the source of the trigger event. The settings <i>RFPower</i> and <i>IFPower</i> require burst signals. The external trigger source is supplied via the AUX 3 connector on the front panel. The AUX 3 pin assignments are:				
Output trigger signals: See command <code>TRIGger:OUTPut:PIN<nr>:SIGNal [?]</code>				
Input trigger: Pin 8: Trigger Input				
H-PSK measurements and the Transmit Time Error measurement require particular trigger settings and synchronization; see Chapter 4. The <i>Power vs. Frame</i> (... <i>POWER</i> : <i>XSLot</i> ...) measurement is most easily performed with an <i>IFPower</i> trigger.				

TRIGger[:SEQuence]:THReshold:RFPower <Threshold>		Level – RF Power		
<Threshold>	Parameter description	Def. value	Default unit	FW vers.
LOW	Low trigger threshold (<i>RF Max. Level – 26 dB</i>)	MEDium	–	V3.40
MEDium	Medium trigger threshold (<i>RF Max. Level – 16 dB</i>)			
HIGH	High trigger threshold (<i>RF Max. Level – 6 dB</i>)			
Command description				
This command sets the RF input signal level at which the measurement is triggered relative to the maximum RF input level; see [SENSe:]LEVEl:MAXimum. The setting has effect for trigger source RFPower only (see TRIG:SEQ:SOUR:<Modulation>).				

TRIGger[:SEQuence]:THReshold:IFPower <Threshold>		Level – IF Power		
<Threshold>	Parameter description	Def. value	Default unit	FW vers.
–47 dB to 0 dB	IF power threshold	–16	dB	V3.40
Command description				
This command sets the IF signal level at which the measurement is triggered. The IF power threshold is defined relative to the maximum RF input level; see [SENSe:]LEVEl:MAXimum. The setting has effect for trigger source IFPower only (see TRIG:SEQ:SOUR:<Modulation>).				

TRIGger[:SEQuence]:SLOPe <Slope>		Slope		
<Slope>	Parameter description	Def. value	Default unit	FW vers.
POSitive	Rising edge	POS	–	V3.40
NEGative	Falling edge			
Command description				
This command qualifies whether the trigger event occurs on the <i>Rising Edge</i> or on the <i>Falling Edge</i> of the trigger signal. The setting has no influence on <i>Free Run</i> measurements (see TRIG:SEQ:SOUR).				

TRIGger:OUTPut:PIN<nr>:SIGNaI[?]		Output Routing		
<Frame_Period>	Description of parameters	Def. value	Def. unit	FW vers.
NONE	No output trigger signal	<nr> = 2: SNCF <nr> = 3 = PP2S <nr> = 4 = SFR <nr> = 5 = PFR	–	V3.10
PP2S	Periodic pulse with period 2 s			
SFRame	Super frame, 80 ms			
SNCFrame	Sync. frame, 26.67 ms			
PFRame	Paging frame, 20 ms			
PCFRame	Power control frame, 1.25 ms			
DEFault	Use default settings			
Description of command				
This command selects the type of periodic pulse signal (or no signal, setting <i>NONE</i>) to be applied to pins 2, 3, 4, and 5 (<nr> = 2 to 5) of the AUX 3 connector.				

RF Generator– RFGenerator

The subsystem *RFGenerator* configures the RF signals generated by the CMU. It corresponds to the tab *Generator* in the popup menu *Connection Control*.

DEfault:RFGenerator[?] <RF Generator>		RF Generator		
<RF Analyzer>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	The parameters are set to their default values Some or all parameters are not set to default	ON	–	V3.05
Description of command				
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystem <i>RFGenerator</i> to their default values (the setting <i>OFF</i> results in an error message).				
If used as a query the command returns whether all parameters are set to their default values (<i>ON</i>) or not (<i>OFF</i>).				

INITiate:RFGenerator	Start RF generator, reserve resources	⇒	<i>RUN</i>
ABORT:RFGenerator	Switch off RF generator, release resources	⇒	<i>OFF</i>
Description of command			FW vers.
These commands have no query form. They start and stop the RF generator, setting it to the status indicated in the top right column.			V3.05

FEtCh:RFGenerator:STATUs?		Generator Status		
Returned values	Description of parameters	Def. Value	Def. unit	FW vers.
OFF RUN ERR	Generator switched off (<i>ABORT</i> or <i>*RST</i>) Running (<i>INITiate</i>) Switched off (could not be started)	OFF	–	V3.05
Description of command				
This command is always a query. It returns the current generator status.				

Generator Settings – Subsystem RFGenerator

The subsystem *RFGenerator* configures all settings for the generated RF signal. It corresponds to the tab *Generator* in the popup menu *Connection Control*.

SOURce:RFGenerator:LEVel:OCNS:VALue?		OCNS Value		
Returned value	Description of parameters	Def. value	Def. unit	FW vers.
OCNS	OCNS level relative to CDMA power	–	dB	V3.05
Description of command				
This command is always a query. It returns the OCNS level in units relative to the CDMA power (see <i>SOURce:RFGenerator:LEVel</i> command).				

SOURce:RFGenerator:LEVel:OCNS:ENABLE[?]				OCNS Enable
<OCNS Enable>				
<OCNS Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	OCNS generator on or off	ON	–	V3.05
Description of command				
This command turns the Orthogonal Channel Noise Simulator on or off. In the ON setting, the OCNS level is such that the sum of all generator levels and the OCNS level equals the nominal base station power. The query returns the OCNS level in units relative to the CDMA power (see <code>SOURce:RFGenerator:LEVel</code> command).				

SOURce:RFGenerator:FREQuency[:RF]:UNIT[?]				Frequency Unit
<Unit>				
<Unit>	Description of parameters	Def. Value	Def. unit	FW vers.
Hz KHZ MHZ GHZ CH	Frequency unit or Channel Number	Hz	Hz	V3.05
Description of command				
This command defines whether the frequency of the RF signal generated is specified in frequency units or as an CDMA channel number. Frequency units must be used to select input signals that are outside the designated CDMA channel range.				

SOURce:RFGenerator:FREQuency[:RF][?]				RF Frequency
<Frequency>				
<Frequency>	Description of parameters	Def. Value	Def. unit	FW vers.
10.000 000 MHz to 2 700 . 000 000 MHz	Input frequency Default Input Frequency for the following standards: 450 MHz, BC 5 Cellular, BC0/BC2/BC3/BC7/BC9/BC10 PCS – BC1/BC4/BC8 IMT2000 – BC6	 460.60 MHz / CH 25 878.49 MHz / CH 283 1937.50 MHz / CH 150 2110.60 MHz / CH 12	Hz	V3.05
Description of command				
This command defines the frequency of the RF signal generated. With the command <code>SOURce:RFGenerator:FREQuency:UNIT</code> , the default frequency unit can be changed, and even CDMA channel numbers can be entered instead of frequencies. In the latter case, the assignment of channel numbers and frequencies meets the specification for the forward channel (signal direction from CMU to mobile under test).				

SOURce:RFGenerator:CHANnel:FFCH[?]				Traffic Channel
<FFCH Channel>				
<FFCH Channel>	Description of parameters	Def. Value	Def. unit	FW vers.
2 to 63	Traffic channel number	8	–	V3.05
Description of command				
This command determines the number of the forward fundamental traffic channel generated by the CMU.				

SOURce:RFGenerator:PROPerTy:PNOffset[?]		PN Offset		
<PN Offset>				
<PN Offset>	Description of parameters	Def. value	Def. unit	FW vers.
0 to +511	PN offset	0	–	V3.05
Description of command				
Describes an offset for the timing of the pilot channel, the sync channel message, and the long code mask of the paging channel.				

SOURce:RFGenerator:QOF:FFCH[?] <QOF>		F-FCH QOF		
<QOF>				
<QOF>	Description of parameters	Def. value	Def. unit	FW vers.
0 0 to 3	Quasi-orthogonal function, RC = 1, 2 Quasi-orthogonal function, RC = 3, 4, 5	0	–	V3.60
Description of command				
This command defines the Quasi-Orthogonal Function of the Forward Fundamental Channel. The range of values depends on the forward radio configuration (SOURce:RFGenerator:RC).				

SOURce:RFGenerator:FROffset:FFCH[?]		Frame Offset		
<Frame Offs>				
<Frame Offs>	Description of parameters	Def. value	Def. unit	FW vers.
0 to +15	Frame offset	0	–	V3.05
Description of command				
This command defines an offset for the forward fundamental traffic channel timing in CDMA frames.				

SOURce:RFGenerator:FRATE:FFCH[?]		Frame Rate		
<Frame Rate>				
<Frame Rate>	Description of parameters	Def. value	Def. unit	FW vers.
EIGHth QUARter HALF FULL DEF	Frames at 1/8 of the rate set Frames at 1/4 of the rate set Frames at 1/2 of the rate set Frames at the full rate set Sets the value to the default setting	FULL	–	V3.05
Description of command				
This command sets the frame rate for the forward fundamental traffic channel.				

SOURce:RFGenerator:RC[?] <RC>		Radio Configuration		
<RC>				
<RC>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 5	Radio configuration of the generator signal	1	–	V3.60
Description of command				
This command selects the radio configuration for the (forward) RF generator signal.				

SOURce:RFGenerator:RSET?		Rate Set		
Response	Description of parameters	Def. value	Def. unit	FW vers.
1 2	Rate	NAN	–	V3.60
Description of command				
This command is always a query and returns the rate set which is determined by the selected radio configuration for the (forward) RF generator signal (SOURce:RFGenerator:RC).				

SOURCE:RFGenerator:SID <SID>		System ID Number		
<SID>	Description of parameters	Def. value	Def. unit	FW vers.
0 to 32767	System ID	1	–	V3.60
Description of command				
This command defines the system identification for the CMU.				

SOURCE:RFGenerator:PREVision <Revision>		Protocol Revision		
<Revision>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 6	Protocol Revision	6	–	V3.60
Description of command				
This command defines the preferred version of the protocol for the CMU to use.				

SOURCE:RFGenerator:MPRevision <Revision>		Minimum Protocol Revision		
<Revision>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 6	Minimum Protocol Revision	1	–	V3.60
Description of command				
This command defines the minimum protocol revision capability of the mobile station.				

SOURCE:RFGenerator:NID <NID>		Network ID Number		
<NID>	Description of parameters	Def. value	Def. unit	FW vers.
0 to 65535	Network ID	1	–	V3.60
Description of command				
This command defines the 16-bit network identity code.				

SOURCE:RFGenerator:PCHannel:RATE <Rate>		Paging Channel Rate		
<Rate>	Description of parameters	Def. value	Def. unit	FW vers.
R4K8 R9K6	4.800 kbps or 9.600 kbps paging channel	R9K6	–	V3.60
Description of command				
This command defines data rate of the base station's paging channel.				

SOURCE:RFGenerator:ESN <ESN>		ESN		
<ESN>	Description of parameters	Def. value	Def. unit	FW vers.
'00000000' to 'FFFFFFF'	ESN	'00000000'	–	V3.60
Description of command				
This command defines the Electronic Serial Number of the mobile station. The number must be entered as an 8-digit hex string.				

SOURCE:RFGenerator:ZLCM <Enable>		Zero Long Code Mask		
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	Enable or disable zero long code mask	OFF	–	V3.60
Description of command				
This command enables or disables the zero long code mask. If this parameter is set to ON, then the calculated long code mask is replaced by an all zero sequence.				

SOURce:RFGenerator:MODulation:MODE[?] <Modulation Mode>		Modulation Mode		
<Modulation Mode>	Description of parameters	Def. value	Def. unit	FW vers.
AUTomatic OFF DEF	CDMA2000 signal according to channel configuration Empty carrier signal (Continuous Wave) Sets the value to the default setting	AUTomatic	–	V3.05
Description of command				
This command selects the method used to modulate the generated RF signal.				

SOURce:RFGenerator:POWer:CDMA[?] <CDMA Power>		CDMA Power		
<CDMA Power>	Description of parameters	Def. value	Def. unit	FW vers.
–120.0 dBm to –33.0 dBm –120.0 dBm to –16.0 dBm –100.0 dBm to 7.0 dBm	RF1 OUT, 0 dB ext. atten. RF2 OUT, 0 dB ext. atten. RF3 OUT, 0 dB ext. atten	–70.0	dBm	V3.05
Description of command				
This command determines total CDMA output power (absolute value, in dBm). CDMA Power value range depends on the RF input used and the external attenuation set. If option R&S CMU-U99 (<i>RF 1 with RF 2 Level Range</i>) is fitted, RF 1 takes on the level range of RF2.				

SOURce:RFGenerator:POWer:OUTput? <Output Power>		Output Power		
Returned value	Description of parameters	Def. value	Def. unit	FW vers.
Output Power	Total output power	NAN	dB	V3.05
Description of command				
This command is always a query. It returns the total output power of the CMU, i.e. the CDMA power plus the AWGN level.				

SOURce:RFGenerator:LEVel:FFCH[?] <FFCH Level>		FFCH Level		
<FFCH Level>	Description of parameters	Def. value	Def. unit	FW vers.
–7 dB to –20 dB MIN MAX DEF ON OFF	Forward fundamental channel level Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting Forward fundamental channel on, last setting re-activated Forward fundamental channel off	–14	dB	V3.05
Description of command				
This command sets the signal level of the fundamental channel of the forward CDMA channel and enables or disables the signal.				

SOURce:RFGenerator:LEVel:FSYNc[?] <FSYNc Level>		FSYNc Level		
<FSYNc Level>	Description of parameters	Def. value	Def. unit	FW vers.
-7 dB to -20 dB MIN MAX DEF ON OFF	Forward sync channel level Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting Forward sync channel on, last setting re-activated Forward sync channel off	-16	dB	V3.05
Description of command				
This command sets the signal level of the sync channel of the forward CDMA channel and enables or disables the signal.				

SOURce:RFGenerator:LEVel:FPICH[?] <FPICH Level>		FPICH Level		
<FPICH Level>	Description of parameters	Def. value	Def. unit	FW vers.
-7 dB to -20 dB MIN MAX DEF ON OFF	Forward pilot channel level Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting Forward pilot channel on, last setting re-activated Forward pilot channel off	-7	dB	V3.05
Description of command				
This command sets the signal level of the pilot channel of the forward CDMA channel and enables or disables the signal.				

SOURce:RFGenerator:LEVel:FPCH[?] <FPCH Level>		FPCH Level		
<FPCH Level>	Description of parameters	Def. value	Def. unit	FW vers.
-7 dB to -20 dB MIN MAX DEF ON OFF	Forward paging channel level Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting Forward paging channel on, last setting re-activated Forward paging channel off	-12	dB	V3.05
Description of command				
This command sets the signal level of the paging channel of the forward CDMA channel and enables or disables the signal.				

CONFigure:RFGenerator:PCBits[?] <Power Control Bits>		Power Control Bits		
<Power Control Bits>	Description of parameters	Def. value	Def. unit	FW vers.
OFF AUTO HOLD ADOW AUP RTES PATTERN	Disable power control bits Auto mode, closed-loop operation Alternating up/down control bits All power control bits down All power control bits up Range test mode Pattern defined by means of the SOURCE:RFGenerator:PCBits:PATTERN... commands	AUToma tic	–	V3.20
Description of command				
This command defines the power control bits in the RF generator signal.				

SOURce:RFGenerator:PCBits:PATTERN:SQMode[?] <Seq_Mode>		Pattern Sequence Mode		
<Seq_Mode>	Description of parameters	Def. value	Def. unit	FW vers.
PREP PFBA PFBH	Pattern repeated Pattern Followed by Auto Pattern Followed by Hold	PREP	–	V3.20
Description of command				
This command selects the algorithm to construct the complete user-defined pattern from the single bit pattern defined by means of the SOURCE:RFGenerator:PCBits:PATTERN:AREA<nr>... commands.				

SOURce:RFGenerator:PCBits:PATTERN:AREA<no>:NOBits[?] <Number_of_Bits>		Number of Bits		
<Number_of_Bits>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 64 1 to 128	Number of bits for area no. 1 Number of bits for area no. 2, 3, 4	32 100	–	V3.20
Description of command				
This command defines the number of bits in each of the 4 areas of the user-defined single pattern.				

SOURce:RFGenerator:PCBits:PATTERN:AREA1:LHBit[?] <Polarity>		Last Hold Bit		
<Polarity>	Description of parameters	Def. value	Def. unit	FW vers.
UP DOWN	Last Hold Bit	DOWN	–	V3.20
Description of command				
This command defines the bit polarity in area no. 1 of the user-defined single pattern.				

SOURce:RFGenerator:PCBits:PATTERN:AREA<no>:POLarity[?] <Polarity>		Polarity		
<Polarity>	Description of parameters	Def. value	Def. unit	FW vers.
UP DOWN	Polarity	UP (area no. 2, 4) DOWN (area no. 3)	–	V3.20
Description of command				
This command defines the bit polarity in areas 2 to 4 of the user-defined single pattern.				


Generator Impairments – Subsystem IMPairments

The subsystem *IMPairments* configures the settings to impair the generated RF signal. The settings are provided in the *Generator* tab of the popup menu *Connection Control*.

SOURce:IMPairments:LEVel:AWGN[?] <AWGN Level>		AWGN Level		
<AWGN Level>	Description of parameters	Def. value	Def. unit	FW vers.
–20.0 dB to +4.0 dB MIN MAX DEF ON OFF	AWGN level Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting AWGN generator on, last setting re-activated AWGN generator off	OFF	dB	V3.05
Description of command				
This command determines an Additional White Gaussian Noise level to impair the RF generator signal.				

SOURce:IMPairments:FOFFset[:RF][?] <Freq. Offset>		BS Frequency Offset		
<Freq. Offset>	Description of parameters	Def. value	Def. unit	FW vers.
–50.0 kHz to +50.0 kHz MIN MAX DEF ON OFF	BS frequency offset setting Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting BS frequency offset on, last setting re-activated No frequency offset	OFF	Hz	V3.05
Description of command				
This command defines an offset for the RF generator frequency set with the command [SENSE:]RFGenerator:FREQUENCY <Number>. The offset frequency must be in multiples of 1 Hz.				

Subsystem for RF Input and Output (External Attenuation at the Connectors)

The subsystem for input and output configures the input and output RF connectors. The subsystem corresponds to the tab *AF/RF*  in the popup menu *Connect Control*.

INPut[:STATe] <State>		RF Input		
<State>	Description of parameters	Def. value	Def. unit	FW vers.
RF1 RF2 RF4	Connector RF 1 used as input Connector RF 2 used as input Connector RF 4 IN used as input	RF2	–	V3.05
Description of command				
This command determines the connector to be used for RF input signals. The bidirectional connectors RF 1 and RF 2 can be used both as input and output connectors in the same measurement (see <i>OUTPut[:STATe]</i>).				
Only one input and one output may be active at the same time, a new RF input setting supersedes the previous one.				

OUTPut[:STATe] <State>				RF Output
<State>	Description of parameters	Def. value	Def. unit	FW vers.
RF1	Connector RF 1 used as output	RF2	–	V3.05
RF2	Connector RF 2 used as output			
RF3	Connector RF 3 OUT used as output			
Description of command				
This command determines the connector to be used for RF output signals. The bidirectional connectors RF 1 and RF 2 can be used as input and output connectors in the same measurement (see INPut[:STATe]).				
Only one input and one output may be active at the same time, a new RF output setting supersedes the previous one.				

[SENSe:]CORRection:LOSS:INPut<nr>[:MAGNitude] SOURce:CORRection:LOSS:INPut<nr>[:MAGNitude] <Attenuation>				Ext. Att. Input
<Attenuation>	Description of parameters	Def. value	Def. unit	FW vers.
–50 dB to +90 dB	Value for external attenuation at the input <nr>, where <nr> = 1, 2, 4	0.0	dB	V3.05
Description of command				
This command assigns an external attenuation value to the inputs of the instrument (RF 1, RF 2, RF 4 IN).				

[SENSe:]CORRection:LOSS:OUTPut<nr>[:MAGNitude] SOURce:CORRection:LOSS:OUTPut<nr>[:MAGNitude] <Attenuation>				Ext. Att. Output
<Attenuation>	Description of parameters	Def. value	Def. unit	FW vers.
–50 dB to +90 dB	Value for external attenuation at output <nr>, where <nr> = 1, 2, 3	0.0	dB	V3.05
Description of command				
This command assigns an external attenuation value to the outputs of the instrument (RF 1, RF 2, RF 3 OUT).				

Subsystem DM:CLOCK (Synchronization)

The subsystem *DM:CLOCK* sets a system clock specific to the network. This frequency is set in the tab *Synch.* in the popup menu *Connect. Control*.

SOURce:DM:CLOCK:STATe <Mode>				REF OUT 2
<Mode>	Description of parameters	Def. Value	Def. unit	FW vers.
ON OFF	Switch on/off system clock	OFF	–	V3.05
Description of command				
This commands switches the system clock specific to the network at the REF OUT 2 connector on or off. When set to on, the frequency is set at 13.1072 MHz.				

SOURce:DM:CLOCK:FREQuency <Frequency> <Frequency>				REF OUT 2
<Frequency>	Description of parameters	Def. value	Def. unit	FW vers.
39.3216 MHz 19.6608 MHz 13.1072 MHz 9.8304 MHz	System Clock Frequency	39.3216	MHz	V3.03
Description of command				
This command determines the system clock frequency applied to <i>REF OUT 2</i> . Any entered value is rounded to one of the four valid frequencies.				

MODulation Measurements

The subsystem *MODulation* measures general scalar modulation parameters. The subsystem corresponds to the *Analyzer/Generator* menu and the popup menu *Modulation Quality Configuration*.

Control of Measurement – Subsystem MODulation

The subsystem *MODulation* controls the modulation measurement. It corresponds to the softkey *Mod. Qual.* in the measurement menu *Analyzer/Generator*.

INITiate:MODulation:MQuality[:OQPSk] INITiate:MODulation:MQuality:HPSK INITiate:MODulation:MQuality:QPSK	Start new measurement	⇒	<i>RUN</i>
ABORt:MODulation:MQuality[:OQPSk] ABORt:MODulation:MQuality:HPSK ABORt:MODulation:MQuality:QPSK	Abort running measurement and switch off	⇒	<i>OFF</i>
STOP:MODulation:MQuality[:OQPSk] STOP:MODulation:MQuality:HPSK STOP:MODulation:MQuality:QPSK	Stop measurement after current stat. cycle	⇒	<i>STOP</i>
CONTinue:MODulation:MQuality[:OQPSk] CONTinue:MODulation:MQuality:HPSK CONTinue:MODulation:MQuality:QPSK	Next measurement step (<i>stepping mode</i>)	⇒	<i>RUN</i>
Description of command			FW vers.
These commands have no query form. They start and stop the modulation measurement, setting it to the status indicated in the top right column.			V3.05

CONFigure:MODulation:MQuality[:OQPSk]:EREPorting[?] CONFigure:MODulation:MQuality:HPSK:EREPorting[?] CONFigure:MODulation:MQuality:QPSK:EREPorting[?] <Report Mode>		Event Reporting		
<Report Mode>	Description of parameters	Def. Value	Def. unit	FW vers.
SRQ	Service request	OFF	–	V3.05
SOPC	Single operation complete			
SRSQ	SRQ and SOPC			
OFF	No reporting			
DEF	Sets the value to the default setting			
Description of command				
This command defines the events generated when the measurement is terminated or stopped (see Chapter 5 of the CMU 200 Operating manual about event reporting).				

FETCh[:SCALar]:MODulation:MQuality[:OQPSk]:STATus? FETCh[:SCALar]:MODulation:MQuality:HPSK:STATus? FETCh[:SCALar]:MODulation:MQuality:QPSK:STATus?		Measurement Status		
Returned values	Description of parameters	Def. Value	Def. unit	FW vers.
OFF	Measurement in the OFF state (*RST or ABORT)	OFF	–	V3.05
RUN	Running (after INITiate, CONTinue or READ)			
STOP	Stopped (STOP)			
ERR	OFF (could not be started)			
STEP	Stepping mode (<stepmode>=STEP)			
RDY	Stopped according to repetition mode and stop condition			
Description of command				
This command is always a query. It returns the status of the measurement (see Chapters 3 and 5).				

XTND:MODulation:MQuality[:OQPSk]:SBSuppress[?] XTND:MODulation:MQuality:HPSK:SBSuppress[?] XTND:MODulation:MQuality:QPSK:SBSuppress[?]		Extend Sideband Suppression Measurement		
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON	Extend sideband suppression measurement (4 offset freq.)	OFF	–	V3.10
OFF	Sideband suppression measurement (1 offset frequency)			
DEFault	Use the default setting			
Description of command				
This command enables or disables the extended input and output arrays for the sideband suppression measurement, see commands CONFIGure:MODulation:MQuality...LIMit, READ[:SCALar]:MODulation:MQuality..., FETCh[:SCALar]:MODulation:MQuality..., SAMPlE[:SCALar]:MODulation:MQuality... and CALCulate[:SCALar]:MODulation:MQuality...MATChing:LIMit.				
The measurement of the upper and lower sideband suppression at the four offset frequencies can be enabled or disabled separately; see commands CONFIGure:MODulation:MQuality:<Application>:CONTrol:FOFFset:SBSuppress:ACP<nr>.				

Test Configuration

The commands of the following subsystems configure the *Modulation* measurement in the *Analyzer/Generator* menu. They correspond to the *Modulation Quality Configuration* menu.

Subsystem MODulation:MQuality:CONTRol

The subsystem *MODulation:MQuality:CONTRol* configures the modulation measurement. It corresponds to the tabs *Control* and *Statistics* in the popup menu *Modulation Quality Configuration*.

DEFault:MODulation:MQuality:CONTRol[?]		Default Settings		
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	The parameters are set to their default values Some or all parameters are not set to default	ON	–	V3.05
Description of command				
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystem <i>OVERview:MODulation:CONTRol</i> to their default values (the setting <i>OFF</i> results in an error message).				
If used as a query the command returns whether all parameters are set to their default values (<i>ON</i>) or not (<i>OFF</i>).				

DEFault:MODulation:MQuality[:OQPSk]:CONTRol[?] DEFault:MODulation:MQuality:HPSK:CONTRol[?] DEFault:MODulation:MQuality:QPSK:CONTRol[?] <Enable>		Default Settings		
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	The parameters are set to their default values Some or all parameters are not set to default	ON	–	V3.05
Description of command				
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the <i>MODulation:MQuality:*:CONTRol</i> subsystem to their default values (the setting <i>OFF</i> results in an error message).				
If used as a query the command returns whether all parameters are set to their default values (<i>ON</i>) or not (<i>OFF</i>).				

CONFigure:MODulation:MQuality[:OQPSk]:CONTrol[?] CONFigure:MODulation:MQuality:HPSK:CONTrol[?] CONFigure:MODulation:MQuality:QPSK:CONTrol[?] <Statistics>, <Repetition>, <Stop Cond>, <Step Mode>		Scope of Measurement		
<Statistics>	Description of parameters	Def. value	Def. unit	
1 to 1000,	Number of bursts within a statistics cycle	100	–	
<Repetition>	Description of parameters	Def. value	Def. unit	
1 to 10000 CONT SING DEF,	Multiple measurement (counting, until Status = STEP RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–	
<Stop Cond>	Description of parameters	Def. value	Def. unit	
NONE SONerror DEF,	Continue measurement even in case of error Stop measurement in case of error (<i>stop on error</i>) Sets the value to the default setting	NONE	–	
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
NONE STEP DEF	Continue measurement according to its rep. mode Interrupt measurement after each statistics cycle Sets the value to the default setting	NONE	–	V3.05
Description of command				
This command sets all measurement control parameters. It combines the ...CONTrol:STATistics and the ...CONTrol:REPetition commands.				

CONFigure:MODulation:MQuality[:OQPSk]:CONTrol:STATistics[?] CONFigure:MODulation:MQuality:HPSK:CONTrol:STATistics[?] CONFigure:MODulation:MQuality:QPSK:CONTrol:STATistics[?] <Statistics>		Statistic Count		
<Statistics>	Description of parameters	Def. Value	Def. unit	FW vers.
1 to 1000	Number of bursts within a statistics cycle	100	–	V3.05
Description of command				
This command selects the type of measured values and determines the number of bursts forming one statistics cycle.				

CONFigure:MODulation:MQuality[:OQPSk]:CONTRol:REPetition[?] CONFigure:MODulation:MQuality:HPSK:CONTRol:REPetition[?] CONFigure:MODulation:MQuality:QPSK:CONTRol:REPetition[?] <Repetition>, <Stop Cond>, <Step Mode>				Test Cycles
<Repetition>	Description of parameters	Def. value	Def. unit	
1 to 10000 CONT SING DEF,	Multiple measurement (counting, until Status = STEP RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–	
<Stop Cond>	Description of parameters	Def. value	Def. unit	
NONE SONerror DEF,	Continue measurement even in case of error Stop measurement in case of error (<i>stop on error</i>) Sets the value to the default setting	NONE	–	
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
NONE STEP DEF	Continue measurement according to its rep. mode Interrupt measurement after each statistics cycle Sets the value to the default setting	NONE	–	V3.05
Description of command				
This command determines the number of statistics cycles, the stop condition and the stepping mode for the measurement.				
Note: In the case of READ commands (READ:...), the <Repetition> parameter has no effect; the measurement is always stopped after a single shot.				

CONFigure:MODulation:MQuality[:OQPSk]:CONTRol:FOFFset:SBSuppress:ACP<nr>[?] CONFigure:MODulation:MQuality:HPSK:CONTRol:FOFFset:SBSuppress:ACP<nr>[?] CONFigure:MODulation:MQuality:QPSK:CONTRol:FOFFset:SBSuppress:ACP<nr>[?] <Freq. Offset>				Sideband Frequency Offset
<Freq. Offset>	Description of parameters	Def. value	Def. unit	FW vers.
0 to 2 MHz DEF MIN MAX OFF	quency offset Sets the value to the default setting minimum maximum Measurement disabled, result INV	see below	Hz	V3.10
Description of command				
This command sets up to 4 frequency offset values (<nr> = 1 to 4) used for the sideband suppression power measurement. The default values are 90 000 Hz for <nr> = 1, 1980 000 Hz for <nr> = 2 and OFF for the two remaining frequency offset values. The sideband suppression measurement yields 4 pairs of results corresponding to symmetrical frequency offsets to the RF frequency (command [SENSe:]RFANalyzer:FREQuency[?]).				

Tolerance values – Subsystem MODulation:LIMit

The subsystem *MODulation:LIMit* defines tolerance values for the modulation measurement. The subsystem corresponds to the *Limits* tab in the popup menu *Modulation Quality Configuration*.

CONFigure:MODulation:MQuality:OQPSk:CMMax:LIMit[?]				Limits
CONFigure:MODulation:MQuality:HPSK:CMMax:LIMit[?]				
CONFigure:MODulation:MQuality:QPSK:CMMax:LIMit[?]				
<Waveform Quality Limit>, <Carrier Freq. Limit>, <Transmit Time Error Limit>, <Carrier Feedthrough Limit>, <Sideband Suppr. 1>, <Sideband Suppr. 2>, <Sideband Suppr. 3>, <Sideband Suppr. 4>				
<Waveform Quality Limit>	Description of parameters	Def. value	Def. unit	
0.0 to 1.0 OFF ON,	Limit for waveform quality No waveform quality limit check Limit check on, last setting re-activated	0.944	–	
<Carrier Freq. Limit>	Description of parameters	Def. value	Def. unit	
0 Hz to 1000 Hz OFF ON,	Upper limit for carrier frequency error No carrier frequency error limit check Limit check on, last setting re-activated	300	Hz	
<Transmit Time Error Limit>	Description of parameters	Def. value	Def. unit	
0.0 s to 0.00001 s OFF ON,	Upper limit for transmit time error No transmit time error limit Limit check on, last setting re-activated	0.000001	s	
<Carrier Feedthrough Limit>	Description of parameters	Def. value	Def. unit	
–120 dB to –20 dB OFF ON,	Upper limit for carrier feedthrough No carrier feedthrough limit check Limit check on, last setting re-activated	–25	dB	
<RESERVED>	Description of parameters	Def. value	Def. unit	
,	Reserved for future setting	–	–	
<Sideband Suppr. 1>	Description of parameters	Def. value	Def. unit	FW vers.
–128 dB to 0 dB OFF ON,	Limit for sideband suppression at frequ. offset 1 No sideband suppress limit check Limit check on, last setting re-activated	–43	dB	V3.05
<Sideband Suppr. 2>	Description of parameters	Def. value	Def. unit	FW vers.
–128 dB to 0 dB OFF ON,	Limit for sideband suppression at frequ. offset 2 No sideband suppress limit check Limit check on, last setting re-activated	–54	dB	V3.10
<Sideband Suppr. 3>	Description of parameters	Def. value	Def. unit	FW vers.
–128 dB to 0 dB OFF ON,	Limit for sideband suppression at frequ. offset 3 No sideband suppress limit check Limit check on, last setting re-activated	–43	dB	V3.10
<Sideband Suppr. 4>	Description of parameters	Def. value	Def. unit	FW vers.
–128 dB to 0 dB OFF ON	Limit for sideband suppression at frequ. offset 4 No sideband suppress limit check Limit check on, last setting re-activated	–43	dB	V3.10
Description of command				
This command defines limits for <i>Current</i> and <i>Max/Min</i> quantities describing the modulation quality. The values <Sideband Suppr. 2>, <Sideband Suppr. 3>, <Sideband Suppr. 4> are only available if the sideband suppression extension is enabled; see command XTND:MODulation:MQuality:<Application>:SBSuppress.				

CONFigure:MODulation:MQuality[:OQPSk]:AVERage:LIMit[?] CONFigure:MODulation:MQuality:HPSK:AVERage:LIMit[?] CONFigure:MODulation:MQuality:QPSK:AVERage:LIMit[?] <Waveform Quality Limit>, <Carrier Freq. Limit>, <Transmit Time Error Limit>, <Carrier Feedthrough Limit>, <Sideband Suppr. 1>, <Sideband Suppr. 2>, <Sideband Suppr. 3>, <Sideband Suppr. 4>				Limits
<Waveform Quality Limit>	Description of parameters	Def. value	Def. unit	
0.0 to 1.0 OFF ON,	Limit for waveform quality No waveform quality limit check Limit check on, last setting re-activated	0.944	–	
<Carrier Freq. Limit>	Description of parameters	Def. value	Def. unit	
0 Hz to 1000 Hz OFF ON,	Upper limit for carrier frequency error No carrier frequency error limit check Limit check on, last setting re-activated	300	Hz	
<Transmit Time Error Limit>	Description of parameters	Def. value	Def. unit	
0.0 s to 0.00001 s OFF ON,	Upper limit for transmit time error No transmit time error limit Limit check on, last setting re-activated	0.000001	s	
<Carrier Feedthrough Limit>	Description of parameters	Def. value	Def. unit	
–120 dB to –20 dB OFF ON,	Upper limit for carrier feedthrough No carrier feedthrough limit check Limit check on, last setting re-activated	–25	dB	
<RESERVED>	Description of parameters	Def. value	Def. unit	
,	Reserved for future setting	–	–	
<Sideband Suppr. 1>	Description of parameters	Def. value	Def. unit	FW vers.
–128 dB to 0 dB OFF ON,	Limit for sideband suppression at frequ. offset 1 No sideband suppress limit check Limit check on, last setting re-activated	–43	dB	V3.05
<Sideband Suppr. 2>	Description of parameters	Def. value	Def. unit	FW vers.
–128 dB to 0 dB OFF ON,	Limit for sideband suppression at frequ. offset 2 No sideband suppress limit check Limit check on, last setting re-activated	–54	dB	V3.05
<Sideband Suppr. 3>	Description of parameters	Def. value	Def. unit	FW vers.
–128 dB to 0 dB OFF ON,	Limit for sideband suppression at frequ. offset 3 No sideband suppress limit check Limit check on, last setting re-activated	–43	dB	V3.05
<Sideband Suppr. 4>	Description of parameters	Def. value	Def. unit	FW vers.
–128 dB to 0 dB OFF ON	Limit for sideband suppression at frequ. offset 4 No sideband suppress limit check Limit check on, last setting re-activated	–43	dB	V3.05
Description of command				
This command defines limits for the <i>Average</i> quantities describing the modulation quality. The values <Sideband Suppr. 2>, <Sideband Suppr. 3>, <Sideband Suppr. 4> are only available if the sideband suppression extension is enabled; see command XTND:MODulation:MQuality:<Application>:SBSuppress.				

DEFAult:MODulation:MQuality[:OQPSk]:CMMax:LIMit[?]		Default Settings		
DEFAult:MODulation:MQuality:HPSK:CMMax:LIMit[?]				
DEFAult:MODulation:MQuality:QPSK:CMMax:LIMit[?]				
<Enable>				
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON	The parameters are set to their default values	ON	–	V3.05
OFF	Some or all parameters are not set to default			
Description of command				
<p>If used as a setting command with the parameter <i>ON</i>, this command sets all parameters of the MODulation:MQuality*:LIMit subsystem to their default values (the setting <i>OFF</i> results in an error message). The length of the parameter lists in the CONFigure:MODulation:MQuality...CMMax:LIMit commands is not affected.</p> <p>If used as a query, the command returns whether all parameters are set to their default values (<i>ON</i>) or not (<i>OFF</i>).</p> <p>The keyword <i>CMMax</i> refers to the <i>Current</i> and <i>Max./Min.</i> limits.</p>				

DEFAult:MODulation:MQuality[:OQPSk]:AVERage:LIMit[?]		Default Settings		
DEFAult:MODulation:MQuality:HPSK:AVERage:LIMit[?]				
DEFAult:MODulation:MQuality:QPSK:AVERage:LIMit[?]				
<Enable>				
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON	The parameters are set to their default values	ON	–	V3.05
OFF	Some or all parameters are not set to default			
Description of command				
<p>If used as a setting command with the parameter <i>ON</i>, this command sets all parameters of the MODulation:MQuality*:LIMit subsystem to their default values (the setting <i>OFF</i> results in an error message). The length of the parameter lists in the CONFigure:MODulation:MQuality...AVERage:LIMit commands is not affected.</p> <p>If used as a query, the command returns whether all parameters are set to their default values (<i>ON</i>) or not (<i>OFF</i>).</p> <p>The keyword <i>CMMax</i> refers to the <i>Current</i> and <i>Max./Min.</i> limits.</p>				

DEFAult:MODulation:MQuality:LIMit[?]		Default Settings		
<Enable>				
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON	The parameters are set to their default values	ON	–	V3.05
OFF	Some or all parameters are not set to default			
Description of command				
<p>If used as a setting command with the parameter <i>ON</i>, this command sets all parameters of the subsystem MODulation:LIMit to their default values (the setting <i>OFF</i> results in an error message). The length of the parameter lists in the CONFigure:MODulation:MQuality...LIMit commands is not affected.</p> <p>If used as a query the command returns whether all parameters are set to their default values (<i>ON</i>) or not (<i>OFF</i>).</p>				

Measured Values – Subsystem MODulation

The subsystem *MODulation* measures and returns the modulation parameters and compares them with the tolerance values. The subsystem corresponds to the various output elements in the measurement menu *Analyzer/Generator*.

READ[:SCALar]:MODulation:MQuality[:OQPSk]? READ[:SCALar]:MODulation:MQuality:HPSK? READ[:SCALar]:MODulation:MQuality:QPSK?					Start single shot measurement and return results
FETCh[:SCALar]:MODulation:MQuality[:OQPSk]? FETCh[:SCALar]:MODulation:MQuality:HPSK? FETCh[:SCALar]:MODulation:MQuality:QPSK?					Read out measurement results (unsynchronized)
SAMPlE[:SCALar]:MODulation:MQuality[:OQPSk]? SAMPlE[:SCALar]:MODulation:MQuality:HPSK? SAMPlE[:SCALar]:MODulation:MQuality:QPSK?					Read out measurement results (synchronized)
Returned values	Value range	Def. value	Def. unit	FW vers.	
MS Power (x3), Waveform Quality (x3), Carrier Frequency Error (x3), Transmit Time Error (x3), Carrier Feedthrough (x3), RESERVED (x3), Lower Sideband Supp. 1 (x3), Upper Sideband Supp. 1 (x3) Lower Sideband Supp. 2 (x3), Upper Sideband Supp. 2 (x3) Lower Sideband Supp. 3 (x3), Upper Sideband Supp. 3 (x3) Lower Sideband Supp. 4 (x3), Upper Sideband Supp. 4 (x3) Out of Tolerance	-120.0 dBm to -33.0 dBm 0.0 to +1.0 -10.0 Hz to 0.0 Hz 0.0 to 0.00001 -120.0 dB to -20.0 dB -120 dB to 10 dB -120 dB to 10 dB -120 dB to 10 dB -120 dB to 10 dB -120 dB to 10 dB -120 dB to 10 dB -120 dB to 10 dB -120 dB to 10 dB 0% to 100 %	NAN NAN NAN NAN NAN NAN NAN NAN NAN NAN NAN NAN NAN NAN	dBm - Hz s dB dB dB dB dB dB dB dB dB %	V3.05	
Description of command					
These commands are always queries. They start a modulation measurement and output all scalar measurement results (see Chapter 4). The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i> , the <i>Average</i> , and the <i>MMax</i> value. Sideband Supp. 1 to Sideband Supp. 4 denotes the sideband suppression at offset frequencies 1 to 4; see commands <code>CONFIgure:MODulation:MQuality:<Application>:CONTRol:FOFFset:SBSuppress:ACP<nr>[?]</code> . The sideband suppression values 2 to 4 are available only if the measurement is enabled; see commands <code>XTND:MODulation:MQuality:<Application>:SBSuppress</code> .					

CALCulate[:SCALar]:MODulation:MQuality[:OQPSk]:MATChing:LIMIt?		Limit Matching														
CALCulate[:SCALar]:MODulation:MQuality:HPSK:MATChing:LIMIt?																
CALCulate[:SCALar]:MODulation:MQuality:QPSK:MATChing:LIMIt?																
Returned values	Value range	Def. value	Def. unit	FW vers.												
Waveform Quality (x3), Carrier Frequency Error (x3), Tansmit Time Error (x3), Carrier Feedthrough (x3), RESERVED (x3), Lower Sideband Supp. 1 (x3), Upper Sideband Supp. 1 (x3) Lower Sideband Supp. 2 (x3), Upper Sideband Supp. 2 (x3) Lower Sideband Supp. 3 (x3), Upper Sideband Supp. 3 (x3) Lower Sideband Supp. 4 (x3), Upper Sideband Supp. 4 (x3)	For all measured values: NMAU NMAL INV OK	INV INV INV INV INV INV INV INV INV INV INV	– – – – – – – – – – –	V3.05												
Description of command																
<p>This command is always a query. It indicates whether and in which way the error limits for the scalar measured values (see above command) have been exceeded. The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i>, the <i>Average</i>, and the <i>MMax</i> value. Sideband Supp. 1 to Sideband Supp. 4 denotes the sideband suppression at offset frequencies 1 to 4; see commands <code>CONFigure:MODulation:MQuality:<Application>:CONTrol:FOFFset:SBSuppress:ACP<nr>[?]</code>. The sideband suppression values 2 to 4 are available only if the measurement is enabled; see commands <code>XTND:MODulation:MQuality:<Application>:SBSuppress</code>.</p> <p>The following messages may be output for all measured values:</p> <table border="0"> <tr> <td>NMAU</td> <td>Underflow of tolerance value</td> <td><i>not matching, underflow</i></td> </tr> <tr> <td>NMAL</td> <td>Tolerance value exceeded</td> <td><i>not matching, overflow</i></td> </tr> <tr> <td>INV</td> <td>Measurement invalid</td> <td><i>invalid</i></td> </tr> <tr> <td>OK</td> <td>all tolerances matched</td> <td></td> </tr> </table>					NMAU	Underflow of tolerance value	<i>not matching, underflow</i>	NMAL	Tolerance value exceeded	<i>not matching, overflow</i>	INV	Measurement invalid	<i>invalid</i>	OK	all tolerances matched	
NMAU	Underflow of tolerance value	<i>not matching, underflow</i>														
NMAL	Tolerance value exceeded	<i>not matching, overflow</i>														
INV	Measurement invalid	<i>invalid</i>														
OK	all tolerances matched															

POWER Measurements

The subsystem *POWER* measures the power of the received RF signal. The subsystem corresponds to the *Power* menu and the popup menu *Power Configuration*.

Note: *The Narrow Band Power (Npower) application is not part of the POWER subsystem but corresponds to the NPOWER subsystem described in section [Narrow-Band Power – NPOWER](#) on p. 6.38 ff.*

POWER:XSLot

The subsystem *POWER:XSLot* controls the *Power vs. Frame* measurement. It corresponds to the measurement menu *Power*, application *Power vs. Frame*, and the sections in the popup menu *Power Configuration* that are related to the *Power vs. Frame* application.

Note: *The POWER:XSLot measurement must be carried out with manual RF Max. Level setting ([SENSe:]LEVel:MODE MANual) and with an appropriate trigger source, e.g. IF power trigger (TRIGger[:SEquence]:SOURCE IFPower). An application example is reported in Chapter 2.*

INITiate:POWER:XSLot	Start new measurement	⇒ RUN
ABORT:Power:XSLot	Abort running measurement and switch off	⇒ OFF
STOP:POWER:XSLot	Stop measurement after current stat. cycle	⇒ STOP
CONTinue:POWER:XSLot	Next measurement step (only <i>stepping mode</i>)	⇒ RUN
Description of command		FW vers.
These commands have no query form. They start or stop the measurement, setting it to the status indicated in the top right column.		V3.50

CONFigure:POWER:XSLot:EREPorting <Mode>		Event Reporting		
<Mode>	Description of parameters	Def. value	Def. unit	FW vers.
SRQ 	Service request	OFF	–	V3.50
SOPC 	Single operation complete			
SRSQ 	SRQ and SOPC			
OFF	No reporting			
Description of command				
This command defines the events generated when the measurement is terminated or stopped (<i>event reporting</i> , see chapter 5 of CMU manual).				

FETCH[:SCALar]:POWER:XSLot:STATus?		Measurement Status		
Return	Description of parameters	Def. value	Def. unit	FW vers.
OFF 	Measurement in the <i>OFF</i> state (*RST or ABORT)	OFF	–	V3.50
RUN 	Running (after INITiate, CONTinue or READ)			
STOP 	Stopped (STOP)			
ERR 	OFF (could not be started)			
STEP 	Stepping mode (<stepmode>=STEP)			
RDY,	Stopped according to repetition mode and stop condition			
1 to 10000 	Counter for current statistics cycle			
NONE	No counting mode set	NONE	–	
Description of command				
This command is always a query. It returns the status of the measurement (see chapters 3 and 5 of CMU manual).				

Subsystem POWER:XSLot:CONTROL

The subsystem *Power:XSLot:CONTROL* controls the *Power vs. Frame* measurement. It corresponds to the parameters in the popup menu *Power Configuration* that define the scope of the *Power vs. Frame* measurement and the maximum RF input level.

CONFigure:POWER:XSLot:CONTROL:REPetition <Repetition>, <StopCondition>, <Stepmode>				Test Cycles
<Repetition>	Description of parameters	Def. value	Def. unit	
CONTInuous	Continuous measurement (<i>continuous</i> , until STOP or ABORT)	SING	–	
SINGleshot	Single measurement (<i>single shot</i> , until Status = RDY)			
1 to 10000	Multiple measurement (<i>counting</i> , until Status = STEP RDY)			
<StopCond>	Description of parameters	Def. value	Def. unit	
SONerror	Stop measurement in case of error (<i>stop on error</i>)	NONE	–	
NONE	Continue measurement even in case of error			
<Stepmode>	Description of parameters	Def. value	Def. unit	FW vers.
STEP	Interrupt measurement after each statistics cycle	NONE	–	V3.50
NONE	Continue measurement according to its rep. mode			
Description of command				
This command determines the number of statistics cycles and the stepping mode for the measurement.				
Note: For READ commands (READ:...), the <Repetition> parameter has no effect; the measurement is always stopped after a single shot.				

CONFigure:POWER:XSLot:CONTROL:PMWidth <Width>				Power Meas. Width
<Width>	Description of parameters	Def. value	Def. unit	FW vers.
0.50 ms to 10.00 ms	Power measurement width	10.00	ms	V3.50
Description of command				
This command defines the duration of the measurement interval in ms. The power meas. width must not exceed half of the step width (CONFigure:POWER:XSLot:CONTROL:SWIDTH); a lower value causes a settings conflict.				

CONFigure:POWER:XSLot:CONTROL:SCOut <Frames>				Step Count
<Frames>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 100	Number of frames measured per statistics cycle	50	(frames)	V3.50
Description of command				
This command defines the number of frames measured in one statistics cycle.				

CONFigure:POWER:XSLot:CONTROL:SWIDTH <Width>				Step Width
<Width>	Description of parameters	Def. value	Def. unit	FW vers.
1.00 ms to 30.00 ms	Step width in multiples of 0.25 ms.	20.00	ms	V3.50
Description of command				
This command defines the duration of a power step (frame), which is equal to the time difference between the beginning of two consecutive measurement intervals. The step width must be twice the power measurement width (CONFigure:POWER:XSLot:CONTROL:SWIDTH) at minimum; if a smaller value is set, the power measurement width is adapted.				

CONFigure:POWer:XSLot:CONTRol:SDElay <Slots>				Step Delay	
<Slots>	Description of parameters	Def. value	Def. unit	FW vers.	
0 to 99	Step delay	0	(frames)	V3.50	
Description of command					
This command defines a delay time (number of frames) between the trigger time and the start of the first measurement interval.					

CONFigure:POWer:XSLot:CONTRol:SINterval <Deviation_1>, <Step_No_1>, ... <Deviation_5>, <Step_No_5>			Step Interval (complete table)		
<Deviation>	Description of parameters	Def. value	Def. unit	FW vers.	
-70.0 dB to +70.0 dB OFF	Deviation	-30.0 dB for <Deviation_1> Off for all other deviations	dB	V3.50	
<Step_No>	Description of parameters	Def. value	Def. unit	FW vers.	
1 to 99 OFF ^{*)}	@ Step Number	25 for <Step_No_1> Off for all other steps	(frames)	V3.50	
Description of command					
This command defines the <i>RF Max. Level</i> to be used for each of the measured power steps and the first step in each step interval. All levels are relative to the <i>RF Max. Level</i> defined by means of [SENSe:]LEVel:MAXimum.					
*) The step numbers must be in ascending order. Inconsistent entries will be auto-corrected.					

CONFigure:POWer:XSLot:CONTRol:SINterval:I<nr> <Deviation>, <Step_No>			Step Interval (single interval)		
<nr>	Description of parameters	Def. value	Def. unit	FW vers.	
1 to 5	Numeric suffix for the step interval no.	1	–	V3.50	
<Deviation>	Description of parameters	Def. value	Def. unit	FW vers.	
-70.0 dB to +70.0 dB OFF	Deviation	-30.0 dB for <nr> = 1 Off for all other deviations	dB	V3.50	
<Step_No>	Description of parameters	Def. value	Def. unit	FW vers.	
1 to 99 OFF ^{*)}	@ Step Number	25 for <nr> = 1 Off for all other steps ^{*)}	(frames)	V3.50	
Description of command					
This command defines the <i>RF Max. Level</i> to be used for each of the measured power steps and the first step in each step interval. All levels are relative to the <i>RF Max. Level</i> defined by means of [SENSe:]LEVel:MAXimum.					
*) The step numbers must be in ascending order. Inconsistent entries will be auto-corrected. As a consequence, CONF:POW:XSL:CONT:SINT:I5 -30.00,1 sets the deviation in the step intervals 1 to 4 to OFF so that the <i>RF Max. Level</i> is constant for all steps.					

CONFigure:POWer:XSLot:CONTRol:SINterval:DEviation <Deviation_1>, ... <Deviation_5>			Step Interval – Deviation (complete table)		
<Deviation>	Description of parameters	Def. value	Def. unit	FW vers.	
-70.0 dB to +70.0 dB OFF	Deviation	-30.0 dB for <Deviation_1> Off for all other deviations	dB	V3.50	
Description of command					
This command defines the <i>RF Max. Level</i> to be used for each of the measured power steps. All levels are relative to the <i>RF Max. Level</i> defined by means of [SENSe:]LEVel:MAXimum.					

CONFigure:POWER:XSLot:CONTrol:SINterval:DEVIation:I<nr>		Step Interval – Deviation(single interval)		
<Deviation>				
<nr>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 5	Numeric suffix for the step interval no.	1	–	V3.50
<Deviation>	Description of parameters	Def. value	Def. unit	FW vers.
–70.0 dB to +70.0 dB OFF	Deviation	–30.0 dB for <nr> = 1 Off for all other deviations	dB	V3.50
Description of command				
This command defines the <i>RF Max. Level</i> to be used for each of the measured power steps. All levels are relative to the <i>RF Max. Level</i> defined by means of [SENSe:]LEVel:MAXimum.				

CONFigure:POWER:XSLot:CONTrol:SINterval:SNUMBER		@ Step Number (complete table)		
<Step_No_1>, ... <Step_No_5>				
<Step_No>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 99 OFF^{*)}	@ Step Number	25 for <Step_No_1> Off for all other steps	(frames)	V3.50
Description of command				
This command defines the first step in each step interval.				
*) The step numbers must be in ascending order. Inconsistent entries will be auto-corrected.				

CONFigure:POWER:XSLot:CONTrol:SINterval:SNUMBER:I<nr>		@ Step Number (single interval)		
<Step_No>				
<nr>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 5	Numeric suffix for the step interval no.	1	–	V3.50
<Step_No>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 99 OFF^{*)}	@ Step Number	25 for <nr> = 1 Off for all other steps ^{*)}	(frames)	V3.50
Description of command				
This command defines the first step in each step interval.				
*) The step numbers must be in ascending order. Inconsistent entries will be auto-corrected.				

DEFault:POWER:XSLot:CONTrol <Enable>		Default Settings		
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	The parameters are set to their default values The parameters differ from the default values (partially or totally)	ON	–	V3.50
Description of command				
If used as a setting command with the parameter <i>ON</i> this command sets all parameters of the subsystem to their default values (the setting <i>OFF</i> causes an error message). If used as a query the command returns whether all parameters are set to their default values (<i>ON</i>) or not (<i>OFF</i>).				

Subsystem POWER:XSLot?

The subsystem *Power:XSLot* measures power versus frame and returns the results. The subsystem corresponds to the measurement menu *Power vs. Frame*.

		Power vs. Frame Results		
READ[:SCALar]:POWer:XSLot:CURRent?		Start single shot measurement and return results		
FETCh[:SCALar]:POWer:XSLot:CURRent?		Read out measurement results (unsynchronized)		
SAMPlE[:SCALar]:POWer:XSLot:CURRent?		Read out measurement results (synchronized)		
<i>Returned Values</i>	Description of parameters	Def. value	Def. unit	FW vers.
-100 dBm to 100 dBm,	Avg. power in frame 0,	NAN,	dBm,	V3.50
...	...,	...,	...,	
-100 dBm to 100 dBm	Avg. power in frame Slot 99 ^{*)}	NAN	dBm	
Description of command				
<p>These commands are always queries. They start a measurement and return all measurement results. The returned list contains the average burst power of the mobile phone in up to 100 consecutive frames.</p> <p>^{*)} The total number of frames measured and the number of output values is given by the step count: CONFigure:POWer:XSLot:CONTRol:SCount.</p>				

Common Measurements and Command Groups

The commands for the measurement groups in this section are identical or almost identical in both test modes. Minor differences between *Non Signalling* and *Signalling* commands are possible; they will be pointed out throughout the section.

Note: **Measurements and signalling states**

To perform any kind of measurement and obtain a meaningful result, an appropriate test setup is required (see application examples in chapter 2 of this manual). Consequently, if the measurements reported in this section are performed in Signalling mode, the Call Established (CEST) signalling state must be reached before any of the commands retrieving test results (READ...?, FETCh...?, SAMPlE...?, or CALCulate...LIMit?) can be used. Test configurations, however, can be defined any time.

Exception: *The wideband power (WPOWer) does not involve any signalling. It can be measured irrespective of the current signalling state.*

Option Query

The *Options* subsystem contains the commands for querying information on the instrument and the available options. It corresponds to the *Options* tab in the *Setup* menu opened via the *SETUP* key on the front panel.

SYSTem:OPTions:INFO:CURRent?		Device Info		
Response	Def. value	Default unit	FW vers.	
Example: Rohde&Schwarz,CMU 200-1100.0008.02,840675/018, V3.10C:SP02 2002-10-05"CDMA2K450MS_Sig"	–	–	V3.10	
Command description				
This command returns information on the device comprising the manufacturer, model, serial number and firmware version of the current function group. This command is always a query.				

SYSTem:VERSion:SW:MMI?		MMI Software Version		
Response	Def. Value	Default unit	FW vers.	
Example: "1.00C[3.40:SP00]"	–	–	V3.20	
Command description				
This command returns information about the current version of the CDMA2k MMI module. This command may be helpful for driver development as the MMI module determines the GPIB command set. This command is always a query.				

Partial Reset

The *RESet* subsystem restores the (factory) default values for the current function group and test mode. It is similar to the *Reset* menu opened via the *RESET* key on the front panel.

SYSTem:RESet:CURRent	Partial Reset
Command description	FW vers.
This command sets all parameters of the current function group and test mode to default values. The command is available in all function groups. In contrast to the <i>Reset</i> menu the command restores the default values defined for remote control operation. In cases where remote and manual control use distinct settings (e.g. the repetition mode for many measurements), the manual control settings are left unchanged.	V3.10

Configuration File Management – System MMEMoRy

The *MMEMoRy* system provides mass storage capabilities for the CMU. The functionality of this system is included in the *Data* menu; see CMU200/300 operating manual.

The mass storage of the CMU may be internal or external. The internal mass storage device is a section on the internal hard disk that is reserved for mass storage (directory *c:\temp*). The external mass storage device is either a floppy disk or a PCMCIA memory card, depending on the instrument configuration. The *<msus>* (mass storage unit specifier) parameter in the *MMEMoRy* commands denotes the root directory of the *INTernal* or *EXTernal* mass storage device.

The *<FileName>* parameter is a string. The contents of the string may contain characters for specifying subdirectories, e.g. "*\TEMP\TRASH\test.txt*" for the file named *test.txt* in the *TEMP\TRASH* subdirectory of the root directory or "*TEMP\TRASH\test.txt*" for the file named *test.txt* in the *TEMP\TRASH* subdirectory of the current directory, to be queried with the base system command *MMEMoRy:DIRectory [:CURRent]?*. The file name itself may contain the period as a separator for extensions.

MMEMoRy:SAVE:CURRent <FileName> [,<msus>]				
Save configurations in current function group and test mode				
Parameters	Parameter description	Def. value	Def. unit	FW vers.
"<FileName>", INTernal EXTernal	Name of the config. file to be created Storage device of the config. file	– INTernal	– –	V3.10
Command description				
This command saves the configuration of the current function group and test mode to a configuration file. A "?" in the specified file name will be replaced by current numbers that are automatically incremented, starting with zero. The auto-increment function overwrites an existing file with a "9" in its file name. For instrument settings that may be different in manual and remote control (e.g. the repetition mode for many measurements) the manual setting is saved. The command is available in all function groups. This command is CMU-specific.				

MMEMoRy:RECall:CURRent <FileName> [,<msus>]				
Recall configurations in current function group and test mode				
Parameters	Parameter description	Def. value	Def. unit	FW vers.
"<FileName>", INTernal EXTernal	Name of the config. file to be recalled Storage device of the config. file	– INTernal	– –	V3.10
Command description				
This command recalls the configuration of the current function group and test mode from a configuration file. The command is available in all function groups. This command is CMU-specific.				

I/Q-IF Interface

The subsystem *IQIF* configures the signal paths for I/Q and IF signals provided by option CMU-B17, *I/Q and IF Interfaces*. It corresponds to the *I/Q-IF* tab of the *Connection Control* menu.

Hint: *How to make sense out of parameter names*

In all path configurations except bypass, both the I/Q and IF output are connected (to either the RF Unit, the Digital Unit or one of the I/Q-IF inputs). The paths differ in the connection of the input branches: The qualifier IO denotes a connected input (with connected output), XO denotes a disconnected input (with connected output). Many parameters of the IQIF commands are composed of two IO/XO qualifiers, the first one standing for the IF signal, the second for the I/Q signal.

Example: *The parameter IOXO denotes a connected IF input and a disconnected IF output, while both output branches are connected.*

For more information see Chapter 4 and the application examples in the CMU200/300 operating manual.

CONFigure:IQIF:RXTXcombined <Scenario>			I/Q-IF	
<Scenario>	Description of parameters	Def. value	Def. unit	FW vers.
BYP	RX/TX Bypass, RXPath = BYP, TXPath = BYP	BYP	–	V3.10
BYIQ	Bypass w. I/Q-OF OUT, RXPath = TXPath =BYIQ			
XOIO	I/Q IN/OUT, RXPath = TXPath = XOIO			
IOIO	IF IN_I/Q IN/OUT, RXPath = TXPath = IOIO			
IOXO	IF IN/OUT, RXPath = TXPath = IOXO			
FPAT	Fading Path, RXPath = BYP, TXPath = XOIO			
UDEF	User-defined scenario, can not be set but may be returned by the query CONF:IQIF:RXTX?			
Description of command				
This command selects the I/Q-IF test scenario, overwriting the current RX and TX path settings (see commands CONFigure:IQIF:RXPath and CONFigure:IQIF:TXPath below). Six different predefined test scenarios with fixed RX and TX path are provided. Additional scenarios may be defined by selecting any other combination of RX and RX paths.				
Note: <i>UDEF is not provided as a setting parameter. If the RX/TX path combination defined via CONFigure:IQIF:RXPath and CONFigure:IQIF:TXPath doesn't correspond to any of the predefined scenarios, then a user-defined scenario is set implicitly, i.e. the query CONF:IQIF:RXTX? returns the value UDEF.</i>				

CONFigure:IQIF:RXPath <Path>			RX Path	
<Path>	Description of parameters	Def. value	Def. unit	FW vers.
BYP	Bypass	BYP	–	V3.10
BYIQ	Bypass w. I/Q-IF OUT			
XOIO	I/Q IN/OUT			
IOIO	IF IN_I/Q IN/OUT			
IOXO	IF IN/OUT			
Description of command				
This command selects the RX signal path, leaving the TX path (see command CONFigure:IQIF:TXPath below) unchanged but adapting the I/Q-IF test scenario to the new RX/TX path combination: If the combination corresponds to a predefined scenario, then CONFigure:IQIF:RXTXcombined is set to the predefined scenario; otherwise it is set to UDEF.				

CONFigure:IQIF:TXPath <Path>				TX Path
<Path>	Description of parameters	Def. value	Def. unit	FW vers.
BYP	Bypass	BYP	–	V3.10
BYIQ	Bypass w. I/Q-IF OUT			
XOIO	I/Q IN/OUT			
IOIO	IF IN_I/Q IN/OUT			
IOXO	IF IN/OUT			
Description of command				
This command selects the TX signal path, leaving the RX path (see command <code>CONFigure:IQIF:RXPath</code> above) unchanged but adapting the I/Q-IF test scenario to the new RX/TX path combination: If the combination corresponds to a predefined scenario, then <code>CONFigure:IQIF:RXTXcombined</code> is set to the predefined scenario; otherwise it is set to <code>UDEF</code> .				

[SENSe:]IQIF:LEVel? <TX Level>				IF Level
<TX Level>	Description of parameters	Def. value	Def. unit	FW vers.
< 0 dB	IF level	NAN	dBFS	V3.60
Description of command				
This command is always a query and returns the IF output level in the TX path relative to the maximum IF output level (PEP) quoted in the data sheet. The value is equal to the I/Q output level in the TX path relative to the maximum I/Q output voltage quoted in the data sheet.				

Symbolic Status Event Register Evaluation

The following commands are used to retrieve the events reported in the CDMA2000 function groups; see section *Symbolic Status Event Register Evaluation* in Chapter 5 of the CMU operating manual. The commands are available in *Non Signalling* and *Signalling* mode.

STATus:OPERation:SYMBOLic:ENABLE <Event>{,<Event>}		Symbolic status evaluation		
Parameter list	Parameter description	Def. Value ¹	Default Unit	FW vers.
<Event>{,<Event>} NONE	List of symbols for events to be reported No event reported	NONE	–	V3.05
Command description				
This command enables event reporting for one or several events in a CDMA2000 function group, i.e. it sets the corresponding bits in the <code>STATus:OPERation:CMU:SUM<nr>:CMU<nr_event>:ENABLE</code> register (<nr> = 1 2, <nr_event> denotes the current function group) and in all sum registers up to the status byte. The events and the corresponding symbols for the function group are listed in Chapter 5 (see section <i>Status Registers</i>). The symbols may be entered in arbitrary order.				

STATus:OPERation:SYMBOLic[:EVENT]?		Symbolic status evaluation		
Response	Parameter description	Def. Value ²	Default Unit	FW vers.
NONE <Event>{,<Event>}	No event reported List of reported events	NONE	–	V3.05
Command description				
This command is always a query. It reads the events reported in a CDMA2000 function group and deletes these events in the <code>STATus:OPERation:CMU:SUM<nr>:CMU<nr_event>:EVENT</code> register as well as in all sum registers.				

¹ The default values quoted in this command are achieved after a `STATus:PRESet` command. `*RST` does not overwrite the entries in the status registers; see section *Reset Values of the Status Reporting Systems* in chapter 5 of the CMU operating manual.

² The default values quoted in this command are achieved after a `*CLS` command. `*RST` does not overwrite the entries in the status registers; see section *Reset Values of the Status Reporting Systems* in chapter 5 of the CMU operating manual.

Extended Event Register

The following commands are used to read the extended event register; see section *Status Reporting System* in Chapter 5. The commands are available in *Non Signalling* and *Signalling* mode.

XTND:STATus:OPERation:FGRegister[:EVENT]?		Extended event register evaluation		
<i>Response</i>	Parameter description	Def. Value ³	Default Unit	FW vers.
0 to 32767	Event part of the extended STATus:OPERation register	–	–	V3.60
Command description				
This command is always a query. It reads and deletes the extended events reported in a CDMA2000 function group.				

XTND:STATus:OPERation:SYMBOLic[:EVENT]?		Symbolic extended event register evaluation		
<i>Response</i>	Parameter description	Def. Value ⁴	Default Unit	FW vers.
NONE <Event>{,<Event>}	No event reported List of reported events	NONE	–	V3.60
Command description				
This command is always a query. It reads and deletes the extended events reported in a CDMA2000 function group.				

RF Selectivity

The following command corresponds to the *RF Selectivity* parameter in the *Misc.* tab of the *Connection Control* menu. The command is available in *Non Signalling* and *Signalling* mode.

CONFigure:RFSelectiv <Mode>		RF Selectivity		
<i>Response</i>	Parameter description	Def. Value	Default Unit	FW vers.
WIDE NARRow	Normal filter, for all TX measurements Recommended in case of interferences from outside the band (not for <i>Spectrum</i> measurements)	WIDE	–	V3.60
Command description				
This command selects the bandwidth of the analog receiver filter.				

³ *RST does not overwrite the entries in the status registers; see section *Reset Values of the Status Reporting Systems* in chapter 5 of the CMU operating manual.

⁴ The default values quoted in this command are achieved after a *CLS command. *RST does not overwrite the entries in the status registers; see section *Reset Values of the Status Reporting Systems* in chapter 5 of the CMU operating manual.

Wideband Power – WPOWER

The subsystem *WPOWER* measures the power of the signal transmitted by the mobile phone using a wideband filter. It corresponds to the softkey *Wideband Power* in the *Connect. Control* menu.

INITiate:WPOWER	Start new measurement	⇒ <i>RUN</i>
ABORt:WPOWER	Abort measurement and switch off	⇒ <i>OFF</i>
STOP:WPOWER	Stop measurement	⇒ <i>STOP</i>
CONTInue:WPOWER	Next measurement step (only <i>counting mode</i>)	⇒ <i>RUN</i>
Description of command		FW vers.
These commands have no query form. They start or stop the measurement, setting it to the status given in the top right column.		1.15 ⁵

CONFigure:WPOWER:EREPorting <Mode>		Event Reporting		
<Mode>	Description of parameters	Def. value	Def. unit	FW vers.
SRQ 	Service request	OFF	–	1.17
SOPC 	Single operation complete			
SRSQ 	SRQ and SOPC			
OFF	No reporting			
Description of command				
This command defines the events generated when the measurement is terminated or stopped (<i>event reporting</i> , see chapter 5 of CMU200 operating manual).				

FETCH:WPOWER:STATus?		Measurement		
<i>Return</i>	Description of parameters	Def. value	Def. unit	FW vers.
OFF 	Measurement in the <i>OFF</i> state (* <i>RST</i> or <i>ABORt</i>)	OFF	–	1.15
RUN 	Running (after <i>INITiate</i> , <i>CONTInue</i> or <i>READ</i>)			
STOP 	Stopped (<i>STOP</i>)			
ERR 	<i>OFF</i> (could not be started)			
STEP 	Stepping mode (< <i>stepmode</i> >= <i>STEP</i>)			
RDY,	Stopped according to repetition mode and stop condition			
1 ... 10000 	Counter for current statistics cycle			
NONE	No counting mode set	NONE	–	
Description of command				
This command is always a query. It returns the status of the measurement (see chapters 3 and 5 of CMU operating manual).				

⁵ For firmware versions <V2.15, the keyword *WPOWER* is replaced by *SPOWER* in all commands.

CONFigure:WPOWER:CONtrol:REPetition <Repetition>,<StopCond>,<Stepmode>				Test cycles
<Repetition>	Description of parameters	Def. value	Def. unit	
CONTInuous SINGleshot 1 ... 10000	Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Multiple measurement (counting, until Status = STEP RDY)	SING	–	
<StopCond>	Description of parameters	Def. value	Def. unit	
SONerror NONE	Start measurement in case of error (stop on error) Continue measurement even in case of error	NONE	–	
<Stepmode>	Description of parameters	Def. value	Def. unit	FW vers.
STEP NONE	Interrupt measurement after each statistics cycle Continue measurement according to its rep. mode	NONE	–	1.15
Description of command				
This command determines the number of statistics cycles, the stop condition and the stepping mode for the measurement.				
Note: In the case of READ commands (READ:...), the <Repetition> parameter has no effect; the measurement is always stopped after a single shot.				

Measured Values – Subsystem WPOWER?

The subsystem WPOWER? retrieves the results of the wideband power measurement.

READ[:SCALar]:WPOWER?	Start single shot measurement and return results			
FETCh[:SCALar]:WPOWER?	Read out measurement results (unsynchronized)			
SAMPlE[:SCALar]:WPOWER?	Read out measurement results (synchronized)			
Return	Description of parameters	Def. value	Def. unit	FW vers.
–30.0dBm to +30.0 dBm	Maximum burst power (not averaged)	NAN	dBm	1.15
Description of command				
These commands are always queries. They start the measurement of the maximum burst power (peak burst power) and return the result.				

Narrow-Band Power – NPOWER

The subsystem *NPOWER* measures the Narrow Band Power using CDMA2000 receiver filters. It corresponds to the *NPower* application of the *Power* measurement.

The CMU measures the average, maximum and minimum power of the RF signal in a waveform interval. In addition to these *Current* values the minimum and maximum power in the entire measurement and the average of the average current values, referenced to a statistics cycle, is calculated (see section [Measured Values – Subsystem NPOWER](#) on p. 6.41 ff.). The measurement can be made with a variable number of samples, see command `CONFigure:NPOWER:CONTRol:CBSize`.

Control of measurement – Subsystem NPOWER

The subsystem *NPOWER* controls the narrow band power measurement. It corresponds to the *NPower* softkey in the *Power* measurement.

INITiate:NPOWER	Start new measurement	⇒	<i>RUN</i>
ABORt:NPOWER	Abort running measurement and switch off	⇒	<i>OFF</i>
STOP:NPOWER	Stop measurement after current stat. cycle	⇒	<i>STOP</i>
CONTinue:NPOWER	Next measurement step (<i>stepping mode</i>)	⇒	<i>RUN</i>
Description of command			FW vers.
These commands have no query form. They start and stop the power measurement, setting it to the status indicated in the top right column.			V3.05

CONFigure:NPOWER:EREPorting[?]		Event Reporting		
<Report Mode>				
<Report Mode>	Description of parameters	Def. value	Def. unit	FW vers.
SRQ 	Service request	OFF	–	V3.05
SOPC 	Single operation complete			
SRSQ 	SRQ and SOPC			
OFF	No reporting			
Description of command				
This command defines the events generated when the measurement is terminated or stopped (see <i>Event Reporting</i> in Chapter 5 of the CMU manual).				

FETCh[:SCALar]:NPOWER:STATus?		Measurement Status		
Return	Description of parameters	Def. value	Def. unit	FW vers.
OFF 	Measurement in the OFF state (*RST or ABORt)	OFF	–	–
RUN 	Running (after INITiate, CONTinue or READ)			
STOP 	Stopped (STOP)			
ERR 	OFF (could not be started)			
STEP 	Stepping mode (<stepmode>=STEP)			
RDY	Stopped according to repetition mode and stop condition			
1 to 10000 	Counter for current statistics cycle	NONE	–	–
NONE	No counting mode set			
1 to 1000	Counter for current evaluation period within a cycle	NONE	–	V3.05
NONE	Statistic count set to off			
Description of command				
This command is always a query. It returns the status of the measurement (see Chapters 3 and 5).				

Subsystem NPOWER:CONTROL

The subsystem *NPOWER:CONTROL* defines the repetition mode and statistic count of the measurement. It corresponds to the *Control* tab of the *Power Configuration* menu.

CONFigure:NPOWER:CONTROL:CBSize[?] <Samples>		Capture Buffer Size		
<Samples>	Description of parameters	Def. value	Def. unit	FW vers.
1024 to 32768 	Total number of samples	4096	–	V3.10
MINimum 	Sets the value to the range minimum			
MAXimum 	Sets the value to the range maximum			
DEF	Sets the value to the default setting			
Description of command				
This command specifies the number of samples acquired to calculate a single shot <i>NPOWER</i> result. A fixed oversampling factor of 4 is used so that the duration of the measurement interval (evaluation period) is proportional to the capture buffer size. Increasing the number of samples slows down the measurement but may be necessary to obtain meaningful results, because CDMA2000 signals typically show rapid variations in time and a large crest factor.				

CONFigure:NPOWER:CONTROL[?] <Statistics>, <Repetition>, <Stop Condition>, <Step Mode>		Scope of Measurement		
<Statistics>	Description of parameters	Def. value	Def. unit	
1 to 1000 	Number of bursts per statistics cycle	100	–	
MINimum 	Sets the value to the range minimum			
MAXimum 	Sets the value to the range maximum			
DEF,	Sets the value to the default setting			
<Repetition>	Description of parameters	Def. value	Def. unit	
1 to 10000 	Multiple measurement (counting, until Status = STEP RDY)	SING	–	
CONTinuous 	Continuous measurement (until STOP or ABORT)			
SINGleshot 	Single shot measurement (until Status = RDY)			
DEFault,	Sets the value to the default setting			
<Stop Condition>	Description of parameters	Def. value	Def. unit	
NONE 	Continue measurement even in case of error	NONE	–	
SON,	Stop measurement in case of error (<i>stop on error</i>)			
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
NONE 	Continue measurement according to its rep. mode	NONE	–	V3.05
STEP	Interrupt measurement after each statistics cycle			
Description of command				
This command combines the ...CONTROL:STATistics and the ...CONTROL:REPetition commands				

CONFigure:NPOWER:CONTROL:STATistics[?] <Statistics>		Statistic Count		
<Statistics>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 1000 	Number of bursts per statistics cycle	100	–	V3.05
MINimum 	Sets the value to the range minimum			
MAXimum 	Sets the value to the range maximum			
DEF	Sets the value to the default setting			
Description of command				
This command specifies the type of measured values and defines the number of bursts forming a statistics cycle.				

CONFigure:NPOWer:CONTRol:REPetition[?]				Test Cycles
<Repetition>, <Stop Cond>, <Step Mode>				
<Repetition>	Description of parameters	Def. value	Def. unit	
1 to 10000 	Multiple measurement (counting, until Status = STEP RDY)	SING	–	
CONTInuous 	Continuous measurement (until STOP or ABORT)			
SINGleshot 	Single shot measurement (until Status = RDY)			
DEFault,	Sets the value to the default setting			
<Stop Cond>	Description of parameters	Def. value	Def. unit	
NONE 	Continue measurement even in case of error	NONE	–	
SONerror 	Stop measurement in case of error (<i>stop on error</i>)			
DEFault,	Default value			
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
NONE 	Continue measurement according to its rep. mode	NONE	–	V3.05
STEP 	Interrupt measurement after each statistics cycle			
DEFault	Default value			
Description of command				
This command determines the number of statistics cycles for the measurement.				
Note: <i>In the case of READ commands (READ:...), the <Repetition> parameter has no effect; the measurement is always stopped after a single shot.</i>				

Measured Values – Subsystem NPOWER

The subsystem *NPOWER* determines and outputs the results of the Narrow Band Power measurements. It corresponds to the output fields in the *Power* measurement menu.

READ[:SCALar]:NPOWER? FETCh[:SCALar]:NPOWER? SAMPlE[:SCALar]:NPOWER?		Scalar results: Start single shot measurement and return results Read out measurement results (unsynchronized) Read out measurement results (synchronized)		
Returned values	Description	Def. value	Def. unit	FW vers.
Avg. Power of Current evaluation period, Min. Power of Current evaluation period, Max. Power of Current evaluation period, Avg. Power referenced to a stat. cycle, Min. Power of the entire measurement, Max. Power of the entire measurement	For all measurements		dBm	V3.05
	Scalar values returned		dBm	
			dBm	
			dBm	
			dBm	
Description of command				
These commands are always queries. They start a measurement and output all scalar measurement results.				

MODulation Measurements

The subsystem *MODulation:OVERview* measures the modulation parameters of the MS transmitter output signal. The subsystem corresponds to the measurement menu *Modulation* and the associated popup menu *Modulation Configuration*.

Common Settings – Subsystem MODulation:OEMP (O-QPSK and H-PSK)

The subsystem *MODulation:OEMP...* configures the generated RF signal and defines the tolerance values. The settings are valid for all *Modulation* measurement applications.

Measurement Environment – Subsystem MODulation:OEMP...:ENVIRONMENT

The subsystem *MODulation:OEMP:ENVIRONMENT...* configures the generated RF signal. It corresponds to the *Measurement Environment* section in the *Control* tab of the *Modulation Configuration* menu. The settings are used only if the environment is enabled; see `CONFigure:MODulation:OEMP:...:ENVIRONMENT:ENABLE`.



The environment settings are not available in Non Signalling mode: The measurement is always performed with the general Connection Control parameters.

CONFigure:MODulation:OEMP[:OQPSk]:ENVironment:ENABle[?]				Environment Enable	
CONFigure:MODulation:OEMP:HPSK:ENVironment:ENABle[?]					
<Enable>					
<Enable>	Description of parameters	Def. Value	Def. Unit	FW vers.	
ON OFF	Enable or disable environment	ON	–	V3.20	
Description of command				Sig. State	
These commands enable or disable the environment for the <i>Modulation</i> measurement applications.				All	

CONFigure:MODulation:OEMP[:OQPSk]:ENVironment:POWER:CDMA[?]				CDMA Power	
CONFigure:MODulation:OEMP:HPSK:ENVironment:POWER:CDMA[?]					
<CDMA Power>					
<CDMA Power>	Description of parameters	Def. value	Def. unit	FW vers.	
–120.0 dBm to –33.0 dBm –120.0 dBm to –16.0 dBm –100.0 dBm to +7.0 dBm DEFault MINimum MAXimum	RF1 OUT, 0 dB ext. atten RF2 OUT, 0 dB ext. atten RF3 OUT, 0 dB ext. atten Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum	–50.0	dBm	V3.20	
Description of command				Sig. State	
These commands determine the total CDMA output power (absolute value, in dBm) of the CMU. The CDMA Power value range depends on the RF input used and the external attenuation set. If option R&S CMU-U99 (<i>RF 1 with RF 2 Level Range</i>) is fitted, RF 1 takes on the level range of RF2.				All	

CONFigure:MODulation:OEMP[:OQPSk]:ENVironment:LEVel:FPICh[?]				F-PICH Level	
CONFigure:MODulation:OEMP:HPSK:ENVironment:LEVel:FPICh[?]					
<Pilot Level>					
<Pilot Level>	Description of parameters	Def. value	Def. unit	FW vers.	
–20.0 dB to –1.0 dB OFF	Pilot Level F-PICH switched off	–7.0	dB	V3.20	
Description of command				Sig. State	
These commands determine the level in the forward pilot channel of the CMU. The channel power is in units relative to the total CDMA power.				All	

CONFigure:MODulation:OEMP[:OQPSk]:ENVironment:LEVel:FFCH[?]				F-FCH Level	
CONFigure:MODulation:OEMP:HPSK:ENVironment:LEVel:FFCH[?]					
<FCH Level>					
<FCH Level>	Description of parameters	Def. value	Def. unit	FW vers.	
–20.0 dB to –1.0 dB OFF	FCH Level F-FCH switched off	–7.4	dB	V3.20	
Description of command				Sig. State	
These commands determines the level in the forward fundamental channel of the CMU. The channel power is in units relative to the total CDMA power.				All	

CONFigure:MODulation:OEMP[:OQPSk]:ENVironment:LEVel:FSCH:ZERO[?]				F-SCH0 Level
CONFigure:MODulation:OEMP:HPSK:ENVironment:LEVel:FSCH:ZERO[?]				
<SCH0 Level>				
<SCH0 Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to -1.0 dB OFF	F-SCH0 Level F-SCH0 switched off	-7	dB	V3.20
Description of command				Sig. State
These commands determine the level in the forward SCH0 channel of the CMU. The channel power is in units relative to the total CDMA power.				All

CONFigure:MODulation:OEMP[:OQPSk]:ENVironment:LEVel:FSCH:ONE[?]				F-SCH1 Level
CONFigure:MODulation:OEMP:HPSK:ENVironment:LEVel:FSCH:ONE[?]				
<SCH1 Level>				
<SCH1 Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to -1.0 dB OFF	F-SCH1 Level F-SCH1 switched off	-7	dB	V3.20
Description of command				Sig. State
These commands determine the level in the forward SCH1 channel of the CMU. The channel power is in units relative to the total CDMA power.				All

CONFigure:MODulation:OEMP[:OQPSk]:ENVironment:EBNT:FFCH?				F-FCH Eb/Nt
CONFigure:MODulation:OEMP:HPSK:ENVironment:EBNT:FFCH?				
<Eb/Nt>				
<Eb/Nt>	Description of parameters	Def. value	Def. unit	FW vers.
-30.969 dB to 18.072 dB	Calculated F-FCH Eb/Nt	-	dB	V3.20
Description of command				Sig. State
These commands are always queries. They return the calculated signal to noise ratio for the forward FCH. This quantity is undefined unless the AWGN generator is turned on (CONFigure:MODulation:OEMP[:OQPSk]:ENVironment:IMPairments:LEVel:AWGN). The quoted range of values is valid for data rates between 9.6 kbps and 153.6 kbps; see <i>Eb/Nt Calculation</i> in Chapter 4.				All

CONFigure:MODulation:OEMP:HPSK:ENVironment:EBNT:FSCH:ZERO?				F-SCH0 Eb/Nt
CONFigure:MODulation:OEMP[:OQPSk]:ENVironment:EBNT:FSCH:ZERO?				
<Eb/Nt>				
<Eb/Nt>	Description of parameters	Def. value	Def. unit	FW vers.
-30.969 dB to 18.072 dB	Calculated F-SCH0 Eb/Nt	-	dB	V3.20
Description of command				Sig. State
These commands are always queries. They return the calculated signal to noise ratio for the forward SCH0. This quantity is undefined unless the AWGN generator is turned on (CONFigure:MODulation:OEMP:HPSK:ENVironment:IMPairments:LEVel:AWGN). The quoted range of values is valid for data rates between 9.6 kbps and 153.6 kbps; see <i>Eb/Nt Calculation</i> in Chapter 4.				All

CONFigure:MODulation:OEMP[:OQPSk]:ENVironment:EBNT:FSCH:ONE? CONFigure:MODulation:OEMP:HPSK:ENVironment:EBNT:FSCH:ONE? <Eb/Nt>				F-SCH1 Eb/Nt
<Eb/Nt>	Description of parameters	Def. value	Def. unit	FW vers.
-30.969 dB to 18.072 dB	Calculated F-SCH1 Eb/Nt	-	dB	V3.20
Description of command				Sig. State
These commands are always queries. They return the calculated signal to noise ratio for the forward SCH1. This quantity is undefined unless the AWGN generator is turned on (CONFigure:MODulation:OEMP[:OQPSk]:ENVironment:IMPairments:LEVel:AWGN). The quoted range of values is valid for data rates between 9.6 kbps and 153.6 kbps; see <i>Eb/Nt Calculation</i> in Chapter 4.				All

CONFigure:MODulation:OEMP[:OQPSk]:ENVironment:FRATe:FFCH[?] CONFigure:MODulation:OEMP:HPSK:ENVironment:FRATe:FFCH[?] <Frame Rate>				Frame Rate
<Frame Rate>	Description of parameters	Def. value	Def. unit	FW vers.
EIGHTh QUARter HALF FULL DEFault	Frames at 1/8 of the rate set Frames at 1/4 of the rate set Frames at 1/2 of the rate set Frames at the full rate set	FULL	-	V3.20
Description of command				Sig. State
These commands set the frame rate for the variable rate traffic channel.				All

CONFigure:MODulation:OEMP[:OQPSk]:ENVironment:IMPairments:LEVel:AWGN[?] CONFigure:MODulation:OEMP:HPSK:ENVironment:IMPairments:LEVel:AWGN[?] <AWGN Level>				AWGN Level
<AWGN Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to +4.0 dB DEFault MINimum MAXimum OFF,	AWGN level Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum	OFF	dB	V3.20
Description of command				Sig. State
These commands determine an Additional White Gaussian Noise level to impair the CMU output signal.				All

CONFigure:MODulation:OEMP[:OQPSk]:ENVironment:IMPairments:FOFFset[?] CONFigure:MODulation:OEMP:HPSK:ENVironment:IMPairments:FOFFset[?] <BS Freq Offset>				BS Frequency Offset
<BS Freq Offset>	Description of parameters	Def. value	Def. unit	FW vers.
-50.0 kHz to +50.0 kHz DEFault MINimum MAXimum OFF	BS frequency offset Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum	OFF	Hz	V3.20
Description of command				Sig. State
These commands determine a frequency offset to impair the CMU output signal.				All

CONFigure:MODulation:OEMP[:OQPSk]:ENVironment:IMPairments:ITFer[?] CONFigure:MODulation:OEMP:HPSK:ENVironment:IMPairments:ITFer[?] <FER>				Injected Tx FER
<FER>	Description of parameters	Def. value	Def. unit	FW vers.
0% to 50% OFF ON	Injected Tx FER Switch FER injection off (equiv. to 0%) Re-activate FER injection, using the previously defined value	OFF	–	V3.20
Description of command				Sig. State
These commands define a percentage of faulty (i.e. erasure) frames that the CMU injects into all traffic channels of its BS Signal.				All

CONFigure:MODulation:OEMP[:OQPSk]:ENVironment:PCBits[?] CONFigure:MODulation:OEMP:HPSK:ENVironment:PCBits[?] <Power Control Bits>				Power Control Bits
Response	Description of parameters	Def. value	Def. unit	FW vers.
OFF AUTomatic HOLD ADOW AUP RTES PATTern	Disable power control bits Auto mode, closed-loop operation Alternating up/down control bits All power control bits down All power control bits up Range test mode Pattern defined by means of the CONF:BSS:PCB:PATTern... commands	AUT	–	V3.20
Description of command				Sig. State
These commands select the power control bit sequence that the CMU sends to the mobile station to control its output power.				All

Tolerance values – Subsystem MODulation:OEMP:LIMit

The subsystem *MODulation:OEMP:LIMit* defines tolerance values for the modulation measurement in all four applications. The subsystem corresponds to the *Limits* tab in the popup menu *Modulation Configuration*.

Note: *The modulation scheme reference O-QPSK is optional in the commands to remain compatible with cdmaOne. O-QPSK supports radio configurations 1 and 2. H-PSK supports radio configurations 3 and 4.*

				Limits
CONFigure:MODulation:OEMP[:OQPSk]:CMMax:LIMit[:SCALar]:SYMMetric[:COMBined][?] CONFigure:MODulation:OEMP:HPSK:CMMax:LIMit[:SCALar]:SYMMetric[:COMBined][?]				
<Limit_Peak_EVM>, <Enable>, <Limit_RMS_EVM>, <Enable>, <Limit_Peak_ME>, <Enable>, <Limit_RMS_ME>, <Enable>, <Limit_Peak_PE>, <Enable>, <Limit_RMS_PE>, <Enable>, <Carrier_Feedthrough_Limit>, <Enable>, <IQ_Imbalance_Limit>, <Enable>, <Carrier_Freq_Error_Limit>, <Enable>, <Tx_Time_Error_Limit>, <Enable>, <WFM_Quality_Limit>, <Enable>				
<Enable>	Description of parameters	Def. value	Def. unit	
ON OFF,	Switch limit check for parameter preceding <Enable> on or off	ON	–	
Parameters	Description of parameters	Def. value	Def. unit	FW vers.
0.0 % to +100.0 %,	(EVM) Error Vector Magnitude Error Peak	+33.4	%	V3.05
0.0 % to +100.0 %,	(EVM) Error Vector Magnitude Error RMS	+23.6	%	
0.0 % to +100.0 %,	(ME) Magnitude Error Peak	+33.4	%	
0.0 % to +100.0 %,	(ME) Magnitude Error RMS	+23.6	%	
0.0 deg to +45.0 deg,	(PE) Phase Error Peak	+19.6	deg	
0.0 deg to +45.0 deg,	(PE) Phase Error RMS	+13.6	deg	
–120.0 dB to –20.0 dB,	Carrier Feedthrough	–25.0	dB	
–120.0 dB to –20.0 dB,	IQ Imbalance	–30.0	dB	
0 Hz to 1000 Hz,	Carrier Frequency Error	+300	Hz	
0.0 μs to 10.0 μs	Transmit Time Error	1.0	s	
0.0 to 1.0	Waveform Quality	0.944	–	
Description of command				Sig. State
This command defines upper limits for the different traces and for the scalar modulation parameters derived from them. The keyword CMMax refers to the <i>Current</i> and <i>Max./Min.</i> traces. After each parameter definition, the limit check for this parameter can be enabled or disabled.				All
Limit definition and enabling of the limit check can be done separately.				

				Limits
CONFigure:MODulation:OEMP[:OQPSk]:AVERage:LIMit[:SCALar]:SYMMetric[:COMBined][?] CONFigure:MODulation:OEMP:HPSK:AVERage:LIMit[:SCALar]:SYMMetric[:COMBined][?] <Limit_Peak_EVM>, <Enable>, <Limit_RMS_EVM>, <Enable>, <Limit_Peak_ME>, <Enable>, <Limit_RMS_ME>, <Enable>, <Limit_Peak_PE>, <Enable>, <Limit_RMS_PE>, <Enable>, <Carrier_Feedthrough_Limit>, <Enable>, <IQ_Imbalance_Limit>, <Enable>, <Carrier_Freq_Error_Limit>, <Enable>, <Tx_Time_Error_Limit>, <Enable>, <WFM_Quality_Limit>, <Enable>				
<Enable>	Description of parameters	Def. value	Def. unit	
ON OFF,	Switch limit check for parameter preceding <Enable> on or off	ON	–	
Parameters	Description of parameters	Def. value	Def. unit	FW vers.
0.0 % to +100.0 %,	(EVM) Error Vector Magnitude Error Peak	+33.4	%	V3.05
0.0 % to +100.0 %,	(EVM) Error Vector Magnitude Error RMS	+23.6	%	
0.0 % to +100.0 %,	(ME) Magnitude Error Peak	+33.4	%	
0.0 % to +100.0 %,	(ME) Magnitude Error RMS	+23.6	%	
0.0 deg to +45.0 deg,	(PE) Phase Error Peak	+19.6	deg	
0.0 deg to +45.0 deg,	(PE) Phase Error RMS	+13.6	deg	
–120.0 dB to –20.0 dB,	Carrier Feedthrough	–25.0	dB	
–120.0 dB to –20.0 dB,	IQ Imbalance	–30.0	dB	
0 Hz to 1000 Hz,	Carrier Frequency Error	+300	Hz	
0.0 μs to 10.0 μs	Transmit Time Error	1.0	s	
0.0 to 1.0	Waveform Quality	0.944	–	
Description of command				Sig. State
This command defines upper limits for the different traces and for the scalar modulation parameters derived from them. The keyword <i>AVERage</i> refers to the <i>Average</i> trace. After each parameter definition, the limit check for this parameter can be enabled or disabled. Limit definition and enabling of the limit check can be done separately.				All

				Limit values
CONFigure:MODulation:OEMP[:OQPSk]:CMMax:LIMit[:SCALar]:SYMMetric[:COMBined]:VALue[?] CONFigure:MODulation:OEMP:HPSK:CMMax:LIMit[:SCALar]:SYMMetric[:COMBined]:VALue[?] <Limit_Peak_EVM>, <Limit_RMS_EVM>, <Limit_Peak_ME>, <Limit_RMS_ME>, <Limit_Peak_PE>, <Limit_RMS_PE>, <Carrier_Feedthrough_Limit>, <IQ_Imbalance_Limit>, <Carrier_Freq_Error_Limit>, <Tx_Time_Error_Limit>, <WFM_Quality_Limit>				
Parameter	Description of parameters	Def. value	Def. unit	FW vers.
0.0 % to +100.0 %,	(EVM) Error Vector Magnitude Error Peak	+33.4	%	V3.05
0.0 % to +100.0 %,	(EVM) Error Vector Magnitude Error RMS	+23.6	%	
0.0 % to +100.0 %,	(ME) Magnitude Error Peak	+33.4	%	
0.0 % to +100.0 %,	(ME) Magnitude Error RMS	+23.6	%	
0.0 deg to +45.0 deg,	(PE) Phase Error Peak	+19.6	deg	
0.0 deg to +45.0 deg,	(PE) Phase Error RMS	+13.6	deg	
–120.0 dB to –20.0 dB,	Carrier Feedthrough	–25.0	dB	
–120.0 dB to –20.0 dB,	IQ Imbalance	–30.0	dB	
0 Hz to 1000 Hz,	Carrier Frequency Error	+300	Hz	
0.0 μs to 10.0 μs,	Transmit Time Error	1.0	s	
0.0 to 1.0	Waveform Quality	0.944	–	
Description of command				Sig. State
This command defines upper limits for the different traces and for the scalar modulation parameters derived from them. The keyword <i>CMMax</i> refers to the <i>Current</i> and <i>Max./Min.</i> traces.				All

Limit values				
CONFigure:MODulation:OEMP[:OQPSk]:AVERAge:LIMit[:SCALar]:SYMMetric[:COMBined]:VALue[?]				
CONFigure:MODulation:OEMP:HPSK:AVERAge:LIMit[:SCALar]:SYMMetric[:COMBined]:VALue[?]				
<Limit_Peak_EVM>, <Limit_RMS_EVM>, <Limit_Peak_ME>, <Limit_RMS_ME>, <Limit_Peak_PE>, <Limit_RMS_PE>, <Carrier_Feedthrough_Limit>, <IQ_Imbalance_Limit>, <Carrier_Freq_Error_Limit>, <Tx_Time_Error_Limit>, <WFM_Quality_Limit>				
Parameter	Description of parameters	Def. value	Def. unit	FW vers.
0.0 % to +100.0 %,	(EVM) Error Vector Magnitude Error Peak	+33.4	%	V3.05
0.0 % to +100.0 %,	(EVM) Error Vector Magnitude Error RMS	+23.6	%	
0.0 % to +100.0 %,	(ME) Magnitude Error Peak	+33.4	%	
0.0 % to +100.0 %,	(ME) Magnitude Error RMS	+23.6	%	
0.0 deg to +45.0 deg,	(PE) Phase Error Peak	+19.6	deg	
0.0 deg to +45.0 deg,	(PE) Phase Error RMS	+13.6	deg	
-120.0 dB to -20.0 dB,	Carrier Feedthrough	-25.0	dB	
-120.0 dB to -20.0 dB,	IQ Imbalance	-30.0	dB	
0 Hz to 1000 Hz,	Carrier Frequency Error	+300	Hz	
0.0 µs to 10.0 µs,	Transmit Time Error	1.0	s	
0.0 to 1.0	Waveform Quality	0.944	-	
Description of command				Sig. State
This command defines upper limits for the different traces and for the scalar modulation parameters derived from them. The keyword <i>AVERAge</i> refers to the <i>Average</i> trace.				All

Limit Enable				
CONFigure:MODulation:OEMP[:OQPSk]:CMMax:LIMit[:SCALar]:SYMMetric[:COMBined]:ENABLE[?]				
CONFigure:MODulation:OEMP:HPSK:CMMax:LIMit[:SCALar]:SYMMetric[:COMBined]:ENABLE[?]				
<Limit_Peak_EVM>, <Limit_RMS_EVM>, <Limit_Peak_ME>, <Limit_RMS_ME>, <Limit_Peak_PE>, <Limit_RMS_PE>, <Carrier_Feedthrough_Limit>, <IQ_Imbalance_Limit>, <Carrier_Freq_Error_Limit>, <Tx_Time_Error_Limit>, <WFM_Quality_Limit>				
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	Switch limit check for corresponding parameter on or off.	ON	-	V3.05
Description of command				Sig. State
This command enables or disables the limit check for the different traces and for the scalar modulation parameters derived from them. The keyword <i>CMMax</i> refers to the <i>Current</i> and <i>Max./Min.</i> traces.				All

Limit Enable				
CONFigure:MODulation:OEMP[:OQPSk]:AVERAge:LIMit[:SCALar]:SYMMetric[:COMBined]:ENABLE[?]				
CONFigure:MODulation:OEMP:HPSK:AVERAge:LIMit[:SCALar]:SYMMetric[:COMBined]:ENABLE[?]				
<Limit_Peak_EVM>, <Limit_RMS_EVM>, <Limit_Peak_ME>, <Limit_RMS_ME>, <Limit_Peak_PE>, <Limit_RMS_PE>, <Carrier_Feedthrough_Limit>, <IQ_Imbalance_Limit>, <Carrier_Freq_Error_Limit>, <Tx_Time_Error_Limit>, <WFM_Quality_Limit>				
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	Switch limit check for corresponding parameter on or off.	ON	-	V3.05
Description of command				Sig. State
This command enables or disables the limit check for the different traces and for the scalar modulation parameters derived from them. The keyword <i>AVERAge</i> refers to the <i>Average</i> trace.				All

DEFault:MODulation:OEMP[:OQPSk]:LIMit[?] DEFault:MODulation:OEMP:HPSK:LIMit[?] <Enable>				Default Settings	
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.	
ON OFF	The parameters are set to their default values Some or all parameters differ from their default values	ON	–	V3.05	
Description of command				Sig. State	
If used as a setting command with the parameter ON, this command sets all parameters of the subsystem MODulation:OEMP:LIMit to their default values (the setting OFF results in an error message). If used as a query the command returns whether all parameters are set to their default values (ON) or not (OFF).				All	

MODulation:OVERview

The subsystem *MODulation:OVERview* measures general scalar modulation parameters. It corresponds to the softkey *Overview O-QPSK (H-PSK)* in the measurement menu *Modulation*.

Note: The modulation scheme reference O-QPSK is optional in the commands to remain compatible with *cdmaOne*. O-QPSK supports radio configurations 1 and 2. H-PSK supports radio configurations 3 and 4.

INITiate:MODulation:OVERview[:OQPSk]	Start new measurement	⇒	<i>RUN</i>	
ABORt:MODulation:OVERview[:OQPSk]	Abort running measurement and switch off	⇒	<i>OFF</i>	
STOP:MODulation:OVERview[:OQPSk]	Stop measurement after current stat. cycle	⇒	<i>STOP</i>	
CONTinue:MODulation:OVERview[:OQPSk]	Next measurement step (only <i>stepping mode</i>)	⇒	<i>RUN</i>	
INITiate:MODulation:OVERview:HPSK	Start new measurement	⇒	<i>RUN</i>	
ABORt:MODulation:OVERview:HPSK	Abort running measurement and switch off	⇒	<i>OFF</i>	
STOP:MODulation:OVERview:HPSK	Stop measurement after current stat. cycle	⇒	<i>STOP</i>	
CONTinue:MODulation:OVERview:HPSK	Next measurement step (<i>stepping mode</i>)	⇒	<i>RUN</i>	
Description of command			Sig. State	FW vers.
These commands have no query form. They start and stop the modulation measurement, setting it to the status indicated in the top right column.			All	V3.05

CONFigure:MODulation:OVERview[:OQPSk]:EREPorting[?] CONFigure:MODulation:OVERview:HPSK:EREPorting[?] <Report Mode>				Event Reporting	
<Report Mode>	Description of parameters	Def. value	Def. unit	FW vers.	
SRQ SOPC SRSQ OFF DEFault	Service request Single operation complete SRQ and SOPC No reporting Sets the value to the default setting	OFF	–	V3.05	
Description of command				Sig. State	
This command defines the events generated when the measurement is terminated or stopped (see <i>Event Reporting</i> in Chapter 5 of the CMU manual).				All	

FETCh[:SCALar]:MODulation:OVERview[:OQPSk]:STATus? FETCh[:SCALar]:MODulation:OVERview:HPSK:STATus?				Measurement Status
Returned values	Description of parameters	Def. value	Def. unit	FW vers.
OFF RUN STOP ERR STEP RDY	Measurement in the OFF state (*RST or ABORT) Running (after INITiate, CONTInue or READ) Stopped (STOP) OFF (could not be started) Stepping mode (<stepmode>=STEP) Stopped according to repetition mode and stop condition	OFF	–	V3.05
1 to 10000 NONE	Counter for current statistics cycle No counting mode set	NONE	–	
1 to 1000 NONE	Counter for current evaluation period within a cycle Statistic count set to off	NONE	–	
Description of command				Sig. State
This command is always a query. It returns the status of the measurement (see Chapters 3 and 5).				All

Subsystem MODulation:OVERview:CONTRol

The subsystem *MODulation:OVERview:CONTRol* configures the modulation measurement. It corresponds to the tabs *Control* and *Statistics* in the popup menu *Modulation Configuration*.

Note: *The application type O-QPSK is omitted from the commands to remain compatible with cdmaOne. The application type H-PSK contains the type in the command. O-QPSK supports radio configurations 1 and 2. H-PSK supports radio configurations 3 and 4.*

CONFIgure:MODulation:OVERview[:OQPSk]:CONTRol[?] CONFIgure:MODulation:OVERview:HPSK:CONTRol[?] <Statistic Count>, <Repetition>, <Stop Cond>, <Step Mode>				Scope of Measurement
<Statistic Count>	Description of parameters	Def. value	Def. unit	
1 to 1000,	Number of bursts per statistics cycle	100	–	
<Repetition>	Description of parameters	Def. value	Def. unit	
1 to 10000 CONTInuous SINGleshot DEFault,	Multiple measurement (counting, until Status = STEP RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–	
<Stop Cond>	Description of parameters	Def. value	Def. unit	
NONE SONerror DEFault,	Continue measurement even in case of error Stop measurement in case of error (<i>stop on error</i>) Sets the value to the default setting	NONE	–	
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
STEP NONE DEFault	Interrupt measurement after each statistics cycle Continue measurement according to its rep. Mode Sets the value to the default setting	NONE	–	V3.05
Description of command				Sig. State
This command combines the ...CONTRol:STATistics and the ...CONTRol:REPetition commands, see below.				All

CONFigure:MODulation:OVERview[:OQPSk]:CONTRol:STATistics[?] CONFigure:MODulation:OVERview:HPSK:CONTRol:STATistics[?] <Statistic Count>				Statistic Count
<Statistic Count>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 1000	Number of bursts per statistics cycle	100	–	V3.05
Description of command				Sig. State
This command specifies the type of measured values and defines the number of bursts forming a statistics cycle.				All

CONFigure:MODulation:OVERview[:OQPSk]:CONTRol:REPetition[?] CONFigure:MODulation:OVERview:HPSK:CONTRol:REPetition[?] <Repetition>, <Stop Cond>, <Step Mode>				Test Cycles
<Repetition>	Description of parameters	Def. value	Def. unit	
1 to 10000 CONTInuous SINGleshot DEFault,	Multiple measurement (counting, until Status = STEP RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–	
<Stop Cond>	Description of parameters	Def. value	Def. unit	
NONE SONerror DEFault,	Continue measurement even in case of error Stop measurement in case of error (<i>stop on error</i>) Sets the value to the default setting	NONE	–	
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
STEP NONE DEFault	Interrupt measurement after each statistics cycle Continue measurement according to its rep. Mode Sets the value to the default setting	NONE	–	V3.05
Description of command				Sig. State
This command determines the repetition mode, stop condition, and stepping mode for the measurement.				All
Note: <i>In the case of READ commands (READ:...), the <Repetition> parameter has no effect; the measurement is always stopped after a single shot.</i>				

Measured Values – Subsystem MODulation:OVERview

The subsystem *MODulation:OVERview* measures and returns the modulation parameters and compares them with the tolerance values. The subsystem corresponds to the various output elements in the measurement menu *MODulation*, application *Overview*.

Note: *The modulation scheme reference O-QPSK is optional in the commands to remain compatible with cdmaOne. O-QPSK supports radio configurations 1 and 2. H-PSK supports radio configurations 3 and 4.*

		Scalar Results		
READ[:SCALar]:MODulation:OVERview[:OQPSk]? FETCh[:SCALar]:MODulation:OVERview[:OQPSk]? SAMPle[:SCALar]:MODulation:OVERview[:OQPSk]?		Start single shot measurement and return results Read out meas. results (unsynchronized) Read out measurement results (synchronized)		
READ[:SCALar]:MODulation:OVERview:HPSK? FETCh[:SCALar]:MODulation:OVERview:HPSK? SAMPle[:SCALar]:MODulation:OVERview:HPSK?		Start single shot measurement and return results Read out meas. results (unsynchronized) Read out measurement results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
EVM Peak (x3), EVM RMS (x3), Magn Error Peak (x3), Magn Error RMS (x3), Phase Error Peak (x3), Phase Error RMS (x3),	0.0 % to 100.0 % 0.0 % to 100.0 % 0.0 % to 100.0 % 0.0 % to 100.0 % 0.0 deg to +45.0 deg 0.0 deg to +45.0 deg	NAN NAN NAN NAN NAN NAN	% % % % deg deg	V3.05
Overv. CarrierFeedth (x3), Overv. I/Q Imbalance (x3), Overv. Carr Freq Error (x3), Overv. Tx Time Error (x3), Overv. WFM Quality (x3), Overv. MS Power (x3)	-120.0 dB to -20.0 dB -120.0 dB to -20.0 dB (QPSK only) 0 Hz to 1000 Hz 0 µs to 10 µs 0 to 1 -133.0 dBm to +19.0 dBm	NAN NAN NAN NAN NAN NAN	dB dB Hz µs - dB	
Overv. Current Statistics Overv. Limit Matching	1 to 1000 0.0 % to 100.0 %	NAN NAN	- %	
Description of command				Sig. State
These commands are always queries. They start a modulation measurement and output all scalar measurement results (see Chapter 4). The calculation of results in an <i>average</i> or <i>peak</i> measurement is described in Chapter 3 (see <i>calculation of statistical quantities</i>). The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i> , the <i>Average</i> , and the <i>MMax</i> value.				All

CALCulate[:SCALar]:MODulation:OVERview[:OQPSk]:MATChing:LIMit? CALCulate[:SCALar]:MODulation:OVERview:HPSK:MATChing:LIMit?				Limit Matching
Returned values	Value range	Def. value	Def. unit	FW vers.
EVM Peak (x3), EVM RMS (x3), Magn Error Peak (x3), Magn Error RMS (x3), Phase Error Peak (x3), Phase Error RMS (x3),	For all measured values: NMAU NMAL INV OK	INV INV INV INV INV INV	– – – – – –	V3.05
Overv. CarrierFeedth (x3), Overv. I/Q Imbalance (x3), Overv. Carr Freq Error (x3), Overv. Tx Time Error (x3), Overv. WFM Quality (x3), Overv. MS Power (x3)		INV INV INV INV INV INV	– – – – – –	
Description of command				Sig. State
This command is always a query. It indicates whether and in which way the error limits for the scalar measured values (see above command) have been exceeded. The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i> , the <i>Average</i> , and the <i>MMax</i> value.				All
The following messages may be output for all measured values:				
NMAU	Underflow of tolerance value		<i>not matching, underflow</i>	
NMAL	Tolerance value exceeded		<i>not matching, overflow</i>	
INV	Measurement invalid		<i>invalid</i>	
OK	all tolerances matched			

MODulation:EVMagnitude

The subsystem *MODulation:EVMagnitude* measures the error vector magnitude as well as general scalar modulation parameters. The subsystem corresponds to the measurement menu *Modulation*, application *EVM O-QPSK (H-PSK)*, and the associated popup menu *Modulation Configuration*.

Control of Measurement – Subsystem MODulation:EVMagnitude

The subsystem *MODulation:EVMagnitude* controls the modulation measurement. It corresponds to the softkey *EVM O-QPSK (H-PSK)* in the measurement menu *Modulation*.

Note: The modulation scheme reference O-QPSK is optional in the commands to remain compatible with *cdmaOne*. O-QPSK supports radio configurations 1 and 2. H-PSK supports radio configurations 3 and 4.

INITiate:MODulation:EVMagnitude[:OQPSk]	Start new measurement	⇒	<i>RUN</i>
ABORt:MODulation:EVMagnitude[:OQPSk]	Abort running measurement and switch off	⇒	<i>OFF</i>
STOP:MODulation:EVMagnitude[:OQPSk]	Stop measurement after current stat. cycle	⇒	<i>STOP</i>
CONTInue:MODulation:EVMagnitude[:OQPSk]	Next measurement step (<i>stepping mode</i>)	⇒	<i>RUN</i>
INITiate:MODulation:EVMagnitude:HPSK	Start new measurement	⇒	<i>RUN</i>
ABORt:MODulation:EVMagnitude:HPSK	Abort running measurement and switch off	⇒	<i>OFF</i>
STOP:MODulation:EVMagnitude:HPSK	Stop measurement after current stat. cycle	⇒	<i>STOP</i>
CONTInue:MODulation:EVMagnitude:HPSK	Next measurement step (<i>stepping mode</i>)	⇒	<i>RUN</i>
Description of command		Sig. State	FW vers.
These commands have no query form. They start and stop the modulation measurement, setting it to the status indicated in the top right column.		All	V3.05

CONFigure:MODulation:EVMagnitude[:OQPSk]:EREPorting[?]		Event Reporting		
CONFigure:MODulation:EVMagnitude:HPSK:EREPorting[?]				
<Report Mode>				
<Report Mode>	Description of parameters	Def. value	Def. unit	FW vers.
SRQ	Service request	OFF	–	V3.05
SOPC	Single operation complete			
SRSQ	SRQ and SOPC			
OFF	No reporting			
DEFault	Sets the value to the default setting			
Description of command				Sig. State
This command defines the events generated when the measurement is terminated or stopped (see <i>Event Reporting</i> in Chapter 5 of the CMU manual).				All

FETCh[:SCALar]:MODulation:EVMagnitude[:OQPSk]:STATus?		Measurement Status		
FETCh[:SCALar]:MODulation:EVMagnitude:HPSK:STATus?				
Returned values	Description of parameters	Def. value	Def. unit	FW vers.
OFF	Measurement in the OFF state (*RST or ABORt)	OFF	–	V3.05
RUN	Running (after INITiate, CONTInue or READ)			
STOP	Stopped (STOP)			
ERR	OFF (could not be started)			
STEP	Stepping mode (<stepmode>=STEP)			
RDY	Stopped according to repetition mode and stop condition			
1 to 10000	Counter for current statistics cycle	NONE	–	
NONE	No counting mode set			
1 to 1000	Counter for current evaluation period within a cycle	NONE	–	
NONE	Statistic count set to off			
Description of command				Sig. State
This command is always a query. It returns the status of the measurement (see Chapters 3 and 5).				All

Subsystem MODulation:EVMagnitude:CONTROL

The subsystem *MODulation:EVMagnitude:CONTROL* configures the modulation measurement. It corresponds to the tabs *Control* and *Statistics* in the popup menu *Modulation Configuration*.

Note: *The modulation scheme reference O-QPSK is optional in the commands to remain compatible with cdmaOne. O-QPSK supports radio configurations 1 and 2. H-PSK supports radio configurations 3 and 4.*

CONFigure:MODulation:EVMagnitude:OQPSK:CONTROL[?]		Scope of Measurement		
CONFigure:MODulation:EVMagnitude:HPSK:CONTROL[?]				
<Statistics Count>, <Repetition>, <Stop Cond>, <Step Mode>				
<Result Mode>	Description of parameters	Def. value	Def. unit	
SCALar ARRay,	Scalar values only (incl. ramp matching) Scalar measured values and arrays	ARR	–	
<Statistics Count>	Description of parameters	Def. value	Def. unit	
1 to 1000,	Number of bursts per statistics cycle	100	–	
<Repetition>	Description of parameters	Def. value	Def. unit	
1 to 10000 CONTInuous SINGleshot DEFault,	Multiple measurement (counting, until Status = STEP RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–	
<Stop Cond>	Description of parameters	Def. value	Def. unit	
NONE SONerror DEFault,	Continue measurement even in case of error Stop measurement in case of error (<i>stop on error</i>) Sets the value to the default setting	NONE	–	
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
STEP NONE DEFault	Interrupt measurement after each statistics cycle Continue measurement according to its rep. mode Sets the value to the default setting	NONE	–	V3.05
Description of command				Sig. State
This command combines theCONTROL:STATistics and ...CONTROL:REPetition commands, see below.				All

CONFigure:MODulation:EVMagnitude:OQPSK:CONTROL:RMODE[?]		Result mode		
CONFigure:MODulation:EVMagnitude:HPSK:CONTROL:RMODE[?]				
<Result Mode>				
<Result Mode>	Description of parameters	Def. value	Def. unit	FW vers.
SCALar ARRay	Scalar values only (incl. ramp matching) Scalar measured values and arrays	ARR	–	V3.05
Description of command				Sig. State
This command specifies the type of measured values.				All

CONFigure:MODulation:EVMagnitude[:OQPSk]:CONTRol:STATistics[?] CONFigure:MODulation:EVMagnitude:HPSK:CONTRol:STATistics[?] <Statistics Count>				Statistics Count
<Statistics Count>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 1000	Number of bursts per statistics cycle	100	–	V3.05
Description of command				Sig. State
This command specifies the type of measured values and defines the number of bursts forming a statistics cycle.				All

CONFigure:MODulation:EVMagnitude[:OQPSk]:CONTRol:REPetition[?] CONFigure:MODulation:EVMagnitude:HPSK:CONTRol:REPetition[?] <Repetition> , <Stop Cond> , <Step Mode>				Test Cycles
<Repetition>	Description of parameters	Def. value	Def. unit	
1 to 10000 CONTInuous SINGleshot DEFault,	Multiple measurement (counting, until Status = STEP RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–	
<Stop Cond>	Description of parameters	Def. value	Def. unit	
NONE SONerror DEFault,	Continue measurement even in case of error Stop measurement in case of error (<i>stop on error</i>) Sets the value to the default setting	NONE	–	
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
STEP NONE DEFault	Interrupt measurement after each statistics cycle Continue measurement according to its rep. mode Sets the value to the default setting	NONE	–	V3.05
Description of command				Sig. State
This command determines the repetition mode, stop condition, and stepping mode for the measurement.				All
Note: In the case of READ commands (READ:...), the <Repetition> parameter has no effect; the measurement is always stopped after a single shot.				

Subsystem SUBarrays:MODulation:EVMMagnitude

The subsystem *SUBarrays:MODulation* defines the measurement range and the type of output values.

CONFigure:SUBarrays:MODulation:EVMMagnitude[:OQPSk][?] CONFigure:SUBarrays:MODulation:EVMMagnitude:HPSK[?] <Mode>, <Start>, <Samples>				Definition of Subarrays
<Mode>	Description of parameters	Def. value	Def. unit	
ALL ARITHmetical MINimum MAXimum	Return all measurement values Return arithm. mean value in every range Return minimum value in every range Return maximum value in every range	ALL	–	
<Start>	Description of parameters	Def. value	Def. unit	
0 μs to 406 μs	Start time in current range	NAN	s	
<Samples>	Description of parameters	Def. value	Def. unit	FW vers.
0 to 500	Number of samples in current range	NAN	–	V3.05
Description of command				Sig. State
<p>This command configures the READ:SUBarrays..., FETCh:SUBarrays..., and SAMPlE:SUBarrays:MODulation:EVMMagnitude commands. It restricts the measurement to up to 32 subranges where either all measurement results (the number of which is given by the second numerical parameter) or a single statistical value is returned. The subranges are defined by the start time and the number of test points which are located on a fixed, equidistant grid with a step width of 1 symbol period.</p> <p>The subranges may overlap but must be within the total range of the <i>Modulation</i> measurement. Test points outside this range are not measured (result NAN) and do not enter into the ARITHmetical, MINimum and MAXimum values.</p> <p>By default, only one range corresponding to the total measurement range is used and all measurement values are returned.</p>				All

Measured Values – Subsystem MODulation:EVMMagnitude

The subsystem *MODulation:EVMMagnitude* measures and returns the modulation parameters and compares them with the tolerance values. The subsystem corresponds to the various output elements in the measurement menu *MODulation*, application *Error Vector Magnitude*.

Note: *The modulation scheme reference O-QPSK is optional in the commands to remain compatible with cdmaOne. O-QPSK supports radio configurations 1 and 2. H-PSK supports radio configurations 3 and 4.*

				Scalar Results
READ[:SCALar]:MODulation:EVMagnitude[:OQPSk]?Start single shot measurement and return results				
FETCh[:SCALar]:MODulation:EVMagnitude[:OQPSk]? Read out meas. results (unsynchronized)				
SAMPlE[:SCALar]:MODulation:EVMagnitude[:OQPSk]?Read out measurement results (synchronized)				
READ[:SCALar]:MODulation:EVMagnitude:HPSK?Start single shot measurement and return results				
FETCh[:SCALar]:MODulation:EVMagnitude:HPSK? Read out meas. results (unsynchronized)				
SAMPlE[:SCALar]:MODulation:EVMagnitude:HPSK? Read out measurement results (synchronized)				
Returned values	Value range	Def. value	Def. unit	FW vers.
EVM Peak (x3)	0.0 % to 100.0 %	NAN	%	V3.05
EVM RMS (x3),	0.0 % to 100.0 %	NAN	%	
EVM Carrier Feedth (x3),	-120.0 dB to -20.0 dB	NAN	dB	
EVM I/Q Imbalance (x3),	-120.0 dB to -20.0 dB (QPSK only)	NAN	dB	
EVM Carr Freq Error (x3),	0 Hz to 1000 Hz	NAN	Hz	
EVM Tx Time Error (x3),	0 µs to 10 µs	NAN	µs	
EVM Waveform Quality (x3),	0 to 1	NAN	–	
EVM MS Power (x3),	-133.0 dBm to +-19.0 dBm	NAN	dB	
EVM Current Statistics	1 to 1000	NAN	–	
EVM Limit Matching	0.0 % to 100.0 %	NAN	%	
Description of command				Sig. State
These commands are always queries. They start a modulation measurement and output the scalar measurement results (see Chapter 4). The calculation of results in an <i>average</i> or <i>peak</i> measurement is described in Chapter 3 (see <i>calculation of statistical quantities</i>). The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i> , the <i>Average</i> , and the <i>MMax</i> value.				All

				Out of Tolerance
CALCulate[:SCALar]:MODulation:EVMagnitude[:OQPSk]:MATChing:LIMit?				
CALCulate[:SCALar]:MODulation:EVMagnitude:HPSK:MATChing:LIMit?				
Returned values	Value range	Def. value	Def. unit	FW vers.
EVM Peak (x3),	For all measured values:	INV	–	V3.05
EVM RMS (x3)		INV	–	
EVM Carrier Feedth (x3),	NMAU NMAL INV OK	INV	–	
EVM I/Q Imbalance (x3),		INV	–	
EVM Carr Freq Error (x3),		INV	–	
EVM Tx Time Error (x3),		INV	–	
EVM WFM Quality (x3),		INV	–	
EVM MS Power (x3)		INV	–	
Description of command				Sig. State
This command is always a query. It indicates whether and in which way the error limits for the scalar measured values (see above command) have been exceeded. The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i> , the <i>Average</i> , and the <i>MMax</i> value. The limits are defined with the <code>CONFigure:MODulation:OEMP...</code> commands.				All
The following messages may be output for all measured values:				
NMAU	Underflow of tolerance value	<i>not matching, underflow</i>		
NMAL	Tolerance value exceeded	<i>not matching, overflow</i>		
INV	Measurement invalid	<i>invalid</i>		
OK	all tolerances matched			

EVM in Evaluation Period				
READ:ARRay:MODulation:EVMagnitude[:OQPSk]:CURRent? READ:ARRay:MODulation:EVMagnitude[:OQPSk]:AVERAge? READ:ARRay:MODulation:EVMagnitude[:OQPSk]:MMAx?				
Start single shot measurement and return results				
FETCh:ARRay:MODulation:EVMagnitude[:OQPSk]:CURRent? FETCh:ARRay:MODulation:EVMagnitude[:OQPSk]:AVERAge? FETCh:ARRay:MODulation:EVMagnitude[:OQPSk]:MMAx?				
Read measurement results (unsynchronized)				
SAMPlE:ARRay:MODulation:EVMagnitude[:OQPSk]:CURRent? SAMPlE:ARRay:MODulation:EVMagnitude[:OQPSk]:AVERAge? SAMPlE:ARRay:MODulation:EVMagnitude[:OQPSk]:MMAx?				
Read measurement results (synchronized)				
READ:ARRay:MODulation:EVMagnitude:HPSK:CURRent? READ:ARRay:MODulation:EVMagnitude:HPSK:AVERAge? READ:ARRay:MODulation:EVMagnitude:HPSK:MMAx?				
Start single shot measurement and return results				
FETCh:ARRay:MODulation:EVMagnitude:HPSK:CURRent? FETCh:ARRay:MODulation:EVMagnitude:HPSK:AVERAge? FETCh:ARRay:MODulation:EVMagnitude:HPSK:MMAx?				
Read measurement results (unsynchronized)				
SAMPlE:ARRay:MODulation:EVMagnitude:HPSK:CURRent? SAMPlE:ARRay:MODulation:EVMagnitude:HPSK:AVERAge? SAMPlE:ARRay:MODulation:EVMagnitude:HPSK:MMAx?				
Read measurement results (synchronized)				
Returned values	Value range	Def. value	Def. unit	FW vers.
1 st value for error vector magnitude,	0.0 % to + 100.0 %,	NAN	%	V3.05
x th value for error vector magnitude	0.0 % to + 100.0 %	NAN	%	
Description of command				Sig. State
These commands are always queries. They return the error vector magnitude vs. time at fixed, equidistant test points. The number of measured values is 500, corresponding to a time range of 0 symbols to 406 microseconds.				All
The calculation of <i>current</i> , <i>average</i> , and <i>mmax</i> (Min./Max.) results is explained in Chapter 3 (see <i>display mode</i>).				

				Subarray Results
READ:SUBarrays:MODulation:EVMagnitude[:OQPSk]:CURRENT? READ:SUBarrays:MODulation:EVMagnitude[:OQPSk]:AVERage? READ:SUBarrays:MODulation:EVMagnitude[:OQPSk]:MMAx?				
Start measurement and wait for end				⇒ RUN
FETCh:SUBarrays:MODulation:EVMagnitude[:OQPSk]:CURRENT? FETCh:SUBarrays:MODulation:EVMagnitude[:OQPSk]:AVERage? FETCh:SUBarrays:MODulation:EVMagnitude[:OQPSk]:MMAx?				
Read meas. results (unsynchronized)				⇒ RUN
SAMPlE:SUBarrays:MODulation:EVMagnitude[:OQPSk]:CURRENT? SAMPlE:SUBarrays:MODulation:EVMagnitude[:OQPSk]:AVERage? SAMPlE:SUBarrays:MODulation:EVMagnitude[:OQPSk]:MMAx?				
Read results (synchronized)				⇒ RUN
READ:SUBarrays:MODulation:EVMagnitude:HPSK:CURRENT? READ:SUBarrays:MODulation:EVMagnitude:HPSK:AVERage? READ:SUBarrays:MODulation:EVMagnitude:HPSK:MMAx?				
Start measurement and wait for end				⇒ RUN
FETCh:SUBarrays:MODulation:EVMagnitude:HPSK:CURRENT? FETCh:SUBarrays:MODulation:EVMagnitude:HPSK:AVERage? FETCh:SUBarrays:MODulation:EVMagnitude:HPSK:MMAx?				
Read meas. results (unsynchronized)				⇒ RUN
SAMPlE:SUBarrays:MODulation:EVMagnitude:HPSK:CURRENT? SAMPlE:SUBarrays:MODulation:EVMagnitude:HPSK:AVERage? SAMPlE:SUBarrays:MODulation:EVMagnitude:HPSK:MMAx?				
Read results (synchronized)				⇒ RUN
Returned values	Value range	Def. value	Def. unit	FW vers.
1 st value for error vector magnitude	0.0 % to + 100.0 %,	NAN	%	V3.05
x th value for error vector magnitude	0.0 % to + 100.0 %	NAN	%	
Description of command				Sig. State
These commands are always queries. They measure and return the error vector magnitude versus time in the subranges defined by means of the <code>CONFigure:SUBarrays:MODulation:EVMagnitude</code> command.				All
The <code>CONFigure:SUBarrays:MODulation:EVMagnitude</code> command defines a maximum of 32 subranges. If one of the statistical modes (<code>ARITHmetical</code> , <code>MINimum</code> , <code>MAXimum</code>) is set, only one value is returned per subrange.				
The calculation of <i>current</i> , <i>average</i> , <i>minimum</i> , and <i>maximum</i> results is explained in Chapter 3 (see <i>display mode</i>).				

MODulation:PERRor

The subsystem *MODulation:PERRor* measures the phase error as well as general scalar modulation parameters. The subsystem corresponds to the measurement menu *Modulation*, application *Phase Error*, and the associated popup menu *Modulation Configuration*.

Control of Measurement – Subsystem MODulation:PERRor

The subsystem *MODulation:PERRor* controls the modulation measurement. It corresponds to the softkey *Phase Error* in the measurement menu *Modulation*.

Note: *The modulation scheme reference O-QPSK is optional in the commands to remain compatible with cdmaOne. O-QPSK supports radio configurations 1 and 2. H-PSK supports radio configurations 3 and 4.*

INITiate:MODulation:PERRor[:OQPSk]	Start new measurement	⇒	<i>RUN</i>
ABORt:MODulation:PERRor[:OQPSk]	Abort running measurement and switch off	⇒	<i>OFF</i>
STOP:MODulation:PERRor[:OQPSk]	Stop measurement after current stat. cycle	⇒	<i>STOP</i>
CONTInue:MODulation:PERRor[:OQPSk]	Next measurement step (<i>stepping mode</i>)	⇒	<i>RUN</i>
INITiate:MODulation:PERRor:HPSK	Start new measurement	⇒	<i>RUN</i>
ABORt:MODulation:PERRor:HPSK	Abort running measurement and switch off	⇒	<i>OFF</i>
STOP:MODulation:PERRor:HPSK	Stop measurement after current stat. cycle	⇒	<i>STOP</i>
CONTInue:MODulation:PERRor:HPSK	Next measurement step (<i>stepping mode</i>)	⇒	<i>RUN</i>
Description of command		Sig. State	FW vers.
These commands have no query form. They start and stop the modulation measurement, setting it to the status indicated in the top right column.		All	V3.05

CONFigure:MODulation:PERRor[:OQPSk]:EREPorting[?]		Event Reporting		
CONFigure:MODulation:PERRor:HPSK:EREPorting[?]				
<Report Mode>				
<Report Mode>	Description of parameters	Def. value	Def. unit	FW vers.
SRQ	Service request	OFF	–	V3.05
SOPC	Single operation complete			
SRSQ	SRQ and SOPC			
OFF	No reporting			
DEFault	Sets the value to the default setting			
Description of command				Sig. State
This command defines the events generated when the measurement is terminated or stopped (see <i>Event Reporting</i> in Chapter 5 of the CMU manual).				All

FETCh[:SCALar]:MODulation:PERRor[:OQPSk]:STATus? FETCh[:SCALar]:MODulation:PERRor:HPSK:STATus?		Measurement Status		
Return	Description of parameters	Def. value	Def. unit	FW vers.
OFF RUN STOP ERR STEP RDY	Measurement in the OFF state (*RST or ABORt) Running (after INITiate, CONTInue or READ) Stopped (STOP) OFF (could not be started) Stepping mode (<stepmode>=STEP) Stopped according to repetition mode and stop condition	OFF	–	V3.05
1 to 10000 NONE	Counter for current statistics cycle No counting mode set	NONE	–	
1 to 1000 NONE	Counter for current evaluation period within a cycle Statistic count set to off	NONE	–	
Description of command				Sig. State
This command is always a query. It returns the status of the measurement (see Chapters 3 and 5).				All

Subsystem MODulation:PERRor:CONTRol

The subsystem *MODulation:PERRor:CONTRol* configures the modulation measurement. It corresponds to the tabs *Control* and *Statistics* in the popup menu *Modulation Configuration*.

Note: *The modulation scheme reference O-QPSK is optional in the commands to remain compatible with cdmaOne. O-QPSK supports radio configurations 1 and 2. H-PSK supports radio configurations 3 and 4.*

CONFigure:MODulation:PERror[:OQPSk]:CONTRol[?]				Scope of Measurement	
CONFigure:MODulation:PERror:HPSK:CONTRol[?]					
<Result Mode>, <Statistics Count>, <Repetition>, <Stop Cond>, <Step Mode>					
<Result Mode>	Description of parameters	Def. value	Def. unit		
SCALar ARRay,	Scalar values only (incl. ramp matching) Scalar measured values and arrays	ARR	–		
<Statistics Count>	Description of parameters	Def. value	Def. unit		
1 to 1000,	Number of bursts per statistics cycle	100	–		
<Repetition>	Description of parameters	Def. value	Def. unit		
1 to 10000 CONTInuous SINGleshot DEFault,	Multiple measurement (counting, until Status = STEP RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–		
<Stop Cond>	Description of parameters	Def. value	Def. unit		
NONE SONerror DEFault,	Continue measurement even in case of error Stop measurement in case of error (<i>stop on error</i>) Sets the value to the default setting	NONE	–		
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.	
STEP NONE DEFault	Interrupt measurement after each statistics cycle Continue measurement according to its rep. Mode Sets the value to the default setting	NONE	–	V3.05	
Description of command					Sig. State
This command combines the ...CONTRol:STATistics, ...CONTRol:REPetition and ...CONTRol:RMODe commands.					All

CONFigure:MODulation:PERror[:OQPSk]:CONTRol:STATistics[?]				Statistics Count	
CONFigure:MODulation:PERror:HPSK:CONTRol:STATistics[?]					
<Statistics Count>					
<Statistics Count>	Description of parameters	Def. value	Def. unit	FW vers.	
1 to 1000	Number of bursts per statistics cycle	100	–	V3.05	
Description of command					Sig. State
This command specifies the type of measured values and defines the number of bursts forming a statistics cycle.					All

CONFigure:MODulation:PERRor[:OQPSk]:CONTrol:REPetition[?] CONFigure:MODulation:PERRor:HPSK:CONTrol:REPetition[?] <Repetition>, <Stop Cond>, <Step Mode>				Test Cycles
<Repetition>	Description of parameters	Def. value	Def. unit	
1 to 10000 CONTInuous SINGleshot DEFault,	Multiple measurement (counting, until Status = STEP RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–	
<Stop Cond>	Description of parameters	Def. value	Def. unit	
NONE SONerror DEFault,	Continue measurement even in case of error Stop measurement in case of error (<i>stop on error</i>) Sets the value to the default setting	NONE	–	
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
STEP NONE DEFault	Interrupt measurement after each statistics cycle Continue measurement according to its rep. Mode Sets the value to the default setting	NONE	–	V3.05
Description of command				Sig. State
This command determines the number of statistics cycles, the stop condition and the stepping mode for the measurement.				All
Note: <i>In the case of READ commands (READ:...), the <Repetition> parameter has no effect; the measurement is always stopped after a single shot.</i>				

CONFigure:MODulation:PERRor[:OQPSk]:CONTrol:RMODe[?] CONFigure:MODulation:PERRor:HPSK:CONTrol:RMODe[?] <Result Mode>				Result Mode
<Result Mode>	Description of parameters	Def. value	Def. unit	FW vers.
SCALar ARRay	Scalar values only (incl. ramp matching) Scalar measured values and arrays	ARR	–	V3.05
Description of command				Sig. State
This command specifies the type of measured values.				All

Subsystem SUBarrays:MODulation:PERRor

The subsystem *SUBarrays:MODulation:PERRor* defines the measurement range and the type of output values.

Note: *The modulation scheme reference O-QPSK is optional in the commands to remain compatible with cdmaOne. O-QPSK supports radio configurations 1 and 2. H-PSK supports radio configurations 3 and 4.*

CONFigure:SUBarrays:MODulation:PERRor[:OQPSK][?] CONFigure:SUBarrays:MODulation:PERRor:HPSK[?] <Mode>, <Start>, <Samples>				Definition of Subarrays	
<Mode>	Description of parameters	Def. value	Def. unit		
ALL ARITHmetical MINimum MAXimum,	Return all measurement values Return arithm. mean value in every range Return minimum value in every range Return maximum value in every range	ALL	–		
<Start>	Description of parameters	Def. value	Def. unit		
0 μs to 406 μs,	Start time in current range	NAN	s		
<Samples>	Description of parameters	Def. value	Def. unit		FW vers.
0 to 500	Number of samples in current range	NAN	–		V3.05
Description of command					Sig. State
<p>This command configures the READ:SUBarrays..., FETCh:SUBarrays..., and SAMPlE:SUBarrays:MODulation:PERRor commands. It restricts the measurement to up to 32 subranges where either all measurement results (the number of which is given by the second numerical parameter) or a single statistical value is returned. The subranges are defined by the start time and the number of test points which are located on a fixed, equidistant grid with a step width of 1 symbol period.</p> <p>The subranges may overlap but must be within the total range of the <i>Modulation</i> measurement. Test points outside this range are not measured (result <i>NAN</i>) and do not enter into the ARITHmetical, MINimum and MAXimum values.</p> <p>By default, only one range corresponding to the total measurement range is used and all measurement values are returned.</p>					All

Measured Values – Subsystem MODulation:PERRor

The subsystem *MODulation:PERRor* measures and returns the modulation parameters and compares them with the tolerance values. The subsystem corresponds to the various output elements in the measurement menu *MODulation*, application *Phase Error*.

Note: *The modulation scheme reference O-QPSK is optional in the commands to remain compatible with cdmaOne. O-QPSK supports radio configurations 1 and 2. H-PSK supports radio configurations 3 and 4.*

		Scalar Results:		
READ[:SCALar]:MODulation:PERRor[:OQPSk]? FETCh[:SCALar]:MODulation:PERRor[:OQPSk]? SAMPlE[:SCALar]:MODulation:PERRor[:OQPSk]?		Start single shot measurement and return results Read out meas. results (unsynchronized) Read out measurement results (synchronized)		
READ[:SCALar]:MODulation:PERRor:HPSK? FETCh[:SCALar]:MODulation:PERRor:HPSK? SAMPlE[:SCALar]:MODulation:PERRor:HPSK?		Start single shot measurement and return results Read out meas. results (unsynchronized) Read out measurement results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
PE Peak (x3),	0.0 deg to +45.0 deg	NAN	%	V3.05
PE RMS (x3),	0.0 deg to +45.0 deg	NAN	%	
PE Carrier Feedth (x3),	-120.0 dB to -20.0 dB	NAN	dB	
PE I/Q Imbalance (x3),	-120.0 dB to -20.0 dB (QPSK only)	NAN	dB	
PE Carr Freq Error (x3),	0 Hz to 1000 Hz	NAN	Hz	
PE Tx Time Error (x3),	0 µs to 10 µs	NAN	µs	
PE WFM Quality (x3),	0 to 1	NAN	-	
PE MS Power (x3),	-133.0 dBm to +19.0 dBm	NAN	dBm	
PE Current Statistics	1 to 1000	NAN	-	
PE Limit Matching	0.0 % to 100.0 %	NAN	%	
Description of command				Sig. State
These commands are always queries. They start a modulation measurement and output the scalar measurement results (see Chapter 4). The calculation of results in an <i>average</i> or <i>peak</i> measurement is described in Chapter 3 (see <i>calculation of statistical quantities</i>). The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i> , the <i>Average</i> , and the <i>MMax</i> value.				All

		Out of Tolerance		
CALCulate[:SCALar]:MODulation:PERRor[:OQPSk]:MATChing:LIMit? CALCulate[:SCALar]:MODulation:PERRor:HPSK:MATChing:LIMit?.				
Returned values	Value range	Def. value	Def. unit	FW vers.
PE Peak (x3),	For all measured values: NMAU NMAL INV OK	INV	-	V3.05
PE RMS (x3)		INV	-	
PE CarrierFeedth (x3),		INV	-	
PE I/Q Imbalance (x3),		INV	-	
PE Carr Freq Error (x3),		INV	-	
PE Tx Time Error (x3),		INV	-	
PE WFM Quality (x3),		INV	-	
PE MS Power (x3)		INV	-	
Description of command				Sig. State
This command is always a query. It indicates whether and in which way the error limits for the scalar measured values (see above command) have been exceeded. The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i> , the <i>Average</i> , and the <i>MMax</i> value. The limits are defined with the <code>CONFigure:MODulation:OEMP...</code> commands.				All
The following messages may be output for all measured values:				
NMAU	Underflow of tolerance value	<i>not matching, underflow</i>		
NMAL	Tolerance value exceeded	<i>not matching, overflow</i>		
INV	Measurement invalid	<i>invalid</i>		
OK	all tolerances matched			

		Phase Error in Burst		
READ:ARRay:MODulation:PERRor[:OQPSk]:CURRent? READ:ARRay:MODulation:PERRor[:OQPSk]:AVERAge? READ:ARRay:MODulation:PERRor[:OQPSk]:MMAx?		Start single shot measurement and return results		
FETCh:ARRay:MODulation:PERRor[:OQPSk]:CURRent? FETCh:ARRay:MODulation:PERRor[:OQPSk]:AVERAge? FETCh:ARRay:MODulation:PERRor[:OQPSk]:MMAx?		Read measurement results (unsynchronized)		
SAMPlE:ARRay:MODulation:PERRor[:OQPSk]:CURRent? SAMPlE:ARRay:MODulation:PERRor[:OQPSk]:AVERAge? SAMPlE:ARRay:MODulation:PERRor[:OQPSk]:MMAx?		Read measurement results (synchronized)		
READ:ARRay:MODulation:PERRor:HPSK:CURRent? READ:ARRay:MODulation:PERRor:HPSK:AVERAge? READ:ARRay:MODulation:PERRor:HPSK:MMAx?		Start single shot measurement and return results		
FETCh:ARRay:MODulation:PERRor:HPSK:CURRent? FETCh:ARRay:MODulation:PERRor:HPSK:AVERAge? FETCh:ARRay:MODulation:PERRor:HPSK:MMAx?		Read measurement results (unsynchronized)		
SAMPlE:ARRay:MODulation:PERRor:HPSK:CURRent? SAMPlE:ARRay:MODulation:PERRor:HPSK:AVERAge? SAMPlE:ARRay:MODulation:PERRor:HPSK:MMAx?		Read measurement results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
1 st value for phase error	-100.0 deg to + 100.0 deg,	NAN	deg	V3.05
x th value for phase error	-100.0 deg to + 100.0 deg	NAN	deg	
Description of command				Sig. State
These commands are always queries. They return the phase error vs. time at fixed, equidistant test points. The number of measured values is 500, corresponding to a time range of 0 symbols to 406 microseconds.				All
The calculation of <i>current</i> , <i>average</i> , and <i>mmax</i> (Min./Max.) results is explained in Chapter 3 (see <i>display mode</i>).				

				Subarray Results
READ:SUBarrays:MODulation:PERror[:OQPSk]:CURRent? READ:SUBarrays:MODulation:PERror[:OQPSk]:AVERAge? READ:SUBarrays:MODulation:PERror[:OQPSk]:MMAx?				
Start measurement and wait for end				⇒ RUN
FETCh:SUBarrays:MODulation:PERror[:OQPSk]:CURRent? FETCh:SUBarrays:MODulation:PERror[:OQPSk]:AVERAge? FETCh:SUBarrays:MODulation:PERror[:OQPSk]:MMAx?				
Read meas. results (unsynchronized)				⇒ RUN
SAMPlE:SUBarrays:MODulation:PERror[:OQPSk]:CURRent? SAMPlE:SUBarrays:MODulation:PERror[:OQPSk]:AVERAge? SAMPlE:SUBarrays:MODulation:PERror[:OQPSk]:MMAx?				
Read results (synchronized)				⇒ RUN
READ:SUBarrays:MODulation:PERror:HPSK:CURRent? READ:SUBarrays:MODulation:PERror:HPSK:AVERAge? READ:SUBarrays:MODulation:PERror:HPSK:MMAx?				
Start measurement and wait for end				⇒ RUN
FETCh:SUBarrays:MODulation:PERror:HPSK:CURRent? FETCh:SUBarrays:MODulation:PERror:HPSK:AVERAge? FETCh:SUBarrays:MODulation:PERror:HPSK:MMAx?				
Read meas. results (unsynchronized)				⇒ RUN
SAMPlE:SUBarrays:MODulation:PERror:HPSK:CURRent? SAMPlE:SUBarrays:MODulation:PERror:HPSK:AVERAge? SAMPlE:SUBarrays:MODulation:PERror:HPSK:MMAx?				
Read results (synchronized)				⇒ RUN
Returned values	Value range	Def. value	Def. unit	FW vers.
1 st value for phase error	100.0 deg to + 100.0 deg,	NAN	deg	V3.05
x th value for phase error	-100.0 deg to + 100.0 deg	NAN	deg	
Description of command				Sig. State
These commands are always queries. They measure and return the phase error versus time in the subranges defined by means of the <code>CONFigure:SUBarrays:MODulation:PERror</code> command.				All
The <code>CONFigure:SUBarrays:MODulation:PERror</code> command defines a maximum of 32 subranges. If one of the statistical modes (<code>ARITHmetical</code> , <code>MINimum</code> , <code>MAXimum</code>) is set, only one value is returned per subrange.				
The calculation of <i>current</i> , <i>average</i> , <i>minimum</i> , and <i>maximum</i> results is explained in Chapter 3 (see <i>display mode</i>).				

MODulation:MERRor

The subsystem *MODulation:MERRor* measures the magnitude error as well as general scalar modulation parameters. The subsystem corresponds to the measurement menu *Modulation*, application *Magnitude Error*, and the associated popup menu *Modulation Configuration*.

Control of Measurement – Subsystem MODulation:MERRor

The subsystem *MODulation:MERRor* controls the modulation measurement. It corresponds to the softkey *Magn. Error* in the measurement menu *Modulation*.

Note: *The modulation scheme reference O-QPSK is optional in the commands to remain compatible with cdmaOne. O-QPSK supports radio configurations 1 and 2. H-PSK supports radio configurations 3 and 4.*

INITiate:MODulation:MERRor[:OQPSk]	Start new measurement	⇒	<i>RUN</i>
ABORT:MODulation:MERRor[:OQPSk]	Abort running measurement and switch off	⇒	<i>OFF</i>
STOP:MODulation:MERRor[:OQPSk]	Stop measurement after current stat. cycle	⇒	<i>STOP</i>
CONTinue:MODulation:MERRor[:OQPSk]	Next measurement step (<i>stepping mode</i>)	⇒	<i>RUN</i>
INITiate:MODulation:MERRor:HPSK	Start new measurement	⇒	<i>RUN</i>
ABORT:MODulation:MERRor:HPSK	Abort running measurement and switch off	⇒	<i>OFF</i>
STOP:MODulation:MERRor:HPSK	Stop measurement after current stat. cycle	⇒	<i>STOP</i>
CONTinue:MODulation:MERRor:HPSK	Next measurement step (<i>stepping mode</i>)	⇒	<i>RUN</i>
Description of command		Sig. State	FW vers.
These commands have no query form. They start and stop the modulation measurement, setting it to the status indicated in the top right column.		All	V3.05

CONFigure:MODulation:MERRor[:OQPSk]:EREPorting[?]		Event Reporting		
CONFigure:MODulation:MERRor:HPSK:EREPorting[?]				
<Report Mode>				
<Report Mode>	Description of parameters	Def. value	Def. unit	FW vers.
SRQ	Service request	OFF	–	V3.05
SOPC	Single operation complete			
SRSQ	SRQ and SOPC			
OFF	No reporting			
DEFault	Sets the value to the default setting			
Description of command				Sig. State
This command defines the events generated when the measurement is terminated or stopped (see <i>Event Reporting</i> in Chapter 5 of the CMU manual).				All

FETCh[:SCALar]:MODulation:MERRor[:OQPSk]:STATus? FETCh[:SCALar]:MODulation:MERRor:HPSK:STATus?		Measurement Status		
Return	Description of parameters	Def. value	Def. unit	FW vers.
OFF RUN STOP ERR STEP RDY	Measurement in the OFF state (*RST or ABORT) Running (after INITiate, CONTInue or READ) Stopped (STOP) OFF (could not be started) Stepping mode (<stepmode>=STEP) Stopped according to repetition mode and stop condition	OFF	–	V3.05
1 to 10000 NONE	Counter for current statistics cycle No counting mode set	NONE	–	
1 to 1000 NONE	Counter for current evaluation period within a cycle Statistic count set to off	NONE	–	
Description of command				Sig. State
This command is always a query. It returns the status of the measurement (see Chapters 3 and 5).				All

Subsystem MODulation:MERRor:CONTRol

The subsystem *MODulation:MERRor:CONTRol* configures the modulation measurement. It corresponds to the tabs *Control* and *Limits* in the popup menu *Modulation Configuration*.

Note: *The modulation scheme reference O-QPSK is optional in the commands to remain compatible with cdmaOne. O-QPSK supports radio configurations 1 and 2. H-PSK supports radio configurations 3 and 4.*

CONFigure:MODulation:MERRor[:OQPSK]:CONTRol[?]				Scope of Measurement	
CONFigure:MODulation:MERRor:HPSK:CONTRol[?]					
<Result Mode>, <Statistics Count>, <Repetition>, <Stop Cond>, <Step Mode>					
<Result Mode>	Description of parameters	Def. value	Def. unit		
SCALar ARRay,	Scalar values only (incl. ramp matching) Scalar measured values and arrays	ARR	–		
<Statistics Count>	Description of parameters	Def. value	Def. unit		
1 to 1000,	Number of bursts per statistics cycle	100	–		
<Repetition>	Description of parameters	Def. value	Def. unit		
1 to 10000 CONTInuous SINGleshot DEFault,	Multiple measurement (counting, until Status = STEP RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–		
<Stop Cond>	Description of parameters	Def. value	Def. unit		
NONE SONerror DEFault,	Continue measurement even in case of error Stop measurement in case of error (<i>stop on error</i>) Sets the value to the default setting	NONE	–		
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.	
STEP NONE DEFault	Interrupt measurement after each statistics cycle Continue measurement according to its rep. Mode Sets the value to the default setting	NONE	–	V3.05	
Description of command					Sig. State
This command combines theCONTRol:RMODE,CONTRol:STATistics, and ...CONTRol:REPetition commands, see below.					All

CONFigure:MODulation:MERRor[:OQPSk]:CONTRol:RMODE[?]				Result mode	
CONFigure:MODulation:MERRor:HPSK:CONTRol:RMODE[?]					
<Result Mode>					
<Result Mode>	Description of parameters	Def. value	Def. unit	FW vers.	
SCALar ARRay	Scalar values only (incl. ramp matching) Scalar measured values and arrays	ARR	–	V3.05	
Description of command					Sig. State
This command specifies the type of measured values.					All

CONFigure:MODulation:MERRor[:OQPSK]:CONTRol:STATistics[?]				Statistics Count	
CONFigure:MODulation:MERRor:HPSK:CONTRol:STATistics[?]					
<Statistics Count>					
<Statistics Count>	Description of parameters	Def. value	Def. unit	FW vers.	
1 to 1000	Number of bursts per statistics cycle	100	–	V3.05	
Description of command					Sig. State
This command specifies the type of measured values and defines the number of bursts forming a statistics cycle.					All

CONFigure:MODulation:MERRor[:OQPSK]:CONTRol:REPetition[?] <Repetition>, <Stop Cond>, <Step Mode>				Test Cycles
<Repetition>	Description of parameters	Def. value	Def. unit	
1 to 10000 CONTInuous SINGleshot DEFault,	Multiple measurement (counting, until Status = STEP RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–	
<Stop Cond>	Description of parameters	Def. value	Def. unit	
NONE SONerror DEFault,	Continue measurement even in case of error Stop measurement in case of error (<i>stop on error</i>) Sets the value to the default setting	NONE	–	
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
STEP NONE DEFault	Interrupt measurement after each statistics cycle Continue measurement according to its rep. Mode Sets the value to the default setting	NONE	–	V3.05
Description of command				Sig. State
This command determines the repetition mode, stop condition, and stepping mode for the measurement.				All
Note: <i>In the case of READ commands (READ:...), the <Repetition> parameter has no effect; the measurement is always stopped after a single shot.</i>				

Subsystem SUBarrays:MODulation:MERRor

The subsystem *SUBarrays:MODulation:MERRor* defines the measurement range and the type of output values.

Note: *The modulation scheme reference O-QPSK is optional in the commands to remain compatible with cdmaOne. O-QPSK supports radio configurations 1 and 2. H-PSK supports radio configurations 3 and 4.*

CONFigure:SUBarrays:MODulation:MERRor[:OQPSk][?] CONFigure:SUBarrays:MODulation:MERRor:HPSK[?] <Mode>, <Start>, <Samples>				Definition of Subarrays
<Mode>	Description of parameters	Def. value	Def. unit	
ALL ARITHmetical MINimum MAXimum,	Return all measurement values Return arithm. mean value in every range Return minimum value in every range Return maximum value in every range	ALL	–	
<Start>	Description of parameters	Def. value	Def. unit	
0 μs to 406 μs,	Start time in current range	NAN	s	
<Samples>	Description of parameters	Def. value	Def. unit	FW vers.
0 to 500	Number of samples in current range	NAN	–	V3.05
Description of command				Sig. State
<p>This command configures the READ:SUBarrays..., FETCh:SUBarrays..., and SAMPlE:SUBarrays:MODulation:MERRor commands. It restricts the measurement to up to 32 subranges where either all measurement results (the number of which is given by the second numerical parameter) or a single statistical value is returned. The subranges are defined by the start time and the number of test points which are located on a fixed, equidistant grid with a step width of 1 symbol period.</p> <p>The subranges may overlap but must be within the total range of the <i>Modulation</i> measurement. Test points outside this range are not measured (result <i>NAN</i>) and do not enter into the ARITHmetical, MINimum and MAXimum values.</p> <p>By default, only one range corresponding to the total measurement range is used and all measurement values are returned.</p>				All

Measured Values – Subsystem MODulation:MERRor

The subsystem *MODulation:MERRor* measures and returns the modulation parameters and compares them with the tolerance values. The subsystem corresponds to the various output elements in the measurement menu *MODulation*, application *Magnitude Error*.

Note: *The modulation scheme reference O-QPSK is optional in the commands to remain compatible with cdmaOne. O-QPSK supports radio configurations 1 and 2. H-PSK supports radio configurations 3 and 4.*

		Scalar Results		
READ[:SCALar]:MODulation:MERRor[:OQPSk]? FETCH[:SCALar]:MODulation:MERRor[:OQPSk]? SAMPlE[:SCALar]:MODulation:MERRor[:OQPSk]?		Start single shot measurement and return results Read out meas. results (unsynchronized) Read out measurement results (synchronized)		
READ[:SCALar]:MODulation:MERRor:HPSK? FETCH[:SCALar]:MODulation:MERRor:HPSK? SAMPlE[:SCALar]:MODulation:MERRor:HPSK?		Start single shot measurement and return results Read out meas. results (unsynchronized) Read out measurement results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
ME Peak (x3), ME RMS (x3),	0.0 % to 100.0 % 0.0 % to 100.0 %	NAN NAN	% %	V3.05
ME CarrierFeedthrough (x3), ME I/Q Imbalance (x3), ME Carr Freq Error (x3), ME Transmit Time Error (x3), ME Waveform Quality (x3), ME MS Power (x3),	-120.0 dB to -20.0 dB -120.0 dB to -20.0 dB (QPSK only) 0 Hz to 1000 Hz 0 µs to 10 µs 0 to 1 -133.0 dBm to +19.0 dBm	NAN NAN NAN NAN NAN NAN	dB dB Hz µs - dB	
ME Current Statistics ME Limit Matching	1 to 1000 0.0 % to 100.0 %	NAN NAN	- %	
Description of command				Sig. State
These commands are always queries. They start a modulation measurement and output the scalar measurement results (see Chapter 4). The calculation of results in an <i>average</i> or <i>peak</i> measurement is described in Chapter 3 (see <i>calculation of statistical quantities</i>). The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i> , the <i>Average</i> , and the <i>MaxMin</i> value.				All

		Out of Tolerance		
CALCulate[:SCALar]:MODulation:MERRor[:OQPSk]:MATChing:LIMit? CALCulate[:SCALar]:MODulation:MERRor:HPSK:MATChing:LIMit?				
Returned values	Value range	Def. value	Def. unit	FW vers.
ME Peak (x3), ME RMS (x3), ME CarrierFeedthrough (x3), ME I/Q Imbalance (x3), ME Carr Freq Error (x3), ME Transmit Time Error (x3), ME Waveform Quality (x3), ME MS Power (x3)	For all measured values: NMAU NMAL INV OK	INV INV INV INV INV INV INV	- - - - - - -	V3.05
Description of command				Sig. State
This command is always a query. It indicates whether and in which way the error limits for the scalar measured values (see above command) have been exceeded. The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i> , the <i>Average</i> , and the <i>MaxMin</i> value. The limits are defined with the <code>CONFigure:MODulation:OEMP...</code> commands.				All
The following messages may be output for all measured values:				
NMAU	Underflow of tolerance value	<i>not matching, underflow</i>		
NMAL	Tolerance value exceeded	<i>not matching, overflow</i>		
INV	Measurement invalid	<i>invalid</i>		
OK	all tolerances matched			

<p>READ:ARRay:MODulation:MERRor[:OQPSk]:CURRent? READ:ARRay:MODulation:MERRor[:OQPSk]:AVERAge? READ:ARRay:MODulation:MERRor[:OQPSk]:MMAx?</p>		Magnitude Error in Evaluation Period		
		Start single shot measurement and return results		
<p>FETCh:ARRay:MODulation:MERRor[:OQPSk]:CURRent? FETCh:ARRay:MODulation:MERRor[:OQPSk]:AVERAge? FETCh:ARRay:MODulation:MERRor[:OQPSk]:MMAx?</p>		Read measurement results (unsynchronized)		
<p>SAMPlE:ARRay:MODulation:MERRor[:OQPSk]:CURRent? SAMPlE:ARRay:MODulation:MERRor[:OQPSk]:AVERAge? SAMPlE:ARRay:MODulation:MERRor[:OQPSk]:MMAx?</p>		Read measurement results (synchronized)		
<p>READ:ARRay:MODulation:MERRor:HPSK:CURRent? READ:ARRay:MODulation:MERRor:HPSK:AVERAge? READ:ARRay:MODulation:MERRor:HPSK:MMAx?</p>		Start single shot measurement and return results		
<p>FETCh:ARRay:MODulation:MERRor:HPSK:CURRent? FETCh:ARRay:MODulation:MERRor:HPSK:AVERAge? FETCh:ARRay:MODulation:MERRor:HPSK:MMAx?</p>		Read measurement results (unsynchronized)		
<p>SAMPlE:ARRay:MODulation:MERRor:HPSK:CURRent? SAMPlE:ARRay:MODulation:MERRor:HPSK:AVERAge? SAMPlE:ARRay:MODulation:MERRor:HPSK:MMAx?</p>		Read measurement results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
1 st value for magnitude error,	0.0 % to + 100.0 %,	NAN	%	V3.05
x th value for magnitude error	0.0 % to + 100.0 %	NAN	%	
Description of command				Sig. State
<p>These commands are always queries. They return the magnitude error vs. time at fixed, equidistant test points. The number of measured values is 500, corresponding to a time range of 0 symbols to 406 microseconds.</p> <p>The calculation of <i>current</i>, <i>average</i>, and <i>mmax</i> (Min./Max.) results is explained in Chapter 3 (see <i>display mode</i>).</p>				All

				Subarray Results
READ:SUBarrays:MODulation:MERRor[:OQPSk]:CURRent? READ:SUBarrays:MODulation:MERRor[:OQPSk]:AVERAge? READ:SUBarrays:MODulation:MERRor[:OQPSk]:MMAx?				
Start measurement and wait for end				⇒ RUN
FETCh:SUBarrays:MODulation:MERRor[:OQPSk]:CURRent? FETCh:SUBarrays:MODulation:MERRor[:OQPSk]:AVERAge? FETCh:SUBarrays:MODulation:MERRor[:OQPSk]:MMAx?				
Read meas. results (unsynchronized)				⇒ RUN
SAMPlE:SUBarrays:MODulation:MERRor[:OQPSk]:CURRent? SAMPlE:SUBarrays:MODulation:MERRor[:OQPSk]:AVERAge? SAMPlE:SUBarrays:MODulation:MERRor[:OQPSk]:MMAx?				
Read results (synchronized)				⇒ RUN
READ:SUBarrays:MODulation:MERRor:HPSK:CURRent? READ:SUBarrays:MODulation:MERRor:HPSK:AVERAge? READ:SUBarrays:MODulation:MERRor:HPSK:MMAx?				
Start measurement and wait for end				⇒ RUN
FETCh:SUBarrays:MODulation:MERRor:HPSK:CURRent? FETCh:SUBarrays:MODulation:MERRor:HPSK:AVERAge? FETCh:SUBarrays:MODulation:MERRor:HPSK:MMAx?				
Read meas. results (unsynchronized)				⇒ RUN
SAMPlE:SUBarrays:MODulation:MERRor:HPSK:CURRent? SAMPlE:SUBarrays:MODulation:MERRor:HPSK:AVERAge? SAMPlE:SUBarrays:MODulation:MERRor:HPSK:MMAx?				
Read results (synchronized)				⇒ RUN
Returned values	Description of parameters	Def. value	Def. unit	FW vers.
1 st value for magnitude error	0.0 % to + 100.0 %,	NAN	%	V3.05
x th value for magnitude error	0.0 % to + 100.0 %	NAN	%	
Description of command				Sig. State
These commands are always queries. They measure and return the magnitude error versus time in the subranges defined by means of the <code>CONFigure:SUBarrays:MODulation:MERRor</code> command.				All
The <code>CONFigure:SUBarrays:MODulation:MERRor</code> command defines a maximum of 32 subranges. If one of the statistical modes (<code>ARITHmetical</code> , <code>MINimum</code> , <code>MAXimum</code>) is set, only one value is returned per subrange.				
The calculation of <i>current</i> , <i>average</i> , <i>minimum</i> , and <i>maximum</i> results is explained in Chapter 3 (see <i>display mode</i>).				

MODulation:IQANalyzer

The subsystem *MODulation:IQANalyzer* measures the I and Q amplitudes of the received O-QPSK or HPSK-modulated signal as a function of time. The subsystem corresponds to the measurement menu *Modulation*, applications *I/Q Analyzer O-QPSK* and *I/Q Analyzer HPSK*, and the sections in the popup menu *Modulation Configuration* that are related to the *I/Q Analyzer...* applications.

Control of Measurement – Subsystem MODulation:IQAnalyzer

The subsystem *MODulation:IQAnalyzer* controls the measurement. It corresponds to the softkeys *I/Q Analyzer O-QPSK* and *I/Q Analyzer HPSK* in the measurement menu *Modulation*.

INITiate:MODulation:IQAnalyzer[:OQPSk]	Start new measurement	⇒	<i>RUN</i>
ABORt:MODulation:IQAnalyzer[:OQPSk]	Abort running measurement and switch off	⇒	<i>OFF</i>
STOP:MODulation:IQAnalyzer[:OQPSk]	Stop measurement after current stat. cycle	⇒	<i>STOP</i>
CONTinue:MODulation:IQAnalyzer[:OQPSk]	Next measurement step (only <i>stepping mode</i>)	⇒	<i>RUN</i>
INITiate:MODulation:IQAnalyzer:HPSK:DPCH	Start new measurement	⇒	<i>RUN</i>
ABORt:MODulation:IQAnalyzer:HPSK:DPCH	Abort running meas. and switch off	⇒	<i>OFF</i>
STOP:MODulation:IQAnalyzer:HPSK:DPCH	Stop meas. after current stat. cycle	⇒	<i>STOP</i>
CONTinue:MODulation:IQAnalyzer:HPSK:DPCH	Next meas. step (only <i>stepping mode</i>)	⇒	<i>RUN</i>
Description of command			FW vers.
These commands have no query form. They start and stop the measurement, setting it to the status indicated in the top right column.			V3.50

CONFigure:MODulation:IQAnalyzer[:OQPSk]:EREPorting <Mode>		Event Reporting		
CONFigure:MODulation:IQAnalyzer:HPSK:DPCH:EREPorting <Mode>				
<Mode>	Description of parameters	Def. value	Def. unit	FW vers.
SRQ 	Service request	OFF	–	V3.50
SOPC 	Single operation complete			
SRSQ 	SRQ and SOPC			
OFF	No reporting			
Description of command				
This command defines the events generated when the measurement is terminated or stopped (<i>event reporting</i> , see Chapter 5 of CMU200/300 operating manual).				

FETCH:MODulation:IQAnalyzer[:OQPSk]:STATus?		Measurement Status		
FETCH:MODulation:IQAnalyzer:HPSK:DPCH:STATus?				
Ret. values	Description of parameters	Def. value	Def. unit	FW vers.
OFF 	Measurement in the <i>OFF</i> state (*RST or ABORt)	OFF	–	V3.50
RUN 	Running (after INITiate, CONTinue or READ)			
STOP 	Stopped (STOP)			
ERR 	<i>OFF</i> (could not be started)			
STEP 	Stepping mode (<stepmode>=STEP)			
RDY,	Stopped according to repetition mode and stop condition			
	Counter for current statistics cycle			
1 to 10000 	No counting mode set	NONE	–	
NONE				
Description of command				
These commands are always queries. They return the status of the measurement (see Chapters 3 and 5 of the CMU200/300 operating manual).				

Test Configuration

The subsystem *MODulation:IQANalyzer...:CONTRol* configures the scope of the modulation measurement. It corresponds to the *Control* tab in the popup menu *Modulation Configuration*.

CONFigure:MODulation:IQANalyzer[:OQPSk]:CONTRol:RMODE <Mode>		Result Mode		
CONFigure:MODulation:IQANalyzer:HPSK:DPCH:CONTRol:RMODE <Mode>				
<Mode>	Description of parameters	Def. value	Def. unit	FW vers.
SCALar	Scalar values only (incl. limit matching)	ARR	–	V3.50
ARRay	Scalar measured values and arrays			
Description of command				
This command specifies the type of measured values.				

CONFigure:MODulation:IQANalyzer[:OQPSk]:CONTRol:REPetition <Repetition>,<StopCond>,<Stepmode>		Test Cycles		
CONFigure:MODulation:IQANalyzer:HPSK:DPCH:CONTRol:REPetition <Repetition>,<StopCond>,<Stepmode>				
<Repetition>	Description of parameters	Def. value	Def. unit	
CONTinuous	Continuous measurement (until STOP or ABORT)	SING	–	
SINGleshot	Single shot measurement (until Status = RDY)			
1 to 10000	Multiple measurement (counting, until Status = STEP RDY)			
<Stepmode>	Description of parameters	Def. value	Def. unit	FW vers.
STEP	Interrupt measurement after each statistics cycle	NONE	–	V3.50
NONE	Continue measurement according to its rep. mode			
Description of command				
This command determines the number of statistics cycles, the stop condition and the stepping mode for the measurement.				
Note: In the case of READ commands (READ:...), the <Repetition> parameter has no effect; the measurement is always stopped after a single shot.				

DEFault:MODulation:IQANalyzer[:OQPSk]:CONTRol <Enable>		Default Settings		
DEFault:MODulation:IQANalyzer:HPSK:DPCH:CONTRol <Enable>				
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON	The parameters are set to default values	ON	–	V3.50
OFF	Some or all parameters differ from the default values			
Description of command				
If used as a setting command with the parameter ON this command sets all parameters of the subsystem to default values (the setting OFF results in an error message). If used as a query the command returns whether all parameters are set to default values (ON) or not (OFF).				

Measured Values – Subsystem MODulation:IQANalyzer[:OQPSk]

The subsystem *MODulation:IQANalyzer:...*? measures and returns the I and Q amplitudes as a function of time. The subsystem corresponds to the various output elements in the measurement menu *MODulation*, applications *I/Q Analyzer O-QPSK* and *I/Q Analyzer HPSK*.

READ[:SCALar]:MODulation:IQANalyzer[:OQPSk]? Scalar Results:				
READ[:SCALar]:MODulation:IQANalyzer:HPSK:DPCH?				
Start single shot measurement and return results				
FETCh[:SCALar]:MODulation:IQANalyzer[:OQPSk]? FETCh[:SCALar]:MODulation:IQANalyzer:HPSK:DPCH?				
Read out meas. results (unsynchronized)				
SAMPle[:SCALar]:MODulation:IQANalyzer[:OQPSk]? SAMPle[:SCALar]:MODulation:IQANalyzer:HPSK:DPCH?				
Read out measurement results (synchronized)				
Returned values	Value range	Def. value	Def. unit	FW vers.
EVM (RMS), Magnitude Error (RMS)	0.0 % to 100.0 %	NAN	%	V3.50
Phase Error (RMS), Waveform Quality	0.0 % to 100.0 %	NAN	%	
I/Q Imbalance, Carrier Feedthrough	-180.0 deg to +180.0 deg	NAN	deg	
MS Power	0.0 to 1.0	NAN	-	
	-100.0 dB to 0.0 dB (QPSK only)	NAN	dB	
	-120.0 dB to -20.0 dB	NAN	dB	
	-133.0 dBm to +19.0 dBm	NAN	dBm	
Description of command				
These commands are always queries. They start a <i>MODulation:IQANalyzer</i> measurement (<i>READ...</i>) and/or return all scalar measurement results (see Chapter 4).				

READ:ARRay:MODulation:IQANalyzer[:OQPSk]:IPHase? Normalized I/Q Amplitude				
READ:ARRay:MODulation:IQANalyzer:HPSK:DPCH:QPHase?				
Start single shot measurement and return results ⇒ <i>RUN</i>				
FETCh:ARRay:MODulation:IQANalyzer[:OQPSk]:IPHase? FETCh:ARRay:MODulation:IQANalyzer:HPSK:DPCH:QPHase?				
Read measurement results (unsynchronized) ⇒ <i>RUN</i>				
SAMPle:ARRay:MODulation:IQANalyzer[:OQPSk]:IPHase? SAMPle:ARRay:MODulation:IQANalyzer:HPSK:DPCH:QPHase?				
Read measurement results (synchronized) ⇒ <i>RUN</i>				
Returned values	Description of parameters	Def. value	Def. unit	FW vers.
-2.0 to +2.0,	1 st value for normalized I or Q amplitude	NAN	deg	V3.50
...	
-2.0 to +2.0	2464 th value for normalized I or Q amplitude	NAN	deg	
Description of command				
These commands are always queries. They return the normalized I and Q amplitudes. The 2064 output values correspond to 616 chip periods. The values no. 1, 5, 9, 13, ..., 2461 correspond to the decision points (symbol times), i.e. to the points in the constellation diagram; the remaining values correspond to the intermediate samples shown in the vector diagram and in the <i>I Phase</i> and <i>Q Phase</i> diagrams.				
The O-QPSK results are returned without offset compensation (see Chapter 4). This means that the constellation points correspond to the values no. 1, 5, 9, 13, ..., 2461 of the <i>I Phase</i> array, but to the values no. 3, 7, 11, 15, ..., 2463 of the <i>Q Phase</i> array.				

SPECTrum:ACP (ACP Spectrum)

The subsystem *SPECTrum:ACP* measures the power of four adjacent channel pairs. These four pairs correspond to symmetrical frequency offsets to the RF frequency (command [SENSe:]RFANalyzer:FREQuency[?]). The subsystem corresponds to the measurement menu *Spectrum* and the associated popup menu *Spectrum Configuration*.

Control of Measurement

The subsystem *SPECTrum:ACP* controls the adjacent channel power spectrum measurement. It corresponds to the softkey *ACP* in the measurement menu *Spectrum*.



The environment settings are not available in Non Signalling mode: The measurement is always performed with the general Connection Control parameters.

INITiate:SPECTrum:ACP	Start new measurement	⇒	<i>RUN</i>
ABORT:SPECTrum:ACP	Abort running measurement and switch off	⇒	<i>OFF</i>
STOP:SPECTrum:ACP	Stop measurement after current stat. cycle	⇒	<i>STOP</i>
CONTinue:SPECTrum:ACP	Next measurement step (<i>stepping mode</i>)	⇒	<i>RUN</i>
Description of command			FW vers.
These commands have no query form. They start and stop the ACP spectrum measurement, setting it to the status indicated in the top right column.			V3.40

CONFigure:SPECTrum:ACP:EREPorting[?]		Event Reporting		
<Report Mode>				
<Report Mode>	Description of parameters	Def. value	Def. unit	FW vers.
SRQ 	Service request	OFF	–	V3.40
SOPC 	Single operation complete			
SRSQ 	SRQ and SOPC			
DEFault 	Sets the value to the default setting			
OFF	No reporting			
Description of command				
This command defines the events generated when the measurement is terminated or stopped (see <i>Event Reporting</i> in Chapter 5 of the CMU manual).				

FETCh[:SCALar]:SPECTrum:ACP:STATus?		Measurement Status		
Return	Description of parameters	Def. value	Def. unit	FW vers.
OFF 	Measurement in the OFF state (*RST or ABORT)	OFF	–	V3.40
RUN 	Running (after INITiate, CONTInue or READ)			
STOP 	Stopped (STOP)			
ERR 	OFF (could not be started)			
STEP 	Stepping mode (<stepmode>=STEP)			
RDY	Stopped according to repetition mode and stop condition			
1 to 10000 	Counter for current statistics cycle	NONE	–	
NONE	No counting mode set			
1 to 1000	Counter for current evaluation period within a cycle	NONE	–	
NONE	Statistic count set to off			
Description of command				
This command is always a query. It returns the status of the measurement (see Chapters 3 and 5).				

Test Configuration

The commands of the following subsystems configure the *ACP Spectrum* measurement in the *Spectrum* menu. They correspond to the *Spectrum Configuration popup* menu.

Subsystem CONTROL

The subsystem *SPECTrum:ACP:CONTROL* configures the ACP Spectrum measurement. It defines the repetition mode, statistic count, stop condition and the offset frequencies of the measurement. It corresponds to the tab *Control* in the popup menu *Spectrum Configuration*.

CONFigure:SPECTrum:ACP:CONTROL[?] <Current Statistics>, <Repetition>, <Stop Cond>, <Step Mode>		Scope of Measurement		
<Current Statistics>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 1000,	Number of bursts per statistics cycle	100	–	V3.40
<Repetition>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 10000 CONTInuous SINGleshot DEFault,	Multiple measurement (<i>counting</i> , until <i>Status = STEP RDY</i>) Continuous measurement (until <i>STOP</i> or <i>ABORT</i>) Single shot measurement (until <i>Status = RDY</i>) Sets the value to the default setting	SING	–	V3.40
<Stop Cond>	Description of parameters	Def. value	Def. unit	FW vers.
NONE SONerror DEFault,	Continue measurement even in case of error Stop measurement in case of error (<i>stop on error</i>) Sets the value to the default setting	NONE	–	V3.40
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
STEP NONE DEFault	Interrupt measurement after each statistics cycle Continue measurement according to its rep. Mode Sets the value to the default setting	NONE	–	V3.40
Description of command				
This command combines the ...CONTROL:RMODe, ...CONTROL:STATistics and the ...CONTROL:REPetition commands, see below.				

CONFigure:SPECTrum:ACP:CONTROL:STATistics[?] <Current Statistics >		Statistic Count		
<Statistics Count>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 1000	Number of bursts per statistics cycle	100	–	V3.40
Description of command				
This command defines the number of bursts forming a statistics cycle.				

CONFigure:SPECTrum:ACP:CONTRol:REPetition[?] <Repetition>, <Stop Cond>, <Step Mode>		Test Cycles		
<Repetition>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 10000 CONTinuous SINGleshot DEFault ,	Multiple measurement (<i>counting</i> , until <i>Status</i> = <i>STEP</i> <i>RDY</i>) Continuous measurement (until <i>STOP</i> or <i>ABORT</i>) Single shot measurement (until <i>Status</i> = <i>RDY</i>) Sets the value to the default setting	SING	–	V3.40
<Stop Cond>	Description of parameters	Def. value	Def. unit	FW vers.
NONE SONerror DEFault ,	Continue measurement even in case of error Stop measurement in case of error (<i>stop on error</i>) Sets the value to the default setting	NONE	–	V3.40
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
STEP NONE DEFault	Interrupt measurement after each statistics cycle Continue measurement according to its rep. Mode Sets the value to the default setting	NONE	–	V3.40
Description of command				
This command determines the repetition mode, stop condition, and stepping mode for the measurement.				
Note: In the case of READ commands (<i>READ:...</i>), the <Repetition> parameter has no effect; the measurement is always stopped after a single shot.				

DEFault:SPECTrum:ACP:CONTRol[?]		Default Settings		
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	The parameters are set to their default values Some or all parameters are not set to default	ON	–	V3.40
Description of command				
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystem <i>SPECTrum:ACP:CONTRol</i> to their default values (the setting <i>OFF</i> results in an error message).				
If used as a query the command returns whether all parameters are set to their default values (<i>ON</i>) or not (<i>OFF</i>).				

CONFigure:SPECTrum:ACP:CONTRol:FOFFset:ACP<nr>[?] <Freq. Offset>		ACP Frequency Offset		
<Freq. Offset>	Description of parameters	Def. value	Def. unit	FW vers.
	The ACP frequency offset depends on the network standard:		Hz	V3.40
0 to 2 MHz OFF ON	Band Class 0, US Cellular Measurement disabled, result INV Enable measurement, last setting re-activated	<nr> = 1: 870.00 kHz <nr> = 2: 885.00 kHz <nr> = 3: 900.00 kHz <nr> = 4: 1980.00 kHz		
0 to 2 MHz OFF ON	Band Class 0, Korean Cellular Measurement disabled, result INV Enable measurement, last setting re-activated	<nr> = 1: 870.00 kHz <nr> = 2: 885.00 kHz <nr> = 3: 900.00 kHz <nr> = 4: 1980.00 kHz		
0 to 2 MHz OFF ON	Band Class 1, North American PCS Measurement disabled, result INV Enable measurement, last setting re-activated	<nr> = 1: 1150.00 kHz <nr> = 2: 1200.00 kHz <nr> = 3: 1250.00 kHz <nr> = 4: 1980.00 kHz		
0 to 2 MHz OFF ON	Band Class 2, TACS Measurement disabled, result INV Enable measurement, last setting re-activated	<nr> = 1: 870.00 kHz <nr> = 2: 885.00 kHz <nr> = 3: 900.00 kHz <nr> = 4: 1980.00 kHz		
0 to 2 MHz OFF ON	Band Class 3, JTACS Measurement disabled, result INV Enable measurement, last setting re-activated	<nr> = 1: 870.00 kHz <nr> = 2: 885.00 kHz <nr> = 3: 900.00 kHz <nr> = 4: 1980.00 kHz		
0 to 2 MHz OFF ON	Band Class 4, Korean PCS Measurement disabled, result INV Enable measurement, last setting re-activated	<nr> = 1: 1150.00 kHz <nr> = 2: 1200.00 kHz <nr> = 3: 1250.00 kHz <nr> = 4: 1980.00 kHz		
0 to 2 MHz OFF ON	Band Class 5, NMT 450 Measurement disabled, result INV Enable measurement, last setting re-activated	<nr> = 1: 870.00 kHz <nr> = 2: 885.00 kHz <nr> = 3: 900.00 kHz <nr> = 4: 1980.00 kHz		
0 to 2 MHz OFF ON	Band Class 6, IMT-2000 Measurement disabled, result INV Enable measurement, last setting re-activated	<nr> = 1: 1150.00 kHz <nr> = 2: 1200.00 kHz <nr> = 3: 1250.00 kHz <nr> = 4: 1980.00 kHz		
0 to 2 MHz OFF ON	Band Class 7, North American 700 MHz Measurement disabled, result INV Enable measurement, last setting re-activated	<nr> = 1: 870.00 kHz <nr> = 2: 885.00 kHz <nr> = 3: 900.00 kHz <nr> = 4: 1980.00 kHz		
0 to 2 MHz OFF ON	Band Class 8, 1800 MHz Measurement disabled, result INV Enable measurement, last setting re-activated	<nr> = 1: 1150.00 kHz <nr> = 2: 1200.00 kHz <nr> = 3: 1250.00 kHz <nr> = 4: 1980.00 kHz		
0 to 2 MHz OFF ON	Band Class 9, North American 900 MHz Measurement disabled, result INV Enable measurement, last setting re-activated	<nr> = 1: 870.00 kHz <nr> = 2: 885.00 kHz <nr> = 3: 900.00 kHz <nr> = 4: 1980.00 kHz		
0 to 2 MHz OFF ON	Band Class 10, Secondary 800 MHz Measurement disabled, result INV Enable measurement, last setting re-activated	<nr> = 1: 870.00 kHz <nr> = 2: 885.00 kHz <nr> = 3: 900.00 kHz <nr> = 4: 1980.00 kHz		
Description of command				
This command determines four frequency offset values (<nr> = 1 to 4) which define the four adjacent channel pairs. <i>OFF</i> will disable the measurement on the specified frequency pair and <i>INV</i> will be returned as result. See also the command CONFigure:NETWork:STANdard				

Subsystem LIMit

SPECTrum:ACP:LIMit

The subsystem *SPECTrum:ACP:LIMit* defines tolerance values for the ACP Spetrum measurement.

CONFigure:SPECTrum:ACP:LIMit:ACP<nr>[?] <ACP Limit>				Limits
<ACP Limit>	Description of parameters	Def. value	Def. unit	FW vers.
-80.0 to +10.0 OFF	Power limit for ACP<nr> Disables the tolerance check for ACP<nr>	<nr> = 1: -43 dB <nr> = 2: -43 dB <nr> = 3: -43 dB <nr> = 4: -54 dB	dB	V3.40
Description of command				
This command defines the upper power limits for the adjacent channel pairs <nr> = 1 to 4. These limits apply to any of the statistic evaluation modes (<i>Current</i> , <i>Average</i> and <i>Maximum</i>).				

DEFault:SPECTrum:ACP:LIMit[?] <Enable>				Default Settings
Enable	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	The parameters are set to their default values Some or all parameters are not set to default	ON	–	V3.40
Description of command				
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystem <i>SPECTrum:ACP:LIMit</i> to their default values (the setting <i>OFF</i> results in an error message).				
If used as a query, the command returns whether all parameters are set to their default values (<i>ON</i>) or not (<i>OFF</i>).				

Measured Values

The subsystem *SPECTrum:ACP* determines and outputs the results of the ACP Spectrum measurement.

XTND:SPECTrum:ACP:STATistics[?] <Enable>				Scope of scalar results
Enable	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	Statistical results returned No statistical results returned	OFF	–	V3.60
Description of command				
This command qualifies whether the READ[:SCALar]:SPECTrum:ACP?, FETCH...?, SAMPLE...? Return the statistical results <i>Out of Tolerance</i> and <i>Current Statistics</i> .				

Returned values		Value range	Def. value	Def. unit	FW vers.
Scalar results:					
READ[:SCALar]:SPECTrum:ACP?		Start single shot measurement and return results			
FETCh[:SCALar]:SPECTrum:ACP?		Read out measurement results (unsynchronized)			
SAMPle[:SCALar]:SPECTrum:ACP?		Read out measurement results (synchronized)			
Power of adj. Channel -4	(Current),	-80.0 dB to 0.0 dB	NAN	dB	V3.40
Power of adj. Channel -3	(Current),		NAN		
Power of adj. Channel -2	(Current),		NAN		
Power of adj. Channel -1	(Current),		NAN		
Power of adj. Channel +1	(Current),		NAN		
Power of adj. Channel +2	(Current),		NAN		
Power of adj. Channel +3	(Current),		NAN		
Power of adj. Channel +4	(Current),		NAN		
Power of adj. Channel -4	(Average),	-80.0 dB to 0.0 dB	NAN	dB	
Power of adj. Channel -3	(Average),		NAN		
Power of adj. Channel -2	(Average),		NAN		
Power of adj. Channel -1	(Average),		NAN		
Power of adj. Channel +1	(Average),		NAN		
Power of adj. Channel +2	(Average),		NAN		
Power of adj. Channel +3	(Average),		NAN		
Power of adj. Channel +4	(Average),		NAN		
Power of adj. Channel -4	(Maximum),	-80.0 dB to 0.0 dB	NAN	dB	
Power of adj. Channel -3	(Maximum),		NAN		
Power of adj. Channel -2	(Maximum),		NAN		
Power of adj. Channel -1	(Maximum),		NAN		
Power of adj. Channel +1	(Maximum),		NAN		
Power of adj. Channel +2	(Maximum),		NAN		
Power of adj. Channel +3	(Maximum),		NAN		
Power of adj. Channel +4	(Maximum),		NAN		
Channel Power	(Current),	-80.0 dBm to 0.0 dBm	NAN	dBm	
Channel Power	(Average),		NAN		
Channel Power	(Maximum),		NAN		
Out of Tolerance,		0 to 100 % ^{*)}	NAN	-	
Current Statistics		1 to 10000 ^{*)}	NAN	-	
Description of command					
These commands are always queries. They start a measurement and output all scalar measurement results.					
*) The statistical values are available only if they are enabled explicitly (XTND:SPECTrum:ACP:STATistics ON).					

CALCulate[:SCALar]:SPECTrum:ACP:MATChing:LIMit?		Limit Matching			
Returned values		Value range	Def. value	Def. unit	FW vers.
Tolerance Channel -4	(Current),	NMAU NMAL INV OK	INV	-	V3.40
Tolerance Channel -3	(Current),				
Tolerance Channel -2	(Current),				
Tolerance Channel -1	(Current),				
Tolerance Channel +1	(Current),				
Tolerance Channel +2	(Current),				
Tolerance Channel +3	(Current),				
Tolerance Channel +4	(Current),				
Tolerance Channel -4	(Average),	NMAU NMAL INV OK	INV	-	
Tolerance Channel -3	(Average),				
Tolerance Channel -2	(Average),				
Tolerance Channel -1	(Average),				
Tolerance Channel +1	(Average),				
Tolerance Channel +2	(Average),				
Tolerance Channel +3	(Average),				
Tolerance Channel +4	(Average),				
Tolerance Channel -4	(Maximum),	NMAU NMAL INV OK	INV	-	
Tolerance Channel -3	(Maximum),				
Tolerance Channel -2	(Maximum),				
Tolerance Channel -1	(Maximum),				
Tolerance Channel +1	(Maximum),				
Tolerance Channel +2	(Maximum),				
Tolerance Channel +3	(Maximum),				
Tolerance Channel +4	(Maximum),				
Description of command					
<p>This command is always a query. It indicates whether and in which way the (fixed) limit have been exceeded. The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i>, the <i>Average</i>, and the <i>Maximum</i> value. The following messages may be generated:</p>					
NMAU	Tolerance value underflow	<i>not matching, underflow</i>			
NMAL	Tolerance value exceeded	<i>not matching, overflow</i>			
INV	Measurement invalid	<i>invalid</i>			
OK	Tolerance value matched				

CDPower Measurements

The subsystem *CDPower* measures the Code Domain Power. The subsystem corresponds to the measurement menu *CDPower* and the sections related to this application in the associated popup menu *Code Domain Power Configuration*.

Common Settings – Subsystem CDPower:CPCCCommon (O-QPSK and H-PSK)

The subsystem *CDPower:CPCCCommon* ... configures the generated RF signal and defines the tolerance values. The settings are valid for all *Code Dom. Power* measurement applications.

Measurement Environment – Subsystem CDPower:CPCCCommon...:ENVIRONMENT

The subsystem *CDPower:CPCCCommon:ENVIRONMENT*... configures the generated RF signal. It corresponds to the *Measurement Environment* section in the *Control* tab of the *Code Dom. Power Configuration* menu. The settings are used only if the environment is enabled; see `CONFigure:CDPower:CPCCCommon:ENVIRONMENT:ENABLE`.



The environment settings are not available in Non Signalling mode: The measurement is always performed with the general Connection Control parameters.

CONFigure:CDPower:CPCCCommon:ENVIRONMENT:ENABLE[?]				Environment Enable	
<Enable>					
<Enable>	Description of parameters	Def. Value	Def. Unit	FW vers.	
ON OFF	Enable or disable environment	ON	–	V3.20	
Description of command					Sig. State
This command enables or disables the environment for all <i>Code Domain Power</i> measurement applications.					All

CONFigure:CDPower:CPCCCommon:ENVIRONMENT:POWER:CDMA[?]				CDMA Power	
<CDMA Power>					
<CDMA Power>	Description of parameters	Def. value	Def. unit	FW vers.	
–120.0 dBm to –33.0 dBm –120.0 dBm to –16.0 dBm –100.0 dBm to +7.0 dBm DEFault MINimum MAXimum	RF1 OUT, 0 dB ext. atten RF2 OUT, 0 dB ext. atten RF3 OUT, 0 dB ext. atten Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum	–50.0	dBm	V3.20	
Description of command					Sig. State
This command determines the total CDMA output power (absolute value, in dBm) of the CMU. The CDMA Power value range depends on the RF input used and the external attenuation set. If option R&S CMU-U99 (<i>RF 1 with RF 2 Level Range</i>) is fitted, RF 1 takes on the level range of RF2.					All

CONFigure:CDPower:CPCCommon:ENVironment:LEVel:FPICH[?]				F-PICH Level
<Pilot Level>				
<Pilot Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to -1.0 dB OFF	Pilot Level F-PICH switched off	-7.0	dB	V3.20
Description of command				Sig. State
This command determines the level in the forward pilot channel of the CMU. The channel power is in units relative to the total CDMA power.				All

CONFigure:CDPower:CPCCommon:ENVironment:LEVel:FFCH[?]				F-FCH Level
<FCH Level>				
<FCH Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to -1.0 dB OFF	FCH Level F-FCH switched off	-7.4	dB	V3.20
Description of command				Sig. State
This command determines the level in the forward fundamental channel of the CMU. The channel power is in units relative to the total CDMA power.				All

CONFigure:CDPower:CPCCommon:ENVironment:LEVel:FSCH:ZERO[?]				F-SCH0 Level
<SCH0 Level>				
<SCH0 Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to -1.0 dB OFF	F-SCH0 Level F-SCH0 switched off	-7.0	dB	V3.20
Description of command				Sig. State
This command determines the level in the forward SCH0 channel of the CMU. The channel power is in units relative to the total CDMA power.				All

CONFigure:CDPower:CPCCommon:ENVironment:LEVel:FSCH:ONE[?]				F-SCH1 Level
<SCH1 Level>				
<SCH1 Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to -1.0 dB OFF	F-SCH1 Level F-SCH1 switched off	-7.0	dB	V3.20
Description of command				Sig. State
This command determines the level in the forward SCH1 channel of the CMU. The channel power is in units relative to the total CDMA power.				All

CONFigure:CDPower:CPCCommon:ENVironment:EBNT:FFCH?				F-FCH Eb/Nt
<Eb/Nt>				
<Eb/Nt>	Description of parameters	Def. value	Def. unit	FW vers.
-30.969 dB to 18.072 dB	Calculated F-FCH Eb/Nt	-	dB	V3.20
Description of command				Sig. State
This command is always a query. It returns the calculated signal to noise ratio for the forward FCH. This quantity is undefined unless the AWGN generator is turned on (CONFigure:CDPower:CPCCommon:ENVironment:IMPairments:LEVel:AWGN). The quoted range of values is valid for data rates between 9.6 kbps and 153.6 kbps; see <i>Eb/Nt Calculation</i> in Chapter 4.				All

CONFigure:CDPower:CPCCommon:ENVironment:EBNT:FSCH:ZERO?				F-SCH0 Eb/Nt
<Eb/Nt>				
<Eb/Nt>	Description of parameters	Def. value	Def. unit	FW vers.
-30.969 dB to 18.072 dB	Calculated F-SCH0 Eb/Nt	-	dB	V3.20
Description of command				Sig. State
This command is always a query. It returns the calculated signal to noise ratio for the forward SCH0. This quantity is undefined unless the AWGN generator is turned on (CONFigure:CDPower:CPCCommon:ENVironment:IMPairments:LEVel:AWGN). The quoted range of values is valid for data rates between 9.6 kbps and 153.6 kbps; see <i>Eb/Nt Calculation</i> in Chapter 4.				All

CONFigure:CDPower:CPCCommon:ENVironment:EBNT:FSCH:ONE?				F-SCH1 Eb/Nt
<Eb/Nt>				
<Eb/Nt>	Description of parameters	Def. value	Def. unit	FW vers.
-30.969 dB to 18.072 dB	Calculated F-SCH1 Eb/Nt	-	dB	V3.20
Description of command				Sig. State
This command is always a query. It returns the calculated signal to noise ratio for the forward SCH1. This quantity is undefined unless the AWGN generator is turned on (CONFigure:CDPower:CPCCommon:ENVironment:IMPairments:LEVel:AWGN). The quoted range of values is valid for data rates between 9.6 kbps and 153.6 kbps; see <i>Eb/Nt Calculation</i> in Chapter 4.				All

CONFigure:CDPower:CPCCommon:ENVironment:FRATE:FFCH[?]				Frame Rate
<Frame Rate>				
<Frame Rate>	Description of parameters	Def. value	Def. unit	FW vers.
EIGHth QUARter HALF FULL DEFault	Frames at 1/8 of the rate set Frames at 1/4 of the rate set Frames at 1/2 of the rate set Frames at the full rate set	FULL	-	V3.20
Description of command				Sig. State
This command sets the frame rate for the variable rate traffic channel.				All

CONFigure:CDPower:CPCCommon:ENVironment:IMPairments:LEVel:AWGN[?]				AWGN Level
<AWGN Level>				
<AWGN Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to +4.0 dB DEFault MINimum MAXimum OFF,	AWGN level Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum	OFF	dB	V3.20
Description of command				Sig. State
This command determines an Additional White Gaussian Noise level to impair the CMU output signal.				All

CONFigure:CDPower:CPCCommon:ENVironment:IMPairments:FOFFset[?] <BS Freq Offset>		BS Frequency Offset		
<BS Freq Offset>	Description of parameters	Def. value	Def. unit	FW vers.
-50.0 kHz to +50.0 kHz DEFault MINimum MAXimum OFF	BS frequency offset Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum	OFF	Hz	V3.20
Description of command				Sig. State
This command determines a frequency offset to impair the CMU output signal.				All

CONFigure:CDPower:CPCCommon:ENVironment:IMPairments:ITFer[?] <FER>		Injected Tx FER		
<FER>	Description of parameters	Def. value	Def. unit	FW vers.
0% to 50% OFF ON	Injected Tx FER Switch FER injection off (equiv. to 0%) Re-activate FER injection, using the previously defined value	OFF	–	V3.20
Description of command				Sig. State
This command defines a percentage of faulty (i.e. erasure) frames that the CMU injects into all traffic channels of its BS Signal.				All

CONFigure:CDPower:CPCCommon:ENVironment:PCBits[?] <Power Control Bits>		Power Control Bits		
<Power Control Bits>	Description of parameters	Def. value	Def. unit	FW vers.
OFF AUTomatic HOLD ADOW AUP RTES PATTern	Disable power control bits Auto mode, closed-loop operation Alternating up/down control bits All power control bits down All power control bits up Range test mode Pattern defined by means of the CONF:BSS:PCB:PATTern... commands	AUT	–	V3.20
Description of command				Sig. State
This command selects the power control bit sequence that the CMU sends to the mobile station to control its output power.				All

Tolerance values – Subsystem CDPower:CPCCommon:LIMit

The subsystem *CDPower:CPCCommon:LIMit* defines tolerance values for the CDP measurement in all four applications. The subsystem corresponds to the *Limits* tab in the popup menu *Code Dom. Power Configuration*.

CONFigure:CDPower:CPCCommon:LIMit:IQLCheck[?] <Enable>				IQ Leakage Check	
Enable	Description of parameters	Def. value	Def. unit	FW vers.	
ON OFF	Enable or disable IQ Leakage Check	ON	–	V3.20	
Description of command				Sig. State	
This command enables or disables the I/Q Leakage Check. In the <i>OFF</i> setting, the limit check of each code channel is restricted to the active branch.				All	

CONFigure:CDPower:CPCCommon:CMAx:LIMit:ASYMmetric[:COMBined][?] <Carrier Feedthrough Limit>, <Freq Error Limit>, <Rho Limit>				Limits	
<Carrier Feedthrough Limit>	Description of parameters	Def. value	Def. unit		
–120.0 to –20.0 DEFault MINimum MAXimum OFF,	Carrier feedthrough limit Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum	–40.0	dB		
<Freq Error Limit>	Description of parameters	Def. value	Def. unit		
0 to 1000.0 Hz DEFault MINimum MAXimum OFF,	Carrier frequency error limit Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum	300.0	Hz		
<Rho Limit>	Description of parameters	Def. value	Def. unit	FW vers.	
0.0 to 1.0 DEFault MINimum MAXimum OFF	Correlated power to the total power ratio limit Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum	0.944	–	V3.05	
Description of command				Sig. State	
This command defines upper limits for the different traces and for the scalar modulation parameters derived from them. The keywords <i>CMAx</i> and <i>AVERage</i> refer to the <i>Current</i> and <i>Max.</i> display and for the <i>Average</i> display, respectively.				All	

CONFigure:CDPower:CPCCommon:AVERage:LIMit:ASYMmetric[:COMBined][?] <Carrier Feedthrough Limit Average>, <Freq Error Limit Average>, <Rho Limit Average>				Limits
<Carrier Feedthrough Limit>	Description of parameters	Def. value	Def. unit	
-120.0 to -20.0 DEFault MINimum MAXimum OFF,	Carrier feedthrough limit Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum	-40.0	dB	
<Freq Error Limit>	Description of parameters	Def. value	Def. unit	
0 to 1000.0 Hz DEFault MINimum MAXimum OFF,	Carrier frequency error limit Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum	300.0	Hz	
<Rho Limit>	Description of parameters	Def. value	Def. unit	FW vers.
0.0 to 1.0 DEFault MINimum MAXimum OFF	Correlated power to the total power ratio limit Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum	0.944	–	V3.05
Description of command				Sig. State
This command defines upper limits for the different traces and for the scalar modulation parameters derived from them. The keywords CMAX and AVERage refer to the Current and Max. display and for the Average display, respectively.				All

DEFault:CDPower:CPCCommon:LIMit[?] <Enable>				Default Settings
Enable	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	The parameters are set to their default values Some or all parameters are not set to default	ON	–	V3.05
Description of command				Sig. State
If used as a setting command with the parameter ON, this command sets all parameters of the subsystem CDPower:CPCCommon:LIMit to their default values (the setting OFF results in an error message).				All
If used as a query, the command returns whether all parameters are set to their default values (ON) or not (OFF).				

CDPower:CDPW

The subsystem *CDPower:CDPW* measures the MS Code Domain Power output. The subsystem corresponds to the measurement menu *Code Domain Power*, application *CDP*, and the sections related to this application in the associated popup menu *Code Domain Power Configuration*.

INITiate:CDPower:CDPW	Start new measurement	⇒	<i>RUN</i>
ABORt:CDPower:CDPW	Abort running measurement and switch off	⇒	<i>OFF</i>
STOP:CDPower:CDPW	Stop measurement after current stat. cycle	⇒	<i>STOP</i>
CONTInue:CDPower:CDPW	Next measurement step (<i>stepping mode</i>)	⇒	<i>RUN</i>
Description of command		Sig. State	FW vers.
These commands have no query form. They start and stop the code domain power measurement, setting it to the status indicated in the top right column.		All	V3.05

CONFigure:CDPower:CDPW:EREPorting[?]		Event Reporting		
<Report Mode>				
<Report Mode>	Description of parameters	Def. value	Def. unit	FW vers.
SRQ	Service request	OFF	–	V3.05
SOPC	Single operation complete			
SRSQ	SRQ and SOPC			
DEFault	Sets the value to the default setting			
OFF	No reporting			
Description of command				Sig. State
This command defines the events generated when the measurement is terminated or stopped (see <i>Event Reporting</i> in Chapter 5 of the CMU manual).				All

CONFigure:CDPower:CDPW:CMAX:LIMit:ASYMmetric[:COMBined][?]		Limits		
<CDP Limit Y>				
<CDP Limit Y>	Description of parameters	Def. value	Def. unit	FW vers.
–60.0 to 0	Peak code domain power Y limit	–23.0	dB	V3.05
MINimum	Sets the value to the range minimum			
MAXimum	Sets the value to the range maximum			
DEFault	Sets the value to the default setting			
OFF				
Description of command				Sig. State
This command defines the upper limit for the code domain power. The keywords <i>CMAX</i> and <i>AVERage</i> refer to the <i>Current</i> and <i>Max.</i> display and for the <i>Average</i> display, respectively.				All

CONFigure:CDPower:CDPW:AVERage:LIMit:ASYMmetric[:COMBined][?]		Limits		
<CDP Limit Y Average>				
<CDP Limit Y>	Description of parameters	Def. value	Def. unit	FW vers.
–60.0 to 0	Peak code domain power Y limit	–23.0	dB	V3.05
MINimum	Sets the value to the range minimum			
MAXimum	Sets the value to the range maximum			
DEFault	Sets the value to the default setting			
OFF				
Description of command				Sig. State
This command defines the upper limit for the code domain power. The keywords <i>CMAX</i> and <i>AVERage</i> refer to the <i>Current</i> and <i>Max.</i> display and for the <i>Average</i> display, respectively.				All

DEFault:CDPower:CDPW:LIMit[?] <Enable>				Default Settings
Enable	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	The parameters are set to their default values Some or all parameters are not set to default	ON	–	V3.05
Description of command				Sig. State
If used as a setting command with the parameter ON, this command sets all parameters of the subsystem CDPower:CDPW:LIMit to their default values (the setting OFF results in an error message). If used as a query, the command returns whether all parameters are set to their default values (ON) or not (OFF).				All

FETCh[:SCALar]:CDPower:CDPW:STATus?				Measurement Status
Return	Description of parameters	Def. value	Def. unit	FW vers.
OFF RUN STOP ERR STEP RDY	Measurement in the OFF state (*RST or ABORt) Running (after INITiate, CONTInue or READ) Stopped (STOP) OFF (could not be started) Stepping mode (<stepmode>=STEP) Stopped according to repetition mode and stop condition	OFF	–	V3.05
1 to 10000 NONE	Counter for current statistics cycle No counting mode set	NONE	–	
1 to 1000 NONE	Counter for current evaluation period within a cycle Statistic count set to off	NONE	–	
Description of command				Sig. State
This command is always a query. It returns the status of the measurement (see Chapters 3 and 5).				All

Subsystem CDPower:CDPW:CONTRol

The subsystem *CDPower:CDPW:CONTRol* defines the resultmode, repetition mode, statistic count, and stop condition of the measurement. These settings are provided in the *Control* tab in the popup menu *Code Domain Power Configuration*.

CONFigure:CDPower:CDPW:CONTRol[?]				Scope of Measurement
<Result Mode>, <Current Statistics>, <Repetition>, <Stop Cond>, <Step Mode>				
<Result Mode>	Description of parameters	Def. value	Def. unit	
SCALar ARRay,	Scalar values only (incl. ramp matching) Scalar measured values and arrays	ARR	–	
<Current Statistics>	Description of parameters	Def. value	Def. unit	
1 to 1000,	Number of bursts per statistics cycle	100	–	
<Repetition>	Description of parameters	Def. value	Def. unit	
1 to 10000 CONTInuous SINGleshot DEFault,	Multiple measurement (<i>counting</i> , until <i>Status = STEP RDY</i>) Continuous measurement (until <i>STOP</i> or <i>ABORT</i>) Single shot measurement (until <i>Status = RDY</i>) Sets the value to the default setting	SING	–	
<Stop Cond>	Description of parameters	Def. value	Def. unit	
NONE SONerror DEFault,	Continue measurement even in case of error Stop measurement in case of error (<i>stop on error</i>) Sets the value to the default setting	NONE	–	
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
STEP NONE DEFault	Interrupt measurement after each statistics cycle Continue measurement according to its rep. Mode Sets the value to the default setting	NONE	–	V3.05
Description of command				Sig. State
This command combines the <code>...CONTRol:RMODe</code> , <code>...CONTRol:STATistics</code> and the <code>...CONTRol:REPetition</code> commands, see below.				All

CONFigure:CDPower:CDPW:CONTRol:SFACTOR[?]				Spreading Factor
<Spreading_Factor>				
<Result Mode>	Description of parameters	Def. value	Def. unit	FW vers.
16 32	Spreading factor	32	–	V3.20
Description of command				Sig. State
This command defines the code class in which the uplink CDMA signal is evaluated.				All

CONFigure:CDPower:CDPW:CONTRol:RMODe[?]				Result mode
<Result Mode>				
<Result Mode>	Description of parameters	Def. value	Def. unit	FW vers.
SCALar ARRay	Scalar values only (incl. ramp matching) Scalar measured values and arrays	ARR	–	V3.05
Description of command				Sig. State
This command specifies the type of measured values.				All

CONFigure:CDPower:CDPW:CONTRol:STATistics[?] <Current Statistics >				Statistic Count
<Current Statistics>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 1000	Number of bursts per statistics cycle	100	–	V3.05
Description of command				Sig. State
This command defines the number of bursts forming a statistics cycle.				All

CONFigure:CDPower:CDPW:CONTRol:REPetition[?] <Repetition>, <Stop Cond>, <Step Mode>				Test Cycles
<Repetition>	Description of parameters	Def. value	Def. unit	
1 to 10000 CONTInuous SINGleshot DEFault,	Multiple measurement (<i>counting</i> , until <i>Status = STEP RDY</i>) Continuous measurement (until <i>STOP</i> or <i>ABORT</i>) Single shot measurement (until <i>Status = RDY</i>) Sets the value to the default setting	SING	–	
<Stop Cond>	Description of parameters	Def. value	Def. unit	
NONE SONerror DEFault,	Continue measurement even in case of error Stop measurement in case of error (<i>stop on error</i>) Sets the value to the default setting	NONE	–	
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
STEP NONE DEFault	Interrupt measurement after each statistics cycle Continue measurement according to its rep. Mode Sets the value to the default setting	NONE	–	V3.05
Description of command				Sig. State
This command determines the repetition mode, stop condition, and stepping mode for the measurement.				All
Note: <i>In the case of READ commands (READ:...), the <Repetition> parameter has no effect; the measurement is always stopped after a single shot.</i>				

CONFigure:CDPower:CDPW:CONTRol:RORDER[?] <Result Order>				Result Order
<Result Order>	Description of parameters	Def. value	Def. unit	FW vers.
HADamard BITReverse	Walsh code channels returned using Hadamard matrix Walsh code channels returned at MSB to LSB	HAD	–	V3.05
Description of command				Sig. State
This command defines the method used to display the code channels. HADamard displays the code channels in order determined by the Hadamard matrix. BITReverse displays the code channels so that the related code channels are adjacent to each other.				All
This setting is only available for Code Domain and Peak Code Domain Error measurement applications.				

Measured Values – Subsystem CDPower:CDPW

The subsystem *CDPower:CDPW* determines and outputs the results of the Code Domain Power measurement.

I Signal Measurement				
READ:ARRAY:CDPower:CHPW:ISIGNAL[:VALUE]:CURRENT?		Start single shot meas. and return results		
FETCH:ARRAY:CDPower:CHPW:ISIGNAL[:VALUE]:CURRENT?		Read meas. results (unsynchronized)		
SAMPLE:ARRAY:CDPower:CHPW:ISIGNAL[:VALUE]:CURRENT?		Read results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
I signal levels	Levels for R_PICH, R_DCCH, R_SCH1	NAN, NAN, NAN	dB	V3.05
Description of command				Sig. State
These commands are always queries. They start a measurement and output the levels of the physical channels in the in-phase signal path (I-signal).				All

I Signal Measurement				
READ:ARRAY:CDPower:CHPW:ISIGNAL[:VALUE]:AVERAGE?		Start single shot meas. and return results		
FETCH:ARRAY:CDPower:CHPW:ISIGNAL[:VALUE]:AVERAGE?		Read meas. results (unsynchronized)		
SAMPLE:ARRAY:CDPower:CHPW:ISIGNAL[:VALUE]:AVERAGE?		Read results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
I signal levels	Levels for R_PICH, R_DCCH, R_SCH1	NAN, NAN, NAN	dB	V3.05
Description of command				Sig. State
These commands are always queries. They start a measurement and output the levels of the physical channels in the in-phase signal path (I-signal).				All

I Signal Measurement				
READ:ARRAY:CDPower:CHPW:ISIGNAL[:VALUE]:MAXIMUM?		Start single shot meas. and return results		
FETCH:ARRAY:CDPower:CHPW:ISIGNAL[:VALUE]:MAXIMUM?		Read meas. results (unsynchronized)		
SAMPLE:ARRAY:CDPower:CHPW:ISIGNAL[:VALUE]:MAXIMUM?		Read results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
I signal levels	Levels for R_PICH, R_DCCH, R_SCH1	NAN, NAN, NAN	dB	V3.05
Description of command				Sig. State
These commands are always queries. They start a measurement and output the levels of the physical channels in the in-phase signal path (I-signal).				All

Q Signal Measurement				
READ:ARRAY:CDPower:CHPW:QSIGNAL[:VALUE]:CURRENT?		Start single shot meas. and return results		
FETCH:ARRAY:CDPower:CHPW:QSIGNAL[:VALUE]:CURRENT?		Read meas. results (unsynchronized)		
SAMPLE:ARRAY:CDPower:CHPW:QSIGNAL[:VALUE]:CURRENT?		Read results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
Q signal levels	Levels for R_FCH, R_SCH0, R_EACH, R_CCCH	NAN, NAN, NAN, NAN	dB	V3.05
Description of command				Sig. State
These commands are always queries. They start a measurement and output the levels of the physical channels in the quadrature signal path (Q-signal).				All

		Q Signal Measurement		
READ:ARRay:CDPower:CHPW:QSiGnal[:VALue]:AVERage?		Start single shot meas. and return results		
FETCh:ARRay:CDPower:CHPW:QSiGnal[:VALue]:AVERage?		Read meas. results (unsynchronized)		
SAMPlE:ARRay:CDPower:CHPW:QSiGnal[:VALue]:AVERage?		Read results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
Q signal levels	Levels for R_FCH, R_SCH0, R_EACH, R_CCCH	NAN, NAN, NAN, NAN	dB	V3.05
Description of command				Sig. State
These commands are always queries. They start a measurement and output the levels of the physical channels in the quadrature signal path (Q-signal).				All

		Q Signal Measurement		
READ:ARRay:CDPower:CHPW:QSiGnal[:VALue]:MAXimum?		Start single shot meas. and return results		
FETCh:ARRay:CDPower:CHPW:QSiGnal[:VALue]:MAXimum?		Read meas. results (unsynchronized)		
SAMPlE:ARRay:CDPower:CHPW:QSiGnal[:VALue]:MAXimum?		Read results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
Q signal levels	Levels for R_FCH, R_SCH0, R_EACH, R_CCCH	NAN, NAN, NAN, NAN	dB	V3.05
Description of command				Sig. State
These commands are always queries. They start a measurement and output the levels of the physical channels in the quadrature signal path (Q-signal).				All

		Active and inactive channels		
FETCh:ARRay:CDPower:CDPW:ISiGnal:STATe?		I signal contributions		
FETCh:ARRay:CDPower:CDPW:QSiGnal:STATe?		Q signal contributions		
Returned values	Value range	Def. value	Def. unit	FW vers.
0 1, ... 0 1	One value for each code channel: 0 denotes an active, 1 an inactive channel	NAN	–	V3.50
Description of command				Sig. State
These commands are always queries. They return the active and inactive channels in the I and Q branch, respectively. The number of values is 16 or 32, depending on the spreading factor set via <code>CONFigure:CDPower:CDPW:CONTRol:SFACTOR</code> .				All

		Scalar results:		
READ[:SCALAr]:CDPower:CDPW?		Start single shot measurement and return results		
FETCh[:SCALAr]:CDPower:CDPW?		Read out measurement results (unsynchronized)		
SAMPlE[:SCALAr]:CDPower:CDPW?		Read out measurement results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
MS Power (x3),	–100.0 dBm to –50.0 dBm	NAN	dBm	V3.05
Carrier Feedthrough (x3),	–120.0 dB to –20.0 dB	NAN	dB	
Frequency Error (x3),	0 to 1000.0 Hz	NAN	Hz	
Rho (x3),	0.0 to 1.0	NAN	–	
Out of Tolerance,	0.0% to 100.0%	NAN	–	
Current Statistics	1 to 10000	NAN	–	
Description of command				Sig. State
These commands are always queries. They start a measurement and output all scalar measurement results. The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i> , the <i>Average</i> , and the <i>MMax</i> value.				All

CALCulate[:SCALar]:CDPower:CDPW:MATChing:LIMit?			Limit Matching	
Returned values	Value range	Def. value	Def. unit	FW vers.
CDP Carrier Feedthrough (x3), CDP Frequency Error (x3), CDP Rho (x3)	For all values NMAU NMAL INV OK	INV INV INV	– – –	V3.05
Description of command				Sig. State
This command is always a query. It indicates whether and in which way the (fixed) limit have been exceeded. The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i> , the <i>Average</i> , and the <i>MMax</i> value. The following messages may be generated:				All
NMAU	Tolerance value underflow	<i>not matching, underflow</i>		
NMAL	Tolerance value exceeded	<i>not matching, overflow</i>		
INV	Measurement invalid	<i>invalid</i>		
OK	Tolerance value matched			

CALCulate:ARRay:CDPower:CDPW:ISIGnal:CURRent[:RESult]:MATChing:LIMit?			I Signal Tolerance	
Returned value	Description	Def. value	Def. unit	FW vers.
32 bit value	Indicator for limit matching in code channel 0 (least significant bit) to 31	NAN	–	V3.05
Description of command				Sig. State
This command is always a query. If a bit is set in the returned value the I signal limit in the corresponding code channel is exceeded.				All

CALCulate:ARRay:CDPower:CDPW:ISIGnal:AVERage[:RESult]:MATChing:LIMit?			I Signal Tolerance	
Returned value	Description	Def. value	Def. unit	FW vers.
32 bit value	Indicator for limit matching in code channel 0 (least significant bit) to 31	NAN	–	V3.05
Description of command				Sig. State
This command is always a query. If a bit is set in the returned value the I signal limit in the corresponding code channel is exceeded.				All

CALCulate:ARRay:CDPower:CDPW:ISIGnal:MAXimum[:RESult]:MATChing:LIMit?			I Signal Tolerance	
Returned value	Description	Def. value	Def. unit	FW vers.
32 bit value	Indicator for limit matching in code channel 0 (least significant bit) to 31	NAN	–	V3.05
Description of command				Sig. State
This command is always a query. If a bit is set in the returned value the I signal limit in the corresponding code channel is exceeded.				All

CALCulate:ARRay:CDPower:CDPW:QSIGnal:CURRent[:RESult]:MATChing:LIMit?			Q Signal Tolerance	
Returned value	Description	Def. value	Def. unit	FW vers.
32 bit value	Indicator for limit matching in code channel 0 (least significant bit) to 31	NAN	–	V3.05
Description of command				Sig. State
This command is always a query. If a bit is set in the returned value the Q signal limit in the corresponding code channel is exceeded.				All

CALCulate:ARRay:CDPower:CDPW:QSiGnal:AVERage[:RESult]:MATChing:LIMit?				Q Signal Tolerance
Returned value	Description	Def. value	Def. unit	FW vers.
32 bit value	Indicator for limit matching in code channel 0 (least significant bit) to 31	NAN	–	V3.05
Description of command				Sig. State
This command is always a query. If a bit is set in the returned value the Q signal limit in the corresponding code channel is exceeded.				All

CALCulate:ARRay:CDPower:CDPW:QSiGnal:MAXimum[:RESult]:MATChing:LIMit?				Q Signal Tolerance
Returned value	Description	Def. value	Def. unit	FW vers.
32 bit value	Indicator for limit matching in code channel 0 (least significant bit) to 31	NAN	–	V3.05
Description of command				Sig. State
This command is always a query. If a bit is set in the returned value the Q signal limit in the corresponding code channel is exceeded.				All

CDPower:PCDep

The subsystem *CDPower:PCDep* measures the MS Peak Code Domain Error Power output. The subsystem corresponds to the measurement menu *Code Domain Power*, application *PCDep*, and the sections related to this application in the associated popup menu *Code Domain Power Configuration*.

Control of measurement – Subsystem CDPower:PCDep

The subsystem *CDPower:PCDep* controls the code domain error power measurement.

INITiate:CDPower:PCDep	Start new measurement	⇒	<i>RUN</i>
ABORT:CDPower:PCDep	Abort running measurement and switch off	⇒	<i>OFF</i>
STOP:CDPower:PCDep	Stop measurement after current stat. cycle	⇒	<i>STOP</i>
CONTinue:CDPower:PCDep	Next measurement step (<i>stepping mode</i>)	⇒	<i>RUN</i>
Description of command			Sig. State
These commands have no query form. They start and stop the code domain error power measurement, setting it to the status indicated in the top right column.			All
			FW vers.
			V3.05

CONFigure:CDPower:PCDep:EREPorting[?]				Event Reporting
<Report Mode>				
<Report Mode>	Description of parameters	Def. value	Def. unit	FW vers.
SRQ	Service request	OFF	–	V3.05
SOPC	Single operation complete			
SRSQ	SRQ and SOPC			
OFF	No reporting			
Description of command				Sig. State
This command defines the events generated when the measurement is terminated or stopped (see <i>Event Reporting</i> in Chapter 5 of the CMU manual).				All

CONFigure:CDPower:PCDep:CMAx:LIMit:ASYMmetric[:COMBined][?]				Limits
<CDP Limit Y>				
<PCDep Limit Y>	Description of parameters	Def. value	Def. unit	FW vers.
-60.0 to 0 DEFault MINimum MAXimum OFF	Peak code domain error power limit Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum	-23.0	dB	V3.05
Description of command				Sig. State
This command defines the upper limit for the peak code domain error power. The keywords CMAx and AVERage refer to the <i>Current</i> and <i>Max.</i> display and for the <i>Average</i> display, respectively.				All

CONFigure:CDPower:PCDep:AVERage:LIMit:ASYMmetric[:COMBined][?]				Limits
<PCD Limit Y Average>				
<PCDep Limit Y>	Description of parameters	Def. value	Def. unit	FW vers.
-60.0 to 0 DEFault MINimum MAXimum OFF	Peak code domain error power limit Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum	-23.0	dB	V3.05
Description of command				Sig. State
This command defines the upper limit for the peak code domain error power. The keywords CMAx and AVERage refer to the <i>Current</i> and <i>Max.</i> display and for the <i>Average</i> display, respectively.				All

DEFault:CDPower:PCDep:LIMit[?]				Default Settings
<Enable>				
Enable	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	The parameters are set to their default values Some or all parameters are not set to default	ON	-	V3.05
Description of command				Sig. State
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystem DEFault:CDPower:PCDep:LIMit to their default values (the setting <i>OFF</i> results in an error message).				All
If used as a query, the command returns whether all parameters are set to their default values (<i>ON</i>) or not (<i>OFF</i>).				

FETCh[:SCALar]:CDPower:PCDep:STATus?		Measurement Status		
Return	Description of parameters	Def. value	Def. unit	FW vers.
OFF RUN STOP ERR STEP RDY	Measurement in the OFF state (*RST or ABORT) Running (after INITiate, CONTInue or READ) Stopped (STOP) OFF (could not be started) Stepping mode (<stepmode>=STEP) Stopped according to repetition mode and stop condition	OFF	–	V3.05
1 to 10000 NONE	Counter for current statistics cycle No counting mode set	NONE	–	
1 to 1000 NONE	Counter for current evaluation period within a cycle Statistic count set to off	NONE	–	
Description of command				Sig. State
This command is always a query. It returns the status of the measurement (see Chapters 3 and 5).				All

Subsystem CDPower:PCDep:CONTRol

The subsystem *CDPower:PCDep:CONTRol* defines the result mode, repetition mode, statistic count, and stop condition of the measurement. These settings are provided in the *Control* tab in the popup menu *Code Domain Power Configuration*.

CONFIgure:CDPower:PCDep:CONTRol[?] <Result Mode>, <Current Statistics>, <Repetition>, <Stop Cond>, <Step Mode>		Scope of Measurement		
<Result Mode>	Description of parameters	Def. value	Def. unit	
SCALar ARRay,	Scalar values only (incl. ramp matching) Scalar measured values and arrays	ARR	–	
<Current Statistics>	Description of parameters	Def. value	Def. unit	
1 to 1000,	Number of bursts per statistics cycle	100	–	
<Repetition>	Description of parameters	Def. value	Def. unit	
1 to 10000 CONTInuous SINGleshot DEFault,	Multiple measurement (counting, until Status = STEP RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–	
<Stop Cond>	Description of parameters	Def. value	Def. unit	
NONE SONerror DEFault,	Continue measurement even in case of error Stop measurement in case of error (<i>stop on error</i>) Sets the value to the default setting	NONE	–	
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
STEP NONE DEFault	Interrupt measurement after each statistics cycle Continue measurement according to its rep. Mode Sets the value to the default setting	NONE	–	V3.05
Description of command				Sig. State
This command combines the ...CONTRol:RMODe, ...CONTRol:STATistics and the ...CONTRol:REPetition commands, see below.				All

CONFigure:CDPower:PCDep:CONTRol:RMODE[?]				Result Mode	
<Result Mode> mode					
<Result Mode>	Description of parameters	Def. value	Def. unit	FW vers.	
SCALar ARRay	Scalar values only (incl. ramp matching) Scalar measured values and arrays	ARR	–	V3.05	
Description of command					Sig. State
This command specifies the type of measured values.					All

CONFigure:CDPower:PCDep:CONTRol:SFACTOR[?]				Spreading Factor	
<Spreading_Factor>					
<Result Mode>	Description of parameters	Def. value	Def. unit	FW vers.	
16 32	Spreading factor	32	–	V3.20	
Description of command					Sig. State
This command defines the code class in which the uplink CDMA signal is evaluated.					All

CONFigure:CDPower:PCDep:CONTRol:RORDER[?]				Result Order	
<Result Order>					
<Result Order>	Description of parameters	Def. value	Def. unit	FW vers.	
HADamard BITReverse	Walsh code channels returned using Hadamard matrix Walsh code channels returned at MSB to LSB	HAD	–	V3.05	
Description of command					Sig. State
This command defines the method used to display the code channels. HADamard displays the code channels in order determined by the Hadamard matrix. BITReverse displays the code channels so that the related code channels are adjacent to each other.					All
This setting is only available for Code Domain and Peak Code Domain Error measurement applications.					

CONFigure:CDPower:PCDep:CONTRol:STATistics[?]				Statistic Count	
<Current Statistics>					
<Current Statistics>	Description of parameters	Def. value	Def. unit	FW vers.	
1 to 1000	Number of bursts per statistics cycle	100	–	V3.05	
Description of command					Sig. State
This command defines the number of bursts forming a statistics cycle.					All

CONFigure:CDPower:PCDep:CONTRol:REPetition[?] <Repetition>, <Stop Cond>, <Step Mode>				Test Cycles	
<Repetition>	Description of parameters	Def. value	Def. unit		
1 to 10000 CONTInuous SINGleshot DEFault,	Multiple measurement (counting, until Status = STEP RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–		
<Stop Cond>	Description of parameters	Def. value	Def. unit		
NONE SONerror DEFault,	Continue measurement even in case of error Stop measurement in case of error (<i>stop on error</i>) Sets the value to the default setting	NONE	–		
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.	
STEP NONE DEFault	Interrupt measurement after each statistics cycle Continue measurement according to its rep. Mode Sets the value to the default setting	NONE	–	V3.05	
Description of command					Sig. State
This command determines the repetition mode, stop condition, and stepping mode for the measurement.					All
Note: <i>In the case of READ commands (READ:...), the <Repetition> parameter has no effect; the measurement is always stopped after a single shot.</i>					

Measured Values – Subsystem CDPower:PCDep

The subsystem *CDPower:PCDep* determines and outputs the results of the Code Domain Error Power. This is the difference between the ideal code domain power and the measured signal.

READ:ARRay:CDPower:PCDep:ISIGnal[:VALue]:CURRent? FETCh:ARRay:CDPower:PCDep:ISIGnal[:VALue]:CURRent? SAMPle:ARRay:CDPower:PCDep:ISIGnal[:VALue]:CURRent?				I Signal Measurement	
				Start single shot meas. and return results Read meas. results (unsynchronized) Read results (synchronized)	
Returned values	Description of parameters	Def. value	Def. unit	FW vers.	
Walsh code	W_0^{32} to W_{31}^{32} for spreading factor 32 W_0^{16} to W_{31}^{16} for spreading factor 16	NAN		V3.05 V3.20	
Description of command					Sig. State
These commands are always queries. They start a measurement and output the levels of the Walsh Code of the in phase signal path (I-signal). The number of values depends on the spreading factor set via CONFigure:CDPower:PCDep:CONTRol:SFACTOR.					All

Returned values		Description of parameters	Def. value	Def. unit	FW vers.
Walsh code		W_0^{32} to W_{31}^{32} for spreading factor 32 W_0^{16} to W_{31}^{16} for spreading factor 16	NAN		V3.05 V3.20
Description of command					Sig. State
These commands are always queries. They start a measurement and output the levels of the Walsh Code of the in phase signal path (I-signal). The number of values depends on the spreading factor set via <code>CONFigure:CDPower:PCDep:CONTRol:SFActor</code> .					All

Returned values		Description of parameters	Def. value	Def. unit	FW vers.
Walsh code		W_0^{32} to W_{31}^{32} for spreading factor 32 W_0^{16} to W_{31}^{16} for spreading factor 16	NAN		V3.05 V3.20
Description of command					Sig. State
These commands are always queries. They start a measurement and output the levels of the Walsh Code of the in phase signal path (I-signal). The number of values depends on the spreading factor set via <code>CONFigure:CDPower:PCDep:CONTRol:SFActor</code> .					All

Returned values		Description of parameters	Def. value	Def. unit	FW vers.
Walsh code		W_0^{32} to W_{31}^{32} for spreading factor 32 W_0^{16} to W_{31}^{16} for spreading factor 16	NAN		V3.05 V3.20
Description of command					Sig. State
These commands are always queries. They start a measurement and output the levels of the Walsh Code of the quadrature signal path (Q-signal). The number of values depends on the spreading factor set via <code>CONFigure:CDPower:PCDep:CONTRol:SFActor</code> .					All

Returned values		Description of parameters	Def. value	Def. unit	FW vers.
Walsh code		W_0^{32} to W_{31}^{32} for spreading factor 32 W_0^{16} to W_{31}^{16} for spreading factor 16	NAN		V3.05 V3.20
Description of command					Sig. State
These commands are always queries. They start a measurement and output the levels of the Walsh Code of the quadrature signal path (Q-signal). The number of values depends on the spreading factor set via <code>CONFigure:CDPower:PCDep:CONTRol:SFActor</code> .					All

		Q Signal Measurement		
READ:ARRAY:CDPower:PCDep:QSignal[:VALue]:MAXimum?		Start single shot meas. and return results		
FETCh:ARRAY:CDPower:PCDep:QSignal[:VALue]:MAXimum?		Read meas. results (unsynchronized)		
SAMPlE:ARRAY:CDPower:PCDep:QSignal[:VALue]:MAXimum?		Read results (synchronized)		
Returned values	Description of parameters	Def. value	Def. unit	FW vers.
Walsh code	W_0^{32} to W_{31}^{32} for spreading factor 32 W_0^{16} to W_{31}^{16} for spreading factor 16	NAN		V3.05 V3.20
Description of command				Sig. State
These commands are always queries. They start a measurement and output the levels of the Walsh Code of the quadrature signal path (Q-signal). The number of values depends on the spreading factor set via <code>CONFigure:CDPower:PCDep:CONTRol:SFACTOR</code> .				All

		Active and inactive channels		
FETCh:ARRAY:CDPower:PCDep:ISignal:STATe?		I signal contributions		
FETCh:ARRAY:CDPower:PCDep:QSignal:STATe?		Q signal contributions		
Returned values	Value range	Def. value	Def. unit	FW vers.
0 1, ... 0 1	One value for each code channel: 0 denotes an active, 1 an inactive channel	NAN	–	V3.50
Description of command				Sig. State
These commands are always queries. They return the active and inactive channels in the I and Q branch, respectively. The number of values is 16 or 32, depending on the spreading factor set via <code>CONFigure:CDPower:PCDep:CONTRol:SFACTOR</code> .				All

		Scalar results:		
READ[:SCALar]:CDPower:PCDep?		Start single shot measurement and return results		
FETCh[:SCALar]:CDPower:PCDep?		Read out measurement results (unsynchronized)		
SAMPlE[:SCALar]:CDPower:PCDep?		Read out measurement results (synchronized)		
Returned values	Description	Def. value	Def. unit	FW vers.
MS Power (x3),	–100.0 dBm to –50.0 dBm	NAN	dBm	V3.05
Carrier Feedthrough (x3),	–120.0 dB to –20.0 dB	NAN	dB	
Frequency Error (x3),	0 to 1000.0 Hz	NAN	Hz	
Rho (x3),	0.0 to 1.0	NAN	–	
Out of Tolerance,	0.0% to 100.0%	NAN	–	
Current Statistics	1 to 10000	NAN	–	
Description of command				Sig. State
These commands are always queries. They start a measurement and output all scalar measurement results. The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i> , the <i>Average</i> , and the <i>MMax</i> value.				All

CALCulate[:SCALar]:CDPower:PCDep:MATChing:LIMit?			Limit Matching	
Returned values	Description	Def. value	Def. unit	FW vers.
PCDep Carrier Feedthrough (x3), PCDep Frequency Error (x3), PCDep Rho (x3)	For all values NMAU NMAL INV OK	NAN	– – –	V3.05
Description of command				Sig. State
This command is always a query. It indicates whether and in which way the (fixed) limit have been exceeded. The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i> , the <i>Average</i> , and the <i>MMax</i> value. The following messages may be generated:				All
NMAU	Tolerance value underflow	<i>not matching, underflow</i>		
NMAL	Tolerance value exceeded	<i>not matching, overflow</i>		
INV	Measurement invalid	<i>invalid</i>		
OK	Tolerance value matched			

CALCulate:ARRay:CDPower:PCDep:ISIGnal:CURRent[:RESult]:MATChing:LIMit?			I Signal Tolerance	
Returned value	Description	Def. value	Def. unit	FW vers.
32 bit value	Indicator for limit matching in code channel 0 (least significant bit) to 31	NAN	–	V3.05
Description of command				Sig. State
This command is always a query. If a bit is set in the returned value the I signal limit in the corresponding code channel is exceeded.				All

CALCulate:ARRay:CDPower:PCDep:ISIGnal:AVERage[:RESult]:MATChing:LIMit?			I Signal Tolerance	
Returned value	Description	Def. value	Def. unit	FW vers.
32 bit value	Indicator for limit matching in code channel 0 (least significant bit) to 31	NAN	–	V3.05
Description of command				Sig. State
This command is always a query. If a bit is set in the returned value the I signal limit in the corresponding code channel is exceeded.				All

CALCulate:ARRay:CDPower:PCDep:ISIGnal:MAXimum[:RESult]:MATChing:LIMit?			I Signal Tolerance	
Returned value	Description	Def. value	Def. unit	FW vers.
32 bit value	Indicator for limit matching in code channel 0 (least significant bit) to 31	NAN	–	V3.05
Description of command				Sig. State
This command is always a query. If a bit is set in the returned value the I signal limit in the corresponding code channel is exceeded.				All

CALCulate:ARRay:CDPower:PCDep:QSIGnal:CURRent[:RESult]:MATChing:LIMit?			Q Signal Tolerance	
Returned value	Description	Def. value	Def. unit	FW vers.
32 bit value	Indicator for limit matching in code channel 0 (least significant bit) to 31	NAN	–	V3.05
Description of command				Sig. State
This command is always a query. If a bit is set in the returned value the Q signal limit in the corresponding code channel is exceeded.				All

CALCulate:ARRay:CDPower:PCDep:QSIGnal:AVERage[:RESult]:MATChing:LIMit?			Q Signal Tolerance	
Returned value	Description	Def. value	Def. unit	FW vers.
32 bit value	Indicator for limit matching in code channel 0 (least significant bit) to 31	NAN	–	V3.05
Description of command				Sig. State
This command is always a query. If a bit is set in the returned value the Q signal limit in the corresponding code channel is exceeded.				All

CALCulate:ARRay:CDPower:PCDep:QSIGnal:MAXimum[:RESult]:MATChing:LIMit?			Q Signal Tolerance	
Returned value	Description	Def. value	Def. unit	FW vers.
32 bit value	Indicator for limit matching in code channel 0 (least significant bit) to 31	NAN	–	V3.05
Description of command				Sig. State
This command is always a query. If a bit is set in the returned value the Q signal limit in the corresponding code channel is exceeded.				All

CDPower:CHPW

The subsystem *CDPower:CHPW* measures the Channel Power. The subsystem corresponds to the measurement menu *Code Domain Power*, application *Channel Power*, and the sections related to this application in the associated popup menu *Code Domain Power Configuration*.

Control of measurement – Subsystem CDPower:CHPW

The subsystem *CDPower:CHPW* controls the channel power measurement.

INITiate:CDPower:CHPW	Start new measurement	⇒	<i>RUN</i>
ABORT:CDPower:CHPW	Abort running measurement and switch off	⇒	<i>OFF</i>
STOP:CDPower:CHPW	Stop measurement after current stat. cycle	⇒	<i>STOP</i>
CONTinue:CDPower:CHPW	Next measurement step (<i>stepping mode</i>)	⇒	<i>RUN</i>
Description of command			Sig. State FW vers.
These commands have no query form. They start and stop the channel power measurement, setting it to the status indicated in the top right column.			All V3.05

CONFigure:CDPower:CHPW:EREPorting[?]			Event Reporting	
<Report Mode>	Description of parameters	Def. value	Def. unit	FW vers.
SRQ	Service request	OFF	–	V3.05
SOPC	Single operation complete			
SRSQ	SRQ and SOPC			
OFF	No reporting			
Description of command				Sig. State
This command defines the events generated when the measurement is terminated or stopped (see <i>Event Reporting</i> in Chapter 5 of the CMU manual).				All

CONFigure:CDPower:CHPW:CMAX:LIMit:ASYMmetric[:COMBined][?] <CHPW Limit Y>				Limits
<CHPW Limit Y>	Description of parameters	Def. value	Def. unit	FW vers.
-60.0 to 0 MINimum MAXimum DEFAULT OFF	Channel power Y limit Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	-23.0	dB	V3.05
Description of command				Sig. State
This command defines the upper limit for the channel power (Y value). The keywords <i>CMAX</i> and <i>AVERage</i> refer to the <i>Current</i> and <i>Max.</i> display and for the <i>Average</i> display, respectively.				All

CONFigure:CDPower:CHPW:AVERage:LIMit:ASYMmetric[:COMBined][?] <CHPW Limit Y Average>				Limits
<CHPW Limit Y Average>	Description of parameters	Def. value	Def. unit	FW vers.
-60.0 to 0 MINimum MAXimum DEFAULT OFF	Channel power Y limit Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	-23.0	dB	V3.05
Description of command				Sig. State
This command defines the upper limit for the channel power (Y value). The keywords <i>CMAX</i> and <i>AVERage</i> refer to the <i>Current</i> and <i>Max.</i> display and for the <i>Average</i> display, respectively.				All

DEFault:CDPower:CHPW:LIMit[?] <Enable>				Default Settings
Enable	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	The parameters are set to their default values Some or all parameters are not set to default	ON	-	V3.05
Description of command				Sig. State
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystem <i>CDPower:CHPW:LIMit</i> to their default values (the setting <i>OFF</i> results in an error message). If used as a query, the command returns whether all parameters are set to their default values (<i>ON</i>) or not (<i>OFF</i>).				All

FETCh[:SCALar]:CDPower:CHPW:STATus?		Measurement Status		
Return	Description of parameters	Def. value	Def. unit	FW vers.
OFF RUN STOP ERR STEP RDY	Measurement in the OFF state (*RST or ABORT) Running (after INITiate, CONTInue or READ) Stopped (STOP) OFF (could not be started) Stepping mode (<stepmode>=STEP) Stopped according to repetition mode and stop condition	OFF	–	V3.05
1 to 10000 NONE	Counter for current statistics cycle No counting mode set	NONE	–	
1 to 1000 NONE	Counter for current evaluation period within a cycle Statistic count set to off	NONE	–	
Description of command				Sig. State
This command is always a query. It returns the status of the measurement (see Chapters 3 and 5).				All

Subsystem CDPower:CHPW:CONTRol

The subsystem *CDPower:CHPW:CONTRol* defines the result mode, repetition mode, statistic count, and stop condition of the measurement. These settings are provided in the *Control* tab in the popup menu *Code Domain Power Configuration*.

CONFIgure:CDPower:CHPW:CONTRol[?] <Result Mode>, <Current Statistics>, <Repetition>, <Stop Cond>, <Step Mode>		Scope of Measurement		
<Result Mode>	Description of parameters	Def. value	Def. unit	
SCALar ARRay,	Scalar values only (incl. ramp matching) Scalar measured values and arrays	ARR	–	
<Current Statistics>	Description of parameters	Def. value	Def. unit	
1 to 1000,	Number of bursts per statistics cycle	100	–	
<Repetition>	Description of parameters	Def. value	Def. unit	
1 to 10000 CONTInuous SINGleshot DEFault,	Multiple measurement (counting, until Status = STEP RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–	
<Stop Cond>	Description of parameters	Def. value	Def. unit	
NONE SONerror DEFault,	Continue measurement even in case of error Stop measurement in case of error (<i>stop on error</i>) Sets the value to the default setting	NONE	–	
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
STEP NONE DEFault	Interrupt measurement after each statistics cycle Continue measurement according to its rep. Mode Sets the value to the default setting	NONE	–	V3.05
Description of command				Sig. State
This command combines the ...CONTRol:RMODE, ...CONTRol:STATistics and the ...CONTRol:REPetition commands, see below.				All

CONFigure:CDPower:CHPW:CONTRol:RMODE[?] <Result Mode>				Result Mode
<Result Mode>	Description of parameters	Def. value	Def. unit	FW vers.
SCALar ARRay	Scalar values only (incl. ramp matching) Scalar measured values and arrays	ARR	–	V3.05
Description of command				Sig. State
This command specifies the type of measured values.				All

CONFigure:CDPower:CHPW:CONTRol:STATistics[?] <Current Statistics >				Statistic Count
<Current Statistics>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 1000	Number of bursts per statistics cycle	100	–	V3.05
Description of command				Sig. State
This command defines the number of bursts forming a statistics cycle.				All

CONFigure:CDPower:CHPW:CONTRol:REPetition[?] <Repetition>, <Stop Cond>, <Step Mode>				Test Cycles
<Repetition>	Description of parameters	Def. value	Def. unit	
1 to 10000 CONTInuous SINGleshot DEFault,	Multiple measurement (counting, until Status = STEP RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–	
<Stop Cond>	Description of parameters	Def. value	Def. unit	
NONE SONerror DEFault,	Continue measurement even in case of error Stop measurement in case of error (<i>stop on error</i>) Sets the value to the default setting	NONE	–	
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
STEP NONE DEFault	Interrupt measurement after each statistics cycle Continue measurement according to its rep. Mode Sets the value to the default setting	NONE	–	V3.05
Description of command				Sig. State
This command determines the repetition mode, stop condition, and stepping mode for the measurement.				All
Note: <i>In the case of READ commands (READ:...), the <Repetition> parameter has no effect; the measurement is always stopped after a single shot.</i>				

Measured Values – Subsystem CDPower:CHPW...?

The subsystem *CDPower:CHPW...?* determines and outputs the results of the Channel Power.

I Signal Measurement				
READ:ARRay:CDPower:CHPW:ISIGnal[:VALue]:CURRent?		Start single shot meas. and return results		
FETCh:ARRay:CDPower:CHPW:ISIGnal[:VALue]:CURRent?		Read meas. results (unsynchronized)		
SAMPlE:ARRay:CDPower:CHPW:ISIGnal[:VALue]:CURRent?		Read results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
I signal levels	Levels for R_PICH, R_DCCH, R_SCH1	NAN, NAN, NAN	dB	V3.05
Description of command				Sig. State
These commands are always queries. They start a measurement and output the levels of the physical channels in the in-phase signal path (I-signal).				All

I Signal Measurement				
READ:ARRay:CDPower:CHPW:ISIGnal[:VALue]:AVERAge?		Start single shot meas. and return results		
FETCh:ARRay:CDPower:CHPW:ISIGnal[:VALue]:AVERAge?		Read meas. results (unsynchronized)		
SAMPlE:ARRay:CDPower:CHPW:ISIGnal[:VALue]:AVERAge?		Read results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
I signal levels	Levels for R_PICH, R_DCCH, R_SCH1	NAN, NAN, NAN	dB	V3.05
Description of command				Sig. State
These commands are always queries. They start a measurement and output the levels of the physical channels in the in-phase signal path (I-signal).				All

I Signal Measurement				
READ:ARRay:CDPower:CHPW:ISIGnal[:VALue]:MAXimum?		Start single shot meas. and return results		
FETCh:ARRay:CDPower:CHPW:ISIGnal[:VALue]:MAXimum?		Read meas. results (unsynchronized)		
SAMPlE:ARRay:CDPower:CHPW:ISIGnal[:VALue]:MAXimum?		Read results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
I signal levels	Levels for R_PICH, R_DCCH, R_SCH1	NAN, NAN, NAN	dB	V3.05
Description of command				Sig. State
These commands are always queries. They start a measurement and output the levels of the physical channels in the in-phase signal path (I-signal).				All

Q Signal Measurement				
READ:ARRay:CDPower:CHPW:QSIGnal[:VALue]:CURRent?		Start single shot meas. and return results		
FETCh:ARRay:CDPower:CHPW:QSIGnal[:VALue]:CURRent?		Read meas. results (unsynchronized)		
SAMPlE:ARRay:CDPower:CHPW:QSIGnal[:VALue]:CURRent?		Read results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
Q signal levels	Levels for R_FCH, R_SCH0, R_EACH, R_CCCH	NAN, NAN, NAN, NAN	dB	V3.05
Description of command				Sig. State
These commands are always queries. They start a measurement and output the levels of the physical channels in the quadrature signal path (Q-signal).				All

		Q Signal Measurement		
READ:ARRay:CDPower:CHPW:QSiGnal[:VALue]:AVERAge?		Start single shot meas. and return results		
FETCh:ARRay:CDPower:CHPW:QSiGnal[:VALue]:AVERAge?		Read meas. results (unsynchronized)		
SAMPlE:ARRay:CDPower:CHPW:QSiGnal[:VALue]:AVERAge?		Read results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
Q signal levels	Levels for R_FCH, R_SCH0, R_EACH, R_CCCH	NAN, NAN, NAN, NAN	dB	V3.05
Description of command				Sig. State
These commands are always queries. They start a measurement and output the levels of the physical channels in the quadrature signal path (Q-signal).				All

		Q Signal Measurement		
READ:ARRay:CDPower:CHPW:QSiGnal[:VALue]:MAXimum?		Start single shot meas. and return results		
FETCh:ARRay:CDPower:CHPW:QSiGnal[:VALue]:MAXimum?		Read meas. results (unsynchronized)		
SAMPlE:ARRay:CDPower:CHPW:QSiGnal[:VALue]:MAXimum?		Read results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
Q signal levels	Levels for R_FCH, R_SCH0, R_EACH, R_CCCH	NAN, NAN, NAN, NAN	dB	V3.05
Description of command				Sig. State
These commands are always queries. They start a measurement and output the levels of the physical channels in the quadrature signal path (Q-signal).				All

FETCh:ARRay:CDPower:CHPW:ISiGnal:StAte?		Active and inactive channels, I branch		
Returned values	Value range	Def. value	Def. unit	FW vers.
R_PICH state,	0 1 2,	NAN	–	V3.50
R_DCCH state,	0 1 2,	NAN		
R_SCH1 state	0 1 2	NAN		
Description of command				Sig. State
These commands are always queries. They return the channel states in the I branch. A 0 denotes an active, 1 an inactive channel, 2 an aliased channel.				All

FETCh:ARRay:CDPower:CHPW:QSiGnal:StAte?		Active and inactive channels, Q branch		
Returned values	Value range	Def. value	Def. unit	FW vers.
R_FCH state,	0 1 2,	NAN	–	V3.50
R_SCH0 state,	0 1 2,	NAN		
R_EACH state,	0 1 2,	NAN		
R_CCCH state	0 1 2	NAN		
Description of command				Sig. State
These commands are always queries. They return the channel states in the Q branch. A 0 denotes an active, 1 an inactive channel, 2 an aliased channel.				All

READ[:SCALar]:CDPower:CHPW? FETCh[:SCALar]:CDPower:CHPW? SAMPle[:SCALar]:CDPower:CHPW?		Scalar results: Start single shot measurement and return results Read out measurement results (unsynchronized) Read out measurement results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
MS Power (x3), Carrier Feedthrough (x3), Frequency Error (x3), Rho (x3), Out of Tolerance, Current Statistics	-100.0 dBm to -50.0 dBm -120.0 dB to -20.0 dB 0 to 1000.0 Hz 0.0 to 1.0 0.0% to 100.0% 1 to 1000	NAN NAN NAN NAN NAN NAN	dBm dB Hz - % -	V3.05
Description of command				Sig. State
These commands are always queries. They start a measurement and output all scalar measurement results. The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i> , the <i>Average</i> , and the <i>MMax</i> value.				All

CALCulate:ARRay:CDPower:CHPW:ISignal:CURRENT[:RESult]:MATCHing:LIMit?		I Signal Tolerance		
Returned value	Description	Def. value	Def. unit	FW vers.
32 bit value	Indicator for limit matching in R-PICH (least significant bit), R_DCCH, R_SCH1	NAN	-	V3.20
Description of command				Sig. State
This command is always a query. If a bit is set in the returned value the I signal limit in the corresponding code channel is exceeded. Bits 3 to 31 are not used.				All

CALCulate:ARRay:CDPower:CHPW:ISignal:AVERage[:RESult]:MATCHing:LIMIT?		I Signal Tolerance		
Returned value	Description	Def. value	Def. unit	FW vers.
32 bit value	Indicator for limit matching in R-PICH (least significant bit), R_DCCH, R_SCH1	NAN	-	V3.20
Description of command				Sig. State
This command is always a query. If a bit is set in the returned value the I signal limit in the corresponding code channel is exceeded. Bits 3 to 31 are not used.				All

CALCulate:ARRay:CDPower:CHPW:ISignal:MAXimum[:RESult]:MATCHing:LIMit?		I Signal Tolerance		
Returned value	Description	Def. value	Def. unit	FW vers.
32 bit value	Indicator for limit matching in R-PICH (least significant bit), R_DCCH, R_SCH1	NAN	-	V3.20
Description of command				Sig. State
This command is always a query. If a bit is set in the returned value the I signal limit in the corresponding code channel is exceeded. Bits 3 to 31 are not used.				All

CALCulate:ARRay:CDPower:CHPW:QSignal:CURRENT[:RESult]:MATCHing:LIMit?		Q Signal Tolerance		
Returned value	Description	Def. value	Def. unit	FW vers.
32 bit value	Indicator for limit matching in R-FCH (least significant bit), R_SCH0, R_EACH, R_CCCH	NAN	-	V3.20
Description of command				Sig. State
This command is always a query. If a bit is set in the returned value the Q signal limit in the corresponding code channel is exceeded. Bits 4 to 31 are not used.				All

CALCulate:ARRay:CDPower:CHPW:QSignal:AVERage[:RESult]:MATChing:LIMit?			Q Signal Tolerance	
Returned value	Description	Def. value	Def. unit	FW vers.
32 bit value	Indicator for limit matching in R-FCH (least significant bit), R_SCH0, R_EACH, R_CCCH	NAN	–	V3.20
Description of command				Sig. State
This command is always a query. If a bit is set in the returned value the Q signal limit in the corresponding code channel is exceeded. Bits 4 to 31 are not used.				All

CALCulate:ARRay:CDPower:CHPW:QSignal:MAXimum[:RESult]:MATChing:LIMit?			Q Signal Tolerance	
Returned value	Description	Def. value	Def. unit	FW vers.
32 bit value	Indicator for limit matching in R-FCH (least significant bit), R_SCH0, R_EACH, R_CCCH	NAN	–	V3.20
Description of command				Sig. State
This command is always a query. If a bit is set in the returned value the Q signal limit in the corresponding code channel is exceeded. Bits 4 to 31 are not used.				All

CALCulate[:SCALar]:CDPower:CHPW:MATChing:LIMit?			Limit Matching	
Returned values	Value range	Def. value	Def. unit	FW vers.
CHP Carrier Feedthrough (x3), CHP Frequency Error (x3), CHP Rho (x3)	For all values NMAU NMAL INV OK	INV INV INV	– – –	V3.05
Description of command				Sig. State
This command is always a query. It indicates whether and in which way the (fixed) limit lines have been exceeded. The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i> , the <i>Average</i> , and the <i>MMax</i> value. The following messages may be generated:				All
NMAU	Tolerance value underflow	<i>not matching, underflow</i>		
NMAL	Tolerance value exceeded	<i>not matching, overflow</i>		
INV	Measurement invalid	<i>invalid</i>		
OK	Tolerance value matched			

CDPower:POFFset

The subsystem *CDPower:POFFset* measures the phase error between the Reverse Pilot Channel and the other code channels radiated by the mobile station. The subsystem corresponds to the measurement menu *Code Domain Power*, application *Phase Offs. H-PSK*, and the sections related to this application in the associated popup menu *Code Domain Power Configuration*.

Control of measurement – Subsystem CDPower:POFFset

The subsystem *CDPower:POFFset* controls the phase offset measurement.

INITiate:CDPower:POFFset	Start new measurement	⇒	<i>RUN</i>
ABORT:CDPower:POFFset	Abort running measurement and switch off	⇒	<i>OFF</i>
STOP:CDPower:POFFset	Stop measurement after current stat. cycle	⇒	<i>STOP</i>
CONTinue:CDPower:POFFset	Next measurement step (<i>stepping mode</i>)	⇒	<i>RUN</i>
Description of command		Sig. State	FW vers.
These commands have no query form. They start and stop the measurement, setting it to the status indicated in the top right column.		All	V3.60

CONFigure:CDPower:POFFset:EREPorting[?]			Event Reporting	
<Report Mode>				
<Report Mode>	Description of parameters	Def. value	Def. unit	FW vers.
SRQ	Service request	OFF	–	V3.60
SOPC	Single operation complete			
SRSQ	SRQ and SOPC			
OFF	No reporting			
Description of command				Sig. State
This command defines the events generated when the measurement is terminated or stopped (see <i>Event Reporting</i> in Chapter 5 of the CMU manual).				All

FETCh[:SCALar]:CDPower:POFFset:STATus?			Measurement Status	
Return	Description of parameters	Def. value	Def. unit	FW vers.
OFF	Measurement in the OFF state (*RST or ABORt)	OFF	–	V3.60
RUN	Running (after INITiate, CONTinue or READ)			
STOP	Stopped (STOP)			
ERR	OFF (could not be started)			
STEP	Stepping mode (<stepmode>=STEP)			
RDY	Stopped according to repetition mode and stop condition			
1 to 10000	Counter for current statistics cycle	NONE	–	
NONE	No counting mode set			
1 to 1000	Counter for current evaluation period within a cycle	NONE	–	
NONE	Statistic count set to off			
Description of command				Sig. State
This command is always a query. It returns the status of the measurement (see Chapters 3 and 5).				All

Subsystem CDPower:POFFset:CONTRol

The subsystem *CDPower:POFFset:CONTRol* defines the result mode, repetition mode, statistic count, and stop condition of the measurement. These settings are provided in the *Control* tab in the popup menu *Code Domain Power Configuration*.

CONFigure:CDPower:POFFset:CONTRol[?]				Scope of Measurement	
<Result Mode>, <Current Statistics>, <Repetition>, <Stop Cond>, <Step Mode>					
<Result Mode>	Description of parameters	Def. value	Def. unit		
SCALar ARRay,	Scalar values only (incl. ramp matching) Scalar measured values and arrays	ARR	–		
<Current Statistics>	Description of parameters	Def. value	Def. unit		
1 to 1000,	Number of bursts per statistics cycle	100	–		
<Repetition>	Description of parameters	Def. value	Def. unit		
1 to 10000 CONTInuous SINGleshot DEFault,	Multiple measurement (counting, until Status = STEP RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–		
<Stop Cond>	Description of parameters	Def. value	Def. unit		
NONE SONerror DEFault,	Continue measurement even in case of error Stop measurement in case of error (<i>stop on error</i>) Sets the value to the default setting	NONE	–		
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.	
STEP NONE DEFault	Interrupt measurement after each statistics cycle Continue measurement according to its rep. Mode Sets the value to the default setting	NONE	–	V3.60	
Description of command					Sig. State
This command combines the ...CONTRol:RMODe, ...CONTRol:STATistics and the ...CONTRol:REPetition commands, see below.					All

CONFigure:CDPower:POFFset:CONTRol:RMODe[?]				Result Mode	
<Result Mode>					
<Result Mode>	Description of parameters	Def. value	Def. unit	FW vers.	
SCALar ARRay	Scalar values only (incl. ramp matching) Scalar measured values and arrays	ARR	–	V3.60	
Description of command					Sig. State
This command specifies the type of measured values.					All

CONFigure:CDPower:POFFset:CONTRol:STATistics[?]				Statistic Count	
<Current Statistics >					
<Current Statistics>	Description of parameters	Def. value	Def. unit	FW vers.	
1 to 1000	Number of bursts per statistics cycle	100	–	V3.60	
Description of command					Sig. State
This command defines the number of bursts forming a statistics cycle.					All

CONFigure:CDPower:POFFset:CONTRol:REPetition[?] <Repetition>, <Stop Cond>, <Step Mode>				Test Cycles	
<Repetition>	Description of parameters	Def. value	Def. unit		
1 to 10000 CONTInuous SINGleshot DEFault,	Multiple measurement (counting, until Status = STEP RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–		
<Stop Cond>	Description of parameters	Def. value	Def. unit		
NONE SONerror DEFault,	Continue measurement even in case of error Stop measurement in case of error (<i>stop on error</i>) Sets the value to the default setting	NONE	–		
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.	
STEP NONE DEFault	Interrupt measurement after each statistics cycle Continue measurement according to its rep. Mode Sets the value to the default setting	NONE	–	V3.60	
Description of command				Sig. State	
This command determines the repetition mode, stop condition, and stepping mode for the measurement.				All	
Note: <i>In the case of READ commands (READ:...), the <Repetition> parameter has no effect; the measurement is always stopped after a single shot.</i>					

Subsystem CDPower:POFFset:LIMit

The subsystem *CDPower:POFFset:LIMit* defines the limit values for the phase offset measurement. These settings are provided in the *Limits* tab in the popup menu *Code Domain Power Configuration*.

CONFigure:CDPower:POFFset:CMAx:LIMit[?] CONFigure:CDPower:POFFset:AVERage:LIMit[?] <CHPW Limit Y>				Phase Offset Limits	
<CHPW Limit Y>	Description of parameters	Def. value	Def. unit	FW vers.	
0.0 rad to 0.2 rad	Limit for phase offset	0.05	radian	V3.60	
Description of command				Sig. State	
This command defines the upper limit for the phase offset (symmetric value; the absolute phase offset must not exceed the limit). The keywords <i>CMAx</i> and <i>AVERage</i> refer to the <i>Current</i> and <i>Max.</i> display and for the <i>Average</i> display, respectively.				All	

DEFault:CDPower:POFFset:LIMit[?] <Enable>				Default Settings	
Enable	Description of parameters	Def. value	Def. unit	FW vers.	
ON OFF	The parameters are set to their default values Some or all parameters are not set to default	ON	–	V3.60	
Description of command				Sig. State	
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystem <i>CDPower:POFFset:LIMit</i> to their default values (the setting <i>OFF</i> results in an error message).				All	
If used as a query, the command returns whether all parameters are set to their default values (<i>ON</i>) or not (<i>OFF</i>).					

Measured Values – Subsystem CDPower:POFFset...?

The subsystem *CDPower:POFFset...?* determines and outputs the results of the phase offset measurement.

READ[:SCALar]:CDPower:POFFset? FETCh[:SCALar]:CDPower:POFFset? SAMPle[:SCALar]:CDPower:POFFset?		Scalar results:		
		Start single shot measurement and return results		
		Read out measurement results (unsynchronized)		
		Read out measurement results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
MS Power (x3),	–100.0 dBm to –50.0 dBm	NAN	dBm	V3.60
Carrier Feedthrough (x3),	–120.0 dB to –20.0 dB	NAN	dB	
Frequency Error (x3),	0 to 1000.0 Hz	NAN	Hz	
Rho (x3),	0.0 to 1.0	NAN	–	
Out of Tolerance,	0.0% to 100.0%	NAN	%	
Current Statistics	1 to 1000	NAN	–	
Description of command				Sig. State
These commands are always queries. They start a measurement and output all scalar measurement results. The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i> , the <i>Average</i> , and the <i>Maximum</i> value.				All

CALCulate[:SCALar]:CDPower:POFFset:MATChing:LIMit?		Limit Matching			
Returned values	Value range	Def. value	Def. unit	FW vers.	
CHP Carrier Feedthrough (x3), CHP Frequency Error (x3), CHP Rho (x3)	For all values NMAU NMAL INV OK	INV INV INV	– – –	V3.60	
Description of command					Sig. State
This command is always a query. It indicates whether and in which way the limit lines have been exceeded. The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i> , the <i>Average</i> , and the <i>MMax</i> value. The following messages may be generated:					All
NMAU	Tolerance value underflow			<i>not matching, underflow</i>	
NMAL	Tolerance value exceeded			<i>not matching, overflow</i>	
INV	Measurement invalid			<i>invalid</i>	
OK	Tolerance value matched				

		I Signal Measurement		
READ:ARRAY:CDPower:POFFset:ISIGnal[:VALue]:CURRent?		Start single shot meas. and return results		
FETCh:ARRAY:CDPower:POFFset:ISIGnal[:VALue]:CURRent?		Read meas. results (unsynchronized)		
SAMPlE:ARRAY:CDPower:POFFset:ISIGnal[:VALue]:CURRent?		Read results (synchronized)		
READ:ARRAY:CDPower:POFFset:ISIGnal[:VALue]:AVERAge?		Start single shot meas. and return results		
FETCh:ARRAY:CDPower:POFFset:ISIGnal[:VALue]:AVERAge?		Read meas. results (unsynchronized)		
SAMPlE:ARRAY:CDPower:POFFset:ISIGnal[:VALue]:AVERAge?		Read results (synchronized)		
READ:ARRAY:CDPower:POFFset:ISIGnal[:VALue]:MAXimum?		Start single shot meas. and return results		
FETCh:ARRAY:CDPower:POFFset:ISIGnal[:VALue]:MAXimum?		Read meas. results (unsynchronized)		
SAMPlE:ARRAY:CDPower:POFFset:ISIGnal[:VALue]:MAXimum?		Read results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
-200 mRad to +200 mRad	I signal phase offset: Values for R_PICH, R_DCCH, R_SCH1, RES	NAN, NAN, NAN, NAN	radian	V3.60
Description of command				Sig. State
These commands are always queries. They start a measurement and return the phase offsets of the physical channels in the in-phase signal path (I-signal). The keywords <i>CURRent</i> , <i>AVERAge</i> , <i>MAXimum</i> denote the display mode. The fourth output value is reserved for future extensions and always NAN in the current firmware version.				All

		Q Signal Measurement		
READ:ARRAY:CDPower:POFFset:QSIGnal[:VALue]:CURRent?		Start single shot meas. and return results		
FETCh:ARRAY:CDPower:POFFset:QSIGnal[:VALue]:CURRent?		Read meas. results (unsynchronized)		
SAMPlE:ARRAY:CDPower:POFFset:QSIGnal[:VALue]:CURRent?		Read results (synchronized)		
READ:ARRAY:CDPower:POFFset:QSIGnal[:VALue]:AVERAge?		Start single shot meas. and return results		
FETCh:ARRAY:CDPower:POFFset:QSIGnal[:VALue]:AVERAge?		Read meas. results (unsynchronized)		
SAMPlE:ARRAY:CDPower:POFFset:QSIGnal[:VALue]:AVERAge?		Read results (synchronized)		
READ:ARRAY:CDPower:POFFset:QSIGnal[:VALue]:MAXimum?		Start single shot meas. and return results		
FETCh:ARRAY:CDPower:POFFset:QSIGnal[:VALue]:MAXimum?		Read meas. results (unsynchronized)		
SAMPlE:ARRAY:CDPower:POFFset:QSIGnal[:VALue]:MAXimum?		Read results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
-200 mRad to +200 mRad	Q signal phase offset: Values for R_FCH, R_SCH0, R_EACH, R_CCCH, R_ACKCH, R_CQICH, RES, RES, RES	NAN, NAN, NAN, NAN, NAN, NAN, NAN, NAN, NAN	radian	V3.60
Description of command				Sig. State
These commands are always queries. They start a measurement and return the phase offsets of the physical channels in the quadrature signal path (Q-signal). The keywords <i>CURRent</i> , <i>AVERAge</i> , <i>MAXimum</i> denote the display mode. The three last output values are reserved for future extensions and always NAN in the current firmware version.				All

FETCh:ARRAY:CDPower:POFFset:ISIGnal:STATe?		Active and inactive channels, I branch		
Returned values	Value range	Def. value	Def. unit	FW vers.
R_PICH state, R_DCCH state, R_SCH1 state, RES	0 1 2, 0 1 2, 0 1 2 Reserved (always NAN)	NAN, NAN, NAN, NAN	-	V3.50
Description of command				Sig. State
These commands are always queries. They return the channel states in the I branch. A 0 denotes an active, 1 an inactive channel, 2 an aliased channel.				All

FETCh:ARRay:CDPower:POFFset:QSIGnal:STATe?		Active and inactive channels, Q branch		
Returned values	Value range	Def. value	Def. unit	FW vers.
R_FCH state,	0 1 2,	NAN	–	V3.60
R_SCH0 state,	0 1 2,	NAN		
R_EACH state,	0 1 2,	NAN		
R_CCCH state,	0 1 2,	NAN		
R_ACKCH state,	0 1 2,	NAN		
R_CQICH state,	0 1 2,	NAN		
RES, RES, RES	Reserved (always NAN, NAN; NAN)	NAN, NAN, NAN		
Description of command				Sig. State
These commands are always queries. They return the channel states in the Q branch. A 0 denotes an active, 1 an inactive channel, 2 an aliased channel.				All

CALCulate:ARRay:CDPower:POFFset:ISIGnal:CURRent[:RESult]:MATChing:LIMit? CALCulate:ARRay:CDPower:POFFset:ISIGnal:AVERAge[:RESult]:MATChing:LIMit? CALCulate:ARRay:CDPower:POFFset:ISIGnal:MAXimum[:RESult]:MATChing:LIMit?		I Signal Tolerance		
Returned value	Description	Def. value	Def. unit	FW vers.
32 bit value	Indicator for limit matching in R-PICH (least significant bit), R_DCCH, R_SCH1	NAN	–	V3.60
Description of command				Sig. State
This command is always a query. If a bit is set in the returned value the I signal limit in the corresponding code channel is exceeded. Bits 3 to 31 are not used. The keywords CURRent, AVERAge, MAXimum denote the display mode.				All

CALCulate:ARRay:CDPower:POFFset:QSIGnal:CURRent[:RESult]:MATChing:LIMit? CALCulate:ARRay:CDPower:POFFset:QSIGnal:AVERAge[:RESult]:MATChing:LIMit? CALCulate:ARRay:CDPower:POFFset:QSIGnal:MAXimum[:RESult]:MATChing:LIMit?		Q Signal Tolerance		
Returned value	Description	Def. value	Def. unit	FW vers.
32 bit value	Indicator for limit matching in R-FCH (least significant bit), R_SCH0, R_EACH, R_CCCH, R_ACKCH, R_CQICH	NAN	–	V3.60
Description of command				Sig. State
This command is always a query. If a bit is set in the returned value the Q signal limit in the corresponding code channel is exceeded. Bits 4 to 31 are not used.				All

CDPower:TOFFset

The subsystem *CDPower:TOFFset* measures the timing error between the Reverse Pilot Channel and the other code channels radiated by the mobile station. The subsystem corresponds to the measurement menu *Code Domain Power*, application *Time Offs. H-PSK*, and the sections related to this application in the associated popup menu *Code Domain Power Configuration*.

Control of measurement – Subsystem CDPower:TOFFset

The subsystem *CDPower:TOFFset* controls the time offset measurement.

INITiate:CDPower:TOFFset	Start new measurement	⇒	<i>RUN</i>
ABORT:CDPower:TOFFset	Abort running measurement and switch off	⇒	<i>OFF</i>
STOP:CDPower:TOFFset	Stop measurement after current stat. cycle	⇒	<i>STOP</i>
CONTinue:CDPower:TOFFset	Next measurement step (<i>stepping mode</i>)	⇒	<i>RUN</i>
Description of command		Sig. State	FW vers.
These commands have no query form. They start and stop the measurement, setting it to the status indicated in the top right column.		All	V3.60

CONFigure:CDPower:TOFFset:EREPorting[?]			Event Reporting	
<Report Mode>				
<Report Mode>	Description of parameters	Def. value	Def. unit	FW vers.
SRQ	Service request	OFF	–	V3.60
SOPC	Single operation complete			
SRSQ	SRQ and SOPC			
OFF	No reporting			
Description of command				Sig. State
This command defines the events generated when the measurement is terminated or stopped (see <i>Event Reporting</i> in Chapter 5 of the CMU manual).				All

FETCh[:SCALar]:CDPower:TOFFset:STATus?			Measurement Status	
Return	Description of parameters	Def. value	Def. unit	FW vers.
OFF	Measurement in the OFF state (*RST or ABORt)	OFF	–	V3.60
RUN	Running (after INITiate, CONTinue or READ)			
STOP	Stopped (STOP)			
ERR	OFF (could not be started)			
STEP	Stepping mode (<stepmode>=STEP)			
RDY	Stopped according to repetition mode and stop condition			
1 to 10000	Counter for current statistics cycle	NONE	–	
NONE	No counting mode set			
1 to 1000	Counter for current evaluation period within a cycle	NONE	–	
NONE	Statistic count set to off			
Description of command				Sig. State
This command is always a query. It returns the status of the measurement (see Chapters 3 and 5).				All

Subsystem CDPower:TOFFset:CONTRol

The subsystem *CDPower:TOFFset:CONTRol* defines the result mode, repetition mode, statistic count, and stop condition of the measurement. These settings are provided in the *Control* tab in the popup menu *Code Domain Power Configuration*.

CONFigure:CDPower:TOFFset:CONTRol[?]				Scope of Measurement
<Result Mode>, <Current Statistics>, <Repetition>, <Stop Cond>, <Step Mode>				
<Result Mode>	Description of parameters	Def. value	Def. unit	
SCALar ARRay,	Scalar values only (incl. ramp matching) Scalar measured values and arrays	ARR	–	
<Current Statistics>	Description of parameters	Def. value	Def. unit	
1 to 1000,	Number of bursts per statistics cycle	100	–	
<Repetition>	Description of parameters	Def. value	Def. unit	
1 to 10000 CONTInuous SINGleshot DEFault,	Multiple measurement (counting, until Status = STEP RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–	
<Stop Cond>	Description of parameters	Def. value	Def. unit	
NONE SONerror DEFault,	Continue measurement even in case of error Stop measurement in case of error (<i>stop on error</i>) Sets the value to the default setting	NONE	–	
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
STEP NONE DEFault	Interrupt measurement after each statistics cycle Continue measurement according to its rep. Mode Sets the value to the default setting	NONE	–	V3.60
Description of command				Sig. State
This command combines the ...CONTRol:RMODe, ...CONTRol:STATistics and the ...CONTRol:REPetition commands, see below.				All

CONFigure:CDPower:TOFFset:CONTRol:RMODe[?]				Result Mode
<Result Mode>				
<Result Mode>	Description of parameters	Def. value	Def. unit	FW vers.
SCALar ARRay	Scalar values only (incl. ramp matching) Scalar measured values and arrays	ARR	–	V3.60
Description of command				Sig. State
This command specifies the type of measured values.				All

CONFigure:CDPower:TOFFset:CONTRol:STATistics[?]				Statistic Count
<Current Statistics >				
<Current Statistics>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 1000	Number of bursts per statistics cycle	100	–	V3.60
Description of command				Sig. State
This command defines the number of bursts forming a statistics cycle.				All

CONFigure:CDPower:TOFFset:CONTRol:REPetition[?] <Repetition>, <Stop Cond>, <Step Mode>				Test Cycles	
<Repetition>	Description of parameters	Def. value	Def. unit		
1 to 10000 CONTInuous SINGleshot DEFault,	Multiple measurement (counting, until Status = STEP RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–		
<Stop Cond>	Description of parameters	Def. value	Def. unit		
NONE SONerror DEFault,	Continue measurement even in case of error Stop measurement in case of error (<i>stop on error</i>) Sets the value to the default setting	NONE	–		
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.	
STEP NONE DEFault	Interrupt measurement after each statistics cycle Continue measurement according to its rep. Mode Sets the value to the default setting	NONE	–	V3.60	
Description of command				Sig. State	
This command determines the repetition mode, stop condition, and stepping mode for the measurement.				All	
Note: <i>In the case of READ commands (READ:...), the <Repetition> parameter has no effect; the measurement is always stopped after a single shot.</i>					

Subsystem CDPower:TOFFset:LIMit

The subsystem *CDPower:TOFFset:LIMit* defines the limit values for the time offset measurement. These settings are provided in the *Limits* tab in the popup menu *Code Domain Power Configuration*.

CONFigure:CDPower:TOFFset:CMAx:LIMit[?] CONFigure:CDPower:TOFFset:AVERage:LIMit[?] <CHPW Limit Y>				Time Offset Limits	
<CHPW Limit Y>	Description of parameters	Def. value	Def. unit	FW vers.	
0 ns to 40 ns	Limit for time offset	10 ns	s	V3.60	
Description of command				Sig. State	
This command defines the upper limit for the time offset (symmetric value; the absolute time offset must not exceed the limit). The keywords <i>CMAx</i> and <i>AVERage</i> refer to the <i>Current</i> and <i>Max.</i> display and for the <i>Average</i> display, respectively.				All	

DEFault:CDPower:TOFFset:LIMit[?] <Enable>				Default Settings	
Enable	Description of parameters	Def. value	Def. unit	FW vers.	
ON OFF	The parameters are set to their default values Some or all parameters are not set to default	ON	–	V3.60	
Description of command				Sig. State	
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystem <i>CDPower:TOFFset:LIMit</i> to their default values (the setting <i>OFF</i> results in an error message).				All	
If used as a query, the command returns whether all parameters are set to their default values (<i>ON</i>) or not (<i>OFF</i>).					

Measured Values – Subsystem CDPower:TOFFset...?

The subsystem *CDPower:TOFFset...?* determines and outputs the results of the time offset measurement.

READ[:SCALar]:CDPower:TOFFset? FETCh[:SCALar]:CDPower:TOFFset? SAMPle[:SCALar]:CDPower:TOFFset?		Scalar results:		
		Start single shot measurement and return results		
		Read out measurement results (unsynchronized)		
		Read out measurement results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
MS Power (x3),	–100.0 dBm to –50.0 dBm	NAN	dBm	V3.60
Carrier Feedthrough (x3),	–120.0 dB to –20.0 dB	NAN	dB	
Frequency Error (x3),	0 to 1000.0 Hz	NAN	Hz	
Rho (x3),	0.0 to 1.0	NAN	–	
Out of Tolerance,	0.0% to 100.0%	NAN	%	
Current Statistics	1 to 1000	NAN	–	
Description of command				Sig. State
These commands are always queries. They start a measurement and output all scalar measurement results. The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i> , the <i>Average</i> , and the <i>Maximum</i> value.				All

CALCulate[:SCALar]:CDPower:TOFFset:MATCHing:LIMit?		Limit Matching			
Returned values	Value range	Def. value	Def. unit	FW vers.	
CHP Carrier Feedthrough (x3), CHP Frequency Error (x3), CHP Rho (x3)	For all values NMAU NMAL INV OK	INV INV INV	– – –	V3.60	
Description of command					Sig. State
This command is always a query. It indicates whether and in which way the limit lines have been exceeded. The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i> , the <i>Average</i> , and the <i>MMax</i> value. The following messages may be generated:					All
NMAU	Tolerance value underflow	<i>not matching, underflow</i>			
NMAL	Tolerance value exceeded	<i>not matching, overflow</i>			
INV	Measurement invalid	<i>invalid</i>			
OK	Tolerance value matched				

		I Signal Measurement		
READ:ARRay:CDPower:TOFFset:ISIGnal[:VALue]:CURRent?		Start single shot meas. and return results		
FETCh:ARRay:CDPower:TOFFset:ISIGnal[:VALue]:CURRent?		Read meas. results (unsynchronized)		
SAMPlE:ARRay:CDPower:TOFFset:ISIGnal[:VALue]:CURRent?		Read results (synchronized)		
READ:ARRay:CDPower:TOFFset:ISIGnal[:VALue]:AVERAge?		Start single shot meas. and return results		
FETCh:ARRay:CDPower:TOFFset:ISIGnal[:VALue]:AVERAge?		Read meas. results (unsynchronized)		
SAMPlE:ARRay:CDPower:TOFFset:ISIGnal[:VALue]:AVERAge?		Read results (synchronized)		
READ:ARRay:CDPower:TOFFset:ISIGnal[:VALue]:MAXimum?		Start single shot meas. and return results		
FETCh:ARRay:CDPower:TOFFset:ISIGnal[:VALue]:MAXimum?		Read meas. results (unsynchronized)		
SAMPlE:ARRay:CDPower:TOFFset:ISIGnal[:VALue]:MAXimum?		Read results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
-40 ns to +40 ns	I signal time offset: Values for R_PICH, R_DCCH, R_SCH1, RES	NAN, NAN, NAN, NAN	s	V3.60
Description of command				Sig. State
These commands are always queries. They start a measurement and output the time offsets of the physical channels in the in-phase signal path (I-signal). The keywords <i>CURRent</i> , <i>AVERAge</i> , <i>MAXimum</i> denote the display mode. The fourth output value is reserved for future extensions and always NAN in the current firmware version.				All

		Q Signal Measurement		
READ:ARRay:CDPower:TOFFset:QSIGnal[:VALue]:CURRent?		Start single shot meas. and return results		
FETCh:ARRay:CDPower:TOFFset:QSIGnal[:VALue]:CURRent?		Read meas. results (unsynchronized)		
SAMPlE:ARRay:CDPower:TOFFset:QSIGnal[:VALue]:CURRent?		Read results (synchronized)		
READ:ARRay:CDPower:TOFFset:QSIGnal[:VALue]:AVERAge?		Start single shot meas. and return results		
FETCh:ARRay:CDPower:TOFFset:QSIGnal[:VALue]:AVERAge?		Read meas. results (unsynchronized)		
SAMPlE:ARRay:CDPower:TOFFset:QSIGnal[:VALue]:AVERAge?		Read results (synchronized)		
READ:ARRay:CDPower:TOFFset:QSIGnal[:VALue]:MAXimum?		Start single shot meas. and return results		
FETCh:ARRay:CDPower:TOFFset:QSIGnal[:VALue]:MAXimum?		Read meas. results (unsynchronized)		
SAMPlE:ARRay:CDPower:TOFFset:QSIGnal[:VALue]:MAXimum?		Read results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
-40 ns to +40 ns	Q signal time offset: Values for R_FCH, R_SCH0, R_EACH, R_CCCH, R_ACKCH, R_CQICH, RES, RES, RES	NAN, NAN, NAN, NAN, NAN, NAN, NAN, NAN, NAN	s	V3.60
Description of command				Sig. State
These commands are always queries. They start a measurement and/or return the time offsets of the physical channels in the quadrature signal path (Q-signal). The keywords <i>CURRent</i> , <i>AVERAge</i> , <i>MAXimum</i> denote the display mode. The three last output values are reserved for future extensions and always NAN in the current firmware version.				All

FETCh:ARRay:CDPower:TOFFset:ISIGnal:STATe?		Active and inactive channels, I branch		
Returned values	Value range	Def. value	Def. unit	FW vers.
R_PICH state,	0 1 2,	NAN,	-	V3.50
R_DCCH state,	0 1 2,	NAN,		
R_SCH1 state,	0 1 2	NAN,		
RES	Reserved (always NAN)	NAN		
Description of command				Sig. State
These commands are always queries. They return the channel states in the I branch. A 0 denotes an active, 1 an inactive channel, 2 an aliased channel.				All

FETCh:ARRay:CDPower:TOFFset:QSIGnal:STATe?		Active and inactive channels, Q branch		
Returned values	Value range	Def. value	Def. unit	FW vers.
R_FCH state,	0 1 2,	NAN	–	V3.60
R_SCH0 state,	0 1 2,	NAN		
R_EACH state,	0 1 2,	NAN		
R_CCCH state,	0 1 2,	NAN		
R_ACKCH state,	0 1 2,	NAN		
R_CQICH state,	0 1 2,	NAN		
RES, RES, RES	Reserved (always NAN, NAN; NAN)	NAN, NAN, NAN		
Description of command				Sig. State
These commands are always queries. They return the channel states in the Q branch. A 0 denotes an active, 1 an inactive channel, 2 an aliased channel.				All

CALCulate:ARRay:CDPower:TOFFset:ISIGnal:CURRent[:RESult]:MATChing:LIMit?		I Signal Tolerance		
CALCulate:ARRay:CDPower:TOFFset:ISIGnal:AVERAge[:RESult]:MATChing:LIMit?				
CALCulate:ARRay:CDPower:TOFFset:ISIGnal:MAXimum[:RESult]:MATChing:LIMit?				
Returned value	Description	Def. value	Def. unit	FW vers.
32 bit value	Indicator for limit matching in R-PICH (least significant bit), R_DCCH, R_SCH1	NAN	–	V3.60
Description of command				Sig. State
This command is always a query. If a bit is set in the returned value the I signal limit in the corresponding code channel is exceeded. Bits 3 to 31 are not used. The keywords <i>CURRent</i> , <i>AVERAge</i> , <i>MAXimum</i> denote the display mode.				All

CALCulate:ARRay:CDPower:TOFFset:QSIGnal:CURRent[:RESult]:MATChing:LIMit?		Q Signal Tolerance		
CALCulate:ARRay:CDPower:TOFFset:QSIGnal:AVERAge[:RESult]:MATChing:LIMit?				
CALCulate:ARRay:CDPower:TOFFset:QSIGnal:MAXimum[:RESult]:MATChing:LIMit?				
Returned value	Description	Def. value	Def. unit	FW vers.
32 bit value	Indicator for limit matching in R-FCH (least significant bit), R_SCH0, R_EACH, R_CCCH, R_ACKCH, R_CQICH	NAN	–	V3.60
Description of command				Sig. State
This command is always a query. If a bit is set in the returned value the Q signal limit in the corresponding code channel is exceeded. Bits 4 to 31 are not used.				All

CDMA Mobile Tests (Signalling Mode)

In the *Signalling* mode, the CMU is able to generate control and traffic channel signals and to set up a call to the mobile. A broad range of signalling parameters can be configured and measurements may be performed with a call connection established.

Network Standards – NETWORK

The *NETWORK* system switches between the different CDMA network standards.

CONFigure:NETWORK:STANdard[?] <Standard>				Network Standard	
<Standard>	Description of parameters	Def. value	Def. unit		
CDMA2000 450 MHz					
N45T	N45T, Band Class 5	NMT-450	–		
CDMA2000 Cellular					
USC	US Cellular, Band Class 0	USC	–		
KCEL	Korean Cellular, Band Class 0				
TACS	TACS, Band Class 2				
JTAC	JTACS, Band Class 3				
NA7C	North American 700 MHz, Band Class 7				
NA9C	North American 900 MHz, Band Class 9				
NA8S	Secondary 800 MHz, Band Class 10				
CDMA2000 PCS					
NAPC	North American PCS, Band Class 1	NAPC	–		
KPCS	Korean PCS, Band Class 4				
B18M	1800 MHz, Band Class 8				
CDMA2000 IMT-2000					
IM2K	IMT-2000, Band Class 6	IM2K	–		FW vers. V3.05
Description of command					Sig. State
This command activates the test mode according to one of the provided CDMA network standards.					All

Connection Control

The remote-control commands presented in this section control the signalling (call setup and release, services, signalling parameters), determine the inputs and outputs as well as the reference frequency. They correspond to the settings in the popup menu of the softkey *Connect Control* located at the top right of each main menu.

Note: *Some parameters of the CMU assume several independent values: The default value is used to set up a call; most default values can be modified in the signalling states Signal Off, Signal On and Registered. The current value during the call (signalling states Connected) can still be changed, however, modifying this current value does not alter the default value. The handoff value comes into effect after a handoff from another to the current network; most handoff values can be set in all signalling states.*

Note: Many of the default and current parameters in CDMA2000-MS occur in the SIGNalling and in the BSSignal subsystems.

Default values are set with a CONFigure ... command, current values are set with the corresponding PROCedure ... command.

Signalling – Subsystem SIGNalling (Call Setup and Cleardown)

The subsystem SIGNalling controls the call setup and cleardown from the CMU to the mobile and determines the signalling parameters. It corresponds to the tab Connection (for different signalling states, see command PROCedure:SIGNalling:ACTion) in the popup menu Connection Control.

PROCedure:SIGNalling:ACTion <Signalling Action>		Signalling Control		
<Signalling Action>	Description of parameters	Def. value	Def. unit	FW vers.
SOFF	Switch off RF signal (<i>signal off</i>)	SOFF	–	V3.05
SON	Switch on RF signal (<i>signal on</i>)			
UNRegister	Unregister the mobile			
CTMobile	Call to mobile (not for CONF:SCON:SCL1:SERV WMT)			
CRELease	Call release			
HANDoff	Handoff (only in signalling state CEST)			
SMESsage	Send SMS (only in signalling state CEST or for CONF:SCON:SCL1:SERV WMT and state < CEST)			
Description of command				Sig. State
This command has no query form and no default value. It changes between the different signalling states of the CMU.				See below




Figure 6-1: Signalling states of the CMU and transitions including Handoff

Signalling states:

See description of command [SENSE:]SIGNalling:STATe?

Actions (initiated from the CMU):

See description of command [PROCedure:]SIGNalling:ACTion

Further transitions between the signalling states (not shown in Figure 6-1) may occur, e.g. in case of errors. For the transitions and signalling states related to handoff procedures (CDMA to AMPS) refer to the AMPS-MS operating manual.

[SENSE:]SIGNalling:STATe?		Signalling State		
Returns	Description of parameters	Def. value	Def. unit	FW vers.
SOFF	RF signal switched off (<i>Signal Off</i>)	SOFF	–	V3.05
SON	RF signal switched on (<i>Signal On</i>)			
REG	MS registration performed (<i>Registered</i>)			
ALER	Mobile is ringing (<i>Alerting</i>)			
CEST	Call to mobile set up (<i>Call Established</i>)			
CPEN	Call pending (<i>Handoff</i> procedures)			
FPEN	Fallback pending (<i>Handoff</i> procedures)			
SMESsage	Short message being sent			
PDOR	PPP Dormant			
PCON	PPP Connected			
Description of command				Sig. State
This command is always a query. It returns the current signalling state.				All

Subsystem Mobile Information

The subsystem *MSSinfo* queries the mobile station for its properties. The subsystem corresponds to the *MS Information* in the *Connection* tab of the *Connection Control* menu. The mobile phone properties do not actually represent measured values, they are provided by the mobile phone during registration.

Note: *If no mobile is connected, or if the mobile under test is not synchronized (signalling states SOFF, SON), the queries in this section will return the default values INV. The Mobile ID and serial number are available in the REG and CEST states. The remaining information is available in the CEST state only and are overwritten by INV if registration is lost (transition from REG or CEST to SON or SOFF).*

In addition, the mobile report must be switched on (CONFigure:MSSignal:MCReport ON) to obtain valid mobile information.

[SENSe:]MSSinfo?		Mobile Information		
Returns	Description of parameters	Def. value	Def. unit	FW vers.
Protocol revision of the mobile station,	1 to 6	NAN	–	V3.05
Mobile Country Code,	0 to 999	NAN		
National Mobile Station Identification,	34-bit MIN (mobile identification number) or 50-bit IMSI	NAN		
ESN of the mobile station,	Electronic Serial number of the mobile station	NAN	–	
Max. EIRP	Maximum Effective Isotropic Radiated Power	NAN	–	
Description of command				Sig. State
This command is always a query. It returns the mobile station information.				All

[SENSe:]MSSinfo:PREVision?		Mobile Information		
Returns	Description of parameters	Def. value	Def. unit	FW vers.
Protocol revision of the mobile station	1 to 6	NAN	–	V3.05
Description of command				Sig. State
This command is always a query. It returns the protocol revision supported by the mobile station.				All

[SENSe:]MSSinfo:BCLSupport?		Mobile Information		
Returns	Description of parameters	Def. value	Def. unit	FW vers.
Band Class Support	Returns the supported mobile station band class in the form: (0 1),(0 1),(0 1),(0 1),(0 1),(0 1),(0 1),(0 1),(0 1),(0 1) to indicate not supported (0) or supported (1) for band classes 0 through 10.	NAN	–	V3.05
Description of command				Sig. State
This command is always a query. It returns the band class supported by the mobile station.				All

[SENSe:]MSSinfo:SCLSupport?		Mobile Information		
Returns	Description of parameters	Def. value	Def. unit	FW vers.
Sub Band Class Support	Returns the supported mobile station subband class in the form: (0 1),(0 1),(0 1),(0 1),(0 1),(0 1),(0 1) to indicate not supported (0) or supported (1) for subband classes 0 through 7.	NAN	–	V3.05
Description of command				Sig. State
This command is always a query. It returns the sub-band class supported by the mobile station.				All

[SENSe:]MSSinfo:TERMinal?		Mobile Information		
Returns	Description of parameters	Def. value	Def. unit	FW vers.
Manufacturer Code,	Mobile station manufacturer code number	–	–	V3.05
Model Number,	Mobile station model number	–	–	
Firmware Revision,	Mobile station firmware revision	–	–	
Local Control,	NSUP SUPP Local control not supported or supported	–		
Reported Service Options	Mobile station service option	–	–	
Description of command				Sig. State
This command is always a query. It returns the mobile station's information.				All

[SENSe:]MSSinfo:AUTHentic?		Authentication		
Returns	Description of parameters	Def. value	Def. unit	FW vers.
Authent. Mode,	NSUP SUPP, Support of authentication	–	–	V3.10
Auth. Response,	Authentication response from the MS, 4-digit hex string	–	–	
RANDC,	The eight most-significant bits of the random challenge value used by the MS (decimal 0 to 255)	–	–	
Call History Count	Value of the call history parameter COUNT used for clone detection (decimal 0 to 255)	–		
Description of command				Sig. State
This command is always a query. It returns the mobile station's authentication information.				All

Subsystem Connection Information

The subsystem *CINFo* queries the parameters used to attempt the connection. The subsystem corresponds to the *Connection Information* section in the *Connection* tab of the *Connection Control* menu. The connection parameters does not actually represent measured values, they are provided by the mobile phone during registration.

Note: *If no mobile is connected, or if the mobile under test is not synchronized (signalling states SOFF, SON), the queries in this section will return the default values INV. The information is provided while the CMU is in the CEST state.*

[SENSe:]CINFo:DNUMBER?		Dialed Number		
Returns	Description of parameters	Def. value	Def. unit	FW vers.
Dialed Number	String parameter	–	–	V3.05
Description of command				Sig. State
This command is always a query. It returns the number dialed at the MS.				All

[SENSe:]CINFo:GECall?		Global Emergency Call		
Returns	Description of parameters	Def. value	Def. unit	FW vers.
Global Emergency Call	Boolean parameter, 0 (false) or 1 (true)	–	–	V3.05
Description of command				Sig. State
This command is always a query. It returns whether the current call is a global emergency call.				All

[SENSe:]CINFo:SOPTion?		Connected Service Options		
Returns	Description of parameters	Def. value	Def. unit	FW vers.
SO no., "SO Name", ...	Number of 1 st connected service option Name of 1 st connected service option, string variable	–	–	V3.05
SO no., "SO Name"	Number of last connected service option Name of last connected service option, string variable			
Description of command				Sig. State
This command is always a query. It returns the numbers and names of all connected service options.				All

[SENSe:]CINFo:FCH:MOPTions?		Connected MUX Options (FCH)		
Returns	Description of parameters	Def. value	Def. unit	FW vers.
FWD MUX, REV MUX	Connected forward MUX option, hex value Connected reverse MUX option, hex value	–	–	V3.05
Description of command				Sig. State
This command is always a query. It returns the connected forward and reverse multipled options for the FCH.				All

[SENSe:]CINFo:FCH:RC?		Connected Radio Configurations (FCH)		
Returns	Description of parameters	Def. value	Def. unit	FW vers.
FWD RC, REV RC	Connected forward radio configuration, decimal value Connected reverse radio configuration, decimal value	–	–	V3.05
Description of command				Sig. State
This command is always a query. It returns the connected forward and reverse radio configurations for the FCH.				All

[SENSe:]CINFo:SCH:ZERO:MOPTions?		Connected MUX Options (SCH0)		
Returns	Description of parameters	Def. value	Def. unit	FW vers.
FWD MUX, REV MUX	Connected forward MUX option, hex value Connected reverse MUX option, hex value	–	–	V3.05
Description of command				Sig. State
This command is always a query. It returns the connected forward and reverse MUX options for the SCH0.				All

[SENSe:]CINFo:SCH:ZERO:RC?		Connected Radio Configurations (SCH0)		
Returns	Description of parameters	Def. value	Def. unit	FW vers.
FWD RC, REV RC	Connected forward radio configuration, decimal value Connected reverse radio configuration, decimal value	–	–	V3.05
Description of command				Sig. State
This command is always a query. It returns the connected forward and reverse radio configurations for the SCH0.				All

Subsystem Messaging (WMT) Information

The subsystem *MINFo* queries information about the last outgoing short message (SMS) and the last short message received at the mobile. The subsystem corresponds to the *Messaging (WMT) Information* section in the *Connection* tab of the *Connection Control* menu. The parameters of a short message to be sent are set in the ...*SCONfig:SClass1:WMT:SMS...* subsystem; see section [Subsystem *SCONfig:SClass*](#): on p. 6.173 ff.

The *MINFo* queries can be used in all signalling states, however, an SMS must be sent before real results can be obtained.

[SENSe:]MINFo:SMS:LOUTgoing:TSTamp?		Last Outgoing – Time Stamp		
Returns	Description of parameters	Def. value	Def. unit	FW vers.
"hh:mm:ss"	Time stamp: hour, minutes, seconds (string parameter)	"–"	–	V3.10
Description of command				Sig. State
This command is always a query. It returns the time stamp associated to the last outgoing short message, if available. Adding a time stamp to a short message is enabled by means of the command <i>CONFigure:SCONfig:SClass1:WMT:SMS:TSTamp:ENABle ON</i> .				All

[SENSe:]MINFo:SMS:LOUTgoing:ACKnowledge?		Last Outgoing – Acknowledge		
Returns	Description of parameters	Def. value	Def. unit	FW vers.
ACKN NACK	Mobile acknowledged last message Mobile did not acknowledge last message (because it was not requested to do so)	–	–	V3.10
FAIL	Mobile failed to acknowledge last message (although it was not requested to do so)			
Description of command				Sig. State
This command is always a query. It returns whether the mobile acknowledged the last outgoing short message. Short message acknowledgement is enabled by means of the command <i>CONFigure:SCONfig:SClass1:WMT:SMS:ACKnowledge:ENABle ON</i> .				All

[SENSe:]MINFo:SMS:LOUTgoing:CCODE?		Last Outgoing – Cause Code		
Returns	Description of parameters	Def. value	Def. unit	FW vers.
<8-bit value>	CAUSE_CODE	–	–	V3.10
Description of command				Sig. State
This command is always a query. It returns the contents of the CAUSE_CODE field of the <i>Alert With Info MS Order Confirmation Message</i> . The CAUSE_CODE provides the delivery status of SMS user data.				All

[SENSe:]MINFo:SMS:LRECeived:TSTamp?		Last Received – Time Stamp		
Returns	Description of parameters	Def. value	Def. unit	FW vers.
"hh:mm:ss"	Time stamp: hour, minutes, seconds (string parameter)	"_"	–	V3.50
Description of command				Sig. State
This command is always a query. It returns the time stamp associated to the last received short message, if available.				All

[SENSe:]MINFo:SMS:LRECeived:TEXT?		Last Received – SMS Text		
Returns	Description of parameters	Def. value	Def. unit	FW vers.
"<max. 160 7-bit ASCII characters>"	SMS text	"_"	–	V3.50
Description of command				Sig. State
This command is always a query. It returns the text of the last received short message.				All

Subsystem Service Configuration

The subsystem SCONfig configures the service configuration to use when establishing a call to the mobile. It corresponds to the *Connection* and *Service Cfg.* tabs in the popup menu *Connection Control*.

[SENSe:]SCINfo?		Service Configuration Info		
Returned Value	Description of parameters	Def. value	Def. unit	FW vers.
F-FCH-RO, R-FCH-RO, Option	Forward and Reverse Radio Configuration, values depending on multiplex option and service option (see Ch. 4) Service Option, syntax: S<Option_no>D, e.g. S55D	–	–	V3.10
Description of command				Sig. State
This command is always a query. It returns the current radio configuration and service option.				All

DEFault:SCONfig[?] <Enable>		Default Settings		
Enable	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	The parameters are set to their default values The parameters differ from their default values (partially or totally)	ON	–	V3.05
Description of command				Sig. State
If used as a setting command with the parameter ON, this command sets all parameters of the subsystem ServiceCONfig to their default values (the setting OFF results in an error message). If used as a query, the command returns whether all parameters are set to their default values (ON) or not (OFF).				All

CONFigure:SCONfig:SCLass1:SERVice[?]				1 st Service Class
PROCedure:SCONfig:SCLass1:SERVice[?]				
<Service(n)>				
<Service(n)>	Description of parameters	Def. value	Def. unit	FW vers.
LOOP SPEech TDAT PDAT WMT	Loopback service Speech service Test data service Packet data service Wireless messaging teleservice (CONFigure... only)	SPE	–	V3.05
Description of command				Sig. State
This command configures the service type to use to establish a call to the mobile. The Loopback mode must be used for receiver quality measurements.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.				

CONFigure:SCONfig:AMOC[?]				Accept MS Originated Call
<Service(n)>				
<Service(n)>	Description of parameters	Def. value	Def. unit	FW vers.
All SCL1 FSC1 ICAW ICFW ICOR ROAW ROFW ROOR BUAW BUFW IGNR	Accept all calls Accept only selected primary service Force to selected primary service Accept No Calls – Intercept (AWIM) Accept No Calls – Intercept (FWIM) Accept No Calls – Intercept (Order) Accept No Calls – Intercept (AWIM) Accept No Calls – Intercept (FWIM) Accept No Calls – Intercept (Order) Accept No Calls – Intercept (AWIM) Accept No Calls – Intercept (FWIM) Ignore MS	ALL	–	V3.40
Description of command				Sig. State
This command selects the types of Mobile Station Originated Calls (MOC) that the CMU will accept and specifies how it will respond to an accepted or rejected MOC.				SON, SOFF, REG

CONFigure:SCONfig:CURRent:RC[?]				Active Radio Configuration
<F_RC>, <R_RC>				
<F-RC>, <R-RC>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 5, 1 to 5	Forward Radio Configuration Reverse Radio Configuration	–	–	V3.50
Description of command				Sig. State
This command selects the forward and reverse radio configuration for the active service option. The range of radio configurations depends on the service option. The settings affect all traffic channels (FCH, SCH0, SCH1) to be configured for the service options, they correspond to the <i>FCH & SCH Common Config</i> . An error message is generated if the settings are incompatible with the active service option.				All

Subsystem SCONfig:SClass:LOOP

The subsystem SCONfig:SClass:LOOP defines the service options for the Loopback service type.

CONFigure:SCONfig:SClass1:LOOP:SOPTION[?]				Loopback Service
PROCEDURE:SCONfig:SClass1:LOOP:SOPTION[?]				
<Loopback Service Current Sel>				
<Loopback Service Current Sel>	Description of parameters	Def. value	Def. unit	FW vers.
S02D	Service Option 2	S02D	–	V3.05
S09D	Service Option 9			
Description of command				Sig. State
This command determines the service option to use when establishing a call in the loopback service mode.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCEDURE form of the command is used in the CEST signalling state.				

CONFigure:SCONfig:SClass1:LOOP:S02D:FCH?				Radio Configuration
PROCEDURE:SCONfig:SClass1:LOOP:S02D:FCH?				
Returned value	Description of parameters	Def. Value	Def. Unit	FW vers.
Forward Radio Configuration,	1 to 4	1	–	V3.05
Forward Multiplex Option,	1 to 4	1	–	
Reverse Radio Configuration,	1 to 3	1	–	
Reverse Multiplex Option	1 to 3	1	–	
Description of command				Sig. State
This command is always a query. It returns the radio configuration and the multiplex option of the forward and reverse fundamental traffic channel for service option 2.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCEDURE form of the command is used in the CEST signalling state.				

CONFigure:SCONfig:SClass1:LOOP:S09D:FCH?				Radio Configuration
PROCEDURE:SCONfig:SClass1:LOOP:S09D:FCH?				
Returned value	Description of parameters	Def. value	Def. unit	FW vers.
Forward Radio Configuration,	2 to 5	2	–	V3.05
Forward Multiplex Option,	2 to 5	2	–	
Reverse Radio Configuration,	2 to 4	2	–	
Reverse Multiplex Option	2 to 4	2	–	
Description of command				Sig. State
This command is always a query. It returns the radio configuration and the multiplex option of the forward and reverse fundamental traffic channel for service option 9.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCEDURE form of the command is used in the CEST signalling state.				

CONFigure:SCONfig:SCLass1:LOOP:S55D:FCH? PROCEDURE:SCONfig:SCLass1:LOOP:S55D:FCH?		Radio Configuration		
Returned value	Description of parameters	Def. value	Def. unit	FW vers.
Forward Radio Configuration,	1 to 5	1	–	V3.10
Forward Multiplex Option,	1 to 5	1	–	
Reverse Radio Configuration,	1 to 4	1	–	
Reverse Multiplex Option	1 to 4	1	–	
Description of command				Sig. State
This command is always a query. It returns the radio configuration and the multiplex option of the forward and reverse fundamental traffic channel for service option 55. The available radio configurations depend on the multiplex options; see Chapter 4.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCEDURE form of the command is used in the CEST signalling state.				

CONFigure:SCONfig:SCLass1:LOOP:S02D:FCH:RC[?] PROCEDURE:SCONfig:SCLass1:LOOP:S02D:FCH:RC[?] <F_RC>, <R_RC>		Radio Configuration		
<F_RC>	Description of parameters	Def. value	Def. unit	
1 to 4 MINimum MAXimum DEFault,	Forward radio configuration Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	1	–	
<R_RC>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 3 MINimum MAXimum DEFault	Reverse radio configuration Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	1	–	V3.05
Description of command				Sig. State
This command sets the radio configuration of the forward and reverse fundamental traffic channel for service option 2.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCEDURE form of the command is used in the CEST signalling state.				

CONFigure:SCONfig:SCLass1:LOOP:S09D:FCH:RC[?]				Radio Configuration
PROCedure:SCONfig:SCLass1:LOOP:S09D:FCH:RC[?]				
<F_RC>, <R_RC>				
<F_RC>	Description of parameters	Def. value	Def. unit	
2 to 5 MINimum MAXimum DEFault,	Forward radio configuration Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	2	–	
<R_RC>	Description of parameters	Def. value	Def. unit	FW vers.
2 to 4 MINimum MAXimum DEFault	Reverse radio configuration Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	2	–	V3.05
Description of command				Sig. State
This command sets the radio configuration of the forward and reverse fundamental traffic channel for service option 9.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.				

CONFigure:SCONfig:SCLass1:LOOP:S55D:FCH:RC[?]				Radio Configuration
PROCedure:SCONfig:SCLass1:LOOP:S55D:FCH:RC[?]				
<F_RC>, <R_RC>				
<F_RC>	Description of parameters	Def. value	Def. unit	
12 to 5 MINimum MAXimum DEFault,	Forward radio configuration Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	1	–	
<R_RC>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 4 MINimum MAXimum DEFault	Reverse radio configuration Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	1	–	V3.10
Description of command				Sig. State
This command sets the radio configuration of the forward and reverse fundamental traffic channel for service option 55. The available radio configurations depend on the multiplex options; see Chapter 4.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.				

CONFigure:SCONfig:SCLass1:LOOP:S55D:FCH:FORWard:MO[?]				Multiplex Option, Forward
PROCedure:SCONfig:SCLass1:LOOP:S55D:FCH:FORWard:MO[?]				
<F_FCH_MO>				
<F_FCH_MO>	Description of parameters	Def. value	Def. unit	
1 2 MINimum MAXimum DEFault	Forward multiplex option Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	1	–	
Description of command				Sig. State
<p>This command sets the multiplex option of the forward fundamental traffic channel for service option 55. The multiplex option in the reverse channel must be equal; therefore the CONFigure:SCONfig:SCLass1:LOOP:S55D:FCH:REVerse:MO setting is overwritten.</p> <p>The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.</p>				See Descript.

CONFigure:SCONfig:SCLass1:LOOP:S55D:FCH:REVerse:MO[?]				Multiplex Option, Reverse
PROCedure:SCONfig:SCLass1:LOOP:S55D:FCH:REVerse:MO[?]				
<R_FCH_MO>				
<R_FCH_MO>	Description of parameters	Def. value	Def. unit	
1 2 MINimum MAXimum DEFault	Reverse multiplex option Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	1	–	
Description of command				Sig. State
<p>This command sets the multiplex option of the reverse fundamental traffic channel for service option 55. The multiplex option in the reverse channel must be equal; therefore the CONFigure:SCONfig:SCLass1:LOOP:S55D:FCH:FORWard:MO setting is overwritten.</p> <p>The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.</p>				See Descript.

CONFigure:SCONfig:SCLass1:LOOP:S02D:FCH:FRAT[?]				Frame Rate
PROCedure:SCONfig:SCLass1:LOOP:S02D:FCH:FRAT[?]				
<Frame Rate>				
<Frame Rate>	Description of parameters	Def. Value	Def. Unit	FW vers.
EIGHth QUARter HALF FULL DEFault	Frames at 1/8 of the rate set Frames at 1/4 of the rate set Frames at 1/2 of the rate set Frames at the full rate set Frame rate set to default	FULL	–	V3.05
Description of command				Sig. State
<p>This command sets the frame rate for a traffic channel for test calls using service option 2.</p> <p>The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.</p>				See Descript.

CONFigure:SCONfig:SCLass1:LOOP:S09D:FCH:FRAT[?]				Frame Rate
PROCedure:SCONfig:SCLass1:LOOP:S09D:FCH:FRAT[?]				
<Frame Rate>				
<Frame Rate>	Description of parameters	Def. Value	Def. Unit	FW vers.
EIGHth QUARter HALF FULL DEFault	Frames at 1/8 of the rate set Frames at 1/4 of the rate set Frames at 1/2 of the rate set Frames at the full rate set Frame rate set to default	FULL	–	V3.05
Description of command				Sig. State
This command sets the frame rate for a traffic channel for test calls using service option 9.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.				

CONFigure:SCONfig:SCLass1:LOOP:S55D:FCH:FRAT[?]				Frame Rate
PROCedure:SCONfig:SCLass1:LOOP:S55D:FCH:FRAT[?]				
<Frame Rate>				
<Frame Rate>	Description of parameters	Def. Value	Def. Unit	FW vers.
EIGHth QUARter HALF FULL DEFault	Frames at 1/8 of the rate set Frames at 1/4 of the rate set Frames at 1/2 of the rate set Frames at the full rate set Frame rate set to default	FULL	–	V3.10
Description of command				Sig. State
This command sets the frame rate for a traffic channel for test calls using service option 55.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.				

CONFigure:SCONfig:SCLass1:LOOP:S02D:FCH:PGEN[?]				Pattern Generation
PROCedure:SCONfig:SCLass1:LOOP:S02D:FCH:PGEN[?]				
<Pattern Generation>				
<Pattern Generation>	Description of parameters	Def. Value	Def. Unit	FW vers.
RANDom FIXed DEFault	Random Fixed	RAND	–	V3.05
Description of command				Sig. State
This command sets the pattern generation for service option 2 to either a random or fixed pattern. If this command is set to FIXed, pattern sent to the mobile station is defined with the command CONFigure:SCONfig:SCLass1:LOOP:S02D:FCH:PATtern[?].				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.				

CONFigure:SCONfig:SCLass1:LOOP:S09D:FCH:PGEN[?] PROCedure:SCONfig:SCLass1:LOOP:S09D:FCH:PGEN[?] <Pattern Generation>				Pattern Generation
<Pattern Generation>	Description of parameters	Def. Value	Def. Unit	FW vers.
RANDom FIXed DEFault	Random Fixed	RAND	–	V3.05
Description of command				Sig. State
This command sets the pattern generation for service option 9 to either a random or fixed pattern. If this command is set to FIXed, pattern sent to the mobile station is defined with the command CONFigure:SCONfig:SCLass1:LOOP:S09D:FCH:PATtern[?].				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.				

CONFigure:SCONfig:SCLass1:LOOP:S55D:FCH:PGEN[?] PROCedure:SCONfig:SCLass1:LOOP:S55D:FCH:PGEN[?] <Pattern Generation>				Pattern Generation
<Pattern Generation>	Description of parameters	Def. Value	Def. Unit	FW vers.
RANDom FIXed DEFault	Random Fixed	RAND	–	V3.10
Description of command				Sig. State
This command sets the pattern generation for service option 55 to either a random or fixed pattern. If this command is set to FIXed, pattern sent to the mobile station is defined with the command CONFigure:SCONfig:SCLass1:LOOP:S55D:FCH:PATtern[?].				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.				

CONFigure:SCONfig:SCLass1:LOOP:S02D:FCH:PATtern[?] PROCedure:SCONfig:SCLass1:LOOP:S02D:FCH:PATtern[?] <Pattern>				Pattern
<Pattern>	Description of parameters	Def. Value	Def. Unit	FW vers.
{Hex value} DEFault	Hex values for pattern generator	A5A5A5A 5A5A5A5 A5	–	V3.05
Description of command				Sig. State
This command defines the pattern used by the pattern generator for service option 2. This pattern is used when the Pattern Generation is set to FIXed.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.				

CONFigure:SCONfig:SCLass1:LOOP:S09D:FCH:PATtern[?]				Pattern
PROCedure:SCONfig:SCLass1:LOOP:S09D:FCH:PATtern[?]				
<Pattern>				
<Pattern>	Description of parameters	Def. Value	Def. Unit	FW vers.
{Hex value} DEFault	Hex values for pattern generator	A5A5A5A 5A5A5A5 A5	–	V3.05
Description of command				Sig. State
This command defines the pattern used by the pattern generator for service option 9. This pattern is used when the Pattern Generation is set to FIXed.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.				

CONFigure:SCONfig:SCLass1:LOOP:S55D:FCH:PATtern[?]				Pattern
PROCedure:SCONfig:SCLass1:LOOP:S55D:FCH:PATtern[?]				
<Pattern>				
<Pattern>	Description of parameters	Def. Value	Def. Unit	FW vers.
{Hex value} DEFault	Hex values for pattern generator	A5A5A5A 5A5A5A5 A5	–	V3.05
Description of command				Sig. State
This command defines the pattern used by the pattern generator for service option 55. This pattern is used when the Pattern Generation is set to FIXed.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.				

Subsystem SCONfig:SCLass:SPEech

The subsystem SCONfig:SCLass:SPEech defines the service options for the Speech service type.

CONFigure:SCONfig:SCLass1:SPEech:SOPTion[?]				Speech Service
PROCedure:SCONfig:SCLass1:SPEech:SOPTion[?]				
<Speech Service Current Sel>				
<Speech Service Current Sel>	Description of parameters	Def. value	Def. unit	FW vers.
S01D S03D S17D SX8T	Service Option 1 Service Option 3 Service Option 17 Service Option 0X8000	S01D	–	V3.05
Description of command				Sig. State
This command determines the service option to use when establishing a call in the speech mode.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.				

CONFigure:SCONfig:SClass1:SPeEch:S01D:FCH? PROCEDURE:SCONfig:SClass1:SPeEch:S01D:FCH?				Radio Configuration
Returned value	Description of parameters	Def. value	Def. unit	FW vers.
Forward Radio Configuration,	1 to 4	1	–	V3.05
Forward Multiplex Option,	1 to 4	1	–	
Reverse Radio Configuration,	1 to 3	1	–	
Reverse Multiplex Option	1 to 3	1	–	
Description of command				Sig. State
This command is always a query. It returns the radio configuration and multiplex option of the forward and reverse fundamental traffic channel for service option 1.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCEDURE form of the command is used in the CEST signalling state.				

CONFigure:SCONfig:SClass1:SPeEch:S03D:FCH? PROCEDURE:SCONfig:SClass1:SPeEch:S03D:FCH?				Radio Configuration
Returned value	Description of parameters	Def. value	Def. unit	FW vers.
Forward Radio Configuration,	1 to 4	1	–	V3.05
Forward Multiplex Option,	1 to 4	1	–	
Reverse Radio Configuration,	1 to 3	1	–	
Reverse Multiplex Option	1 to 3	1	–	
Description of command				Sig. State
This command is always a query. It returns the radio configuration and multiplex option of the forward and reverse fundamental traffic channel for service option 3.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCEDURE form of the command is used in the CEST signalling state.				

CONFigure:SCONfig:SClass1:SPeEch:S17D:FCH? PROCEDURE:SCONfig:SClass1:SPeEch:S17D:FCH?				Radio Configuration
Returned value	Description of parameters	Def. value	Def. unit	FW vers.
Forward Radio Configuration,	2 to 5	2	–	V3.05
Forward Multiplex Option,	2 to 5	2	–	
Reverse Radio Configuration,	2 to 4	2	–	
Reverse Multiplex Option	2 to 4	2	–	
Description of command				Sig. State
This command is always a query. It returns the radio configuration and multiplex option of the forward and reverse fundamental traffic channel for service option 17.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCEDURE form of the command is used in the CEST signalling state.				

CONFigure:SCONfig:SClass1:SPeEch:SX8T:FCH? PROCedure:SCONfig:SClass1:SPeEch:SX8T:FCH?				Radio Configuration
Returned value	Description of parameters	Def. value	Def. unit	FW vers.
Forward Radio Configuration,	2 to 5	2	–	V3.05
Forward Multiplex Option,	2 to 5	2	–	
Reverse Radio Configuration,	2 to 4	2	–	
Reverse Multiplex Option	2 to 4	2	–	
Description of command				Sig. State
This command is always a query. It returns the radio configuration and multiplex option of the forward and reverse fundamental traffic channel for service option X8T.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.				

CONFigure:SCONfig:SClass1:SPeEch:S01D:FCH:RC[?] PROCedure:SCONfig:SClass1:SPeEch:S01D:FCH:RC[?] <F_RC>, <R_RC>				Radio Configuration
<F_RC>	Description of parameters	Def. value	Def. unit	
1 to 4 MINimum MAXimum DEFault,	Forward radio configuration Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	1	–	
<R_RC>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 3 MINimum MAXimum DEFault	Reverse radio configuration Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	1	–	V3.05
Description of command				Sig. State
This command sets the radio configuration of the forward and reverse fundamental traffic channel for service option 01D.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.				

CONFigure:SCONfig:SClass1:SPeECH:S03D:FCH:RC[?]				Radio Configuration
PROCedure:SCONfig:SClass1:SPeECH:S03D:FCH:RC[?]				
<F_RC>, <R_RC>				
<F_RC>	Description of parameters	Def. value	Def. unit	
1 to 4 MINimum MAXimum DEFault,	Forward radio configuration Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	1	–	
<R_RC>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 3 MINimum MAXimum DEFault	Reverse radio configuration Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	1	–	V3.05
Description of command				Sig. State
This command sets the radio configuration of the forward and reverse fundamental traffic channel for service option 03.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.				

CONFigure:SCONfig:SClass1:SPeECH:S17D:FCH:RC[?]				Radio Configuration
PROCedure:SCONfig:SClass1:SPeECH:S17D:FCH:RC[?]				
<F_RC>, <R_RC>				
<F_RC>	Description of parameters	Def. value	Def. unit	
2 to 5 MINimum MAXimum DEFault,	Forward radio configuration Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	2	–	
<R_RC>	Description of parameters	Def. value	Def. unit	FW vers.
2 to 4 MINimum MAXimum DEFault	Reverse radio configuration Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	2	–	V3.05
Description of command				Sig. State
This command sets the radio configuration of the forward and reverse fundamental traffic channel for service option 17.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.				

CONFigure:SCONfig:SClass1:SPeech: SX8T:FCH:RC[?] PROCedure:SCONfig:SClass1:SPeech: SX8T:FCH:RC[?] <F_RC>, <R_RC>				Radio Configuration
<F_RC>	Description of parameters	Def. value	Def. unit	
2 to 5 MINimum MAXimum DEFault,	Forward radio configuration Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	2	–	
<R_RC>	Description of parameters	Def. value	Def. unit	FW vers.
2 to 4 MINimum MAXimum DEFault	Reverse radio configuration Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	2	–	V3.05
Description of command				Sig. State
This command sets the radio configuration of the forward and reverse fundamental traffic channel for service option X8T.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.				

CONFigure:SCONfig:SClass1:SPeech:S01D:VCODer[?] <VoCoder>				VoCoder
<VoCoder>	Description of parameters	Def. value	Def. unit	FW vers.
ECHO V8 V8Low ECAL DCAL DEFault	Loop back in the CMU with delay 8K speech coder, amplified analog input signal 8k speech coder Encoder Cal. Decoder Cal. Use the default setting	ECHO	–	V3.05 V3.10
Description of command				Sig. State
This command configures how the CMU returns the data transmitted over the traffic channel to the mobile for service option 1. The delay time is set via CONFigure:SCONfig:SClass1:SPeech:S01D:EDELay.				all

CONFigure:SCONfig:SClass1:SPeech:S03D:VCODer[?] <VoCoder>				VoCoder
<VoCoder>	Description of parameters	Def. value	Def. unit	FW vers.
ECHO V8E V8ELow ECAL DCAL DEFault	Loop back in the CMU with delay 8K enhanced speech coder, amplified analog input signal 8k enhanced speech coder Encoder Cal. Decoder Cal. Use the default setting	ECHO	–	V3.05 V3.10
Description of command				Sig. State
This command configures how the CMU returns the data transmitted over the traffic channel to the mobile for service option 3. The delay time is set via CONFigure:SCONfig:SClass1:SPeech:S03D:EDELay.				all

CONFigure:SCONfig:SClass1:SPeEch:S17D:VCOder[?] <VoCoder>				VoCoder
<VoCoder>	Description of parameters	Def. value	Def. unit	FW vers.
ECHO	Loop back in the CMU with delay	ECHO	–	V3.05
V13	13K speech coder, amplified analog input signal			V3.20
V13Low	13k speech coder			V3.20
ECAL	Encoder Cal.			V3.15
DCAL	Decoder Cal.			V3.15
DEfault	Use the default setting			V3.15
Description of command				Sig. State
This command configures how the CMU returns the data transmitted over the traffic channel to the mobile for service option 17. The delay time is set via CONFigure:SCONfig:SClass1:SPeEch:S17D:EDELay.				all

CONFigure:SCONfig:SClass1:SPeEch:SX8T:VCOder[?] <VoCoder>				VoCoder
<VoCoder>	Description of parameters	Def. value	Def. unit	FW vers.
ECHO	Loop back in the CMU with delay	ECHO	–	V3.05
DEfault				
Description of command				Sig. State
This command configures how the CMU returns the data transmitted over the traffic channel to the mobile for service option X8T. The delay time is set via CONFigure:SCONfig:SClass1:SPeEch:SX8T:EDELay.				all

CONFigure:SCONfig:SClass1:SPeEch:S01D:EDELay[?] CONFigure:SCONfig:SClass1:SPeEch:S03D:EDELay[?] CONFigure:SCONfig:SClass1:SPeEch:S17D:EDELay[?] CONFigure:SCONfig:SClass1:SPeEch:SX8T:EDELay[?] <Delay>				Echo Delay
<Delay>	Description of parameters	Def. value	Def. unit	FW vers.
0.04 s to 5 s	Delay before the received data is looped back	2.0	s	V3.08
MINimum	Sets the value to the range minimum			
MAXimum	Sets the value to the range maximum			
DEfault	Sets the value to the default setting			
Description of command				Sig. State
These commands define the time that the CMU waits before it loops back the received data if the Voice Coder is set to Echo mode. The entered value is rounded to the closest of the values: $0.04 + (n*0.02)$, where $0 \leq n \leq 248$.				all
The four commands are valid for service options 1, 3, 17 and 0x800, respectively.				

Subsystem SCONfig:SClass:TDAT

The subsystem SCONfig:SClass:TDAT defines the service options for the Test Data service type.

CONFigure:SConfig:SClass1:TDAT:SOPTion[?]				Test Data Service
PROCedure:SConfig:SClass1:TDAT:SOPTion[?]				
<Test Data Service Current Sel>				
<Test Data Service Current Sel>	Description of parameters	Def. value	Def. unit	FW vers.
S32D	Service Option 32	S32D	–	V3.05
Description of command				Sig. State
This command determines the service option to use when establishing a call in the test data mode, particularly for the high data rates using the supplemental channels (SCH).				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.				

CONFigure:SConfig:SClass1:TDAT:S32D:FSCCommon:RC[?]				Radio Configuration
PROCedure:SConfig:SClass1:TDAT:S32D:FSCCommon:RC[?]				
<F_RC>, <R_RC>				
<F_RC>	Description of parameters	Def. value	Def. unit	
1 to 5 MINimum MAXimum DEFault,	Forward radio configuration Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	1	–	
<R_RC>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 5 MINimum MAXimum DEFault	Reverse radio configuration Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	1	–	V3.05
Description of command				Sig. State
This command sets a common radio configuration of the fundamental and supplemental forward and reverse traffic channel for service option 32.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.				

CONFigure:SConfig:SClass1:TDAT:S32D:FCH?				Radio Configuration
Returned value	Description of parameters	Def. value	Def. unit	FW vers.
Forward Radio Configuration,	1 to 5	1	–	V3.05
Forward Multiplex Option,	1 to 5	1	–	
Reverse Radio Configuration,	1 to 5	1	–	
Reverse Multiplex Option	1 to 5	1	–	
Description of command				Sig. State
This command is always a query. It returns the radio configuration and multiplex option of the forward and reverse fundamental traffic channel for service option 32.				All

CONFigure:SCONfig:SClass1:TDAT:S32D:FCH:FORWard:PGEN[?]				Pattern Generation
<Pattern Generation>				
<Pattern Generation>	Description of parameters	Def. Value	Def. Unit	FW vers.
RANDom FIXed DEFault	Random Fixed	RAND	–	V3.05
Description of command				Sig. State
This command sets the pattern generation for service option 32 to either a random or fixed pattern for the forward fundamental channel. If this command is set to FIXed, the pattern sent to the mobile station is defined with the command: CONFigure:SClass1:TDAT:S32D:FCH:FORWard:PATtern[?].				All

CONFigure:SCONfig:SClass1:TDAT:S32D:FCH:REVerse:PGEN[?]				Pattern Generation
<Pattern Generation>				
<Pattern Generation>	Description of parameters	Def. Value	Def. Unit	FW vers.
RANDom FIXed DEFault	Random Fixed	RAND	–	V3.05
Description of command				Sig. State
This command sets the pattern generation for service option 32 to either a random or fixed pattern for the reverse fundamental channel. If this command is set to FIXed, the pattern sent to the mobile station is defined with the command: CONFigure:SClass1:TDAT:S32D:FCH:FORWard:PATtern[?].				All

CONFigure:SCONfig:SClass1:TDAT:S32D:FCH:FORWard:PATtern[?]				Pattern
<Pattern>				
<Pattern>	Description of parameters	Def. Value	Def. Unit	FW vers.
{Hex value} DEFault	Hex values for pattern generator	A5A5A5A5 A5A5A5A5	–	V3.05
Description of command				Sig. State
This command defines the pattern used by the pattern generator for service option 32. This pattern is used when the Pattern Generation is set to FIXed.				All

CONFigure:SCONfig:SClass1:TDAT:S32D:FCH:REVerse:PATtern[?]				Pattern
<Pattern>				
<Pattern>	Description of parameters	Def. Value	Def. Unit	FW vers.
{Hex value} DEFault	Hex values for pattern generator	A5A5A5A5 A5A5A5A5	–	V3.05
Description of command				Sig. State
This command defines the pattern used by the pattern generator for service option 32. This pattern is used when the Pattern Generation is set to FIXed.				All

CONFigure:SCONfig:SClass1:TDAT:S32D:FCH:FORWard:CBFRames[?]				Circular Buffer Frames
<Circular Buffer Frames>				
<Circular Buffer Frames>	Description of parameters	Def. Value	Def. Unit	FW vers.
1 to 255	Forward circular buffer frames	2	–	V3.05
Description of command				Sig. State
This command sets the number of frames to use in the circular buffer of the forward fundamental channel when the random pattern is selected.				All

CONFigure:SCONfig:SClass1:TDAT:S32D:FCH:REVerse:CBFRames[?]				Circular Buffer Frames
<Circular Buffer Frames>				
<Circular Buffer Frames>	Description of parameters	Def. Value	Def. Unit	FW vers.
1 to 255	Reverse circular buffer frames	2	–	V3.05
Description of command				Sig. State
This command sets the number of frames to use in the circular buffer of the reverse fundamental channel when the random pattern is selected.				All

CONFigure:SCONfig:SClass1:TDAT:S32D:FCH:FORWard:TXON[?]				Transmit On Period
<Transmit On Period>				
<Transmit On Period>	Description of parameters	Def. Value	Def. Unit	FW vers.
0 to 255	Forward transmission on period	1	–	V3.05
Description of command				Sig. State
This command sets the transmission on period in frames of the forward fundamental channel when the frame activity is deterministic.				All

CONFigure:SCONfig:SClass1:TDAT:S32D:FCH:REVerse:TXON[?]				Transmit On Period
<Transmit On Period>				
<Transmit On Period>	Description of parameters	Def. Value	Def. Unit	FW vers.
0 to 255	Reverse transmission on period	1	–	V3.05
Description of command				Sig. State
This command sets the transmission on period in frames of the reverse fundamental channel when the frame activity is deterministic.				All

CONFigure:SCONfig:SClass1:TDAT:S32D:FCH:FORWard:TXOFF[?]				Transmit Off Period
<Transmit Off Period>				
<Transmit Off Period>	Description of parameters	Def. Value	Def. Unit	FW vers.
0 to 255	Forward transmission off period	0	–	V3.05
Description of command				Sig. State
This command sets the transmission off period in frames of the forward fundamental channel when the frame activity is deterministic.				All

CONFigure:SCONfig:SClass1:TDAT:S32D:FCH:REVerse:TXOff[?]				Transmit Off Period
<Transmit Off Period>				
<Transmit Off Period>	Description of parameters	Def. Value	Def. Unit	FW vers.
0 to 255	Reverse transmission off period	0	–	V3.05
Description of command				Sig. State
This command sets the transmission off period in frames of the reverse fundamental channel when the frame activity is deterministic.				All

CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ZERO:FORWARD:ENABLE[?]				Forward SCH0 Enable
<SCH0 Enable>				
<SCH0 Enable>	Description of parameters	Def. Value	Def. Unit	FW vers.
ON OFF	Enable or disable forward supplemental channel 0.	OFF	–	V3.05
Description of command				Sig. State
This command disables or enables the forward supplemental channel 0.				All

CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ZERO:REVerse:ENABLE?				Reverse SCH0 Enable
<SCH0 Enable>				
<SCH0 Enable>	Description of parameters	Def. Value	Def. Unit	FW vers.
ON OFF	Reverse supplemental channel 0 enabled or disabled	OFF	–	V3.05
Description of command				Sig. State
This command queries whether the reverse supplemental channel 0 is enabled. The channel is enabled if the forward channel is enabled (CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ZERO:FORWARD:ENABLE) and vice versa.				All

CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ZERO?				Radio Configuration
Returned value	Description of parameters	Def. value	Def. unit	FW vers.
Forward Radio Configuration,	1 to 5	1	–	V3.05
Forward Multiplex Option,	1 to 5	1	–	
Reverse Radio Configuration,	1 to 5	1	–	
Reverse Multiplex Option	1 to 5	1	–	
Description of command				Sig. State
This command is always a query. It returns the radio configuration and multiplex option of the forward and reverse supplemental traffic channel 0 for service option 32.				All

CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ZERO:FORWARD:CHANNEL[?]				SCH0 Channel (Walsh Code)
<FSCH Channel>				
<FSCH Channel>	Description of parameters	Def. value	Def. unit	FW vers.
0 to 127	Forward supplemental channel SCH0 Walsh code	35	–	V3.60
Description of command				Sig. State
This command determines the Walsh code for the forward supplemental traffic channel.				All

CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ZERO:FORWard:QOF[?]				SCH0 QOF
<QOF>				
<QOF>	Description of parameters	Def. value	Def. unit	FW vers.
0 to 3	Quasi-orthogonal Function	0	–	V3.60
Description of command				Sig. State
This command sets the Quasi-orthogonal Function that the Supplemental Channel SCH0 uses in the forward CDMA channel.				All

CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ZERO:FORWard:PGEN[?]				Pattern Generation
<Pattern Generation>				
<Pattern Generation>	Description of parameters	Def. Value	Def. Unit	FW vers.
RANdOm FIXed DEFault	Random Fixed	RAND	–	V3.05
Description of command				Sig. State
This command sets the pattern generation for service option 32 to either a random or fixed pattern for the forward fundamental channel. If this command is set to FIXed, the pattern sent to the mobile station is defined with the command: CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ZERO:FORWard:PATtern[?].				All

CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ZERO:REVerse:PGEN[?]				Pattern Generation
<Pattern Generation>				
<Pattern Generation>	Description of parameters	Def. Value	Def. Unit	FW vers.
RANdOm FIXed DEFault	Random Fixed	RAND	–	V3.05
Description of command				Sig. State
This command sets the pattern generation for service option 32 to either a random or fixed pattern for the reverse fundamental channel. If this command is set to FIXed, the pattern sent to the mobile station is defined with the command: CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ZERO:FORWard:PATtern[?].				All

CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ZERO:FORWard:PATtern[?]				Pattern
<Pattern>				
<Pattern>	Description of parameters	Def. Value	Def. Unit	FW vers.
{Hex value} DEFault	Hex values for pattern generator	A5A5A5A5 A5A5A5A5	–	V3.05
Description of command				Sig. State
This command defines the pattern used by the pattern generator for service option 32. This pattern is used when the Pattern Generation is set to FIXed.				All

CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ZERO:REVerse:PATtern[?]				Pattern
<Pattern>				
<Pattern>	Description of parameters	Def. Value	Def. Unit	FW vers.
{Hex value} DEFault	Hex values for pattern generator	A5A5A5A5 A5A5A5A5	–	V3.05
Description of command				Sig. State
This command defines the pattern used by the pattern generator for service option 32. This pattern is used when the Pattern Generation is set to FIXED.				All

CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ZERO:FORward:CBFRames[?]				Circular Buffer Frames
<Circular Buffer Frames>				
<Circular Buffer Frames>	Description of parameters	Def. Value	Def. Unit	FW vers.
1 to 255	Forward circular buffer frames	2	–	V3.05
Description of command				Sig. State
This command sets the number of frames to use in the circular buffer of the forward supplemental channel 0 when the random pattern is selected.				All

CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ZERO:REVerse:CBFRames[?]				Circular Buffer Frames
<Circular Buffer Frames>				
<Circular Buffer Frames>	Description of parameters	Def. Value	Def. Unit	FW vers.
1 to 255	Reverse circular buffer frames	2	–	V3.05
Description of command				Sig. State
This command sets the number of frames to use in the circular buffer of the reverse supplemental channel 0 when the random pattern is selected.				All

CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ZERO:FORward:TXON[?]				Transmit On Period
<Transmit On Period>				
<Transmit On Period>	Description of parameters	Def. Value	Def. Unit	FW vers.
0 to 255	Forward transmission on period	1	–	V3.05
Description of command				Sig. State
This command sets the transmission on period in frames of the forward supplemental channel 0 when the frame activity is deterministic.				All

CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ZERO:REVerse:TXON[?]				Transmit On Period
<Transmit On Period>				
<Transmit On Period>	Description of parameters	Def. Value	Def. Unit	FW vers.
0 to 255	Reverse transmission on period	1	–	V3.05
Description of command				Sig. State
This command sets the transmission on period in frames of the reverse supplemental channel 0 when the frame activity is deterministic.				All

CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ZERO:FORWard:TXOff[?]				Transmit Off Period	
<Transmit Off Period>					
<Transmit Off Period>	Description of parameters	Def. Value	Def. Unit	FW vers.	
0 to 255	Forward transmission off period	0	–	V3.05	
Description of command					Sig. State
This command sets the transmission off period in frames of the forward supplemental channel 0 when the frame activity is deterministic.					All

CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ZERO:REVErse:TXOff[?]				Transmit Off Period	
<Transmit Off Period>					
<Transmit Off Period>	Description of parameters	Def. Value	Def. Unit	FW vers.	
0 to 255	Reverse transmission off period	0	–	V3.05	
Description of command					Sig. State
This command sets the transmission off period in frames of the reverse supplemental channel 0 when the frame activity is deterministic.					All

CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ZERO:FORWard:MPPL[?]				MuxPPL	
<MuxPPL>					
<MuxPPL>	Description of parameters	Def. Value	Def. Unit	FW vers.	
1 2 4 8	MuxPDUs per physical layer SDU	1	–	V3.05	
Description of command					Sig. State
This command sets the MuxPDUs per physical layer SDU which is used to determine Multiplex Option and Data Rate of the forward supplemental channel 0. Refer to Table 6-1 and Table 6-2 on p. 6.159 about the relationship between MuxPPU, Frame Size, and Data Rate.					All

CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ZERO:REVErse:MPPL[?]				MuxPPL	
<MuxPPL>					
<MuxPPL>	Description of parameters	Def. Value	Def. Unit	FW vers.	
1 2 4 8	MuxPDUs per physical layer SDU	1	–	V3.05	
Description of command					Sig. State
This command sets the MuxPDUs per physical layer SDU which is used to determine Multiplex Option and Data Rate of the reverse supplemental channel 0. Refer to Table 6-1 and Table 6-2 on p. 6.159 about the relationship between MuxPPU, Frame Size, and Data Rate.					All

Table 6-1: MuxPDUs per physical layer SDU

F-SCHs are assigned W_n^N , where $N = 4, 8, 16, 32, 64, 128, 128, \text{ and } 128$ for the maximum assigned QPSK symbol rate. The maximum assigned QPSK symbol rate depends on the radio class, frame size, and multiplex option. The multiplex option depends on the frame type (Rate 1, Rate 2, or Rate 3) and MuxPDUs per physical layer SDU. Any QOF may be used. The following table illustrates the Walsh selection versus the combinations of these parameters:

MuxPDUs per physical layer SDU			Frame Size								
Frame Type			RC3			RC4			RC5		
Rate 1	Rate 2	Rate 3	20 ms	40 ms	80 ms	20 ms	40 ms	80 ms	20 ms	40 ms	80 ms
1			W_n^{64}	W_n^{128}	W_n^{128}	W_n^{128}	W_n^{128}	W_n^{128}	W_n^{64}	W_n^{128}	W_n^{128}
2	1		W_n^{32}	W_n^{64}	W_n^{128}	W_n^{64}	W_n^{128}	W_n^{128}	W_n^{32}	W_n^{64}	W_n^{128}
4	2		W_n^{16}	W_n^{32}	W_n^{64}	W_n^{32}	W_n^{64}	W_n^{128}	W_n^{16}	W_n^{32}	W_n^{64}
8	4		W_n^8	W_n^{16}	W_n^{32}	W_n^{16}	W_n^{32}	W_n^{64}	W_n^8	W_n^{16}	W_n^{32}
	8		W_n^4	W_n^8	W_n^{16}	W_n^8	W_n^{16}	W_n^{32}	W_n^4	W_n^8	W_n^{16}
		1				W_n^4	W_n^8	W_n^{16}			

Table 6-2: MuxPDUs per Physical Layer per Data Rate

MuxPDUs per Physical Layer SDU	Data Rate (kbps)					
	F-SCH RC=3, 4 R-SCH RC=3			F-SCH RC=5 R-SCH RC=4		
	Frame Type			Frame Type		
	Rate 1	Rate 2	Rate 3	Rate 1	Rate 2	Rate 3
1	9.6	19.2		14.4	28.8	
2	19.2	38.4		28.8	57.6	
4	38.4	76.8		57.6	115.2	
8	76.8	153.6		115.2	230.4	
-			307.2			-

CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ZERO:FORward:FRType[?]				Frame Type
<Frame Type>				
<Frame Type>	Description of parameters	Def. Value	Def. Unit	FW vers.
0	Frame type rate 1 for forward supp. channel 0	0	–	V3.05
1	Frame type rate 2 for forward supp. channel 0	1		
Description of command				Sig. State
This command sets the frame type used for the forward supplemental channel 0 to determine the Multiplex Option and Data Rate.				All

CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ZERO:REVerse:FRTYpe[?]				Frame Type
<Frame Type>				
<Frame Type>	Description of parameters	Def. Value	Def. Unit	FW vers.
0	Frame type rate 1 for forward supp. channel 0	0	–	V3.05
1	Frame type rate 2 for forward supp. channel 0	1		
Description of command				Sig. State
This command sets the frame type used for the reverse supplemental channel 0 to determine the Multiplex Option and Data Rate.				All

CONFigure:SCONfig:SCLass1:PDAT:S32D:SCH:ZERO:FORWard:CODing				Coding, Forward
<Coding>				
<Coding>, settings	Description of parameters	Def. Value	Def. Unit	FW vers.
CONV	Convolutional encoding	CONV	–	V3.40
TURBo	Turbo encoding			
<Coding>, query (additional)	Description of parameters	Def. Value	Def. Unit	FW vers.
CTIP	Convolutional (Turbo if possible)	–	–	V3.40
Description of command				Sig. State
This command selects the coding method of the forward supplemental channel 0. <i>CTIP</i> is not a setting parameter: It indicates that convolutional coding is used because turbo coding is not supported for the selected data rate of 9.6 kbps. Turbo encoding will be used as soon as the data rate is increased beyond 9.6 kbps.				All

CONFigure:SCONfig:SCLass1:PDAT:S32D:SCH:ZERO:REVerse:CODing				Coding, Reverse
<Coding>				
<Coding>, settings	Description of parameters	Def. Value	Def. Unit	FW vers.
CONV	Convolutional encoding	CONV	–	V3.40
TURBo	Turbo encoding			
<Coding>, query (additional)	Description of parameters	Def. Value	Def. Unit	FW vers.
CTIP	Convolutional (Turbo if possible)	–	–	V3.40
Description of command				Sig. State
This command selects the coding method of the reverse supplemental channel 0. <i>CTIP</i> is not a setting parameter: It indicates that convolutional coding is used because turbo coding is not supported for the selected data rate of 9.6 kbps. Turbo encoding will be used as soon as the data rate is increased beyond 9.6 kbps.				All

CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ZERO:FORWard:DRATe?				Data Rate
<Data Rate>				
<Data Rate>	Description of parameters	Def. Value	Def. Unit	FW vers.
9.6 to 153.6	Forward supplemental channel 0 data rate	–	kbps	V3.05
Description of command				Sig. State
This command is always a query. It returns the data rate of the forward supplemental channel 0. The data rate is dependent on the Radio Configuration, MuxPDUs per Physical Layer SDU, and Frame Type.				All

CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ZERO:REVerse:DRATe?				Data Rate
<Data Rate>				
<Data Rate>	Description of parameters	Def. Value	Def. Unit	FW vers.
9.6 to 153.6	Reverse supplemental channel 0 data rate	–	kbps	V3.05
Description of command				Sig. State
This command is always a query. It returns the data rate of the reverse supplemental channel 0. The data rate is dependent on the Radio Configuration, MuxPDUs per Physical Layer SDU, and Frame Type.				All

CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ONE:FORWARD:ENABLE[?]				Forward SCH1 Enable
<SCH1 Enable>				
<SCH1 Enable>	Description of parameters	Def. Value	Def. Unit	FW vers.
ON OFF	Enable or disable forward supplemental channel 1.	OFF	–	V3.20
Description of command				Sig. State
This command disables or enables the forward supplemental channel 1.				All

CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ONE:REVERSE:ENABLE?				Reverse SCH1 Enable
<SCH1 Enable>				
<SCH1 Enable>	Description of parameters	Def. Value	Def. Unit	FW vers.
ON OFF	Reverse supplemental channel 1 enabled or disabled	OFF	–	V3.20
Description of command				Sig. State
This command queries whether the reverse supplemental channel 1 is enabled. The channel is enabled if the forward channel is enabled (CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ONE:FORWARD:ENABLE) and vice versa.				All

CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ONE?				Radio Configuration
Returned value	Description of parameters	Def. value	Def. unit	FW vers.
Forward Radio Configuration,	1 to 5	1	–	V3.20
Forward Multiplex Option,	1 to 5	1	–	
Reverse Radio Configuration,	1 to 5	1	–	
Reverse Multiplex Option	1 to 5	1	–	
Description of command				Sig. State
This command is always a query. It returns the radio configuration and multiplex option of the forward and reverse supplemental traffic channel 1 for service option 32.				All

CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ONE:FORWARD:CHANNEL[?]				SCH1 Channel (Walsh Code)
<FSCH Channel>				
<FSCH Channel>	Description of parameters	Def. value	Def. unit	FW vers.
0 to 127	Forward supplemental channel SCH1 Walsh code	37	–	V3.60
Description of command				Sig. State
This command determines the Walsh code for the forward supplemental traffic channel.				All

CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ONE:FORWard:QOF[?]				SCH1 QOF
<QOF>				
<QOF>	Description of parameters	Def. value	Def. unit	FW vers.
0 to 3	Quasi-orthogonal Function	0	–	V3.60
Description of command				Sig. State
This command sets the Quasi-orthogonal Function that the Supplemental Channel SCH1 uses in the forward CDMA channel.				All

CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ONE:FORWard:PGEN[?]				Pattern Generation
<Pattern Generation>				
<Pattern Generation>	Description of parameters	Def. Value	Def. Unit	FW vers.
RANdOm FIXed DEFault	Random Fixed	RAND	–	V3.20
Description of command				Sig. State
This command sets the pattern generation for service option 32 to either a random or fixed pattern for the forward fundamental channel. If this command is set to FIXed, the pattern sent to the mobile station is defined with the command: CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ONE:FORWard:PATtern[?].				All

CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ONE:REVerse:PGEN[?]				Pattern Generation
<Pattern Generation>				
<Pattern Generation>	Description of parameters	Def. Value	Def. Unit	FW vers.
RANdOm FIXed DEFault	Random Fixed	RAND	–	V3.20
Description of command				Sig. State
This command sets the pattern generation for service option 32 to either a random or fixed pattern for the reverse fundamental channel. If this command is set to FIXed, the pattern sent to the mobile station is defined with the command: CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ONE:FORWard:PATtern[?].				All

CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ONE:FORWard:PATtern[?]				Pattern
<Pattern>				
<Pattern>	Description of parameters	Def. Value	Def. Unit	FW vers.
{Hex value} DEFault	Hex values for pattern generator	A5A5A5A5 A5A5A5A5	–	V3.20
Description of command				Sig. State
This command defines the pattern used by the pattern generator for service option 32. This pattern is used when the Pattern Generation is set to FIXed.				All

CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ONE:REVerse:PATtern[?]				Pattern
<Pattern>				
<Pattern>	Description of parameters	Def. Value	Def. Unit	FW vers.
{Hex value} DEFault	Hex values for pattern generator	A5A5A5A5 A5A5A5A5	–	V3.20
Description of command				Sig. State
This command defines the pattern used by the pattern generator for service option 32. This pattern is used when the Pattern Generation is set to FIXED.				All

CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ONE:FORWard:CBFRames[?]				Circular Buffer Frames
<Circular Buffer Frames>				
<Circular Buffer Frames>	Description of parameters	Def. Value	Def. Unit	FW vers.
1 to 255	Forward circular buffer frames	2	–	V3.20
Description of command				Sig. State
This command sets the number of frames to use in the circular buffer of the forward supplemental channel 1 when the random pattern is selected.				All

CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ONE:REVerse:CBFRames[?]				Circular Buffer Frames
<Circular Buffer Frames>				
<Circular Buffer Frames>	Description of parameters	Def. Value	Def. Unit	FW vers.
1 to 255	Reverse circular buffer frames	2	–	V3.20
Description of command				Sig. State
This command sets the number of frames to use in the circular buffer of the reverse supplemental channel 1 when the random pattern is selected.				All

CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ONE:FORWard:TXON[?]				Transmit On Period
<Transmit On Period>				
<Transmit On Period>	Description of parameters	Def. Value	Def. Unit	FW vers.
0 to 255	Forward transmission on period	1	–	V3.20
Description of command				Sig. State
This command sets the transmission on period in frames of the forward supplemental channel 1 when the frame activity is deterministic.				All

CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ONE:REVerse:TXON[?]				Transmit On Period
<Transmit On Period>				
<Transmit On Period>	Description of parameters	Def. Value	Def. Unit	FW vers.
0 to 255	Reverse transmission on period	1	–	V3.20
Description of command				Sig. State
This command sets the transmission on period in frames of the reverse supplemental channel 1 when the frame activity is deterministic.				All

CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ONE:FORWard:TXOFF[?]				Transmit Off Period
<Transmit Off Period>				
<Transmit Off Period>	Description of parameters	Def. Value	Def. Unit	FW vers.
0 to 255	Forward transmission off period	0	–	V3.20
Description of command				Sig. State
This command sets the transmission off period in frames of the forward supplemental channel 1 when the frame activity is deterministic.				All

CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ONE:REVerse:TXOFF[?]				Transmit Off Period
<Transmit Off Period>				
<Transmit Off Period>	Description of parameters	Def. Value	Def. Unit	FW vers.
0 to 255	Reverse transmission off period	0	–	V3.20
Description of command				Sig. State
This command sets the transmission off period in frames of the reverse supplemental channel 1 when the frame activity is deterministic.				All

CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ONE:FORWard:MPPL[?]				MuxPPL
<MuxPPL>				
<MuxPPL>	Description of parameters	Def. Value	Def. Unit	FW vers.
1, 2, 4, 8	MuxPDUs per physical layer SDU	1	–	V3.20
Description of command				Sig. State
This command sets the MuxPDUs per physical layer SDU which is used to determine Multiplex Option and Data Rate of the forward supplemental channel 1. Refer to Table 6-1 and Table 6-2 on p. 6.159 about the relationship between MuxPPU, Frame Size, and Data Rate.				All

CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ONE:REVerse:MPPL[?]				MuxPPL
<MuxPPL>				
<MuxPPL>	Description of parameters	Def. Value	Def. Unit	FW vers.
1, 2, 4, 8	MuxPDUs per physical layer SDU	1	–	V3.20
Description of command				Sig. State
This command sets the MuxPDUs per physical layer SDU which is used to determine Multiplex Option and Data Rate of the reverse supplemental channel 1. Refer to Table 6-1 and Table 6-2 on p. 6.159 about the relationship between MuxPPU, Frame Size, and Data Rate.				All

CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ONE:FORWard:FRType[?]				Frame Type
<Frame Type>				
<Frame Type>	Description of parameters	Def. Value	Def. Unit	FW vers.
0	Frame type rate 1 for forward supp. channel 1	0	–	V3.20
1	Frame type rate 2 for forward supp. channel 1	1		
Description of command				Sig. State
This command sets the frame type used for the forward supplemental channel 1 to determine the Multiplex Option and Data Rate.				All

CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ONE:REVerse:FRType[?]				Frame Type
<Frame Type>				
<Frame Type>	Description of parameters	Def. Value	Def. Unit	FW vers.
0	Frame type rate 1 for forward supp. channel 1	0	–	V3.20
1	Frame type rate 2 for forward supp. channel 1	1		
Description of command				Sig. State
This command sets the frame type used for the reverse supplemental channel 1 to determine the Multiplex Option and Data Rate.				All

CONFigure:SCONfig:SCLass1:PDAT:S32D:SCH:ONE:FORWARD:CODing				Coding, Forward
<Coding>				
<Coding>, settings	Description of parameters	Def. Value	Def. Unit	FW vers.
CONV	Convolutional encoding	CONV	–	V3.40
TURBo	Turbo encoding			
<Coding>, query (additional)	Description of parameters	Def. Value	Def. Unit	FW vers.
CTIP	Convolutional (Turbo if possible)	–	–	V3.40
Description of command				Sig. State
This command selects the coding method of the forward supplemental channel 1. <i>CTIP</i> is not a setting parameter: It indicates that convolutional coding is used because turbo coding is not supported for the selected data rate of 9.6 kbps. Turbo encoding will be used as soon as the data rate is increased beyond 9.6 kbps.				All

CONFigure:SCONfig:SCLass1:PDAT:S32D:SCH:ONE:REVerse:CODing				Coding, Reverse
<Coding>				
<Coding>, settings	Description of parameters	Def. Value	Def. Unit	FW vers.
CONV	Convolutional encoding	CONV	–	V3.40
TURBo	Turbo encoding			
<Coding>, query (additional)	Description of parameters	Def. Value	Def. Unit	FW vers.
CTIP	Convolutional (Turbo if possible)	–	–	V3.40
Description of command				Sig. State
This command selects the coding method of the reverse supplemental channel 1. <i>CTIP</i> is not a setting parameter: It indicates that convolutional coding is used because turbo coding is not supported for the selected data rate of 9.6 kbps. Turbo encoding will be used as soon as the data rate is increased beyond 9.6 kbps.				All

CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ONE:FORWARD:DRATE?				Data Rate
<Data Rate>				
<Data Rate>	Description of parameters	Def. Value	Def. Unit	FW vers.
9.6 to 153.6	Forward supplemental channel 1 data rate	–	kbps	V3.20
Description of command				Sig. State
This command is always a query. It returns the data rate of the forward supplemental channel 1. The data rate is dependent on the Radio Configuration, MuxPDUs per Physical Layer SDU, and Frame Type.				All

CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ONE:REVerse:DRATe?				Data Rate
<Data Rate>				
<Data Rate>	Description of parameters	Def. Value	Def. Unit	FW vers.
9.6 to 153.6	Reverse supplemental channel 1 data rate	–	kbps	V3.20
Description of command				Sig. State
This command is always a query. It returns the data rate of the reverse supplemental channel 1. The data rate is dependent on the Radio Configuration, MuxPDUs per Physical Layer SDU, and Frame Type.				All

Subsystem SCONfig:SClass:PDAT

The subsystem SCONfig:SClass:PDAT configures service option SO33 the service options for the Packet Data service type.

CONFigure:SCONfig:SClass1:PDAT:SOPTion[?]				Packet Data Service
PROCEDURE:SCONfig:SClass1:PDAT:SOPTion[?]				
<Test Data Service Current Sel>				
<Test Data Service Current Sel>	Description of parameters	Def. value	Def. unit	FW vers.
S33D	Service Option 33	S33D	–	V3.20
Description of command				Sig. State
This command determines the service option to use when establishing a call in the test data mode, particularly for the high data rates using the supplemental channels (SCH).				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCEDURE form of the command is used in the CEST signalling state.				

CONFigure:SCONfig:SClass1:PDAT:S33D:FSCCommon:RC[?]				Radio Configuration
PROCEDURE:SCONfig:SClass1:PDAT:S33D:FSCCommon:RC[?]				
<F_RC>, <R_RC>				
<F_RC>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 5 MINimum MAXimum DEFAULT,	Forward radio configuration Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	1	–	
<R_RC>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 5 MINimum MAXimum DEFAULT	Reverse radio configuration Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	1	–	V3.20
Description of command				Sig. State
This command sets a common radio configuration of the fundamental and supplemental forward and reverse traffic channel for service option 33.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCEDURE form of the command is used in the CEST signalling state.				

CONFigure:SCONfig:SClass1:PDAT:S33D:FCH?				Radio Configuration	
Returned value	Description of parameters	Def. value	Def. unit	FW vers.	
Forward Radio Configuration,	1 to 5	1	–	V3.20	
Forward Multiplex Option,	1 to 5	1	–		
Reverse Radio Configuration,	1 to 5	1	–		
Reverse Multiplex Option	1 to 5	1	–		
Description of command				Sig. State	
This command is always a query. It returns the radio configuration and multiplex option of the forward and reverse fundamental traffic channel for service option 33.				All	

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ZERO:FORWARD:ENABLE[?]				Forward SCH0 Enable	
<SCH0 Enable>					
<SCH0 Enable>	Description of parameters	Def. Value	Def. Unit	FW vers.	
ON OFF	Enable or disable forward supplemental channel 0.	OFF	–	V3.20	
Description of command				Sig. State	
This command disables or enables the forward supplemental channel 0.				All	

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ZERO:REVERSE:ENABLE?				Reverse SCH0 Enable	
<SCH0 Enable>					
<SCH0 Enable>	Description of parameters	Def. Value	Def. Unit	FW vers.	
ON OFF	Reverse supplemental channel 0 enabled or disabled	OFF	–	V3.20	
Description of command				Sig. State	
This command queries whether the reverse supplemental channel 0 is enabled. The channel is enabled if the forward channel is enabled (CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ZERO:FORWARD:ENABLE) and vice versa.				All	

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ZERO?				Radio Configuration	
Returned value	Description of parameters	Def. value	Def. unit	FW vers.	
Forward Radio Configuration,	1 to 5	1	–	V3.20	
Forward Multiplex Option,	1 to 5	1	–		
Reverse Radio Configuration,	1 to 5	1	–		
Reverse Multiplex Option	1 to 5	1	–		
Description of command				Sig. State	
This command is always a query. It returns the radio configuration and multiplex option of the forward and reverse supplemental traffic channel 0 for service option 33.				All	

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ZERO:FORWARD:CHANNEL[?]				SCH0 Channel (Walsh Code)	
<FSCH Channel>					
<FSCH Channel>	Description of parameters	Def. value	Def. unit	FW vers.	
0 to 127	Forward supplemental channel SCH0 Walsh code	35	–	V3.60	
Description of command				Sig. State	
This command determines the Walsh code for the forward supplemental traffic channel.				All	

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ZERO:FORWard:QOF[?]				SCH0 QOF
<QOF>				
<QOF>	Description of parameters	Def. value	Def. unit	FW vers.
0 to 3	Quasi-orthogonal Function	0	–	V3.60
Description of command				Sig. State
This command sets the Quasi-orthogonal Function that the Supplemental Channel SCH0 uses in the forward CDMA channel.				All

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ZERO:FORWard:MPPL[?]				MuxPPL
<MuxPPL>				
<MuxPPL>	Description of parameters	Def. Value	Def. Unit	FW vers.
1 2 4 8	MuxPDUs per physical layer SDU	1	–	V3.20
Description of command				Sig. State
This command sets the MuxPDUs per physical layer SDU which is used to determine Multiplex Option and Data Rate of the forward supplemental channel 0. Refer to Table 6-1 and Table 6-2 on p. 6.159 about the relationship between MuxPPU, Frame Size, and Data Rate.				All

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ZERO:REVERSE:MPPL[?]				MuxPPL
<MuxPPL>				
<MuxPPL>	Description of parameters	Def. Value	Def. Unit	FW vers.
1 2 4 8	MuxPDUs per physical layer SDU	1	–	V3.20
Description of command				Sig. State
This command sets the MuxPDUs per physical layer SDU which is used to determine Multiplex Option and Data Rate of the reverse supplemental channel 0. Refer to Table 6-1 and Table 6-2 on p. 6.159 about the relationship between MuxPPU, Frame Size, and Data Rate.				All

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ZERO:FORWard:FRType[?]				Frame Type
<Frame Type>				
<Frame Type>	Description of parameters	Def. Value	Def. Unit	FW vers.
0 1	Frame type rate 1 for forward supp. channel 0 Frame type rate 2 for forward supp. channel 0	0 1	–	V3.20
Description of command				Sig. State
This command sets the frame type used for the forward supplemental channel 0 to determine the Multiplex Option and Data Rate.				All

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ZERO:REVERSE:FRType[?]				Frame Type
<Frame Type>				
<Frame Type>	Description of parameters	Def. Value	Def. Unit	FW vers.
0 1	Frame type rate 1 for forward supp. channel 0 Frame type rate 2 for forward supp. channel 0	0 1	–	V3.20
Description of command				Sig. State
This command sets the frame type used for the reverse supplemental channel 0 to determine the Multiplex Option and Data Rate.				All

CONFigure:SCONfig:SCLass1:PDAT:S33D:SCH:ZERO:FORward:CODing				Coding, Forward
<Coding>				
<Coding>, settings	Description of parameters	Def. Value	Def. Unit	FW vers.
CONV TURBo	Convolutional encoding Turbo encoding	CONV	–	V3.40
<Coding>, query (additional)	Description of parameters	Def. Value	Def. Unit	FW vers.
CTIP	Convolutional (Turbo if possible)	–	–	V3.40
Description of command				Sig. State
This command selects the coding method of the forward supplemental channel 0. <i>CTIP</i> is not a setting parameter: It indicates that convolutional coding is used because turbo coding is not supported for the selected data rate of 9.6 kbps. Turbo encoding will be used as soon as the data rate is increased beyond 9.6 kbps.				All

CONFigure:SCONfig:SCLass1:PDAT:S33D:SCH:ZERO:REVErse:CODing				Coding, Reverse
<Coding>				
<Coding>, settings	Description of parameters	Def. Value	Def. Unit	FW vers.
CONV TURBo	Convolutional encoding Turbo encoding	CONV	–	V3.40
<Coding>, query (additional)	Description of parameters	Def. Value	Def. Unit	FW vers.
CTIP	Convolutional (Turbo if possible)	–	–	V3.40
Description of command				Sig. State
This command selects the coding method of the reverse supplemental channel 0. <i>CTIP</i> is not a setting parameter: It indicates that convolutional coding is used because turbo coding is not supported for the selected data rate of 9.6 kbps. Turbo encoding will be used as soon as the data rate is increased beyond 9.6 kbps.				All

CONFigure:SCONfig:SCLass1:PDAT:S33D:SCH:ZERO:FORward:DRATe?				Data Rate
<Data Rate>				
<Data Rate>	Description of parameters	Def. Value	Def. Unit	FW vers.
9.6 to 153.6	Forward supplemental channel 0 data rate	–	kbps	V3.20
Description of command				Sig. State
This command is always a query. It returns the data rate of the forward supplemental channel 0. The data rate is dependent on the Radio Configuration, MuxPDUs per Physical Layer SDU, and Frame Type.				All

CONFigure:SCONfig:SCLass1:PDAT:S33D:SCH:ZERO:REVErse:DRATe?				Data Rate
<Data Rate>				
<Data Rate>	Description of parameters	Def. Value	Def. Unit	FW vers.
9.6 to 153.6	Reverse supplemental channel 0 data rate	–	kbps	V3.20
Description of command				Sig. State
This command is always a query. It returns the data rate of the reverse supplemental channel 0. The data rate is dependent on the Radio Configuration, MuxPDUs per Physical Layer SDU, and Frame Type.				All

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ONE:FORward:ENABLE[?]				Forward SCH1 Enable	
<SCH1 Enable>					
<SCH1 Enable>	Description of parameters	Def. Value	Def. Unit	FW vers.	
ON OFF	Enable or disable forward supplemental channel 1.	OFF	–	V3.20	
Description of command					Sig. State
This command disables or enables the forward supplemental channel 1.					All

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ONE:REVerse:ENABLE?				Reverse SCH1 Enable	
<SCH1 Enable>					
<SCH1 Enable>	Description of parameters	Def. Value	Def. Unit	FW vers.	
ON OFF	Reverse supplemental channel 1 enabled or disabled	OFF	–	V3.20	
Description of command					Sig. State
This command queries whether the reverse supplemental channel 1 is enabled. The channel is enabled if the forward channel is enabled (CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ONE:FORward:ENABLE) and vice versa.					All

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ONE?				Radio Configuration	
Returned value	Description of parameters	Def. value	Def. unit	FW vers.	
Forward Radio Configuration,	1 to 5	1	–	V3.20	
Forward Multiplex Option,	1 to 5	1	–		
Reverse Radio Configuration,	1 to 5	1	–		
Reverse Multiplex Option	1 to 5	1	–		
Description of command					Sig. State
This command is always a query. It returns the radio configuration and multiplex option of the forward and reverse supplemental traffic channel 1 for service option 33.					All

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ONE:FORward:CHANnel[?]				SCH1 Channel (Walsh Code)	
<FSCH Channel>					
<FSCH Channel>	Description of parameters	Def. value	Def. unit	FW vers.	
0 to 127	Forward supplemental channel SCH1 Walsh code	37	–	V3.60	
Description of command					Sig. State
This command determines the Walsh code for the forward supplemental traffic channel.					All

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ONE:FORward:QOF[?]				SCH1 QOF	
<QOF>					
<QOF>	Description of parameters	Def. value	Def. unit	FW vers.	
0 to 3	Quasi-orthogonal Function	0	–	V3.60	
Description of command					Sig. State
This command sets the Quasi-orthogonal Function that the Supplemental Channel SCH1 uses in the forward CDMA channel.					All

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ONE:FORWard:MPPL[?]				MuxPPL
<MuxPPL>				
<MuxPPL>	Description of parameters	Def. Value	Def. Unit	FW vers.
1 2 4 8	MuxPDUs per physical layer SDU	1	–	V3.20
Description of command				Sig. State
This command sets the MuxPDUs per physical layer SDU which is used to determine Multiplex Option and Data Rate of the forward supplemental channel 1. Refer to Table 6-1 and Table 6-2 on p. 6.159 about the relationship between MuxPPU, Frame Size, and Data Rate.				All

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ONE:REVerse:MPPL[?]				MuxPPL
<MuxPPL>				
<MuxPPL>	Description of parameters	Def. Value	Def. Unit	FW vers.
1 2 4 8	MuxPDUs per physical layer SDU	1	–	V3.20
Description of command				Sig. State
This command sets the MuxPDUs per physical layer SDU which is used to determine Multiplex Option and Data Rate of the reverse supplemental channel 1. Refer to Table 6-1 and Table 6-2 on p. 6.159 about the relationship between MuxPPU, Frame Size, and Data Rate.				All

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ONE:FORWard:FRType[?]				Frame Type
<Frame Type>				
<Frame Type>	Description of parameters	Def. Value	Def. Unit	FW vers.
0 1	Frame type rate 1 for forward supp. channel 1 Frame type rate 2 for forward supp. channel 1	0 1	–	V3.20
Description of command				Sig. State
This command sets the frame type used for the forward supplemental channel 1 to determine the Multiplex Option and Data Rate.				All

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ONE:REVerse:FRType[?]				Frame Type
<Frame Type>				
<Frame Type>	Description of parameters	Def. Value	Def. Unit	FW vers.
0 1	Frame type rate 1 for forward supp. channel 1 Frame type rate 2 for forward supp. channel 1	0 1	–	V3.20
Description of command				Sig. State
This command sets the frame type used for the reverse supplemental channel 1 to determine the Multiplex Option and Data Rate.				All

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ONE:FORWard:CODing				Coding, Forward
<Coding>				
<Coding>, settings	Description of parameters	Def. Value	Def. Unit	FW vers.
CONV TURBo	Convolutional encoding Turbo encoding	CONV	–	V3.40
<Coding>, query (additional)	Description of parameters	Def. Value	Def. Unit	FW vers.
CTIP	Convolutional (Turbo if possible)	–	–	V3.40
Description of command				Sig. State
This command selects the coding method of the forward supplemental channel 1. <i>CTIP</i> is not a setting parameter: It indicates that convolutional coding is used because turbo coding is not supported for the selected data rate of 9.6 kbps. Turbo encoding will be used as soon as the data rate is increased beyond 9.6 kbps.				All

CONFigure:SCONfig:SCLass1:PDAT:S33D:Sch:ONE:REVerse:CODing				Coding, Reverse
<Coding>				
<Coding>, settings	Description of parameters	Def. Value	Def. Unit	FW vers.
CONV TURBo	Convolutional encoding Turbo encoding	CONV	–	V3.40
<Coding>, query (additional)	Description of parameters	Def. Value	Def. Unit	FW vers.
CTIP	Convolutional (Turbo if possible)	–	–	V3.40
Description of command				Sig. State
This command selects the coding method of the reverse supplemental channel 1. <i>CTIP</i> is not a setting parameter: It indicates that convolutional coding is used because turbo coding is not supported for the selected data rate of 9.6 kbps. Turbo encoding will be used as soon as the data rate is increased beyond 9.6 kbps.				All

CONFigure:SCONfig:SCLass1:PDAT:S33D:Sch:ONE:FORWard:DRATe?				Data Rate
<Data Rate>				
<Data Rate>	Description of parameters	Def. Value	Def. Unit	FW vers.
9.6 to 153.6	Forward supplemental channel 1 data rate	–	kbps	V3.20
Description of command				Sig. State
This command is always a query. It returns the data rate of the forward supplemental channel 1. The data rate is dependent on the Radio Configuration, MuxPDUs per Physical Layer SDU, and Frame Type.				All

CONFigure:SCONfig:SCLass1:PDAT:S33D:Sch:ONE:REVerse:DRATe?				Data Rate
<Data Rate>				
<Data Rate>	Description of parameters	Def. Value	Def. Unit	FW vers.
9.6 to 153.6	Reverse supplemental channel 1 data rate	–	kbps	V3.20
Description of command				Sig. State
This command is always a query. It returns the data rate of the reverse supplemental channel 1. The data rate is dependent on the Radio Configuration, MuxPDUs per Physical Layer SDU, and Frame Type.				All

CONFigure:SCONfig:SCLass1:PDAT:S33D:REVerse[:STATic]:IPAdDress				PPP IP Addresses, Static
CONFigure:SCONfig:SCLass1:PDAT:S33D:FORWard[:STATic]:IPAdDress				
<Addr_1>, <Addr_2>, <Addr_3>, <Addr_4>				
Address parts	Ranges of values	Def. value	Def. unit	FW vers.
<Addr_1>,	0 to 255	192	–	V3.20
<Addr_2>,	0 to 255	168	–	
<Addr_3>,	0 to 255	1	–	
<Addr_4>	0 to 255	1 (for reverse address) 2 (for forward address)	–	
Description of command				Sig. State
These commands define the static PPP IP addresses of the MS (:REVerse) and the BS/CMU (:FORWard). The addresses are used if the CMU is configured for static IP addressing (CONFigure:IPAdDress:MODE STATic)				All

CONFigure:SCONfig:SClass1:PDAT:S33D:REVerse:DYNamic:IPADdress? PPP IP Addresses, Dynamic				
CONFigure:SCONfig:SClass1:PDAT:S33D:FORWard:DYNamic:IPADdress? <Addr_1>, <Addr_2>, <Addr_3>, <Addr_4>				
Address parts	Ranges of values	Def. value	Def. unit	FW vers.
<Addr_1>,	0 to 255	NAN	–	V3.60
<Addr_2>,	0 to 255	NAN	–	
<Addr_3>,	0 to 255	NAN	–	
<Addr_4>	0 to 255	NAN	–	
Description of command				Sig. State
These commands query the dynamically allocated PPP IP addresses of the MS (:REVerse) and the BS/CMU (:FORWard). The addresses are available if the CMU is configured for dynamic IP addressing using DHCP (CONFigure:IPADdress:MODE DYNamic)				All

The commands for CDMA data testing (with option R&S CMU-K87) are listed in Chapter 8.

Subsystem SCONfig:SClass:WMT

The subsystem SCONfig:SClass:WMT:SMS defines the parameters for the Wireless Messaging Teleservice. It corresponds to the *Messaging Teleservice (WMT)* section in the *Service Cfg.* tab of the *Connection Control* menu.

CONFigure:SCONfig:SClass1:WMT:SOPtion Selected Service Option				
<WMT_Current>				
<WMT_Current>	Description of parameters	Def. value	Def. unit	FW vers.
S06D S14D CCON	Service Option 6 / 14 (SMS) for SMS from SON or REG SMS @ Current Connection for SMS from CONN (query only)	S06D	–	V3.50
Description of command				Sig. State
This command selects the service option for the Messaging Teleservice. If used as a query in the CONN state, the command returns that it is possible to send an SMS @ Current Connection irrespective of the 1 st service selection.				All

CONFigure:SCONfig:SClass1:WMT:SMS:ACKnowledge:ENABLE[?] Acknowledge				
<Enable>				
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	Enable or disable acknowledgement of short messages	ON	–	V3.10
Description of command				Sig. State
This command qualifies whether the mobile shall acknowledge the received short message.				All

CONFigure:SCONfig:SClass1:WMT:SMS:TSTamp:ENABLE[?] Add Time Stamp				
<Enable>				
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	Add or omit time stamp	ON	–	V3.10
Description of command				Sig. State
This command qualifies whether a time stamp is added when the short message is sent to the MS.				All

CONFigure:SCONfig:SClass1:WMT:SMS:LENGTH[?] <Char>			Max. Outgoing SMS Length	
<Char>	Description of parameters	Def. value	Def. unit	FW vers.
18 to 152	Max. no. of characters	152	–	V3.60
Description of command				Sig. State
This command restricts the maximum length of the SMS message to be sent (including the optional time stamp which is of the form [CMU200 00:00:00]) and truncates the <i>Outgoing SMS</i> (CONFigure:SCONfig:SClass1:WMT:SMS:TEXT) to the selected number of characters.				All

CONFigure:SCONfig:SClass1:WMT:SMS:TEXT[?]			Outgoing SMS	
Returns	Description of parameters	Def. value	Def. unit	FW vers.
"<max. 142 7-bit ASCII characters>"	SMS text	"CMU200 Short Message Service, The quick brown fox jumps over the lazy dog."	–	V3.10
Description of command				Sig. State
This command defines the text of the short message to be sent to the MS. The number of characters is limited to 142 because 18 characters are reserved for the optional time stamp.				All

CONFigure:SCONfig:SClass1:WMT:SMS:S06D:FCH?			SO 6, FCH Config.	
Returns	Description of parameters	Def. value	Def. unit	FW vers.
1 3 4, 1, 1 3, 1	F_FCH_RC, forward Radio Configuration F_FCH_MO, forward Multiplex Option R_FCH_RC, reverse Radio Configuration R_FCH_MO, reverse Multiplex Option	1 1 1 1	– – – –	V3.10
Description of command				Sig. State
This command is always a query. It returns the current FCH configuration for Service Option 6 including the forward and reverse Radio Configuration and the forward and reverse Multiplex option.				All

CONFigure:SCONfig:SClass1:WMT:SMS:S14D:FCH?			SO 14, FCH Config.	
Returns	Description of parameters	Def. value	Def. unit	FW vers.
2 5, 1, 2 4, 1	F_FCH_RC, Forward Radio Configuration F_FCH_MO, Forward Multiplex Option R_FCH_RC, Reverse Radio Configuration R_FCH_MO, Reverse Multiplex Option	1 1 1 1	– – – –	V3.50
Description of command				Sig. State
This command is always a query. It returns the current FCH configuration for Service Option 14 including the forward and reverse Radio Configuration and the forward and reverse Multiplex option.				All

CONFigure:SCONfig:SClass1:WMT:SMS:S06D:FCH:RC <F_RC>, <R_RC>			SO 6, Radio Configuration	
<F_RC>	Description of parameters	Def. value	Def. unit	FW vers.
1 3 4,	F_FCH_RC, Forward Radio Configuration	1	–	
<R_RC>	Description of parameters	Def. value	Def. unit	FW vers.
1 3	R_FCH_RC, Reverse Radio Configuration	1	–	V3.50
Description of command				Sig. State
This command sets a common radio configuration of the fundamental forward and reverse traffic channel for service option 6.				All

CONFigure:SCONfig:SClass1:WMT:SMS:S14D:FCH:RC				SO 14, Radio Configuration	
<F_RC>, <R_RC>					
<F_RC>	Description of parameters	Def. value	Def. unit		
2 5,	F_FCH_RC, Forward Radio Configuration	2	–		
<R_RC>	Description of parameters	Def. value	Def. unit	FW vers.	
2 4	R_FCH_RC, Reverse Radio Configuration	2	–	V3.50	
Description of command				Sig. State	
This command sets a common radio configuration of the fundamental forward and reverse traffic channel for service option 14.				All	

Subsystem BSSignal... (Signal of Base Station/CMU)

The subsystem *BSSignal* configures the RF, traffic channels, and levels of the signals transmitted by the CMU to the mobile station. It corresponds to the tab *BS Signal* in the popup menu *Connection Control*.

DEFault:BSSignal[?]				Default Settings	
<Enable>					
Enable	Description of parameters	Def. value	Def. unit	FW vers.	
ON OFF	The parameters are set to their default values The parameters differ from their default values (partially or totally)	ON	–	V3.05	
Description of command				Sig. State	
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystem BS Signal to their default values (the setting <i>OFF</i> results in an error message).				SON SOFF REG Q: all	
If used as a query, the command returns whether all parameters are set to their default values (<i>ON</i>) or not (<i>OFF</i>).					

UNIT:BSSignal:CHANnel[:RF][?]				RF Channel	
<RF Channel Unit>					
<RF Channel Unit>	Description of parameters	Def. value	Def. unit	FW vers.	
CH HZ MHZ KHZ GHZ	Frequency unit or Channel Number	CH	CH	V3.05	
Description of command				Sig. State	
This command defines whether the frequency of the RF signal generated is specified in frequency units or as an CDMA channel number. Frequency units must be used to select input signals that are outside the designated CDMA channel range.				SON SOFF REG Q: all	

CONFigure:BSSignal:CHANnel[:RF][?]				RF Channel
PROCedure:BSSignal:CHANnel[:RF][?]				
<RF Channel/Freq>				
<RF Channel/Freq>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 300 539 to 871 1039 to 1473 1792 to 2016	RF channels, Band Class 5, NTM-450	25		V3.05
1 to 799 991 to 1023	RF channels, Band Class 0, US and Korean Cellular	283	–	
0 to 1000 1329 to 2047	RF channels, Band Class 2, TACS	79		
1 to 799 801 to 1039 1041 to 1199 1201 to 1600	RF channels, Band Class 3, JTACS	76	–	
0 to 359	RF channels, Band Class 7, North American 700 MHz	14		
0 to 699	RF channels, Band Class 9, 900 MHz	18		
0 to 919	RF channels, Band Class 10, Secondary 800 MHz	50		
0 to 1199	RF channels, Band Class 1, North American PCS	150	–	
0 to 599	RF channels, Band Class 4, Korean PCS	45	–	
0 to 1499	RF channels, Band Class 8, 1800 MHz PCS	16		
0 to 1199	RF channels, Band Class 6, IMT-2000	12		
Description of command				Sig. State
This command determines the RF channel number. The frequency changes according to the selected channel number.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.				

CONFigure:BSSignal:POWER:CDMA[?]				CDMA Power
PROCedure:BSSignal:POWER:CDMA[?]				
<CDMA Power>				
<CDMA Power>	Description of parameters	Def. value	Def. unit	FW vers.
–120.0 dBm to –33.0 dBm –120.0 dBm to –16.0 dBm –100.0 dBm to 7.0 dBm MINimum MAXimum DEFault	RF1 OUT , 0 dB ext. atten RF2 OUT , 0 dB ext. atten RF3 OUT , 0 dB ext. atten Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	–70.0	dBm	V3.05
Description of command				Sig. State
This command determines total CDMA output power (absolute value, in dBm). CDMA Power value range depends on the RF input used and the external attenuation set.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state. If option R&S CMU-U99 (<i>RF 1 with RF 2 Level Range</i>) is fitted, RF 1 takes on the level range of RF2.				

CONFigure:BSSignal:POWer:OUTPut?				Output Power
Returned Value	Description of parameters	Def. value	Def. unit	FW vers.
Output Power	-120.0 dBm to -33.0 dBm	NAN	dBm	V3.05
Description of command				Sig. State
This command is always a query. It returns the total output power of the CMU, i.e. the CDMA power plus the AWGN level.				SOFF SON REG Q: all

CONFigure:BSSignal:LEVel:FSYnc[?] <FSYNC Level>				RF Level
<FSYNC Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to -1.0 dB DEFault MINimum MAXimum ON OFF	Forward Sync Channel Level Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum Forward Sync Channel on Forward Sync Channel off	-16.0	dB	V3.05
Description of command				Sig. State
This command determines the signal level of the sync channel in the forward CDMA channel. The power is in units relative to the total CDMA power.				SOFF SON REG Q: all

CONFigure:BSSignal:LEVel:FPICH[?] <FPICH Level>				RF Level
<FPICH Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to -1.0 dB DEFault MINimum MAXimum ON OFF	Forward pilot channel level Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum Forward pilot channel on Forward pilot channel off	-7.0	dB	V3.05
Description of command				Sig. State
This command determines the signal level of the pilot channel in the forward CDMA channel.				SOFF SON REG Q: all

CONFigure:BSSignal:LEVel:OCNS:ENABLE[?] <Mode>				OCNS Settings
<Mode> (for setting command)	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	OCNS generator on or off	ON	-	V3.05
Description of command				Sig. State
This command switches the Orthogonal Channel Noise Simulator on or off. When set to ON, the OCNS level is such that the sum of all generator levels and the OCNS level equals the nominal base station power.				SOFF SON REG Q: all

CONFigure:BSSignal:LEVEL:OCNS:VALue?		OCNS Settings		
Returned Value	Description of parameters	Def. value	Def. unit	FW vers.
OCNS Level	OCNS level relative to CDMA power	–	dB	V3.05
Description of command				Sig. State
This command is always a query. It returns the level of the Orthogonal Channel Noise Simulator in units relative to the CDMA power (see CONFigure:BSSignal:LEVEL command).				SOFF SON REG Q: all

CONFigure:BSSignal:PCBits[?] <Power Control Bits>		Power Control Bits		
<Power Control Bits>	Description of parameters	Def. value	Def. unit	FW vers.
OFF AUTomatic HOLD ADOW AUP RTES PATTern	Disable power control bits Auto mode, closed-loop operation Alternating up/down control bits All power control bits down All power control bits up Range test mode Pattern defined by means of the CONF:BSS:PCB:PATTern... commands	AUT	–	V3.05
Description of command				Sig. State
This command defines the power control bits in the BS signal.				SOFF SON REG Q: all

CONFigure:BSSignal:PCBits:PATTern:SQMode[?] <Seq_Mode>		Pattern Sequence Mode		
<Seq_Mode>	Description of parameters	Def. value	Def. unit	FW vers.
PREP PFBA PFBH	Pattern repeated Pattern Followed by Auto Pattern Followed by Hold	PREP	–	V3.20
Description of command				Sig. State
This command selects the algorithm to construct the complete user-defined pattern from the single bit pattern defined by means of the CONFigure:BSSignal:PCBits:PATTern:AREA<nr>... commands.				SOFF SON REG Q: all

CONFigure:BSSignal:PCBits:SSIZE[?] <Step>		Step Size		
<Step>	Description of parameters	Def. value	Def. unit	FW vers.
0.25 dB 0.5 dB 1.0 dB 0.5 dB 1.0 dB 1.0 dB	Power step size (protocol revision 6) Power step size (protocol revisions 4 and 5) Power step size (protocol revisions 1 to 3)	1.0	dB	V3.40
Description of command				Sig. State
This command selects the step size that the mobile station is to use for closed loop power control.				SOFF SON REG Q: all
Note: The range depends on the protocol revision of the mobile as described above. Changing the protocol revision (CONFigure:NETWork: SYSTem:PREVision) resets the step size to its default value of 1.00 dB.				

CONFigure:BSSignal:PCBits:PATtern:AREA<no>:NOBits[?]				Number of Bits
<Number_of_Bits>				
<Number_of_Bits>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 64	Number of bits for area no. 1	32	–	V3.20
1 to 128	Number of bits for area no. 2, 3, 4	100		
Description of command				Sig. State
This command defines the number of bits in each of the 4 areas of the user-defined single pattern.				SOFF SON REG Q: all

CONFigure:BSSignal:PCBits:PATtern:AREA1:LHBit[?]				Last Hold Bit
<Polarity>				
<Polarity>	Description of parameters	Def. value	Def. unit	FW vers.
UP DOWN	Last Hold Bit	DOWN	–	V3.20
Description of command				Sig. State
This command defines the bit polarity in area no. 1 of the user-defined single pattern.				SOFF SON REG Q: all

CONFigure:BSSignal:PCBits:PATtern:AREA<no>:POLarity[?]				Polarity
<Polarity>				
<Polarity>	Description of parameters	Def. value	Def. unit	FW vers.
UP DOWN	Polarity	UP (area no. 2, 4) DOWN (area no. 3)	–	V3.20
Description of command				Sig. State
This command defines the bit polarity in areas 2 to 4 of the user-defined single pattern (1 is not a valid suffix).				SOFF SON REG Q: all

CONFigure:BSSignal:CHANnel:FFCH[?]				Traffic Channel
PROCedure:BSSignal:CHANnel:FFCH[?]				
<FFCH Channel>				
<FFCH Channel>	Description of parameters	Def. value	Def. unit	FW vers.
0 to 63	Forward fundamental traffic channel	8	–	V3.05
Description of command				Sig. State
This command determines the forward fundamental traffic channel number. The command is valid in the Call Established state.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.				

CONFigure:BSSignal:LEVel:FFCH[?] PROCedure:BSSignal:LEVel:FFCH[?] <FFCH Level>				RF Level
<FFCH Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to -1.0 dB DEFault MINimum MAXimum ON OFF	Forward fundamental traffic channel level Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum Forward fundamental traffic channel level on Forward fundamental traffic channel level off	-14.0	dB	V3.05
Description of command				Sig. State
This command determines the signal level of the fundamental traffic channel in the forward CDMA channel.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.				

CONFigure:BSSignal:FROffset:FFCH[?] PROCedure:BSSignal:FROffset:FFCH[?] <Frame Offs>				Frame Offset
<Frame Offs>	Description of parameters	Def. value	Def. unit	FW vers.
0 to +15	Frame offset	0	-	V3.05
Description of command				Sig. State
This command determines an offset for the traffic channel timing in CDMA frames.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.				

CONFigure:BSSignal:QOF:FFCH[?] PROCedure:BSSignal:QOF:FFCH[?] <QOF>				QOF
<QOF>	Description of parameters	Def. value	Def. unit	FW vers.
0 to 3	Quasi-orthogonal Function	0	-	V3.05
Description of command				Sig. State
This command sets the Quasi-orthogonal Function that the Fundamental Channel uses in the forward CDMA channel.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.				

CALCulate[:SCALar]:BSSignal:EBNT:FFCH? <Eb/Nt>				F-FCH Eb/Nt
<Eb/Nt>	Description of parameters	Def. value	Def. unit	FW vers.
-30.969 dB to 18.072 dB	Calculated F-FCH Eb/Nt	-	dB	V3.10
Description of command				Sig. State
This command is always a query. It returns the calculated signal to noise ratio for the forward FCH. This quantity is undefined unless the AWGN generator is turned on (CONFigure:IMPairments:LEVel:AWGN). The quoted range of values is valid for data rates between 9.6 kbps and 153.6 kbps; see <i>Eb/Nt Calculation</i> in Chapter 4.				All

CONFigure:BSSignal:LEVel:FSCH:ZERO[?]				SCH0 Level
PROCedure:BSSignal:LEVel:FSCH:ZERO[?]				
<FSCH0 Level>				
<FSCH0 Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to -1.0 dB DEFault MINimum MAXimum ON OFF	Forward supplemental traffic channel level Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum Forward supplemental traffic channel level on Forward supplemental traffic channel level off	-7	dB	V3.05
Description of command				Sig. State
This command determines the signal level of the supplemental traffic channel SCH0 in the forward CDMA channel.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.				

CONFigure:BSSignal:CHANnel:FSCH:ZERO[?]				SCH0 Channel (Walsh Code)
PROCedure:BSSignal:CHANnel:FSCH:ZERO[?]				
<FSCH Channel>				
<FSCH Channel>	Description of parameters	Def. value	Def. unit	FW vers.
0 to 127	Forward supplemental channel SCH0 Walsh code	35	-	V3.05
Description of command				Sig. State
This command determines the Walsh code for the forward supplemental traffic channel. The command is valid in the Call Established state. The Walsh codes of the forward SCH0 for SO 32 and SO 33 can be changed independently using CONFigure:SCONfig:SCLass1:PDAT:S<nr>D:SCH:ZERO:FORward:CHANnel. CONFigure:BSSignal:CHANnel:FSCH:ZERO affects the SCH0 for the currently selected service option (or SO 32, if neither SO 32 nor SO 33 is selected).				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.				

CONFigure:BSSignal:FROffset:FSCH:ZERO[?]				SCH0 Frame Offset
PROCedure:BSSignal:FROffset:FSCH:ZERO[?]				
<Frame Offs>				
<Frame Offs>	Description of parameters	Def. value	Def. unit	FW vers.
0 to +15	SCH0 Frame offset	0	-	V3.05
Description of command				Sig. State
This command determines an offset for the forward supplemental traffic channel SCH0 timing in CDMA frames.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.				

CONFigure:BSSignal:QOF:FSCH:ZERO[?] PROCEDURE:BSSignal:QOF:FSCH:ZERO[?] <QOF>				SCH0 QOF
<QOF>	Description of parameters	Def. value	Def. unit	FW vers.
0 to 3	Quasi-orthogonal Function	0	–	V3.05
Description of command				Sig. State
<p>This command sets the Quasi-orthogonal Function that the Supplemental Channel SCH0 uses in the forward CDMA channel. The QOF of the forward SCH0 for SO 32 and SO 33 can be changed independently using CONFigure:SCONfig:SClass1:PDAT:S<nr>D:SCH:ZERO:FORWARD:QOF. CONFigure:BSSignal:QOF:FSCH:ZERO affects the SCH0 for the currently selected service option (or SO 32, if neither SO 32 nor SO 33 is selected).</p> <p>The CONFigure form of the command is used in all signalling states except CEST. The PROCEDURE form of the command is used in the CEST signalling state.</p>				See Descript.

CALCulate[:SCALAr]:BSSignal:EBNT:FSCH:ZERO? <Eb/Nt>				F-SCH0 Eb/Nt
<Eb/Nt>	Description of parameters	Def. value	Def. unit	FW vers.
–30.969 dB to 18.072 dB	Calculated F-SCH0 Eb/Nt	–	dB	V3.10
Description of command				Sig. State
<p>This command is always a query. It returns the calculated signal to noise ratio for the forward SCH0. This quantity is undefined unless the AWGN generator is turned on (CONFigure:IMPairments:LEVel:AWGN). The quoted range of values is valid for data rates between 9.6 kbps and 153.6 kbps; see <i>Eb/Nt Calculation</i> in Chapter 4.</p>				All

CONFigure:BSSignal:LEVel:FSCH:ONE[?] PROCEDURE:BSSignal:LEVel:FSCH:ONE[?] <FSCH1 Level>				SCH1 Level
<FSCH1 Level>	Description of parameters	Def. value	Def. unit	FW vers.
–20.0 dB to –1.0 dB DEFault MINimum MAXimum ON OFF	Forward supplemental traffic channel level Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum Forward supplemental traffic channel level on Forward supplemental traffic channel level off	–7	dB	V3.20
Description of command				Sig. State
<p>This command determines the signal level of the supplemental traffic channel SCH1 in the forward CDMA channel.</p> <p>The CONFigure form of the command is used in all signalling states except CEST. The PROCEDURE form of the command is used in the CEST signalling state.</p>				See Descript.

CONFigure:BSSignal:CHANnel:FSCH:ONE[?]				SCH1 Channel (Walsh Code)	
PROCedure:BSSignal:CHANnel:FSCH:ONE[?]					
<FSCH Channel>					
<FSCH Channel>	Description of parameters	Def. value	Def. unit	FW vers.	
0 to 127	Forward supplemental channel SCH0 Walsh code	37	–	V3.05	
Description of command				Sig. State	
<p>This command determines the Walsh code for the forward supplemental traffic channel. The command is valid in the Call Established state. The Walsh codes of the forward SCH1 for SO 32 and SO 33 can be changed independently using <code>CONFigure:SCONfig:SClass1:PDAT:S<nr>D:SCH:ONE:FORward:CHANnel</code>. <code>CONFigure:BSSignal:CHANnel:FSCH:ONE</code> affects the SCH1 for the currently selected service option (or SO 32, if neither SO 32 nor SO 33 is selected).</p> <p>The <code>CONFigure</code> form of the command is used in all signalling states except CEST. The <code>PROCedure</code> form of the command is used in the CEST signalling state.</p>				See Descript.	

CONFigure:BSSignal:FROffset:FSCH:ONE[?]				SCH1 Frame Offset	
PROCedure:BSSignal:FROffset:FSCH:ONE[?]					
<Frame Offs>					
<Frame Offs>	Description of parameters	Def. value	Def. unit	FW vers.	
0 to +15	SCH1 Frame offset	0	–	V3.20	
Description of command				Sig. State	
<p>This command determines an offset for the forward supplemental traffic channel SCH1 timing in CDMA frames.</p> <p>The <code>CONFigure</code> form of the command is used in all signalling states except CEST. The <code>PROCedure</code> form of the command is used in the CEST signalling state.</p>				See Descript.	

CONFigure:BSSignal:QOF:FSCH:ONE[?]				SCH1 QOF	
PROCedure:BSSignal:QOF:FSCH:ONE[?]					
<QOF>					
<QOF>	Description of parameters	Def. value	Def. unit	FW vers.	
0 to 3	Quasi-orthogonal Function	0	–	V3.05	
Description of command				Sig. State	
<p>This command sets the Quasi-orthogonal Function that the Supplemental Channel SCH1 uses in the forward CDMA channel. The QOF of the forward SCH1 for SO 32 and SO 33 can be changed independently using <code>CONFigure:SCONfig:SClass1:PDAT:S<nr>D:SCH:ONE:FORward:QOF</code>. <code>CONFigure:BSSignal:QOF:FSCH:ONE</code> affects the SCH1 for the currently selected service option (or SO 32, if neither SO 32 nor SO 33 is selected).</p> <p>The <code>CONFigure</code> form of the command is used in all signalling states except CEST. The <code>PROCedure</code> form of the command is used in the CEST signalling state.</p>				See Descript.	

CALCulate[:SCALAR]:BSSignal:EBNT:FSCH:ONE?				F-SCH1 Eb/Nt	
<Eb/Nt>					
<Eb/Nt>	Description of parameters	Def. value	Def. unit	FW vers.	
–30.969 dB to 18.072 dB	Calculated F-SCH1 Eb/Nt	–	dB	V3.20	
Description of command				Sig. State	
<p>This command is always a query. It returns the calculated signal to noise ratio for the forward SCH1. This quantity is undefined unless the AWGN generator is turned on (<code>CONFigure:IMPairments:LEVel:AWGN</code>). The quoted range of values is valid for data rates between 9.6 kbps and 153.6 kbps; see <i>Eb/Nt Calculation</i> in Chapter 4.</p>				All	

CONFigure:BSSignal:CHANnel:FPCH[?]				Paging Channel
PROCedure:BSSignal:CHANnel:FPCH[?]				
<FPCH Channel>				
<FPCH Channel>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 7	Forward paging channel	1	–	V3.05
Description of command				Sig. State
This command determines the forward paging channel number.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.				

CONFigure:BSSignal:LEVel:FPCH[?]				RF Level
PROCedure:BSSignal:LEVel:FPCH[?]				
<FPCH Level>				
<FPCH Level>	Description of parameters	Def. value	Def. unit	FW vers.
–20.0 dB to –1.0 dB DEFault MINimum MAXimum ON OFF	Forward paging channel level Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum Forward paging channel level on Forward paging channel level off	–7.0	dB	V3.05
Description of command				Sig. State
This command determines the signal level of the paging channel in the forward CDMA channel.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.				

CONFigure:BSSignal:USAGe:FQPCh[?]				Quick Paging Channel
PROCedure:BSSignal:USAGe:FQPCh[?]				
<Quick Paging Channel>				
<Quick Paging Channel>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	Forward quick paging channel	OFF	–	V3.05
Description of command				Sig. State
This command enables or disables the forward quick paging channel number.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.				

CONFigure:BSSignal:CHANnel:FQPCh?				Quick Paging Channel
PROCedure:BSSignal:CHANnel:FQPCh?				
<Quick Paging Channel>				
<Quick Paging Channel>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 7	Forward quick paging channel	1	–	V3.05
Description of command				Sig. State
This command determines the forward quick paging channel number.				See Descript.

CONFigure:BSSignal:LEVel:FQPCh[?] PROCedure:BSSignal:LEVel:FQPCh[?] <Quick Paging Level>				Quick Paging Level
<Quick Paging Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to -1.0 dB DEFault MINimum MAXimum ON OFF	Forward quick paging channel level Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum Forward quick paging channel level on Forward quick paging channel level off	-7.0	dB	V3.05
Description of command				Sig. State
This command determines the signal level of the quick paging channel in the forward CDMA channel. The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.				See Descript.

CONFigure:BSSignal:IBITs:FQPCh[?] PROCedure:BSSignal:IBITs:FQPCh[?] <Indicator Bits>				Indicator Bits				
<Indicator Bits>	Description of parameters	Def. value	Def. unit	FW vers.				
00 to 11	Quick paging channel instruction bits	11	-	V3.05				
Description of command				Sig. State				
This command sends the quick paging channel indicator bits to the mobile station to instruct the mobile to monitor the assigned pagin channel slot or go to sleep mode. Two bits are sent to increase reliability. The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state. The bits are read as follows:				See Descript.				
<table border="1"> <tr> <td>Read bit 1</td> <td>Bit 1 = 1: Read bit 2 Bit 1 = 0: Mobile to sleep mode</td> </tr> <tr> <td>Read bit 2</td> <td>Bit 2 = 1: Mobile monitors paging channel Bit 2 = 0: Mobile to sleep mode</td> </tr> </table>					Read bit 1	Bit 1 = 1: Read bit 2 Bit 1 = 0: Mobile to sleep mode	Read bit 2	Bit 2 = 1: Mobile monitors paging channel Bit 2 = 0: Mobile to sleep mode
Read bit 1	Bit 1 = 1: Read bit 2 Bit 1 = 0: Mobile to sleep mode							
Read bit 2	Bit 2 = 1: Mobile monitors paging channel Bit 2 = 0: Mobile to sleep mode							

CONFigure:BSSignal:DUTPaging:FQPCh[?] PROCedure:BSSignal:DUTPaging:FQPCh[?] <DUT Paging>				Paging
<DUT Paging>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	Mobile station quick paging enable	ON	-	V3.05
Description of command				Sig. State
This command enables or disables the quick paging channel of the mobile station under test. The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.				See Descript.

CONFigure:BSSignal:PROPerTy:PNOffset[?] PROCedure:BSSignal:PROPerTy:PNOffset[?] <PN Offs>				PN Offset
<PN Offs>	Description of parameters	Def. value	Def. unit	FW vers.
0 to +511	PN offset	0	–	V3.05
Description of command				Sig. State
This command determines an offset for the timing of the pilot channel, the sync channel message, and the long code mask of the paging channel.				See Descript.
The CONFigure form of the command is used in all signalling states except CEST. The PROCedure form of the command is used in the CEST signalling state.				

CONFigure:BSSignal:PROPerTy:CLDTime[?] <Call Loss Timer>				Call Loss Timer
<Call Loss Timer>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 5 DEFault MINimum MAXimum OFF ON	Call loss detection timer Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum Disables the call loss detection timer Re-enables the call loss detection timer	1	s	V3.05
Description of command				Sig. State
This command sets the timeout value of the fade timer (in increments of 0.1 seconds) to detect when a call is lost or dropped.				SOFF SON REG Q: all

CONFigure:BSSignal:PROPerTy:PRTTimeout[?] <Timeout>				Page Response Timeout
<Timeout>	Description of parameters	Def. value	Def. unit	FW vers.
5 s to 15 s	Timeout value	15	s	V3.60
Description of command				Sig. State
This command sets the timeout value of the page timer (in increments of 1 seconds) to define the maximum time the CMU will attempt to page the mobile.				SOFF SON REG Q: all

Subsystem IMPairments... (Impairments to the BS Signal)

The subsystem *IMPairments* distorts the BS Signal in order to more closely simulate actual operating conditions. It corresponds to the *Impairments* section in the *BS Signal* tab in the popup menu *Connection Control*.

CONFigure:IMPairments:LEVel:AWGN[?]				AWGN Level
<AWGN Level>				
<AWGN Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to +4.0 dB DEFault MINimum MAXimum ON OFF	AWGN level Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum AWGN generator on AWGN generator off	OFF	dB	V3.05
Description of command				Sig. State
This command determines the Additive White Gaussian Noise level to impair the RF generator signal.				SOFF SON REG Q: all

CONFigure:IMPairments:FOFFset[:RF][?]				Carrier Frequency Offset
<Freq. Offset>				
<Freq. Offset>	Description of parameters	Def. value	Def. unit	FW vers.
-3.0 kHz to +3.0 kHz DEFault MINimum MAXimum ON OFF	BS frequency offset setting Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum Frequency offset on No frequency offset	OFF	Hz	V3.05
Description of command				Sig. State
This command determines a frequency offset to impair the RF generator signal.				SOFF SON REG Q: all

CONFigure: IMPairments:ITFer[?] <FER>				Injected Tx FER
<FER>				
<FER>	Description of parameters	Def. value	Def. unit	FW vers.
0% to 50% OFF ON	Injected Tx FER Switch FER injection off (equiv. to 0%) Re-activate FER injection, using the previously defined value	OFF	-	V3.20
Description of command				Sig. State
This command defines a percentage of faulty (i.e. erasure) frames that the CMU injects into all traffic channels of its BS Signal.				SOFF SON REG Q: all

Subsystem HANDoff:TARGet (Handoff Target)

The subsystem *HANDoff:TARGet* sets the target for a forced handoff of the mobile phone. The corresponding softkeys are located in the tab *Handoff* in the popup menu *Connect. Control*.

STATus:HANDoff:TARGet:LIST?				Destination List
Returns	Description of parameters	Def. value	Def. unit	FW vers.
"CDMA2KCellIMS" "CDMA2KPCSMS" "CDMA2KIMT2KMS" "CDMA2K450MS" "AMPSMS" "CDMA2KCellIMSFallback" "CDMA2KPCSMSFallback" "CDMA2KIMT2KMSFallback" "CDMA2K450MSFallback" "AMPSMSFallback"	Target list for CDMA (excluding the origin network)	Complete list	–	V3.05
Description of command				Sig. State
This command is always a query and returns a list of all networks that are available for a handoff. On registration, the complete (default) target list is replaced by the actual target list depending on the capabilities of the mobile station.				All

CONFigure:HANDoff:TARGet[?] <Handoff Target>				Destination Selection
<Handoff Target>	Description of parameters	Def. value	Def. unit	FW vers.
"CDMA2KCellIMS" "CDMA2KPCSMS" "CDMA2KIMT2KMS" "CDMA2K450MS" "AMPSMS" "CDMA2KCellIMSFallback" "CDMA2KPCSMSFallback" "CDMA2KIMT2KMSFallback" "CDMA2K450MSFallback" "AMPSMSFallback"	Target for CDMA handoff	NONE	–	V3.05
NONE	No handoff			
Description of command				Sig. State
This command selects a handoff target. The targets available depend on the current network and on the capabilities of the mobile station; see previous command. The query returns <i>NONE</i> unless a destination has been selected before.				CEST Q: all
Handoff is initiated via the PROCedure:SIGNalling:ACTion HANDoff command.				

Subsystem NETWORK

The subsystem *NETWork* determines parameters of the radio network and the existing radio link. The subsystem corresponds to the *Network* tab of the popup menu *Connection Control*.

Subsystem NETWork:IDENTity

The subsystem *NETWork:IDENTity* determines the identity of the radio network and the mobile. The subsystem corresponds to the table field *Network Identity* in the *Network* tab of the popup menu *Connection Control*.

CONFigure:NETWork:IDENTity:NID[?]				Network ID
<Network ID Number>				
<Network ID Number>	Description of parameters	Def. value	Def. unit	FW vers.
0 to 65535 MINimum MAXimum DEFault	Network identity code Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	1	–	V3.05
Description of command				Sig. State
This command defines the 16-bit network identity code.				SOFF SON REG Q: all

CONFigure:NETWork:IDENTity:MCC[?]				Mobile Country Code
<Mobile Country Code_Network>				
<Mobile Country Code_Network>	Description of parameters	Def. value	Def. unit	FW vers.
0 to 999 DEFault	Mobile country code Sets the value to the default setting	“999”	–	V3.05
Description of command				Sig. State
This command defines the mobile country code for the network.				SOFF SON REG Q: all

Subsystem MSSignal (Mobile Settings)

The subsystem *MSSignal* defines mobile parameters used to set up the connection. The subsystem corresponds to the table field *Mobile Settings* in the *Network* tab of the popup menu in *Connection Control*.

CONFigure:MSSignal:ID[?] <Mobile ID (MIN/IMSI)>				MS ID Type	
<Mobile ID (MIN/IMSI)>	Description of parameters	Def. value	Def. unit	FW vers.	
{Value} DEFault	34-bit MIN (mobile identification number) or 50-bit IMSI (international mobile subscriber identity) Sets the value to the default setting	0000000001	–	V3.05	
Description of command				Sig. State	
This command determines which type of mobile station identity is to be used for call setup to the mobile phone.				All	

CONFigure:MSSignal:ID:URData[?] <Mobile ID (MIN/IMSI)>				Use Mobile Registration Data	
<Mobile ID (MIN/IMSI)>	Description of parameters	Def. value	Def. unit	FW vers.	
ON OFF DEFault	Use mobile registration data to attempt a connection Always use fixed mobile ID Sets the value to the default setting	OFF	–	V3.05	
Description of command				Sig. State	
This command qualifies whether the CMU uses the mobile ID received during mobile registration or the ID defined via CONFigure:MSSignal:ID to attempt a connection.				All	

CONFigure:MSSignal:MCRReport[?] <Enable>				Mobile Capabilities Report	
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.	
ON OFF	Enable or disable report	ON	–	V3.60	
Description of command				Sig. State	
This command qualifies whether the mobile capabilities report is requested during registration and displayed. When set to OFF most of the parameters in the [SENSe:]MSSinfo... subsystem return invalid results.				All	

CONFigure:MSSignal:MCC[?] <Mobile Country Code>				MS Country Code	
<Mobile Country Code>	Description of parameters	Def. value	Def. unit	FW vers.	
0 to 999 DEFault	Mobile country code Sets the value to the default setting	999	–	V3.05	
Description of command				Sig. State	
This command defines the mobile station's country code.				All	

Subsystem NETWORK:SYSTEM (System Parameters)

The subsystem *NETWork:System* determines system parameters for the radio connection. The subsystem corresponds to the table field *System Parameters* in the *Network* tab of the popup menu in *Connection Control*.

CONFigure:NETWork:SYSTEM:SID[?]				Network System ID	
<System ID Number>					
<System ID Number>	Description of parameters	Def. value	Def. unit	FW vers.	
0 to 32767 MINimum MAXimum DEFault	System ID number Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	1	–	V3.05	
Description of command				Sig. State	
This command defines the system identification for the CMU.				SOFF SON REG Q: all	

CONFigure:NETWork:SYSTEM:SWA[?]				Active/Candidate Window	
<Size>					
<Size>	Description of parameters	Def. value	Def. unit	FW vers.	
0 to 15	Window size SRCH_WIN_A	8	–	V3.60	
Description of command				Sig. State	
This command sets the size of the search window for each pilot in the Active Set or Candidate Set.				all	

CONFigure:NETWork:SYSTEM:SWN[?]				Neighbor Window	
<Size>					
<Size>	Description of parameters	Def. value	Def. unit	FW vers.	
0 to 15	Window size SRCH_WIN_N	8	–	V3.60	
Description of command				Sig. State	
This command sets the size of the search window for each pilot in the Neighbor Set.				all	

CONFigure:NETWork:SYSTEM:SWR[?]				Remaining Window	
<Size>					
<Size>	Description of parameters	Def. value	Def. unit	FW vers.	
0 to 15	Window size SRCH_WIN_R	8	–	V3.60	
Description of command				Sig. State	
This command sets the size of the search window for each pilot in the Remaining Set.				all	

CONFigure:NETWork:SYSTem:BSID[?] <Base Station ID Number>				Base Station ID
<Base Station ID Number>	Description of parameters	Def. value	Def. unit	FW vers.
0 to 65535 MINimum MAXimum DEFault	16-bit BTS ID Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	1	–	V3.05
Description of command				Sig. State
This command defines the base station identification for the CMU.				SOFF SON REG Q: all

CONFigure:NETWork:SYSTem:PREVision[?] <Protocol Revision>				Protocol Revision
<Protocol Revision>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 6 MINimum MAXimum DEFault	Protocol Revision Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	6	–	V3.05
Description of command				Sig. State
This command defines the version of the transmission protocol for the CMU to use.				SOFF SON REG Q: all
Note: <i>Changing the Protocol Revision of the CMU resets the Power Control Step Size CONFigure:BSSignal:PCBits:SSIZe to its default value of 1.00 dB.</i>				

CONFigure:NETWork:SYSTem:MPRevision[?] <Minimum Protocol Revision>				Minimum Protocol Revision
<Minimum Protocol Revision>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 6 MINimum MAXimum DEFault	Minimum protocol revision Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	1	–	V3.05
Description of command				Sig. State
This command defines the minimum protocol revision capability of the mobile station.				SOFF SON REG Q: all

CONFigure:NETWork:SYSTem:IMSI:ETWelve[?] <IMSI 11 12>				BS IMSI
<IMSI 11 12>	Description of parameters	Def. value	Def. unit	FW vers.
00 to 99 DEFault	ASCII value Sets the value to the default setting	01	–	V3.05
Description of command				Sig. State
This command defines an ASCII string containing two digits representing the 11 th and 12 th digit of the IMSI of the base station.				SOFF SON REG Q: all

CONFigure:NETWork:SYSTem:UWCard[?]				State Use Wildcard	
<State Use Wildcard>					
<State Use Wildcard>	Description of parameters	Def. value	Def. unit	FW vers.	
ON OFF	Special values for MCC and IMSI_11_12 on or off.	OFF	–	V3.05	
Description of command					Sig. State
This value indicates whether to use special values for MCC and IMSI_11_12 that indicate to the mobile that it needs to use only IMSI_S.					SOFF SON REG Q: all

CONFigure:NETWork:SYSTem:AUTHeNtic[?]				State Authentication	
<State Authentication>					
<State Authentication>	Description of parameters	Def. value	Def. unit	FW vers.	
ON OFF	Authentication mode	OFF	–	V3.05	
Description of command					Sig. State
This command switches the authentication mode on and off.					SOFF SON REG Q: all

CONFigure:NETWork:SYSTem:ACHallenge[?]				State Challenge	
<State Challenge>					
<State Challenge>	Description of parameters	Def. value	Def. unit	FW vers.	
00000000 _{HEX} to FFFFFFF _{HEX}	8 digit hex string	DEAFBEEF	–	V3.05	
Description of command					Sig. State
This command sets the random challenge value for authentication. It is valid only with Authentication mode is switched on.					SOFF SON REG Q: all

Subsystem NETWork:CINDicator (Call Indicators)

The subsystem *NETWork:CINDicators* defines the parameters needed to perform the *Land Party to Mobile Station Caller ID* tests. The subsystem corresponds to the *Call Indicators* section in the *Network* tab of the popup menu in *Connection Control*.

CONFigure:NETWork:CINDicator:CID				Caller ID	
<ID>					
<ID>	Description of parameters	Def. value	Def. unit	FW vers.	
'<10-digit>' OFF ON	Caller ID (10-digit decimal string variable) Disable transfer of caller ID Re-enable previously defined caller ID	OFF	–	V3.60	
Description of command					Sig. State
This command defines the caller ID to be sent to the mobile.					all

CONFigure:NETWork:CINDicator:PINdicator <Indicator>		Caller ID Presentation Indicator		
<Indicator>	Description of parameters	Def. value	Def. unit	FW vers.
PAL PRES NNA	Presentation Allowed Presentation Restricted Number not Available	PAL	–	V3.60
Description of command				Sig. State
This command specifies how the mobile under test will display the <i>Caller ID</i> (CPN) (CONFigure :NETWork:CINDicator:CID) received from the CMU.				all

CONFigure:NETWork:CINDicator:CWINdicator <Indicator>		Call Waiting Indicator		
<Indicator>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	Initiate transfer of caller ID No transfer	OFF	–	V3.60
Description of command				Sig. State
If set to <i>ON</i> during an established call, this command initiates the transfer of the <i>Caller ID</i> to the mobile. The call waiting indicator is automatically set to <i>Off</i> when the connection is released.				CEST

Subsystem NETWork:PCHannel (Paging Channel)

The subsystem *NETWork:PCHannel* determines the paging channel parameters. The subsystem corresponds to the table field *Paging Channel* in the *Network* tab of the popup menu in *Connection Control*.

CONFigure:NETWork:PCHannel:RATE <Paging Channel Rate>		Paging Channel Rate		
<Paging Channel Rate>	Description of parameters	Def. value	Def. unit	FW vers.
R4K8 R9K6 DEFault	4800 bps data rate 9600 bps data rate Sets the value to the default setting	R9K6	Bps	V3.05
Description of command				Sig. State
This command sets the date rate of the paging channel.				SOFF SON REG Q: all

CONFigure:NETWork:PCHannel:SCIndex[?]				Slot Cycle Index						
<Paging CH Slot Cycle Index>										
<Paging CH Slot Cycle Index>	Description of parameters	Def. value	Def. unit	FW vers.						
0 to 7 MINimum MAXimum DEFault	10-bit Slot Cycle index Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	0	–	V3.05						
Description of command				Sig. State						
This command determines the length of the slot cycle by setting the number of slots in the slot cycle. Each slot cycle equals 1.28 seconds. The number of slots in the slot cycle is determined by the formula: $\text{Slot cycle} = 1.28 \times 2^i \text{ (where } i \text{ equals the slot cycle index)}$ For example: <table style="margin-left: 40px; border: none;"> <tr> <td>i = 0</td> <td>Slot cycle = 1.28 seconds</td> </tr> <tr> <td>i = 1</td> <td>Slot cycle = 2.56 seconds</td> </tr> <tr> <td>i = 2</td> <td>Slot cycle = 5.12 seconds</td> </tr> </table> The paging channel is monitored during the slot cycle when operating in the slotted mode. A mobile stations slot occurs once per slot cycle				i = 0	Slot cycle = 1.28 seconds	i = 1	Slot cycle = 2.56 seconds	i = 2	Slot cycle = 5.12 seconds	SOFF SON REG Q: all
i = 0	Slot cycle = 1.28 seconds									
i = 1	Slot cycle = 2.56 seconds									
i = 2	Slot cycle = 5.12 seconds									

CONFigure:NETWork:PCHannel:MSCIndex[?]				Max. Slot Cycle Index
<Max Slot Cycle Index>				
<Max Slot Cycle Index>	Description of parameters	Def. value	Def. unit	FW vers.
0 to 7 MINimum MAXimum DEFault	Maximum 10-bit slot cycle index Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	0	–	V3.05
Description of command				Sig. State
This command sets the maximum slot cycle index allowed to determine the slot cycle length.				SOFF SON REG Q: all

Subsystem NETWORK:REGistration

The subsystem *NETWORK:REGistration* defines when the registration procedure is to be performed. The subsystem corresponds to the table field *Registration* in the *Network* tab of the popup menu in *Connection Control*.

CONFigure:NETWork:REGistration:TBASed[?]		Timer Based Registration		
<Timer Based Registration>				
<Timer Base Registration>	Description of parameters	Def. value	Def. unit	FW vers.
12.16 14.48 17.20 20.48 24.32 28.96 34.40 40.96 48.64 57.92 68.88 81.92 97.36 115.84 137.76 163.84 194.80 231.68 275.52 327.68 389.60 463.36 551.04 655.36 779.28 926.80 1102.16 1310.72 1558.64 1853.60 2204.32 2621.44 3117.36 3707.20 4408.64 5242.88 6234.80 7414.48 8817.36 10485.76 12469.68 14829.04 17634.80 20971.52 24939.44 29658.16 35269.68 41943.04 49878.96 59316.40 70529.44 83886.08 99757.92 118632.80 141078.96 167772.16 199515.84 OFF	Registration interval in seconds	12.16	s	V3.05
No periodic registration				
Description of command				Sig. State
This command sets the time between registration attempts. Any entry is rounded to one of the allowed values listed above.				SOFF SON REG Q: all

CONFigure:NETWork:REGistration:HOME[?]		Registration Home		
<Registration Home>				
<Registration Home>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	Home registration on or off	ON	–	V3.05
Description of command				Sig. State
This command enables the home (non-roaming) registration mode.				SOFF SON REG Q: all

CONFigure:NETWork:REGistration:FSID[?]		Registration FSID		
<Registration SID>				
<Registration SID>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	Foreign System ID registration on or off	ON	–	V3.05
Description of command				Sig. State
This command determines whether a registration procedure is to be executed when the system identity is changed.				SOFF SON REG Q: all

CONFigure:NETWork:REGistration:FNID[?]				Registration FNID
<Registration NID>				
<Registration NID>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	Foreign Network ID registration on or off	ON	–	V3.05
Description of command				Sig. State
This command determines whether a registration procedure is to be executed when the network identity is changed.				SOFF SON REG Q: all

CONFigure:NETWork:REGistration:PUP[?]				Registration Power Up
<Registration Up>				
<Registration Up>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	Power up registration on or off	ON	–	V3.05
Description of command				Sig. State
This command determines whether a registration procedure is to be executed on power-up of the mobile station.				SOFF SON REG Q: all

CONFigure:NETWork:REGistration:PDOWN[?]				Registration Power Down
<Registration Down>				
<Registration Down>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	Registration at power down on or off	ON	–	V3.05
Description of command				Sig. State
This command determines whether a registration procedure is to be executed on power-down of the mobile station.				SOFF SON REG Q: all

CONFigure:NETWork:REGistration:PARAmeter[?]				Registration Parameter
<Registration Reg>				
<Registration Reg>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	Parameter registration mode on of off	ON	–	V3.05
Description of command				Sig. State
This command determines whether a registration procedure is to be executed after a parameter change.				SOFF SON REG Q: all

Subsystem NETWORK:APRobes

The subsystem *NETWORK:APRobes* determines the access probe channel parameters. The subsystem corresponds to the table field *Access Probes* in the *Network* tab of the popup menu in *Connection Control*.

CONFigure:NETWork:APRobes:MODE[?]				Access Probes
<Mode>				
<Mode>	Description of parameters	Def. value	Def. unit	FW vers.
ACKnowledge IGNore DEFault	Acknowledge or ignore access probes	ACKN		V3.05
Description of command				Sig. State
This command instructs the CMU to acknowledge or ignore the access probes form the mobile station.				SOFF SON REG Q: all

CONFigure:NETWork:APRobes:NOFFset[?]				Nominal Offset
<Nominal Offset>				
<Nominal Offset>	Description of parameters	Def. value	Def. unit	FW vers.
-24/-8 dB to 7 dB MINimum MAXimum DEFault	Nominal power offset (NOM_PWR)	0 dB	dB	V3.05
Description of command				Sig. State
This command sets the nominal transmit power offset of the access probes. The offset range is dependent on the network setting.				SOFF SON REG Q: all

CONFigure:NETWork:APRobes:IOFFset[?]				Initial Offset
<Initial Offset>				
<Initial Offset>	Description of parameters	Def. value	Def. unit	FW vers.
-16 dB to 15 dB MINimum MAXimum DEFault	Initial power offset (INIT_PWR)	0 dB	dB	V3.05
Description of command				Sig. State
This command sets the value of the initial transmit power offset of the access probes.				SOFF SON REG Q: all

CONFigure:NETWork:APRobes:PINCrement[?]				Probe Increment
<Power Increment>				
<Power Increment>	Description of parameters	Def. value	Def. unit	FW vers.
0 dB to 7 dB MINimum MAXimum DEFault	Access probe power increment (PWR_STEP)	3 dB	dB	V3.05
Description of command				Sig. State
This command sets the size of the power step between consecutive access probes.				SOFF SON REG Q: all

CONFigure:NETWork:APRobes:PPSquence[?]				Probes per Sequence
<Probes per Sequence>				
<Probes per Sequence>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 16 MINimum MAXimum DEFault	Access probes contained in sequence (NUM_STEP)	16	–	V3.60
Description of command				Sig. State
This command sets the number of access probes contained in a single access probe sequence.				SOFF SON REG Q: all

CONFigure:NETWork:APRobes:SPATtempt[?]				Sequences per Attempt
<Probe Sequences>				
<Probe Sequences>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 15 MINimum MAXimum DEFault	Number of access probe sequences (MAX_RSP_SEQ)	1	–	V3.05
Description of command				Sig. State
This command sets the maximum number of access probe sequences sent during the access attempt.				SOFF SON REG Q: all

SAPPower (Standby and Access Probe Power)

The subsystem *SAPPower* contains the commands for measuring the standby and access probe power. It corresponds to the softkey *Power* of the tab *Signalling* in the menu group *Connect. Control*.

Note: *In contrast to the measurement groups reported below, the *SAPPower* measurement can be performed in the signalling states SON, and REG only. Configurations are always possible.*


INITiate:SAPPower	Start new measurement	⇒	RUN
ABORt:SAPPower	Abort running measurement and switch off	⇒	OFF
STOP:SAPPower	Stop measurement after current stat. cycle	⇒	STOP
CONTInue:SAPPower	Next measurement step (<i>stepping mode</i>)	⇒	RUN
Description of command		Sig. State	FW vers.
These commands have no query form. They start or stop the measurement, setting it to the status given in the top right column.		SON REG	V3.00

CONFigure:SAPPower:EREPorting[?]		Event Reporting		
<Report Mode>				
<Report Mode>	Description of parameters	Def. value	Def. unit	FW vers.
SRQ	Service request	OFF	–	V3.00
SOPC	Single operation complete			
SRSQ	SRQ and SOPC			
OFF	No reporting			
Description of command				Sig. State
This command defines the events generated when the measurement is terminated or stopped (<i>event reporting</i> , see Chapter 5).				all

FETCh[:SCALar]:SAPPower:STATus?				
<Measurement Status>, <Statistic Count>				
<Measurement Status>	Description of parameters	Def. value	Def. unit	
OFF	Measurement in the <i>OFF</i> state (*RST or ABORt)	OFF	–	
RUN	Running (after INITiate, CONTInue or READ)			
STOP	Stopped (STOP)			
ERR	OFF (could not be started)			
STEP	Stepping mode (<stepmode>=STEP)			
RDY	Stopped according to repetition mode and stop condition			
<Statistic Count>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 10000	Counter for current statistics cycle	OFF		V3.00
NONE	No counting mode set			
Description of command				Sig. State
This command is always a query. It returns the status of the measurement (see Chapters 3 and 5).				all

READ[:SCALar]:SAPPower? FETCh[:SCALar]:SAPPower? SAMPle[:SCALar]:SAPPower? <Standby Power>, <Access Probe Power>		Scalar Results: Start single shot measurement and return results Read out measurement results (unsynchronized) Read out measurement results (synchronized)		
<Standby Power>	Description of parameters	Def. value	Def. unit	
-30.0 dBm to +30.0 dBm	Standby power	NAN	dBm	
<Access Probe Power>	Description of parameters	Def. value	Def. unit	FW vers.
-30.0 dBm to +30.0 dBm	Access probe power	NAN	dBm	V3.00
Description of command				Sig. State
These commands are always queries. They start the measurement of the standby and access probe power and output the result.				SON REG

AF and RF Input, Output, and External Attenuation

These subsystems contain the commands for configuration of the input and output RF connectors and the AF connectors. The subsystem corresponds to the tab AF/RF  in the popup menu *Connect Control*.

INPut[:STATe] <State>		RF Input		
<State>	Description of parameters	Def. value	Def. unit	FW vers.
RF1	Connector RF1 used as input	RF2	-	V3.05
RF2	Connector RF2 used as input			
RF4	Connector RF4 IN used as input			
Description of command				Sig. State
This command determines the connector to be used for RF input signals. The bi-directional connectors RF 1 and RF 2 can be used both as input and output connectors in the same measurement (see OUTPut[:STATe]). Only one input and one output may be active at the same time, a new RF input setting supersedes the previous one.				All

OUTPut[:STATe] <State>		RF Output		
<State>	Description of parameters	Def. value	Def. unit	FW vers.
RF1	Connector RF1 used as output	RF2	-	V3.05
RF2	Connector RF2 used as output			
RF3	Connector RF3 OUT used as output			
Description of command				Sig. State
This command determines the connector to be used for RF output signals. The bi-directional connectors RF 1 and RF 2 can be used as input and output connectors in the same measurement (see INPut[:STATe]). Only one input and one output may be active at the same time, a new RF output setting supersedes the previous one.				All

[SENSe:]CORRection:LOSS:INPut<nr>[:MAGNitude] <Attenuation>				Ext. Att. Input
SOURce:CORRection:LOSS:INPut<nr>[:MAGNitude] <Attenuation>				
<Attenuation>	Description of parameters	Def. value	Def. unit	FW vers.
-50 dB to +90 dB	Value for external attenuation at output <nr>, where <nr> = 1, 2, 4	0.0	dB	V3.05
Description of command				Sig. State
This command assigns an external attenuation value to the inputs of the instrument (<i>RF 1, RF 2, RF 4 IN</i>).				All

[SENSe:]CORRection:LOSS:OUTPut<nr>[:MAGNitude]				Ext. Att. Output
SOURce:CORRection:LOSS:OUTPut<nr>[:MAGNitude] <Attenuation>				
<Attenuation>	Description of parameters	Def. value	Def. unit	FW vers.
-50 dB to +90 dB	Value for external attenuation at output <nr>, where <nr> = 1, 2, 3	0.0	dB	V3.05
Description of command				Sig. State
This command assigns an external attenuation value to the outputs of the instrument (<i>RF 1, RF 2, RF 3 OUT</i>).				All

ROUTE:SPENcoder[:INPut][?]				Speech Input
<Encoder Input>				
<Speech Encoder Input>	Description of parameters	Def. value	Def. unit	FW vers.
HANDset GENerator	Use 9-pole SPEECH connector Use AF OUT connector	HAND	–	V3.05
Description of command				Sig. State
This command selects the input source for the CMU speech encoder. The GENerator setting uses the audio generator signal which is fed to the AF OUT connector.				All

ROUTE:SPDecoder[:OUTPut][?]				Speech Output
<Decoder Output>				
<Speech Decoder Output>	Description of parameters	Def. value	Def. unit	FW vers.
HANDset ANALyzer ANA2 ABOTH	Output to 9-pole SPEECH connector Output to audio analyzer. AF IN disabled. Output to secondary audio analyzer. AUX 1 disabled Output to primary audio analyzer. AF IN and AUX 1 disabled.	HAND	–	V3.05
Description of command				Sig. State
This command routes the speech decoder output to the selected destination.				All

Subsystem DM:CLOCK (Synchronization)

The subsystem *DM:CLOCK* sets a system clock specific to the network. This frequency is set in the tab *Sync.* in the popup menu *Connection Control*.

SOURCE:DM:CLOCK:STATE				REF OUT 2	
<Mode>					
<Mode>	Description of parameters	Def. value	Def. unit	FW vers.	
ON OFF	Switch on/off system clock	OFF	–	V3.05	
Description of command					Sig. State
This command switches the system clock at output <i>REF OUT 2</i> on or off.					All

SOURCE:DM:CLOCK:FREQUENCY <Frequency>				REF OUT 2	
<Frequency>					
<Frequency>	Description of parameters	Def. value	Def. unit	FW vers.	
39.3216 MHz 19.6608 MHz 13.1072 MHz 9.8304 MHz	System Clock Frequency	39.3216	MHz	V3.03	
Description of command					Sig. State
This command determines the system clock frequency applied to <i>REF OUT 2</i> .					All

Subsystem TRIGGER (Trigger Mode)

The subsystem *TRIGGER* defines the trigger source. It corresponds to the tab *Misc.* in the popup menu *Connection Control*.

DEFAULT:TRIGGER[:SEQUENCE][?]				Default All Settings	
<Trigger Source>					
<Trigger Source>	Description of parameters	Def. value	Def. unit	FW vers.	
ON OFF	The parameters are set to their default values Some or all parameters are not set to default	ON	–	V3.10	
Description of command					
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystem <i>TRIGGER</i> to their default values (the setting <i>OFF</i> results in an error message).					
If used as a query the command returns whether all parameters are set to their default values (<i>ON</i>) or not (<i>OFF</i>).					

TRIGger[:SEQuence]:SOURce[?] <Trigger>				Trigger
<Trigger>	Description of parameters	Def. value	Def. unit	FW vers.
INT ernal	Trigger source from internal clock	INT	–	V3.03
EXT ernal	External Trigger source supplied			
FRUN	Trigger set to free run			V3.40
RFP ower	Wideband RF power trigger			
IFP ower	Narrow-band IF power trigger			
Description of command				Sig. State
This command selects the source of the trigger event. <i>INT</i> ernal uses the trigger signal from the signalling unit of the CMU. The settings <i>RFP</i> ower and <i>IFP</i> ower require burst signals. <i>External</i> requires a trigger source supplied via the AUX 3 connector on the front panel.				All
AUX 3 pin assignments				
Output trigger signals: see command TRIGger:OUTPut:PIN<nr>:SIGNal[?]				
Input trigger: Pin 8: Trigger Input				
H-PSK measurements and the Transmit Time Error measurement require particular trigger settings and synchronization; see Chapter 4.				

TRIGger[:SEQuence]:THREshold:RFPower <Threshold>				Level – RF Power
<Threshold>	Parameter description	Def. value	Default unit	FW vers.
LOW	Low trigger threshold (<i>RF Max. Level</i> – 26 dB)	MEDIum	–	V3.40
MEDIum	Medium trigger threshold (<i>RF Max. Level</i> – 16 dB)			
HIGH	High trigger threshold (<i>RF Max. Level</i> – 6 dB)			
Command description				Sig. State
This command sets the RF input signal level at which the measurement is triggered relative to the maximum RF input level; see [SENSe:]LEVel:MAXimum. The setting has effect for trigger source <i>RFP</i> ower only (see TRIG:SEQ:SOUR:<Modulation>).				All

TRIGger[:SEQuence]:THREshold:IFPower <Threshold>				Level – IF Power
<Threshold>	Parameter description	Def. value	Default unit	FW vers.
–47 dB to 0 dB	IF power threshold	–16	dB	V3.40
Command description				Sig. State
This command sets the IF signal level at which the measurement is triggered. The IF power threshold is defined relative to the maximum RF input level; see [SENSe:]LEVel:MAXimum. The setting has effect for trigger source <i>IFP</i> ower only (see TRIG:SEQ:SOUR:<Modulation>).				All

TRIGger[:SEQuence]:SLOPe <Slope>				Slope
<Slope>	Parameter description	Def. value	Default unit	FW vers.
POS itive	Rising edge	POS	–	V3.40
NEG ative	Falling edge			
Command description				Sig. State
This command qualifies whether the trigger event occurs on the <i>Rising Edge</i> or on the <i>Falling Edge</i> of the trigger signal. The setting has no influence on <i>Free Run</i> measurements (see TRIG:SEQ:SOUR).				All

TRIGger:OUTPut:PIN<nr>:SIGNal[?] <Frame_Period>			Output Routing	
<Frame_Period>	Description of parameters	Def. value	Def. unit	FW vers.
NONE PP2S SFrame SNCFramE PFRamE PCFRamE DEFault	No output trigger signal Periodic pulse with period 2 s Super frame, 80 ms Sync. frame, 26.67 ms Paging frame, 20 ms Power control frame, 1.25 ms Use default settings	<nr> = 2: SNCF <nr> = 3 = PP2S <nr> = 4 = SFR <nr> = 5 = PFR	–	V3.10
Description of command				
This command selects the type of periodic pulse signal (or no signal, setting <i>NONE</i>) to be applied to pins 2, 3, 4, and 5 (<nr> = 2 to 5) of the AUX 3 connector.				

Subsystem LEVEL (Input Path Settings)

The subsystem *LEVEL* configures the RF input path by defining the expected input level. It corresponds to the tab *Analyzer* in the popup menu *Connection Control*.

DEFault:RFANalyzer[?] <RF Analyzer>			RF Analyzer	
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	The parameters are set to their default values The parameters differ from the default values (partially or totally)	ON	–	V3.05
Description of command				
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystems <i>LEVEL</i> to their default values (the setting <i>OFF</i> results in an error message).				
If used as a query the command returns whether all parameters are set to their default values (<i>ON</i>) or not (<i>OFF</i>).				

[SENSe:]LEVEl:MODE[?] <RF Level Mode>			RF Level Mode	
<RF Level Mode>	Description of parameters	Def. value	Def. unit	FW vers.
AUTomatic MANual	Maximum input level mode for RF	MAN	–	V3.05
Description of command				
This command defines the maximum expected input level mode.				

[SENSe:]LEVEl:MAXimum[?] <RF Manual Max Level>			Max. RF Level	
<RF Manual Max Level>	Description of parameters	Def. value	Def. unit	FW vers.
–43 dBm to +44 dBm	Maximum input level for RF 1	0.0	dBm	V3.05
–57 dBm to +30 dBm	Maximum input level for RF 2	0.0	dBm	
–80 dBm to +9 dBm	Maximum input level for RF 4 IN	0.0	dBm	
Description of command				
This command defines the maximum expected input level. The value range depends on the RF input used and the external attenuation set (see [SENSe:]CORREction:LOSS:INPut<nr>[:MAGNitude] command). If option R&S CMU-U99 (<i>RF 1 with RF 2 Level Range</i>) is fitted, RF 1 takes on the level range of RF2.				

Subsystem ENVIRONMENT (Measurement Environments)

The subsystem *ENVIRONMENT*... enables or disables all measurement environments. This parameter is set in the *Misc.* tab of the popup menu *Connection Control*.

CONFigure:ALL:ENVIRONMENT:ENABLE[?] <Enable>		Environment Enable		
<Enable>	Description of parameters	Def. Value	Def. Unit	FW vers.
ON OFF SOME	Enable or disable all measurement environments Some but not all measurement environments enabled (no setting parameter, returned by query only)	ON	–	V3.20
Description of command				Sig. State
This command enables or disables all measurement environments. SOME is returned if the measurement environments were enabled or disabled selectively using the CONFigure:<Application>:ENVIRONMENT:ENABLE commands.				All

Subsystem MENU (Connection Control Behavior)

The subsystem *MENU*... defines in what instances the *Connection Control* popup menu is automatically opened or closed. The parameters are set in the *Misc.* tab of the popup menu *Connection Control*.

CONFigure:MENU:CCTRI:AOPen[?] <Enable>		Open autom. if not connected		
<Enable>	Description of parameters	Def. Value	Def. Unit	FW vers.
ON OFF	Open <i>Connection Control</i> menu automatically if change of signalling state is required <i>Connection Control</i> menu must be opened manually	ON	–	V3.60
Description of command				Sig. State
This command qualifies whether the <i>Connection Control</i> menu is automatically opened.				All

CONFigure:MENU:CCTRI:AClose[?] <Enable>		Close autom. if connected		
<Enable>	Description of parameters	Def. Value	Def. Unit	FW vers.
ON OFF	Close <i>Connection Control</i> menu automatically as soon as the R&S CMU enters the <i>Connected</i> state <i>Connection Control</i> menu must be closed manually	ON	–	V3.60
Description of command				Sig. State
This command qualifies whether the <i>Connection Control</i> menu is automatically closed.				All

OVERview Measurement

The subsystem *OVERview* measures the most important power, modulation, and receiver quality parameters using a set of configuration settings that is independent of the other measurement groups (*POWer*, *MODulation*, *Code Domain Power*, *RXQuality*). The subsystem corresponds to the *Overview* menu and the associated popup menu *Overview Configuration*.

Subsystem OVERview:MCQuality

The subsystem *OVERview:MCQuality:ENVIRONMENT...* configures the generated RF signal. It corresponds to the *Measurement Environment* section in the *Control* tab of the *Overview Configuration* menu. The settings are used only if the environment is enabled; see *CONFigure:OVERview:MCQuality:ENVIRONMENT:ENABLE*. All settings apply to both O-QPSK and H-PSK modulation.

CONFigure:OVERview:MCQuality:ENVIRONMENT:ENABLE[?]				Environment Enable	
<Enable>					
<Enable>	Description of parameters	Def. Value	Def. Unit	FW vers.	
ON OFF	Enable or disable environment	ON	–	V3.20	
Description of command				Sig. State	
This command enables or disables the environment for all <i>Overview</i> measurement applications.				All	

CONFigure:OVERview:MCQuality:ENVIRONMENT:POWer:CDMA[?]				CDMA Power	
<CDMA Power>					
<CDMA Power>	Description of parameters	Def. value	Def. unit	FW vers.	
–120.0 dBm to –33.0 dBm –120.0 dBm to –16.0 dBm –100.0 dBm to +7.0 dBm DEFault MINimum MAXimum	RF1 OUT, 0 dB ext. atten RF2 OUT, 0 dB ext. atten RF3 OUT, 0 dB ext. atten Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum	–60.0	dBm	V3.20	
Description of command				Sig. State	
This command determines the total CDMA output power (absolute value, in dBm) of the CMU. The CDMA Power value range depends on the RF input used and the external attenuation set. If option R&S CMU-U99 (<i>RF 1 with RF 2 Level Range</i>) is fitted, RF 1 takes on the level range of RF2.				All	

CONFigure:OVERview:MCQuality:ENVIRONMENT:LEVel:FPICH[?]				F-PICH Level	
<Pilot Level>					
<Pilot Level>	Description of parameters	Def. value	Def. unit	FW vers.	
–20.0 dB to –1.0 dB OFF	Pilot Level F-PICH switched off	–7.0	dB	V3.20	
Description of command				Sig. State	
This command determines the level in the forward pilot channel of the CMU. The channel power is in units relative to the total CDMA power.				All	

CONFigure:OVERview:MCQuality:ENVIRONMENT:LEVEL:FFCH[?]				F-FCH Level
<FCH Level>				
<FCH Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to -1.0 dB OFF	FCH Level F-FCH switched off	-7.4	dB	V3.20
Description of command				Sig. State
This command determines the level in the forward fundamental channel of the CMU. The channel power is in units relative to the total CDMA power.				All

CONFigure:OVERview:MCQuality:ENVIRONMENT:LEVEL:FSCH:ZERO[?]				F-SCH0 Level
<SCH0 Level>				
<SCH0 Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to -1.0 dB OFF	F-SCH0 Level F-SCH0 switched off	-7	dB	V3.20
Description of command				Sig. State
This command determines the level in the forward SCH0 channel of the CMU. The channel power is in units relative to the total CDMA power.				All

CONFigure:OVERview:MCQuality:ENVIRONMENT:LEVEL:FSCH:ONE[?]				F-SCH1 Level
<SCH1 Level>				
<SCH1 Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to -1.0 dB OFF	F-SCH1 Level F-SCH1 switched off	-7	dB	V3.20
Description of command				Sig. State
This command determines the level in the forward SCH1 channel of the CMU. The channel power is in units relative to the total CDMA power.				All

CONFigure:OVERview:MCQuality:ENVIRONMENT:EBNT:FFCH?				F-FCH Eb/Nt
<Eb/Nt>				
<Eb/Nt>	Description of parameters	Def. value	Def. unit	FW vers.
-30.969 dB to 18.072 dB	Calculated F-FCH Eb/Nt	-	dB	V3.20
Description of command				Sig. State
This command is always a query. It returns the calculated signal to noise ratio for the forward FCH. This quantity is undefined unless the AWGN generator is turned on (CONFigure:OVERview:MCQuality:ENVIRONMENT:IMPAIRMENTS:LEVEL:AWGN). The quoted range of values is valid for data rates between 9.6 kbps and 153.6 kbps; see <i>Eb/Nt Calculation</i> in Chapter 4.				All

CONFigure:OVERview:MCQuality:ENVIRONMENT:EBNT:FSCH:ZERO?				F-SCH0 Eb/Nt
<Eb/Nt>				
<Eb/Nt>	Description of parameters	Def. value	Def. unit	FW vers.
-30.969 dB to 18.072 dB	Calculated F-SCH0 Eb/Nt	-	dB	V3.20
Description of command				Sig. State
This command is always a query. It returns the calculated signal to noise ratio for the forward SCH0. This quantity is undefined unless the AWGN generator is turned on (CONFigure:OVERview:MCQuality:ENVIRONMENT:IMPAIRMENTS:LEVEL:AWGN). The quoted range of values is valid for data rates between 9.6 kbps and 153.6 kbps; see <i>Eb/Nt Calculation</i> in Chapter 4.				All

CONFigure:OVERview:MCQuality:ENVIRONMENT:EBNT:FSCH:ONE?				F-SCH1 Eb/Nt
<Eb/Nt>				
<Eb/Nt>	Description of parameters	Def. value	Def. unit	FW vers.
-30.969 dB to 18.072 dB	Calculated F-SCH1 Eb/Nt	-	dB	V3.20
Description of command				Sig. State
This command is always a query. It returns the calculated signal to noise ratio for the forward SCH1. This quantity is undefined unless the AWGN generator is turned on (CONFigure:OVERview:MCQuality:ENVIRONMENT:IMPAIRments:LEVEL:AWGN). The quoted range of values is valid for data rates between 9.6 kbps and 153.6 kbps; see <i>Eb/Nt Calculation</i> in Chapter 4.				All

CONFigure:OVERview:MCQuality:ENVIRONMENT:FRATE:FFCH[?]				Frame Rate
<Frame Rate>				
<Frame Rate>	Description of parameters	Def. value	Def. unit	FW vers.
EIGHth QUARter HALF FULL DEFault	Frames at 1/8 of the rate set Frames at 1/4 of the rate set Frames at 1/2 of the rate set Frames at the full rate set	FULL	-	V3.20
Description of command				Sig. State
This command sets the frame rate for the variable rate traffic channel.				All

CONFigure:OVERview:MCQuality:ENVIRONMENT:IMPAIRments:LEVEL:AWGN[?]				AWGN Level
<AWGN Level>				
<AWGN Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to +4.0 dB DEFault MINimum MAXimum OFF,	AWGN level Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum	OFF	dB	V3.20
Description of command				Sig. State
This command determines an Additional White Gaussian Noise level to impair the CMU output signal.				All

CONFigure:OVERview:MCQuality:ENVIRONMENT:IMPAIRments:FOFFset[?]				BS Frequency Offset
<BS Freq Offset>				
<BS Freq Offset>	Description of parameters	Def. value	Def. unit	FW vers.
-50.0 kHz to +50.0 kHz DEFault MINimum MAXimum OFF	BS frequency offset Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum	OFF	Hz	V3.20
Description of command				Sig. State
This command determines a frequency offset to impair the CMU output signal.				All

CONFigure:OVERview:MCQuality:ENVIRONMENT:IMPairments[?]				Injected Tx FER
<FER>				
<FER>	Description of parameters	Def. value	Def. unit	FW vers.
0% to 50% OFF ON	Injected Tx FER Switch FER injection off (equiv. to 0%) Re-activate FER injection, using the previously defined value	OFF	–	V3.20
Description of command				Sig. State
This command defines a percentage of faulty (i.e. erasure) frames that the CMU injects into all traffic channels of its BS Signal.				All

CONFigure:OVERview:MCQuality:ENVIRONMENT:PCBits[?]				Power Control Bits
<Power Control Bits>				
<Power Control Bits>	Description of parameters	Def. value	Def. unit	FW vers.
OFF AUTomatic HOLD ADOW AUP RTES PATTern	Disable power control bits Auto mode, closed-loop operation Alternating up/down control bits All power control bits down All power control bits up Range test mode Pattern defined by means of the CONF:BSS:PCB:PATTern... commands	AUT	–	V3.20
Description of command				Sig. State
This command selects the power control bit sequence that the CMU sends to the mobile station to control its output power.				All

General Configurations – Subsystem OVERview:PPOWER

The subsystem *OVERview:PPOWER* controls the pilot power measurement. It corresponds to the *Pilot Power* softkey in the *Overview* menu.

CONFigure:OVERview:PPOWER:ENABLE[?]				Pilot Power Enable
<Enable>				
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	Activate/disable the pilot power report	ON	–	V3.05
Description of command				Sig. State
This command activates or disables the transmission of the pilot power measured by the mobile station.				All

[SENSe:]OVERview:PPOWER?				Pilot Power
Returned values	Description of parameters	Def. value	Def. unit	FW vers.
Reported PPower, Actual PPower	–20 dB to –7 dB –20 dB to –7 dB	INV INV	dB dB	V3.05
Description of command				Sig. State
This command is always a query. It returns the pilot power reported by the mobile station and the actual pilot power transmitted by the CMU.				All

OVERview:OVERview

The subsystem *OVERview:OVERview* controls the measurement of general power and modulation parameters. It corresponds to the *Overview Meas.* softkey in the *Overview* menu and the associated output fields and to the *Overview Configuration* menu.

Note: *The modulation scheme reference O-QPSK is optional in the commands to remain compatible with cdmaOne. O-QPSK supports radio configurations 1 and 2. H-PSK supports radio configurations 3 and 4.*

INITiate:OVERview:OVERview[:OQPSK]	Start new measurement	⇒	RUN
ABORT:OVERview:OVERview[:OQPSK]	Abort running measurement and switch off	⇒	OFF
STOP:OVERview:OVERview[:OQPSK]	Stop measurement after current stat. cycle	⇒	STOP
CONTinue:OVERview:OVERview[:OQPSK]	Next measurement step (<i>stepping mode</i>)	⇒	RUN
INITiate:OVERview:OVERview:HPSK	Start new measurement	⇒	RUN
ABORT:OVERview:OVERview:HPSK	Abort running measurement and switch off	⇒	OFF
STOP:OVERview:OVERview:HPSK	Stop measurement after current stat. cycle	⇒	STOP
CONTinue:OVERview:OVERview:HPSK	Next measurement step (<i>stepping mode</i>)	⇒	RUN
Description of command		Sig. State	FW vers.
These commands have no query form. They start and stop the overview measurement, setting it to the status indicated in the top right column.		All	V3.05

FETCh[:SCALar]:OVERview:OVERview[:OQPSk]:STATus?		Measurement Status		
FETCh[:SCALar]:OVERview:OVERview:HPSK:STATus?				
Return	Description of parameters	Def. value	Def. unit	FW vers.
OFF	Measurement in the OFF state (*RST or ABORT)	OFF	–	V3.05
RUN	Running (after INITiate, CONTinue or READ)			
STOP	Stopped (STOP)			
ERR	OFF (could not be started)			
STEP	Stepping mode (<stepmode>=STEP)			
RDY	Stopped according to repetition mode and stop condition			
1 to 10000	Counter for current statistics cycle	NONE	–	
NONE	No counting mode set			
1 to 1000	Counter for current evaluation period within a cycle	NONE	–	
NONE	Statistic count set to off			
Description of command				Sig. State
This command is always a query. It returns the status of the measurement (see Chapters 3 and 5).				All

CONFigure:OVERview:OVERview[:OQPSk]:EREPorting[?]		Event Reporting		
CONFigure:OVERview:OVERview:HPSK:EREPorting[?]				
<Report Mode>				
<Report Mode>	Description of parameters	Def. value	Def. unit	FW vers.
SRQ	Service request	OFF	–	V3.05
SOPC	Single operation complete			
SRSQ	SRQ and SOPC			
OFF	No reporting			
DEFault	Use the default setting			
Description of command				Sig. State
This command defines the events generated when the measurement is terminated or stopped (see <i>Event Reporting</i> in Chapter 5 of the CMU manual).				All

XTND:OVERview:OVERview[:OQPSk]:SBSuppress[?] XTND:OVERview:OVERview:HPSK:SBSuppress[?]		Extend Sideband Suppression Measurement		
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF DEFault	Extend sideband suppression measurement (4 offset freq.) Sideband suppression measurement (1 offset frequency) Use the default setting	OFF	–	V3.10
Description of command				Sig. State
This command enables or disables the extended input and output arrays for the sideband suppression measurement, see commands CONFIGure:OVERview:OVERview:...LIMit..., READ[:SCALar]:OVERview:OVERview..., FETCh[:SCALar]:OVERview:OVERview..., SAMPlE[:SCALar]:OVERview:OVERview... and CALCulate[:SCALar]:OVERview:OVERview...MATCHing:LIMit.				All
The measurement of the upper and lower sideband suppression at the four offset frequencies can be enabled or disabled separately; see commands CONFIGure:OVERview:OVERview:<Application>:CONTrol:FOFFset:SBSuppress:ACP<nr>.				

Subsystem OVERview:OVERview:CONTrol

The subsystem *OVERview:OVERview:CONTrol* defines the repetition mode, statistic count, and stop condition of the measurement. These settings are provided in the *Control* and *Statistics* tabs of the popup menu *Overview Configuration*.

Note: The modulation scheme reference O-QPSK is optional in the commands to remain compatible with *cdmaOne*. O-QPSK supports radio configurations 1 and 2. H-PSK supports radio configurations 3 and 4.

CONFIGure:OVERview:OVERview[:OQPSk]:CONTrol[?] CONFIGure:OVERview:OVERview:HPSK:CONTrol[?] <Statistic Count>, <Repetition>, <Stop Cond>, <Step Mode>		Scope of Measurement		
<Statistic Count>	Description of parameters	Def. value	Def. unit	
1 to 1000,	Number of bursts per statistics cycle	100	–	
<Repetition>	Description of parameters	Def. value	Def. unit	
1 to 10000 CONTInuous SINGleshot DEFault,	Multiple measurement (counting, until Status = STEP RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Default setting	SING	–	
<Stop Cond>	Description of parameters	Def. value	Def. unit	
NONE SONerror DEFault,	Continue measurement even in case of error Stop measurement in case of error (<i>stop on error</i>) Default setting	NONE	–	
<Step Mode>	Description of parameters	Def. value	Def. unit	FW-Vers.
STEP NONE DEFault	Interrupt measurement after each statistics cycle Continue measurement according to its rep. Mode Default setting	NONE	–	V3.05
Description of command				Sig. State
This command combines the ...CONTrol:STATistics and the ...CONTrol:REPetition commands, see below.				All

CONFigure:OVERview:OVERview[:OQPSk]:CONTrol:STATistics[?] CONFigure:OVERview:OVERview:HPSK:CONTrol:STATistics[?] <Statistic Count>				Elapsed Statistic
<Statistic Count>	Description of parameters	Def. value	Def. unit	FW-Vers.
1 to 1000	Number of bursts per statistics cycle	100	–	V3.05
Description of command				Sig. State
This command specifies the type of measured values and defines the number of bursts forming a statistics cycle.				All

CONFigure:OVERview:OVERview[:OQPSk]:CONTrol:REPetition[?] CONFigure:OVERview:OVERview:HPSK:CONTrol:REPetition[?] <Repetition>, <Stop Cond>, <Step Mode>				Test Cycles
<Repetition>	Description of parameters	Def. value	Def. unit	
1 to 10000 CONTInuous SINGleshot DEFault,	Multiple measurement (counting, until Status = STEP RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Default value	SING	–	
<Stop Cond>	Description of parameters	Def. value	Def. unit	
NONE SONerror DEFault,	Continue measurement even in case of error Stop measurement in case of error (<i>stop on error</i>) Default value	NONE	–	
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
NONE STEP DEFault	Continue measurement according to its rep. mode Interrupt measurement after each statistics cycle Default value	NONE	–	V3.05
Description of command				Sig. State
This command determines the repetition mode, stop condition, and stepping mode for the measurement.				All
Note: <i>In the case of READ commands (READ:...), the <Repetition> parameter has no effect; the measurement is always stopped after a single shot.</i>				

CONFigure:OVERview:OVERview[:OQPSk]:CONTrol:FOFFset:SBSuppress[?] CONFigure:OVERview:OVERview:HPSK:CONTrol:FOFFset:SBSuppress[?] <SB Freq. Offset>				Injected Tx FER
<SB Freq. Offset>	Description of parameters	Def. value	Def. unit	FW vers.
–1.6 MHz to +1.6 MHz DEFault MINimum MAXimum OFF	Sideband Suppression Frequency Offset setting Default value No frequency offset	900000	Hz	V3.05
Description of command				Sig. State
This command determines a frequency offset to impair the signal for the sideband suppression measurement.				All

Sideband Frequency Offset				
CONFigure:OVERview:OVERview[:OQPSk]:CONTrol:FOFFset:SBSuppress:ACP<nr>[?]				
CONFigure:OVERview:OVERview:HPSK:CONTrol:FOFFset:SBSuppress:ACP<nr>[?]				
<Freq. Offset>				
<Freq. Offset>	Description of parameters	Def. value	Def. unit	FW vers.
0 to 2 MHz DEF MIN MAX OFF	Sideband frequency offset Sets the value to the default setting minimum maximum Measurement disabled, result INV	see below	Hz	V3.10
Description of command				
<p>This command sets up to 4 frequency offset values (<nr> = 1 to 4) used for the sideband suppression power measurement. The default values are 90 000 Hz for <nr> = 1, 1980 000 Hz for <nr> = 2 and OFF for the two remaining frequency offset values. The sideband suppression measurement yields 4 pairs of results corresponding to symmetrical frequency offsets to the RF frequency (command [SENSe:]RFANalyzer:FREQuency[?]).</p>				

Subsystem OVERview:OVERview:LIMit

The subsystem *OVERview:OVERview:...LIMit* defines the tolerance values for the overview measurement. The subsystem corresponds to the *Overview Limits* section in the *Limits* tab in the popup menu *Overview Configuration*.

Note: *The modulation scheme reference O-QPSK is optional in the commands to remain compatible with cdmaOne. O-QPSK supports radio configurations 1 and 2. H-PSK supports radio configurations 3 and 4.*

				Limits
CONFigure:OVERview:OVERview[:OQPSk]:CMMax:LIMit[:SCALar]:SYMMetric[:COMBined][?] CONFigure:OVERview:OVERview:HPSK:CMMax:LIMit[:SCALar]:SYMMetric[:COMBined][?] <Carrier Freq. Error>, <Enable>, <Transmit Time Error>, <Enable>, <Waveform Quality>, <Enable>, <Sideband Suppr. 1>, <Enable>, <Sideband Suppr. 2>, <Enable>, <Sideband Suppr. 3>, <Enable>, <Sideband Suppr. 4>, <Enable>				
<Enable>	Description of parameters	Def. value	Def. unit	
ON OFF,	Switch limit check for parameter preceding <Enable> on or off	ON	–	
<Carrier Freq. Error>	Description of parameters	Def. value	Def. unit	
0.0 Hz to +1000.0 Hz,	Upper limit for carrier frequency error	+300	Hz	
<Transmit Time Error>	Description of parameters	Def. value	Def. unit	
0.0 µs to 10.0 µs,	Upper limit for transmit time error	1.0	µs	
<Waveform Quality>	Description of parameters	Def. value	Def. unit	
0.0 to 1.0,	Lower limit for waveform quality	0.944	–	
<Sideband Suppr. 1>	Description of parameters	Def. value	Def. unit	FW vers.
–128 to 0,	Limit for sideband suppression at frequ. offset 1	–43	dB	V3.05
<Sideband Suppr. 2>	Description of parameters	Def. value	Def. unit	FW vers.
–128 dB to 0 dB,	Limit for sideband suppression at frequ. offset 2	–54	dB	V3.10
<Sideband Suppr. 3>	Description of parameters	Def. value	Def. unit	FW vers.
–128 dB to 0 dB,	Limit for sideband suppression at frequ. offset 3	–43	dB	V3.10
<Sideband Suppr. 4>	Description of parameters	Def. value	Def. unit	FW vers.
–128 dB to 0 dB	Limit for sideband suppression at frequ. offset 4	–43	dB	V3.10
Description of command				Sig. State
This command defines upper limits for the different traces and for the scalar modulation parameters derived from them. The keywords <i>CMMax</i> and <i>AVERage</i> refer to the <i>Current</i> and <i>Max./Min.</i> display and <i>Average</i> display, respectively. After each parameter definition, the limit check for this parameter can be enabled or disabled. The values <Sideband Suppr. 2>, <Sideband Suppr. 3>, <Sideband Suppr. 4> and the corresponding <Enable> parameters are only available if the sideband suppression extension is enabled; see command <i>XTND:OVERview:OVERview:<Application>:SBSuppress</i> . Limit definition and enabling of the limit check can be done separately.				All

				Limits
CONFigure:OVERview:OVERview[:OQPSk]:AVERage:LIMit[:SCALar]:SYMMetric[:COMBined][?] CONFigure:OVERview:OVERview:HPSK:AVERage:LIMit[:SCALar]:SYMMetric[:COMBined][?] <Carrier Freq. Error>, <Enable>, <Transmit Time Error>, <Enable>, <Waveform Quality>, <Enable>, <Sideband Suppr. 1>, <Enable>, <Sideband Suppr. 2>, <Enable>, <Sideband Suppr. 3>, <Enable>, <Sideband Suppr. 4>, <Enable>				
<Enable>	Description of parameters	Def. value	Def. unit	
ON OFF,	Switch limit check for parameter preceding <Enable> on or off	ON	–	
<Carrier Freq. Error>	Description of parameters	Def. value	Def. unit	
0.0 Hz to +1000.0 Hz,	Upper limit for carrier frequency error	+300	Hz	
<Transmit Time Error>	Description of parameters	Def. value	Def. unit	
0.0 µs to 10.0 µs,	Upper limit for transmit time error	1.0	µs	
<Waveform Quality>	Description of parameters	Def. value	Def. unit	
0.0 to 1.0,	Lower limit for waveform quality	0.944	–	
<Sideband Suppr. 1>	Description of parameters	Def. value	Def. unit	FW vers.
–128 to 0,	Limit for sideband suppression at frequ. offset 1	–43	dB	V3.05
<Sideband Suppr. 2>	Description of parameters	Def. value	Def. unit	FW vers.
–128 dB to 0 dB,	Limit for sideband suppression at frequ. offset 2	–54	dB	V3.10
<Sideband Suppr. 3>	Description of parameters	Def. value	Def. unit	FW vers.
–128 dB to 0 dB ,	Limit for sideband suppression at frequ. offset 3	–43	dB	V3.10
<Sideband Suppr. 4>	Description of parameters	Def. value	Def. unit	FW vers.
–128 dB to 0 dB	Limit for sideband suppression at frequ. offset 4	–43	dB	V3.10
Description of command				Sig. State
This command defines upper limits for the different traces and for the scalar modulation parameters derived from them. The keywords <i>CMMax</i> and <i>AVERage</i> refer to the <i>Current</i> and <i>Max./Min.</i> display and <i>Average</i> display, respectively. After each parameter definition, the limit check for this parameter can be enabled or disabled. The values <Sideband Suppr. 2>, <Sideband Suppr. 3>, <Sideband Suppr. 4> and the corresponding <Enable> parameters are only available if the sideband suppression extension is enabled; see command <i>XTND:OVERview:OVERview:<Application>:SBSuppress.</i>				All
Limit definition and enabling of the limit check can be done separately.				

				Limit Enable
CONFigure:OVERview:OVERview[:OQPSk]:CMMax:LIMit[:SCALar]:SYMMetric[:COMBined]:ENABLE[?] CONFigure:OVERview:OVERview:HPSK:CMMax:LIMit[:SCALar]:SYMMetric[:COMBined]:ENABLE[?] <Carrier Freq Error>, <Transmit Time Error>, <Waveform Quality>, <Sideband Suppr. 1>, <Sideband Suppr. 2>, <Sideband Suppr. 3>, <Sideband Suppr. 4>				
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	Switch limit check for corresponding parameter on or off.	ON	–	V3.05
Description of command				Sig. State
This command enables or disables the limit check for the different traces and for the scalar modulation parameters derived from them. The keywords <i>CMMax</i> and <i>AVERage</i> refer to the <i>Current</i> and <i>Max./Min.</i> display and <i>Average</i> display, respectively. The values <Sideband Suppr. 2>, <Sideband Suppr. 3>, <Sideband Suppr. 4> are only available if the sideband suppression extension is enabled; see command <i>XTND:OVERview:OVERview:<Application>:SBSuppress.</i>				All

				Limit Enable
CONFigure:OVERview:OVERview[:OQPSk]:AVERage:LIMit[:SCALar]:SYMMetric[:COMBined]:ENABLE[?] CONFigure:OVERview:OVERview:HPSK:AVERage:LIMit[:SCALar]:SYMMetric[:COMBined]:ENABLE[?] <Carrier Freq Error>, <Transmit Time Error>, <Waveform Quality>, <Sideband Suppr. 1>, <Sideband Suppr. 2>, <Sideband Suppr. 3>, <Sideband Suppr. 4>				
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	Switch limit check for corresponding parameter on or off.	ON	–	V3.05
Description of command				Sig. State
This command enables or disables the limit check for the different traces and for the scalar modulation parameters derived from them. The keywords <i>CMMax</i> and <i>AVERage</i> refer to the <i>Current</i> and <i>Max./Min.</i> display and <i>Average</i> display, respectively. The values <i><Sideband Suppr. 2></i> , <i><Sideband Suppr. 3></i> , <i><Sideband Suppr. 4></i> are only available if the sideband suppression extension is enabled; see command <i>XTND:OVERview:OVERview:<Application>:SBSuppress.</i>				All

				Overview Limits
CONFigure:OVERview:OVERview[:OQPSk]:CMMax:LIMit[:SCALar]:SYMMetric[:COMBined]:VALue[?] CONFigure:OVERview:OVERview:HPSK:CMMax:LIMit[:SCALar]:SYMMetric[:COMBined]:VALue[?] <Carrier Freq. Error>, <Transmit Time Error>, <Waveform Quality>, <Sideband Suppr. 1>, <Sideband Suppr. 2>, <Sideband Suppr. 3>, <Sideband Suppr. 4>				
<Carrier Freq. Error>	Description of parameters	Def. value	Def. unit	
0.0 Hz to +1000.0 Hz,	Upper limit for carrier frequency error	+300	Hz	
<Transmit Time Error>	Description of parameters	Def. value	Def. unit	
0.0 µs to 10.0 µs,	Upper limit for transmit time error	1.0	µs	
<Waveform Quality>	Description of parameters	Def. value	Def. unit	
0.0 to 1.0,	Lower limit for waveform quality	0.944	–	
<Sideband Suppr. 1>	Description of parameters	Def. value	Def. unit	FW vers.
–128 to 0	Upper sideband suppression limit	–43	dB	V3.05
<Sideband Suppr. 2>	Description of parameters	Def. value	Def. unit	FW vers.
–128 dB to 0 dB ,	Limit for sideband suppression at frequ. offset 2	–54	dB	V3.10
<Sideband Suppr. 3>	Description of parameters	Def. value	Def. unit	FW vers.
–128 dB to 0 dB,	Limit for sideband suppression at frequ. offset 3	–43	dB	V3.10
<Sideband Suppr. 4>	Description of parameters	Def. value	Def. unit	FW vers.
–128 dB to 0 dB	Limit for sideband suppression at frequ. offset 4	–43	dB	V3.10
Description of command				Sig. State
This commands defines the upper limits for the overview measurement. The keywords <i>CMMax</i> and <i>AVERage</i> refer to the <i>Current</i> and <i>Max./Min.</i> display and <i>Average</i> display, respectively. The values <i><Sideband Suppr. 2></i> , <i><Sideband Suppr. 3></i> , <i><Sideband Suppr. 4></i> are only available if the sideband suppression extension is enabled; see command <i>XTND:OVERview:OVERview:<Application>:SBSuppress.</i>				All

				Overview Limits
CONFigure:OVERview:OVERview[:OQPSk]:AVERage:LIMit[:SCALar]:SYMMetric[:COMBined]:VALue[?] CONFigure:OVERview:OVERview:HPSK:AVERage:LIMit[:SCALar]:SYMMetric[:COMBined]:VALue[?] <Carrier Freq Error>, <Transmit Time Error>, <Waveform Quality>, <Sideband Suppr. 1>, <Sideband Suppr. 2>, <Sideband Suppr. 3>, <Sideband Suppr. 4>				
<Carrier Freq. Error>	Description of parameters	Def. value	Def. unit	
0.0 Hz to +1000.0 Hz,	Upper limit for carrier frequency error	+300	Hz	
<Transmit Time Error>	Description of parameters	Def. value	Def. unit	
0.0 µs to 10.0 µs,	Upper limit for transmit time error	1.0	µs	
<Waveform Quality>	Description of parameters	Def. value	Def. unit	
0.0 to 1.0,	Lower limit for waveform quality	0.944	–	
<Sideband Suppr. 1>	Description of parameters	Def. value	Def. unit	FW vers.
–128 to 0	Upper sideband suppression limit	–43	dB	V3.05
<Sideband Suppr. 2>	Description of parameters	Def. value	Def. unit	FW vers.
–128 dB to 0 dB,	Limit for sideband suppression at frequ. offset 2	–54	dB	V3.10
<Sideband Suppr. 3>	Description of parameters	Def. value	Def. unit	FW vers.
–128 dB to 0 dB,	Limit for sideband suppression at frequ. offset 3	–43	dB	V3.10
<Sideband Suppr. 4>	Description of parameters	Def. value	Def. unit	FW vers.
–128 dB to 0 dB	Limit for sideband suppression at frequ. offset 4	–43	dB	V3.10
Description of command				Sig. State
This commands defines the upper limits for the overview measurement. The keywords <i>CMMax</i> and <i>AVERage</i> refer to the <i>Current</i> and <i>Max./Min.</i> display and <i>Average</i> display, respectively. The values <Sideband Suppr. 2>, <Sideband Suppr. 3>, <Sideband Suppr. 4> are only available if the sideband suppression extension is enabled; see command <code>XTND:OVERview:OVERview:<Application>:SBSuppress.</code>				All

				Default Settings
DEFault:OVERview:OVERview[:OQPSk]:LIMit[?] DEFault:OVERview:OVERview:HPSK:LIMit[?] <Enable>				
Enable	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	The parameters are set to their default values Some or all parameters are not set to default	ON	–	V3.05
Description of command				Sig. State
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystem <code>OVERview:OVERview:LIMit</code> to their default values (the setting <i>OFF</i> results in an error message). The length of the parameter lists in the commands is not affected.				All
If used as a query, the command returns whether all parameters are set to their default values (<i>ON</i>) or not (<i>OFF</i>).				

Measured Values – Subsystem OVERview:OVERview

The subsystem *OVERview:OVERview* determines and outputs the results of the overview measurement. In the *Overview* menu, it corresponds to the output fields associated to the *Overview Meas.* softkey.

Note: *The modulation scheme reference O-QPSK is optional in the commands to remain compatible with cdmaOne. O-QPSK supports radio configurations 1 and 2. H-PSK supports radio configurations 3 and 4.*

READ[:SCALar]:OVERview:OVERview[:OQPSK]? FETCh[:SCALar]:OVERview:OVERview[:OQPSK]? SAMPle[:SCALar]:OVERview:OVERview[:OQPSK]?		Scalar results: Start single shot measurement and return results Read out measurement results (unsynchronized) Read out measurement results (synchronized)		
READ[:SCALar]:OVERview:OVERview:HPSK? FETCh[:SCALar]:OVERview:OVERview:HPSK? SAMPle[:SCALar]:OVERview:OVERview:HPSK?		Start single shot measurement and return results Read out measurement results (unsynchronized) Read out measurement results (synchronized)		
Returned values	Description of parameters	Def. value	Def. unit	FW vers.
Expected MS Power (x1),	-100 dB to 10 dB	NAN	dBm	V3.05
Measured MS Power (x3),	-100 dB to 10 dB	NAN	dBm	
Expected Carrier Frequency (x1),	0 to 1000.0 Hz	NAN	MHz	
Carrier Frequency Error (x3),	0 to 1000.0 Hz	NAN	Hz	
Transmit Time Error (x3),	0.0 µs to 10.0 µs	NAN	µs	
Waveform Quality (x3),	0.0 to 1.0	NAN	-	
Lower Sideband Supp. 1 (x3),	-128 dB to 0	NAN	dB	
Upper Sideband Supp. 1 (x3)	-128 dB to 0	NAN	dB	
Lower Sideband Supp. 2 (x3),	-128 dB to 0	NAN	dB	V3.10
Upper Sideband Supp. 2 (x3)	-128 dB to 0	NAN	dB	V3.10
Lower Sideband Supp. 3 (x3),	-128 dB to 0	NAN	dB	V3.10
Upper Sideband Supp. 3 (x3)	-128 dB to 0	NAN	dB	V3.10
Lower Sideband Supp. 4 (x3),	-128 dB to 0	NAN	dB	V3.10
Upper Sideband Supp. 4 (x3)	-128 dB to 0	NAN	dB	V3.10
Description of command				Sig. State
These commands are always queries. They start a measurement and output all scalar measurement results (see Chapter 5). The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i> , the <i>Average</i> , and the <i>MMax</i> value. Sideband Supp. 1 to Sideband Supp. 4 denotes the sideband suppression at offset frequencies 1 to 4; see commands <code>CONFigure:OVERview:OVERview<Application>:CONTRol:FOFFset:SBSuppress:ACP<nr></code> . The sideband suppression values 2 to 4 are available only if the measurement is enabled; see commands <code>XTND:OVERview:OVERview: <Application>:SBSuppress</code> .				All

CALCulate[:SCALar]:OVERview:OVERview[:OQPSk]:MATChing:LIMit?				Limit Matching												
CALCulate[:SCALar]:OVERview:OVERview:HPSK:MATChing:LIMit?																
Returned values	Value range	Def. value	Def. unit	FW vers.												
Carrier Frequency Error (x3), Transmit Time Error (x3), Waveform Quality (x3), Lower Sideband Supp. 1 (x3), Upper Sideband Supp. 1 (x3), Lower Sideband Supp. 2 (x3), Upper Sideband Supp. 2 (x3), Lower Sideband Supp. 3 (x3), Upper Sideband Supp. 3 (x3), Lower Sideband Supp. 4 (x3), Upper Sideband Supp. 4 (x3)	For all values: NMAU NMAL INV OK	INV INV INV INV INV INV INV INV INV INV	– – – – – – – – – –	V3.05 V3.10 V3.10 V3.10 V3.10 V3.10 V3.10												
Description of command				Sig. State												
<p>This command is always a query. It indicates whether and in which way the tolerances for the overview measurement have been exceeded. The symbol (x3) behind a value indicates that the list contains three results corresponding to the <i>Current</i>, the <i>Average</i>, and the <i>MMax</i> value. The following messages may be generated:</p> <table border="0"> <tr> <td>NMAU</td> <td>Tolerance value underflow</td> <td><i>not matching, underflow</i></td> </tr> <tr> <td>NMAL</td> <td>Tolerance value exceeded</td> <td><i>not matching, overflow</i></td> </tr> <tr> <td>INV</td> <td>Measurement invalid</td> <td><i>invalid</i></td> </tr> <tr> <td>OK</td> <td>Tolerance value matched</td> <td></td> </tr> </table> <p>Sideband Supp. 1 to Sideband Supp. 4 denotes the sideband suppression at offset frequencies 1 to 4; see commands <code>CONFigure:OVERview:OVERview<Application>:CONTRol:FOFFset:SBSuppress:ACP<nr></code>. The sideband suppression values 2 to 4 are available only if the measurement is enabled; see commands <code>XTND:OVERview:OVERview:<Application>:SBSuppress</code>.</p>				NMAU	Tolerance value underflow	<i>not matching, underflow</i>	NMAL	Tolerance value exceeded	<i>not matching, overflow</i>	INV	Measurement invalid	<i>invalid</i>	OK	Tolerance value matched		All
NMAU	Tolerance value underflow	<i>not matching, underflow</i>														
NMAL	Tolerance value exceeded	<i>not matching, overflow</i>														
INV	Measurement invalid	<i>invalid</i>														
OK	Tolerance value matched															

OVERview:CQuality

The subsystem *OVERview:CQuality* controls the measurement of general channel quality parameters. It corresponds to the *Channel Quality* hotkey in the *Overview* menu and the associated output fields and to the *Channel Quality* sections of the *Overview Configuration* menu.

INITiate:OVERview:CQuality	Start new measurement	⇒	RUN
ABOrt:OVERview:CQuality	Abort running measurement and switch off	⇒	OFF
STOP:OVERview:CQuality	Stop measurement after current stat. cycle	⇒	STOP
CONTinue:OVERview:CQuality	Next measurement step (only stepping mode)	⇒	RUN
Description of command			Sig. State
These commands have no query form. They start and stop the overview measurement, setting it to the status indicated in the top right column.			All
			FW vers.
			V3.05

CONFigure:OVERview:CQQuality:EReporting[?]				Event Reporting
<Report Mode>				
<Report Mode>	Description of parameters	Def. value	Def. unit	FW vers.
SRQ	Service request	OFF	–	V3.05
SOPC	Single operation complete			
SRSQ	SRQ and SOPC			
OFF	No reporting			
DEFault				
Description of command				Sig. State
This command defines the events generated when the measurement is terminated or stopped (see <i>Event Reporting</i> in Chapter 5 of the CMU manual).				All

FETCh[:SCALar]:OVERview:CQQuality:STATus?				Measurement Status
Return	Description of parameters	Def. value	Def. unit	FW vers.
OFF	Measurement in the OFF state (*RST or ABORT)	OFF	–	V3.05
RUN	Running (after INITiate, CONTInue or READ)			
STOP	Stopped (STOP)			
ERR	OFF (could not be started)			
STEP	Stepping mode (<stepmode>=STEP)			
RDY	Stopped according to repetition mode and stop condition			
1 to 10000	Counter for current statistics cycle	NONE	–	
NONE	No counting mode set			
1 to 1000	Counter for current evaluation period within a cycle	NONE	–	
NONE	Statistic count set to off			
Description of command				Sig. State
This command is always a query. It returns the status of the measurement (see Chapters 3 and 5).				All

XTND:OVERview:CQQuality:CLEVel[?]				Provide Confidence Level Measurement
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON	Provide confidence level results	OFF	–	V3.10
OFF	Do not return the confidence level results			
DEFault	Use the default setting			
Description of command				Sig. State
This command enables or disables the extended output arrays for the confidence level measurement, see commands <code>READ[:SCALar]:OVERview:CQQuality?</code> , <code>FETCh[:SCALar]:OVERview:OVERview: CQQuality?</code> , <code>SAMPle[:SCALar]:OVERview:OVERview:CQQuality?</code> and <code>CALCulate[:SCALar]:OVERview::CQQuality:MATChing:LIMit.</code>				All

Subsystem OVERview:CQQuality:CONTRol

The subsystem *OVERview:CQQuality:CONTRol* defines the statistic count, repetition mode, and stop condition of the measurement. These settings are provided in the *Control* and *Limits* tabs of the popup menu *Overview Configuration*.

CONFigure:OVERview:CQQuality:CONTRol:FRAMes[?] <Max Frames>				Maximum Frame Number	
<Max Frames>	Description of parameters	Def. value	Def. unit	FW vers.	
1 to 10000	Maximum frames	1000	–	V3.05	
Description of command				Sig. State	
This command determines the maximum number of frames used to calculate the frame error rate.				All	

CONFigure:OVERview:CQQuality:CONTRol:REPetition[?] <Repetition>, <Stop Cond>, <Step Mode>				Test Cycles	
<Repetition>	Description of parameters	Def. value	Def. unit		
1 to 10000 CONTInuous SINGleshot DEFault,	Multiple measurement (<i>counting</i> , until Status = STEP RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY)	SING	–		
<Stop Cond>	Description of parameters	Def. value	Def. unit		
NONE SONerror DEFault,	Continue measurement even in case of error Stop measurement in case of error (<i>stop on error</i>)	NONE	–		
<Stop Cond>	Description of parameters	Def. value	Def. unit		
NONE ALEX CLEX FLEX DEFault,	Not aborted, measurement over all frames Measurement aborted if any limit is exceeded Measurement aborted if confidence level limit is exceeded Measurement aborted if frame limit is exceeded Sets the value to the default setting	NONE	–		
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.	
STEP NONE DEFault	Interrupt measurement after each statistics cycle Continue measurement according to its rep. mode	NONE	–	V3.05	
Description of command				Sig. State	
This command determines the repetition mode, stop condition, and stepping mode for the measurement.				All	
Note: In the case of READ commands (READ:...), the <Repetition> parameter has no effect; the measurement is always stopped after a single shot.					

Subsystem OVERview:CQQuality:LIMit

The subsystem *OVERview:CQQuality:...LIMit* defines the tolerance values for the overview measurement. The subsystem corresponds to the *Channel Quality* section in the *Limits* tab in the popup menu *Overview Configuration*.

--	--

CONFigure:OVERview:CQQuality:CAMMax:LIMit:MFER[?]		Maximum Frame Error Rate		
<Maximum FER>				
<Maximum FER>	Description of parameters	Def. value	Def. unit	FW vers.
0.1% to +5.0% OFF ON MIN MAX DEF	Upper limit for frame error rate Disable limit check Enable limit check Use minimum, maximum, or default value	0.5	%	V3.10
Description of command				Sig. State
This commands defines the upper limit for the frame error rate in the channel quality measurement.				All

CONFigure:OVERview:CQQuality:CAMMax:LIMit:CLeVel[?]		Minimum Confidence Level		
<Maximum FER>				
<Maximum FER>	Description of parameters	Def. value	Def. unit	FW vers.
85.0 % to +99.99 % OFF ON MIN MAX DEF	Upper limit for frame error rate Disable limit check Enable limit check Use minimum, maximum, or default value	95.0	%	V3.10
Description of command				Sig. State
This commands defines the lower limit for the confidence level in the channel quality measurement.				All

DEFault:OVERview:CQQuality:LIMit[?]		Limit Default Settings		
<Enable>				
Enable	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	The parameters are set to their default values Some or all parameters are not set to default	ON	–	V3.05
Description of command				Sig. State
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystem <i>OVERview:CQQuality:LIMit</i> to their default values (the setting <i>OFF</i> results in an error message).				All
If used as a query, the command returns whether all parameters are set to their default values (<i>ON</i>) or not (<i>OFF</i>).				

Measured Values – Subsystem OVERview:CQQuality

The subsystem *OVERview:CQQuality* determines and outputs the results of the channel quality measurement. In the *Overview* menu, it corresponds to the output fields associated to the *Channel Quality* hotkey.

READ[:SCALAr]:OVERview:CQQuality?		Scalar results:		
FETCh[:SCALAr]:OVERview:CQQuality?		Start single shot measurement and return results		
SAMPlE[:SCALAr]:OVERview:CQQuality?		Read out measurement results (unsynchronized)		
		Read out measurement results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
Frames transmitted,	1 to 1000	NAN	–	V3.05
Frame Error Rate	0% to 100%	NAN	%	V3.05
Confidence Level	0% to 100%	NAN	%	V3.10
Description of command				Sig. State
These commands are always queries. They start a measurement and output all scalar measurement results (see Chapter 5). The confidence level is available only if the measurement is enabled; see command XTND:OVERview:CQQuality:CLEVel.				All

CALCulate[:SCALAr]:OVERview:CQQuality:MATCHing:LIMit?		Limit Matching		
Returned values	Value range	Def. value	Def. unit	FW vers.
FER Limit,	For all values: NMAU NMAL INV OK	INV	–	V3.05
Confidence Level		INV	–	V3.10
Description of command				Sig. State
This command is always a query. It indicates whether and in which way the tolerances for the overview measurement have been exceeded. The confidence level is available only if the measurement is enabled; see command XTND:OVERview:CQQuality:CLEVel. The following messages may be generated:				All
NMAU	Tolerance value underflow	<i>not matching, underflow</i>		
NMAL	Tolerance value exceeded	<i>not matching, overflow</i>		
INV	Measurement invalid	<i>invalid</i>		
OK	Tolerance value matched			

Power Measurements

The *POWER* subsystem measures the transmitter output power of the mobile station. It is divided into several subsystems corresponding to the different *Power* applications.

POWER:MIOutput

The subsystem *POWER:MIOutput* measures the MS minimum output power. The subsystem corresponds to the measurement menu *Power*, application *Minimum Output*, and the sections related to this application in the associated popup menu *Power Configuration*.

Control of measurement – Subsystem POWER:MIOutput

The subsystem *POWER:MIOutput* controls the minimum output measurement.

Note: *The modulation scheme reference O-QPSK is optional in the commands to remain compatible with cdmaOne. O-QPSK supports radio configurations 1 and 2. H-PSK supports radio configurations 3 and 4.*

INITiate:POWER:MIOutput[:OQPSk]	Start new measurement	⇒	<i>RUN</i>
ABORt:POWER:MIOutput[:OQPSk]	Abort running measurement and switch off	⇒	<i>OFF</i>
STOP:POWER:MIOutput[:OQPSk]	Stop measurement after current stat. cycle	⇒	<i>STOP</i>
CONTinue:POWER:MIOutput[:OQPSk]	Next measurement step (only <i>stepping mode</i>)	⇒	<i>RUN</i>
INITiate:POWER:MIOutput:HPSK	Start new measurement	⇒	<i>RUN</i>
ABORt:POWER:MIOutput:HPSK	Abort running measurement and switch off	⇒	<i>OFF</i>
STOP:POWER:MIOutput:HPSK	Stop measurement after current stat. cycle	⇒	<i>STOP</i>
CONTinue:POWER:MIOutput:HPSK	Next measurement step (only <i>stepping mode</i>)	⇒	<i>RUN</i>
Description of command		Sig. State	FW vers.
These commands have no query form. They start and stop the power measurement, setting it to the status indicated in the top right column.		All	V3.05

CONFigure:POWER:MIOutput[:OQPSk]:EREPorting[?]		Event Reporting		
CONFigure:POWER:MIOutput:HPSK:EREPorting[?]				
<Report Mode>				
<Report Mode>	Description of parameters	Def. value	Def. unit	FW vers.
SRQ	Service request	OFF	–	V3.05
SOPC	Single operation complete			
SRSQ	SRQ and SOPC			
OFF	No reporting			
DEFault				
Description of command				Sig. State
This command defines the events generated when the measurement is terminated or stopped (see <i>Event Reporting</i> in Chapter 5 of the CMU manual).				All

FETCh[:SCALar]:POWer:MIOutput[:OQPSk]:STATus? FETCh[:SCALar]:POWer:MIOutput:HPSK:STATus?		Measurement Status		
Return	Description of parameters	Def. value	Def. unit	FW vers.
OFF RUN STOP ERR STEP RDY	Measurement in the OFF state (*RST or ABORT) Running (after INITiate, CONTinue or READ) Stopped (STOP) OFF (could not be started) Stepping mode (<stepmode>=STEP) Stopped according to repetition mode and stop condition	OFF	–	V3.05
1 to 10000 NONE	Counter for current statistics cycle No counting mode set	NONE	–	
1 to 1000 NONE	Counter for current evaluation period within a cycle Statistic count set to off	NONE	–	
Description of command				Sig. State
This command is always a query. It returns the status of the measurement (see Chapters 3 and 5).				All

Subsystem POWER:MIOutput:CONTRol

The subsystem *POWER:MIOutput:CONTRol* defines the repetition mode, statistic count, and stop condition of the measurement. These settings are provided in the *Control* and *Statistics* tabs in the popup menu *Power Configuration*.

Note: The modulation scheme reference *O-QPSK* is optional in the commands to remain compatible with *cdmaOne*. *O-QPSK* supports radio configurations 1 and 2. *H-PSK* supports radio configurations 3 and 4.

CONFigure:POWer:MIOutput[:OQPSK]:CONTRol[?] CONFigure:POWer:MIOutput:HPSK:CONTRol[?] <Statistics>, <Repetition>, <Stop Cond>, <Step Mode>		Scope of Measurement		
<Statistics>	Description of parameters	Def. value	Def. unit	
1 to 1000,	Number of bursts per statistics cycle	100	–	
<Repetition>	Description of parameters	Def. value	Def. unit	
1 to 10000 CONTInuous SINGleshot DEFault,	Multiple measurement (<i>counting</i> , until <i>Status = STEP RDY</i>) Continuous measurement (until <i>STOP</i> or <i>ABORT</i>) Single shot measurement (until <i>Status = RDY</i>)	SING	–	
<Stop Cond>	Description of parameters	Def. value	Def. unit	
NONE SONerror DEFault,	Continue measurement even in case of error Stop measurement in case of error (<i>stop on error</i>)	NONE	–	
<Step Mode>	Description of parameters	Def. value	Def. unit	FW-Vers.
STEP NONE DEFault	Interrupt measurement after each statistics cycle Continue measurement according to its rep. mode	NONE	–	V3.05
Description of command				Sig. State
This command combines the ...CONTRol:STATistics and the ...CONTRol:REPetition commands, see below.				All

CONFigure:POWer:MIOutput[:OQPSK]:CONTRol:STATistics[?] CONFigure:POWer:MIOutput:HPSK:CONTRol:STATistics[?] <Statistics>		Statistic Count		
<Statistics>	Description of parameters	Def. value	Def. unit	FW-Vers.
1 to 1000 NONE	Number of bursts per statistics cycle Statistics off (equivalent to 1)	100	–	V3.05
Description of command				Sig. State
This command specifies the number of bursts forming a statistics cycle.				All

CONFigure:POWer:MIOutput[:OQPSk]:CONTRol:REPetition[?] CONFigure:POWer:MIOutput:HPSK:CONTRol:REPetition[?] <Repetition>, <Stop Cond>, <Step Mode>				Test Cycles
<Repetition>	Description of parameters	Def. value	Def. unit	
1 to 10000 CONTInuous SINGleshot DEFault,	Multiple measurement (<i>counting</i> , until Status = STEP RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY)	SING	–	
<Stop Cond>	Description of parameters	Def. value	Def. unit	
NONE SONerror,	Continue measurement even in case of error Stop measurement in case of error (<i>stop on error</i>)	NONE	–	
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
STEP NONE	Interrupt measurement after each statistics cycle Continue measurement according to its rep. mode	NONE	–	V3.05
Description of command				Sig. State
This command determines the repetition mode, stop condition, and stepping mode for the measurement.				All
Note: In the case of READ commands (<i>READ:...</i>), the <Repetition> parameter has no effect; the measurement is always stopped after a single shot.				

Test Configuration

The subsystem *POWer:MIOutput:ENVIRONMENT...* configures the generated RF signal. It corresponds to the *Measurement Environment* section in the *Control* tab of the *Power Configuration* menu. The settings are used only if the environment is enabled; see *CONFigure:POWer:MIOutput:ENVIRONMENT:ENABLE*.

Note: The modulation scheme reference O-QPSK is optional in the commands to remain compatible with *cdmaOne*. O-QPSK supports radio configurations 1 and 2. H-PSK supports radio configurations 3 and 4.

CONFigure:POWer:MIOutput[:OQPSk]:ENVIRONMENT:ENABLE[?] CONFigure:POWer:MIOutput:HPSK:ENVIRONMENT:ENABLE[?] <Enable>				Environment Enable
<Enable>	Description of parameters	Def. Value	Def. Unit	FW vers.
ON OFF	Enable or disable environment	ON	–	V3.20
Description of command				Sig. State
These commands enable or disable the environment for the <i>Min. Power</i> measurement applications.				All

CONFigure:POWer:MIOutput[:OQPSk]:ENVironment:POWer:CDMA[?] CONFigure:POWer:MIOutput:HPSK:ENVironment:POWer:CDMA[?] <CDMA Power>				CDMA Power
<CDMA Power>	Description of parameters	Def. value	Def. unit	FW vers.
-120.0 dBm to -33.0 dBm -120.0 dBm to -16.0 dBm -100.0 dBm to +7.0 dBm DEFault MINimum MAXimum	RF1 OUT, 0 dB ext. atten RF2 OUT, 0 dB ext. atten RF3 OUT, 0 dB ext. atten Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum	-25.0	dBm	V3.20
Description of command				Sig. State
These commands determine the total CDMA output power (absolute value, in dBm) of the CMU. The CDMA Power value range depends on the RF input used and the external attenuation set. If option R&S CMU-U99 (RF 1 with RF 2 Level Range) is fitted, RF 1 takes on the level range of RF2.				All

CONFigure:POWer:MIOutput[:OQPSk]:ENVironment:LEVel:FPICH[?] CONFigure:POWer:MIOutput:HPSK:ENVironment:LEVel:FPICH[?] <Pilot Level>				F-PICH Level
<Pilot Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to -1.0 dB OFF	Pilot Level F-PICH switched off	-7.0	dB	V3.20
Description of command				Sig. State
These commands determine the level in the forward pilot channel of the CMU. The channel power is in units relative to the total CDMA power.				All

CONFigure:POWer:MIOutput[:OQPSk]:ENVironment:LEVel:FFCH[?] CONFigure:POWer:MIOutput:HPSK:ENVironment:LEVel:FFCH[?] <FCH Level>				F-FCH Level
<FCH Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to -1.0 dB OFF	FCH Level F-FCH switched off	-7.4	dB	V3.20
Description of command				Sig. State
These commands determines the level in the forward fundamental channel of the CMU. The channel power is in units relative to the total CDMA power.				All

CONFigure:POWer:MIOutput[:OQPSk]:ENVironment:LEVel:FSCH:ZERO[?] CONFigure:POWer:MIOutput:HPSK:ENVironment:LEVel:FSCH:ZERO[?] <SCH0 Level>				F-SCH0 Level
<SCH0 Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to -1.0 dB OFF	F-SCH0 Level F-SCH0 switched off	-7	dB	V3.20
Description of command				Sig. State
These commands determine the level in the forward SCH0 channel of the CMU. The channel power is in units relative to the total CDMA power.				All

CONFigure:POWer:MIOutput[:OQPSk]:ENVIRONMENT:LEVel:FSCH:ONE[?]				F-SCH1 Level
CONFigure:POWer:MIOutput:HPSK:ENVIRONMENT:LEVel:FSCH:ONE[?]				
<SCH1 Level>				
<SCH1 Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to -1.0 dB OFF	F-SCH1 Level F-SCH1 switched off	-7	dB	V3.20
Description of command				Sig. State
These commands determine the level in the forward SCH1 channel of the CMU. The channel power is in units relative to the total CDMA power.				All

CONFigure:POWer:MIOutput[:OQPSk]:ENVIRONMENT:EBNT:FFCH?				F-FCH Eb/Nt
CONFigure:POWer:MIOutput:HPSK:ENVIRONMENT:EBNT:FFCH?				
<Eb/Nt>				
<Eb/Nt>	Description of parameters	Def. value	Def. unit	FW vers.
-30.969 dB to 18.072 dB	Calculated F-FCH Eb/Nt	-	dB	V3.20
Description of command				Sig. State
These commands are always queries. They return the calculated signal to noise ratio for the forward FCH. This quantity is undefined unless the AWGN generator is turned on (CONFigure:POWer:MIOutput[:OQPSk]:ENVIRONMENT:IMPAIRMENTS:LEVel:AWGN). The quoted range of values is valid for data rates between 9.6 kbps and 153.6 kbps; see <i>Eb/Nt Calculation</i> in Chapter 4.				All

CONFigure:POWer:MIOutput:HPSK:ENVIRONMENT:EBNT:FSCH:ZERO?				F-SCH0 Eb/Nt
CONFigure:POWer:MIOutput[:OQPSk]:ENVIRONMENT:EBNT:FSCH:ZERO?				
<Eb/Nt>				
<Eb/Nt>	Description of parameters	Def. value	Def. unit	FW vers.
-30.969 dB to 18.072 dB	Calculated F-SCH0 Eb/Nt	-	dB	V3.20
Description of command				Sig. State
These commands are always queries. They return the calculated signal to noise ratio for the forward SCH0. This quantity is undefined unless the AWGN generator is turned on (CONFigure:POWer:MIOutput:HPSK:ENVIRONMENT:IMPAIRMENTS:LEVel:AWGN). The quoted range of values is valid for data rates between 9.6 kbps and 153.6 kbps; see <i>Eb/Nt Calculation</i> in Chapter 4.				All

CONFigure:POWer:MIOutput[:OQPSk]:ENVIRONMENT:EBNT:FSCH:ONE?				F-SCH1 Eb/Nt
CONFigure:POWer:MIOutput:HPSK:ENVIRONMENT:EBNT:FSCH:ONE?				
<Eb/Nt>				
<Eb/Nt>	Description of parameters	Def. value	Def. unit	FW vers.
-30.969 dB to 18.072 dB	Calculated F-SCH1 Eb/Nt	-	dB	V3.20
Description of command				Sig. State
These commands are always queries. They return the calculated signal to noise ratio for the forward SCH1. This quantity is undefined unless the AWGN generator is turned on (CONFigure:POWer:MIOutput[:OQPSk]:ENVIRONMENT:IMPAIRMENTS:LEVel:AWGN). The quoted range of values is valid for data rates between 9.6 kbps and 153.6 kbps; see <i>Eb/Nt Calculation</i> in Chapter 4.				All

CONFigure:POWer:MIOutput[:OQPSk]:ENVironment:FRATe:FFCH[?]				Frame Rate
CONFigure:POWer:MIOutput:HPSK:ENVironment:FRATe:FFCH[?]				
<Frame Rate>				
<Frame Rate>	Description of parameters	Def. value	Def. unit	FW vers.
EIGHth QUARter HALF FULL DEFault	Frames at 1/8 of the rate set Frames at 1/4 of the rate set Frames at 1/2 of the rate set Frames at the full rate set	FULL	–	V3.20
Description of command				Sig. State
These commands set the frame rate for the variable rate traffic channel.				All

CONFigure:POWer:MIOutput[:OQPSk]:ENVironment:IMPairments:LEVel:AWGN[?]				AWGN Level
CONFigure:POWer:MIOutput:HPSK:ENVironment:IMPairments:LEVel:AWGN[?]				
<AWGN Level>				
<AWGN Level>	Description of parameters	Def. value	Def. unit	FW vers.
–20.0 dB to +4.0 dB DEFault MINimum MAXimum OFF,	AWGN level Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum	OFF	dB	V3.20
Description of command				Sig. State
These commands determine an Additional White Gaussian Noise level to impair the CMU output signal.				All

CONFigure:POWer:MIOutput[:OQPSk]:ENVironment:IMPairments:FOFFset[?]				BS Frequency Offset
CONFigure:POWer:MIOutput:HPSK:ENVironment:IMPairments:FOFFset[?]				
<BS Freq Offset>				
<BS Freq Offset>	Description of parameters	Def. value	Def. unit	FW vers.
–50.0 kHz to +50.0 kHz DEFault MINimum MAXimum OFF	BS frequency offset Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum	OFF	Hz	V3.20
Description of command				Sig. State
These commands determine a frequency offset to impair the CMU output signal.				All

CONFigure:POWer:MIOutput[:OQPSk]:ENVIRONMENT:IMPairments:ITFer[?] CONFigure:POWer:MIOutput:HPSK:ENVIRONMENT:IMPairments:ITFer[?] <FER>				Injected Tx FER
<FER>	Description of parameters	Def. value	Def. unit	FW vers.
0% to 50% OFF ON	Injected Tx FER Switch FER injection off (equiv. to 0%) Re-activate FER injection, using the previously defined value	OFF	–	V3.20
Description of command				Sig. State
These commands define a percentage of faulty (i.e. erasure) frames that the CMU injects into all traffic channels of its BS Signal.				All

CONFigure:POWer:MIOutput[:OQPSk]:ENVIRONMENT:PCBits? CONFigure:POWer:MIOutput:HPSK:ENVIRONMENT:PCBits? <Power Control Bits>				Power Control Bits
Response	Description of parameters	Def. value	Def. unit	FW vers.
ADOW	All power control bits down	–	–	V3.20
Description of command				Sig. State
These commands are always queries. They return the fixed Power Control Bit sequence of the <i>Min. Power</i> application.				All

Subsystem POWER:MIOutput:LIMit

The subsystem *POWER:MIOutput:LIMit* defines the tolerance values for the minimum output measurement. The subsystem corresponds to the *Minimum Power* section in the *Limits* tab of the *Power Configuration* popup menu.

Note: *The modulation scheme reference O-QPSK is optional in the commands to remain compatible with cdmaOne. O-QPSK supports radio configurations 1 and 2. H-PSK supports radio configurations 3 and 4.*

CONFigure:POWer:MIOutput[:OQPSk]:CAMMax:LIMit[:SCALar]:ASYMmetric[:COMBined]:VALue[?] CONFigure:POWer:MIOutput:HPSK:CAMMax:LIMit[:SCALar]:ASYMmetric[:COMBined]:VALue[?] <Absolute Min Power>, <Waveform Quality>				Minimum Output Limits
<Absolute Min Power>	Description of parameters	Def. value	Def. unit	
–128.0 dBm to 0.0 dBm,	Upper limit for absolute min. power	–50	dBm	
<Waveform Quality>	Description of parameters	Def. value	Def. unit	FW vers.
0.0 to 1.0	Lower limit for waveform quality	0.944	–	V3.05
Description of command				Sig. State
This commands defines the tolerance limits for the minimum output measurement. The limits apply to all measurement curves (<i>Current, Average, Minimum, Maximum</i>).				All

DEFault:POWer:MIOutput[:OQPSk]:LIMit[?] DEFault:POWer:MIOutput:HPSK:LIMit[?]		Limits Default Settings		
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	The parameters are set to their default values Some or all parameters are not set to default	ON	–	V3.05
Description of command				Sig. State
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystem <i>POWER:MIOutput:LIMit</i> to their default values (the setting <i>OFF</i> results in an error message).				All
If used as a query the command returns whether all parameters are set to their default values (<i>ON</i>) or not (<i>OFF</i>).				

Measured Values – Subsystem *POWER:MIOutput*

The subsystem *POWER:MIOutput* determines and outputs the results of the *Minimum Output* measurement. They correspond to the measurement menu *Power*, application *Minimum Output*, with its various display elements.

Note: *The modulation scheme reference O-QPSK is optional in the commands to remain compatible with cdmaOne. O-QPSK supports radio configurations 1 and 2. H-PSK supports radio configurations 3 and 4.*

READ[:SCALar]:POWer:MIOutput[:OQPSk]? FETCh[:SCALar]:POWer:MIOutput[:OQPSK]? SAMPle[:SCALar]:POWer:MIOutput[:OQPSk]?		Scalar results:		
		Start single shot measurement and return results		
		Read out measurement results (unsynchronized)		
		Read out measurement results (synchronized)		
READ[:SCALar]:POWer:MIOutput:HPSK? FETCh[:SCALar]:POWer:MIOutput:HPSK? SAMPle[:SCALar]:POWer:MIOutput:HPSK?		Start single shot measurement and return results		
		Read out measurement results (unsynchronized)		
		Read out measurement results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
Total Power Current, Total Power Average, Total Power Minimum, Total Power Maximum,	–100.0 dBm to –50.0 dBm	NAN	dBm	V3.05
	–100.0 dBm to –50.0 dBm	NAN	dBm	
	–100.0 dBm to –50.0 dBm	NAN	dBm	
	–100.0 dBm to –50.0 dBm	NAN	dBm	
Waveform Quality Current, Waveform Quality Average, Waveform Quality Minimum, Waveform Quality Maximum,	0.0 to 1.0	NAN	–	
	0.0 to 1.0	NAN	–	
	0.0 to 1.0	NAN	–	
	0.0 to 1.0	NAN	–	
Measurements out of Tolerance	0.0% to 100.0%	NAN	%	
Description of command				Sig. State
These commands are always queries. They start a measurement and output all scalar measurement results.				All

CALCulate[:SCALar]:POWER:MIOutput[:OQPSk]:MATChing:LIMit? CALCulate[:SCALar]:POWER:MIOutput:HPSK:MATChing:LIMit?				Limit Matching
Returned values	Value range	Def. value	Def. unit	FW vers.
Total Power Current, Total Power Average, Total Power Minimum, Total Power Maximum, Waveform Quality Current, Waveform Quality Average, Waveform Quality Minimum, Waveform Quality Maximum	For all values NMAU NMAL INV OK	INV INV INV INV INV INV INV	– – – – – – –	V3.05
Description of command				Sig. State
This command is always a query. It indicates whether and in which way the (fixed) limit lines have been exceeded. The following messages may be generated:				All
NMAU	Tolerance value underflow	<i>not matching, underflow</i>		
NMAL	Tolerance value exceeded	<i>not matching, overflow</i>		
INV	Measurement invalid	<i>invalid</i>		
OK	Tolerance value matched			

POWER:MAOutput

The subsystem *POWER:MAOutput* measures the MS maximum output power. The subsystem corresponds to the measurement menu *Power*, application *Maximum Output*, and the sections related to this application in the associated popup menu *Power Configuration*.

Control of measurement – Subsystem POWER:MAOutput

The subsystem *POWER:MAOutput* controls the maximum output measurement.

Note: *The modulation scheme reference O-QPSK is optional in the commands to remain compatible with cdmaOne. O-QPSK supports radio configurations 1 and 2. H-PSK supports radio configurations 3 and 4.*

INITiate:POWER:MAOutput[:OQPSk]	Start new measurement	⇒	<i>RUN</i>
ABORT:POWER:MAOutput[:OQPSk]	Abort running measurement and switch off	⇒	<i>OFF</i>
STOP:POWER:MAOutput[:OQPSk]	Stop measurement after current stat. cycle	⇒	<i>STOP</i>
CONTinue:POWER:MAOutput[:OQPSk]	Next measurement step (<i>stepping mode</i>)	⇒	<i>RUN</i>
INITiate:POWER:MAOutput:HPSK	Start new measurement	⇒	<i>RUN</i>
ABORT:POWER:MAOutput:HPSK	Abort running measurement and switch off	⇒	<i>OFF</i>
STOP:POWER:MAOutput:HPSK	Stop measurement after current stat. cycle	⇒	<i>STOP</i>
CONTinue:POWER:MAOutput:HPSK	Next measurement step (<i>stepping mode</i>)	⇒	<i>RUN</i>
Description of command			Sig. State
These commands have no query form. They start and stop the power measurement, setting it to the status indicated in the top right column.			All
			FW vers.
			V3.05

CONFigure:POWer:MAOutput[:OQPSk]:EREPorting[?] CONFigure:POWer:MAOutput:HPSK:EREPorting[?] <Report Mode>				Event Reporting
<Report Mode>	Description of parameters	Def. value	Def. unit	FW vers.
SRQ	Service request	OFF	–	V3.05
SOPC	Single operation complete			
SRSQ	SRQ and SOPC			
OFF	No reporting			
DEFAult				
Description of command				Sig. State
This command defines the events generated when the measurement is terminated or stopped (see <i>Event Reporting</i> in Chapter 5 of the CMU manual).				All

FETCh[:SCALar]:POWer:MAOutput[:OQPSk]:STATus? FETCh[:SCALar]:POWer:MAOutput:HPSK:STATus?				Measurement Status
Return	Description of parameters	Def. value	Def. unit	FW vers.
OFF	Measurement in the OFF state (*RST or ABORT)	OFF	–	V3.05
RUN	Running (after INITiate, CONTinue or READ)			
STOP	Stopped (STOP)			
ERR	OFF (could not be started)			
STEP	Stepping mode (<stepmode>=STEP)			
RDY	Stopped according to repetition mode and stop condition			
1 to 10000	Counter for current statistics cycle	NONE	–	
NONE	No counting mode set			
1 to 1000	Counter for current evaluation period within a cycle	NONE	–	
NONE	Statistic count set to off			
Description of command				Sig. State
This command is always a query. It returns the status of the measurement (see Chapters 3 and 5).				All

Subsystem POWER:MAOutput:CONTRol

The subsystem *POWER:MAOutput:CONTRol* defines the repetition mode, statistic count, and stop condition of the measurement. These settings are provided in the *Control* and *Statistics* tabs in the pop-up menu *Power Configuration*.

Note: *The modulation scheme reference O-QPSK is optional in the commands to remain compatible with cdmaOne. O-QPSK supports radio configurations 1 and 2. H-PSK supports radio configurations 3 and 4.*

CONFigure:POWer:MAOutput[:OQPSk]:CONTRol[?] CONFigure:POWer:MAOutput:HPSK:CONTRol[?] <Statistic Count>, <Repetition>, <Stop Cond>, <Step Mode>				Scope of Measurement
<Statistic Count>	Description of parameters	Def. value	Def. unit	
1 to 1000,	Number of bursts per statistics cycle	100	–	
<Repetition>	Description of parameters	Def. value	Def. unit	
1 to 10000 CONTInuous SINGleshot DEFault,	Multiple measurement (<i>counting</i> , until Status = STEP RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY)	SING	–	
<Stop Cond>	Description of parameters	Def. value	Def. unit	
NONE SONerror DEFault,	Continue measurement even in case of error Stop measurement in case of error (<i>stop on error</i>)	NONE	–	
<Step Mode>	Description of parameters	Def. value	Def. unit	FW-Vers.
STEP NONE DEFault	Interrupt measurement after each statistics cycle Continue measurement according to its rep. mode	NONE	–	V3.05
Description of command				Sig. State
This command combines the ...CONTRol:STATistics and the ...CONTRol:REPetition commands, see below.				All

CONFigure:POWer:MAOutput[:OQPSk]:CONTRol:STATistics[?] CONFigure:POWer:MAOutput:HPSK:CONTRol:STATistics[?] <Statistic Count >				Scope of Measurement
<Statistic Count>	Description of parameters	Def. value	Def. unit	FW-Vers.
1 to 1000	Number of bursts per statistics cycle	100	–	V3.05
Description of command				Sig. State
This command specifies the number of bursts forming a statistics cycle.				All

CONFigure:POWer:MAOutput[:OQPSk]:CONTRol:REPetition[?] CONFigure:POWer:MAOutput:HPSK:CONTRol:REPetition[?] <Repetition>, <Stop Cond>, <Step Mode>				Test Cycles
<Repetition>	Description of parameters	Def. value	Def. unit	
1 to 10000 CONTInuous SINGleshot DEFault,	Multiple measurement (<i>counting</i> , until Status = STEP RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY)	SING	–	
<Stop Cond>	Description of parameters	Def. value	Def. unit	
NONE SONerror DEFault,	Continue measurement even in case of error Stop measurement in case of error (<i>stop on error</i>)	NONE	–	
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
STEP NONE DEFault	Interrupt measurement after each statistics cycle Continue measurement according to its rep. mode	NONE	–	V3.05
Description of command				Sig. State
This command determines the repetition mode, stop condition, and stepping mode for the measurement.				All
Note: <i>In the case of READ commands (READ:...), the <Repetition> parameter has no effect; the measurement is always stopped after a single shot.</i>				

Test Configuration

The subsystem *POWer:MAOutput:ENVironment...* configures the generated RF signal. It corresponds to the *Measurement Environment* section in the *Control* tab of the *Power Configuration* menu. The settings are used only if the environment is enabled; see *CONFigure:POWer:MAOutput:ENVironment:ENABLE*.

Note: *The modulation scheme reference O-QPSK is optional in the commands to remain compatible with cdmaOne. O-QPSK supports radio configurations 1 and 2. H-PSK supports radio configurations 3 and 4.*

CONFigure:POWer:MAOutput[:OQPSk]:ENVironment:ENABLE[?] CONFigure:POWer:MAOutput:HPSK:ENVironment:ENABLE[?] <Enable>				Environment Enable
<Enable>	Description of parameters	Def. Value	Def. Unit	FW vers.
ON OFF	Enable or disable environment	ON	–	V3.20
Description of command				Sig. State
These commands enable or disable the environment for the <i>Max. Power</i> measurement applications.				All

CONFigure:POWer:MAOutput[:OQPSk]:ENVironment:POWer:CDMA[?] CONFigure:POWer:MAOutput:HPSK:ENVironment:POWer:CDMA[?] <CDMA Power>				CDMA Power
<CDMA Power>	Description of parameters	Def. value	Def. unit	FW vers.
-120.0 dBm to -33.0 dBm -120.0 dBm to -16.0 dBm -100.0 dBm to +7.0 dBm DEFault MINimum MAXimum	RF1 OUT, 0 dB ext. atten RF2 OUT, 0 dB ext. atten RF3 OUT, 0 dB ext. atten Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum	-104.0	dBm	V3.20
Description of command				Sig. State
These commands determine the total CDMA output power (absolute value, in dBm) of the CMU. The CDMA Power value range depends on the RF input used and the external attenuation set. If option R&S CMU-U99 (RF 1 with RF 2 Level Range) is fitted, RF 1 takes on the level range of RF2.				All

CONFigure:POWer:MAOutput[:OQPSk]:ENVironment:LEVel:FPiCh[?] CONFigure:POWer:MAOutput:HPSK:ENVironment:LEVel:FPiCh[?] <Pilot Level>				F-PICH Level
<Pilot Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to -1.0 dB OFF	Pilot Level F-PICH switched off	-7.0	dB	V3.20
Description of command				Sig. State
These commands determine the level in the forward pilot channel of the CMU. The channel power is in units relative to the total CDMA power.				All

CONFigure:POWer:MAOutput[:OQPSk]:ENVironment:LEVel:FFCH[?] CONFigure:POWer:MAOutput:HPSK:ENVironment:LEVel:FFCH[?] <FCH Level>				F-FCH Level
<FCH Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to -1.0 dB OFF	FCH Level F-FCH switched off	-7.4	dB	V3.20
Description of command				Sig. State
These commands determines the level in the forward fundamental channel of the CMU. The channel power is in units relative to the total CDMA power.				All

CONFigure:POWer:MAOutput[:OQPSk]:ENVironment:LEVel:FSCH:ZERO[?] CONFigure:POWer:MAOutput:HPSK:ENVironment:LEVel:FSCH:ZERO[?] <SCH0 Level>				F-SCH0 Level
<SCH0 Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to -1.0 dB OFF	F-SCH0 Level F-SCH0 switched off	-7	dB	V3.20
Description of command				Sig. State
These commands determine the level in the forward SCH0 channel of the CMU. The channel power is in units relative to the total CDMA power.				All

CONFigure:POWer:MAOutput[:OQPSk]:ENVIRONMENT:LEVel:FSCH:ONE[?]				F-SCH1 Level
CONFigure:POWer:MAOutput:HPSK:ENVIRONMENT:LEVel:FSCH:ONE[?]				
<SCH1 Level>				
<SCH1 Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to -1.0 dB OFF	F-SCH1 Level F-SCH1 switched off	-7	dB	V3.20
Description of command				Sig. State
These commands determine the level in the forward SCH1 channel of the CMU. The channel power is in units relative to the total CDMA power.				All

CONFigure:POWer:MAOutput[:OQPSk]:ENVIRONMENT:EBNT:FFCH?				F-FCH Eb/Nt
CONFigure:POWer:MAOutput:HPSK:ENVIRONMENT:EBNT:FFCH?				
<Eb/Nt>				
<Eb/Nt>	Description of parameters	Def. value	Def. unit	FW vers.
-30.969 dB to 18.072 dB	Calculated F-FCH Eb/Nt	-	dB	V3.20
Description of command				Sig. State
These commands are always queries. They return the calculated signal to noise ratio for the forward FCH. This quantity is undefined unless the AWGN generator is turned on (CONFigure:POWer:MAOutput[:OQPSk]:ENVIRONMENT:IMPAIRMENTS:LEVel:AWGN). The quoted range of values is valid for data rates between 9.6 kbps and 153.6 kbps; see <i>Eb/Nt Calculation</i> in Chapter 4.				All

CONFigure:POWer:MAOutput:HPSK:ENVIRONMENT:EBNT:FSCH:ZERO?				F-SCH0 Eb/Nt
CONFigure:POWer:MAOutput[:OQPSk]:ENVIRONMENT:EBNT:FSCH:ZERO?				
<Eb/Nt>				
<Eb/Nt>	Description of parameters	Def. value	Def. unit	FW vers.
-30.969 dB to 18.072 dB	Calculated F-SCH0 Eb/Nt	-	dB	V3.20
Description of command				Sig. State
These commands are always queries. They return the calculated signal to noise ratio for the forward SCH0. This quantity is undefined unless the AWGN generator is turned on (CONFigure:POWer:MAOutput:HPSK:ENVIRONMENT:IMPAIRMENTS:LEVel:AWGN). The quoted range of values is valid for data rates between 9.6 kbps and 153.6 kbps; see <i>Eb/Nt Calculation</i> in Chapter 4.				All

CONFigure:POWer:MAOutput[:OQPSk]:ENVIRONMENT:EBNT:FSCH:ONE?				F-SCH1 Eb/Nt
CONFigure:POWer:MAOutput:HPSK:ENVIRONMENT:EBNT:FSCH:ONE?				
<Eb/Nt>				
<Eb/Nt>	Description of parameters	Def. value	Def. unit	FW vers.
-30.969 dB to 18.072 dB	Calculated F-SCH1 Eb/Nt	-	dB	V3.20
Description of command				Sig. State
These commands are always queries. They return the calculated signal to noise ratio for the forward SCH1. This quantity is undefined unless the AWGN generator is turned on (CONFigure:POWer:MAOutput[:OQPSk]:ENVIRONMENT:IMPAIRMENTS:LEVel:AWGN). The quoted range of values is valid for data rates between 9.6 kbps and 153.6 kbps; see <i>Eb/Nt Calculation</i> in Chapter 4.				All

CONFigure:POWer:MAOutput[:OQPSk]:ENVIRONMENT:FRATe:FFCH[?]				Frame Rate
CONFigure:POWer:MAOutput:HPSK:ENVIRONMENT:FRATe:FFCH[?]				
<Frame Rate>				
<Frame Rate>	Description of parameters	Def. value	Def. unit	FW vers.
EIGHth QUARter HALF FULL DEFault	Frames at 1/8 of the rate set Frames at 1/4 of the rate set Frames at 1/2 of the rate set Frames at the full rate set	FULL	–	V3.20
Description of command				Sig. State
These commands set the frame rate for the variable rate traffic channel.				All

CONFigure:POWer:MAOutput[:OQPSk]:ENVIRONMENT:IMPairments:LEVel:AWGN[?]				AWGN Level
CONFigure:POWer:MAOutput:HPSK:ENVIRONMENT:IMPairments:LEVel:AWGN[?]				
<AWGN Level>				
<AWGN Level>	Description of parameters	Def. value	Def. unit	FW vers.
–20.0 dB to +4.0 dB DEFault MINimum MAXimum OFF,	AWGN level Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum	OFF	dB	V3.20
Description of command				Sig. State
These commands determine an Additional White Gaussian Noise level to impair the CMU output signal.				All

CONFigure:POWer:MAOutput[:OQPSk]:ENVIRONMENT:IMPairments:FOFFset[?]				BS Frequency Offset
CONFigure:POWer:MAOutput:HPSK:ENVIRONMENT:IMPairments:FOFFset[?]				
<BS Freq Offset>				
<BS Freq Offset>	Description of parameters	Def. value	Def. unit	FW vers.
–50.0 kHz to +50.0 kHz DEFault MINimum MAXimum OFF	BS frequency offset Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum	OFF	Hz	V3.20
Description of command				Sig. State
These commands determine a frequency offset to impair the CMU output signal.				All

CONFigure:POWer:MAOutput[:OQPSk]:ENVIRONMENT:IMPairments:ITFer[?] CONFigure:POWer:MAOutput:HPSK:ENVIRONMENT:IMPairments:ITFer[?] <FER>				Injected Tx FER
<FER>	Description of parameters	Def. value	Def. unit	FW vers.
0% to 50% OFF ON	Injected Tx FER Switch FER injection off (equiv. to 0%) Re-activate FER injection, using the previously defined value	OFF	–	V3.20
Description of command				Sig. State
These commands define a percentage of faulty (i.e. erasure) frames that the CMU injects into all traffic channels of its BS Signal.				All

CONFigure:POWer:MAOutput[:OQPSk]:ENVIRONMENT:PCBits? CONFigure:POWer:MAOutput:HPSK:ENVIRONMENT:PCBits? <Power Control Bits>				Power Control Bits
Response	Description of parameters	Def. value	Def. unit	FW vers.
AUP	All power control bits up	–	–	V3.20
Description of command				Sig. State
These commands are always queries. They return the fixed Power Control Bit sequence of the <i>Max. Power</i> application.				All

Subsystem POWER:MAOutput:LIMit

The subsystem *POWER:MAOutput:LIMit* defines the tolerance values for the maximum output measurement. The subsystem corresponds to the *Maximum Output* section in the *Limits* tab of the *Power Configuration* popup menu.

Note: *The modulation scheme reference O-QPSK is optional in the commands to remain compatible with cdmaOne. O-QPSK supports radio configurations 1 and 2. H-PSK supports radio configurations 3 and 4.*

CONFigure:POWer:MAOutput[:OQPSk]:CAMMax:LIMit[:SCALAr]:ASYMmetric[:COMBined]:VALue[?] CONFigure:POWer:MAOutput:HPSK:CAMMax:LIMit[:SCALAr]:ASYMmetric[:COMBined]:VALue[?] <Absolute Max Power>, <Upper Limit>, <Lower Limit>, <Waveform Quality>				Output Limits
<Absolute Max Power>	Description of parameters	Def. value	Def. unit	
0.0 dBm to +128.0 dBm,	Absolute maximum power	23.0	dBm	
<Upper Limit>	Description of parameters	Def. value	Def. unit	
–128.0 dBm to +128.0 dBm,	Upper limit for maximum power	7.0	dB	
<Lower Limit>	Description of parameters	Def. value	Def. unit	
–128.0 dBm to +128.0 dBm,	Lower limit for maximum power	0.0	dBm	
<Waveform Quality>	Description of parameters	Def. value	Def. unit	FW vers.
0.0 to 1.0	Lower limit for waveform quality	0.944	–	V3.05
Description of command				Sig. State
This commands defines the tolerance limits for the maximum output measurement. The limits apply to all measurement curves (<i>Current, Average, Minimum, Maximum</i>).				All

DEFault:POWer:MAOutput[:OQPSk]:LIMit[?] DEFault:POWer:MAOutput:HPSK:LIMit[?] <Enable>				Default Settings
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	the parameters are set to their default values Some or all parameters are not set to default	ON	–	V3.05
Description of command				Sig. State
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystem <i>POWER:MAOutput:LIMit</i> to their default values (the setting <i>OFF</i> results in an error message). If used as a query the command returns whether all parameters are set to their default values (<i>ON</i>) or not (<i>OFF</i>).				All

Measured Values – Subsystem POWER

The subsystem *POWER:MAOutput* determines and outputs the results of the *Maximum Output* measurement. They correspond to the measurement menu *Power*, application *Maximum Output*, with its various display elements.

Note: *The modulation scheme reference O-QPSK is optional in the commands to remain compatible with cdmaOne. O-QPSK supports radio configurations 1 and 2. H-PSK supports radio configurations 3 and 4.*

READ[:SCALar]:POWer:MAOutput[:OQPSk]? FETCh[:SCALar]:POWer:MAOutput[:OQPSk]? SAMPlE[:SCALar]:POWer:MAOutput[:OQPSk]?		Scalar results:		
		Start single shot measurement and return results		
		Read out measurement results (unsynchronized)		
		Read out measurement results (synchronized)		
READ[:SCALar]:POWer:MAOutput:HPSK? FETCh[:SCALar]:POWer:MAOutput:HPSK? SAMPlE[:SCALar]:POWer:MAOutput:HPSK?		Start single shot measurement and return results		
		Read out measurement results (unsynchronized)		
		Read out measurement results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
Total Power Current, Total Power Average, Total Power Minimum, Total Power Maximum,	–100.0 dBm to –50.0 dBm –100.0 dBm to –50.0 dBm –100.0 dBm to –50.0 dBm –100.0 dBm to –50.0 dBm	NAN NAN NAN NAN	dBm dBm dBm dBm	V3.05
Waveform Quality Current, Waveform Quality Average, Waveform Quality Minimum, Waveform Quality Maximum,	0.0 to 1.0 0.0 to 1.0 0.0 to 1.0 0.0 to 1.0	NAN NAN NAN NAN	– – – –	
Meas. out of Tolerance	0.0% to 100.0%	NAN	%	
Description of command				Sig. State
These commands are always queries. They start a measurement and output all scalar measurement results.				All

CALCulate[:SCALar]:POWer:MAOutput[:OQPSk]:MATChing:LIMit? CALCulate[:SCALar]:POWer:MAOutput:HPSK:MATChing:LIMit?				Limit Matching
Returned values	Value range	Def. value	Def. unit	FW vers.
Total Power Current, Total Power Average, Total Power Minimum, Total Power Maximum, Waveform Quality Current, Waveform Quality Average, Waveform Quality Minimum, Waveform Quality Maximum	For all values NMAU NMAL INV OK	INV INV INV INV INV INV INV	– – – – – – –	V3.05
Description of command				Sig. State
This command is always a query. It indicates whether and in which way the (fixed) limit lines have been exceeded. The following messages may be generated:				All
NMAU	Tolerance value underflow	<i>not matching, underflow</i>		
NMAL	Tolerance value exceeded	<i>not matching, overflow</i>		
INV	Measurement invalid	<i>invalid</i>		
OK	Tolerance value matched			

POWER:GOUTput

The subsystem *POWER:GOUTput* measures the MS gated output power. The subsystem corresponds to the measurement menu *Power*, application *Gated Output*, and the sections related to this application in the associated popup menu *Power Configuration*.

Note: To ensure that the mobile station's output signal is gated, establish a connection with Reverse Radio Configuration 1 or 2.

Control of measurement – Subsystem POWER:GOUTput

The subsystem *POWER:GOUTput* controls the gated output measurement.

INITiate:POWer:GOUTput	Start new measurement	⇒ <i>RUN</i>
ABORt:POWer:GOUTput	Abort running measurement and switch off	⇒ <i>OFF</i>
STOP:POWer:GOUTput	Stop measurement after current stat. cycle	⇒ <i>STOP</i>
CONTInue:POWer:GOUTput	Next measurement step (<i>stepping mode</i>)	⇒ <i>RUN</i>
Description of command		FW vers.
These commands have no query form. They start and stop the power measurement, setting it to the status indicated in the top right column.		V3.05

CONFigure:POWer:GOUTput:EREPorting[?]				Event Reporting
<Report Mode>				
<Report Mode>	Description of parameters	Def. value	Def. unit	FW vers.
SRQ	Service request	OFF	–	V3.05
SOPC	Single operation complete			
SRSQ	SRQ and SOPC			
OFF	No reporting			
DEFault	Sets the value to the default setting			
Description of command				Sig. State
This command defines the events generated when the measurement is terminated or stopped (see <i>Event Reporting</i> in Chapter 5 of the CMU manual).				All

FETCh[:SCALar]:POWer:GOUTput:STATus?				Measurement Status
Return	Description of parameters	Def. value	Def. unit	FW vers.
OFF	Measurement in the OFF state (*RST or ABORT)	OFF	–	V3.05
RUN	Running (after INITiate, CONTinue or READ)			
STOP	Stopped (STOP)			
ERR	OFF (could not be started)			
STEP	Stepping mode (<stepmode>=STEP)			
RDY	Stopped according to repetition mode and stop condition			
1 to 10000	Counter for current statistics cycle	NONE	–	
NONE	No counting mode set			
1 to 1000	Counter for current evaluation period within a cycle	NONE	–	
NONE	Statistic count set to off			
Description of command				Sig. State
This command is always a query. It returns the status of the measurement (see Chapters 3 and 5).				All

Subsystem POWER:GOUTput:CONTRol

The subsystem *POWER:GOUTput:CONTRol* defines the repetition mode, statistic count, and stop condition of the measurement. These settings are provided in the *Control* tab in the popup menu *Power Configuration*.

CONFigure:POWer:GOUTput:CONTRol[?]				Scope of Measurement
<Result Mode>, <Statistic Count>, <Repetition>, <Stop Cond>, <Step Mode>				
<Result Mode>	Description of parameters	Def. value	Def. unit	
SCALar ARRay,	Scalar values only (incl. ramp matching) Scalar measured values and arrays	ARR	–	
<Statistic Count>	Description of parameters	Def. value	Def. unit	
1 to 1000,	Number of bursts per statistics cycle	100	–	
<Repetition>	Description of parameters	Def. value	Def. unit	
1 to 10000 CONTInuous SINGleshot DEFault,	Multiple measurement (counting, until Status = STEP RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–	
<Stop Cond>	Description of parameters	Def. value	Def. unit	
NONE SONerror DEFault,	Continue measurement even in case of error Stop measurement in case of error (<i>stop on error</i>) Sets the value to the default setting	NONE	–	
<Step Mode>	Description of parameters	Def. value	Def. unit	FW-Vers.
STEP NONE DEFault	Interrupt measurement after each statistics cycle Continue measurement according to its rep. Mode Sets the value to the default setting	NONE	–	V3.05
Description of command				Sig. State
This command combines the ...CONTRol:RMODE, ...CONTRol:STATistics and ...CONTRol:REPetition commands, see below.				All

CONFigure:POWer:GOUTput:CONTRol:RMODE[?]				Result Mode
<Result Mode>				
<Result Mode>	Description of parameters	Def. value	Def. unit	FW-Vers.
SCALar ARRay	Scalar values only (incl. ramp matching) Scalar measured values and arrays	ARR	–	V3.05
Description of command				Sig. State
This command specifies the type of measured values.				All

CONFigure:POWer:GOUTput:CONTRol:STATistics[?]				Statistic Count
<Statistics>				
<Statistics>	Description of parameters	Def. value	Def. unit	FW-Vers.
1 to 1000	Number of bursts per statistics cycle	100	–	V3.05
Description of command				
This command specifies the number of bursts forming a statistics cycle.				All

CONFigure:POWer:GOUTput:CONTRol:REPetition[?]				Test Cycles	
<Repetition>, <Stop Cond>, <Step Mode>					
<Repetition>	Description of parameters	Def. value	Def. unit		
1 to 10000 CONTInuous SINGleshot DEFault,	Multiple measurement (counting, until Status = STEP RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Sets the value to the default setting	SING	–		
<Stop Cond>	Description of parameters	Def. value	Def. unit		
NONE SONerror DEFault,	Continue measurement even in case of error Stop measurement in case of error (<i>stop on error</i>) Sets the value to the default setting	NONE	–		
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.	
STEP NONE DEFault	Interrupt measurement after each statistics cycle Continue measurement according to its rep. Mode Sets the value to the default setting	NONE	–	V3.05	
Description of command					Sig. State
This command determines the repetition mode, stop condition, and stepping mode for the measurement.					All
Note: <i>In the case of READ commands (READ:...), the <Repetition> parameter has no effect; the measurement is always stopped after a single shot.</i>					

CONFigure:POWer:GOUTput:CONTRol:PCGcount[?]				Power Control Groups	
<PCG Count>					
<PCG Count>	Description of parameters	Def. value	Def. unit	FW vers.	
1 to 200	Power Control Groups	100	–	V3.05	
Description of command					Sig. State
This command determines how many power control groups are used for a single trace in the Gated Output measurement.					All

DEFault:POWer:GOUTput:LIMit[?]				Default Settings	
<Enable>					
Enable	Description of parameters	Def. value	Def. unit	FW vers.	
ON OFF	The parameters are set to their default values Some or all parameters are not set to default	ON	–	V3.05	
Description of command					Sig. State
If used as a setting command with the parameter ON, this command sets all parameters of the subsystem POWER:GOUTput:Limt to their default values (the setting OFF results in an error message).					All
If used as a query, the command returns whether all parameters are set to their default values (ON) or not (OFF).					

Test Configuration

The subsystem *Power:GOUTput:ENVIRONMENT...* configures the generated RF signal. It corresponds to the *Measurement Environment* section in the *Control* tab of the *Power Configuration* menu. The settings are used only if the environment is enabled; see `CONFigure:POWer:GOUTput:ENVironment:ENABle`.

CONFigure:POWer:GOUTput:ENVironment:ENABle[?]				Environment Enable	
<Enable>					
<Enable>	Description of parameters	Def. Value	Def. Unit	FW vers.	
ON OFF	Enable or disable environment	ON	–	V3.20	
Description of command					Sig. State
This command enables or disables the environment for the <i>Gated Output</i> power application.					All

CONFigure:POWer:GOUTput:ENVironment:POWer:CDMA[?]				CDMA Power	
<CDMA Power>					
<CDMA Power>	Description of parameters	Def. value	Def. unit	FW vers.	
–120.0 dBm to –33.0 dBm –120.0 dBm to –16.0 dBm –100.0 dBm to +7.0 dBm DEFault MINimum MAXimum	RF1 OUT, 0 dB ext. atten RF2 OUT, 0 dB ext. atten RF3 OUT, 0 dB ext. atten Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum	–50.0	dBm	V3.20	
Description of command					Sig. State
This command determines the total CDMA output power (absolute value, in dBm) of the CMU. The CDMA Power value range depends on the RF input used and the external attenuation set. If option R&S CMU-U99 (<i>RF 1 with RF 2 Level Range</i>) is fitted, RF 1 takes on the level range of RF2.					All

CONFigure:POWer:GOUTput:ENVironment:LEVel:FPICh[?]				F-PICH Level	
<Pilot Level>					
<Pilot Level>	Description of parameters	Def. value	Def. unit	FW vers.	
–20.0 dB to –1.0 dB OFF	Pilot Level F-PICH switched off	–7.0	dB	V3.20	
Description of command					Sig. State
This command determines the level in the forward pilot channel of the CMU. The channel power is in units relative to the total CDMA power.					All

CONFigure:POWer:GOUTput:ENVironment:LEVel:FFCH[?]				F-FCH Level	
<FCH Level>					
<FCH Level>	Description of parameters	Def. value	Def. unit	FW vers.	
–20.0 dB to –1.0 dB OFF	FCH Level F-FCH switched off	–7.4	dB	V3.20	
Description of command					Sig. State
This command determines the level in the forward fundamental channel of the CMU. The channel power is in units relative to the total CDMA power.					All

CONFigure:POWer:GOUTput:ENVironment:LEVel:FSCH:ZERO[?]				F-SCH0 Level
<SCH0 Level>				
<SCH0 Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to -1.0 dB OFF	F-SCH0 Level F-SCH0 switched off	-7	dB	V3.20
Description of command				Sig. State
This command determines the level in the forward SCH0 channel of the CMU. The channel power is in units relative to the total CDMA power.				All

CONFigure:POWer:GOUTput:ENVironment:LEVel:FSCH:ONE[?]				F-SCH1 Level
<SCH1 Level>				
<SCH1 Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to -1.0 dB OFF	F-SCH1 Level F-SCH1 switched off	-7	dB	V3.20
Description of command				Sig. State
This command determines the level in the forward SCH1 channel of the CMU. The channel power is in units relative to the total CDMA power.				All

CONFigure:POWer:GOUTput:ENVironment:EBNT:FFCH?				F-FCH Eb/Nt
<Eb/Nt>				
<Eb/Nt>	Description of parameters	Def. value	Def. unit	FW vers.
-30.969 dB to 18.072 dB	Calculated F-FCH Eb/Nt	-	dB	V3.20
Description of command				Sig. State
This command is always a query. It returns the calculated signal to noise ratio for the forward FCH. This quantity is undefined unless the AWGN generator is turned on (CONFigure:POWer:GOUTput:ENVironment:IMPairments:LEVel:AWGN). The quoted range of values is valid for data rates between 9.6 kbps and 153.6 kbps; see <i>Eb/Nt Calculation</i> in Chapter 4.				All

CONFigure:POWer:GOUTput:ENVironment:EBNT:FSCH:ZERO?				F-SCH0 Eb/Nt
<Eb/Nt>				
<Eb/Nt>	Description of parameters	Def. value	Def. unit	FW vers.
-30.969 dB to 18.072 dB	Calculated F-SCH0 Eb/Nt	-	dB	V3.20
Description of command				Sig. State
This command is always a query. It returns the calculated signal to noise ratio for the forward SCH0. This quantity is undefined unless the AWGN generator is turned on (CONFigure:POWer:GOUTput:ENVironment:IMPairments:LEVel:AWGN). The quoted range of values is valid for data rates between 9.6 kbps and 153.6 kbps; see <i>Eb/Nt Calculation</i> in Chapter 4.				All

CONFigure:POWer:GOUTput:ENVironment:EBNT:FSCH:ONE?				F-SCH1 Eb/Nt
<Eb/Nt>				
<Eb/Nt>	Description of parameters	Def. value	Def. unit	FW vers.
-30.969 dB to 18.072 dB	Calculated F-SCH1 Eb/Nt	-	dB	V3.20
Description of command				Sig. State
This command is always a query. It returns the calculated signal to noise ratio for the forward SCH1. This quantity is undefined unless the AWGN generator is turned on (CONFigure:POWer:GOUTput:ENVironment:IMPairments:LEVel:AWGN). The quoted range of values is valid for data rates between 9.6 kbps and 153.6 kbps; see <i>Eb/Nt Calculation</i> in Chapter 4.				All

CONFigure:POWer:GOUTput:ENVIRONMENT:FRATe:FFCH[?]				Frame Rate
<Frame Rate>				
<Frame Rate>	Description of parameters	Def. value	Def. unit	FW vers.
EIGHth QUARter HALF	Frames at 1/8 of the rate set Frames at 1/4 of the rate set Frames at 1/2 of the rate set	EIGH	–	V3.20
Description of command				Sig. State
This command sets the frame rate for the variable rate traffic channel.				All

CONFigure:POWer:GOUTput:ENVIRONMENT:IMPAirments:LEVel:AWGN[?]				AWGN Level
<AWGN Level>				
<AWGN Level>	Description of parameters	Def. value	Def. unit	FW vers.
–20.0 dB to +4.0 dB DEFault MINimum MAXimum OFF,	AWGN level Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum	OFF	dB	V3.20
Description of command				Sig. State
This command determines an Additional White Gaussian Noise level to impair the CMU output signal.				All

CONFigure:POWer:GOUTput:ENVIRONMENT:IMPAirments:FOFFset[?]				BS Frequency Offset
<BS Freq Offset>				
<BS Freq Offset>	Description of parameters	Def. value	Def. unit	FW vers.
–50.0 kHz to +50.0 kHz DEFault MINimum MAXimum OFF	BS frequency offset Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum	OFF	Hz	V3.20
Description of command				Sig. State
This command determines a frequency offset to impair the CMU output signal.				All

CONFigure:POWer:GOUTput:ENVIRONMENT:IMPAirments:ITFer[?]				Injected Tx FER
<FER>				
<FER>	Description of parameters	Def. value	Def. unit	FW vers.
0% to 50% OFF ON	Injected Tx FER Switch FER injection off (equiv. to 0%) Re-activate FER injection, using the previously defined value	OFF	–	V3.20
Description of command				Sig. State
This command defines a percentage of faulty (i.e. erasure) frames that the CMU injects into all traffic channels of its BS Signal.				All

CONFigure:POWer:GOUTput:ENVIRONMENT:PCBits?				Power Control Bits
Response	Description of parameters	Def. value	Def. unit	FW vers.
AUT	Auto mode, closed-loop operation	AUT	–	V3.20
Description of command				Sig. State
This command is always a query and returns the power control bit sequence that the CMU sends to the mobile station to control its output power.				All

Subsystem POWER:GOUTput:LIMit

The subsystem *POWER:GOUTput:LIMit* defines the tolerance values for the gated output measurement. The subsystem corresponds to the *Limits* tab of the *Power Configuration* popup menu.

DEFAult:POWer:GOUTput:LIMit[?]		Limits Default Settings		
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	The parameters are set to their default values Some or all parameters are not set to default	ON	–	V3.05
Description of command				Sig. State
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystem <i>POWER:GOUTput:LIMit</i> to their default values (the setting <i>OFF</i> results in an error message).				All
If used as a query the command returns whether all parameters are set to their default values (<i>ON</i>) or not (<i>OFF</i>).				

CONFigure:POWer:GOUTput:CAMMax:LIMit:A:VALue[?]		A Limit (Rise Time)		
<A Limit>	Description of parameters	Def. value	Def. unit	FW vers.
1 µs to 10 µs DEFAult MINimum MAXimum OFF	Maximum rise time Default value Sets the value to the range minimum Sets the value to the range maximum No offset	7E-06	s	V3.08
Description of command				Sig. State
This command sets the maximum rise time of the gated output power.				All

CONFigure:POWer:GOUTput:CAMMax:LIMit:B:VALue[?]		B Limit (Fall Time)		
<B Limit>	Description of parameters	Def. value	Def. unit	FW vers.
1 µs to 10 µs DEFAult MINimum MAXimum OFF	Maximum fall time Default value Sets the value to the range minimum Sets the value to the range maximum No offset	7E-06	s	V3.08
Description of command				Sig. State
This command sets the maximum fall time of the gated output power.				All

CONFigure:POWer:GOUTput:CAMMax:LIMit:BREReference:VALue[?]				B Limit (Reference Time)	
<B Limit_Ref>					
<B Limit_Ref>	Description of parameters	Def. value	Def. unit	FW vers.	
1240 μs to 1266 μs DEFault MINimum MAXimum OFF	B reference time Default value Sets the value to the range minimum Sets the value to the range maximum No offset	1.247E-3	s	V3.08	
Description of command					Sig. State
This command sets an offset time for the right limit reference line and the right part of the power template relative to the upper end of the lower part of the power template. This parameter must be larger than the sum of the <i>E Limit (Reference Time)</i> and the gated-on time <i>E Limit (Gated On)</i> ; see below. The maximum B reference time is equal to the sum of the following three values: $max(B\ Limit\ (Ref.\ Time)) = max(E\ Limit\ (Gated\ On)) + max(E\ Limit\ (Ref.\ Time)) + min(B\ Limit\ (Fall\ Time))$					All

CONFigure:POWer:GOUTput:CAMMax:LIMit:C:VALue[?]				C Limit	
<C Limit>					
<C Limit>	Description of parameters	Def. value	Def. unit	FW vers.	
-20 dB to -1 dB DEFault MINimum MAXimum OFF	Gated-on power Default value Sets the value to the range minimum Sets the value to the range maximum No offset	-3	dB	V3.08	
Description of command					Sig. State
This command sets the minimum level of the gated-on power relative to the mean output power.					All

CONFigure:POWer:GOUTput:CAMMax:LIMit:D:RELative:VALue[?]				C Limit (relative)	
<D Limit_Rel>					
<D Limit_Rel>	Description of parameters	Def. value	Def. unit	FW vers.	
-25 dB to 0 dB DEFault MINimum MAXimum OFF	Gated-off power (relative) Default value Sets the value to the range minimum Sets the value to the range maximum No offset	-20	dB	V3.08	
Description of command					Sig. State
This command sets the maximum level of the gated-off power relative to the mean output power.					All

CONFigure:POWer:GOUTput:CAMMax:LIMit:D:ABS:VALue[?]				C Limit (absolute)	
<D Limit_Abs>					
<D Limit_Abs>	Description of parameters	Def. value	Def. unit	FW vers.	
-70 dBm to 0 dBm DEFault MINimum MAXimum OFF	Gated-off power (absolute) Default value Sets the value to the range minimum Sets the value to the range maximum No offset	-54	dBm	V3.08	
Description of command					Sig. State
This command sets the absolute maximum level of the gated-off power.					All

CONFigure:POWer:GOUTput:CAMMax:LIMit:E:VALue[?] <E Limit>				E Limit (Gated On)	
<E Limit>	Description of parameters	Def. value	Def. unit	FW vers.	
1240 μs to 1260 μs DEFault MINimum MAXimum OFF	Gated-on time Default value Sets the value to the range minimum Sets the value to the range maximum No offset	1.247E-3	s	V3.08	
Description of command					Sig. State
This command sets the minimum gated-on time. Increasing this parameter also increases <i>B Limit (Reference Time)</i> so that: $B \text{ Limit (Reference Time)} \geq E \text{ Limit (Reference Time)} + E \text{ Limit (Gated On)}$.					All

CONFigure:POWer:GOUTput:CAMMax:LIMit:EREFerence:VALue[?] <E Limit_Ref>				E Limit (Reference Time)	
<E Limit_Ref>	Description of parameters	Def. value	Def. unit	FW vers.	
0 μs to 5 μs DEFault MINimum MAXimum OFF	E reference time Default value Sets the value to the range minimum Sets the value to the range maximum No offset	0	s	V3.08	
Description of command					Sig. State
This command sets an offset time for the lower and right part of the power template relative to the 0-μs time reference of the x-axis and the measurement curve. Increasing this parameter also increases <i>B Limit (Reference Time)</i> so that: $B \text{ Limit (Ref. Time)} \geq E \text{ Limit (Ref. Time)} + E \text{ Limit (Gated On)}$.					All

Subsystem SUBarrays:POWer:GOUTput

The subsystem *SUBarrays:POWer:GOUTput* defines the measurement range and the type of output values.

CONFigure:SUBarrays:POWer:GOUTput[?] <Mode>, <Start>, <Samples>				Definition of Subarrays	
<Mode>	Description of parameters	Def. value	Def. unit	FW vers.	
ALL ARITHmetical MINimum MAXimum,	Return all measurement values Return arithm. mean value in every range Return minimum value in every range Return maximum value in every range	ALL	–		
<Start>	Description of parameters	Def. value	Def. unit		
–0.0001 s to 0.0014 s,	Start time in current range	NAN	s		
<Samples>	Description of parameters	Def. value	Def. unit	FW vers.	
0 to 1664	Number of samples in range	NAN	–	V3.05	
Description of command					Sig. State
This command configures the <code>READ:SUBarrays:POWer:GOUTput...</code> , <code>FETCh:SUBarrays:POWer:GOUTput...</code> , <code>SAMPle:SUBarrays:POWer:GOUTput...</code> commands. It restricts the measurement to up to 32 subranges where either all measurement results (the number of which is given by the second numerical parameter) or a single statistical value is returned. The subranges are defined by a start time and the number of test points which are located on a fixed, equidistant grid. The subranges may overlap but must be within the total range of the <i>POWer:GOUTput</i> measurement. Test points outside this range are not measured (result <i>NAN</i>) and do not enter into the <i>ARITHmetical</i> , <i>MINimum</i> and <i>MAXimum</i> values.					All

Measured Values – Subsystem POWER:GOUTput

The subsystem *POWER:GOUTput* determines and outputs the results of the *Gated Output* measurement. They correspond to the graphical measurement menu *Power*, application *Gated Output*, with its various display elements.

		Scalar results		
READ[:SCALar]:POWER:GOUTput?		Start single shot measurement and return results		
FETCh[:SCALar]:POWER:GOUTput?		Read out measurement results (unsynchronized)		
SAMPlE[:SCALar]:POWER:GOUTput?		Read out measurement results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
Mean Output, Out Of Tolerance, Limit Lines Matching	0.0 dBm to +100.0 dBm 0.0% to 100% NMAU NMAL INV OK	NAN NAN INV	dBm % –	V3.05
Description of command				Sig. State
These commands are always queries. They start a measurement and output all scalar measurement results.				All

		Burst Power		
READ:ARRays:POWER:GOUTput:CURREnt?		Start single shot measurement and return results		
READ:ARRays:POWER:GOUTput:AVERAge?				
READ:ARRays:POWER:GOUTput:MINimum?				
READ:ARRays:POWER:GOUTput:MAXimum?				
FETCh:ARRays:POWER:GOUTput:CURREnt?		Read measurement results (unsynchronized)		
FETCh:ARRays:POWER:GOUTput:AVERAge?				
FETCh:ARRays:POWER:GOUTput:MINimum?				
FETCh:ARRays:POWER:GOUTput:MAXimum?				
SAMPlE:ARRays:POWER:GOUTput:CURREnt?		Read measurement results (synchronized)		
SAMPlE:ARRays:POWER:GOUTput:AVERAge?				
SAMPlE:ARRays:POWER:GOUTput:MINimum?				
SAMPlE:ARRays:POWER:GOUTput:MAXimum?				
Returned values	Value range	Def. value	Def. unit	FW vers.
BurstPower[1] (1 st value for burst power),	–100.0 dB... + 10.0 dB,	NAN	dB	V3.05
BurstPower[x] (x th value for burst power)	–100.0 dB... + 10.0 dB	NAN	dB	
Description of command				Sig. State
These commands are always queries. They output the burst power versus time at fixed, equidistant test points. The number of measured values is 1664.				All
The measured power is evaluated with 64 chips (i.e. 52 μs) before and after the actual isolated Power Control Group (PCG). Considering an oversampling factor of 1, a total of 64 + 1536 + 64 = 1664 valid samples is returned.				

				Burst Power
READ:SUBarrays:POWer:GOUTput:CURRent? READ:SUBarrays:POWer:GOUTput:AVERAge? READ:SUBarrays:POWer:GOUTput:MINimum? READ:SUBarrays:POWer:GOUTput:MAXimum?				
		Start measurement and wait for end	⇒	RUN
FETCh:SUBarrays:POWer:GOUTput:CURRent? FETCh:SUBarrays:POWer:GOUTput:AVERAge? FETCh:SUBarrays:POWer:GOUTput:MINimum? FETCh:SUBarrays:POWer:GOUTput:MAXimum?				
		Read measurement results (unsynchronized)	⇒	RUN
SAMPlE:SUBarrays:POWer:GOUTput:CURRent? SAMPlE:SUBarrays:POWer:GOUTput:AVERAge? SAMPlE:SUBarrays:POWer:GOUTput:MINimum? SAMPlE:SUBarrays:POWer:GOUTput:MAXimum?				
		Read measurement results (synchronized)	⇒	RUN
Measured values	Description	Def. value	Def. unit	FW vers.
BurstPower[1], 1 st value for burst power	-100.0 dB... + 10.0 dB,	NAN	dB	V3.05
BurstPower[x], x th value for burst power	-100.0 dB... + 10.0 dB	NAN	dB	
Description of command				Sig. State
These commands are always queries. They output the burst power versus time in the subranges defined by means of the <code>CONFigure:SUBarrays:POWer:GOUTput</code> command.				All
The <code>CONFigure:SUBarrays:POWer:GOUTput</code> command defines a maximum of 32 subranges. If one of the statistical modes (<code>ARIThmetical</code> , <code>MINimum</code> , <code>MAXimum</code>) is set, only one value is returned per subrange.				
The calculation of <i>current</i> , <i>average</i> , <i>minimum</i> , and <i>maximum</i> results is explained in Chapter 3 (see <i>display mode</i>).				

CALCulate[:SCALar]:POWer:GOUTput:MATChing:RAMP?				Ramp Matchhing
Returned values	Description	Def. value	Def. unit	FW vers.
Total Ramp Status	NMAU NMAL INV OK	INV	–	V3.05
Description of command				Sig. State
This command is always a query. It indicates whether and in which way the (fixed) limit lines have been exceeded. The following messages may be generated:				All
NMAU	Tolerance value underflow	<i>not matching, underflow</i>		
NMAL	Tolerance value exceeded	<i>not matching, overflow</i>		
INV	Measurement invalid	<i>invalid</i>		
OK	Tolerance value matched			

CALCulate:ARRay:POWer:GOUTput:MATChing:LIMit?			Limit Matching		
Returned values	Description	Def. value	Def. unit	FW vers.	
Upper Limits (Bit Field),	0x00000000	No limits are exceeded.	NAN		V3.05
	0x00000001	If there was a lower limit line (–100 µs to 0), this limit would be exceeded.			
	0x00000002	Lower Limit exeeded (0 to 1250 µs).			
	0x00000004	If there was a lower limit line (–1250 µs to infinity), it would be exceeded.			
	Any OR operation of these possibilities shows the appropriate combination.				
Lower Limits (Bit Field)	0x00000000	No limits are exceeded.			
	0x00000001	Upper limit exceeded (inifinity to –7 µs).			
	0x00000002	If there was an upper limit line (–7 µs to 1257 µs) it would be exceeded.			
	0x00000004	Upper limit exceeded (1257 µs to infinity).			
	Any OR operation of these possibilities shows the appropriate combination.				
Description of command				Sig. State	
This command is always a query. It indicates whether and in which way the tolerances for the scalar measured values have been exceeded.				All	

POWER:OLTResponse

The subsystem *POWER:OLTResponse* measures the MS open loop time response. The subsystem corresponds to the measurement menu *Power*, application *Open Loop Time Response*, and the sections related to this application in the associated popup menu *Power Configuration*.

Control of measurement – Subsystem POWER:OLTResponse

The subsystem *POWER:OLTResponse* controls the open loop time response measurement.

INITiate:POWER:OLTResponse	Start new measurement	⇒ RUN
ABORt:POWER:OLTResponse	Abort running measurement and switch off	⇒ OFF
STOP:POWER:OLTResponse	Stop measurement after current stat. cycle	⇒ STOP
CONTinue:POWER:OLTResponse	Next measurement step (only stepping mode)	⇒ RUN
Description of command		FW vers.
These commands have no query form. They start and stop the power measurement, setting it to the status indicated in the top right column.		V3.00

CONFigure:POWER:OLTResponse:EREPorting[?]		Event Reporting		
Enable	Description of parameters	Def. value	Def. unit	FW vers.
ON	SRQ Service request SOPC Single operation complete	OFF	–	V3.00
OFF	SRSQ SRQ and SOPC No reporting			
Description of command				Sig. State
This command defines the events generated when the measurement is terminated or stopped (<i>event reporting</i> , see Chapter 5 of CMU200 manual).				All

FETCh[:SCALar]:POWER:OLTResponse:STATus?		Measurement Status		
Return	Description of parameters	Def. value	Def. unit	FW vers.
OFF	Measurement in the <i>OFF</i> state (*RST or ABORt)	OFF	–	V3.00
RUN	Running (after INITiate, CONTinue or READ)			
STOP	Stopped (STOP)			
ERR	OFF (could not be started)			
STEP	Stepping mode (<stepmode>=STEP)			
RDY	Stopped according to repetition mode and stop condition			
Description of command				Sig. State
This command is always a query. It returns the status of the measurement (see Chapters 3 and 5).				All

Test Configuration

The subsystem *POWER:OLTResponse:ENVIRONMENT...* configures the generated RF signal. It corresponds to the *Measurement Environment* section in the *Control* tab of the *Power Configuration* menu. The settings are used only if the environment is enabled; see *CONFigure:POWER:OLTResponse:ENVIRONMENT:ENABLE*.

CONFigure:POWER:OLTResponse:ENVIRONMENT:ENABLE[?]				Environment Enable	
<Enable>					
<Enable>	Description of parameters	Def. Value	Def. Unit	FW vers.	
ON OFF	Enable or disable environment	ON	–	V3.20	
Description of command					Sig. State
This command enables or disables the environment for the <i>Gated Output</i> power application.					All

CONFigure:POWER:OLTResponse:ENVIRONMENT:POWER:CDMA[?]				Initial CDMA Power	
<CDMA Power>					
<CDMA Power>	Description of parameters	Def. value	Def. unit	FW vers.	
–120.0 dBm to –33.0 dBm –120.0 dBm to –16.0 dBm –100.0 dBm to +7.0 dBm DEFault MINimum MAXimum	RF1 OUT, 0 dB ext. atten RF2 OUT, 0 dB ext. atten RF3 OUT, 0 dB ext. atten Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum	–60.0	dBm	V3.20	
Description of command					Sig. State
This command determines the total CDMA output power (absolute value, in dBm) of the CMU prior to the initial power step of the <i>Open Loop Time Response</i> measurement. The CDMA Power value range depends on the RF input used and the external attenuation set. If option R&S CMU-U99 (<i>RF 1 with RF 2 Level Range</i>) is fitted, RF 1 takes on the level range of RF2.					All

CONFigure:POWER:OLTResponse:ENVIRONMENT:LEVEL:FPICH[?]				F-PICH Level	
<Pilot Level>					
<Pilot Level>	Description of parameters	Def. value	Def. unit	FW vers.	
–20.0 dB to –1.0 dB OFF	Pilot Level F-PICH switched off	–7.0	dB	V3.20	
Description of command					Sig. State
This command determines the level in the forward pilot channel of the CMU. The channel power is in units relative to the total CDMA power.					All

CONFigure:POWER:OLTResponse:ENVIRONMENT:LEVEL:FFCH[?]				F-FCH Level	
<FCH Level>					
<FCH Level>	Description of parameters	Def. value	Def. unit	FW vers.	
–20.0 dB to –1.0 dB OFF	FCH Level F-FCH switched off	–7.4	dB	V3.20	
Description of command					Sig. State
This command determines the level in the forward fundamental channel of the CMU. The channel power is in units relative to the total CDMA power.					All

CONFigure:POWer:OLTResponse:ENVironment:LEVel:FSCH:ZERO[?]				F-SCH0 Level	
<SCH0 Level>					
<SCH0 Level>	Description of parameters	Def. value	Def. unit	FW vers.	
-20.0 dB to -1.0 dB OFF	F-SCH0 Level F-SCH0 switched off	-7	dB	V3.20	
Description of command					Sig. State
This command determines the level in the forward SCH0 channel of the CMU. The channel power is in units relative to the total CDMA power.					All

CONFigure:POWer:OLTResponse:ENVironment:LEVel:FSCH:ONE[?]				F-SCH1 Level	
<SCH1 Level>					
<SCH1 Level>	Description of parameters	Def. value	Def. unit	FW vers.	
-20.0 dB to -1.0 dB OFF	F-SCH1 Level F-SCH1 switched off	-7	dB	V3.20	
Description of command					Sig. State
This command determines the level in the forward SCH1 channel of the CMU. The channel power is in units relative to the total CDMA power.					All

CONFigure:POWer:OLTResponse:ENVironment:EBNT:FFCH?				F-FCH Eb/Nt	
<Eb/Nt>					
<Eb/Nt>	Description of parameters	Def. value	Def. unit	FW vers.	
-30.969 dB to 18.072 dB	Calculated F-FCH Eb/Nt	-	dB	V3.20	
Description of command					Sig. State
This command is always a query. It returns the calculated signal to noise ratio for the forward FCH. This quantity is undefined unless the AWGN generator is turned on (CONFigure:POWer:OLTResponse:ENVironment:IMPairments:LEVel:AWGN). The quoted range of values is valid for data rates between 9.6 kbps and 153.6 kbps; see <i>Eb/Nt Calculation</i> in Chapter 4.					All

CONFigure:POWer:OLTResponse:ENVironment:EBNT:FSCH:ZERO?				F-SCH0 Eb/Nt	
<Eb/Nt>					
<Eb/Nt>	Description of parameters	Def. value	Def. unit	FW vers.	
-30.969 dB to 18.072 dB	Calculated F-SCH0 Eb/Nt	-	dB	V3.20	
Description of command					Sig. State
This command is always a query. It returns the calculated signal to noise ratio for the forward SCH0. This quantity is undefined unless the AWGN generator is turned on (CONFigure:POWer:OLTResponse:ENVironment:IMPairments:LEVel:AWGN). The quoted range of values is valid for data rates between 9.6 kbps and 153.6 kbps; see <i>Eb/Nt Calculation</i> in Chapter 4.					All

CONFigure:POWer:OLTResponse:ENVironment:EBNT:FSCH:ONE?				F-SCH1 Eb/Nt
<Eb/Nt>				
<Eb/Nt>	Description of parameters	Def. value	Def. unit	FW vers.
-30.969 dB to 18.072 dB	Calculated F-SCH1 Eb/Nt	-	dB	V3.20
Description of command				Sig. State
This command is always a query. It returns the calculated signal to noise ratio for the forward SCH1. This quantity is undefined unless the AWGN generator is turned on (CONFigure:POWer:OLTResponse:ENVironment:IMPairments:LEVel:AWGN). The quoted range of values is valid for data rates between 9.6 kbps and 153.6 kbps; see <i>Eb/Nt Calculation</i> in Chapter 4.				All

CONFigure:POWer:OLTResponse:ENVironment:FRATE:FFCH?				Frame Rate
<Frame Rate>				
<Frame Rate>	Description of parameters	Def. value	Def. unit	FW vers.
FULL	Frames at the full rate set	FULL	-	V3.20
Description of command				Sig. State
This command is always a query and returns the fixed frame rate for <i>Open Loop Time Response</i> measurements.				All

CONFigure:POWer:OLTResponse:ENVironment:IMPairments:LEVel:AWGN[?]				AWGN Level
<AWGN Level>				
<AWGN Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to +4.0 dB DEFault MINimum MAXimum OFF,	AWGN level Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum	OFF	dB	V3.20
Description of command				Sig. State
This command determines an Additional White Gaussian Noise level to impair the CMU output signal.				All

CONFigure:POWer:OLTResponse:ENVironment:IMPairments:FOFFset[?]				BS Frequency Offset
<BS Freq Offset>				
<BS Freq Offset>	Description of parameters	Def. value	Def. unit	FW vers.
-50.0 kHz to +50.0 kHz DEFault MINimum MAXimum OFF	BS frequency offset Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum	OFF	Hz	V3.20
Description of command				Sig. State
This command determines a frequency offset to impair the CMU output signal.				All

CONFigure:POWer:OLTResponse:ENVironment:IMPairments:ITFer[?]				Injected Tx FER
<FER>				
<FER>	Description of parameters	Def. value	Def. unit	FW vers.
0% to 50% OFF ON	Injected Tx FER Switch FER injection off (equiv. to 0%) Re-activate FER injection, using the previously defined value	OFF	–	V3.20
Description of command				Sig. State
This command defines a percentage of faulty (i.e. erasure) frames that the CMU injects into all traffic channels of its BS Signal.				All

CONFigure:POWer:OLTResponse:ENVironment:PCBits?				Power Control Bits
Response	Description of parameters	Def. value	Def. unit	FW vers.
HOLD	Auto mode, closed-loop operation	–	–	V3.20
Description of command				Sig. State
This command is always a query and returns the power control bit sequence that the CMU sends to the mobile station to control its output power.				All

CONFigure:POWer:OLTResponse:PSTep[?]				BS Power Step
<Power Step>				
<Power Step>	Description of parameters	Def. value	Def. unit	FW vers.
0.0 dB to +100.0 dB	BS power step	+20	dB	V3.00
Description of command				Sig. State
This command sets the power step of the CMU.				All

CONFigure:POWer:OLTResponse:PSDirection[?]				Power Step Direction
<Power Step Direction>				
<Power Step Direction>	Description of parameters	Def. value	Def. unit	FW vers.
UP Down	BS power step direction	UP	–	V3.00
Description of command				Sig. State
This command sets the power step direction of the CMU.				All

Measured Values – Subsystem POWER:OLTResponse

The subsystem *POWER:OLTResponse* determines and outputs the results of the Open Loop Time Response measurement. They correspond to the graphical measurement menu *Power*, application *Open Loop Time Response*, with its various display elements.

		Scalar results:		
READ[:SCALar]:POWER:OLTResponse?		Start single shot measurement and return results		
FETCh[:SCALar]:POWER:OLTResponse?		Read out meas. results (unsynchronized)		
SAMPlE[:SCALar]:POWER:OLTResponse?		Read out measurement results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
Initial MS Power,	-100.0 dBm to +20.0 dBm	NAN	dBm	V3.00
Initial BS Power,	-100.0 dBm to +20.0 dBm	NAN	dBm	
Current BS Power,	-100.0 dBm to +20.0 dBm	NAN	dBm	
Limit Matching	NMAL NMAU INV MATC	INV	-	
Description of command				Sig. State
These commands are always queries. They start a measurement and output all scalar measurement results.				CONN
The calculation of results in an <i>average</i> or <i>peak</i> measurement is described in Chapter 3 (see <i>display modes</i>).The following messages may be output for <i>Limit Matching</i> :				
NMAU	Tolerance value underflow	<i>not matching, underflow</i>		
NMAL	Tolerance value exceeded	<i>not matching, overflow</i>		
INV	Measurement invalid	<i>invalid</i>		
MATC	Tolerance value matched			

		Burst Power		
READ:ARRAy:POWER:OLTResponse?		Start single shot measurement and return results		
FETCh:ARRAy:POWER:OLTResponse?		Read meas. results (unsynchronized)		
SAMPlE:ARRAy:POWER:OLTResponse?		Read results (synchronized)		
Returned values	Description of parameters	Def. value	Def. unit	FW vers.
-100.0 dB... + 10.0 dB,	BurstPower[1], 1 st value for burst power	NAN	dB	V3.00
...	
-100.0 dB... + 10.0 dB	BurstPower[x], xth value for burst power	NAN	dB	
Description of command				FW vers.
These commands are always queries. They output the burst power versus time at fixed, equidistant test points. The number of measured values is 320. This corresponds to a time interval of 100 milliseconds.				CONN

Receiver Quality Measurements

The subsystem *Receiver Quality* measures the receiver quality of the CDMA mobile phone. The settings are used to assess the quality of transmission between the CMU and the device under test. The subsystem corresponds to the main menu *Receiver Quality* and the associated popup menu *Receiver Quality Configuration*.

Note: *In order to perform channel quality and receiver quality measurements and obtain meaningful results, an appropriate test setup is required (see application examples in Chapter 2 of this manual). Consequently, for these types of measurements, the Call Established (CEST) signalling state must be reached before any of the commands retrieving test results (READ...?, FETCh...?, SAMPlE...?, or CALCulate...LIMit?) can be used. Test configurations, however, can be defined any time.*

RXQuality:FER (Frame Erasure Rate)

The subsystem *RXQuality:FER* contains the commands for receiver quality measurements. The subsystem corresponds to the main menu *Receiver Quality* and the corresponding sections of the associated popup menu *Receiver Quality Configuration*.

Note: *Receiver Quality commands define both the fundamental and supplemental channels of the traffic channel. The GPIB command abbreviations represent the following channels:*

<i>FCH</i>	<i>GPIB commands for the Fundamental traffic channel</i>
<i>SCH/SCCH</i>	<i>GPIB commands for the Supplemental (code) channel</i>
<i>FSSCommon</i>	<i>GPIB commands affecting the Fundamental and Supplemental (code) channels (FCH and SCH/SCCH)</i>

Common Settings – Subsystem RXQuality:FER:FSSCommon:TSETup<nr>

This subsystem selects one out of 5 test setups. It corresponds to the hotkeys associated to the *Test Setup* softkey.

CONFigure:RXQuality:FER:FSSCommon:TSETup[?]				Test Setup
<Test Setup>				
<Test Setup>	Description of parameters	Def. value	Def. unit	FW vers.
T1	Test Setup 1: Sensitivity	T3	–	V3.05
T2	Test Setup 2: Dynamic range			
T3	Test Setup 3: Traffic channel demodulation			
T4	Test Setup 4: User 1			
T5	Test Setup 5: User 2			
DEFault	Sets the value to the default setting			
Description of command				Sig. State
This command selects one out of 5 test setups, i.e. one data set parametrizing a particular receiver quality measurement. When a test setup is switched over, the running measurement is stopped and all measured values are set invalid.				CEST

Measurement Environment – Subsystem
RXQuality:FER:FSSCommon:TSETup<nr>

The subsystem *RXQuality:FER:FSSCommon:TSETup<nr>:ENVIRONMENT...* configures the generated RF signal. It corresponds to the *Measurement Environment* section in the *Control* tab of the *Receiver Quality Configuration* menu. The settings are used only if the environment is enabled; see *CONFigure:RXQuality:FER:FSSCommon:TSETup<nr>:ENVIRONMENT:ENABLE*.

CONFigure:RXQuality:FER:FSSCommon:TSETup<nr>:ENVIRONMENT:ENABLE[?]				Environment Enable
<Enable>				
<Enable>	Description of parameters	Def. Value	Def. Unit	FW vers.
ON OFF	Enable or disable environment	ON	–	V3.20
Description of command				Sig. State
This command enables or disables the environment for an individual test setup <nr> (<nr> = 1 to 5) <i>Receiver Quality</i> measurement applications.				All

CONFigure:RXQuality:FER:FSSCommon:TSETup<nr>:ENVIRONMENT:POWER:CDMA[?]				CDMA Power
<CDMA Power>				
	Description of parameters	Def. value	Def. unit	FW vers.
–120.0 dBm to –33.0 dBm	RF1 OUT, 0 dB ext. atten	–104.0 (1)	dBm	V3.20
–120.0 dBm to –16.0 dBm	RF2 OUT, 0 dB ext. atten	–25.0 (2)	dBm	
–100.0 dBm to +7.0 dBm	RF3 OUT, 0 dB ext. atten	–75.0 (3)	dBm	
DEFault	Sets the value to the default setting	–70.0 (4)	dBm	
MINimum	Sets the value to the range minimum	–70.0 (5)	dBm	
MAXimum	Sets the value to the range maximum			
Description of command				Sig. State
This command determines the total CDMA output power (absolute value, in dBm) of the CMU. The CDMA Power value range depends on the RF input used and the external attenuation set. The suffix <nr> refers to the selected test setup (<nr> = 1 to 5); the range is the same for all test setups but not the default values. If option R&S CMU-U99 (<i>RF 1 with RF 2 Level Range</i>) is fitted, RF 1 takes on the level range of RF2.				All

CONFigure:RXQuality:FER:FSSCommon:TSETup<nr>:ENVIRONMENT:LEVEL:FPICH[?]				F-PICH Level
<Pilot Level>				
<Pilot Level>	Description of parameters	Def. value	Def. unit	FW vers.
–20.0 dB to –1.0 dB	Pilot Level	–7.0 (All)	dB	V3.20
OFF	F-PICH switched off			
Description of command				Sig. State
This command determines the level in the forward pilot channel of the CMU. The channel power is in units relative to the total CDMA power. The suffix <nr> refers to the selected test setup (<nr> = 1 to 5); the range and the default values are the same for all test setups.				All

CONFigure:RXQuality:FER:FSSCommon:TSETup<nr>:ENVIRONMENT:LEVEL:FFCH[?]				F-FCH Level
<FCH Level>				
<FCH Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to -1.0 dB OFF	FCH Level F-FCH switched off	-15.6 (1) -15.6 (2) -14.0 (3) -14.0 (4) -14.0 (5)	dB	V3.20
Description of command				Sig. State
This command determines the level in the forward fundamental channel of the CMU. The channel power is in units relative to the total CDMA power. The suffix <nr> refers to the selected test setup (<nr> = 1 to 5); the range is the same for all test setups but not the default values.				All

CONFigure:RXQuality:FER:FSSCommon:TSETup<nr>:ENVIRONMENT:LEVEL:FSCH:ZERO[?]				F-SCH0 Level
<SCH0 Level>				
<SCH0 Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to -1.0 dB OFF	F-SCH0 Level F-SCH0 switched off	-7.0 (All)	dB	V3.20
Description of command				Sig. State
This command determines the level in the forward SCH0 channel of the CMU. The channel power is in units relative to the total CDMA power. The suffix <nr> refers to the selected test setup (<nr> = 1 to 5); the range and the default values are the same for all test setups.				All

CONFigure:RXQuality:FER:FSSCommon:TSETup<nr>:ENVIRONMENT:LEVEL:FSCH:ONE[?]				F-SCH1 Level
<SCH1 Level>				
<SCH1 Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to -1.0 dB OFF	F-SCH1 Level F-SCH1 switched off	-7.0 (All)	dB	V3.20
Description of command				Sig. State
This command determines the level in the forward SCH1 channel of the CMU. The channel power is in units relative to the total CDMA power. The suffix <nr> refers to the selected test setup (<nr> = 1 to 5); the range and the default values are the same for all test setups.				All

CONFigure:RXQuality:FER:FSSCommon:TSETup<nr>:ENVIRONMENT:EBNT:FFCH?				F-FCH Eb/Nt
<Eb/Nt>				
<Eb/Nt>	Description of parameters	Def. value	Def. unit	FW vers.
-30.969 dB to 18.072 dB	Calculated F-FCH Eb/Nt	-	dB	V3.20
Description of command				Sig. State
This command is always a query. It returns the calculated signal to noise ratio for the forward FCH. This quantity is undefined unless the AWGN generator is turned on (CONFigure:RXQuality:FER:FSSCommon:TSETup<nr>:ENVIRONMENT:IMPAIRMENTS:LEVEL:AWGN). The suffix <nr> refers to the selected test setup (<nr> = 1 to 5). The quoted range of values is valid for data rates between 9.6 kbps and 153.6 kbps; see <i>Eb/Nt Calculation</i> in Chapter 4.				All

CONFigure:RXQuality:FER:FSSCommon:TSETup<nr>:ENVIRONMENT:EBNT:FSCH:ZERO? F-SCH0 Eb/Nt <Eb/Nt>				
<Eb/Nt>	Description of parameters	Def. value	Def. unit	FW vers.
-30.969 dB to 18.072 dB	Calculated F-SCH0 Eb/Nt	-	dB	V3.20
Description of command				Sig. State
This command is always a query. It returns the calculated signal to noise ratio for the forward SCH0. This quantity is undefined unless the AWGN generator is turned on (CONFigure:RXQuality:FER:FSSCommon:TSETup<nr>:ENVIRONMENT:IMPAIRMENTS:LEVEL:AWGN). The suffix <nr> refers to the selected test setup (<nr> = 1 to 5). The quoted range of values is valid for data rates between 9.6 kbps and 153.6 kbps; see <i>Eb/Nt Calculation</i> in Chapter 4.				All

CONFigure:RXQuality:FER:FSSCommon:TSETup<nr>:ENVIRONMENT:EBNT:FSCH:ONE? F-SCH1 Eb/Nt <Eb/Nt>				
<Eb/Nt>	Description of parameters	Def. value	Def. unit	FW vers.
-30.969 dB to 18.072 dB	Calculated F-SCH1 Eb/Nt	-	dB	V3.20
Description of command				Sig. State
This command is always a query. It returns the calculated signal to noise ratio for the forward SCH1. This quantity is undefined unless the AWGN generator is turned on (CONFigure:RXQuality:FER:FSSCommon:TSETup<nr>:ENVIRONMENT:IMPAIRMENTS:LEVEL:AWGN). The suffix <nr> refers to the selected test setup (<nr> = 1 to 5). The quoted range of values is valid for data rates between 9.6 kbps and 153.6 kbps; see <i>Eb/Nt Calculation</i> in Chapter 4.				All

CONFigure:RXQuality:FER:FSSCommon:TSETup<nr>:ENVIRONMENT:FRATE:FFCH[?] Frame Rate <Frame Rate>				
<Frame Rate>	Description of parameters	Def. value	Def. unit	FW vers.
EIGHTh QUARter HALF FULL DEFault	Frames at 1/8 of the rate set Frames at 1/4 of the rate set Frames at 1/2 of the rate set Frames at the full rate set	FULL	-	V3.20
Description of command				Sig. State
This command sets the frame rate for the variable rate traffic channel. The suffix <nr> refers to the selected test setup (<nr> = 1 to 5). The range and default value is the same for all test setups.				All

CONFigure:RXQuality:FER:FSSCommon:TSETup<nr>:ENVIRONMENT:IMPAIRMENTS:LEVEL:AWGN[?] AWGN Level <AWGN Level>				
<AWGN Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to +4.0 dB DEFault MINimum MAXimum OFF,	AWGN level Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum	OFF (1) OFF (2) -1.0 (3) OFF (4) OFF (5)	dB	V3.20
Description of command				Sig. State
This command determines an Additional White Gaussian Noise level to impair the CMU output signal. The suffix <nr> refers to the selected test setup (<nr> = 1 to 5); the range is the same for all test setups but not the default values.				All

CONFigure:RXQuality:FER:FSSCommon:TSETup<nr>:ENVIRONMENT:IMPAIRMENTS:FOFFset[?]BS Frequency Offset				
<BS Freq Offset>				
<BS Freq Offset>	Description of parameters	Def. value	Def. unit	FW vers.
-50.0 kHz to +50.0 kHz DEFault MINimum MAXimum OFF	BS frequency offset Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum	OFF (All)	Hz	V3.20
Description of command				Sig. State
This command determines a frequency offset to impair the CMU output signal. The suffix <nr> refers to the selected test setup (<nr> = 1 to 5). The range and default value is the same for all test setups.				All

CONFigure:RXQuality:FER:FSSCommon:TSETup<nr>:ENVIRONMENT:IMPAIRMENTS:ITFer[?]Injected Tx FER				
<FER>				
<FER>	Description of parameters	Def. value	Def. unit	FW vers.
0% to 50% OFF ON	Injected Tx FER Switch FER injection off (equiv. to 0%) Re-activate FER injection, using the previously defined value	OFF (All)	–	V3.20
Description of command				Sig. State
This command defines a percentage of faulty (i.e. erasure) frames that the CMU injects into all traffic channels of its BS Signal. The suffix <nr> refers to the selected test setup (<nr> = 1 to 5). The range and default value is the same for all test setups.				All

CONFigure:RXQuality:FER:FSSCommon:TSETup<nr>:ENVIRONMENT:PCBits?				
Power Control Bits				
Response	Description of parameters	Def. value	Def. unit	FW vers.
AUT	Auto mode, closed-loop operation	AUT	–	V3.20
Description of command				Sig. State
This command is always a query and returns the power control bit sequence that the CMU sends to the mobile station to control its output power.				All

Control of Measurement – Subsystem RXQuality:FER

The subsystem *RXQuality:FER* controls the receiver quality measurements.

INITiate:RXQuality:FER:FCH	Start new measurement	⇒	RUN
INITiate:RXQuality:FER:SCHScch	Start new measurement	⇒	RUN
ABORT:RXQuality:FER:FCH	Abort running measurement and switch off	⇒	OFF
ABORT:RXQuality:FER:SCHScch	Abort running measurement and switch off	⇒	OFF
STOP:RXQuality:FER:FCH	Stop measurement	⇒	STOP
STOP:RXQuality:FER:SCHScch	Stop measurement	⇒	STOP
CONTInue:RXQuality:FER:FCH	Next measurement step (stepping mode)	⇒	RUN
CONTInue:RXQuality:FER:SCHScch	Next measurement step (stepping mode)	⇒	RUN
Description of command			Sig. State
These commands do not exist as queries. They start or stop the current measurement, setting it to the status indicated.			All
			FW vers.
			V3.05

CONFigure:RXQuality:FER:FCH:EREPorting[?]				Event Reporting
CONFigure:RXQuality:FER:SCHScch:EREPorting[?]				
<Report Mode>				
<Report Mode>	Description of parameters	Def. value	Def. unit	FW vers.
SRQ	Service request	OFF	–	V3.05
SOPC	Single operation complete			
SRSQ	SRQ and SRSQ			
OFF	No reporting			
DEFAult	Sets the value to the default setting			
Description of command				Sig. State
This command defines the events generated when the measurement is terminated or stopped (see <i>Event Reporting</i> in Chapter 5 of the CMU manual).				All

FETCh[:SCALar]:RXQuality:FER:FCH:STATus?				Measurement Status
FETCh[:SCALar]:RXQuality:FER:SCHScch:STATus?				
Return	Description of parameters	Def. value	Def. unit	FW vers.
OFF	Measurement in the OFF state (*RST or ABORt)	OFF	–	V3.05
RUN	Running (after INITiate, CONTInue or READ)			
STOP	Stopped (STOP)			
ERR	OFF (could not be started)			
STEP	Stepping mode (<stepmode>=STEP)			
RDY	Stopped according to repetition mode and stop condition			
1 to 10000	Counter for current statistics cycle	NONE	–	
NONE	No counting mode set			
1 to 1000	Counter for current evaluation period within a cycle	NONE	–	
NONE	Statistic count set to off			
Description of command				Sig. State
This command is always a query. It returns the status of the measurement.				All

XTND:RXQuality:FER:SCHScch:SCH:ONE[?]				SCH1 Extension
<Enable>				
<Min Confidence Level>	Description of parameters	Def. value	Def. unit	FW vers.
ON	SCH1 results included	OFF	–	V3.20
OFF	SCH1 results not included			
Description of command				Sig. State
This command extends the output arrays of the READ..., FETCh..., SAMPlE[:SCALar]:RXQuality:FER:SCHScch? commands and the CALCulate[:SCALar]:RXQuality:FER:SCHScch:MATCHing:LIMit? command to include the results for the SCH1.				All

Subsystem RXQuality:FER:CONTRol

The subsystem *RXQuality:FER:CONTRol* sets the control parameters for the receiver quality measurements. The subsystem corresponds to the tab *Control* in the popup menu *Receiver Quality Configuration*.

CONFigure:RXQuality:FER:FCH:CONTRol:TSETup<nr>:FRAMes[?] CONFigure:RXQuality:FER:SCHScch:CONTRol:TSETup<nr>:FRAMes[?] <Frame Count>				Max. Number of Frames
<Frame Count>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 100000 MINimum MAXimum DEFault	Maximum number of frames to be sent Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	1000	–	V3.05
Description of command				Sig. State
This command defines the maximum number of frames to be sent for the measurement. The suffix <nr> refers to the selected test setup (<nr> = 1 to 5); the range and the default value is the same for all test setups.				All

CONFigure:RXQuality:FER:FCH:CONTRol:TSETup<nr>:REPetition[?] CONFigure:RXQuality:FER:SCHScch:CONTRol:TSETup<nr>:REPetition[?] <Repetition>, <Stop Cond>, <Step Mode>				Test Cycles
<Repetition>	Description of parameters	Def. value	Def. unit	
CONTInuous SINGleshot 1 to 10000 DEFault,	Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Multiple measurement (counting, until Status = STEP RDY) Sets the value to the default setting	SING	–	
<Stop Cond>	Description of parameters	Def. value	Def. unit	
NONE ALEX CLEX FLEX DEFault,	Not aborted, measurement over all frames Measurement aborted if any limit is exceeded Measurement aborted if confidence level limit is exceeded Measurement aborted if frame limit is exceeded Sets the value to the default setting	NONE	–	
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
STEP NONE DEFault	Interrupt measurement after each statistics cycle Continue measurement according to its rep. mode Sets the value to the default setting	NONE	–	V3.05
Description of command				Sig. State
This command defines the repetition mode, stop condition, and stepping mode for the measurement. The suffix <nr> refers to the selected test setup (<nr> = 1 to 5); the range and the default value is the same for all test setups.				All

Subsystem RXQuality:FER:FCH:LIMit

The subsystem *RXQuality:FER:FCH:LIMit* defines tolerance values for the receiver quality measurements. The subsystem corresponds to the tab *Limits* in the popup menu *Receiver Quality Configuration*.

DEFault:RXQuality:FER:FCH:LIMit:TSETup<nr>[?]		Limit Default Settings		
DEFault:RXQuality:FER:SCHScch:LIMit:TSETup<nr>[?]				
<Enable>				
Enable	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	The parameters are set to their default values Some or all parameters are not set to default	ON	–	V3.05
Description of command				Sig. State
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystem <i>OVERview:CQuality:LIMit</i> to their default values (the setting <i>OFF</i> results in an error message). The suffix <i><nr></i> refers to the selected test setup (<i><nr></i> = 1 to 5).				All
If used as a query, the command returns whether all parameters are set to their default values (<i>ON</i>) or not (<i>OFF</i>).				

CONFigure:RXQuality:FER:FCH:LIMit:TSETup<nr>:MFER[?]		Max. FER, FCH		
CONFigure:RXQuality:FER:SCHScch:LIMit:TSETup<nr>:MFER[?]				
<Max FER Limit>				
<Max FER Limit>	Description of parameters	Def. value	Def. unit	FW vers.
0.1 % to 50.0 % MINimum MAXimum DEFault ON OFF	Maximum Frame Error Rate Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	0.5	%	V3.05
Description of command				Sig. State
This command defines the tolerances for the receiver quality measurement for test setup <i><nr></i> (1 to 5). The range and default value is the same for all test setups.				All

CONFigure:RXQuality:FER:SCHScch:LIMit:TSETup<nr>:SCH:ZERO:MFER[?]		Max. FER, SCH		
CONFigure:RXQuality:FER:SCHScch:LIMit:TSETup<nr>:SCH:ONE:MFER[?]				
<Max FER Limit>				
<Max FER Limit>	Description of parameters	Def. value	Def. unit	FW vers.
0.1 % to 100.0 % MINimum MAXimum DEFault ON OFF	Maximum Frame Error Rate Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	0.5	%	V3.20
Description of command				Sig. State
This command defines the tolerances for the FER on the SCHs for test setup <i><nr></i> (1 to 5). The range and default value is the same for all test setups.				All

CONFigure:RXQuality:FER:FCH:LIMit:TSETup<nr>:CLEVel[?]		Min. Confidence Level		
CONFigure:RXQuality:FER:SCHScch:LIMit:TSETup<nr>:CLEVel[?]				
<Min Confidence Level>				
<Min Confidence Level>	Description of parameters	Def. value	Def. unit	FW vers.
85.0 % to 99.99 % MINimum MAXimum DEFault ON OFF	Minimum Confidence Level Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	95.0	%	V3.05
Description of command				Sig. State
This command defines the tolerances for the receiver quality measurement for test setup <nr> (1 to 5). The ranges and default values are the same for all test setups.				All

CONFigure:RXQuality:FER:SCHScch:LIMit:TSETup<nr>SCH:ZERO:CLEVel[?]		Min. Confidence Level		
CONFigure:RXQuality:FER:SCHScch:LIMit:TSETup<nr>SCH:ONE:CLEVel[?]				
<Min Confidence Level>				
<Min Confidence Level>	Description of parameters	Def. value	Def. unit	FW vers.
85.0 % to 99.99 % MINimum MAXimum DEFault ON OFF	Minimum Confidence Level Sets the value to the range minimum Sets the value to the range maximum Sets the value to the default setting	95.0	%	V3.20
Description of command				Sig. State
This command defines the tolerances for the minimum confidence level on the SCHs for test setup <nr> (1 to 5). The ranges and default values are the same for all test setups.				All

Measured Values – Subsystem RXQuality:FER

The subsystem *RXQuality:FER* measures and outputs the bit error rate and compares it with the tolerance values. The subsystem corresponds to the output fields in the *Receiver Quality* menu.

Scalar Results:				
READ[:SCALar]:RXQuality:FER:FCH?			Start single shot measurement and return results	
READ[:SCALar]:RXQuality:FER:SCHScch?				
FEtCh[:SCALar]:RXQuality:FER:FCH?			Read out meas. results (unsynchronized)	
FEtCh[:SCALar]:RXQuality:FER:SCHScch?				
SAMPlE[:SCALar]:RXQuality:FER:FCH?			Read out measurement results (synchronized)	
SAMPlE[:SCALar]:RXQuality:FER:SCHScch?				
Returned values	Value range	Def. value	Def. unit	FW vers.
Frame Error Rate (FER) for SCH0, Frame Errors (abs) for SCH0, Elapsed Frames for SCH0, Confidence Level for SCH0,	0.0% to 100.0% 0 to 20000 0 to 20000 0.000% to 100.000%	NAN NAN NAN NAN	% – – %	V3.05
Frame Error Rate (FER) for SCH1, Frame Errors (abs) for SCH1, Elapsed Frames for SCH1, Confidence Level for SCH1	0.0% to 100.0% 0 to 20000 0 to 20000 0.000% to 100.000%	NAN NAN NAN NAN	% – – %	V3.20
Description of command				Sig. State
These commands are always queries. They start a receiver quality measurement and output the measurement results (see also detailed explanation of measured values in Chapter 4). The SCH1 results are included only if the output is explicitly enabled (XTND:RXQuality:FER:SCHScch:SCH:ONE ON).				All

Limit Matching				
CALCulate[:SCALar]:RXQuality:FER:FCH:MATChing:LIMit?				
CALCulate[:SCALar]:RXQuality:FER:SCHScch:MATChing:LIMit?				
Returned values	Description of parameters	Def. value	Def. unit	FW vers.
Maximum FER for SCH0, Confidence Level for SCH0,	For all measured values: NMAU NMAL INV OK	INV INV	– –	V3.05
Maximum FER for SCH1, Confidence Level for SCH1	For all measured values: NMAU NMAL INV OK	INV INV	– –	V3.20
Description of command				Sig. State
This command is always a query. It indicates whether and in which way the permissible error limits for the measured values of the bit error rate test (see command above) have been exceeded. The SCH1 results are included only if the output is explicitly enabled (XTND:RXQuality:FER:SCHScch:SCH:ONE ON).				All
The following messages can be output for the measured quantities:				
NMAU	Underflow of tolerance value		not matching, underflow	
NMAL	Tolerance value exceeded		not matching, overflow	
INV	Measurement invalid		invalid	
OK	All tolerances matched			

RXQuality:FPC (Forward Power Control)

The subsystem *RXQuality:FPC* contains the commands for receiver quality measurements. The subsystem corresponds to the main menu *Receiver Quality* and the corresponding sections of the associated popup menu *Receiver Quality Configuration*.

**Measurement Environment – Subsystem
RXQuality:FER:FSSCommon:TSETup<nr>**

The subsystem *RXQuality:FPCControl:ENVIRONMENT...* configures the generated RF signal. It corresponds to the *Measurement Environment* section in the *Control* tab of the *Receiver Quality Configuration* menu. The settings are used only if the environment is enabled; see *CONFigure:RXQuality:FPCControl:ENVIRONMENT:ENABLE*.

CONFigure:RXQuality:FPCControl:ENVIRONMENT:ENABLE[?]				Environment Enable	
<Enable>					
<Enable>	Description of parameters	Def. Value	Def. Unit	FW vers.	
ON OFF	Enable or disable environment	ON	–	V3.20	
Description of command					Sig. State
This command enables or disables the environment for the <i>Forward Power Control</i> application.					All

CONFigure:RXQuality:FPCControl:ENVIRONMENT:POWER:CDMA[?]				CDMA Power	
<CDMA Power>					
<CDMA Power>	Description of parameters	Def. value	Def. unit	FW vers.	
–120.0 dBm to –33.0 dBm –120.0 dBm to –16.0 dBm –100.0 dBm to +7.0 dBm DEFault MINimum MAXimum	RF1 OUT, 0 dB ext. atten RF2 OUT, 0 dB ext. atten RF3 OUT, 0 dB ext. atten Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum	–50.0	dBm	V3.20	
Description of command					Sig. State
This command determines the total CDMA output power (absolute value, in dBm) of the CMU. The CDMA Power value range depends on the RF input used and the external attenuation set. If option R&S CMU-U99 (<i>RF 1 with RF 2 Level Range</i>) is fitted, RF 1 takes on the level range of RF2.					All

CONFigure:RXQuality:FPCControl:ENVIRONMENT:LEVEL:FPICH[?]				F-PICH Level	
<Pilot Level>					
<Pilot Level>	Description of parameters	Def. value	Def. unit	FW vers.	
–20.0 dB to –7.0 dB OFF	Pilot Level F-PICH switched off	–7.0	dB	V3.20	
Description of command					Sig. State
This command determines the level in the forward pilot channel of the CMU. The channel power is in units relative to the total CDMA power.					All

CONFigure:RXQuality:FPControl:ENVIRONMENT:LEVEL:FFCH[?]				F-FCH Level
<FCH Level>				
<FCH Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to -7.0 dB OFF	FCH Level F-FCH switched off	-15.6	dB	V3.20
Description of command				Sig. State
This command determines the level in the forward fundamental channel of the CMU. The channel power is in units relative to the total CDMA power.				All

CONFigure:RXQuality:FPControl:ENVIRONMENT:LEVEL:FSCH:ZERO[?]				F-SCH0 Level
<SCH0 Level>				
<SCH0 Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to -7.0 dB OFF	F-SCH0 Level F-SCH0 switched off	-13.5	dB	V3.20
Description of command				Sig. State
This command determines the level in the forward SCH0 channel of the CMU. The channel power is in units relative to the total CDMA power.				All

CONFigure:RXQuality:FPControl:ENVIRONMENT:LEVEL:FSCH:ONE[?]				F-SCH1 Level
<SCH1 Level>				
<SCH1 Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to -7.0 dB OFF	F-SCH1 Level F-SCH1 switched off	-13.5	dB	V3.20
Description of command				Sig. State
This command determines the level in the forward SCH1 channel of the CMU. The channel power is in units relative to the total CDMA power.				All

CONFigure:RXQuality:FPControl:ENVIRONMENT:FRATE:FFCH[?]				Frame Rate
<Frame Rate>				
<Frame Rate>	Description of parameters	Def. value	Def. unit	FW vers.
EIGHTh QUARter HALF FULL DEFault	Frames at 1/8 of the rate set Frames at 1/4 of the rate set Frames at 1/2 of the rate set Frames at the full rate set	FULL	-	V3.20
Description of command				Sig. State
This command sets the frame rate for the variable rate traffic channel.				All

CONFigure:RXQuality:FPControl:ENVIRONMENT:IMPAIRMENTS:LEVEL:AWGN[?]				AWGN Level
<AWGN Level>				
<AWGN Level>	Description of parameters	Def. value	Def. unit	FW vers.
-20.0 dB to +4.0 dB DEFault MINimum MAXimum OFF,	AWGN level Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum	OFF	dB	V3.20
Description of command				Sig. State
This command determines an Additional White Gaussian Noise level to impair the CMU output signal.				All

CONFigure:RXQuality:FPCControl:ENVIRONMENT:IMPAIRMENTS:FOFFset[?] <BS Freq Offset>		BS Frequency Offset		
<BS Freq Offset>	Description of parameters	Def. value	Def. unit	FW vers.
-50.0 kHz to +50.0 kHz DEFault MINimum MAXimum OFF	BS frequency offset Sets the value to the default setting Sets the value to the range minimum Sets the value to the range maximum	OFF	Hz	V3.20
Description of command				Sig. State
This command determines a frequency offset to impair the CMU output signal.				All

CONFigure:RXQuality:FPCControl:ENVIRONMENT:IMPAIRMENTS:ITFer[?] <FER>		Injected Tx FER		
<FER>	Description of parameters	Def. value	Def. unit	FW vers.
0% to 50% OFF ON	Injected Tx FER Switch FER injection off (equiv. to 0%) Re-activate FER injection, using the previously defined value	OFF	–	V3.20
Description of command				Sig. State
This command defines a percentage of faulty (i.e. erasure) frames that the CMU injects into all traffic channels of its BS Signal.				All

CONFigure:RXQuality:FPCControl:ENVIRONMENT:PCBits?		Power Control Bits		
Response	Description of parameters	Def. value	Def. unit	FW vers.
AUT	Auto mode, closed-loop operation	AUT	–	V3.20
Description of command				Sig. State
This command is always a query and returns the power control bit sequence that the CMU sends to the mobile station to control its output power.				All

Control of Measurement – Subsystem RXQuality:FPC

The subsystem *RXQuality:FPC* controls the Forward Power Control measurement of the receiver quality. The subsystem corresponds to the tab *Control* in the popup menu *Receiver Quality Configuration*.

INITiate:RXQuality:FPCControl	Start new measurement	⇒	RUN
ABORt:RXQuality:FPCControl	Abort running measurement and switch off	⇒	OFF
STOP:RXQuality:FPCControl	Stop measurement	⇒	STOP
CONTinue:RXQuality:FPCControl	Next measurement step (stepping mode)	⇒	RUN
Description of command			Sig. State
These commands do not exist as queries. They start or stop the current measurement, setting it to the status indicated.			All
			FW vers.
			V3.05

FETCh[:SCALar]:RXQuality:FPControl:STATus?				Measurement Status	
Return	Description of parameters	Def. value	Def. unit	FW vers.	
OFF RUN STOP ERR STEP RDY,	Measurement in the OFF state (*RST or ABORT) Running (after INITiate, CONTInue or READ) Stopped (STOP) OFF (could not be started) Stepping mode (<stepmode>=STEP) Stopped according to repetition mode and stop condition	OFF	–	–	
1 to 10000 NONE,	Counter for current statistics cycle No counting mode set	NONE	–	–	
1 to 10000 NONE	Counter for current evaluation period within a cycle Statistic count set to off	NONE	–	V3.05	
Description of command				Sig. State	
This command is always a query. It returns the status of the measurement.				All	

Subsystem RXQuality:FPControl:CONTRol

The subsystem *RXQuality:FER:CONTRol:CONTRol* sets the control parameters for the receiver quality measurements. The subsystem corresponds to the tab *Control* in the popup menu *Receiver Quality Configuration*.

CONFIgure:RXQuality:FPControl:EREPorting <Report Mode>				Event Reporting	
<Report Mode>	Description of parameters	Def. value	Def. unit	FW vers.	
SRQ SOPC SRSQ OFF DEFault	Service request Single operation complete SRQ and SRSQ No reporting Sets the value to the default setting	OFF	–	V3.05	
Description of command				Sig. State	
This command defines the events generated when the measurement is terminated or stopped (see <i>Event Reporting</i> in Chapter 5 of the CMU manual).				All	

CONFigure:RXQuality:FPControl:CONTRol[?]				Scope of Measurement	
<Statistics>, <Repetition>, <Stop Cond>, <Step Mode>					
<Statistics>	Description of parameters	Def. value	Def. unit		
1 to 1000,	Number of bursts per statistics cycle	100	–		
<Repetition>	Description of parameters	Def. value	Def. unit		
1 to 10000 CONTinuous SINGleshot DEFault,	Multiple measurement (<i>counting</i> , until Status = STEP RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY)	SING	–		
<Stop Cond>	Description of parameters	Def. value	Def. unit		
NONE ALEX DEFault,	Continue measurement even in case of error Stop measurement in case of error (if any limit is exceeded)	NONE	–		
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.	
STEP NONE DEFault	Interrupt measurement after each statistics cycle Continue measurement according to its rep. mode	NONE	–	V3.05	
Description of command					Sig. State
This command combines the ...CONTRol:STATistics and the ...CONTRol:REPetition commands, see below.					All

CONFigure:RXQuality:FPControl:CONTRol:STATistics[?]				Statistic Count	
<Statistics>					
<Statistics>	Description of parameters	Def. value	Def. unit	FW vers.	
1 to 1000 NONE	Number of bursts per statistics cycle Statistics off (equivalent to 1)	100	–	V3.05	
Description of command					Sig. State
This command specifies the number of bursts forming a statistics cycle.					All

CONFigure:RXQuality:FPCControl:CONTrol:REPetition[?]				Test Cycles
<Repetition>				
<Repetition>	Description of parameters	Def. value	Def. unit	
1 to 10000	Multiple measurement (<i>counting</i> , until Status = STEP RDY)	SING	–	
CONTInuous SINGleshot DEFault	Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY)			
<Stop Cond>	Description of parameters	Def. value	Def. unit	
NONE ALEX DEFault,	Continue measurement even in case of error Stop measurement in case of error (if any limit is exceeded)	NONE	–	
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
STEP NONE DEFault	Interrupt measurement after each statistics cycle Continue measurement according to its rep. mode	NONE	–	V3.05
Description of command				Sig. State
This command determines the repetition mode for the measurement.				All
Note: In the case of READ commands (READ:...), the <Repetition> parameter has no effect; the measurement is always stopped after a single shot.				

CONFigure:RXQuality:FPCControl:CONTrol:FPCMMode[?]				Mode
<Mode>				
<Mode>	Description of parameters	Def. value	Def. unit	FW vers.
000 to 010	Forward power control mode (binary)	0	–	V3.05
Description of command				Sig. State
This command defines the forward power control operating mode. The different modes control the number of power control bits used to monitor the traffic channels. A total of 800 control bits are available. The mode can be set between 0 and 2 (binary format).				All
000 = All 800 bits are used to monitor the FCH channel				
001 = 400 bits are used to monitor the FCH, 400 bits to monitor the SCH0				
010 = 200 bits are used to monitor the FCH, 600 bits used to monitor the SCH0				

CONFigure:RXQuality:FPCControl:CONTrol:RDElay[?]				Delay
<Delay>				
<Delay>	Description of parameters	Def. value	Def. unit	FW vers.
4*n (0 ≤ n ≤ 31)	Number of frames to delay	0	–	V3.05
Description of command				Sig. State
This command sets the number of frames to delay before restarting the error statistics collection. Values that are not an integer multiple of 4 are rounded to the closest allowed value.				All

CONFigure:RXQuality:FPControl:CONTRol:RFRames[?]				Frames
<Frames>				
<Frames>	Description of parameters	Def. value	Def. unit	FW vers.
5 to 905	Number of frames for PMRM data	5	–	V3.05
Description of command				Sig. State
This command sets the number of frames for the mobile station to use to compile the PMRM (Power Measurement Report Message) data.				All
Allowed values are: 5, 7, 10, 14, 20, 28, 40, 57, 80, 113, 160, 226, 320, 453, 640, 905. Any other value is rounded to the nearest allowed value !				

CONFigure:RXQuality:FPControl:CONTRol:CPrimary[?]				Primary Channel
<Primary>				
<Primary>	Description of parameters	Def. value	Def. unit	FW vers.
FCH	Primary fundamental traffic channel	FCH	–	V3.05
Description of command				Sig. State
This command sets primary fundamental traffic channel to use. FCH is the only available selection.				All

CONFigure:RXQuality:FPControl:CONTRol:CSEcondary[?]				Secondary Channel
<Secondary>				
<Secondary>	Description of parameters	Def. value	Def. unit	FW vers.
SCH0	Supplemental traffic channel	SCH0	–	V3.05
Description of command				Sig. State
This command sets the supplemental traffic channel. SCH0 is the only available selection.				All

CONFigure:RXQuality:FPControl:CONTRol:FCH:TFER[?]				Target FER
<Target FER>				
<Target FER>	Description of parameters	Def. value	Def. unit	FW vers.
0.2 to 30	Target frame error rate of fundamental traffic channel	0.5	%	V3.05
Description of command				Sig. State
This command sets a Frame Error Rate target (percentage of error) for the mobile station to achieve on the forward fundamental traffic channel. The mobile station continually adjusts its outer loop E_b/N_t setpoint to achieve and maintain the <i>Target FER</i> setting. The range of the outer loop setpoint is bound by the minimum and maximum setpoint settings.				All
Allowed target FER values are: 0.2, 0.5, 1, 1.5, 2, 2.5, 3, 3.5, 4, 4.5, 5, 5.5, 6, 6.5, 7.5, 8, 8.5, 9, 9.5, 10, 11, 12, 13, 14, 15, 18, 21, 24, 27, 30. Any other value is rounded to the nearest allowed value !				

CONFigure:RXQuality:FPControl:CONTROL:FCH:LSPoint:STTic:LOWer[?]				Eb/Nt Setpoint
<Static Level>				
<Static Level>	Description of parameters	Def. value	Def. unit	FW vers.
0.000 to 31.750	Lower static Eb/Nt outer loop setpoint level	0.000	dB	V3.05
Description of command				Sig. State
<p>This command sets the minimum level that the mobile station is allowed to move the Eb/Nt setpoint to for forward power control of the forward fundamental traffic channel. If the static value is used, the setting can be adjusted between 0 and the current Maximum level.</p> <p>This setting is only valid if the lower dynamic Eb/Nt setpoint is off (CONFigure:RXQuality:FPControl:CONTROL:FCH:LSPoint:DYNamic:LOWer[?]). If the dynamic setpoint is on, a query returns HFF.</p> <p>Note: <i>Setting the Minimum and Maximum setpoints to the same values freezes the setpoint to that value, not allowing the mobile to adjust the level.</i></p>				All

CONFigure:RXQuality:FPControl:CONTROL:FCH:LSPoint:DYNamic:LOWer[?]				Eb/Nt Setpoint
<Dynamic Level>				
<Dynamic Level>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF DEFault	Enable the lower dynamic Eb/Nt outer loop setpoint	OFF	–	V3.05
Description of command				Sig. State
<p>This command enables or disables the use of the dynamic (minimum) setpoint setting for forward power control of the forward fundamental traffic channel.</p> <p>When set to on, the minimum level is automatically set to the current mobile station's setpoint. When set to OFF, the static level setting is used. Refer to the command (CONFigure:RXQuality:FPControl:CONTROL:FCH:LSPoint:STTic:LOWer[?]).</p> <p>Note: <i>Setting both the Minimum and Maximum levels to Dynamic freezes the setpoint to the mobile station's current setpoint.</i></p>				All

CONFigure:RXQuality:FPControl:CONTROL:FCH:LSPoint:STTic:UPPer[?]				Eb/Nt Setpoint
<Static Level>				
<Static Level>	Description of parameters	Def. value	Def. unit	FW vers.
0.000 to 31.750	Upper static Eb/Nt outer loop setpoint level	31.750	dB	V3.05
Description of command				Sig. State
<p>This command sets the maximum level that the mobile station is allowed to move the Eb/Nt setpoint to for forward power control of the forward fundamental traffic channel. If the static value is used, the setting can be adjusted between 31.750 and the current Minimum level.</p> <p>This setting is only valid if the upper dynamic Eb/Nt setpoint is off (CONFigure:RXQuality:FPControl:CONTROL:FCH:LSPoint:DYNamic:UPPer[?]). If the dynamic setpoint is on, a query returns HFF.</p> <p>Note: <i>Setting the Minimum and Maximum setpoints to the same values freezes the setpoint to that value, not allowing the mobile to adjust the level.</i></p>				All

CONFigure:RXQuality:FPControl:CONTRol:FCH:LSPoint:DYNAMIC:UPPer[?] <Enable>				Eb/Nt Setpoint
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF DEFault	Enable the upper dynamic Eb/Nt outer loop setpoint	OFF	–	V3.05
Description of command				Sig. State
This command enables or disables the use of the dynamic (maximum) setpoint setting for forward power control of the forward fundamental traffic channel.				All
When set to on, the maximum level is automatically set to the current mobile station's setpoint. When set to OFF, the static level setting is used. Refer to the command (CONFigure:RXQuality:FPControl:CONTRol:FCH:LSPoint:STTic:UPPer[?]).				
Note: Setting both the Minimum and Maximum levels to Dynamic freezes the setpoint to the mobile station's current setpoint.				

CONFigure:RXQuality:FPControl:CONTRol:FCH:LSPoint:INITial[?] CONFigure:RXQuality:FPControl:CONTRol:SCH:ZERO:LSPoint:INITial[?] CONFigure:RXQuality:FPControl:CONTRol:SCH:ONE:LSPoint:INITial[?] <Initial Setpoint>				Initial Eb/Nt Setpoint
<Initial Setpoint>	Description of parameters	Def. value	Def. unit	FW vers.
0.000 to 31.750	Initial Eb/Nt outer loop setpoint level	6.0	dB	V3.60
Description of command				Sig. State
This command sets the initial outer loop Eb/Nt setpoint.				All

CONFigure:RXQuality:FPControl:CONTRol:FCH:LSPoint:THReshold[?] CONFigure:RXQuality:FPControl:CONTRol:SCH:ZERO:LSPoint:THReshold[?] CONFigure:RXQuality:FPControl:CONTRol:SCH:ONE:LSPoint:THReshold[?] <Threshold>				Eb/Nt Setpoint Threshold
<Threshold>	Description of parameters	Def. value	Def. unit	FW vers.
0.000 to 31.750 OFF	Eb/Nt setpoint report threshold No outer loop report message sent	OFF	dB	V3.60
Description of command				Sig. State
This command sets the Eb/Nt setpoint report threshold above which the mobile station will send the outer loop report message.				All

CONFigure:RXQuality:FPControl:CONTRol:SCH:ZERO:TFER[?] CONFigure:RXQuality:FPControl:CONTRol:SCH:ONE:TFER[?] <Target FER>				Target FER
<Target FER>	Description of parameters	Def. value	Def. unit	FW vers.
0.2 to 30	Target frame error rate of supplemental traffic channel 0	0.5	%	V3.05
Description of command				Sig. State
These commands set a Frame Error Rate target (percentage of error) for the mobile station to achieve on the forward supplemental traffic channels 0 or 1. The mobile station continually adjusts its outer loop Eb/Nt setpoint to achieve and maintain the Target FER setting. The range of the outer loop setpoint is bound by the minimum and maximum setpoint settings.				All
Allowed target FER values are: 0.2, 0.5, 1, 1.5, 2, 2.5, 3, 3.5, 4, 4.5, 5, 5.5, 6, 6.5, 7.5, 8, 8.5, 9, 9.5, 10, 11, 12, 13, 14, 15, 18, 21, 24, 27, 30. Any other value is rounded to the nearest allowed value !				

CONFigure:RXQuality:FPControl:CONTRol:SCH:ZERO:LSPoint:STTic:LOWer[?]				E _b /N _t Setpoint
CONFigure:RXQuality:FPControl:CONTRol:SCH:ONE:LSPoint:STTic:LOWer[?]				
<Static Level>				
<Static Level>	Description of parameters	Def. value	Def. unit	FW vers.
0.000 to 31.750	Lower static E _b /N _t outer loop setpoint level	0.000	dB	V3.05
Description of command				Sig. State
<p>These commands set the minimum level that the mobile station is allowed to move the E_b/N_t setpoint to for forward power control of the forward supplemental traffic channels 0 or 1. If the static value is used, the setting can be adjusted between 0 and the current Maximum level.</p> <p>This setting is only valid if the lower dynamic E_b/N_t setpoint is off (CONFigure:RXQuality:FPControl:CONTRol:SCH:LSPoint:DYNamic:LOWer[?]). If the dynamic setpoint is on, a query returns HFF.</p> <p>Note: <i>Setting the Minimum and Maximum setpoints to the same values freezes the setpoint to that value, not allowing the mobile to adjust the level.</i></p>				All

CONFigure:RXQuality:FPControl:CONTRol:SCH:ZERO:LSPoint:DYNamic:LOWer[?]				E _b /N _t Setpoint
CONFigure:RXQuality:FPControl:CONTRol:SCH:ONE:LSPoint:DYNamic:LOWer[?]				
<Enable>				
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF DEFault	Enable the lower dynamic E _b /N _t outer loop setpoint	OFF	–	V3.05
Description of command				Sig. State
<p>These commands enable or disable the use of the dynamic (minimum) setpoint setting for forward power control of the forward supplemental traffic channels 0 or 1.</p> <p>When set to on, the minimum level is automatically set to the current mobile station's setpoint. When set to OFF, the static level setting is used. Refer to the command (CONFigure:RXQuality:FPControl:CONTRol:SCH:LSPoint:STTic:LOWer[?]).</p> <p>Note: <i>Setting both the Minimum and Maximum levels to Dynamic freezes the setpoint to the mobile station's current setpoint.</i></p>				All

CONFigure:RXQuality:FPControl:CONTRol:SCH:ZERO:LSPoint:STTic:UPPer[?]				E _b /N _t Setpoint
CONFigure:RXQuality:FPControl:CONTRol:SCH:ONE:LSPoint:STTic:UPPer[?]				
<Static Level>				
<Static Level>	Description of parameters	Def. value	Def. unit	FW vers.
0.000 to 31.750	Upper static E _b /N _t outer loop setpoint level	31.750	dB	V3.05
Description of command				Sig. State
<p>These commands set the maximum level that the mobile station is allowed to move the E_b/N_t setpoint to for forward power control of the supplemental traffic channels 0 or 1. If the static value is used, the setting can be adjusted between 31.750 and the current minimum level.</p> <p>This setting is only valid if the upper dynamic E_b/N_t setpoint is off (CONFigure:RXQuality:FPControl:CONTRol:SCH:LSPoint:DYNamic:UPPer[?]). If the dynamic setpoint is on, a query returns HFF.</p> <p>Note: <i>Setting the Minimum and Maximum setpoints to the same values freezes the setpoint to that value, not allowing the mobile to adjust the level.</i></p>				All

CONFigure:RXQuality:FPControl:CONTRol:SCH:ZERO:LSPoint:DYNamic:UPPer[?] CONFigure:RXQuality:FPControl:CONTRol:SCH:ONE:LSPoint:DYNamic:UPPer[?] <Dynamic Level>				Eb/Nt Setpoint
<Dynamic Level>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF DEFault	Enable the upper dynamic Eb/Nt outer loop setpoint	OFF	–	V3.05
Description of command				Sig. State
<p>These commands enable or disable the use of the dynamic (maximum) setpoint setting for forward power control of the forward supplemental traffic channels 0 or 1.</p> <p>When set to on, the maximum level is automatically set to the current mobile station's setpoint. When set to OFF, the static level setting is used. Refer to the command (CONFigure:RXQuality:FPControl:CONTRol:SCH:LSPoint:STTic:UPPer[?]).</p> <p>Note: <i>Setting both the Minimum and Maximum levels to Dynamic freezes the setpoint to the mobile station's current setpoint.</i></p>				All

Measured Values – Subsystem RXQuality:FPControl

The subsystem *RXQuality:FPControl* measures and outputs the bit error rate and compares it with the tolerance values. The subsystem corresponds to the output fields in the *Forward Power Control Receiver Quality* menu.

		Scalar Results:		
READ[:SCALar]:RXQuality:FPControl?		Start single shot measurement and return results		
FETCh[:SCALar]:RXQuality:FPControl?		Read out meas. results (unsynchronized)		
SAMPlE[:SCALar]:RXQuality:FPControl?		Read out measurement results (synchronized)		
Returned values	Value range	Def. value	Def. unit	FW vers.
Actual Output Power,	–120.0 dBm to –33.0 dBm,	NAN	dBm	V3.05
FER (FCH),	0.0% to 100.0%,	NAN	%	
Frame Errors (FCH),	0 to 20000,	NAN	–	
Transmitted Frames (FCH),	0 to 20000,	NAN	–	
Confidence Level (FCH),	0.000% to 100.000%,	NAN	%	
Adjusted Level (FCH),	,	NAN		
Fwd Channel Level (FCH),	,	NAN		
Current Setpoint (FCH),	0.000 to 31.750,	NAN	–	
BS Calculated E_bN_t (FCH),	,	NAN		
FER (DCCH),	Not values returned for the Dedicated	NAN	%	
Frame Errors (DCCH),	Control Channel.	NAN	–	
Transmitted Frames (DCCH),		NAN	–	
Confidence Level (DCCH),		NAN	%	
Adjusted Level (DCCH),		NAN		
Fwd Channel Level (DCCH),		NAN		
Current Setpoint (DCCH),		NAN	–	
BS Calculated E_bN_t (DCCH),		NAN		
FER (SCH0),	0.0% to 100.0%	NAN	%	
Frame Errors (SCH0),	0 to 20000	NAN	–	
Transmitted Frames (SCH0),	0 to 20000	NAN	–	
Confidence Level (SCH0),	0.000% to 100.000%	NAN	%	
Adjusted Level (SCH0),		NAN		
Fwd Channel Level (SCH0),		NAN		
Current Setpoint (SCH0),	0.000 to 31.750	NAN	–	
BS Calculated E_bN_t (SCH0),		NAN		
FER (SCH1),	No values returned for the Supplemental	NAN	%	
Frame Errors(SCH1),	Channel 1.	NAN	–	
Transmitted Frames (SCH1),		NAN	–	
Confidence Level (SCH1),		NAN	%	
Adjusted Level (SCH1),		NAN		
Fwd Channel Level (SCH1),		NAN		
Current Setpoint (SCH1),		NAN	–	
BS Calculated E_bN_t (SCH1)		NAN		
Description of command				Sig. State
These commands are always queries. They start the Forward Power Control measurement and output the measurement results (refer to Chapter 4 about measured values). Values are returned for the Total Output Power, Fundamental Channel, and Supplemental Channel 0. The Dedicated Control Channel and Supplemental Channel 1 are not measured.				All

List of Non-Signalling Commands

In the following, all remote-control commands of the CDMA2000 Non-Signalling function group are listed. They are arranged alphabetically by the second keyword of the command so that related commands are listed together.

Table 6-1 Remote-control commands (Non-Signalling)

Code Domain Power (Common)

<i>CONFigure:CDPower:CPCCCommon:LIMit:IQLCheck</i> [?]	6.92
<i>CONFigure:CDPower:CPCCCommon:CMAX:LIMit:ASYMmetric:COMBined</i> [?]	6.92
<i>CONFigure:CDPower:CPCCCommon:AVERAge:LIMit:ASYMmetric:COMBined</i> [?]	6.93
<i>DEFault:CDPower:CPCCCommon:LIMit</i> [?]	6.93

Code Domain Power

<i>INITiate:CDPower:CDPW</i>	6.94
<i>ABORt:CDPower:CDPW</i>	6.94
<i>STOP:CDPower:CDPW</i>	6.94
<i>CONTInue:CDPower:CDPW</i>	6.94
<i>CONFigure:CDPower:CDPW:EREPorting</i> [?]	6.94
<i>CONFigure:CDPower:CDPW:CMAX:LIMit:ASYMmetric:COMBined</i> [?]	6.94
<i>CONFigure:CDPower:CDPW:AVERAge:LIMit:ASYMmetric:COMBined</i> [?]	6.94
<i>DEFault:CDPower:CDPW:LIMit</i> [?]	6.95
<i>FETCh:SCALar]:CDPower:CDPW:STATus?</i>	6.95
<i>CONFigure:CDPower:CDPW:CONTRol</i> [?]	6.96
<i>CONFigure:CDPower:CDPW:CONTRol:SFACTor</i> [?]	6.96
<i>CONFigure:CDPower:CDPW:CONTRol:RMODE</i> [?]	6.96
<i>CONFigure:CDPower:CDPW:CONTRol:STATistics</i> [?]	6.97
<i>CONFigure:CDPower:CDPW:CONTRol:REPetition</i> [?]	6.97
<i>CONFigure:CDPower:CDPW:CONTRol:RORDer</i> [?]	6.97
<i>READ:ARRay:CDPower:CHPW:ISIGnal:VALue:CURRent?</i>	6.98
<i>FETCh:ARRay:CDPower:CHPW:ISIGnal:VALue:CURRent?</i>	6.98
<i>SAMPlE:ARRay:CDPower:CHPW:ISIGnal:VALue:CURRent?</i>	6.98
<i>READ:ARRay:CDPower:CHPW:ISIGnal:VALue:AVERAge?</i>	6.98
<i>FETCh:ARRay:CDPower:CHPW:ISIGnal:VALue:AVERAge?</i>	6.98
<i>SAMPlE:ARRay:CDPower:CHPW:ISIGnal:VALue:AVERAge?</i>	6.98
<i>READ:ARRay:CDPower:CHPW:ISIGnal:VALue:MAXimum?</i>	6.98
<i>FETCh:ARRay:CDPower:CHPW:ISIGnal:VALue:MAXimum?</i>	6.98
<i>SAMPlE:ARRay:CDPower:CHPW:ISIGnal:VALue:MAXimum?</i>	6.98
<i>READ:ARRay:CDPower:CHPW:QSIGnal:VALue:CURRent?</i>	6.98
<i>FETCh:ARRay:CDPower:CHPW:QSIGnal:VALue:CURRent?</i>	6.98
<i>SAMPlE:ARRay:CDPower:CHPW:QSIGnal:VALue:CURRent?</i>	6.98
<i>READ:ARRay:CDPower:CHPW:QSIGnal:VALue:AVERAge?</i>	6.99
<i>FETCh:ARRay:CDPower:CHPW:QSIGnal:VALue:AVERAge?</i>	6.99
<i>SAMPlE:ARRay:CDPower:CHPW:QSIGnal:VALue:AVERAge?</i>	6.99
<i>READ:ARRay:CDPower:CHPW:QSIGnal:VALue:MAXimum?</i>	6.99
<i>FETCh:ARRay:CDPower:CHPW:QSIGnal:VALue:MAXimum?</i>	6.99
<i>SAMPlE:ARRay:CDPower:CHPW:QSIGnal:VALue:MAXimum?</i>	6.99
<i>FETCh:ARRay:CDPower:CDPW:ISIGnal:STATe?</i>	6.99
<i>FETCh:ARRay:CDPower:CDPW:QSIGnal:STATe?</i>	6.99
<i>SAMPlE:SCALar]:CDPower:CDPW?</i>	6.99
<i>READ:SCALar]:CDPower:CDPW?</i>	6.99
<i>FETCh:SCALar]:CDPower:CDPW?</i>	6.99
<i>CALCulate:SCALar]:CDPower:CDPW:MATChing:LIMit?</i>	6.100

CALCulate:ARRay:CDPower:CDPW:ISIGnal:CURRent[:RESult]:MATChing:LIMit? 6.100
 CALCulate:ARRay:CDPower:CDPW:ISIGnal:AVERAge[:RESult]:MATChing:LIMit? 6.100
 CALCulate:ARRay:CDPower:CDPW:ISIGnal:MAXimum[:RESult]:MATChing:LIMit? 6.100
 CALCulate:ARRay:CDPower:CDPW:QSIGnal:CURRent[:RESult]:MATChing:LIMit? 6.100
 CALCulate:ARRay:CDPower:CDPW:QSIGnal:AVERAge[:RESult]:MATChing:LIMit? 6.101
 CALCulate:ARRay:CDPower:CDPW:QSIGnal:MAXimum[:RESult]:MATChing:LIMit? 6.101

Code Domain Power (Peak Code Domain Error Power)

INITiate:CDPower:PCDep 6.101
 ABORt:CDPower:PCDep 6.101
 CONTinue:CDPower:PCDep 6.101
 STOP:CDPower:PCDep 6.101
 CONFigure:CDPower:PCDep:EREPorting[?] 6.101
 CONFigure:CDPower:PCDep:CMAx:LIMit:ASYMmetric[:COMBined][?] 6.102
 CONFigure:CDPower:PCDep:AVERAge:LIMit:ASYMmetric[:COMBined][?] 6.102
 DEFault:CDPower:PCDep:LIMit[?] 6.102
 FETCh[:SCALar]:CDPower:PCDep:STATus? 6.103
 CONFigure:CDPower:PCDep:CONTRol[?] 6.103
 CONFigure:CDPower:PCDep:CONTRol:RMODE[?] 6.104
 CONFigure:CDPower:PCDep:CONTRol:SFACTOR[?] 6.104
 CONFigure:CDPower:PCDep:CONTRol:RORDER[?] 6.104
 CONFigure:CDPower:PCDep:CONTRol:STATistics[?] 6.104
 CONFigure:CDPower:PCDep:CONTRol:REPetition[?] 6.105
 READ:ARRay:CDPower:PCDep:ISIGnal[:VALue]:CURRent? 6.105
 FETCh:ARRay:CDPower:PCDep:ISIGnal[:VALue]:CURRent? 6.105
 SAMPlE:ARRay:CDPower:PCDep:ISIGnal[:VALue]:CURRent? 6.105
 READ:ARRay:CDPower:PCDep:ISIGnal[:VALue]:AVERAge? 6.106
 FETCh:ARRay:CDPower:PCDep:ISIGnal[:VALue]:AVERAge? 6.106
 SAMPlE:ARRay:CDPower:PCDep:ISIGnal[:VALue]:AVERAge? 6.106
 READ:ARRay:CDPower:PCDep:ISIGnal[:VALue]:MAXimum? 6.106
 FETCh:ARRay:CDPower:PCDep:ISIGnal[:VALue]:MAXimum? 6.106
 SAMPlE:ARRay:CDPower:PCDep:ISIGnal[:VALue]:MAXimum? 6.106
 READ:ARRay:CDPower:PCDep:QSIGnal[:VALue]:CURRent? 6.106
 FETCh:ARRay:CDPower:PCDep:QSIGnal[:VALue]:CURRent? 6.106
 SAMPlE:ARRay:CDPower:PCDep:QSIGnal[:VALue]:CURRent? 6.106
 READ:ARRay:CDPower:PCDep:QSIGnal[:VALue]:AVERAge? 6.106
 FETCh:ARRay:CDPower:PCDep:QSIGnal[:VALue]:AVERAge? 6.106
 SAMPlE:ARRay:CDPower:PCDep:QSIGnal[:VALue]:AVERAge? 6.106
 READ:ARRay:CDPower:PCDep:QSIGnal[:VALue]:MAXimum? 6.107
 FETCh:ARRay:CDPower:PCDep:QSIGnal[:VALue]:MAXimum? 6.107
 SAMPlE:ARRay:CDPower:PCDep:QSIGnal[:VALue]:MAXimum? 6.107
 FETCh:ARRay:CDPower:PCDep:ISIGnal:STATe? 6.107
 FETCh:ARRay:CDPower:PCDep:QSIGnal:STATe? 6.107
 SAMPlE[:SCALar]:CDPower:PCDep? 6.107
 READ[:SCALar]:CDPower:PCDep? 6.107
 FETCh[:SCALar]:CDPower:PCDep? 6.107
 CALCulate[:SCALar]:CDPower:PCDep:MATChing:LIMit? 6.108
 CALCulate:ARRay:CDPower:PCDep:ISIGnal:CURRent[:RESult]:MATChing:LIMit? 6.108
 CALCulate:ARRay:CDPower:PCDep:ISIGnal:AVERAge[:RESult]:MATChing:LIMit? 6.108
 CALCulate:ARRay:CDPower:PCDep:ISIGnal:MAXimum[:RESult]:MATChing:LIMit? 6.108
 CALCulate:ARRay:CDPower:PCDep:QSIGnal:CURRent[:RESult]:MATChing:LIMit? 6.108
 CALCulate:ARRay:CDPower:PCDep:QSIGnal:AVERAge[:RESult]:MATChing:LIMit? 6.109
 CALCulate:ARRay:CDPower:PCDep:QSIGnal:MAXimum[:RESult]:MATChing:LIMit? 6.109

Code Domain Power (Channel Power)

INITiate:CDPower:CHPW 6.109
 ABORt:CDPower:CHPW 6.109
 STOP:CDPower:CHPW 6.109

CONTinue:CDPower:CHPW	6.109
CONFigure:CDPower:CHPW:EREPorting[?]	6.109
CONFigure:CDPower:CHPW:CMAX:LIMit:ASYMmetric:COMBined[?]	6.110
CONFigure:CDPower:CHPW:AVERAge:LIMit:ASYMmetric:COMBined[?]	6.110
DEFault:CDPower:CHPW:LIMit[?][?]	6.110
FETCh:SCALar]:CDPower:CHPW:STATus?	6.111
CONFigure:CDPower:CHPW:CONTRol[?]	6.111
CONFigure:CDPower:CHPW:CONTRol:RMODE[?]	6.112
CONFigure:CDPower:CHPW:CONTRol:STATistics[?]	6.112
CONFigure:CDPower:CHPW:CONTRol:REPetition[?]	6.112
READ:ARRay:CDPower:CHPW:ISIGnal[:VALue]:CURRent?	6.113
FETCh:ARRay:CDPower:CHPW:ISIGnal[:VALue]:CURRent?	6.113
SAMPle:ARRay:CDPower:CHPW:ISIGnal[:VALue]:CURRent?	6.113
READ:ARRay:CDPower:CHPW:ISIGnal[:VALue]:AVERAge?	6.113
FETCh:ARRay:CDPower:CHPW:ISIGnal[:VALue]:AVERAge?	6.113
SAMPle:ARRay:CDPower:CHPW:ISIGnal[:VALue]:AVERAge?	6.113
READ:ARRay:CDPower:CHPW:ISIGnal[:VALue]:MAXimum?	6.113
FETCh:ARRay:CDPower:CHPW:ISIGnal[:VALue]:MAXimum?	6.113
SAMPle:ARRay:CDPower:CHPW:ISIGnal[:VALue]:MAXimum?	6.113
READ:ARRay:CDPower:CHPW:QSIGnal[:VALue]:CURRent?	6.113
FETCh:ARRay:CDPower:CHPW:QSIGnal[:VALue]:CURRent?	6.113
SAMPle:ARRay:CDPower:CHPW:QSIGnal[:VALue]:CURRent?	6.113
READ:ARRay:CDPower:CHPW:QSIGnal[:VALue]:AVERAge?	6.114
FETCh:ARRay:CDPower:CHPW:QSIGnal[:VALue]:AVERAge?	6.114
SAMPle:ARRay:CDPower:CHPW:QSIGnal[:VALue]:AVERAge?	6.114
READ:ARRay:CDPower:CHPW:QSIGnal[:VALue]:MAXimum?	6.114
FETCh:ARRay:CDPower:CHPW:QSIGnal[:VALue]:MAXimum?	6.114
SAMPle:ARRay:CDPower:CHPW:QSIGnal[:VALue]:MAXimum?	6.114
FETCh:ARRay:CDPower:CHPW:ISIGnal:STATe?	6.114
FETCh:ARRay:CDPower:CHPW:QSIGnal:STATe?	6.114
READ[:SCALar]:CDPower:CHPW?	6.115
FETCh[:SCALar]:CDPower:CHPW?	6.115
SAMPle[:SCALar]:CDPower:CHPW?	6.115
CALCulate:ARRay:CDPower:CHPW:ISIGnal:CURRent[:RESult]:MATChing:LIMit?	6.115
CALCulate:ARRay:CDPower:CHPW:ISIGnal:AVERAge[:RESult]:MATChing:LIMit?	6.115
CALCulate:ARRay:CDPower:CHPW:ISIGnal:MAXimum[:RESult]:MATChing:LIMit?	6.115
CALCulate:ARRay:CDPower:CHPW:QSIGnal:CURRent[:RESult]:MATChing:LIMit?	6.115
CALCulate:ARRay:CDPower:CHPW:QSIGnal:AVERAge[:RESult]:MATChing:LIMit?	6.116
CALCulate:ARRay:CDPower:CHPW:QSIGnal:MAXimum[:RESult]:MATChing:LIMit?	6.116
CALCulate[:SCALar]:CDPower:CHPW:MATChing:LIMit?	6.116

Code Domain Power (Phase Offset)

INITiate:CDPower:POFFset	6.117
ABORt:CDPower:POFFset	6.117
STOP:CDPower:POFFset	6.117
CONTinue:CDPower:POFFset	6.117
CONFigure:CDPower:POFFset:EREPorting[?]	6.117
FETCh:SCALar]:CDPower:POFFset:STATus?	6.117
CONFigure:CDPower:POFFset:CONTRol[?]	6.118
CONFigure:CDPower:POFFset:CONTRol:RMODE[?]	6.118
CONFigure:CDPower:POFFset:CONTRol:STATistics[?]	6.118
CONFigure:CDPower:POFFset:CONTRol:REPetition[?]	6.119
CONFigure:CDPower:POFFset:CMAX:LIMit[?]	6.119
CONFigure:CDPower:POFFset:AVERAge:LIMit[?]	6.119
DEFault:CDPower:POFFset:LIMit[?][?]	6.119
READ[:SCALar]:CDPower:POFFset?	6.120
FETCh[:SCALar]:CDPower:POFFset?	6.120
SAMPle[:SCALar]:CDPower:POFFset?	6.120
CALCulate[:SCALar]:CDPower:POFFset:MATChing:LIMit?	6.120

READ:ARRay:CDPower:POFFset:ISIGnal[:VALue]:CURRent?	6.121
FETCh:ARRay:CDPower:POFFset:ISIGnal[:VALue]:CURRent?	6.121
SAMPlE:ARRay:CDPower:POFFset:ISIGnal[:VALue]:CURRent?	6.121
READ:ARRay:CDPower:POFFset:ISIGnal[:VALue]:AVERAge?	6.121
FETCh:ARRay:CDPower:POFFset:ISIGnal[:VALue]:AVERAge?	6.121
SAMPlE:ARRay:CDPower:POFFset:ISIGnal[:VALue]:AVERAge?	6.121
READ:ARRay:CDPower:POFFset:ISIGnal[:VALue]:MAXimum?	6.121
FETCh:ARRay:CDPower:POFFset:ISIGnal[:VALue]:MAXimum?	6.121
SAMPlE:ARRay:CDPower:POFFset:ISIGnal[:VALue]:MAXimum?	6.121
READ:ARRay:CDPower:POFFset:QSIGnal[:VALue]:CURRent?	6.121
FETCh:ARRay:CDPower:POFFset:QSIGnal[:VALue]:CURRent?	6.121
SAMPlE:ARRay:CDPower:POFFset:QSIGnal[:VALue]:CURRent?	6.121
READ:ARRay:CDPower:POFFset:QSIGnal[:VALue]:AVERAge?	6.121
FETCh:ARRay:CDPower:POFFset:QSIGnal[:VALue]:AVERAge?	6.121
SAMPlE:ARRay:CDPower:POFFset:QSIGnal[:VALue]:AVERAge?	6.121
READ:ARRay:CDPower:POFFset:QSIGnal[:VALue]:MAXimum?	6.121
FETCh:ARRay:CDPower:POFFset:QSIGnal[:VALue]:MAXimum?	6.121
SAMPlE:ARRay:CDPower:POFFset:QSIGnal[:VALue]:MAXimum?	6.121
FETCh:ARRay:CDPower:POFFset:ISIGnal:STATe?	6.121
FETCh:ARRay:CDPower:POFFset:QSIGnal:STATe?	6.122
CALCulate:ARRay:CDPower:POFFset:ISIGnal:CURRent[:RESult]:MATChing:LIMit?	6.122
CALCulate:ARRay:CDPower:POFFset:ISIGnal:AVERAge[:RESult]:MATChing:LIMit?	6.122
CALCulate:ARRay:CDPower:POFFset:ISIGnal:MAXimum[:RESult]:MATChing:LIMit?	6.122
CALCulate:ARRay:CDPower:POFFset:QSIGnal:CURRent[:RESult]:MATChing:LIMit?	6.122
CALCulate:ARRay:CDPower:POFFset:QSIGnal:AVERAge[:RESult]:MATChing:LIMit?	6.122
CALCulate:ARRay:CDPower:POFFset:QSIGnal:MAXimum[:RESult]:MATChing:LIMit?	6.122

Code Domain Power (Timing Offset)

INITiate:CDPower:TOFFset	6.123
ABORt:CDPower:TOFFset	6.123
STOP:CDPower:TOFFset	6.123
CONTInue:CDPower:TOFFset	6.123
CONFigure:CDPower:TOFFset:EREPorting[?]	6.123
FETCh[:SCALar]:CDPower:TOFFset:STATus?	6.123
CONFigure:CDPower:TOFFset:CONTRol[?]	6.124
CONFigure:CDPower:TOFFset:CONTRol:RMODE[?]	6.124
CONFigure:CDPower:TOFFset:CONTRol:STATistics[?]	6.124
CONFigure:CDPower:TOFFset:CONTRol:REPetition[?]	6.125
CONFigure:CDPower:TOFFset:CMAX:LIMit[?]	6.125
CONFigure:CDPower:TOFFset:AVERAge:LIMit[?]	6.125
DEFault:CDPower:TOFFset:LIMit[?][?]	6.125
READ[:SCALar]:CDPower:TOFFset?	6.126
FETCh[:SCALar]:CDPower:TOFFset?	6.126
SAMPlE[:SCALar]:CDPower:TOFFset?	6.126
CALCulate[:SCALar]:CDPower:TOFFset:MATChing:LIMit?	6.126
READ:ARRay:CDPower:TOFFset:ISIGnal[:VALue]:CURRent?	6.127
FETCh:ARRay:CDPower:TOFFset:ISIGnal[:VALue]:CURRent?	6.127
SAMPlE:ARRay:CDPower:TOFFset:ISIGnal[:VALue]:CURRent?	6.127
READ:ARRay:CDPower:TOFFset:ISIGnal[:VALue]:AVERAge?	6.127
FETCh:ARRay:CDPower:TOFFset:ISIGnal[:VALue]:AVERAge?	6.127
SAMPlE:ARRay:CDPower:TOFFset:ISIGnal[:VALue]:AVERAge?	6.127
READ:ARRay:CDPower:TOFFset:ISIGnal[:VALue]:MAXimum?	6.127
FETCh:ARRay:CDPower:TOFFset:ISIGnal[:VALue]:MAXimum?	6.127
SAMPlE:ARRay:CDPower:TOFFset:ISIGnal[:VALue]:MAXimum?	6.127
READ:ARRay:CDPower:TOFFset:QSIGnal[:VALue]:CURRent?	6.127
FETCh:ARRay:CDPower:TOFFset:QSIGnal[:VALue]:CURRent?	6.127
SAMPlE:ARRay:CDPower:TOFFset:QSIGnal[:VALue]:CURRent?	6.127
READ:ARRay:CDPower:TOFFset:QSIGnal[:VALue]:AVERAge?	6.127
FETCh:ARRay:CDPower:TOFFset:QSIGnal[:VALue]:AVERAge?	6.127

SAMPlE:ARRAy:CDPower:TOFFset:QSIGnal[:VALue]:AVERAge?	6.127
READ:ARRAy:CDPower:TOFFset:QSIGnal[:VALue]:MAXimum?	6.127
FETCh:ARRAy:CDPower:TOFFset:QSIGnal[:VALue]:MAXimum?	6.127
SAMPlE:ARRAy:CDPower:TOFFset:QSIGnal[:VALue]:MAXimum?	6.127
FETCh:ARRAy:CDPower:TOFFset:ISIGnal:STATe?	6.127
FETCh:ARRAy:CDPower:TOFFset:QSIGnal:STATe?	6.128
CALCulate:ARRAy:CDPower:TOFFset:ISIGnal:CURRent[:RESult]:MATChing:LIMit?	6.128
CALCulate:ARRAy:CDPower:TOFFset:ISIGnal:AVERAge[:RESult]:MATChing:LIMit?	6.128
CALCulate:ARRAy:CDPower:TOFFset:ISIGnal:MAXimum[:RESult]:MATChing:LIMit?	6.128
CALCulate:ARRAy:CDPower:TOFFset:QSIGnal:CURRent[:RESult]:MATChing:LIMit?	6.128
CALCulate:ARRAy:CDPower:TOFFset:QSIGnal:AVERAge[:RESult]:MATChing:LIMit?	6.128
CALCulate:ARRAy:CDPower:TOFFset:QSIGnal:MAXimum[:RESult]:MATChing:LIMit?	6.128

Inputs and Outputs

[SENSe:]LEVel:MODE[?]	6.3
[SENSe:]LEVel:MAXimum[?]	6.3
INPut[:STATe]	6.13
OUTPut[:STATe]	6.14
[SENSe:]CORRection:LOSS:INPut<nr>[:MAGNitude]	6.14
SOURce:CORRection:LOSS:INPut<nr>[:MAGNitude]	6.14
[SENSe:]CORRection:LOSS:OUTPut<nr>[:MAGNitude]	6.14
SOURce:CORRection:LOSS:OUTPut<nr>[:MAGNitude]	6.14
SOURce:DM:CLOCK:STATe	6.14
SOURce:DM:CLOCK:FREQUency	6.15

Impairments

SOURce:IMPairments:LEVel:AWGN[?]	6.13
SOURce:IMPairments:FOFFset[:RF][?]	6.13

I/Q-IF Interface

CONFigure:IQIF:RXTXcombined	6.33
CONFigure:IQIF:RXPath	6.33
CONFigure:IQIF:TXPath	6.34
[SENSe:]IQIF:LEVel?	6.34

Modulation (Analyzer/Generator)

INITiate:MODulation:MQuality[:OQPSk]	6.16
INITiate:MODulation:MQuality:HPSK	6.16
INITiate:MODulation:MQuality:QPSK	6.16
ABORt:MODulation:MQuality[:OQPSk]	6.16
ABORt:MODulation:MQuality:HPSK	6.16
ABORt:MODulation:MQuality:QPSK	6.16
STOP:MODulation:MQuality[:OQPSk]	6.16
STOP:MODulation:MQuality:HPSK	6.16
STOP:MODulation:MQuality:QPSK	6.16
CONTinue:MODulation:MQuality[:OQPSk]	6.16
CONTinue:MODulation:MQuality:HPSK	6.16
CONTinue:MODulation:MQuality:QPSK	6.16
CONFigure:MODulation:MQuality[:OQPSk]:EREPorting[?]	6.16
CONFigure:MODulation:MQuality:HPSK:EREPorting[?]	6.16
CONFigure:MODulation:MQuality:QPSK:EREPorting[?]	6.16
FETCh[:SCALar]:MODulation:MQuality[:OQPSk]:STATus?	6.17
FETCh[:SCALar]:MODulation:MQuality:HPSK:STATus?	6.17
FETCh[:SCALar]:MODulation:MQuality:QPSK:STATus?	6.17
XTND:MODulation:MQuality[:OQPSk]:SBSuppress[?]	6.17
XTND:MODulation:MQuality:HPSK:SBSuppress[?]	6.17

XTND:MODulation:MQuality:QPSK:SBSuppress[?]	6.17
DEFault:MODulation:MQuality:CONTRol[?]	6.18
DEFault:MODulation:MQuality:OQPSKj:CONTRol[?]	6.18
DEFault:MODulation:MQuality:HPSK:CONTRol[?]	6.18
DEFault:MODulation:MQuality:QPSK:CONTRol[?]	6.18
CONFigure:MODulation:MQuality:OQPSKj:CONTRol[?]	6.19
CONFigure:MODulation:MQuality:HPSK:CONTRol[?]	6.19
CONFigure:MODulation:MQuality:QPSK:CONTRol[?]	6.19
CONFigure:MODulation:MQuality:OQPSKj:CONTRol:STATistics[?]	6.19
CONFigure:MODulation:MQuality:HPSK:CONTRol:STATistics[?]	6.19
CONFigure:MODulation:MQuality:QPSK:CONTRol:STATistics[?]	6.19
CONFigure:MODulation:MQuality:OQPSKj:CONTRol:REPetition[?]	6.20
CONFigure:MODulation:MQuality:HPSK:CONTRol:REPetition[?]	6.20
CONFigure:MODulation:MQuality:QPSK:CONTRol:REPetition[?]	6.20
CONFigure:MODulation:MQuality:OQPSKj:CONTRol:FOFFset:SBSuppress:ACP<nr>[?]	6.20
CONFigure:MODulation:MQuality:HPSK:CONTRol:FOFFset:SBSuppress:ACP<nr>[?]	6.20
CONFigure:MODulation:MQuality:QPSK:CONTRol:FOFFset:SBSuppress:ACP<nr>[?]	6.20
CONFigure:MODulation:MQuality:OQPSKj:CMMax:LIMit[?]	6.21
CONFigure:MODulation:MQuality:HPSK:CMMax:LIMit[?]	6.21
CONFigure:MODulation:MQuality:QPSK:CMMax:LIMit[?]	6.21
CONFigure:MODulation:MQuality:OQPSKj:AVERage:LIMit[?]	6.22
CONFigure:MODulation:MQuality:HPSK:AVERage:LIMit[?]	6.22
CONFigure:MODulation:MQuality:QPSK:AVERage:LIMit[?]	6.22
DEFault:MODulation:MQuality:OQPSKj:CMMax:LIMit[?]	6.23
DEFault:MODulation:MQuality:HPSK:CMMax:LIMit[?]	6.23
DEFault:MODulation:MQuality:QPSK:CMMax:LIMit[?]	6.23
DEFault:MODulation:MQuality:OQPSKj:AVERage:LIMit[?]	6.23
DEFault:MODulation:MQuality:HPSK:AVERage:LIMit[?]	6.23
DEFault:MODulation:MQuality:QPSK:AVERage:LIMit[?]	6.23
DEFault:MODulation:MQuality:LIMit[?]	6.23
READ[:SCALar]:MODulation:MQuality:OQPSKj?	6.24
READ[:SCALar]:MODulation:MQuality:HPSK?	6.24
READ[:SCALar]:MODulation:MQuality:QPSK?	6.24
FETCh[:SCALar]:MODulation:MQuality:OQPSKj?	6.24
FETCh[:SCALar]:MODulation:MQuality:HPSK?	6.24
FETCh[:SCALar]:MODulation:MQuality:QPSK?	6.24
SAMPlE[:SCALar]:MODulation:MQuality:OQPSKj?	6.24
SAMPlE[:SCALar]:MODulation:MQuality:HPSK?	6.24
SAMPlE[:SCALar]:MODulation:MQuality:QPSK?	6.24
CALCulate[:SCALar]:MODulation:MQuality:OQPSKj:MATChing:LIMit?	6.25
CALCulate[:SCALar]:MODulation:MQuality:HPSK:MATChing:LIMit?	6.25
CALCulate[:SCALar]:MODulation:MQuality:QPSK:MATChing:LIMit?	6.25

Modulation (Error Vector Magnitude)

INITiate:MODulation:EVMagnitude[:OQPSKj]	6.54
ABORt:MODulation:EVMagnitude[:OQPSKj]	6.54
STOP:MODulation:EVMagnitude[:OQPSKj]	6.54
CONTinue:MODulation:EVMagnitude[:OQPSKj]	6.54
INITiate:MODulation:EVMagnitude:HPSK	6.54
ABORt:MODulation:EVMagnitude:HPSK	6.54
STOP:MODulation:EVMagnitude:HPSK	6.54
CONTinue:MODulation:EVMagnitude:HPSK	6.54
CONFigure:MODulation:EVMagnitude[:OQPSKj]:EREPorting[?]	6.54
CONFigure:MODulation:EVMagnitude:HPSK:EREPorting[?]	6.54
FETCh[:SCALar]:MODulation:EVMagnitude[:OQPSKj]:STATus?	6.54
FETCh[:SCALar]:MODulation:EVMagnitude:HPSK:STATus?	6.54
CONFigure:MODulation:EVMagnitude[:OQPSKj]:CONTRol[?]	6.55
CONFigure:MODulation:EVMagnitude:HPSK:CONTRol[?]	6.55
CONFigure:MODulation:EVMagnitude[:OQPSKj]:CONTRol:RMODE[?]	6.55

CONFigure:MODulation:EVMagnitude:HPSK:CONTRol:RMODE[?]	6.55
CONFigure:MODulation:EVMagnitude[:OQPSk]:CONTRol:STATistics[?]	6.56
CONFigure:MODulation:EVMagnitude:HPSK:CONTRol:STATistics[?]	6.56
CONFigure:MODulation:EVMagnitude[:OQPSk]:CONTRol:REPetition[?]	6.56
CONFigure:MODulation:EVMagnitude:HPSK:CONTRol:REPetition[?]	6.56
CONFigure:SUBarrays:MODulation:EVMagnitude[:OQPSk][?]	6.57
CONFigure:SUBarrays:MODulation:EVMagnitude:HPSK[?]	6.57
READ[:SCALar]:MODulation:EVMagnitude[:OQPSk]?	6.58
FETCh[:SCALar]:MODulation:EVMagnitude[:OQPSk]?	6.58
SAMPlE[:SCALar]:MODulation:EVMagnitude[:OQPSk]?	6.58
READ[:SCALar]:MODulation:EVMagnitude:HPSK?	6.58
FETCh[:SCALar]:MODulation:EVMagnitude:HPSK?	6.58
SAMPlE[:SCALar]:MODulation:EVMagnitude:HPSK?	6.58
CALCulate[:SCALar]:MODulation:EVMagnitude[:OQPSk]:MATChing:LIMit?	6.58
CALCulate[:SCALar]:MODulation:EVMagnitude:HPSK:MATChing:LIMit?	6.58
READ:ARRay:MODulation:EVMagnitude[:OQPSk]:CURRent?	6.59
READ:ARRay:MODulation:EVMagnitude[:OQPSk]:AVERAge?	6.59
READ:ARRay:MODulation:EVMagnitude[:OQPSk]:MMAX?	6.59
FETCh:ARRay:MODulation:EVMagnitude[:OQPSk]:CURRent?	6.59
FETCh:ARRay:MODulation:EVMagnitude[:OQPSk]:AVERAge?	6.59
FETCh:ARRay:MODulation:EVMagnitude[:OQPSk]:MMAX?	6.59
SAMPlE:ARRay:MODulation:EVMagnitude[:OQPSk]:CURRent?	6.59
SAMPlE:ARRay:MODulation:EVMagnitude[:OQPSk]:AVERAge?	6.59
SAMPlE:ARRay:MODulation:EVMagnitude[:OQPSk]:MMAX?	6.59
READ:ARRay:MODulation:EVMagnitude:HPSK:CURRent?	6.59
READ:ARRay:MODulation:EVMagnitude:HPSK:AVERAge?	6.59
READ:ARRay:MODulation:EVMagnitude:HPSK:MMAX?	6.59
FETCh:ARRay:MODulation:EVMagnitude:HPSK:CURRent?	6.59
FETCh:ARRay:MODulation:EVMagnitude:HPSK:AVERAge?	6.59
FETCh:ARRay:MODulation:EVMagnitude:HPSK:MMAX?	6.59
SAMPlE:ARRay:MODulation:EVMagnitude:HPSK:CURRent?	6.59
SAMPlE:ARRay:MODulation:EVMagnitude:HPSK:AVERAge?	6.59
SAMPlE:ARRay:MODulation:EVMagnitude:HPSK:MMAX?	6.59
READ:SUBarrays:MODulation:EVMagnitude[:OQPSk]:CURRent?	6.60
READ:SUBarrays:MODulation:EVMagnitude[:OQPSk]:AVERAge?	6.60
READ:SUBarrays:MODulation:EVMagnitude[:OQPSk]:MMAX?	6.60
FETCh:SUBarrays:MODulation:EVMagnitude[:OQPSk]:CURRent?	6.60
FETCh:SUBarrays:MODulation:EVMagnitude[:OQPSk]:AVERAge?	6.60
FETCh:SUBarrays:MODulation:EVMagnitude[:OQPSk]:MMAX?	6.60
SAMPlE:SUBarrays:MODulation:EVMagnitude[:OQPSk]:CURRent?	6.60
SAMPlE:SUBarrays:MODulation:EVMagnitude[:OQPSk]:AVERAge?	6.60
SAMPlE:SUBarrays:MODulation:EVMagnitude[:OQPSk]:MMAX?	6.60
READ:SUBarrays:MODulation:EVMagnitude:HPSK:CURRent?	6.60
READ:SUBarrays:MODulation:EVMagnitude:HPSK:AVERAge?	6.60
READ:SUBarrays:MODulation:EVMagnitude:HPSK:MMAX?	6.60
FETCh:SUBarrays:MODulation:EVMagnitude:HPSK:CURRent?	6.60
FETCh:SUBarrays:MODulation:EVMagnitude:HPSK:AVERAge?	6.60
FETCh:SUBarrays:MODulation:EVMagnitude:HPSK:MMAX?	6.60
SAMPlE:SUBarrays:MODulation:EVMagnitude:HPSK:CURRent?	6.60
SAMPlE:SUBarrays:MODulation:EVMagnitude:HPSK:AVERAge?	6.60
SAMPlE:SUBarrays:MODulation:EVMagnitude:HPSK:MMAX?	6.60

Modulation (IQ Analyzer)

INITiate:MODulation:IQANalyzer[:OQPSk]	6.77
ABORt:MODulation:IQANalyzer[:OQPSk]	6.77
STOP:MODulation:IQANalyzer[:OQPSk]	6.77
CONTinue:MODulation:IQANalyzer[:OQPSk]	6.77
INITiate:MODulation:IQANalyzer:HPSK:DPCH	6.77
ABORt:MODulation:IQANalyzer:HPSK:DPCH	6.77

STOP:MODulation:IQANalyzer:HPSK:DPCH-no query	6.77
CONTinue:MODulation:IQANalyzer:HPSK:DPCH-no query	6.77
CONFigure:MODulation:IQANalyzer[:OQPSk]:EREPorting	6.77
CONFigure:MODulation:IQANalyzer:HPSK:DPCH:EREPorting.....	6.77
FETCh:MODulation:IQANalyzer[:OQPSk]:STATus?.....	6.77
FETCh:MODulation:IQANalyzer:HPSK:DPCH:STATus?.....	6.77
CONFigure:MODulation:IQANalyzer[:OQPSk]:CONTRol:RMODe	6.78
CONFigure:MODulation:IQANalyzer:HPSK:DPCH:CONTRol:RMODe	6.78
CONFigure:MODulation:IQANalyzer[:OQPSk]:CONTRol:REPetition	6.78
CONFigure:MODulation:IQANalyzer:HPSK:DPCH:CONTRol:REPetition.....	6.78
DEFault:MODulation:IQANalyzer[:OQPSk]:CONTRol.....	6.78
DEFault:MODulation:IQANalyzer:HPSK:DPCH:CONTRol.....	6.78
READ[:SCALar]:MODulation:IQANalyzer[:OQPSk]?	6.79
READ[:SCALar]:MODulation:IQANalyzer:HPSK:DPCH?.....	6.79
FETCh[:SCALar]:MODulation:IQANalyzer[:OQPSk]?.....	6.79
FETCh[:SCALar]:MODulation:IQANalyzer:HPSK:DPCH?	6.79
SAMPle[:SCALar]:MODulation:IQANalyzer[:OQPSk]?	6.79
SAMPle[:SCALar]:MODulation:IQANalyzer:HPSK:DPCH?.....	6.79
READ:ARRay:MODulation:IQANalyzer[:OQPSk]:IPHase?.....	6.79
READ:ARRay:MODulation:IQANalyzer:HPSK:DPCH:QPHase?.....	6.79
FETCh:ARRay:MODulation:IQANalyzer[:OQPSk]:IPHase?.....	6.79
FETCh:ARRay:MODulation:IQANalyzer:HPSK:DPCH:QPHase?	6.79
SAMPle:ARRay:MODulation:IQANalyzer[:OQPSk]:IPHase?.....	6.79
SAMPle:ARRay:MODulation:IQANalyzer:HPSK:DPCH:QPHase?.....	6.79

Modulation (Magnitude Error)

INITiate:MODulation:MERRor[:OQPSk]	6.69
ABORt:MODulation:MERRor[:OQPSk].....	6.69
STOP:MODulation:MERRor[:OQPSk]	6.69
CONTinue:MODulation:MERRor[:OQPSk]	6.69
INITiate:MODulation:MERRor:HPSK.....	6.69
ABORt:MODulation:MERRor:HPSK.....	6.69
STOP:MODulation:MERRor:HPSK.....	6.69
CONTinue:MODulation:MERRor:HPSK	6.69
CONFigure:MODulation:MERRor[:OQPSk]:EREPorting[?].....	6.69
CONFigure:MODulation:MERRor:HPSK:EREPorting[?].....	6.69
FETCh[:SCALar]:MODulation:MERRor[:OQPSk]:STATus?	6.70
FETCh[:SCALar]:MODulation:MERRor:HPSK:STATus?	6.70
CONFigure:MODulation:MERRor[:OQPSk]:CONTRol[?]	6.71
CONFigure:MODulation:MERRor:HPSK:CONTRol[?].....	6.71
CONFigure:MODulation:MERRor[:OQPSk]:CONTRol:RMODe[?].....	6.71
CONFigure:MODulation:MERRor:HPSK:CONTRol:RMODe[?].....	6.71
CONFigure:MODulation:MERRor[:OQPSk]:CONTRol:STATistics[?].....	6.71
CONFigure:MODulation:MERRor:HPSK:CONTRol:STATistics[?].....	6.71
CONFigure:MODulation:MERRor[:OQPSk]:CONTRol:REPetition[?].....	6.72
CONFigure:MODulation:MERRor:HPSK:CONTRol:REPetition[?].....	6.72
CONFigure:SUBarrays:MODulation:MERRor[:OQPSk][?].....	6.73
CONFigure:SUBarrays:MODulation:MERRor:HPSK[?].....	6.73
READ[:SCALar]:MODulation:MERRor[:OQPSk]?	6.74
FETCh[:SCALar]:MODulation:MERRor[:OQPSk]?.....	6.74
SAMPle[:SCALar]:MODulation:MERRor[:OQPSk]?	6.74
READ[:SCALar]:MODulation:MERRor:HPSK?	6.74
FETCh[:SCALar]:MODulation:MERRor:HPSK?.....	6.74
SAMPle[:SCALar]:MODulation:MERRor:HPSK?	6.74
CALCulate[:SCALar]:MODulation:MERRor[:OQPSk]:MATChing:LIMit?	6.74
CALCulate[:SCALar]:MODulation:MERRor:HPSK:MATChing:LIMit?.....	6.74
READ:ARRay:MODulation:MERRor[:OQPSk]:CURRent?	6.75
READ:ARRay:MODulation:MERRor[:OQPSk]:AVERAge?.....	6.75
READ:ARRay:MODulation:MERRor[:OQPSk]:MMAx?.....	6.75

FETCh:ARRay:MODulation:MERRor[:OQPSk]:CURRent?	6.75
FETCh:ARRay:MODulation:MERRor[:OQPSk]:AVERAge?	6.75
FETCh:ARRay:MODulation:MERRor[:OQPSk]:MMAX?	6.75
SAMPlE:ARRay:MODulation:MERRor[:OQPSk]:CURRent?	6.75
SAMPlE:ARRay:MODulation:MERRor[:OQPSk]:AVERAge?	6.75
SAMPlE:ARRay:MODulation:MERRor[:OQPSk]:MMAX?	6.75
READ:ARRay:MODulation:MERRor:HPSK:CURRent?	6.75
READ:ARRay:MODulation:MERRor:HPSK:AVERAge?	6.75
READ:ARRay:MODulation:MERRor:HPSK:MMAX?	6.75
FETCh:ARRay:MODulation:MERRor:HPSK:CURRent?	6.75
FETCh:ARRay:MODulation:MERRor:HPSK:AVERAge?	6.75
FETCh:ARRay:MODulation:MERRor:HPSK:MMAX?	6.75
SAMPlE:ARRay:MODulation:MERRor:HPSK:CURRent?	6.75
SAMPlE:ARRay:MODulation:MERRor:HPSK:AVERAge?	6.75
SAMPlE:ARRay:MODulation:MERRor:HPSK:MMAX?	6.75
READ:SUBarrays:MODulation:MERRor[:OQPSk]:CURRent?	6.76
READ:SUBarrays:MODulation:MERRor[:OQPSk]:AVERAge?	6.76
READ:SUBarrays:MODulation:MERRor[:OQPSk]:MMAX?	6.76
FETCh:SUBarrays:MODulation:MERRor[:OQPSk]:CURRent?	6.76
FETCh:SUBarrays:MODulation:MERRor[:OQPSk]:AVERAge?	6.76
FETCh:SUBarrays:MODulation:MERRor[:OQPSk]:MMAX?	6.76
SAMPlE:SUBarrays:MODulation:MERRor[:OQPSk]:CURRent?	6.76
SAMPlE:SUBarrays:MODulation:MERRor[:OQPSk]:AVERAge?	6.76
SAMPlE:SUBarrays:MODulation:MERRor[:OQPSk]:MMAX?	6.76
READ:SUBarrays:MODulation:MERRor:HPSK:CURRent?	6.76
READ:SUBarrays:MODulation:MERRor:HPSK:AVERAge?	6.76
READ:SUBarrays:MODulation:MERRor:HPSK:MMAX?	6.76
FETCh:SUBarrays:MODulation:MERRor:HPSK:CURRent?	6.76
FETCh:SUBarrays:MODulation:MERRor:HPSK:AVERAge?	6.76
FETCh:SUBarrays:MODulation:MERRor:HPSK:MMAX?	6.76
SAMPlE:SUBarrays:MODulation:MERRor:HPSK:CURRent?	6.76
SAMPlE:SUBarrays:MODulation:MERRor:HPSK:AVERAge?	6.76
SAMPlE:SUBarrays:MODulation:MERRor:HPSK:MMAX?	6.76

Modulation (OEMP)

CONFigure:MODulation:OEMP[:OQPSk]:CMMax:LIMit[:SCALar]:SYMMetric[:COMBined][?]	6.46
CONFigure:MODulation:OEMP:HPSK:CMMax:LIMit[:SCALar]:SYMMetric[:COMBined][?]	6.46
CONFigure:MODulation:OEMP[:OQPSk]:AVERAge:LIMit[:SCALar]:SYMMetric[:COMBined][?]	6.47
CONFigure:MODulation:OEMP:HPSK:AVERAge:LIMit[:SCALar]:SYMMetric[:COMBined][?]	6.47
CONFigure:MODulation:OEMP[:OQPSk]:CMMax:LIMit[:SCALar]:SYMMetric[:COMBined]:VALue[?]	6.47
CONFigure:MODulation:OEMP:HPSK:CMMax:LIMit[:SCALar]:SYMMetric[:COMBined]:VALue[?]	6.47
CONFigure:MODulation:OEMP[:OQPSk]:AVERAge:LIMit[:SCALar]:SYMMetric[:COMBined]:VALue[?]	6.48
CONFigure:MODulation:OEMP:HPSK:AVERAge:LIMit[:SCALar]:SYMMetric[:COMBined]:VALue[?]	6.48
CONFigure:MODulation:OEMP[:OQPSk]:CMMax:LIMit[:SCALar]:SYMMetric[:COMBined]:ENABLE[?]	6.48
CONFigure:MODulation:OEMP:HPSK:CMMax:LIMit[:SCALar]:SYMMetric[:COMBined]:ENABLE[?]	6.48
CONFigure:MODulation:OEMP[:OQPSk]:AVERAge:LIMit[:SCALar]:SYMMetric[:COMBined]:ENABLE[?]	6.48
CONFigure:MODulation:OEMP:HPSK:AVERAge:LIMit[:SCALar]:SYMMetric[:COMBined]:ENABLE[?]	6.48
DEFault:MODulation:OEMP[:OQPSk]:LIMit[?]	6.49
DEFault:MODulation:OEMP:HPSK:LIMit[?]	6.49

Modulation (Overview)

INITiate:MODulation:OVERview[:OQPSk]	6.49
ABORt:MODulation:OVERview[:OQPSk]	6.49
STOP:MODulation:OVERview[:OQPSk]	6.49
CONTinue:MODulation:OVERview[:OQPSk]	6.49
INITiate:MODulation:OVERview:HPSK	6.49
ABORt:MODulation:OVERview:HPSK	6.49
STOP:MODulation:OVERview:HPSK	6.49

CONTinue:MODulation:OVERview:HPSK.....	6.49
CONFigure:MODulation:OVERview[:OQPSk]:EREPorting[?]	6.49
CONFigure:MODulation:OVERview:HPSK:EREPorting[?]	6.49
FETCh[:SCALar]:MODulation:OVERview[:OQPSk]:STATus?	6.50
FETCh[:SCALar]:MODulation:OVERview:HPSK:STATus?	6.50
CONFigure:MODulation:OVERview[:OQPSk]:CONTRol[?]	6.50
CONFigure:MODulation:OVERview:HPSK:CONTRol[?]	6.50
CONFigure:MODulation:OVERview[:OQPSk]:CONTRol:STATistics[?]	6.51
CONFigure:MODulation:OVERview:HPSK:CONTRol:STATistics[?]	6.51
CONFigure:MODulation:OVERview[:OQPSk]:CONTRol:REPetition[?]	6.51
CONFigure:MODulation:OVERview:HPSK:CONTRol:REPetition[?]	6.51
READ[:SCALar]:MODulation:OVERview[:OQPSk]?.....	6.52
FETCh[:SCALar]:MODulation:OVERview[:OQPSk]?.....	6.52
SAMPlE[:SCALar]:MODulation:OVERview[:OQPSk]?.....	6.52
READ[:SCALar]:MODulation:OVERview:HPSK?.....	6.52
FETCh[:SCALar]:MODulation:OVERview:HPSK?.....	6.52
SAMPlE[:SCALar]:MODulation:OVERview:HPSK?.....	6.52
CALCulate[:SCALar]:MODulation:OVERview[:OQPSk]:MATChing:LIMit?	6.53
CALCulate[:SCALar]:MODulation:OVERview:HPSK:MATChing:LIMit?	6.53

Modulation (Phase Error)

INITiate:MODulation:PERRor[:OQPSk].....	6.61
ABORt:MODulation:PERRor[:OQPSk].....	6.61
STOP:MODulation:PERRor[:OQPSk].....	6.61
CONTinue:MODulation:PERRor[:OQPSk].....	6.61
INITiate:MODulation:PERRor:HPSK.....	6.61
ABORt:MODulation:PERRor:HPSK.....	6.61
STOP:MODulation:PERRor:HPSK.....	6.61
CONTinue:MODulation:PERRor:HPSK.....	6.61
CONFigure:MODulation:PERRor[:OQPSk]:EREPorting[?]	6.61
CONFigure:MODulation:PERRor:HPSK:EREPorting[?]	6.61
FETCh[:SCALar]:MODulation:PERRor[:OQPSk]:STATus?	6.62
FETCh[:SCALar]:MODulation:PERRor:HPSK:STATus?	6.62
CONFigure:MODulation:PERRor[:OQPSk]:CONTRol[?]	6.63
CONFigure:MODulation:PERRor:HPSK:CONTRol[?]	6.63
CONFigure:MODulation:PERRor[:OQPSk]:CONTRol:STATistics[?]	6.63
CONFigure:MODulation:PERRor:HPSK:CONTRol:STATistics[?]	6.63
CONFigure:MODulation:PERRor[:OQPSk]:CONTRol:REPetition[?]	6.64
CONFigure:MODulation:PERRor:HPSK:CONTRol:REPetition[?]	6.64
CONFigure:MODulation:PERRor[:OQPSk]:CONTRol:RMODE[?]	6.64
CONFigure:MODulation:PERRor:HPSK:CONTRol:RMODE[?]	6.64
CONFigure:SUBarrays:MODulation:PERRor[:OQPSk][?]	6.65
CONFigure:SUBarrays:MODulation:PERRor:HPSK[?]	6.65
READ[:SCALar]:MODulation:PERRor[:OQPSk]?.....	6.66
FETCh[:SCALar]:MODulation:PERRor[:OQPSk]?.....	6.66
SAMPlE[:SCALar]:MODulation:PERRor[:OQPSk]?.....	6.66
READ[:SCALar]:MODulation:PERRor:HPSK?.....	6.66
FETCh[:SCALar]:MODulation:PERRor:HPSK?.....	6.66
SAMPlE[:SCALar]:MODulation:PERRor:HPSK?.....	6.66
CALCulate[:SCALar]:MODulation:PERRor[:OQPSk]:MATChing:LIMit?	6.66
CALCulate[:SCALar]:MODulation:PERRor:HPSK:MATChing:LIMit?	6.66
READ:ARRay:MODulation:PERRor[:OQPSk]:CURRent?	6.67
READ:ARRay:MODulation:PERRor[:OQPSk]:AVERAge?	6.67
READ:ARRay:MODulation:PERRor[:OQPSk]:MMAx?	6.67
FETCh:ARRay:MODulation:PERRor[:OQPSk]:CURRent?	6.67
FETCh:ARRay:MODulation:PERRor[:OQPSk]:AVERAge?	6.67
FETCh:ARRay:MODulation:PERRor[:OQPSk]:MMAx?	6.67
SAMPlE:ARRay:MODulation:PERRor[:OQPSk]:CURRent?	6.67
SAMPlE:ARRay:MODulation:PERRor[:OQPSk]:AVERAge?	6.67

SAMPlE:ARRAy:MODUlation:PERRor[:OQPSk]:MMAx?	6.67
READ:ARRAy:MODUlation:PERRor:HPSK:CURRent?	6.67
READ:ARRAy:MODUlation:PERRor:HPSK:AVERAge?	6.67
READ:ARRAy:MODUlation:PERRor:HPSK:MMAx?	6.67
FETCh:ARRAy:MODUlation:PERRor:HPSK:CURRent?	6.67
FETCh:ARRAy:MODUlation:PERRor:HPSK:AVERAge?	6.67
FETCh:ARRAy:MODUlation:PERRor:HPSK:MMAx?	6.67
SAMPlE:ARRAy:MODUlation:PERRor:HPSK:CURRent?	6.67
SAMPlE:ARRAy:MODUlation:PERRor:HPSK:AVERAge?	6.67
SAMPlE:ARRAy:MODUlation:PERRor:HPSK:MMAx?	6.67
READ:SUBArrays:MODUlation:PERRor[:OQPSk]:CURRent?	6.68
READ:SUBArrays:MODUlation:PERRor[:OQPSk]:AVERAge?	6.68
READ:SUBArrays:MODUlation:PERRor[:OQPSk]:MMAx?	6.68
FETCh:SUBArrays:MODUlation:PERRor[:OQPSk]:CURRent?	6.68
FETCh:SUBArrays:MODUlation:PERRor[:OQPSk]:AVERAge?	6.68
FETCh:SUBArrays:MODUlation:PERRor[:OQPSk]:MMAx?	6.68
SAMPlE:SUBArrays:MODUlation:PERRor[:OQPSk]:CURRent?	6.68
SAMPlE:SUBArrays:MODUlation:PERRor[:OQPSk]:AVERAge?	6.68
SAMPlE:SUBArrays:MODUlation:PERRor[:OQPSk]:MMAx?	6.68
READ:SUBArrays:MODUlation:PERRor:HPSK:CURRent?	6.68
READ:SUBArrays:MODUlation:PERRor:HPSK:AVERAge?	6.68
READ:SUBArrays:MODUlation:PERRor:HPSK:MMAx?	6.68
FETCh:SUBArrays:MODUlation:PERRor:HPSK:CURRent?	6.68
FETCh:SUBArrays:MODUlation:PERRor:HPSK:AVERAge?	6.68
FETCh:SUBArrays:MODUlation:PERRor:HPSK:MMAx?	6.68
SAMPlE:SUBArrays:MODUlation:PERRor:HPSK:CURRent?	6.68
SAMPlE:SUBArrays:MODUlation:PERRor:HPSK:AVERAge?	6.68
SAMPlE:SUBArrays:MODUlation:PERRor:HPSK:MMAx?	6.68

Narrow Band Power

INITiate:NPOWer	6.38
ABORt:NPOWer	6.38
STOP:NPOWer	6.38
CONTInue:NPOWer	6.38
CONFigure:NPOWer:EREPorting[?]	6.38
FETCh[:SCALar]:NPOWer:STATus?	6.38
CONFigure:NPOWer:CONTRol:CBSize[?]	6.39
CONFigure:NPOWer:CONTRol[?]	6.39
CONFigure:NPOWer:CONTRol:STATistics[?]	6.39
CONFigure:NPOWer:CONTRol:REPetition[?]	6.40
READ[:SCALar]:NPOWer?	6.41
FETCh[:SCALar]:NPOWer?	6.41
SAMPlE[:SCALar]:NPOWer?	6.41

Options

SYSTem:OPTions:INFO:CURRent?	6.31
------------------------------	------

Partial Reset

SYSTem:RESet:CURRent	6.32
----------------------	------

Power vs. Frame

INITiate:POWer:XSLot	6.26
ABORt:POWer:XSLot	6.26
STOP:POWer:XSLot	6.26
CONTInue:POWer:XSLot	6.26
CONFigure:POWer:XSLot:EREPorting	6.26

FETCh:POWer:XSLot:STATUs? 6.26

CONFigure:POWer:XSLot:CONTRol:REPetition 6.27

CONFigure:POWer:XSLot:CONTRol:PMWidth 6.27

CONFigure:POWer:XSLot:CONTRol:SCOUNT 6.27

CONFigure:POWer:XSLot:CONTRol:SWIDth 6.27

CONFigure:POWer:XSLot:CONTRol:SDELay 6.28

CONFigure:POWer:XSLot:CONTRol:SINTerval 6.28

CONFigure:POWer:XSLot:CONTRol:SINTerval:l<nr> 6.28

CONFigure:POWer:XSLot:CONTRol:SINTerval:DEViation 6.28

CONFigure:POWer:XSLot:CONTRol:SINTerval:DEViation:l<nr> 6.29

CONFigure:POWer:XSLot:CONTRol:SINTerval:SNUMber 6.29

CONFigure:POWer:XSLot:CONTRol:SINTerval:SNUMber:l<nr> 6.29

DEFault:POWer:XSLot:CONTRol 6.29

READ[:SCALar]:POWer:XSLot:CURRent? 6.30

FETCh[:SCALar]:POWer:XSLot:CURRent? 6.30

SAMPle[:SCALar]:POWer:XSLot:CURRent? 6.30

RF Analyzer

DEFault:RFANalyzer[?] 6.2

[SENSe:]RFANalyzer:FREQuency:UNIT[?] 6.2

[SENSe:]RFANalyzer:FREQuency[?] 6.3

[SENSe:]RFANalyzer:FOFFset[?] 6.3

RF Generator

DEFault:RFGenerator[?] 6.6

INITiate:RFGenerator 6.6

ABORt:RFGenerator 6.6

FETCh:RFGenerator:STATUs? 6.6

SOURce:RFGenerator:LEVel:OCNS:VALue? 6.6

SOURce:RFGenerator:LEVel:OCNS:ENABle[?] 6.7

SOURce:RFGenerator:FREQuency[:RF]:UNIT[?] 6.7

SOURce:RFGenerator:FREQuency[:RF][?] 6.7

SOURce:RFGenerator:CHANnel:FFCH[?] 6.7

SOURce:RFGenerator:PROPerty:PNOFFset[?] 6.8

SOURce:RFGenerator:QOF:FFCH[?] 6.8

SOURce:RFGenerator:FROFFset:FFCH[?] 6.8

SOURce:RFGenerator:FRATe:FFCH[?] 6.8

SOURce:RFGenerator:RC[?] 6.8

SOURce:RFGenerator:RSET? 6.8

SOURce:RFGenerator:SID 6.9

SOURce:RFGenerator:PREVision 6.9

SOURce:RFGenerator:MPREvision 6.9

SOURce:RFGenerator:NID 6.9

SOURce:RFGenerator:PCHannel:RATE 6.9

SOURce:RFGenerator:ESN 6.9

SOURce:RFGenerator:ZLCM 6.9

SOURce:RFGenerator:MODulation:MODE[?] 6.10

SOURce:RFGenerator:POWer:CDMA[?] 6.10

SOURce:RFGenerator:POWer:OUTput? 6.10

SOURce:RFGenerator:LEVel:FFCH[?] 6.10

SOURce:RFGenerator:LEVel:FSYNc[?] 6.11

SOURce:RFGenerator:LEVel:FPICh[?] 6.11

SOURce:RFGenerator:LEVel:FPCH[?] 6.11

CONFigure:RFGenerator:PCBits[?] 6.12

SOURce:RFGenerator: PATTern:SQMode[?] 6.12

SOURce:RFGenerator: PATTern: AREA<no>:NOBits[?] 6.12

SOURce:RFGenerator: PATTern: AREA1:LHBit[?] 6.12

SOURce:RFGenerator: PATTern: AREA<no>:POLarity[?] 6.12

RF Selectivity

CONFigure:RFSelectiv 6.35

Save/Recall

MMEMory:SAVE:CURRent 6.32

MMEMory:RECall:CURRent 6.32

Spectrum

INITiate:SPECTrum:ACP 6.80

ABORt:SPECTrum:ACP 6.80

STOP:SPECTrum:ACP 6.80

CONTInue:SPECTrum:ACP 6.80

CONFigure:SPECTrum:ACP:EREPorting[?] 6.80

FETCh[:SCALar]:SPECTrum:ACP:STATus? 6.81

CONFigure:SPECTrum:ACP:CONTRol[?] 6.82

CONFigure:SPECTrum:ACP:CONTRol:STATistics[?] 6.82

CONFigure:SPECTrum:ACP:CONTRol:REPetition[?] 6.83

DEFault:SPECTrum:ACP:CONTRol[?] 6.83

CONFigure:SPECTrum:ACP:CONTRol:FOFFset:ACP<nr>[?] 6.84

CONFigure:SPECTrum:ACP:LIMit:ACP1[?] 6.85

DEFault:SPECTrum:ACP:LIMit[?] 6.85

XTND:SPECTrum:ACP:STATistics[?] 6.85

READ[:SCALar]:SPECTrum:ACP? 6.86

FETCh[:SCALar]:SPECTrum:ACP? 6.86

SAMPlE[:SCALar]:SPECTrum:ACP? 6.86

CALCulate[:SCALar]:SPECTrum:ACP:MATChing:LIMit? 6.87

Symbolic Status Event Register Evaluation

STATus:OPERation:SYMBolic:ENABle 6.34

STATus:OPERation:SYMBolic:EVENTj? 6.34

XTND:STATus:OPERation:FGRegister[:EVENTj]? 6.35

XTND:STATus:OPERation:SYMBolic:EVENTj? 6.35

Version

SYSTem:VERSion:SW:MMI? 6.31

Wide Band Power

INITiate:WPOWER 6.36

ABORt:WPOWER 6.36

STOP:WPOWER 6.36

CONTInue:WPOWER 6.36

CONFigure:WPOWER:EREPorting 6.36

FETCh:WPOWER:STATus? 6.36

CONFigure:WPOWER:CONTRol:REPetition 6.37

READ[:SCALar]:WPOWER? 6.37

FETCh[:SCALar]:WPOWER? 6.37

SAMPlE[:SCALar]:WPOWER? 6.37

Trigger

DEFault:TRIGger[:SEQuence][?] 6.4

DEFault:TRIGger[:SEQuence]:SOURce[?] 6.4

TRIGger[:SEQuence]:SOURce[?] 6.4

TRIGger[:SEQuence]:THReshold:RFPower 6.5

<i>TRIGger[SEquence]:THReshold:IFPower</i>	6.5
<i>TRIGger[SEquence]:SLOPe</i>	6.5
<i>TRIGger:OUTPut:PIN<nr>:SIGNa[?]</i>	6.5

List of Signalling Commands

In the following, all remote-control commands of the CDMA2000 Signalling function group are listed. They are arranged alphabetically by the second keyword of the command so that related commands are listed together.

Table 6-2 Remote-control commands (Signalling)

Base Station Signal

<i>DEFault:BSSignal[?]</i>	6.175
<i>UNIT:BSSignal:CHANnel[:RF][?]</i>	6.175
<i>CONFigure:BSSignal:CHANnel[:RF][?]</i>	6.176
<i>PROCeDure:BSSignal:CHANnel[:RF][?]</i>	6.176
<i>CONFigure:BSSignal:POWer:CDMA[?]</i>	6.176
<i>PROCeDure:BSSignal:POWer:CDMA[?]</i>	6.176
<i>CONFigure:BSSignal:POWer:OUTPut?</i>	6.177
<i>CONFigure:BSSignal:LEVel:FSYNc[?]</i>	6.177
<i>CONFigure:BSSignal:LEVel:FPiCh[?]</i>	6.177
<i>CONFigure:BSSignal:LEVel:OCNS:ENABle[?]</i>	6.177
<i>CONFigure:BSSignal:LEVel:OCNS:VALue?</i>	6.178
<i>CONFigure:BSSignal:PCBits[?]</i>	6.178
<i>CONFigure:BSSignal:PATtern:SQMode[?]</i>	6.178
<i>CONFigure:BSSignal:PATtern:SSiZe[?]</i>	6.178
<i>CONFigure:BSSignal: PATtern:AREA<no>:NOBits[?]</i>	6.179
<i>CONFigure:BSSignal:PATtern:AREA1:LHBit[?]</i>	6.179
<i>CONFigure:BSSignal:PATtern:AREA<no>:POLarity[?]</i>	6.179
<i>CONFigure:BSSignal:CHANnel:FFCH[?]</i>	6.179
<i>PROCeDure:BSSignal:CHANnel:FFCH[?]</i>	6.179
<i>CONFigure:BSSignal:LEVel:FFCH[?]</i>	6.180
<i>PROCeDure:BSSignal:LEVel:FFCH[?]</i>	6.180
<i>CONFigure:BSSignal:FROffset:FFCH[?]</i>	6.180
<i>PROCeDure:BSSignal:FROffset:FFCH[?]</i>	6.180
<i>CONFigure:BSSignal:QOF:FFCH[?]</i>	6.180
<i>PROCeDure:BSSignal:QOF:FFCH[?]</i>	6.180
<i>CALCulate[:SCALar]:BSSignal:EBNT:FFCH?</i>	6.180
<i>CONFigure:BSSignal:LEVel:FSCH:ZERO[?]</i>	6.181
<i>PROCeDure:BSSignal:LEVel:FSCH:ZERO[?]</i>	6.181
<i>CONFigure:BSSignal:CHANnel:FSCH:ZERO[?]</i>	6.181
<i>PROCeDure:BSSignal:CHANnel:FSCH:ZERO[?]</i>	6.181
<i>CONFigure:BSSignal:FROffset:FSCH:ZERO[?]</i>	6.181
<i>PROCeDure:BSSignal:FROffset:FSCH:ZERO[?]</i>	6.181
<i>CONFigure:BSSignal:QOF:FSCH:ZERO[?]</i>	6.182
<i>PROCeDure:BSSignal:QOF:FSCH:ZERO[?]</i>	6.182
<i>CALCulate[:SCALar]:BSSignal:EBNT:FSCH:ZERO?</i>	6.182
<i>CONFigure:BSSignal:LEVel:FSCH:ONE[?]</i>	6.182
<i>PROCeDure:BSSignal:LEVel:FSCH:ONE[?]</i>	6.182
<i>CONFigure:BSSignal:CHANnel:FSCH:ONE[?]</i>	6.183
<i>PROCeDure:BSSignal:CHANnel:FSCH:ONE[?]</i>	6.183
<i>CONFigure:BSSignal:FROffset:FSCH:ONE[?]</i>	6.183
<i>PROCeDure:BSSignal:FROffset:FSCH:ONE[?]</i>	6.183
<i>CONFigure:BSSignal:QOF:FSCH:ONE[?]</i>	6.183
<i>PROCeDure:BSSignal:QOF:FSCH:ONE[?]</i>	6.183
<i>CALCulate[:SCALar]:BSSignal:EBNT:FSCH:ONE?</i>	6.183
<i>CONFigure:BSSignal:CHANnel:FPCH[?]</i>	6.184
<i>PROCeDure:BSSignal:CHANnel:FPCH[?]</i>	6.184
<i>CONFigure:BSSignal:LEVel:FPCH[?]</i>	6.184
<i>PROCeDure:BSSignal:LEVel:FPCH[?]</i>	6.184
<i>CONFigure:BSSignal:USAGe:FQPCh[?]</i>	6.184

PROCedure:BSSignal:USAGe:FQPCh[?]	6.184
CONFigure:BSSignal:CHANnel:FQPCh?	6.184
PROCedure:BSSignal:CHANnel:FQPCh?	6.184
CONFigure:BSSignal:LEVel:FQPCh[?]	6.185
PROCedure:BSSignal:LEVel:FQPCh[?]	6.185
CONFigure:BSSignal:IBITs:FQPCh[?]	6.185
PROCedure:BSSignal:IBITs:FQPCh[?]	6.185
CONFigure:BSSignal:DUTPaging:FQPCh[?]	6.185
PROCedure:BSSignal:DUTPaging:FQPCh[?]	6.185
CONFigure:BSSignal:PROPerTy:PNOFFset[?]	6.186
PROCedure:BSSignal:PROPerTy:PNOFFset[?]	6.186
CONFigure:BSSignal:PROPerTy:CLDTime[?]	6.186
CONFigure:BSSignal:PROPerTy:PRTIMEout[?]	6.186

Code Domain Power (Common)

CONFigure:CDPower:CPCCCommon:ENVironment:ENABle[?]	6.88
CONFigure:CDPower:CPCCCommon:ENVironment:LEVel[?]	6.88
CONFigure:CDPower:CPCCCommon:ENVironment:LEVel:FPICh[?]	6.89
CONFigure:CDPower:CPCCCommon:ENVironment:LEVel:FFCH[?]	6.89
CONFigure:CDPower:CPCCCommon:ENVironment:LEVel:FSCH:ZERO[?]	6.89
CONFigure:CDPower:CPCCCommon:ENVironment:LEVel:FSCH:ONE[?]	6.89
CONFigure:CDPower:CPCCCommon:ENVironment:EBNT:FFCH?	6.89
CONFigure:CDPower:CPCCCommon:ENVironment:EBNT:FSCH:ZERO?	6.90
CONFigure:CDPower:CPCCCommon:ENVironment:EBNT:FSCH:ONE?	6.90
CONFigure:CDPower:CPCCCommon:ENVironment:FRAte:FFCH[?]	6.90
CONFigure:CDPower:CPCCCommon:ENVironment:IMPairments:LEVel:AWGN[?]	6.90
CONFigure:CDPower:CPCCCommon:ENVironment:IMPairments:FOFFset[?]	6.91
CONFigure:CDPower:CPCCCommon:ENVironment:IMPairments:ITFer[?]	6.91
CONFigure:CDPower:CPCCCommon:ENVironment:PCBits[?]	6.91
CONFigure:CDPower:CPCCCommon:LIMit:IQLCheck[?]	6.92
CONFigure:CDPower:CPCCCommon:CMAX:LIMit:ASYMmetric:COMBined[?]	6.92
CONFigure:CDPower:CPCCCommon:AVERAge:LIMit:ASYMmetric:COMBined[?]	6.93
DEFault:CDPower:CPCCCommon:LIMit[?]	6.93

Code Domain Power

INITiate:CDPower:CDPW	6.94
ABORt:CDPower:CDPW	6.94
STOP:CDPower:CDPW	6.94
CONTInue:CDPower:CDPW	6.94
CONFigure:CDPower:CDPW:EREPorting[?]	6.94
CONFigure:CDPower:CDPW:CMAX:LIMit:ASYMmetric:COMBined[?]	6.94
CONFigure:CDPower:CDPW:AVERAge:LIMit:ASYMmetric:COMBined[?]	6.94
DEFault:CDPower:CDPW:LIMit[?]	6.95
FETCh[:SCALar]:CDPower:CDPW:STATus?	6.95
CONFigure:CDPower:CDPW:CONTrol[?]	6.96
CONFigure:CDPower:CDPW:CONTrol:SFActor[?]	6.96
CONFigure:CDPower:CDPW:CONTrol:RMODe[?]	6.96
CONFigure:CDPower:CDPW:CONTrol:STATistics[?]	6.97
CONFigure:CDPower:CDPW:CONTrol:REPetition[?]	6.97
CONFigure:CDPower:CDPW:CONTrol:ROrDer[?]	6.97
READ:ARRay:CDPower:CHPW:ISIGnal[:VALue]:CURRent?	6.98
FETCh:ARRay:CDPower:CHPW:ISIGnal[:VALue]:CURRent?	6.98
SAMPle:ARRay:CDPower:CHPW:ISIGnal[:VALue]:CURRent?	6.98
READ:ARRay:CDPower:CHPW:ISIGnal[:VALue]:AVERAge?	6.98
FETCh:ARRay:CDPower:CHPW:ISIGnal[:VALue]:AVERAge?	6.98
SAMPle:ARRay:CDPower:CHPW:ISIGnal[:VALue]:AVERAge?	6.98
READ:ARRay:CDPower:CHPW:ISIGnal[:VALue]:MAXimum?	6.98
FETCh:ARRay:CDPower:CHPW:ISIGnal[:VALue]:MAXimum?	6.98

SAMPlE:ARRAy:CDPower:CHPW:ISIGnal[:VALue]:MAXimum? 6.98
 READ:ARRAy:CDPower:CHPW:QSIGnal[:VALue]:CURRent? 6.98
 FETCh:ARRAy:CDPower:CHPW:QSIGnal[:VALue]:CURRent? 6.98
 SAMPlE:ARRAy:CDPower:CHPW:QSIGnal[:VALue]:CURRent? 6.98
 READ:ARRAy:CDPower:CHPW:QSIGnal[:VALue]:AVERAge? 6.99
 FETCh:ARRAy:CDPower:CHPW:QSIGnal[:VALue]:AVERAge? 6.99
 SAMPlE:ARRAy:CDPower:CHPW:QSIGnal[:VALue]:AVERAge? 6.99
 READ:ARRAy:CDPower:CHPW:QSIGnal[:VALue]:MAXimum? 6.99
 FETCh:ARRAy:CDPower:CHPW:QSIGnal[:VALue]:MAXimum? 6.99
 SAMPlE:ARRAy:CDPower:CHPW:QSIGnal[:VALue]:MAXimum? 6.99
 FETCh:ARRAy:CDPower:CDPW:ISIGnal:STATe? 6.99
 FETCh:ARRAy:CDPower:CDPW:QSIGnal:STATe? 6.99
 SAMPlE[:SCALAr]:CDPower:CDPW? 6.99
 READ[:SCALAr]:CDPower:CDPW? 6.99
 FETCh[:SCALAr]:CDPower:CDPW? 6.99
 CALCulate[:SCALAr]:CDPower:CDPW:MATChing:LIMit? 6.100
 CALCulate:ARRAy:CDPower:CDPW:ISIGnal:CURRent[:RESult]:MATChing:LIMit? 6.100
 CALCulate:ARRAy:CDPower:CDPW:ISIGnal:AVERAge[:RESult]:MATChing:LIMit? 6.100
 CALCulate:ARRAy:CDPower:CDPW:ISIGnal:MAXimum[:RESult]:MATChing:LIMit? 6.100
 CALCulate:ARRAy:CDPower:CDPW:QSIGnal:CURRent[:RESult]:MATChing:LIMit? 6.100
 CALCulate:ARRAy:CDPower:CDPW:QSIGnal:AVERAge[:RESult]:MATChing:LIMit? 6.101
 CALCulate:ARRAy:CDPower:CDPW:QSIGnal:MAXimum[:RESult]:MATChing:LIMit? 6.101

Code Domain Power (Peak Code Domain Error Power)

INITiate:CDPower:PCDep 6.101
 ABORt:CDPower:PCDep 6.101
 CONTInue:CDPower:PCDep 6.101
 STOP:CDPower:PCDep 6.101
 CONFigure:CDPower:PCDep:EREPorting[?] 6.101
 CONFigure:CDPower:PCDep:CMAx:LIMit:ASYMmetric[:COMBined][?] 6.102
 CONFigure:CDPower:PCDep:AVERAge:LIMit:ASYMmetric[:COMBined][?] 6.102
 DEFault:CDPower:PCDep:LIMit[?] 6.102
 FETCh[:SCALAr]:CDPower:PCDep:STATus? 6.103
 CONFigure:CDPower:PCDep:CONTRol[?] 6.103
 CONFigure:CDPower:PCDep:CONTRol:RMODE[?] 6.104
 CONFigure:CDPower:PCDep:CONTRol:SFACTOR[?] 6.104
 CONFigure:CDPower:PCDep:CONTRol:RORDer[?] 6.104
 CONFigure:CDPower:PCDep:CONTRol:STATistics[?] 6.104
 CONFigure:CDPower:PCDep:CONTRol:REPetition[?] 6.105
 READ:ARRAy:CDPower:PCDep:ISIGnal[:VALue]:CURRent? 6.105
 FETCh:ARRAy:CDPower:PCDep:ISIGnal[:VALue]:CURRent? 6.105
 SAMPlE:ARRAy:CDPower:PCDep:ISIGnal[:VALue]:CURRent? 6.105
 READ:ARRAy:CDPower:PCDep:ISIGnal[:VALue]:AVERAge? 6.106
 FETCh:ARRAy:CDPower:PCDep:ISIGnal[:VALue]:AVERAge? 6.106
 SAMPlE:ARRAy:CDPower:PCDep:ISIGnal[:VALue]:AVERAge? 6.106
 READ:ARRAy:CDPower:PCDep:ISIGnal[:VALue]:MAXimum? 6.106
 FETCh:ARRAy:CDPower:PCDep:ISIGnal[:VALue]:MAXimum? 6.106
 SAMPlE:ARRAy:CDPower:PCDep:ISIGnal[:VALue]:MAXimum? 6.106
 READ:ARRAy:CDPower:PCDep:QSIGnal[:VALue]:CURRent? 6.106
 FETCh:ARRAy:CDPower:PCDep:QSIGnal[:VALue]:CURRent? 6.106
 SAMPlE:ARRAy:CDPower:PCDep:QSIGnal[:VALue]:CURRent? 6.106
 READ:ARRAy:CDPower:PCDep:QSIGnal[:VALue]:AVERAge? 6.106
 FETCh:ARRAy:CDPower:PCDep:QSIGnal[:VALue]:AVERAge? 6.106
 SAMPlE:ARRAy:CDPower:PCDep:QSIGnal[:VALue]:AVERAge? 6.106
 READ:ARRAy:CDPower:PCDep:QSIGnal[:VALue]:MAXimum? 6.107
 FETCh:ARRAy:CDPower:PCDep:QSIGnal[:VALue]:MAXimum? 6.107
 SAMPlE:ARRAy:CDPower:PCDep:QSIGnal[:VALue]:MAXimum? 6.107
 FETCh:ARRAy:CDPower:PCDep:ISIGnal:STATe? 6.107
 FETCh:ARRAy:CDPower:PCDep:QSIGnal:STATe? 6.107

SAMPlE[:SCALar]:CDPower:PCDep? 6.107
 READ[:SCALar]:CDPower:PCDep? 6.107
 FETCh[:SCALar]:CDPower:PCDep? 6.107
 CALCulate[:SCALar]:CDPower:PCDep:MATChing:LIMit? 6.108
 CALCulate:ARRay:CDPower:PCDep:ISIGnal:CURRent[:RESult]:MATChing:LIMit? 6.108
 CALCulate:ARRay:CDPower:PCDep:ISIGnal:AVERage[:RESult]:MATChing:LIMit? 6.108
 CALCulate:ARRay:CDPower:PCDep:ISIGnal:MAXimum[:RESult]:MATChing:LIMit? 6.108
 CALCulate:ARRay:CDPower:PCDep:QSIGnal:CURRent[:RESult]:MATChing:LIMit? 6.108
 CALCulate:ARRay:CDPower:PCDep:QSIGnal:AVERage[:RESult]:MATChing:LIMit? 6.109
 CALCulate:ARRay:CDPower:PCDep:QSIGnal:MAXimum[:RESult]:MATChing:LIMit? 6.109

Code Domain Power (Channel Power)

INITiate:CDPower:CHPW 6.109
 ABORt:CDPower:CHPW 6.109
 STOP:CDPower:CHPW 6.109
 CONTinue:CDPower:CHPW 6.109
 CONFigure:CDPower:CHPW:EREPorting[?] 6.109
 CONFigure:CDPower:CHPW:CMAx:LIMit:ASYMmetric[:COMBined][?] 6.110
 CONFigure:CDPower:CHPW:AVERage:LIMit:ASYMmetric[:COMBined][?] 6.110
 DEFault:CDPower:CHPW:LIMit[?][?] 6.110
 FETCh[:SCALar]:CDPower:CHPW:STATus? 6.111
 CONFigure:CDPower:CHPW:CONTRol[?] 6.111
 CONFigure:CDPower:CHPW:CONTRol:RMODE[?] 6.112
 CONFigure:CDPower:CHPW:CONTRol:STATistics[?] 6.112
 CONFigure:CDPower:CHPW:CONTRol:REPetition[?] 6.112
 READ:ARRay:CDPower:CHPW:ISIGnal[:VALue]:CURRent? 6.113
 FETCh:ARRay:CDPower:CHPW:ISIGnal[:VALue]:CURRent? 6.113
 SAMPlE:ARRay:CDPower:CHPW:ISIGnal[:VALue]:CURRent? 6.113
 READ:ARRay:CDPower:CHPW:ISIGnal[:VALue]:AVERage? 6.113
 FETCh:ARRay:CDPower:CHPW:ISIGnal[:VALue]:AVERage? 6.113
 SAMPlE:ARRay:CDPower:CHPW:ISIGnal[:VALue]:AVERage? 6.113
 READ:ARRay:CDPower:CHPW:ISIGnal[:VALue]:MAXimum? 6.113
 FETCh:ARRay:CDPower:CHPW:ISIGnal[:VALue]:MAXimum? 6.113
 SAMPlE:ARRay:CDPower:CHPW:ISIGnal[:VALue]:MAXimum? 6.113
 READ:ARRay:CDPower:CHPW:QSIGnal[:VALue]:CURRent? 6.113
 FETCh:ARRay:CDPower:CHPW:QSIGnal[:VALue]:CURRent? 6.113
 SAMPlE:ARRay:CDPower:CHPW:QSIGnal[:VALue]:CURRent? 6.113
 READ:ARRay:CDPower:CHPW:QSIGnal[:VALue]:AVERage? 6.114
 FETCh:ARRay:CDPower:CHPW:QSIGnal[:VALue]:AVERage? 6.114
 SAMPlE:ARRay:CDPower:CHPW:QSIGnal[:VALue]:AVERage? 6.114
 READ:ARRay:CDPower:CHPW:QSIGnal[:VALue]:MAXimum? 6.114
 FETCh:ARRay:CDPower:CHPW:QSIGnal[:VALue]:MAXimum? 6.114
 SAMPlE:ARRay:CDPower:CHPW:QSIGnal[:VALue]:MAXimum? 6.114
 FETCh:ARRay:CDPower:CHPW:ISIGnal:STATe? 6.114
 FETCh:ARRay:CDPower:CHPW:QSIGnal:STATe? 6.114
 READ[:SCALar]:CDPower:CHPW? 6.115
 FETCh[:SCALar]:CDPower:CHPW? 6.115
 SAMPlE[:SCALar]:CDPower:CHPW? 6.115
 CALCulate:ARRay:CDPower:CHPW:ISIGnal:CURRent[:RESult]:MATChing:LIMit? 6.115
 CALCulate:ARRay:CDPower:CHPW:ISIGnal:AVERage[:RESult]:MATChing:LIMit? 6.115
 CALCulate:ARRay:CDPower:CHPW:ISIGnal:MAXimum[:RESult]:MATChing:LIMit? 6.115
 CALCulate:ARRay:CDPower:CHPW:QSIGnal:CURRent[:RESult]:MATChing:LIMit? 6.115
 CALCulate:ARRay:CDPower:CHPW:QSIGnal:AVERage[:RESult]:MATChing:LIMit? 6.116
 CALCulate:ARRay:CDPower:CHPW:QSIGnal:MAXimum[:RESult]:MATChing:LIMit? 6.116
 CALCulate[:SCALar]:CDPower:CHPW:MATChing:LIMit? 6.116

Code Domain Power (Phase Offset)

INITiate:CDPower:POFFset 6.117

ABORt:CDPower:POFFset.....	6.117
STOP:CDPower:POFFset.....	6.117
CONTInue:CDPower:POFFset.....	6.117
CONFigure:CDPower:POFFset:EREPorting[?].	6.117
FETCh[:SCALar]:CDPower:POFFset:STATus?	6.117
CONFigure:CDPower:POFFset:CONTRol[?].	6.118
CONFigure:CDPower:POFFset:CONTRol:RMODE[?].	6.118
CONFigure:CDPower:POFFset:CONTRol:STATistics[?].	6.118
CONFigure:CDPower:POFFset:CONTRol:REPetition[?].	6.119
CONFigure:CDPower:POFFset:CMAX:LIMit[?].	6.119
CONFigure:CDPower:POFFset:AVERAge:LIMit[?].	6.119
DEFault:CDPower:POFFset:LIMit[?][?].	6.119
READ[:SCALar]:CDPower:POFFset?.....	6.120
FETCh[:SCALar]:CDPower:POFFset?.....	6.120
SAMPle[:SCALar]:CDPower:POFFset?.....	6.120
CALCulate[:SCALar]:CDPower:POFFset:MATChing:LIMit?.....	6.120
READ:ARRay:CDPower:POFFset:ISIGnal[:VALue]:CURRent?.....	6.121
FETCh:ARRay:CDPower:POFFset:ISIGnal[:VALue]:CURRent?.....	6.121
SAMPle:ARRay:CDPower:POFFset:ISIGnal[:VALue]:CURRent?.....	6.121
READ:ARRay:CDPower:POFFset:ISIGnal[:VALue]:AVERAge?.....	6.121
FETCh:ARRay:CDPower:POFFset:ISIGnal[:VALue]:AVERAge?.....	6.121
SAMPle:ARRay:CDPower:POFFset:ISIGnal[:VALue]:AVERAge?.....	6.121
READ:ARRay:CDPower:POFFset:ISIGnal[:VALue]:MAXimum?.....	6.121
FETCh:ARRay:CDPower:POFFset:ISIGnal[:VALue]:MAXimum?.....	6.121
SAMPle:ARRay:CDPower:POFFset:ISIGnal[:VALue]:MAXimum?.....	6.121
READ:ARRay:CDPower:POFFset:QSIGnal[:VALue]:CURRent?.....	6.121
FETCh:ARRay:CDPower:POFFset:QSIGnal[:VALue]:CURRent?.....	6.121
SAMPle:ARRay:CDPower:POFFset:QSIGnal[:VALue]:CURRent?.....	6.121
READ:ARRay:CDPower:POFFset:QSIGnal[:VALue]:AVERAge?.....	6.121
FETCh:ARRay:CDPower:POFFset:QSIGnal[:VALue]:AVERAge?.....	6.121
SAMPle:ARRay:CDPower:POFFset:QSIGnal[:VALue]:AVERAge?.....	6.121
READ:ARRay:CDPower:POFFset:QSIGnal[:VALue]:MAXimum?.....	6.121
FETCh:ARRay:CDPower:POFFset:QSIGnal[:VALue]:MAXimum?.....	6.121
SAMPle:ARRay:CDPower:POFFset:QSIGnal[:VALue]:MAXimum?.....	6.121
FETCh:ARRay:CDPower:POFFset:ISIGnal:STATe?.....	6.121
FETCh:ARRay:CDPower:POFFset:QSIGnal:STATe?.....	6.122
CALCulate:ARRay:CDPower:POFFset:ISIGnal:CURRent[:RESult]:MATChing:LIMit?.....	6.122
CALCulate:ARRay:CDPower:POFFset:ISIGnal:AVERAge[:RESult]:MATChing:LIMit?.....	6.122
CALCulate:ARRay:CDPower:POFFset:ISIGnal:MAXimum[:RESult]:MATChing:LIMit?.....	6.122
CALCulate:ARRay:CDPower:POFFset:QSIGnal:CURRent[:RESult]:MATChing:LIMit?.....	6.122
CALCulate:ARRay:CDPower:POFFset:QSIGnal:AVERAge[:RESult]:MATChing:LIMit?.....	6.122
CALCulate:ARRay:CDPower:POFFset:QSIGnal:MAXimum[:RESult]:MATChing:LIMit?.....	6.122

Code Domain Power (Timing Offset)

INITiate:CDPower:TOFFset.....	6.123
ABORt:CDPower:TOFFset.....	6.123
STOP:CDPower:TOFFset.....	6.123
CONTInue:CDPower:TOFFset.....	6.123
CONFigure:CDPower:TOFFset:EREPorting[?].	6.123
FETCh[:SCALar]:CDPower:TOFFset:STATus?	6.123
CONFigure:CDPower:TOFFset:CONTRol[?].	6.124
CONFigure:CDPower:TOFFset:CONTRol:RMODE[?].	6.124
CONFigure:CDPower:TOFFset:CONTRol:STATistics[?].	6.124
CONFigure:CDPower:TOFFset:CONTRol:REPetition[?].	6.125
CONFigure:CDPower:TOFFset:CMAX:LIMit[?].	6.125
CONFigure:CDPower:TOFFset:AVERAge:LIMit[?].	6.125
DEFault:CDPower:TOFFset:LIMit[?][?].	6.125
READ[:SCALar]:CDPower:TOFFset?.....	6.126
FETCh[:SCALar]:CDPower:TOFFset?.....	6.126

SAMPlE[:SCALar]:CDPower:TOFFset? 6.126
 CALCulate[:SCALar]:CDPower:TOFFset:MATChing:LIMit? 6.126
 READ:ARRay:CDPower:TOFFset:ISIGnal[:VALue]:CURRent? 6.127
 FETCh:ARRay:CDPower:TOFFset:ISIGnal[:VALue]:CURRent? 6.127
 SAMPlE:ARRay:CDPower:TOFFset:ISIGnal[:VALue]:CURRent? 6.127
 READ:ARRay:CDPower:TOFFset:ISIGnal[:VALue]:AVERAge? 6.127
 FETCh:ARRay:CDPower:TOFFset:ISIGnal[:VALue]:AVERAge? 6.127
 SAMPlE:ARRay:CDPower:TOFFset:ISIGnal[:VALue]:AVERAge? 6.127
 READ:ARRay:CDPower:TOFFset:ISIGnal[:VALue]:MAXimum? 6.127
 FETCh:ARRay:CDPower:TOFFset:ISIGnal[:VALue]:MAXimum? 6.127
 SAMPlE:ARRay:CDPower:TOFFset:ISIGnal[:VALue]:MAXimum? 6.127
 READ:ARRay:CDPower:TOFFset:QSIGnal[:VALue]:CURRent? 6.127
 FETCh:ARRay:CDPower:TOFFset:QSIGnal[:VALue]:CURRent? 6.127
 SAMPlE:ARRay:CDPower:TOFFset:QSIGnal[:VALue]:CURRent? 6.127
 READ:ARRay:CDPower:TOFFset:QSIGnal[:VALue]:AVERAge? 6.127
 FETCh:ARRay:CDPower:TOFFset:QSIGnal[:VALue]:AVERAge? 6.127
 SAMPlE:ARRay:CDPower:TOFFset:QSIGnal[:VALue]:AVERAge? 6.127
 READ:ARRay:CDPower:TOFFset:QSIGnal[:VALue]:MAXimum? 6.127
 FETCh:ARRay:CDPower:TOFFset:QSIGnal[:VALue]:MAXimum? 6.127
 SAMPlE:ARRay:CDPower:TOFFset:QSIGnal[:VALue]:MAXimum? 6.127
 FETCh:ARRay:CDPower:TOFFset:ISIGnal:STATe? 6.127
 FETCh:ARRay:CDPower:TOFFset:QSIGnal:STATe? 6.128
 CALCulate:ARRay:CDPower:TOFFset:ISIGnal:CURRent[:RESult]:MATChing:LIMit? 6.128
 CALCulate:ARRay:CDPower:TOFFset:ISIGnal:AVERAge[:RESult]:MATChing:LIMit? 6.128
 CALCulate:ARRay:CDPower:TOFFset:ISIGnal:MAXimum[:RESult]:MATChing:LIMit? 6.128
 CALCulate:ARRay:CDPower:TOFFset:QSIGnal:CURRent[:RESult]:MATChing:LIMit? 6.128
 CALCulate:ARRay:CDPower:TOFFset:QSIGnal:AVERAge[:RESult]:MATChing:LIMit? 6.128
 CALCulate:ARRay:CDPower:TOFFset:QSIGnal:MAXimum[:RESult]:MATChing:LIMit? 6.128

Connection Info

[SENSe:]CINFo:DNUMber? 6.135
 [SENSe:]CINFo:GECall? 6.136
 [SENSe:]CINFo:SOPtion? 6.136
 [SENSe:]CINFo:FCH:MOPTions? 6.136
 [SENSe:]CINFo:FCH:RC? 6.136
 [SENSe:]CINFo:SCH:ZERO:MOPTions? 6.136
 [SENSe:]CINFo:SCH:ZERO:RC? 6.137

Environments

CONFigure:ALL:ENVironment:ENABle[?] 6.206

Handoff

STATus:HANDoff:TARGet:LIST? 6.188
 CONFigure:HANDoff:TARGet[?] 6.188

Impairments

CONFigure:IMPairments:LEVel:AWGN[?] 6.187
 CONFigure:IMPairments:FOFFset[:RF][?] 6.187
 CONFigure:IMPairments[?] 6.187

Inputs and Outputs

INPut[:STATe] 6.201
 OUTPut[:STATe] 6.201
 [SENSe:]CORRection:LOSS:INPut<nr>[:MAGNitude] 6.202

SOURce:CORRection:LOSS:INPut<nr>[:MAGNitude].....	6.202
[SENSe:]CORRection:LOSS:OUTPut<nr>[:MAGNitude].....	6.202
SOURce:CORRection:LOSS:OUTPut<nr>[:MAGNitude].....	6.202
ROUTe:SPENcoder[:INPut][?]	6.202
ROUTe:SPDecoDer[:OUTPut][?]	6.202
SOURce:DM:CLOCK:STATE.....	6.203
SOURce:DM:CLOCK:FREQUency.....	6.203

I/Q-IF Interface

CONFigure:IQIF:RXTXcombined	6.32
CONFigure:IQIF:RXPath	6.32
CONFigure:IQIF:TXPath	6.33
[SENSe:]IQIF:LEVel?	6.33

Menu – Connection Control Behavior

CONFigure:MENU:CCTRI:AOPen[?]	6.206
CONFigure:MENU:CCTRI:AClose[?]	6.206

Messaging (WMT) Info

[SENSe:]MINFo:SMS:LOUTgoing:TSTamp?.....	6.137
[SENSe:]MINFo:SMS:LOUTgoing:ACKNowledge?	6.137
[SENSe:]MINFo:SMS:LOUTgoing:CCODE?	6.137
[SENSe:]MINFo:SMS:LRECeived:TSTamp?.....	6.138
[SENSe:]MINFo:SMS:LRECeived:TEXT?	6.138

Mobile Station Signalling Info

[SENSe:]MSSinfo?.....	6.134
[SENSe:]MSSinfo:PREVision?	6.134
[SENSe:]MSSinfo:BCLSupport?.....	6.134

Mobile Station Signal

CONFigure:MSSignal:ID[?]	6.100
CONFigure:MSSignal:ID:URData[?]	6.100
CONFigure:MSSignal:MCReport[?]	6.100
CONFigure:MSSignal:MCC[?]	6.100

Narrow Band Power

INITiate:NPOWER	6.37
ABORt:NPOWER.....	6.37
STOP:NPOWER.....	6.37
CONTInue:NPOWER.....	6.37
CONFigure:NPOWER:EREPorting[?]	6.37
FETCh[:SCALar]:NPOWER:STATus?.....	6.37
CONFigure:NPOWER:CONTRol:CBSize[?]	6.38
CONFigure:NPOWER:CONTRol[?]	6.38
CONFigure:NPOWER:CONTRol:STATistics[?]	6.38
CONFigure:NPOWER:CONTRol:REPetition[?]	6.39
READ[:SCALar]:NPOWER?.....	6.39
FETCh[:SCALar]:NPOWER?	6.39
SAMPlE[:SCALar]:NPOWER?.....	6.39

Network

CONFigure:NETWork:IDENtity:NID[?] 6.189

CONFigure:NETWork:IDENtity:MCC[?] 6.189

CONFigure:NETWork:SYSTem:SID[?] 6.191

CONFigure:NETWork:SYSTem:SWA[?] 6.191

CONFigure:NETWork:SYSTem:SWN[?] 6.191

CONFigure:NETWork:SYSTem:SWR[?] 6.191

CONFigure:NETWork:SYSTem:BSID[?] 6.192

CONFigure:NETWork:SYSTem:PREVision[?] 6.192

CONFigure:NETWork:SYSTem:MPRevision[?] 6.192

CONFigure:NETWork:SYSTem:IMSI:ETWelve[?] 6.192

CONFigure:NETWork:SYSTem:UWCard[?] 6.193

CONFigure:NETWork:SYSTem:AUTHentic[?] 6.193

CONFigure:NETWork:SYSTem:ACHallenge[?] 6.193

CONFigure:NETWork:CINDicator:CID 6.193

CONFigure:NETWork:CINDicator:PINdicator 6.194

CONFigure:NETWork:CINDicator:CWINdicator 6.194

CONFigure:NETWork:PCHannel:RATE 6.194

CONFigure:NETWork:PCHannel:SCINdex[?] 6.195

CONFigure:NETWork:PCHannel:MSCindex[?] 6.195

CONFigure:NETWork:REGistration:TBASeD[?] 6.196

CONFigure:NETWork:REGistration:HOME[?] 6.196

CONFigure:NETWork:REGistration:FSID[?] 6.196

CONFigure:NETWork:REGistration:FNID[?] 6.197

CONFigure:NETWork:REGistration:PUP[?] 6.197

CONFigure:NETWork:REGistration:PDOWn[?] 6.197

CONFigure:NETWork:REGistration:PARAmeter[?] 6.197

CONFigure:NETWork:APRobes:MODE[?] 6.198

CONFigure:NETWork:APRobes:NOFFset[?] 6.198

CONFigure:NETWork:APRobes:IOFFset[?] 6.198

CONFigure:NETWork:APRobes:PINCrement[?] 6.199

CONFigure:NETWork:APRobes:PPSQuence[?] 6.199

CONFigure:NETWork:APRobes:SPATtempt[?] 6.199

Options

SYSTem:OPTions:INFO:CURRent? 6.30

Overview

CONFigure:OVERview:MCQuality:ENVironment:ENABLE[?] 6.207

CONFigure:OVERview:MCQuality:ENVironment:LEVel[?] 6.207

CONFigure:OVERview:MCQuality:ENVironment:LEVel:FPICH[?] 6.207

CONFigure:OVERview:MCQuality:ENVironment:LEVel:FFCH[?] 6.208

CONFigure:OVERview:MCQuality:ENVironment:LEVel:FSCH:ZERO[?] 6.208

CONFigure:OVERview:MCQuality:ENVironment:LEVel:FSCH:ONE[?] 6.208

CONFigure:OVERview:MCQuality:ENVironment:EBNT:FFCH? 6.208

CONFigure:OVERview:MCQuality:ENVironment:EBNT:FSCH:ZERO? 6.208

CONFigure:OVERview:MCQuality:ENVironment:EBNT:FSCH:ONE? 6.209

CONFigure:OVERview:MCQuality:ENVironment:FRATe:FFCH[?] 6.209

CONFigure:OVERview:MCQuality:ENVironment:IMPairments:LEVel:AWGN[?] 6.209

CONFigure:OVERview:MCQuality:ENVironment:IMPairments:FOFFset[?] 6.209

CONFigure:OVERview:MCQuality:ENVironment:IMPairments[?] 6.210

CONFigure:OVERview:MCQuality:ENVironment:PCBits[?] 6.210

CONFigure:OVERview:PPOWer:ENABLE[?] 6.210

[SENSe:]OVERview:PPOWer? 6.210

INITiate:OVERview:OVERview[:OQPSk] 6.211

ABORt:OVERview:OVERview[:OQPSk] 6.211

STOP:OVERview:OVERview[:OQPSk] 6.211

CONTInue:OVERview:OVERview[:OQPSk] 6.211

INITiate:OVERview:OVERview:HPSK.....	6.211
ABORt:OVERview:OVERview:HPSK.....	6.211
STOP:OVERview:OVERview:HPSK.....	6.211
CONTInue:OVERview:OVERview:HPSK.....	6.211
FETCh[:SCALar]:OVERview:OVERview[:OQPSk]:STATus?.....	6.211
FETCh[:SCALar]:OVERview:OVERview:HPSK:STATus?.....	6.211
CONFigure:OVERview:OVERview[:OQPSk]:EREPorting[?].	6.211
CONFigure:OVERview:OVERview:HPSK:EREPorting[?].	6.211
XTND:OVERview:OVERview[:OQPSk]:SBSuppr[?].	6.212
XTND:OVERview:OVERview:HPSK:SBSuppr[?].	6.212
CONFigure:OVERview:OVERview[:OQPSk]:CONTRol[?].	6.212
CONFigure:OVERview:OVERview:HPSK:CONTRol[?].	6.212
CONFigure:OVERview:OVERview[:OQPSk]:CONTRol:STATistics[?].	6.213
CONFigure:OVERview:OVERview:HPSK:CONTRol:STATistics[?].	6.213
CONFigure:OVERview:OVERview[:OQPSk]:CONTRol:REPetition[?].	6.213
CONFigure:OVERview:OVERview:HPSK:CONTRol:REPetition[?].	6.213
CONFigure:OVERview:OVERview[:OQPSk]:CONTRol:FOFFset:SBSuppr[?].	6.213
CONFigure:OVERview:OVERview:HPSK:CONTRol:FOFFset:SBSuppr[?].	6.213
CONFigure:OVERview:OVERview[:OQPSk]:CONTRol:FOFFset:SBSuppr:ACP<nr>[?].	6.214
CONFigure:OVERview:OVERview:HPSK:CONTRol:FOFFset:SBSuppr:ACP<nr>[?].	6.214
CONFigure:OVERview:OVERview[:OQPSk]:CMMax:LIMit[:SCALar]:SYMMetric[:COMBined][?].	6.215
CONFigure:OVERview:OVERview:HPSK:CMMax:LIMit[:SCALar]:SYMMetric[:COMBined][?].	6.215
CONFigure:OVERview:OVERview[:OQPSk]:AVERAge:LIMit[:SCALar]:SYMMetric[:COMBined][?].	6.216
CONFigure:OVERview:OVERview:HPSK:AVERAge:LIMit[:SCALar]:SYMMetric[:COMBined][?].	6.216
CONFigure:OVERview:OVERview[:OQPSk]:CMMax:LIMit[:SCALar]:SYMMetric[:COMBined]:ENABLE[?].	6.216
CONFigure:OVERview:OVERview:HPSK:CMMax:LIMit[:SCALar]:SYMMetric[:COMBined]:ENABLE[?].	6.216
CONFigure:OVERview:OVERview[:OQPSk]:AVERAge:LIMit[:SCALar]:SYMMetric[:COMBined]:ENABLE[?].	6.217
CONFigure:OVERview:OVERview:HPSK:AVERAge:LIMit[:SCALar]:SYMMetric[:COMBined]:ENABLE[?].	6.217
CONFigure:OVERview:OVERview[:OQPSk]:CMMax:LIMit[:SCALar]:SYMMetric[:COMBined]:VALue[?].	6.217
CONFigure:OVERview:OVERview:HPSK:CMMax:LIMit[:SCALar]:SYMMetric[:COMBined]:VALue[?].	6.217
CONFigure:OVERview:OVERview[:OQPSk]:AVERAge:LIMit[:SCALar]:SYMMetric[:COMBined]:VALue[?].	6.218
CONFigure:OVERview:OVERview:HPSK:AVERAge:LIMit[:SCALar]:SYMMetric[:COMBined]:VALue[?].	6.218
DEFault:OVERview:OVERview:LIMit[?].	6.218
DEFault:OVERview:OVERview:HPSK:LIMit[?].	6.218
READ[:SCALar]:OVERview:OVERview[:OQPSk]?.....	6.219
FETCh[:SCALar]:OVERview:OVERview[:OQPSk]?.....	6.219
SAMPle[:SCALar]:OVERview:OVERview[:OQPSk]?.....	6.219
READ[:SCALar]:OVERview:OVERview:HPSK?.....	6.219
FETCh[:SCALar]:OVERview:OVERview:HPSK?.....	6.219
SAMPle[:SCALar]:OVERview:OVERview:HPSK?.....	6.219
CALCulate[:SCALar]:OVERview:OVERview[:OQPSk]:MATChing:LIMit?.....	6.220
CALCulate[:SCALar]:OVERview:OVERview:HPSK:MATChing:LIMit?.....	6.220
INITiate:OVERview:CQQuality.....	6.220
ABORt:OVERview:CQQuality.....	6.220
STOP:OVERview:CQQuality.....	6.220
CONTInue:OVERview:CQQuality.....	6.220
CONFigure:OVERview:CQQuality:EREPorting[?].	6.221
FETCh[:SCALar]:OVERview:CQQuality:STATus?.....	6.221
XTND:OVERview:CQQuality:CLeVel[?].	6.221
CONFigure:OVERview:CQQuality:CONTRol:FRAMes[?].	6.222
CONFigure:OVERview:CQQuality:CONTRol:REPetition[?].	6.222
CONFigure:OVERview:CQQuality:CAMMax:LIMit[:SCALar]:SYMMetric[:COMBined]:VALue[?].	6.223
CONFigure:OVERview:CQQuality:CAMMax:LIMit:MFER[?].	6.223
CONFigure:OVERview:CQQuality:CAMMax:LIMit:CLeVel[?].	6.223
DEFault:OVERview:CQQuality:LIMit[?].	6.223
READ[:SCALar]:OVERview:CQQuality?.....	6.224
FETCh[:SCALar]:OVERview:CQQuality?.....	6.224
SAMPle[:SCALar]:OVERview:CQQuality?.....	6.224
CALCulate[:SCALar]:OVERview:CQQuality:MATChing:LIMit?.....	6.224

Partial Reset

SYSTem:RESet:CURRent 6.31

Power (Gated Output)

INITiate:POWer:GOUTput 6.243

ABORt:POWer:GOUTput 6.243

STOP:POWer:GOUTput 6.243

CONTInue:POWer:GOUTput 6.243

CONFigure:POWer:GOUTput:EREPorting[?] 6.244

FETCh[:SCALar]:POWer:GOUTput:STATUs? 6.244

CONFigure:POWer:GOUTput:CONTRol[?] 6.245

CONFigure:POWer:GOUTput:CONTRol:RMODe[?] 6.245

CONFigure:POWer:GOUTput:CONTRol:STATistics[?] 6.245

CONFigure:POWer:GOUTput:CONTRol:REPetition[?] 6.246

CONFigure:POWer:GOUTput:CONTRol:PCGcount[?] 6.246

DEFault:POWer:GOUTput:LIMit[?] 6.246

CONFigure:POWer:GOUTput:ENVironment:ENABle[?] 6.247

CONFigure:POWer:GOUTput:ENVironment:LEVel[?] 6.247

CONFigure:POWer:GOUTput:ENVironment:LEVel:FPICh[?] 6.247

CONFigure:POWer:GOUTput:ENVironment:LEVel:FFCH[?] 6.247

CONFigure:POWer:GOUTput:ENVironment:LEVel:FSCH:ZERO[?] 6.248

CONFigure:POWer:GOUTput:ENVironment:LEVel:FSCH:ONE[?] 6.248

CONFigure:POWer:GOUTput:ENVironment:EBNT:FFCH? 6.248

CONFigure:POWer:GOUTput:ENVironment:EBNT:FSCH:ZERO? 6.248

CONFigure:POWer:GOUTput:ENVironment:EBNT:FSCH:ONE? 6.248

CONFigure:POWer:GOUTput:ENVironment:FRATe:FFCH[?] 6.249

CONFigure:POWer:GOUTput:ENVironment:IMPairments:LEVel:AWGN[?] 6.249

CONFigure:POWer:GOUTput:ENVironment:IMPairments:FOFFset[?] 6.249

CONFigure:POWer:GOUTput:ENVironment:IMPairments:ITFer[?] 6.249

CONFigure:POWer:GOUTput:ENVironment:PCBits? 6.249

DEFault:POWer:GOUTput:LIMit[?] 6.250

CONFigure:POWer:GOUTput:CAMMax:LIMit:A:VALue[?] 6.250

CONFigure:POWer:GOUTput:CAMMax:LIMit:B:VALue[?] 6.250

CONFigure:POWer:GOUTput:CAMMax:LIMit:BREReference:VALue[?] 6.251

CONFigure:POWer:GOUTput:CAMMax:LIMit:C:VALue[?] 6.251

CONFigure:POWer:GOUTput:CAMMax:LIMit:D:RELative:VALue[?] 6.251

CONFigure:POWer:GOUTput:CAMMax:LIMit:D:ABS:VALue[?] 6.251

CONFigure:POWer:GOUTput:CAMMax:LIMit:E:VALue[?] 6.252

CONFigure:POWer:GOUTput:CAMMax:LIMit:EREReference:VALue[?] 6.252

CONFigure:SUBarrays:POWer:GOUTput[?] 6.252

READ[:SCALar]:POWer:GOUTput? 6.253

FETCh[:SCALar]:POWer:GOUTput? 6.253

SAMPle[:SCALar]:POWer:GOUTput? 6.253

READ:ARRays:POWer:GOUTput:CURRent? 6.253

READ:ARRays:POWer:GOUTput:AVERAge? 6.253

READ:ARRays:POWer:GOUTput:MINimum? 6.253

READ:ARRays:POWer:GOUTput:MAXimum? 6.253

FETCh:ARRays:POWer:GOUTput:CURRent? 6.253

FETCh:ARRays:POWer:GOUTput:AVERAge? 6.253

FETCh:ARRays:POWer:GOUTput:MINimum? 6.253

FETCh:ARRays:POWer:GOUTput:MAXimum? 6.253

SAMPle:ARRays:POWer:GOUTput:CURRent? 6.253

SAMPle:ARRays:POWer:GOUTput:AVERAge? 6.253

SAMPle:ARRays:POWer:GOUTput:MINimum? 6.253

SAMPle:ARRays:POWer:GOUTput:MAXimum? 6.253

READ:SUBarrays:POWer:GOUTput:CURRent? 6.254

READ:SUBarrays:POWer:GOUTput:AVERAge? 6.254

READ:SUBarrays:POWer:GOUTput:MINimum? 6.254

READ:SUBarrays:POWer:GOUTput:MAXimum? 6.254

FETCh:SUBarrays:POWer:GOUTput:CURRent?	6.254
FETCh:SUBarrays:POWer:GOUTput:AVERAge?	6.254
FETCh:SUBarrays:POWer:GOUTput:MINimum?	6.254
FETCh:SUBarrays:POWer:GOUTput:MAXimum?	6.254
SAMPlE:SUBarrays:POWer:GOUTput:CURRent?	6.254
SAMPlE:SUBarrays:POWer:GOUTput:AVERAge?	6.254
SAMPlE:SUBarrays:POWer:GOUTput:MINimum?	6.254
SAMPlE:SUBarrays:POWer:GOUTput:MAXimum?	6.254
CALCulate[SCALar]:POWer:GOUTput:MATChing:RAMP?	6.254
CALCulate:ARRay:POWer:GOUTput:MATChing:LIMit?	6.255

Power (Maximum Output)

INITiate:POWer:MAOutput[OQPSk]	6.234
ABORt:POWer:MAOutput[OQPSk]	6.234
STOP:POWer:MAOutput[OQPSk]	6.234
CONTinue:POWer:MAOutput[OQPSk]	6.234
INITiate:POWer:MAOutput:HPSK	6.234
ABORt:POWer:MAOutput:HPSK	6.234
STOP:POWer:MAOutput:HPSK	6.234
CONTinue:POWer:MAOutput:HPSK	6.234
CONFigure:POWer:MAOutput[OQPSk]:EREPorting[?]	6.235
CONFigure:POWer:MAOutput:HPSK:EREPorting[?]	6.235
FETCh[SCALar]:POWer:MAOutput[OQPSk]:STATus?	6.235
FETCh[SCALar]:POWer:MAOutput:HPSK:STATus?	6.235
CONFigure:POWer:MAOutput[OQPSk]:CONTrol[?]	6.236
CONFigure:POWer:MAOutput:HPSK:CONTrol[?]	6.236
CONFigure:POWer:MAOutput[OQPSk]:CONTrol:STATistics[?]	6.236
CONFigure:POWer:MAOutput:HPSK:CONTrol:STATistics[?]	6.236
CONFigure:POWer:MAOutput[OQPSk]:CONTrol:REPetition[?]	6.237
CONFigure:POWer:MAOutput:HPSK:CONTrol:REPetition[?]	6.237
CONFigure:POWer:MAOutput[OQPSk]:ENVironment:ENABle[?]	6.237
CONFigure:POWer:MAOutput:HPSK:ENVironment:ENABle[?]	6.237
CONFigure:POWer:MAOutput[OQPSk]:ENVironment:LEVel[?]	6.238
CONFigure:POWer:MAOutput:HPSK:ENVironment:LEVel[?]	6.238
CONFigure:POWer:MAOutput[OQPSk]:ENVironment:LEVel:FPICh[?]	6.238
CONFigure:POWer:MAOutput:HPSK:ENVironment:LEVel:FPICh[?]	6.238
CONFigure:POWer:MAOutput[OQPSk]:ENVironment:LEVel:FFCH[?]	6.238
CONFigure:POWer:MAOutput:HPSK:ENVironment:LEVel:FFCH[?]	6.238
CONFigure:POWer:MAOutput[OQPSk]:ENVironment:LEVel:FSCH:ZERO[?]	6.238
CONFigure:POWer:MAOutput:HPSK:ENVironment:LEVel:FSCH:ZERO[?]	6.238
CONFigure:POWer:MAOutput[OQPSk]:ENVironment:LEVel:FSCH:ONE[?]	6.239
CONFigure:POWer:MAOutput:HPSK:ENVironment:LEVel:FSCH:ONE[?]	6.239
CONFigure:POWer:MAOutput[OQPSk]:ENVironment:EBNT:FFCH?	6.239
CONFigure:POWer:MAOutput:HPSK:ENVironment:EBNT:FFCH?	6.239
CONFigure:POWer:MAOutput:HPSK:ENVironment:EBNT:FSCH:ZERO?	6.239
CONFigure:POWer:MAOutput[OQPSk]:ENVironment:EBNT:FSCH:ZERO?	6.239
CONFigure:POWer:MAOutput[OQPSk]:ENVironment:EBNT:FSCH:ONE?	6.239
CONFigure:POWer:MAOutput:HPSK:ENVironment:EBNT:FSCH:ONE?	6.239
CONFigure:POWer:MAOutput[OQPSk]:ENVironment:FRATe:FFCH[?]	6.240
CONFigure:POWer:MAOutput:HPSK:ENVironment:FRATe:FFCH[?]	6.240
CONFigure:POWer:MAOutput[OQPSk]:ENVironment:IMPairments:LEVel:AWGN[?]	6.240
CONFigure:POWer:MAOutput:HPSK:ENVironment:IMPairments:LEVel:AWGN[?]	6.240
CONFigure:POWer:MAOutput[OQPSk]:ENVironment:IMPairments:FOFFset[?]	6.240
CONFigure:POWer:MAOutput:HPSK:ENVironment:IMPairments:FOFFset[?]	6.240
CONFigure:POWer:MAOutput[OQPSk]:ENVironment:IMPairments:ITFer[?]	6.241
CONFigure:POWer:MAOutput:HPSK:ENVironment:IMPairments:ITFer[?]	6.241
CONFigure:POWer:MAOutput[OQPSk]:ENVironment:PCBits?	6.241
CONFigure:POWer:MAOutput:HPSK:ENVironment:PCBits?	6.241
CONFigure:POWer:MAOutput[OQPSk]:CAMMax:LIMit[SCALar]:ASYMmetric[COMBined]:VALue[?]	6.241

CONFigure:POWer:MAOutput:HPSK:CAMMax:LIMit[:SCALar]:ASYMmetric[:COMBined]:VALue[?]..... 6.241

DEFault:POWer:MAOutput[:OQPSk]:LIMit[?]..... 6.242

DEFault:POWer:MAOutput:HPSK:LIMit[?]..... 6.242

READ[:SCALar]:POWer:MAOutput[:OQPSk]?..... 6.242

FETCh[:SCALar]:POWer:MAOutput[:OQPSk]?..... 6.242

SAMPle[:SCALar]:POWer:MAOutput[:OQPSk]?..... 6.242

READ[:SCALar]:POWer:MAOutput:HPSK?..... 6.242

FETCh[:SCALar]:POWer:MAOutput:HPSK?..... 6.242

SAMPle[:SCALar]:POWer:MAOutput:HPSK?..... 6.242

CALCulate[:SCALar]:POWer:MAOutput[:OQPSk]:MATChing:LIMit?..... 6.243

CALCulate[:SCALar]:POWer:MAOutput:HPSK:MATChing:LIMit?..... 6.243

Power (Minimum Output)

INITiate:POWer:MIOutput[:OQPSk]..... 6.225

ABORt:POWer:MIOutput[:OQPSk]..... 6.225

STOP:POWer:MIOutput[:OQPSk]..... 6.225

CONTInue:POWer:MIOutput[:OQPSk]..... 6.225

INITiate:POWer:MIOutput:HPSK..... 6.225

ABORt:POWer:MIOutput:HPSK..... 6.225

STOP:POWer:MIOutput:HPSK..... 6.225

CONTInue:POWer:MIOutput:HPSK..... 6.225

CONFigure:POWer:MIOutput[:OQPSk]:EREPorting[?]..... 6.225

CONFigure:POWer:MIOutput:HPSK:EREPorting[?]..... 6.225

FETCh[:SCALar]:POWer:MIOutput[:OQPSk]:STATus?..... 6.226

FETCh[:SCALar]:POWer:MIOutput:HPSK:STATus?..... 6.226

CONFigure:POWer:MIOutput[:OQPSk]:CONTRol[?]..... 6.227

CONFigure:POWer:MIOutput:HPSK:CONTRol[?]..... 6.227

CONFigure:POWer:MIOutput[:OQPSk]:CONTRol:STATistics[?]..... 6.227

CONFigure:POWer:MIOutput:HPSK:CONTRol:STATistics[?]..... 6.227

CONFigure:POWer:MIOutput[:OQPSk]:CONTRol:REPetition[?]..... 6.228

CONFigure:POWer:MIOutput:HPSK:CONTRol:REPetition[?]..... 6.228

CONFigure:POWer:MIOutput[:OQPSk]:ENVironment:ENABle[?]..... 6.228

CONFigure:POWer:MIOutput:HPSK:ENVironment:ENABle[?]..... 6.228

CONFigure:POWer:MIOutput[:OQPSk]:ENVironment:LEVel[?]..... 6.229

CONFigure:POWer:MIOutput:HPSK:ENVironment:LEVel[?]..... 6.229

CONFigure:POWer:MIOutput[:OQPSk]:ENVironment:LEVel:FPiCh[?]..... 6.229

CONFigure:POWer:MIOutput:HPSK:ENVironment:LEVel:FPiCh[?]..... 6.229

CONFigure:POWer:MIOutput[:OQPSk]:ENVironment:LEVel:FFCH[?]..... 6.229

CONFigure:POWer:MIOutput:HPSK:ENVironment:LEVel:FFCH[?]..... 6.229

CONFigure:POWer:MIOutput[:OQPSk]:ENVironment:LEVel:FSCH:ZERO[?]..... 6.229

CONFigure:POWer:MIOutput:HPSK:ENVironment:LEVel:FSCH:ZERO[?]..... 6.229

CONFigure:POWer:MIOutput[:OQPSk]:ENVironment:LEVel:FSCH:ONE[?]..... 6.230

CONFigure:POWer:MIOutput:HPSK:ENVironment:LEVel:FSCH:ONE[?]..... 6.230

CONFigure:POWer:MIOutput[:OQPSk]:ENVironment:EBNT:FFCH?..... 6.230

CONFigure:POWer:MIOutput:HPSK:ENVironment:EBNT:FFCH?..... 6.230

CONFigure:POWer:MIOutput:HPSK:ENVironment:EBNT:FSCH:ZERO?..... 6.230

CONFigure:POWer:MIOutput[:OQPSk]:ENVironment:EBNT:FSCH:ZERO?..... 6.230

CONFigure:POWer:MIOutput[:OQPSk]:ENVironment:EBNT:FSCH:ONE?..... 6.230

CONFigure:POWer:MIOutput:HPSK:ENVironment:EBNT:FSCH:ONE?..... 6.230

CONFigure:POWer:MIOutput[:OQPSk]:ENVironment:FRATe:FFCH[?]..... 6.231

CONFigure:POWer:MIOutput:HPSK:ENVironment:FRATe:FFCH[?]..... 6.231

CONFigure:POWer:MIOutput[:OQPSk]:ENVironment:LEVel:AWGN[?]..... 6.231

CONFigure:POWer:MIOutput:HPSK:ENVironment:LEVel:AWGN[?]..... 6.231

CONFigure:POWer:MIOutput[:OQPSk]:ENVironment:IMPairments:FOFFset[?]..... 6.231

CONFigure:POWer:MIOutput:HPSK:ENVironment:IMPairments:FOFFset[?]..... 6.231

CONFigure:POWer:MIOutput[:OQPSk]:ENVironment:IMPairments:ITFer[?]..... 6.232

CONFigure:POWer:MIOutput:HPSK:ENVironment:IMPairments:ITFer[?]..... 6.232

CONFigure:POWer:MIOutput[:OQPSk]:ENVironment:PCBits?..... 6.232

CONFigure:POWer:MIOutput:HPSK:ENVironment:PCBits?..... 6.232

CONFigure:POWer:MIOutput[:OQPSk]:CAMMax:LIMit[:SCALar]:ASYMmetric[:COMBined]:VALue[?]	6.232
CONFigure:POWer:MIOutput:HPSK:CAMMax:LIMit[:SCALar]:ASYMmetric[:COMBined]:VALue[?]	6.232
DEFault:POWer:MIOutput[:OQPSk]:LIMit[?]	6.233
DEFault:POWer:MIOutput:HPSK:LIMit[?]	6.233
READ[:SCALar]:POWer:MIOutput[:OQPSk]?	6.233
FETCh[:SCALar]:POWer:MIOutput[:OQPSk]?	6.233
SAMPle[:SCALar]:POWer:MIOutput[:OQPSk]?	6.233
READ[:SCALar]:POWer:MIOutput:HPSK?	6.233
FETCh[:SCALar]:POWer:MIOutput:HPSK?	6.233
SAMPle[:SCALar]:POWer:MIOutput:HPSK?	6.233
CALCulate[:SCALar]:POWer:MIOutput[:OQPSk]:MATChing:LIMit?	6.234
CALCulate[:SCALar]:POWer:MIOutput:HPSK:MATChing:LIMit?	6.234

Power (Open Loop Time Response)

INITiate:POWer:OLTResponse	6.256
ABORt:POWer:OLTResponse	6.256
STOP:POWer:OLTResponse	6.256
CONTinue:POWer:OLTResponse	6.256
CONFigure:POWer:OLTResponse:EREPorting[?]	6.256
FETCh[:SCALar]:POWer:OLTResponse:STATus?	6.256
CONFigure:POWer:OLTResponse:ENVironment:ENABle[?]	6.257
CONFigure:POWer:OLTResponse:ENVironment:LEVel[?]	6.257
CONFigure:POWer:OLTResponse:ENVironment:LEVel:FPICh[?]	6.257
CONFigure:POWer:OLTResponse:ENVironment:LEVel:FFCH[?]	6.257
CONFigure:POWer:OLTResponse:ENVironment:LEVel:FSCH:ZERO[?]	6.258
CONFigure:POWer:OLTResponse:ENVironment:LEVel:FSCH:ONE[?]	6.258
CONFigure:POWer:OLTResponse:ENVironment:EBNT:FFCH?	6.258
CONFigure:POWer:OLTResponse:ENVironment:EBNT:FSCH:ZERO?	6.258
CONFigure:POWer:OLTResponse:ENVironment:EBNT:FSCH:ONE?	6.259
CONFigure:POWer:OLTResponse:ENVironment:FRATe:FFCH?	6.259
CONFigure:POWer:OLTResponse:ENVironment:IMPairments:LEVel:AWGN[?]	6.259
CONFigure:POWer:OLTResponse:ENVironment:IMPairments:FOFFset[?]	6.259
CONFigure:POWer:OLTResponse:ENVironment:IMPairments:ITFer[?]	6.260
CONFigure:POWer:OLTResponse:ENVironment:PCBits?	6.260
CONFigure:POWer:OLTResponse:PSTep[?]	6.260
CONFigure:POWer:OLTResponse:PSDirection[?]	6.260
READ[:SCALar]:POWer:OLTResponse?	6.261
FETCh[:SCALar]:POWer:OLTResponse?	6.261
SAMPle[:SCALar]:POWer:OLTResponse?	6.261
READ:ARRAy:POWer:OLTResponse?	6.261
FETCh:ARRAy:POWer:OLTResponse?	6.261
SAMPle:ARRAy:POWer:OLTResponse?	6.261

Reciever Quality (Frame Error Rate)

CONFigure:RXQuality:FER:FSSCommon:TSETup[?]	6.262
CONFigure:RXQuality:FER:FSSCommon:TSETup<nr>:ENVironment:ENABle[?]	6.263
CONFigure:RXQuality:FER:FSSCommon:TSETup<nr>:ENVironment:LEVel[?]	6.263
CONFigure:RXQuality:FER:FSSCommon:TSETup<nr>:ENVironment:LEVel:FPICh[?]	6.263
CONFigure:RXQuality:FER:FSSCommon:TSETup<nr>:ENVironment:LEVel:FFCH[?]	6.264
CONFigure:RXQuality:FER:FSSCommon:TSETup<nr>:ENVironment:LEVel:FSCH:ZERO[?]	6.264
CONFigure:RXQuality:FER:FSSCommon:TSETup<nr>:ENVironment:LEVel:FSCH:ONE[?]	6.264
CONFigure:RXQuality:FER:FSSCommon:TSETup<nr>:ENVironment:EBNT:FFCH?	6.264
CONFigure:RXQuality:FER:FSSCommon:TSETup<nr>:ENVironment:EBNT:FSCH:ZERO?	6.265
CONFigure:RXQuality:FER:FSSCommon:TSETup<nr>:ENVironment:EBNT:FSCH:ONE?	6.265
CONFigure:RXQuality:FER:FSSCommon:TSETup<nr>:ENVironment:FRATe:FFCH[?]	6.265
CONFigure:RXQuality:FER:FSSCommon:TSETup<nr>:ENVironment:IMPairments:LEVel:AWGN[?]	6.265
CONFigure:RXQuality:FER:FSSCommon:TSETup<nr>:ENVironment:IMPairments:FOFFset[?]	6.266
CONFigure:RXQuality:FER:FSSCommon:TSETup<nr>:ENVironment:IMPairments:ITFer[?]	6.266

CONFigure:RXQuality:FER:FSSCommon:TSETup<nr>:ENVironment:PCBits?	6.266
INITiate:RXQuality:FER:FCH	6.266
ABORt:RXQuality:FER:FCH	6.266
STOP:RXQuality:FER:FCH	6.266
CONTinue:RXQuality:FER:FCH	6.266
INITiate:RXQuality:FER:SCHScch	6.266
ABORt:RXQuality:FER:SCHScch	6.266
STOP:RXQuality:FER:SCHScch	6.266
CONTinue:RXQuality:FER:SCHScch	6.266
CONFigure:RXQuality:FER:FCH:EREPorting[?]	6.267
CONFigure:RXQuality:FER:SCHScch:EREPorting[?]	6.267
FETCh[:SCALar]:RXQuality:FER:FCH:STATus?	6.267
FETCh[:SCALar]:RXQuality:FER:SCHScch:STATus?	6.267
XTND:RXQuality:FER:SCHScch:SCH:ONE[?]	6.267
CONFigure:RXQuality:FER:FCH:CONTrol:TSETup<nr>:FRAMes[?]	6.268
CONFigure:RXQuality:FER:SCHScch:CONTrol:TSETup<nr>:FRAMes[?]	6.268
CONFigure:RXQuality:FER:FCH:CONTrol:TSETup<nr>:REPetition[?]	6.268
CONFigure:RXQuality:FER:SCHScch:CONTrol:TSETup<nr>:REPetition[?]	6.268
DEFault:RXQuality:FER:FCH:LIMit:TSETup<nr>[?]	6.269
DEFault:RXQuality:FER:SCHScch:LIMit:TSETup<nr>[?]	6.269
CONFigure:RXQuality:FER:FCH:LIMit:TSETup<nr>:MFER[?]	6.269
CONFigure:RXQuality:FER:SCHScch:LIMit:TSETup<nr>:MFER[?]	6.269
CONFigure:RXQuality:FER:SCHScch:LIMit:TSETup<nr>:SCH:ZERO:MFER[?]	6.269
CONFigure:RXQuality:FER:SCHScch:LIMit:TSETup<nr>:SCH:ONE:MFER[?]	6.269
CONFigure:RXQuality:FER:FCH:LIMit:TSETup<nr>:CLEVel[?]	6.270
CONFigure:RXQuality:FER:SCHScch:LIMit:TSETup<nr>:CLEVel[?]	6.270
CONFigure:RXQuality:FER:SCHScch:LIMit:TSETup<nr>:SCH:ZERO:CLEVel[?]	6.270
CONFigure:RXQuality:FER:SCHScch:LIMit:TSETup<nr>:SCH:ONE:CLEVel[?]	6.270
READ[:SCALar]:RXQuality:FER:FCH?	6.271
FETCh[:SCALar]:RXQuality:FER:FCH?	6.271
SAMPle[:SCALar]:RXQuality:FER:FCH?	6.271
READ[:SCALar]:RXQuality:FER:SCHScch?	6.271
FETCh[:SCALar]:RXQuality:FER:SCHScch?	6.271
SAMPle[:SCALar]:RXQuality:FER:SCHScch?	6.271
CALCulate[:SCALar]:RXQuality:FER:FCH:MATCHing:LIMit?	6.271
CALCulate[:SCALar]:RXQuality:FER:SCHScch:MATCHing:LIMit?	6.271

Reciever Quality (Forward Power Control)

CONFigure:RXQuality:FPControl:ENVironment:ENABle[?]	6.272
CONFigure:RXQuality:FPControl:ENVironment:LEVel[?]	6.272
CONFigure:RXQuality:FPControl:ENVironment:LEVel:FPICh[?]	6.272
CONFigure:RXQuality:FPControl:ENVironment:LEVel:FFCH[?]	6.273
CONFigure:RXQuality:FPControl:ENVironment:LEVel:FSCH:ZERO[?]	6.273
CONFigure:RXQuality:FPControl:ENVironment:LEVel:FSCH:ONE[?]	6.273
CONFigure:RXQuality:FPControl:ENVironment:FRATe:FFCH[?]	6.273
CONFigure:RXQuality:FPControl:ENVironment:IMPairments:LEVel:AWGN[?]	6.273
CONFigure:RXQuality:FPControl:ENVironment:IMPairments:FOFFset[?]	6.274
CONFigure:RXQuality:FPControl:ENVironment:IMPairments:ITFer[?]	6.274
CONFigure:RXQuality:FPControl:ENVironment:PCBits?	6.274
INITiate:RXQuality:FPControl	6.274
ABORt:RXQuality:FPControl	6.274
STOP:RXQuality:FPControl	6.274
CONTinue:RXQuality:FPControl	6.274
FETCh[:SCALar]:RXQuality:FPControl:STATus?	6.275
CONFigure:RXQuality:FPControl:EREPorting	6.275
CONFigure:RXQuality:FPControl:CONTrol[?]	6.276
CONFigure:RXQuality:FPControl:CONTrol:STATistics[?]	6.276
CONFigure:RXQuality:FPControl:CONTrol:REPetition[?]	6.277
CONFigure:RXQuality:FPControl:CONTrol:FPCMode[?]	6.277

CONFigure:RXQuality:FPControl:CONTRol:RDElay[?]	6.277
CONFigure:RXQuality:FPControl:CONTRol:RFRames[?]	6.278
CONFigure:RXQuality:FPControl:CONTRol:CPPrimary[?]	6.278
CONFigure:RXQuality:FPControl:CONTRol:CSECondary[?]	6.278
CONFigure:RXQuality:FPControl:CONTRol:FCH:TFER[?]	6.278
CONFigure:RXQuality:FPControl:CONTRol:FCH:LSPoint:STTic:LOWer[?]	6.279
CONFigure:RXQuality:FPControl:CONTRol:FCH:LSPoint:DYNamic:LOWer[?]	6.279
CONFigure:RXQuality:FPControl:CONTRol:FCH:LSPoint:STTic:UPPer[?]	6.279
CONFigure:RXQuality:FPControl:CONTRol:FCH:LSPoint:DYNamic:UPPer[?]	6.280
CONFigure:RXQuality:FPControl:CONTRol:FCH:LSPoint:INITial[?]	6.280
CONFigure:RXQuality:FPControl:CONTRol:SCH:ZERO:LSPoint:INITial[?]	6.280
CONFigure:RXQuality:FPControl:CONTRol:SCH:ONE:LSPoint:INITial[?]	6.280
CONFigure:RXQuality:FPControl:CONTRol:FCH:LSPoint:THReshold[?]	6.280
CONFigure:RXQuality:FPControl:CONTRol:SCH:ZERO:LSPoint:THReshold[?]	6.280
CONFigure:RXQuality:FPControl:CONTRol:SCH:ONE:LSPoint:THReshold[?]	6.280
CONFigure:RXQuality:FPControl:CONTRol:SCH:ZERO:TFER[?]	6.280
CONFigure:RXQuality:FPControl:CONTRol:SCH:ONE:TFER[?]	6.280
CONFigure:RXQuality:FPControl:CONTRol:SCH:ZERO:LSPoint:STTic:LOWer[?]	6.281
CONFigure:RXQuality:FPControl:CONTRol:SCH:ONE:LSPoint:STTic:LOWer[?]	6.281
CONFigure:RXQuality:FPControl:CONTRol:SCH:ZERO:LSPoint:DYNamic:LOWer[?]	6.281
CONFigure:RXQuality:FPControl:CONTRol:SCH:ONE:LSPoint:DYNamic:LOWer[?]	6.281
CONFigure:RXQuality:FPControl:CONTRol:SCH:ZERO:LSPoint:STTic:UPPer[?]	6.281
CONFigure:RXQuality:FPControl:CONTRol:SCH:ONE:LSPoint:STTic:UPPer[?]	6.281
CONFigure:RXQuality:FPControl:CONTRol:SCH:ZERO:LSPoint:DYNamic:UPPer[?]	6.282
CONFigure:RXQuality:FPControl:CONTRol:SCH:ONE:LSPoint:DYNamic:UPPer[?]	6.282
READ[:SCALar]:RXQuality:FPControl?	6.283
FETCh[:SCALar]:RXQuality:FPControl?	6.283
SAMPle[:SCALar]:RXQuality:FPControl?	6.283

RF Analyzer

DEFault:RFANalyzer[?]	6.205
[SENSe:]LEVel:MODE[?]	6.205
[SENSe:]LEVel:MAXimum[?]	6.205

Save/Recall

MMEMemory:SAVE:CURRent	6.31
MMEMemory:RECall:CURRent	6.31

Standby and Access Probe Power

INITiate:SAPPower	6.200
ABORt:SAPPower	6.200
STOP:SAPPower	6.200
CONTInue:SAPPower	6.200
CONFigure:SAPPower:EREPorting[?]	6.200
FETCh[:SCALar]:SAPPower:STATus?	6.200
READ[:SCALar]:SAPPower?	6.201
FETCh[:SCALar]:SAPPower?	6.201
SAMPle[:SCALar]:SAPPower?	6.201

Service Configuration

[SENSe:]SCINfo?	6.138
DEFault:SCONfig[?]	6.138
CONFigure:SCONfig:SCLass1:SERVice[?]	6.139
PROCedure:SCONfig:SCLass1:SERVice[?]	6.139
CONFigure:SCONfig:AMOC[?]	6.139
CONFigure:SCONfig:CURRent:RC[?]	6.139

CONFigure:SCONfig:SCLass1:LOOP:SOPTion[?]..... 6.140

PROCedure:SCONfig:SCLass1:LOOP:SOPTion[?]..... 6.140

CONFigure:SCONfig:SCLass1:LOOP:S02D:FCH? 6.140

PROCedure:SCONfig:SCLass1:LOOP:S02D:FCH? 6.140

CONFigure:SCONfig:SCLass1:LOOP:S09D:FCH? 6.140

PROCedure:SCONfig:SCLass1:LOOP:S09D:FCH? 6.140

CONFigure:SCONfig:SCLass1:LOOP:S55D:FCH? 6.141

PROCedure:SCONfig:SCLass1:LOOP:S55D:FCH? 6.141

CONFigure:SCONfig:SCLass1:LOOP:S02D:FCH:RC[?] 6.141

PROCedure:SCONfig:SCLass1:LOOP:S02D:FCH:RC[?] 6.141

CONFigure:SCONfig:SCLass1:LOOP:S09D:FCH:RC[?] 6.142

PROCedure:SCONfig:SCLass1:LOOP:S09D:FCH:RC[?] 6.142

CONFigure:SCONfig:SCLass1:LOOP:S55D:FCH:RC[?] 6.142

PROCedure:SCONfig:SCLass1:LOOP:S55D:FCH:RC[?] 6.142

CONFigure:SCONfig:SCLass1:LOOP:S55D:FCH:FORWard:MO[?] 6.143

PROCedure:SCONfig:SCLass1:LOOP:S55D:FCH:FORWard:MO[?] 6.143

CONFigure:SCONfig:SCLass1:LOOP:S55D:FCH:REVerse:MO[?] 6.143

PROCedure:SCONfig:SCLass1:LOOP:S55D:FCH:REVerse:MO[?] 6.143

CONFigure:SCONfig:SCLass1:LOOP:S02D:FCH:FRAT[?] 6.143

PROCedure:SCONfig:SCLass1:LOOP:S02D:FCH:FRAT[?] 6.143

CONFigure:SCONfig:SCLass1:LOOP:S09D:FCH:FRAT[?] 6.144

PROCedure:SCONfig:SCLass1:LOOP:S09D:FCH:FRAT[?] 6.144

CONFigure:SCONfig:SCLass1:LOOP:S55D:FCH:FRAT[?] 6.144

PROCedure:SCONfig:SCLass1:LOOP:S55D:FCH:FRAT[?] 6.144

CONFigure:SCONfig:SCLass1:LOOP:S02D:FCH:PGEN[?] 6.144

PROCedure:SCONfig:SCLass1:LOOP:S02D:FCH:PGEN[?] 6.144

CONFigure:SCONfig:SCLass1:LOOP:S09D:FCH:PGEN[?] 6.145

PROCedure:SCONfig:SCLass1:LOOP:S09D:FCH:PGEN[?] 6.145

CONFigure:SCONfig:SCLass1:LOOP:S55D:FCH:PGEN[?] 6.145

PROCedure:SCONfig:SCLass1:LOOP:S55D:FCH:PGEN[?] 6.145

CONFigure:SCONfig:SCLass1:LOOP:S02D:FCH:PATTem[?] 6.145

PROCedure:SCONfig:SCLass1:LOOP:S02D:FCH:PATTem[?] 6.145

CONFigure:SCONfig:SCLass1:LOOP:S09D:FCH:PATTem[?] 6.146

PROCedure:SCONfig:SCLass1:LOOP:S09D:FCH:PATTem[?] 6.146

CONFigure:SCONfig:SCLass1:LOOP:S55D:FCH:PATTem[?] 6.146

PROCedure:SCONfig:SCLass1:LOOP:S55D:FCH:PATTem[?] 6.146

CONFigure:SCONfig:SCLass1:SPEech:SOPTion[?]..... 6.146

PROCedure:SCONfig:SCLass1:SPEech:SOPTion[?]..... 6.146

CONFigure:SCONfig:SCLass1:SPEech:S01D:FCH? 6.147

PROCedure:SCONfig:SCLass1:SPEech:S01D:FCH? 6.147

CONFigure:SCONfig:SCLass1:SPEech:S03D:FCH? 6.147

PROCedure:SCONfig:SCLass1:SPEech:S03D:FCH? 6.147

CONFigure:SCONfig:SCLass1:SPEech:S17D:FCH? 6.147

PROCedure:SCONfig:SCLass1:SPEech:S17D:FCH? 6.147

CONFigure:SCONfig:SCLass1:SPEech: SX8T:FCH? 6.148

PROCedure:SCONfig:SCLass1:SPEech: SX8T:FCH? 6.148

CONFigure:SCONfig:SCLass1:SPEech:S01D:FCH:RC[?] 6.148

PROCedure:SCONfig:SCLass1:SPEech:S01D:FCH:RC[?] 6.148

CONFigure:SCONfig:SCLass1:SPEech:S03D:FCH:RC[?] 6.149

PROCedure:SCONfig:SCLass1:SPEech:S03D:FCH:RC[?] 6.149

CONFigure:SCONfig:SCLass1:SPEech:S17D:FCH:RC[?] 6.149

PROCedure:SCONfig:SCLass1:SPEech:S17D:FCH:RC[?] 6.149

CONFigure:SCONfig:SCLass1:SPEech: SX8T:FCH:RC[?] 6.150

PROCedure:SCONfig:SCLass1:SPEech: SX8T:FCH:RC[?] 6.150

CONFigure:SCONfig:SCLass1:SPEech:S01D:VCODer[?] 6.150

CONFigure:SCONfig:SCLass1:SPEech:S03D:VCODer[?] 6.150

CONFigure:SCONfig:SCLass1:SPEech:S17D:VCODer[?] 6.151

CONFigure:SCONfig:SCLass1:SPEech: SX8T:VCODer[?] 6.151

CONFigure:SCONfig:SCLass1:SPEech:S01D:EDALay[?]..... 6.151

CONFigure:SCONfig:SCLass1:SPEech:S02D:EDALay[?]..... 6.151

CONFigure:SCONfig:SCLass1:SPEech:S17D:EDALay[?]	6.151
CONFigure:SCONfig:SCLass1:SPEech: SX8T:EDALay[?]	6.151
CONFigure:SCONfig:SCLass1:TDAT:SOPTion[?]	6.152
PROcEDURE:SCONfig:SCLass1:TDAT:SOPTion[?]	6.152
CONFigure:SCONfig:SCLass1:TDAT:S32D:FSCommon:RC[?]	6.152
PROcEDURE:SCONfig:SCLass1:TDAT:S32D:FSCommon:RC[?]	6.152
CONFigure:SCONfig:SCLass1:TDAT:S32D:FCH?	6.152
CONFigure:SCONfig:SCLass1:TDAT:S32D:FCH:FORWard:PGEN[?]	6.153
CONFigure:SCONfig:SCLass1:TDAT:S32D:FCH:REVerse:PGEN[?]	6.153
CONFigure:SCONfig:SCLass1:TDAT:S32D:FCH:FORWard:PATtern[?]	6.153
CONFigure:SCONfig:SCLass1:TDAT:S32D:FCH:REVerse:PATtern[?]	6.153
CONFigure:SCONfig:SCLass1:TDAT:S32D:FCH:FORWard:CBFRames[?]	6.154
CONFigure:SCONfig:SCLass1:TDAT:S32D:FCH:REVerse:CBFRames[?]	6.154
CONFigure:SCONfig:SCLass1:TDAT:S32D:FCH:FORWard:TXON[?]	6.154
CONFigure:SCONfig:SCLass1:TDAT:S32D:FCH:REVerse:TXON[?]	6.154
CONFigure:SCONfig:SCLass1:TDAT:S32D:FCH:FORWard:TXOFF[?]	6.154
CONFigure:SCONfig:SCLass1:TDAT:S32D:FCH:REVerse:TXOFF[?]	6.155
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ZERO:FORWard:ENABle[?]	6.155
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ZERO:REVerse:ENABle?	6.155
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ZERO?	6.155
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ZERO:FORWard:CHANnel[?]	6.155
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ZERO:FORWard:QOF[?]	6.156
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ZERO:FORWard:PGEN[?]	6.156
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ZERO:REVerse:PGEN[?]	6.156
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ZERO:FORWard:PATtern[?]	6.156
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ZERO:REVerse:PATtern[?]	6.157
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ZERO:FORWard:CBFRames[?]	6.157
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ZERO:REVerse:CBFRames[?]	6.157
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ZERO:FORWard:TXON[?]	6.157
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ZERO:REVerse:TXON[?]	6.157
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ZERO:FORWard:TXOFF[?]	6.158
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ZERO:REVerse:TXOFF[?]	6.158
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ZERO:FORWard:MPPL[?]	6.158
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ZERO:REVerse:MPPL[?]	6.158
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ZERO:FORWard:FRTYpe[?]	6.159
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ZERO:REVerse:FRTYpe[?]	6.160
CONFigure:SCONfig:SCLass1:PDAT:S32D:SCH:ZERO:FORWard:CODing	6.160
CONFigure:SCONfig:SCLass1:PDAT:S32D:SCH:ZERO:REVerse:CODing	6.160
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ZERO:FORWard:DRATe?	6.160
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ZERO:REVerse:DRATe?	6.161
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ONE:FORWard:ENABle[?]	6.161
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ONE:REVerse:ENABle?	6.161
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ONE?	6.161
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ONE:FORWard:CHANnel[?]	6.161
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ONE:FORWard:QOF[?]	6.162
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ONE:FORWard:PGEN[?]	6.162
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ONE:REVerse:PGEN[?]	6.162
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ONE:FORWard:PATtern[?]	6.162
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ONE:REVerse:PATtern[?]	6.163
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ONE:FORWard:CBFRames[?]	6.163
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ONE:REVerse:CBFRames[?]	6.163
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ONE:FORWard:TXON[?]	6.163
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ONE:REVerse:TXON[?]	6.163
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ONE:FORWard:TXOFF[?]	6.164
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ONE:REVerse:TXOFF[?]	6.164
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ONE:FORWard:MPPL[?]	6.164
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ONE:REVerse:MPPL[?]	6.164
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ONE:FORWard:FRTYpe[?]	6.164
CONFigure:SCONfig:SCLass1:TDAT:S32D:SCH:ONE:REVerse:FRTYpe[?]	6.165
CONFigure:SCONfig:SCLass1:PDAT:S32D:SCH:ONE:FORWard:CODing	6.165

CONFigure:SCONfig:SClass1:PDAT:S32D:SCH:ONE:REVerse:CODing 6.165

CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ONE:FORWard:DRATe? 6.165

CONFigure:SCONfig:SClass1:TDAT:S32D:SCH:ONE:REVerse:DRATe? 6.166

CONFigure:SCONfig:SClass1:PDAT:SOPTion[?] 6.166

PROcEDURE:SCONfig:SClass1:PDAT:SOPTion[?] 6.166

CONFigure:SCONfig:SClass1:PDAT:S33D:FSCommon:RC[?] 6.166

PROcEDURE:SCONfig:SClass1:PDAT:S33D:FSCommon:RC[?] 6.166

CONFigure:SCONfig:SClass1:PDAT:S33D:FCH? 6.167

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ZERO:FORWard:ENABle[?] 6.167

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ZERO:REVerse:ENABle? 6.167

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ZERO? 6.167

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ZERO:FORWard:CHANnel[?] 6.167

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ZERO:FORWard:QOF[?] 6.168

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ZERO:FORWard:MPPL[?] 6.168

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ZERO:REVerse:MPPL[?] 6.168

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ZERO:FORWard:FRTYpe[?] 6.168

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ZERO:REVerse:FRTYpe[?] 6.168

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ZERO:FORWard:CODing 6.169

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ZERO:REVerse:CODing 6.169

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ZERO:FORWard:DRATe? 6.169

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ZERO:REVerse:DRATe? 6.169

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ONE:FORWard:ENABle[?] 6.170

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ONE:REVerse:ENABle? 6.170

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ONE? 6.170

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ONE:FORWard:CHANnel[?] 6.170

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ONE:FORWard:QOF[?] 6.170

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ONE:FORWard:MPPL[?] 6.171

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ONE:REVerse:MPPL[?] 6.171

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ONE:FORWard:FRTYpe[?] 6.171

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ONE:REVerse:FRTYpe[?] 6.171

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ONE:FORWard:CODing 6.171

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ONE:REVerse:CODing 6.172

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ONE:FORWard:DRATe? 6.172

CONFigure:SCONfig:SClass1:PDAT:S33D:SCH:ONE:REVerse:DRATe? 6.172

CONFigure:SCONfig:SClass1:PDAT:S33D:REVerse[.STATic]:IPADdress 6.172

CONFigure:SCONfig:SClass1:PDAT:S33D:FORWard[.STATic]:IPADdress 6.172

CONFigure:SCONfig:SClass1:PDAT:S33D:REVerse:DYNamic:IPADdress? 6.173

CONFigure:SCONfig:SClass1:PDAT:S33D:FORWard:DYNamic:IPADdress? 6.173

CONFigure:SCONfig:SClass1:WMT:SOPTion 6.173

CONFigure:SCONfig:SClass1:WMT:SMS:ACKNowledge:ENABle[?] 6.173

CONFigure:SCONfig:SClass1:WMT:SMS:TSTamp:ENABle[?] 6.173

CONFigure:SCONfig:SClass1:WMT:SMS:LENGth[?] 6.174

CONFigure:SCONfig:SClass1:WMT:SMS:TEXT[?] 6.174

CONFigure:SCONfig:SClass1:WMT:SMS:S06D:FCH? 6.174

CONFigure:SCONfig:SClass1:WMT:SMS:S14D:FCH? 6.174

CONFigure:SCONfig:SClass1:WMT:SMS:S06D:FCH:RC 6.174

CONFigure:SCONfig:SClass1:WMT:SMS:S14D:FCH:RC 6.175

Signalling

PROcEDURE:SIGNalling:ACTion 6.132

[SENSe:]SIGNalling:STATe? 6.133

Spectrum

INIATiate:SPECTrum:ACP 6.80

ABORt:SPECTrum:ACP 6.80

STOP:SPECTrum:ACP 6.80

CONTInue:SPECTrum:ACP 6.80

CONFigure:SPECTrum:ACP:EREPorting[?] 6.80

<i>FETCh</i> [: <i>SCALar</i>]: <i>SPECtrum</i> : <i>ACP</i> : <i>STATus</i> ?	6.81
<i>CONFigure</i> : <i>SPECtrum</i> : <i>ACP</i> : <i>CONTRol</i> [?]	6.82
<i>CONFigure</i> : <i>SPECtrum</i> : <i>ACP</i> : <i>CONTRol</i> : <i>STATistics</i> [?]	6.82
<i>CONFigure</i> : <i>SPECtrum</i> : <i>ACP</i> : <i>CONTRol</i> : <i>REPetition</i> [?]	6.83
<i>DEFault</i> : <i>SPECtrum</i> : <i>ACP</i> : <i>CONTRol</i> [?]	6.83
<i>CONFigure</i> : <i>SPECtrum</i> : <i>ACP</i> : <i>CONTRol</i> : <i>FOFFset</i> : <i>ACP</i> < <i>nr</i> >[?]	6.84
<i>CONFigure</i> : <i>SPECtrum</i> : <i>ACP</i> : <i>LIMit</i> : <i>ACP1</i> [?]	6.85
<i>DEFault</i> : <i>SPECtrum</i> : <i>ACP</i> : <i>LIMit</i> [?]	6.85
<i>XTND</i> : <i>SPECtrum</i> : <i>ACP</i> : <i>STATistics</i> [?]	6.85
<i>READ</i> [: <i>SCALar</i>]: <i>SPECtrum</i> : <i>ACP</i> ?	6.86
<i>FETCh</i> [: <i>SCALar</i>]: <i>SPECtrum</i> : <i>ACP</i> ?	6.86
<i>SAMPle</i> [: <i>SCALar</i>]: <i>SPECtrum</i> : <i>ACP</i> ?	6.86
<i>CALCulate</i> [: <i>SCALar</i>]: <i>SPECtrum</i> : <i>ACP</i> : <i>MATChing</i> : <i>LIMit</i> ?	6.87

Symbolic Status Event Register Evaluation

<i>STATus</i> : <i>OPERation</i> : <i>SYMBOLic</i> : <i>ENABle</i>	6.33
<i>STATus</i> : <i>OPERation</i> : <i>SYMBOLic</i> : <i>EVENT</i> [?]	6.33
<i>XTND</i> : <i>STATus</i> : <i>OPERation</i> : <i>FGRegister</i> : <i>EVENT</i> [?]	6.34
<i>XTND</i> : <i>STATus</i> : <i>OPERation</i> : <i>SYMBOLic</i> : <i>EVENT</i> [?]	6.34

Trigger

<i>DEFault</i> : <i>TRIGger</i> : <i>SEquence</i> [?]	6.203
<i>TRIGger</i> : <i>SEquence</i> : <i>SOURce</i> [?]	6.204
<i>TRIGger</i> : <i>SEquence</i> : <i>THReshold</i> : <i>RFPower</i>	6.204
<i>TRIGger</i> : <i>SEquence</i> : <i>THReshold</i> : <i>IFPower</i>	6.204
<i>TRIGger</i> : <i>SEquence</i> : <i>SLOPe</i>	6.204
<i>TRIGger</i> : <i>OUTPut</i> : <i>PIN</i> < <i>nr</i> >: <i>SIGNal</i> [?]	6.205

Version

<i>SYSTem</i> : <i>VERSion</i> : <i>SW</i> : <i>MMI</i> ?	6.30
---	------

Wide Band Power

<i>INITiate</i> : <i>WPOWER</i>	6.35
<i>ABORt</i> : <i>WPOWER</i>	6.35
<i>STOP</i> : <i>WPOWER</i>	6.35
<i>CONTinue</i> : <i>WPOWER</i>	6.35
<i>CONFigure</i> : <i>WPOWER</i> : <i>EREPorting</i>	6.35
<i>FETCh</i> : <i>WPOWER</i> : <i>STATus</i> ?	6.35
<i>CONFigure</i> : <i>WPOWER</i> : <i>CONTRol</i> : <i>REPetition</i>	6.36
<i>READ</i> [: <i>SCALar</i>]: <i>WPOWER</i> ?	6.36
<i>FETCh</i> [: <i>SCALar</i>]: <i>WPOWER</i> ?	6.36
<i>SAMPle</i> [: <i>SCALar</i>]: <i>WPOWER</i> ?	6.36

7 Remote Control – Program Example

The following example program illustrates primary and secondary addressing by setting up a call and performing simple measurements with the CMU. In the example, remote control via GPIB bus and the programming language *Winbatch* is used.

Winbatch uses device names such as *CMUBASE*, *C2KCell-S*, *AMPS-MS* which are previously defined and assigned to the primary address, secondary address, and some general device settings.

With these device names, a complete command line reads:

```
CMUBASE: <CMU_Command>
```

where <CMU_Command> may be any of the commands (setting commands or queries) specified within the function group and mode identified by the device name *CMUBASE*. Program sequences consisting of commands that are defined in several function groups and modes can be re-used with an exchanged device name.

In addition to these data transfer commands, *Winbatch* provides *WHILE*, *GOTO*, and *IF* statements to express conditions and define loops.

With the statement:

```
WHILE C2KCell-S: sign:stat? <> REG
```

the instrument waits until it has reached the signalling state *Registered* before it executes the following commands.

For a C program assigning secondary addresses, refer to Chapter 7 of the CMU operating manual.

Preliminary configurations for different measurements are defined, and the network parameters are set. A CDMA2000 connection with F-RC 5, R-RC 4 is established, several measurements are executed followed by an handoff to AMPS.

Before running the program, configure your *Winbatch* settings such that *CMUBASE* is the device name for the CMU *BASE* system and *C2KCell-S*, *AMPS-MS* denote the function groups *CDMA2000 Cellular*, *AMPS Signalling* function groups.

```
ECHO ON
```

```
FPRINT -----
FPRINT INITIALISATION ROUTINE:
FPRINT ASK FOR THE IDENTIFIER OF THE CMU, RESET THE INSTRUMENT,
FPRINT DEFINE THE SECONDARY ADDRESSES FOR ALL AVAILABLE FUNCTION GROUPS
FPRINT -----
```

```
CMUBASE: *IDN?
CMUBASE: *RST;*OPC?
CMUBASE: *CLS
```

```
CMUBASE: SYST:ERR?
```

```

; Get primary and secondary addresses
CMUBASE: SYSTEM:REMOTE:ADDR:PRIM?
CMUBASE: SYST:REM:ADDR:SEC?

; Set the secondary address of the functional groups
CMUBASE: SYST:REM:ADDR:SEC?

CMUBASE: SYST:REM:ADDR:SEC 1,"CDMA2K450MS_Sig"
CMUBASE: SYST:REM:ADDR:SEC 2,"CDMA2K450MS_NSig"
CMUBASE: SYST:REM:ADDR:SEC 3,"CDMA2KCellMS_Sig"
CMUBASE: SYST:REM:ADDR:SEC 4,"CDMA2KCellMS_NSig"
CMUBASE: SYST:REM:ADDR:SEC 5,"CDMA2KPCSMS_Sig"
CMUBASE: SYST:REM:ADDR:SEC 6,"CDMA2KPCSMS_NSig"
CMUBASE: SYST:REM:ADDR:SEC 7,"CDMA2KIMT2KMS_Sig"
CMUBASE: SYST:REM:ADDR:SEC 8,"CDMA2KIMT2KMS_NSig"
CMUBASE: SYST:REM:ADDR:SEC 9,"AMPSMS_Sig"
CMUBASE: SYST:REM:ADDR:SEC 10,"AMPSMS_NSig"
CMUBASE: SYST:REM:ADDR:SEC 11,"RF_NSig"

CMUBASE: SYST:REM:ADDR:SEC?

FPRINT -----
FPRINT Configure the connector
FPRINT -----
C2KCell-S: INP:STAT RF2
C2KCell-S: OUTP:STAT RF2
C2KCell-S: SENS:CORR:LOSS:INP2 1.0
C2KCell-S: SENS:CORR:LOSS:OUTP2 1.0

FPRINT -----
FPRINT Network configuration
FPRINT -----

C2KCell-S: CONFigure:NETWork:STANDard USC
C2KCell-S: CONFigure:NETWork:STANDard?

C2KCell-S: CONFigure:NETWork:IDENTity:MCC?
C2KCell-S: CONFigure:NETWork:SYSTEM:SID 1
C2KCell-S: CONFigure:NETWork:SYSTEM:SID?
C2KCell-S: CONFigure:NETWork:IDENTity:NID?

FPRINT -----
FPRINT SUBSYSTEM BSSignal
FPRINT -----

C2KCell-S: CONFigure:BSSignal:CHANnel 283
C2KCell-S: CONFigure:BSSignal:CHANnel?
C2KCell-S: CONFigure:BSSignal:POWER:CDMA -50
C2KCell-S: CONFigure:BSSignal:POWER:CDMA?
C2KCell-S: CONFigure:BSSignal:POWER:OUTput?

FPRINT -----
FPRINT SUBSYSTEM Service Configuration
FPRINT -----

C2KCell-S: CONFigure:SCONfig:SCLass1:SERVICE Loop
C2KCell-S: CONFigure:SCONfig:SCLass1:SERVICE?

```

```

C2KCell-S: CONFigure:SCONfig:SCLass1:LOOP:S02D:FCH:RC 1,1
C2KCell-S: CONFigure:SCONfig:SCLass1:LOOP:S02D:FCH:RC?
C2KCell-S: CONFigure:SCONfig:SCLass1:LOOP:S09D:FCH:RC 5,4
C2KCell-S: CONFigure:SCONfig:SCLass1:LOOP:S09D:FCH:RC?

C2KCell-S: CONFigure:SCONfig:SCLass1:LOOP:S02D:FCH?
C2KCell-S: CONFigure:SCONfig:SCLass1:LOOP:S09D:FCH?

C2KCell-S: CONFigure:SCONfig:SCLass1:LOOP:SOPTion S02D
C2KCell-S: CONFigure:SCONfig:SCLass1:LOOP:SOPTion?

FPRINT -----
FPRINT Configure Overview measurements
FPRINT -----

C2KCell-S: CONFigure:OVERview:OVERview:HPSK:CONTRol:STATistics 50
C2KCell-S: CONFigure:OVERview:OVERview:HPSK:CONTRol:STATistics?

C2KCell-S: CONFigure:OVERview:CQQuality:CONTRol:FRAMES 30
C2KCell-S: CONFigure:OVERview:CQQuality:CONTRol:FRAMES?

C2KCell-S: CONFigure:OVERview:PPOWER:ENABLE ON
C2KCell-S: CONFigure:OVERview:PPOWER:ENABLE?

FPRINT -----
FPRINT Configure FER measurement
FPRINT -----

C2KCell-S: CONFigure:RXQuality:FER:FSSCommon:CONTRol:TSETup1:POWER:CDMA -104
C2KCell-S: CONFigure:RXQuality:FER:FSSCommon:CONTRol:TSETup1:POWER:CDMA?
C2KCell-S: CONFigure:RXQuality:FER:FSSCommon:CONTRol:TSETup1:LEVel -7, -
15.6, -13.5
C2KCell-S: CONFigure:RXQuality:FER:FSSCommon:CONTRol:TSETup1:LEVel?

C2KCell-S: CONFigure:RXQuality:FER:FCH:CONTRol:TSETup1:FRAMES 10
C2KCell-S: CONFigure:RXQuality:FER:FCH:CONTRol:TSETup1:FRAMES?
C2KCell-S: CONFigure:RXQuality:FER:FCH:CONTRol:TSETup1:REPetition
SING,NONE,NONE
C2KCell-S: CONFigure:RXQuality:FER:FCH:CONTRol:TSETup1:REPetition?

C2KCell-S: CONFigure:RXQuality:FER:FSSCommon:CONTRol:TSETup2:POWER:CDMA -25
C2KCell-S: CONFigure:RXQuality:FER:FSSCommon:CONTRol:TSETup2:POWER:CDMA?
C2KCell-S: CONFigure:RXQuality:FER:FSSCommon:CONTRol:TSETup2:LEVel -7, -
15.6, -13.5
C2KCell-S: CONFigure:RXQuality:FER:FSSCommon:CONTRol:TSETup2:LEVel?

C2KCell-S: CONFigure:RXQuality:FER:FCH:CONTRol:TSETup2:FRAMES 10
C2KCell-S: CONFigure:RXQuality:FER:FCH:CONTRol:TSETup2:FRAMES?
C2KCell-S: CONFigure:RXQuality:FER:FCH:CONTRol:TSETup2:REPetition
SING,NONE,NONE
C2KCell-S: CONFigure:RXQuality:FER:FCH:CONTRol:TSETup2:REPetition?

FPRINT -----
FPRINT Configure NPM measurement
FPRINT -----

```

```

C2KCell-S: CONFigure:NPOWer:CONTRol:REPetition SING,NONE,NONE
C2KCell-S: CONFigure:NPOWer:CONTRol:REPetition?
C2KCell-S: CONFigure:NPOWer:EREPorting?
C2KCell-S: CONFigure:NPOWer:CONTRol:STATistics 1
C2KCell-S: CONFigure:NPOWer:CONTRol:STATistics?

FPRINT -----
FPRINT Configure the CMU - Function Group AMPS
FPRINT -----

AMPS-MS: CONFigure:NETWork:MS:CMAC 7
AMPS-MS: CONFigure:NETWork:MS:VMAC 7
AMPS-MS: CONFIGURE:BSSIGNAL:AVC:CHANNEL 312
AMPS-MS: CONFigure:NETWork:OCHandoff:MS:VMAC 7

FPRINT -----
FPRINT Switch on the RF Signal and wait for registration
FPRINT -----

C2KCell-S: PROC:SIGN:ACT SON
C2KCell-S: SIGNalling:STATe?

REPORT OFF
WHILE C2KCell-S: sign:stat? <> REG
REPORT ON

C2KCell-S: SIGNalling:STATe?

FPRINT -----
FPRINT Establish SO9 Call: F-RC = 5 and R-RC = 4
FPRINT -----

C2KCell-S: CONFigure:SCONfig:SCLass1:LOOP:SOPTion S09D
C2KCell-S: CONFigure:SCONfig:SCLass1:LOOP:SOPTion?

C2KCell-S: PROCedure:SIGNalling:ACTion CTM

REPORT OFF
WHILE C2KCell-S: sign:stat? <> CEST
REPORT ON

C2KCell-S: SIGNalling:STATe?

FPRINT -----
FPRINT Overview Pilot Power, Modulation and Channel Quality in parallel
FPRINT -----

C2KCell-S: INIT:OVERview:CQQuality
C2KCell-S: READ:OVERview:OVERview:HPSK?
C2KCell-S: OVERview:PPOWer?

WHILE C2KCell-S: FETC:OVERview:CQQuality:STAT? !{ } RDY

; Collect CQuality results
C2KCell-S: FETC:OVERview:CQQuality?
C2KCell-S: ABORT:OVERview:CQQuality

```

```

FPRINT -----
FPRINT FER measurement
FPRINT -----

C2KCell-S: CONFigure:RXQuality:FER:FSSCommon:TSETup T1
C2KCell-S: CONFigure:RXQuality:FER:FSSCommon:TSETup?
C2KCell-S: READ:SCALar:RXQuality:FER:FCH?

C2KCell-S: CONFigure:RXQuality:FER:FSSCommon:TSETup T2
C2KCell-S: CONFigure:RXQuality:FER:FSSCommon:TSETup?
C2KCell-S: READ:SCALar:RXQuality:FER:FCH?

FPRINT -----
FPRINT NPM measurement
FPRINT -----

[NPOWLOOP]
C2KCell-S: READ:NPOwer?
REPEAT 15 NPOWLOOP

FPRINT -----
FPRINT CDP measurement
FPRINT -----

C2KCell-S: READ:SCALar:CDPower:CDPW?
C2KCell-S: READ:SCALar:CDPower:PCDep?
C2KCell-S: READ:SCALar:CDPower:CHPW?

FPRINT -----
FPRINT Start the AMPS Handoff
FPRINT -----

C2KCell-S: STATus:HANDoff:TARGet:LIST?
C2KCell-S: CONFigure:HANDoff:TARGet 'AMPSMS'
C2KCell-S: CONFigure:HANDoff:TARGet?

C2KCell-S: PROCedure:SIGNalling:ACTion HAND

FPRINT -----
FPRINT Query the CMU State
FPRINT -----

REPORT OFF
WHILE AMPS-MS: sign:stat? <> CEST
REPORT ON

FPRINT -----
FPRINT AMPS Handoff was successful
FPRINT Query the power class of the mobile
FPRINT -----
AMPS-MS: MSSinfo:PClass?

```

```
FPRINT -----  
FPRINT Start TX Tests Modulation measurement  
FPRINT Result: CarrierFreqError, TotalPeakDeviation, SATFreqError,  
SATPeakDeviation, STFreqError, STPeakDeviation,  
FPRINT      AudioPeakDeviation, AudioRMSDeviation, ModDistNoise,  
CarrierPower, ResidualAM  
FPRINT -----
```

AMPS-MS: READ:TXT:MOD?

```
FPRINT -----  
FPRINT Call Release  
FPRINT -----
```

AMPS-MS: PROCedure:SIGNalling:ACTion CREL

Contents

8	CDMA2000 Data Testing.....	8.1
	Setting up a Packet Data Connection.....	8.1
	TCP/IP Settings (Setup – TCP/IP).....	8.3
	Packet Data Service Configuration.....	8.6
	Packet Data Measurements.....	8.15
	RLP Frame & IP Statistics	8.15
	Softkey Selections	8.15
	Measurement Results	8.16
	Ping Measurement.....	8.18
	Softkey Selections	8.18
	Measurement Results	8.19
	Ping Configuration	8.20
	Basic IP Test Environments	8.22
	Ping.....	8.22
	Internal FTP Server	8.23
	IP Connection with external PC.....	8.24
	Remote Control Commands.....	8.25
	Configuration of the Service Option 33.....	8.25
	RLPStatistic (RLP Frame & IP Statistics).....	8.32
	PING (RLP Frame & IP Statistics).....	8.34
	Subsystem PING:CONTROL	8.35
	Measured Values	8.37

8 CDMA2000 Data Testing

The R&S CMU supports Service Option 33 that CDMA2000 mobiles can use to request packet data service through a serving node supporting a standard Internet Point-to-Point Protocol (PPP) interface to network layer protocols. Configuration of Service Option 33 is described in section [Packet Data Service Configuration](#) on p. 8.6 ff.

Packet data services can be tested with different IP protocols and test environments:

- If the Simple IP protocol is used, a PPP link is established to the mobile and PPP authentication is allowed. The CMU can directly assess the quality of a PPP connection using its internal FTP server and the Ping application but also operate as an IP interface between a network server and the mobile; see section [Basic IP Test Environments](#) on p. 8.22 ff.
- If the Mobile IP (MIP) protocol is used, the mobile performs MIP registration / authentication but no PPP authentication. The CMU can be configured to operate in either the MIP stand alone or in MIP gateway mode. Configuration of the MIP test modes and possible tests are described in section [Packet Data Service Configuration](#) on p. 8.6 ff.

MIP tests require option R&S CMU-K87, *CDMA2000 Data Testing*. In addition to MIP support, option R&S CMU-K87 provides a preconfigured *RLP Frame & Statistics* and a *Ping* measurement; see section [Packet Data Measurements](#) on p. 8.15 ff. For more information and application examples please refer to application note 1CM51, *Packet Data Testing*, on the CMU documentation CD-ROM.

Note: *To be integrated in a network, the CMU must be equipped with option R&S CMU-B87, Interface for CDMA2000 Data Tests. This option includes the Message Monitor, a software accessory for the CDMA2000 options to be installed on a PC. The Message Monitor captures, interprets, and displays the CDMA forward and reverse link messages and the PPP messages (LCP, IPCP, PAP, CHAP protocols) exchanged between a CMU200 and a mobile station. For more information refer to the separate CMU-B87 operating manual, stock no. 1007.9616.32.*

Setting up a Packet Data Connection

Integration of the CMU into a Mobile IP or Simple IP test environment requires the configuration of the necessary IP addresses and test parameters. The application note 1CM51, *Packet Data Testing*, on the CMU documentation CD-ROM reports the most common test configurations in detail; the following procedure can serve as a general guideline.

- Open the Misc tab of the Connection Control menu (see section [TCP/IP Settings \(Setup – TCP/IP\)](#) on p. 8.3 ff.). In the TCP/IP section configure the CMU for either Static or Dynamic IP addressing.
- If you choose static addressing, assign the necessary IP address information. Open the *Service Cfg.* tab and assign a compatible *MS PPP IP Address* and *BS PPP IP Address* (see section [Packet Data Service Configuration](#) on p. 8.6 ff.).

The IP addresses will be valid for the duration of the connection.

- If you choose to integrate your R&S CMU into a Mobile IP environment, go to the *Protocol – Mobile IP* subsection in the *Service Cfg.* tab (see section [Packet Data Service Configuration](#) on p. 8.6 ff.) and activate or deactivate the *MIP Stand Alone Mode*. Depending on the selected MIP mode, define the remaining Mobile IP parameters. For MIP stand alone mode, the *Home Agent Secret* must comply with the one stored in the mobile.
- Open the *Connection* tab, select *Packet Data Service* as primary service class.

- In the *FCH & SCH Config.* section in the *Service Cfg.* tab, select the data rates for the forward and reverse link suitable for your application (e.g. asymmetric data rates for file transfer in one way).
- Establish an RF connection between your mobile and the CMU and wait until it has performed a CDMA2000 network registration.
- From the *Registered* state, establish a SO33 (IP) data call from the mobile using a dial-up connection and #777 as the dialed number.

Packet Data Service is activated and the CMU enters the *PPP Connected* state; see Fig. 8-1 below.

PPP Signalling States

For packet data connections, the CMU uses a modified state machine where the CDMA2000 network signalling states *Signal Off*, *Signal On*, and *Registered* are complemented by the *PPP Dormant* and *PPP Connected* states (see Fig. 8-1 below). The *PPP Connected* state is reached in two steps after a SO33 data call is set up from the mobile: The traffic channels are first established and then the PPP link is set up. *Disconnect MS* transitions from *PPP Connected* to *PPP Dormant*. In the *PPP Dormant* state, the packet data service option is disconnected, however, a logical IP connection is maintained.

The following icons in the menu headers indicate the new signalling states:





Fig. 8-1 Signalling states for packet data connections

TCP/IP Settings (Setup – TCP/IP)

The *TCP/IP* tab of the *Setup* menu provides the IP address information for the *Universal Signalling Unit CMU-B83*, to be used for CDMA2000 data application tests.

➤ To access the *Setup* menu, press the *SETUP* key on the front panel of the instrument.

Note: The *TCP/IP* information is not changed after a reset of the instrument. The default values (factory settings) can be restored by means of the Default Settings switch.

The *TCP/IP* settings belong to the R&S CMU200 base system. For detailed information, in particular concerning remote control, refer to the R&S CMU200/300 operating manual.

All *TCP/IP* settings are disabled while a packet data connection is active.




Figure 8-2 Connection Control – Misc. Settings

Default Settings The *Default Settings* switch assigns default values to all settings in the *TCP/IP* section (the default values are quoted in the command description in the *R&S CMU200/300 operating manual*).

Remote control

SYSTem:TCPip:SECondary:DEFault ON | OFF

Type of CMU IP Addressing

Depending on the network capacities and the user preferences, the *TCP/IP* address information for the R&S CMU can be configured in two different ways:

Static

Manual setting of the addresses in the *Static* *TCP/IP* address subsection. This option must be selected if the network does not support dynamic *TCP/IP* configuration using the Dynamic Host Configuration Protocol (DHCP).

Dynamic

Automatic assignment of all necessary addresses (including the MS PPP IP and BS PPP IP addresses displayed in the *Service Config.* tab of the *Connection Control* menu; see section [Packet Data Service Configuration](#) on p. 8.6 ff.) using a definite CMU hostname and DHCP (dynamic *TCP/IP* configuration). See description of the *Dynamic* subsection below.

Dynamic (Retry)? Repeat the dynamic addressing procedure. This message is displayed after a failed attempt to use dynamic addressing. Possible error scenarios are listed in [Table 8-1](#) below.

Attention! *If you choose static TCP/IP addressing, contact your network administrator to obtain a valid IP address. Connection errors can affect the entire network.*

```
Remote control
SYSTem:TCPip:SECondary:MODE
    STATic | DYNAmic (| PENding | UDEF)
SYSTem:TCPip:SECondary:FCODE?
```

Static

Sets the IP addresses to be used if *Static* CMU IP addressing is selected:

IP Address IP address of the CMU
Subnet Mask Subnet Mask address of the CMU
Default Gateway Address used to configure a default route in the CMU

For more information on IP addresses refer to the CMU-B87 operating manual, stock no. 1007.9616.32.

```
Remote Control SYSTem:TCPip:SECondary:STATic:IPAdDress <IP1>, <IP2>, <IP3>, <IP4>
SYSTem:TCPip:SECondary:STATic:SMASk <SM1>, <SM2>, <SM3>, <SM4>
SYSTem:TCPip:SECondary:STATic:DGATeway <GW1>, <GW2>, <GW3>, <GW4>
```

Dynamic

Sets the CMU hostname and displays the IP addresses obtained from the network if *Dynamic* CMU IP addressing is selected. To establish a dynamic IP connection proceed as follows:

1. In the *Dynamic* subsection, enter the *CMU Hostname* you wish to assign to the CMU.
2. Select dynamic Type of CMU IP Addressing.

During the IP address acquisition phase, the CMU hostname is registered with the DHCP server and the CMU displays the message *DHCP Procedure Pending*. This operation may take several seconds to complete depending on network traffic, DHCP server congestion, etc. When the DHCP procedure completes, the acquired addresses are displayed in the *Dynamic* TCP/IP address subsection. If dynamic TCP/IP configuration fails, the R&S CMU displays one of the failure messages listed in [Table 8-1](#) below and the Ethernet interface is disabled.

Note: *When the DHCP server on the network is running Windows Server, the DNS is not properly notified of the CMU hostname. In order to identify the CMU by its hostname, it will be necessary to add the hostname, along with the IP address obtained from DHCP and displayed on the CMU, to the DNS table. This must be done whenever the CMU is re-booted and thus obtains a new address via DHCP. If the CMU is not added to the DNS table, the instrument must be identified only by its IP address.*

```
Remote Control SYSTem:TCPip:SECondary:DYNAmic:HNAME
SYSTem:TCPip:SECondary:DYNAmic:DNS?
SYSTem:TCPip:SECondary:DYNAmic:IPAdDress?
SYSTem:TCPip:SECondary:DYNAmic:SMASk?
SYSTem:TCPip:SECondary:DYNAmic:DGATeway?
```


DHCP Failure

The R&S CMU contacts the DHCP server during the following scenarios:

- At R&S CMU initialization (if *Type of CMU IP Addressing* is set to *Dynamic*).
- At run-time when the user changes the *Type of CMU IP Addressing* from *Static* to *Dynamic*.

- At run-time when the lease has expired. The DHCP client is required to renew its lease with the DHCP server when the lease duration has expired.

The DHCP procedure may fail for a number of reasons. Possible failure scenarios and error messages in the *Type of CMU IP Addressing* field are listed in [Table 8-1 below](#). In case of a failure the *Dynamic* parameter field and a yellow notice box show *DHPC Failure – External Ethernet IP connection is now disabled*.



Whenever a DHCP failure condition is detected, the R&S CMU takes the following actions:

- The CMU200 Ethernet interface is disabled.
- Bit no. 14 of the `STATUS:OPERation` register for the R&S CMU base system and bit no. 1 of the extended `STATUS:OPERation` register for the CDMA2000 function groups is set (see Chapter 5 of the CMU 200/300 manual and CDMA2000 operating manual).

By disabling the Ethernet interface, the CMU200 will not be able to communicate with any remote hosts.

- Dynamic CMU *IP Address* is set to “169.254.X.X” (where X.X is derived from the serial number of the CMU200)
- Dynamic CMU *Subnet Mask* is set to “255.255.0.0”.
- Dynamic CMU *Default Gateway* address is removed.
- Dynamic *MS and BS PPP IP Addresses* (see section [Packet Data Service Configuration](#) on p. 8.6 ff.) are set to the static MS and BS PPP IP Address values.

By maintaining these PPP IP Addresses, the CMU200 will still be able to establish SO33 data calls. Only the internal FTP server can be used to transfer data to/from the mobile since no outside communication is possible.

Remote Control `SYSTEM:TCPIP:SECondary:FCODE?`

Table 8-1 DHCP Failure Scenarios, error messages and error codes

Message in Type of CMU IP Addressing	Error code IPAD : DYN : F COD ?	Failure reason	Possible cause
Dyn. Event Failed	-1	The DHCP Server failed to respond or rejected the DHCP request.	<ul style="list-style-type: none"> • CMU200 ethernet cable not properly connected to LAN • DHCP server unavailable
No Target IP Allocated	-2	The DHCP Server failed to allocate the Target (CMU200) IP Address.	<ul style="list-style-type: none"> • CMU200 ethernet cable not properly connected to LAN • DHCP server unavailable
Interface Down	-3	The CMU200 Ethernet Interface is disabled.	CMU200 ethernet cable not properly connected to LAN
No Router IP Allocated	-4	The DHCP Server failed to allocate the Router/Gateway IP Address.	DHCP server not configured to support TAG 3 (router). See RFC 2132 for more details.
Mobile Home IP Addr.	-5	The DHCP Server failed to allocate the BS and MS PPP IP Addresses.	<ul style="list-style-type: none"> • DHCP server not configured to support TAG 68 (mobile IP home agent). See RFC 2132 for more details. • DHCP server not configured to return 2 IP Addresses in TAG 68 (mobile IP home agent). See RFC 2132 for more details.
Bind Failure	-6	The CMU200 failed to initialize the DHCP client software.	Internal CMU200 DHCP software initialization problem.

Packet Data Service Configuration

The parameters in the *Packet Data Service* section of the *Service Cfg.* tab in the *Connection Control* menu configure Service Option 33 for *Packet Data Service*.

The configuration of the traffic channels for SO33 is described in Chapter 4. The *Protocol* section provides the parameters for end-to-end data testing. Most of the data tests require option R&S CMU-K87, *CDMA2000 Data Testing*. The following paragraphs describe the parameters and their use; for further information refer to the application note 1CM51, *Packet Data Testing*, on the CMU documentation CD-ROM.

Note: *Many of the TCP/IP settings are disabled while a packet data connection is active. Proceed as described in section [Setting up a Packet Data Connection](#) on p. 8.1 ff. and first configure your test environment before activating the Packet Data Service.*




Figure 4-3 Connection Control – Service Configuration (Packet Data Service)

Mobile IP

In the *Mobile IP* (MIP) section, the CMU is configured for one of the two basic MIP test environments *MIP stand alone* and *MIP gateway*. For both MIP environments, the CMU can use either static IP addressing or dynamic addressing (DHCP); see section *TCP/IP Settings (Setup – TCP/IP)* on p. 8.1 ff.

- In MIP gateway mode the CMU behaves like a gateway (router) between the mobile and the Foreign Agent (see *MIP Protocol Features* below). The CMU knows the Foreign Agent and Mobile Node Home IP addresses in order to route messages between the Foreign Agent and the mobile.




Figure 4-4 Data test environment : MIP gateway mode

- In MIP stand-alone mode the MIP functionality is restricted so that the Foreign Agent and Home Agent (see [MIP Protocol Features](#) below) are not present. MIP is still used to enable the CMU to broadcast pre-configured Agent Advertisements to the mobile, perform MD5 authentication with the mobile and respond the MIP Registration Request Message.




Figure 4-5 Data test environment : MIP standalone mode

The parameters to be set for the two MIP modes and for packet data connections based on the Simple IP protocol are listed in [Table 8-2](#) below.

MIP Protocol Features

Mobile IP (MIP) is a protocol that allows mobiles to travel outside their home area network and send and receive IP packets in a foreign network without having to update their home IP address. To this end the mobile is associated with two IP addresses: The static *MS Node Home Agent IP Address* plus a dynamic *Care-of Address*. In addition the MIP protocol introduces two new elements in the network environment: Home Agent and Foreign Agent (see Figure 4-4 above).

The *Home Agent* is a router with an interface on the mobile node's home network which the mobile keeps informed of its location, so that the home agent can intercept packets destined to the *MS Node Home Agent IP Address* and forward (tunnel) them to the mobile using the dynamic *Care-of Address*.

The *Foreign Agent* is a router on the mobile node's foreign network which de-tunnels the packets for the mobile node received from the home agent and serves as a default router for packets generated by the mobile node.

Table 8-2 Parameters for the Mobile IP (MIP) and Simple IP connections

Test environment	MIP gateway	MIP stand alone	Simple IP
Prerequisites	Both R&S CMU-B87 and CMU-K87 are required. Option R&S CMU-B87 (hardware – <i>Interface for CDMA2000 Data Tests</i>) is needed to connect the R&S CMU to the remote FA/HA servers. The R&S CMU-K87 (software) supports the MIP functionality, authentication etc.	R&S CMU-K87 required; R&S CMU-B87 is optional. Option R&S CMU-B87 (hardware – <i>Interface for CDMA2000 Data Tests</i>) is needed to connect the R&S CMU to an external server. The R&S CMU-K87 (software) supports the MIP functionality, authentication etc.	R&S CMU-K87 and R&S CMU-B87 are optional. Option R&S CMU-B87 (hardware – <i>Interface for CDMA2000 Data Tests</i>) is needed to connect the CMU to an external server. The R&S CMU-K87 is needed to do PPP authentication or packet zone configuration.

Test environment	MIP gateway	MIP stand alone	Simple IP
Activation	Static or dynamic IP addressing (Connect. Cont. – Misc.) MIP Stand Alone Mode: Off	Static or dynamic IP addressing (Connect. Cont. – Misc.) MIP Stand Alone Mode: On	Static or dynamic IP addressing (Conn. Cont. – Misc.)
Parameters: Mobile IP	Foreign Agent IP Addr. MS Node Home Agent IP Addr. (query) Care-of Address (query)	Mobile Home IP Address, MS Node Home Agent Secret, MIP Agent Advertisements, Registration Reply Code Registration Reply Lifetime MIP authentication type	–
Parameters: PPP	IP Address (Static/Dynamic) not allocated to the MS but still needed to filled in properly to set up the PPP link. Inactivity Control	IP Address (Static/Dynamic) not allocated to the MS but still needed to filled in properly to set up the PPP link. Inactivity Control	IP Address (Static/Dynamic) IP address assignment during PPP link establishment (IPCP prot.) Inactivity Control (with CMU-K87) PPP Authentication (CHAP/PAP; with CMU-K87)
Packet Zone Configuration	–	All parameters	All parameters (with CMU-K87)

MIP Stand Alone Mode

Selects the MIP mode that the CMU is configured for.

- On* MIP stand alone mode. In this mode, no *Foreign Agent IP Address* is used because no foreign agent is present.
- Off* MIP gateway mode. In this mode, the *Foreign Agent IP Address* can be set. The *Mobile Home IP Address*, *MS Node Home Agent Secret*, *MIP Agent Advertisements*, *Registration Reply Code* are automatically assigned by the Home Agent/Foreign Agent.

The two alternative modes and their parameters are described above.

Remote control: `CONFigure:SCONfig:SClass<nr>:PDAT:S33D:MIP:SAMode`

Mobile Node Home IP Addr.

IP address of the mobile in its home network (optional). This address can be defined in MIP stand alone mode and is used in case the home IP address is not programmed in the mobile (its IP address is set to 0.0.0.0). If a home IP address is programmed in the mobile then the *Mobile NodeHome IP Addr.* is overwritten with the value programmed in the phone (when the MS completes the MIP Registration).

Remote control: `CONFigure:SCONfig:SClass<nr>:PDAT:S33D:MIP:MHIP`

Foreign Agent Home IP Addr.

IP address of the Foreign Agent (see [MIP Protocol Features above](#)), to be defined in MIP gateway mode. If the CMU is directly connected to the Foreign Agent, then the *Default Gateway* (see section [TCP/IP Settings \(Setup – TCP/IP\)](#) on p. 8.1 ff.) should match the FA Address.

However, if the CMU is connected to another gateway that then routes the IP packets to/from the FA, the default gateway is different from the Foreign Agent Address.

Remote control: `CONFigure:SCONfig:SClass<nr>:PDAT:S33D:MIP:FAIP`

MS Node Home Agent Secret Secret used by the R&S CMU to do Mobile IP MD5 authentication in MIP stand alone mode. This value **must** match the MN-HA secret programmed in the mobile phone, otherwise, no IP connection can be set up from the MS.

Remote control: `CONFigure:SCONfig:SClass<nr>:PDAT:S33D:MIP:HASecret`

MS Node Home Agent IP Addr. IP address of the Home Agent; see [MIP Protocol Features above](#). The address is programmed in the mobile and used for registration and tunneling purposes. It is captured and displayed when a mobile IP call is made.

Remote control: `CONFigure:SCONfig:SClass<nr>:PDAT:S33D:MIP:HAIP?`

Care of Address IP address that the Foreign Agent uses to decapsulate packets which have been tunneled by the home agent and to deliver them to the mobile node. The address is captured and displayed when a mobile IP call is made.

Remote control: `CONFigure:SCONfig:SClass<nr>:PDAT:S33D:MIP:COAddress?`

MP Agent Advertisements Enables or disables the R&S CMU to broadcast MIP Agent Advertisements to advertise its presence on the network. This parameter is available in MIP stand alone mode only. With disabled MP Agent Advertisements, no IP connection from the MS can be set up.

Remote control: `CONFigure:SCONfig:SClass<nr>:PDAT:S33D:MIP:AADV`

Registration Reply Code Code number sent to the mobile in the CAUSE_CODE field of the *Registration Reply* message. This parameter is available in MIP stand alone mode only where it can be used to test different failure conditions at the network.

An MIP call can be set up if the MS is configured with registration reply code 0, *Registration Accepted*. With all other codes, MIP registration will fail. The MIP phone may revert back to Simple IP.

Remote control: `CONFigure:SCONfig:SClass<nr>:PDAT:S33D:MIP:RRCode`

Registration Reply Lifetime Number of seconds remaining before the registration is considered expired and the mobile has to re-register. This parameter is sent to the mobile in the *Registration Reply* message in order to govern the time between consecutive registrations from the mobile. It is available in MIP stand alone mode only. The following values have special meanings:

- The minimum value of 0 s indicates that the mobile has to de-register.
- The maximum value of 65535 s indicates infinity: the registration never expires.

Remote control: `CONFigure:SCONfig:SClass<nr>:PDAT:S33D:MIP:RRLTime`

MIP Authentication Type Authentication type for the Mobile IP MD5 authentication in MIP stand alone mode. The parameter is used by the R&S CMU200 when encrypting/decrypting the Mobile IP messages. The R&S supports authentication according to standard RFC 2002 or the extended standard RFC 2002 bis, according to which the SPI number must be included as part of the authentication calculation.

The parameter is available in MIP stand alone mode only.

Remote control: `CONFigure:SCONfig:SClass1:PDAT:S33D:MIP:AUTHentic:TYPE
R02 | R02B`

PPP The *PPP* section provides the addresses for the Point-to-Point Protocol connection between the CMU and the mobile, configures the mobile's authentication procedure and the timers controlling the transition between PPP Dormant and PPP Connected state.

PPP – IP Address – Static Definition of the static IP addresses for the R&S CMU (BS) and the mobile node (MS). The addresses are used if the CMU is configured for static IP addressing; see section [TCP/IP Settings \(Setup – TCP/IP\)](#) on p. 8.1 ff:

- In a *Simple IP* test environment, the PPP IP addresses are used for the PPP connection between the R&S CMU and the mobile node. These addresses must be within the R&S CMU's subnet, defined in the *Misc.* tab (*Subnet Mask*).
- In a *Mobile IP* test environment, the PPP IP addresses are not assigned to a definite connection (the addresses in the *Mobile IP* section are used instead; see above). Still the PPP IP addresses are used internally and should be configured properly (i.e. within the R&S CMU's subnet).

Note: *The BS PPP and MS PPP IP addresses assigned must be **different** from the CMU and Gateway IP Addresses defined in the Misc. tab of the Connection Control menu; see Figure 8-2 on p. 8.3.*

Remote control: `CONFigure:SCONfig:SClass<nr>:PDAT:S33D:REVerse[:STATIC]:IPAddress
CONFigure:SCONfig:SClass<nr>:PDAT:S33D:FORWard[:STATIC]:IPAddress`

PPP – IP Address – Dynamic Display of the dynamically allocated IP addresses for the CMU (BS) and the mobile under test (MS). The addresses are available if the CMU is configured for dynamic IP addressing using DHCP; see section [TCP/IP Settings \(Setup – TCP/IP\)](#) on p. 8.1 ff. They are used in the same way as static PPP IP addresses.

Remote control: `CONFigure:SCONfig:SClass<nr>:PDAT:S33D:REVerse:DYNamic:IPAddress?
CONFigure:SCONfig:SClass<nr>:PDAT:S33D:FORWard:DYNamic:IPAddress?`

PPP – Authentication Selects and configures the PPP authentication algorithm to be used for Simple IP connections. Refer to document RFC 1334, *PPP authentication protocols*, for details.

PPP Authentication Type

For Mobile IP connections authentication must be disabled (*NONE*). For Simple IP connections, both the *PAP* and *CHAP* authentication protocols are supported.

Username Max. 72-character username for PAP or CHAP authentication.

Password Max. 72-character password for PAP or CHAP authentication.

CHAP Interval Time interval used for CHAP authentication. The interval defines how often the mobile is re-authenticated with the system.

Remote control: `CONFigure:SCONfig:SClass<nr>:PDAT:S33D:AUTHentic:TYPE`
`CONFigure:SCONfig:SClass<nr>:PDAT:S33D:AUTHentic:UNAME`
`CONFigure:SCONfig:SClass<nr>:PDAT:S33D:AUTHentic:PWOrd`
`CONFigure:SCONfig:SClass<nr>:PDAT:S33D:AUTHentic:CINterval`

PPP – Inactivity Control

Configures the timers controlling the transition of the MS between PPP Dormant and PPP Connected state. In the dormant state, the packet data service option is disconnected, however, a logical IP connection is maintained. The CMU can transition the MS from PPP Dormant to PPP Connected state by sending data to the MS; for details refer to document TIA/IS-707-A-3.

The MS states *PPP Dormant* and *PPP Connected* correspond to two distinct signalling states of the CMU; see [Fig. 8-1](#) on p. [8.2](#).

Network PPP Inactivity Timer

Time interval after which the CMU will transition the MS from PPP Connected to PPP Dormant state if there is no data being sent to or received from the MS. Switching the timer *Off* disables the automatic transition to PPP Dormant state so that the MS will remain PPP Connected after a SO33 data connection is established.

This timer also governs if the CMU transitions the MS out of the PPP Dormant state (to PPP Connected) if there is incoming data for the MS. If the timer is set to something other than OFF, this functionality is enabled.

The *MS Inactivity Control* parameters are stored and maintained in the MS but can be changed by sending a *Service Option Control Message* in the *PPP Connected* state.

MS Dormant Control Value of the DORM_CNTL parameter in the standard. Enables or disables packet data dormant timer control of the MS. If dormant timer control is enabled, the MS will not return to PPP Connected state until the *MS Dormant Timer* has expired. Disabling MS dormant control is equivalent to a *MS Dormant Timer* of 0 s.

MS Dormant Timer Value of the DORM_TIME parameter in the standard. Defines the time that the MS, after receiving data in the PPP Dormant state, will wait before returning to PPP Connected. The timer is used only if *MS Dormant Control* is enabled.

Service Opt. Ctrl Msg.Execute causes the CMU to send a *Service Option Control Message* to the MS in order to configure its *MS Dormant Timer* and *MS Dormant Control* parameters. The button is enabled in the *PPP Connected* state only. While the message is transferred, the *Execute* button is grayed out to indicate that the transfer is in progress. The button is re-enabled after the MS has acknowledged the message.

For application examples related to MS packet dormant timer control refer to the application note 1CM51, *Packet Data Testing*, on the CMU documentation CD-ROM.

Remote control: `CONFigure:SCONfig:SClass<nr>:PDAT:S33D:IAControl:NIATimer`
`CONFigure:SCONfig:SClass<nr>:PDAT:S33D:IAControl:MSDControl`

```
CONFigure:SCONfig:SClass<nr>:PDAT:S33D:IAControl:MSDTimer
CONFigure:SCONfig:SClass<nr>:PDAT:S33D:IAControl:SOCMessage
CONFigure:SCONfig:SClass<nr>:PDAT:S33D:IAControl:SOCMessage:STATE?
```

Packet Zone Configuration

Configures the CMU for *Packet Zone Connection/Reconnection* tests, to be performed in MIP stand alone mode.

Note: *When the MIP Mode is set to Gateway, the packet zone parameters are not utilized since no packet zone changes are allowed in this mode.*

This functionality can be used to test whether the mobile properly reconnects the packet data service option on receiving a new packet zone ID while it is in PPP Dormant state. It can be used also to test the packet zone connection control feature in PPP Connected state. For details refer to standard TIA/IS-707-A-3.

Packet Zone ID Packet data services zone identifier. This parameter can be changed in the *PPP Dormant* state to check the mobile's reconnection capability; see background information on PDSNs and Packet Zones below. It is disabled in the *PPP Connected* state. The IDs of visited packet zones are stored in a list with selectable length; see *Packet Zone List Length* below.

Target PDSN Qualifies whether the Packet Data Service Node (PDSN) is *Changed* along with the *Packet Zone ID*, or whether it remains *Unchanged*. See background information on PDSNs and Packet Control Functions below.

The following parameters are stored in the MS but can be changed by sending a *Service Option Control Message* in the *PPP Connected* state.

Packet Zone Connect.

Ctrl. Value of the PKT_CON_CNTL parameter defined in the standard. The values 1 to 4 specify how the mobile shall use the packet zone based reconnection feature and the list of visited *Packet Zone IDs*.

Packet Zone List Length

Value of the PKT_ZONE_LIST_LEN parameter defined in the standard. Defines the maximum number of visited *Packet Zone IDs* that the MS is to retain in its packet data zone identifier list.

Service Opt. Ctrl Msg. Execute causes the CMU to send a Service Option Control Message to the MS in order to update its Packet Zone Connect. Ctrl. and Packet Zone List Length parameters. The button is enabled in the PPP Connected state only. While the message is transferred, the Execute button is grayed out to indicate that the transfer is in progress. The button is re-enabled after the MS has acknowledged the message.

For application examples related to packet data mobility management refer to the application note 1CM51, *Packet Data Testing*, on the CMU documentation CD-ROM.

Remote control:

```
CONFigure:SCONfig:SClass<nr>:PDAT:S33D:PZONE:ID
CONFigure:SCONfig:SClass<nr>:PDAT:S33D:PZONE:TPDSn
CONFigure:SCONfig:SClass<nr>:PDAT:S33D:PZONE:CCTRL
CONFigure:SCONfig:SClass<nr>:PDAT:S33D:PZONE:LLENGTH
CONFigure:SCONfig:SClass<nr>:PDAT:S33D:PZONE:SOCMessage
CONFigure:SCONfig:SClass<nr>:PDAT:S33D:PZONE:SOCMessage:STATE?
```

PDSNs and Packet Zones

In the Mobile IP test environment, each Foreign Agent corresponds to a Packet Data Service Node (PDSN) which can service one or more packet zones. The zones are identified by their *Packet Zone ID*. A mobile in the PPP Dormant state shall initiate a reconnection of the packet data service option whenever it moves to a packet zone that is not on its internally stored list of visited packet zones.

The CMU can change the *Packet Zone ID* to simulate the transition to a new packet zone. The *Target PDSN* parameter qualifies whether the old and the new packet zones belong to the same PDSN (like zone A and zone B in Fig. 8-6 below), or whether the transition implies a change of the PDSN (like the transition from zone B to zone C in Fig. 8-6 below).

- In the *Unchanged* mode (same PDSN), the CMU acknowledges the packet zone change but does not re-establish the PPP connection with the mobile. The Care of Address remains unchanged.
- In the *Changed* mode (new PDSN), the CMU allocates a traffic channel and then establishes a new PPP connection with the mobile. A Mobile IP capable MS will perform a Mobile IP registration with the Home Agent to obtain an new Care of Address.




Fig. 8-6 Target PDSNs and Packet Zones

Packet Data Measurements

With option R&S CMU-K87, *CDMA2000 Data Testing*, it is possible to configure packet data measurements and evaluate the results at the CMU.

- The *RLP / IP Statistics* measurement evaluates the data flow on the CMU.
- The *Ping* measurement provides the ping statistics including the possible source of connection errors.

The packet data measurement menus form the second group of measurement menus *Menus (2/2)*. They can be opened from the *Menu Select* menu or from any other measurement menu in *CDMA2000 Signalling* after pressing the *Menus (1/2)/(2/2)* toggle key.

RLP Frame & IP Statistics

The *RLP / IP Statistics* menu displays a statistical evaluation of the data flow on the CMU. *RLP / IP Statistics* is an application of option R&S CMU-K87, *CDMA2000 Data Testing* which can be used to monitor test scenarios using the Mobile IP or Simple IP protocol types.

The *RLP / IP Statistics* results are available while the packet data service option is connected (signalling state *PPP Connected*). The results become invalid as soon the MS enters the *PPP Dormant* state.




Figure 8-7 RLP / IP Statistics Measurement menu

Softkey Selections

The *RLP / IP Statistics* measurement is controlled by means of the measurement control softkey below the *Connect. Control* softkey. The properties of the measurement control softkey are analogous in all measurements; see section *Analyzer/Generator – Measurement Control* in the *Non Signalling* section.

```

Remote Control INITiate:RLPStatistic
                ABORT:RLPStatistic
                STOP:RLPStatistic
                CONTinue:RLPStatistic
                FETCh:RLPStatistic:STATus?
    
```

The *Refresh Interval* hotkey is associated with the measurement control softkey.



Defines the time after which all results in the *RLP / IP Statistics* measurement menu are updated.

Remote Control `CONFigure:RLPStatistic:CONTrol:RINTerval[?]`

The remaining softkeys provide additional settings.




The *Analyzer Level/Trigger* softkey toggles between two sets of hotkeys to control the level in the RF signal path and define the trigger settings. These general settings are provided in the *Analyzer* and *Trigger* tabs of the *Connection Control* menu; see sections *Analyzer Control (Connection Control – Analyzer)* and *Trigger (Connection Control – Trigger)* in Chapter 4.



The *BS Signal Level / Imp.* softkey toggles between two sets of hotkeys to adjust the signal impairments and the base station signal levels. These general settings are provided in the *BS Signal* tab of the *Connection Control* menu; see section *Signals of the CMU (Connection Control – BS Signal)* in Chapter 4.



The *BS Signal Set. / P. Ctrl* softkey displays a set of hotkeys to adjust the RF channel and frame rate and the power control bits that the CMU sends to the mobile station to control its output power. These general settings are provided in the *BS Signal* tab of the *Connection Control* menu; see section *Signals of the CMU (Connection Control – BS Signal)* in Chapter 4.



The *Menus* toggle softkey displays the hotkey bar for switching to the other measurement menus.

Measurement Results

The results of the *RLP / IP Statistics* measurement are displayed in the central part of the measurement menu. The results are always available and constantly updated while a PPP connection is active and the measurement is switched on.

Table of RLP Frame Types

Rx	Rx Total	Tx	Tx Total	RLP Frame Type
0	1	0	1	Data (Unsegmented)
0	1	0	1	Data (Segmented)
3	787	6	3618	Fill
44	13095	0	0	Idle
2	435	0	18	NAK
0	8	0	0	SYNC
0	8	0	0	ACK
0	0	0	8	SYNACK
0	38	44	11053	B_Data
0	126	296	72827	C_Data
0	32	8	2179	D_Data
0	0	0	0	Reassembly
0	31	96	42690	Blank
0	0	0	0	Invalid
49	14562	450	132395	Summary

6742	0.0 kBit/s	Rx	3315738	105.1 kBit/s	Tx
PPP Total Bytes	Data Rate		PPP Total Bytes	Data Rate	

Data Rates

Figure 8-8 Measurement results (RLP / IP Statistics)

Table of RLP Frame Types

The RLP frames transferred between the CMU and the mobile are monitored in a table with four different columns containing the number of frames that the CMU received in the last *Refresh Interval (Rx)*, the total number of frames received since the beginning of the PPP connection (*Rx Total*), the number of frames transmitted in the last *Refresh Interval (Tx)*, and the total number of frames transmitted (*Tx Total*).

RLP (Radio Link Protocol Type 3) provides an octet stream transport service over forward and reverse traffic channels to support CDMA data services. The RLC procedures and frame types are described in standard 3GPP2 C.S0017-0-2.10. The table rows contain the complete list of RLP frame types:

Data (Unsegmented) / Data (Segmented) / Fill / Idle
Special RLP data frame formats

NAK NAK Control frame, requests the retransmission of one or more data frames

SYNC / SYN/NACK / ACK
Control frame types used during RLP initialization

B_Data / C_Data / D_Data
Data frames format B, C, or D

Reassembly Segmented RLP frame

Blank RLP frame that contains no bits

Invalid Frame discarded as invalid during RLP's frame validity checks

Summary Sum of all previous RLP frames. As the list contains all frame types, this is equal to the total number of RLP frames received.

PPP Total Bytes

Total number of bytes that the CMU received (*Rx*) or transmitted (*Tx*) since the beginning of the PPP connection.

Data Rate

Current received or transmitted data rate in kBit/s, averaged over the *Refresh Interval*.

Remote Control FETCh:RLPStatistic?

Ping Measurement

The *Ping* menu configures the R&S CMU to send repeated echo requests of configurable size (pings) to the mobile, wait for the echo and display the ping statistics including the possible source of connection errors. *Ping* is an application of option R&S CMU-K87, *CDMA2000 Data Testing*, which can be used to monitor test scenarios using the Mobile IP or Simple IP protocol types.

Ping measurements can be performed with a logical IP connection to the MS (signalling states *PPP Connected* or *PPP Dormant*). Sending a ping in *PPP Dormant* state will cause the MS to return to *PPP Connected* as long as the *Network PPP Inactivity Timer* is not set to *Off*. On the other hand, a ping *Repeat Interval* larger than the *Network PPP Inactivity Timer* (see p. 8.12) will prevent the transition from *PPP Connected* to *PPP Dormant*.

PING can also be used without a logical IP Connection to the MS, in order to PING a server connected to the CMU.




Figure 8-9 Ping Measurement menu

Softkey Selections

The *Ping* measurement is controlled by means of the measurement control softkey below the *Connect*. *Control* softkey and the associated hotkeys. The properties of the measurement control softkey are analogous in all measurements; see section *Analyzer/Generator – Measurement Control* in the *Non Signalling* section. The hotkeys associated with the measurement control key provide specific measurement settings. These settings are also provided in the configuration menu; see section *Ping Configuration* on p. 8.20 ff.

```

Remote Control  INITiate:PING
                 ABORT:PING
                 STOP:PING
                 CONTinue:PING
                 FETCh[:SCALar]:PING:STATus?
    
```

The remaining softkeys provide additional settings.

Analyzer Level Trg.

The *Analyzer Level/Trigger* softkey toggles between two sets of hotkeys to control the level in the RF signal path and define the trigger settings. These general settings are provided in the *Analyzer* and *Trigger* tabs of the *Connection Control* menu; see sections *Analyzer Control (Connection Control – Analyzer)* and *Trigger (Connection Control – Trigger)* in Chapter 4.

BS Signal Level Imp.

The *BS Signal Level / Imp.* softkey toggles between two sets of hotkeys to adjust the signal impairments and the base station signal levels. These general settings are provided in the *BS Signal* tab of the *Connection Control* menu; see section *Signals of the CMU (Connection Control – BS Signal)* in Chapter 4.

BS Signal Set. P. Ctrl

The *BS Signal Set. / P. Ctrl* softkey displays a set of hotkeys to adjust the RF channel and frame rate and the power control bits that the CMU sends to the mobile station to control its output power. These general settings are provided in the *BS Signal* tab of the *Connection Control* menu; see section *Signals of the CMU (Connection Control – BS Signal)* in Chapter 4.

Menus

The *Menus* toggle softkey displays the hotkey bar for switching to the other measurement menus.

Measurement Results

The results of the ping measurement and the basic settings are displayed in the central part of the measurement menu.




Figure 8-10 Measurement results (Ping)

Table of results The table displays the last five ping events of the current statistics cycle together with the used *IP Address*, the size of the send buffer (*Packet Size*) and the *Time* the CMU had to wait for the reply.

If the *Time* exceeds the *Ping Timeout*, the third column displays one of the following error messages:

No Host host unreachable (e.g. because a wrong IP address was used)
Inactive Link host could be reached but did not reply
Timeout ping timeout exceeded but none of the previous errors occurred

Ping statistics The progress of the measurement is shown in a statistics field with a green bar graph and the current number of elapsed pings. The bar reaches the end of the field each time a statistics cycle (comprising the number of echo requests defined via *Ping Count*) is completed.

Settings table The *Settings* table shows the statistical settings of the ping measurement defined in the configuration menu (see below) and the essential RF signal setting defined with softkey/hotkey combinations.

Remote Control READ[:SCALar]:PING?
 FETCh[:SCALar]:PING?
 SAMPlE[:SCALar]:PING?

Ping Configuration

The popup menu *Ping Configuration* provides specific settings for the Ping measurement. It is called up by pressing the measurement softkey at the top right in the measurement menu twice (once if it is already selected).




Figure 8-11 Ping Configuration Control

The statistics of *Ping* measurements is based on a statistics cycle comprising the number of echo requests defined via *Ping Count*. The *Repetition* mode is set by means of the *Ping – Repetition* softkey/hotkey combination and has the same meaning in all measurements; it is described in section *Overview Configuration – Control*.

The following additional parameters are available:

- Default Settings** Assigns default values to all *Ping* settings.
- Repeat Interval** Time between two consecutive echo requests.
- Timeout** Timeout in milliseconds to wait for each reply.
- Packet Size** Number of bytes in the send buffer.

IP Address If *Use MS IP Address* is selected, then the R&S CMU sends pings to the MS IP address defined in the *Service Cfg.* tab of the *Connection Control* menu:

<i>Mobile Home IP Address</i>	in MIP stand alone or gateway mode
<i>MS PPP IP Address</i>	for Simple IP connections

Otherwise the IP address defined in the *Ping Configuration* menu is used.

Remote Control DEFault:PING:CONTRol[?]
CONFigure:PING:CONTRol:PCOunt[?]
CONFigure:PING:CONTRol:REPetition[?]
CONFigure:PING:CONTRol:RINTerval[?]
CONFigure:PING:CONTRol:TOUT[?]
CONFigure:PING:CONTRol:PSIZE[?]
CONFigure:PING:CONTRol:MSIP[?]
CONFigure:PING:CONTRol:IPADdress[?]

Basic IP Test Environments

The tests and test environments described in this section are independent of the IP protocol type. Option R&S CMU-K87, *CDMA2000 Data Testing*, is required only if the Mobile IP protocol is used.

The packet data service provides a basic IP connection between a mobile and the base station/CMU. With a mobile supporting a data connection via a cable to a PC, a typical test setup looks as follows:




Figure 8-12 Test setup for packet data services

The RF link between the mobile and the CMU/base station plus the data cable link to PC#1 are equivalent to a point-to-point connection between the CMU and the PC#1. The R&S CMU is equipped with an internal 250 kbyte FTP server that can be addressed using the *BS PPP IP Address* set in the *Service Cfg.* tab. With this feature, it is possible to directly address the CMU, e.g. to:

- Send a ping to the internal FTP server.
- Transfer data from and to the internal server using FTP.

Alternatively, it is possible to connect the CMU to a second external PC#2 using the Ethernet connection of option R&S CMU-B87, *Interface for CDMA2000 Data Tests*. With this extended test setup, the CMU can be used as an IP interface to the mobile, e.g. to:

- Analyze IP traffic from the mobile at PC#2.
- Open an FTP session between PC#1 and an external FTP server running on PC#2, avoiding the restrictions of the CMU's internal FTP server.
- Configure PC#2 as a web server and test web applications.


Ping

This application requires a point-to-point connection between the CMU and the PC#1 (right-hand side of Figure 8-12). No additional PC # 2 is required. Ping is an application with equal traffic in the forward and the reverse link.

Command Line

- To send a ping to the CMU use the following command line syntax:

```
ping -w 4000 -l 512 192.168.0.5 -t
where:  -w          number of milliseconds to wait for response
        -l          byte length of echo request
        192.168.0.5 example CMU PPP IP address
        -t          if present, continues sending echo packets
```


Example


```

C:\WINNT\System32\cmd.exe
C:\>ping -w 4000 -l 512 192.168.0.5
Ping wird ausgeführt für 192.168.0.5 mit 512 Bytes Daten:
Antwort von 192.168.0.5: Bytes=512 Zeit=551ms TTL=64
Antwort von 192.168.0.5: Bytes=512 Zeit=550ms TTL=64
Antwort von 192.168.0.5: Bytes=512 Zeit=551ms TTL=64
Antwort von 192.168.0.5: Bytes=512 Zeit=530ms TTL=64
Ping-Statistik für 192.168.0.5:
    Pakete: Gesendet = 4, Empfangen = 4, Verloren = 0 (0% Verlust),
    Ca. Zeitangaben in Millisek.:
        Minimum = 530ms, Maximum = 551ms, Mittelwert = 545ms
C:\>

```

Internal FTP Server

This application requires a point-to-point connection between the CMU and the PC#1 (right-hand side of Figure 8-12). No additional PC # 2 is required. The connection allows to directly test the upload and download speed, e.g. at different asymmetrical data rates in the forward and reverse link.

FTP Server Characteristics

The internal FTP server of the CMU has a size of 250 kbyte and can be addressed using the *BS PPP IP Address* set in the *Service Cfg.* tab. The server contains three standard test files of different size (2 kbyte, 20 kbyte and 200 kbyte). The server is cleared and the test files are re-loaded during each startup procedure of the CMU.

Command Line

Anonymous FTP access to the internal server is allowed using the username 'ftp' with password 'ftp'.

- To connect to the server use the following command line syntax:

```

ftp://ftp.192.168.0.5
user:      ftp
password:  ftp

```

- Use the following commands:

```

dir          show files
hash        displays progress
get bin200k  download a file
quit        close the FTP session

```

Example

```

C:\>ftp 192.168.0.5
Verbindung mit 192.168.0.5 wurde hergestellt.
220 CMU200/B-83 FTP server (ver 5.4.2) ready.
Benutzer (192.168.0.5:(none)): ftp
331 Guest login ok, send your complete e-mail address as password.
Kennwort:
230 Guest login ok, upload directory is .
ftp> bin
200 Type set to I, binary mode
ftp> hash
Hashmarkierungsdruck EIN FTP: <2048 Bytes/Hash>.
ftp> dir
200 Port set okay
150 Opening ASCII mode data connection
-rwx--a-- 1 user group 2048 Jan 1 1980 BIN2K
-rwx--a-- 1 user group 20480 Jan 1 1980 BIN20K
-rwx--a-- 1 user group 204800 Jan 1 1980 BIN200K
226 Transfer complete
FTP: 183 Bytes empfangen in 0,03Sekunden 6,10KB/s
ftp> get bin200k
200 Port set okay
150 Opening BINARY mode data connection
#####
226 Transfer complete
FTP: 204800 Bytes empfangen in 19,28Sekunden 10,62KB/s
ftp> del bin200k
200 File deleted successfully.
ftp> put FSU_24.pdf
200 Port set okay
150 Opening BINARY mode data connection
#####
226 Transfer complete
FTP: 53532 Bytes gesendet in 0,00Sekunden 53532000,00KB/s
ftp>

```

Data Traffic

The data traffic to and from the CMU can be observed in the *Code Domain Power* menu:

- When a file is transferred from the PC#1 to the internal FTP server (FTP upload), the bar graphs in the *Code Domain Power* show active reverse traffic channels (FCH and SCHs, if the latter are enabled).
- When a file is transferred from the internal FTP server to the PC#1 (FTP download), the bar graphs in the *Code Domain Power* show temporary activity in the reverse traffic channels, which is due to the exchange of signalling messages. The forward channels are not visualized in the *Code Domain Power* menu.

IP Connection with external PC

With an additional second PC#2 (left-hand side of Figure 8-12) connected through the Ethernet connection of option R&S CMU-B87, *Interface for CDMA2000 Data Tests*, the CMU can be used as an IP interface to the mobile. Assuming that the Ethernet PC address of PC#2 is 192.168.0.3, the CMU Ethernet IP address is 192.168.0.2, and the mobile's PPP IP address is 192.168.0.1, enter the following commands on the PC #2:

```

route delete 192.168.0.0
route add 192.168.0.0 mask 255.255.0.0 192.168.0.2

```

The two PCs PC#1 and PC#2 should now be able to see each other and use network services and applications such as Ping, FTP, and HTTP.

E.g., with an FTP server running on PC#2, it is possible to open an FTP session from PC#1 using the command line:

```
ftp://ftp.192.168.0.3
```

Remote Control Commands

The following sections describe the remote control commands which are related to the packet data test features described in this chapter. Many of the commands are only available with option R&S CMU-K87; for an overview refer to Table 8-2 on p. 8.8.



The TCP/IP addressing commands belong to the R&S CMU200 base system (SYSTEM:TCPip:SECondary...). They are described in the R&S CMU200/300 operating manual.

Configuration of the Service Option 33

The commands in this section configure the CMU and the mobile for end-to-end data testing using service option SO33. Most of the commands require option R&S CMU-K87, *CDMA2000 Data Testing* (see Table 8-2 on p. 8.8).

CONFigure:SCONfig:SClass1:PDAT:S33D:MIP:SAMode[?]				MIP Stand Alone Mode	
<Enable>					
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.	
ON OFF	MIP stand alone mode MIP gateway mode	ON	–	V3.60	
Description of command					Sig. State
This command selects the MIP mode that the CMU is configured for.					All ¹

CONFigure:SCONfig:SClass1:PDAT:S33D:MIP:MHIP				Mobile Node Home IP Address	
<Addr_1>, <Addr_2>, <Addr_3>, <Addr_4>					
Address parts	Ranges of values	Def. value	Def. unit	FW vers.	
<Addr_1>, <Addr_2>, <Addr_3>, <Addr_4>	0 to 255 0 to 255 0 to 255 0 to 255	10 10 10 10	– – – –	V3.60	
Description of command					Sig. State
This command defines the IP address of the mobile in its home network.					All ¹

CONFigure:SCONfig:SClass1:PDAT:S33D:MIP:FAIP				Foreign Agent Home IP Address	
<Addr_1>, <Addr_2>, <Addr_3>, <Addr_4>					
Address parts	Ranges of values	Def. value	Def. unit	FW vers.	
<Addr_1>, <Addr_2>, <Addr_3>, <Addr_4>	0 to 255 0 to 255 0 to 255 0 to 255	NAN NAN NAN NAN	– – – –	V3.60	
Description of command					Sig. State
This command defines the IP address of the of the Foreign Agent. The command is only available in MIP gateway mode (CONFigure:SCONfig:SClass1:PDAT :S33D:MIP:SAMode OFF).					All ¹

¹ This command cannot be used while a packet data connection is active (CONFigure:SCONfig:SClass1:SERVICE PDAT).

CONFigure:SCONfig:SClass1:PDAT:S33D:MIP:HASecret				Foreign Agent Home IP Address
<Secret>				
<Secret>	Description of parameters	Def. value	Def. unit	FW vers.
'<max 16 characters>'	0 to 255	'cmu'	–	V3.60
Description of command				Sig. State
This command defines the secret used by the R&S CMU to do Mobile IP MD5 authentication in MIP stand alone mode.				All ²

CONFigure:SCONfig:SClass1:PDAT:S33DS33D:MIP:HAIP?				MS Node Home Agent IP Address
<Addr_1>, <Addr_2>, <Addr_3>, <Addr_4>				
Address parts	Ranges of values	Def. value	Def. unit	FW vers.
<Addr_1>,	0 to 255	NAN	–	V3.60
<Addr_2>,	0 to 255	NAN	–	
<Addr_3>,	0 to 255	NAN	–	
<Addr_4>	0 to 255	NAN	–	
Description of command				Sig. State
This commands queries the IP address of the Home Agent. This address is programmed in the mobile and used for registration and tunneling purposes. It is captured and displayed when a mobile IP call is made.				All

CONFigure:SCONfig:SClass1:PDAT:S33DS33D:MIP:COAddress?				Care of Address
<Addr_1>, <Addr_2>, <Addr_3>, <Addr_4>				
Address parts	Ranges of values	Def. value	Def. unit	FW vers.
<Addr_1>,	0 to 255	NAN	–	V3.60
<Addr_2>,	0 to 255	NAN	–	
<Addr_3>,	0 to 255	NAN	–	
<Addr_4>	0 to 255	NAN	–	
Description of command				Sig. State
This commands queries the IP address that the Foreign Agent uses to decapsulate packets which have been tunneled by the home agent and to deliver them to the mobile node. The address is captured and displayed when a mobile IP call is made.				All

CONFigure:SCONfig:SClass1:PDAT:S33D:MIP:AADV[?]				MIP Agent Advertisements
<Enable>				
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	Enable or disable advertisements	ON	–	V3.60
Description of command				Sig. State
This command enables or disables the R&S CMU to broadcast MIP Agent Advertisements to advertise its presence on the network. The command is only available in MIP stand alone mode (CONFigure:SCONfig:SClass1:PDAT :S33D:MIP:SAMode OFF).				All

²This command cannot be used while a packet data connection is active (CONFigure:SCONfig:SClass1:SERVICE PDAT) and while the CMU is configured for MIP gateway mode (CONFigure:SCONfig:SClass1:PDAT:S33D:MIP:SAMode OFF).

CONFigure:SCONfig:SClass1:PDAT:S33D:MIP:RRCode[?]				Registration Reply Code	
<Code No>					
<Code No>	Description of parameters	Def. value	Def. unit	FW vers.	
0	Registration accepted	0	–	V3.60	
1	Registration accepted, no simultaneous bindings				
64	Reason unspecified				
65	Administratively prohibited				
66	Insufficient resources				
67	MS node failed authentication				
68	Home agent failed authentication				
69	Requested lifetime too long				
70	Poorly formed request				
71	Poorly formed reply				
72	Requested encapsulation unavailable				
73	Van Jacobson compression unavailable				
80	Home network unreachable (ICMP error)				
81	Home agent host unreachable (ICMP error)				
82	Home agent port unreachable (ICMP error)				
88	Home agent unreachable (ICMP error)				
128	Reason unspecified				
129	Administratively prohibited				
130	Insufficient resources				
131	MS node failed authentication				
132	Foreign agent failed authentication				
133	Reg. identification mismatch				
134	Poorly formed request				
135	Too many simultaneous mobility bindings				
136	Unknown home agent address				
Description of command				Sig. State	
This command defines a code number sent to the mobile in the CAUSE_CODE field of the <i>Registration Reply</i> message. Any number different from the values listed above will be auto-corrected. The command is only available in MIP stand alone mode (CONFigure:SCONfig:SClass1:PDAT:S33D:MIP:SAMode OFF).				All	

CONFigure:SCONfig:SClass1:PDAT:S33D:MIP:RRLTime[?]				Registration Reply Lifetime	
<Time>					
<Time>	Description of parameters	Def. value	Def. unit	FW vers.	
0 s to 65535 s	Time remaining before the mobile has to re-register	600	s	V3.60	
Description of command				Sig. State	
This command defines the number of seconds remaining before the registration is considered expired. The command is only available in MIP stand alone mode (CONFigure:SCONfig:SClass1:PDAT:S33D:MIP:SAMode OFF). A value of 0 s means that the mobile has to de-register; a value of 65535 s means infinity.				All	

CONFigure:SCONfig:SClass1:PDAT:S33D:MIP:AUTHentic:TYPE[?]				MIP Authentication Type	
<Type>					
<Type>	Description of parameters	Def. value	Def. unit	FW vers.	
R02 R02B	Authentication according to RFC 2002 or RFC 2002bis	R02	–	V3.80	
Description of command				Sig. State	
This command selects the authentication protocol for Mobile IP connections. The command is only available in MIP stand alone mode (CONFigure:SCONfig:SClass1:PDAT:S33D:MIP:SAMode OFF).				All	

CONFigure:SCONfig:SClass1:PDAT:S33D:REVerse[:STATic]:IPADdress				PPP IP Addresses, Static
CONFigure:SCONfig:SClass1:PDAT:S33D:FORWard[:STATic]:IPADdress				
<Addr_1>, <Addr_2>, <Addr_3>, <Addr_4>				
Address parts	Ranges of values	Def. value	Def. unit	FW vers.
<Addr_1>,	0 to 255	192	–	V3.20
<Addr_2>,	0 to 255	168	–	
<Addr_3>,	0 to 255	1	–	
<Addr_4>	0 to 255	1 (for reverse address) 2 (for forward address)	–	
Description of command				Sig. State
These commands define the static PPP IP addresses of the MS (:REVerse) and the BS/CMU (:FORWard). The addresses are used if the CMU is configured for static IP addressing (CONFigure:IPADdress:MODE STATic)				All

CONFigure:SCONfig:SClass1:PDAT:S33D:REVerse:DYNAmic:IPADdress?				PPP IP Addresses, Dynamic
CONFigure:SCONfig:SClass1:PDAT:S33D:FORWard:DYNAmic:IPADdress?				
<Addr_1>, <Addr_2>, <Addr_3>, <Addr_4>				
Address parts	Ranges of values	Def. value	Def. unit	FW vers.
<Addr_1>,	0 to 255	NAN	–	V3.60
<Addr_2>,	0 to 255	NAN	–	
<Addr_3>,	0 to 255	NAN	–	
<Addr_4>	0 to 255	NAN	–	
Description of command				Sig. State
These commands query the dynamically allocated PPP IP addresses of the MS (:REVerse) and the BS/CMU (:FORWard). The addresses are available if the CMU is configured for dynamic IP addressing using DHCP (CONFigure:IPADdress:MODE DYNAmic)				All

CONFigure:SCONfig:SClass1:PDAT:S33D:AUTHentic:TYPE[?]				PPP Authentication Type
<Type>				
<Type>	Description of parameters	Def. value	Def. unit	FW vers.
NONE CHAP PAP	Authentication disabled PPP authentication using the CHAP or PAP protocol	NONE	–	V3.60
Description of command				Sig. State
This command selects the authentication protocol for Simple IP connections. Authentication must be disabled for Mobile IP connections.				All ¹

CONFigure:SCONfig:SClass1:PDAT:S33D:AUTHentic:UNAMe[?]				Username (PPP authentication)
<Name>				
<Name>	Description of parameters	Def. value	Def. unit	FW vers.
'<max. 72 characters>'	Username	'*'	–	V3.60
Description of command				Sig. State
This command selects the username for CHAP or PAP authentication (CONFigure:SCONfig:SClass1:PDAT:S33D:AUTHentic:TYPE).				All ¹

CONFigure:SCONfig:SClass1:PDAT:S33D:AUTHentic:PWORd[?]		Password (PPP authentication)		
<Password>				
<Password>	Description of parameters	Def. value	Def. unit	FW vers.
'<max. 72 characters>'	Password	**	–	V3.60
Description of command				Sig. State
This command selects the password for CHAP or PAP authentication (CONFigure:SCONfig :SClass1:PDAT:S33D:AUTHentic:TYPE).				All ¹

CONFigure:SCONfig:SClass1:PDAT:S33D:AUTHentic:CINterval[?]		CHAP Interval (PPP authentication)		
<Time>				
<Time>	Description of parameters	Def. value	Def. unit	FW vers.
30 s to 600 s	CHAP Interval	30	s	V3.60
Description of command				Sig. State
This command defines the time interval for CHAP authentication (CONFigure:SCONfig :SClass1:PDAT:S33D:AUTHentic:TYPE). The interval defines how often the mobile is de-authenticated with the system.				All ¹

CONFigure:SCONfig:SClass1:PDAT:S33D:IAControl:NIATimer[?]		Network PPP Inactivity Timer		
<Time>				
<Time>	Description of parameters	Def. value	Def. unit	FW vers.
5 s to 60 s OFF	Network PPP inactivity timer No timer used, MS remains in the PPP Connected state	OFF	s	V3.60
Description of command				Sig. State
This command defines the time interval after which the CMU will transition the MS from PPP Connected to PPP Dormant state if there is no data being sent to the MS.				All ^{Error!} Bookmark not defined.

CONFigure:SCONfig:SClass1:PDAT:S33D:IAControl:MSDControl[?]		MS Dormant Control		
<Enable>				
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	Enable or disable MS dormant control	OFF	s	V3.60
Description of command				Sig. State
This command enables or disables packet data dormant timer control of the MS. The setting takes effect only after a <i>Service Option Control Message</i> is transferred to the MS (CONFigure:SCONfig :SClass<nr>:PDAT:S33D:IAControl:SOCSMessage).				All

CONFigure:SCONfig:SClass1:PDAT:S33D:IAControl:MSDTimer[?]		MS Dormant Timer		
<Time>				
<Time>	Description of parameters	Def. value	Def. unit	FW vers.
0.0 s to 25.5 s	MS dormant timer	0	s	V3.60
Description of command				Sig. State
This command defines the time that the MS, after receiving data in the PPP Dormant state, will wait before returning to PPP Connected. The time is not used if MS dormant control is disabled (CONFigure:SCONfig:SClass1:PDAT:S33D:IAControl:MSDControl OFF). Moreover the setting takes effect only after a <i>Service Option Control Message</i> is transferred to the MS (CONFigure:SCONfig:SClass<nr>:PDAT:S33D:IAControl :SOCSMessage).				All

INITiate:SCONfig:SClass1:PDAT:S33D:IAControl:SOCMessage[?]		Service Option Ctrl. Message		
Description of command		Sig. State	FW vers.	
This command sends a <i>Service Option Control Message</i> to the MS in order to configure its <i>MS Dormant Timer</i> and <i>MS Dormant Control</i> parameters (CONFigure:SCONfig:SClass1:PDAT:S33D:IAControl:MSDTimer, CONFigure:SCONfig:SClass1:PDAT:S33D:IAControl:MSDControl).		PCON	V3.60	

[SENSe:]SCONfig:SClass1:PDAT:S33D:IAControl:SOCMessage:STATE? <State>		SO Ctrl. Message State		
<State>	Description of parameters	Def. value	Def. unit	FW vers.
0	No SO Control Message being sent	–	–	V3.60
1	Transfer in progress (being sent but not acknowledged yet)			
Description of command				Sig. State
This command is always a query and returns the status of the <i>Service Option Control Message</i> transfer from the CMU to the MS (CONFigure:SCONfig:SClass<nr>:PDAT:S33D:IAControl :SOCMessage).				All

CONFigure:SCONfig:SClass1:PDAT:S33D:PZONE:ID[?] <ID>		Packet Zone ID		
<ID>	Description of parameters	Def. value	Def. unit	FW vers.
0 to 255	Packet zone ID	0	–	V3.60
Description of command				Sig. State
This command selects a packet data services zone identifier to be transferred to the MS.				PDOR

CONFigure:SCONfig:SClass1:PDAT:S33D:PZONE:TPDSn[?] <Mode>		Target PDSN		
<Mode>	Description of parameters	Def. value	Def. unit	FW vers.
CHANGed UCHanged	PDSN changed along with the packet zone ID PDSN unchanged	UCH	–	V3.60
Description of command				Sig. State
This command qualifies whether the Packet Data Service Node (PDSN) is changed along with the Packet Zone ID, or whether it remains unchanged.				All

CONFigure:SCONfig:SClass1:PDAT:S33D:PZONE:CCTRI[?] <Value>		Packet Zone Connect. Control		
<Value>	Description of parameters	Def. value	Def. unit	FW vers.
0	Disable packet zone connection control	0	–	V3.60
1	Enable packet zone connection control			
2	Clear the packet zone identifier list			
3	Transfer the packet zone identifier list to the base station			
Description of command				Sig. State
This command defines the value of the PKT_CON_CNTL parameter defined in the standard.				All

CONFigure:SCONfig:SClass1:PDAT:S33D:PZONE:LLENgth[?] <Value>		Packet Zone List Length		
<Value>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 15	Max. number of packet zone IDs in the MS's list	1	–	V3.60
Description of command				Sig. State
This command defines the value of the PKT_ZONE_LIST_LEN parameter defined in the standard.				All

INITiate:SCONfig:SClass1:PDAT:S33D:PZONE:SOCMessage[?]		Service Option Ctrl. Message	
Description of command	Sig. State	FW vers.	
This command sends a <i>Service Option Control Message</i> to the MS in order to configure its <i>Packet Zone Connect. Control</i> and <i>Packet Zone List Length</i> parameters (CONFigure:SCONfig:SClass1:PDAT:S33D:PZONE:CCTRL, CONFigure:SCONfig:SClass1:PDAT:S33D:PZONE:LLENgth).	PCON	V3.60	

[SENSe:]SCONfig:SClass1:PDAT:S33D:PZONE:SOCMessage:STATE? <State>		SO Ctrl. Message State		
<State>	Description of parameters	Def. value	Def. unit	FW vers.
0	No SO Control Message being sent	–	–	V3.60
1	Transfer in progress (being sent but not acknowledged yet)			
Description of command				Sig. State
This command is always a query and returns the status of the <i>Service Option Control Message</i> transfer from the CMU to the MS (CONFigure:SCONfig:SClass<nr>:PDAT:S33D:PZONE:SOCCMessage).				All

RLPStatistic (RLP Frame & IP Statistics)

The subsystem *RLPStatistic* measures the data flow on the CMU. It corresponds to the *RLP / IP Statistics* measurement. All commands require option R&S CMU-K87, *CDMA2000 Data Testing*.

INITiate:RLPStatistic	Start new measurement	⇒	RUN
ABORT:RLPStatistic	Abort running measurement and switch off	⇒	OFF
STOP:RLPStatistic	Stop measurement after current stat. cycle	⇒	STOP
CONTinue:RLPStatistic	Next measurement step (<i>stepping mode</i>)	⇒	RUN
Description of command		Sig. State	FW vers.
These commands have no query form. They start or stop the measurement, setting it to the status given in the top right column. The measurement always runs in continuous mode.		PCON	V3.60

CONFigure:RLPStatistic:CONTrol:RINTerval[?]				Refresh Interval	
<Time>					
<Time>	Description of parameters	Def. value	Def. unit	FW vers.	
1 s to 100 s	Refresh interval	1	s	V3.60	
Description of command				Sig. State	
This command defines the time after which all results of the <i>RLPStatistic</i> measurement are updated.				all	

FETCh:RLPStatistic:STATus?				
<Measurement Status>, <Stat. Results>				
<Measurement Status>	Description of parameters	Def. value	Def. unit	
OFF RUN STOP ERR	Measurement in the <i>OFF</i> state (*RST or ABORT) Running (after <i>INITiate</i> , <i>CONTinue</i> or <i>READ</i>) Stopped (<i>STOP</i>) <i>OFF</i> (could not be started)	OFF	–	
<Stat. Results>	Description of parameters	Def. value	Def. unit	FW vers.
<Value>, <Value>, <Value>, <Value>	Rx: PPP Total Bytes Rx: Data Rate Tx: PPP Total Bytes Tx: Data Rate	NAN, NAN, NAN, NAN	– – – –	V3.60
Description of command				Sig. State
This command is always a query. It returns the status of the measurement (see Chapters 3 and 5) and the statistical results.				PCON

PING (RLP Frame & IP Statistics)

The subsystem *PING* controls the *Ping* measurement. All commands require option R&S CMU-K87, *CDMA2000 Data Testing*.

INITiate:PING	Start new measurement	⇒	RUN
ABORT:PING	Abort running measurement and switch off	⇒	OFF
STOP:PING	Stop measurement after current stat. cycle	⇒	STOP
CONTinue:PING	Next measurement step (<i>stepping mode</i>)	⇒	RUN
Description of command		Sig. State	FW vers.
These commands have no query form. They start or stop the measurement, setting it to the status given in the top right column.		PDOR, PCON	V3.60

CONFigure:PING:EREPorting[?]		Event Reporting		
<Report Mode>				
<Report Mode>	Description of parameters	Def. value	Def. unit	FW vers.
SRQ	Service request	OFF	–	V3.60
SOPC	Single operation complete			
SRSQ	SRQ and SOPC			
OFF	No reporting			
Description of command				Sig. State
This command defines the events generated when the measurement is terminated or stopped (<i>event reporting</i> , see Chapter 5).				all

FETCH[:SCALar]:PING:STATus?				
<Stat. Results>				
<Stat. Results>	Description of parameters	Def. value	Def. unit	
OFF	Measurement in the OFF state (*RST or ABORT)	OFF	–	
RUN	Running (after INITiate, CONTinue or READ)			
STOP	Stopped (STOP)			
ERR	OFF (could not be started)			
STEP	Stepping mode (<stepmode>=STEP)			
RDY	Stopped according to repetition mode and stop condition			
1 to 10000	Counter for current statistics cycle	NONE	–	
NONE	No counting mode set			
1 to 1000	Counter for current ping within a cycle	NONE	–	
NONE	Statistic count set to off			
Description of command				Sig. State
This command is always a query. It returns the status of the measurement (see Chapters 3 and 5) and the statistical results. A statistics cycle comprises the number of pings defined by means of CONFigure:PING:CONTrol:PCount.				all

Subsystem PING:CONTRol

The subsystem *PING:CONTRol* provides specific settings for the *PING* measurement. These settings are provided in the *Control* tab of the popup menu *Ping Configuration*.

DEFault:PING:CONTRol[?]				Use MS IP Address
<Enable>				
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	The parameters are set to their default values The parameters differ from the default values (partially or totally)	ON	–	V3.60
Description of command				Sig. State
If used as a setting command with the parameter <i>ON</i> , this command sets all parameters of the subsystems to their default values (the setting <i>OFF</i> results in an error message).				all
If used as a query the command returns whether all parameters are set to their default values (<i>ON</i>) or not (<i>OFF</i>).				

CONFigure:PING:CONTRol:REPetition[?]				Test Cycles
<Repetition>, <Stop Cond>, <Step Mode>				
<Repetition>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 10000 CONTInuous SINGleshot DEFault,	Multiple measurement (counting, until Status = STEP RDY) Continuous measurement (until STOP or ABORT) Single shot measurement (until Status = RDY) Default value	SING	–	V3.60
<Stop Cond>	Description of parameters	Def. value	Def. unit	FW vers.
NONE,	Continue measurement even in case of error	NONE	–	V3.60
<Step Mode>	Description of parameters	Def. value	Def. unit	FW vers.
NONE	Continue measurement according to its rep. mode	NONE	–	V3.60
Description of command				Sig. State
This command determines the repetition mode for the ping measurement. Stop condition, and stepping mode are not used and must be set to NONE.				all
Note: <i>In the case of READ commands (READ:...), the <Repetition> parameter has no effect; the measurement is always stopped after a single shot.</i>				

CONFigure:PING:CONTRol:PCOunt[?]				Ping Count
<Pings>				
<Pings>	Description of parameters	Def. value	Def. unit	FW vers.
1 to 255	Ping count	5	–	V3.60
Description of command				Sig. State
This command defines the number of pings in a statistics cycle.				all

CONFigure:PING:CONTRol:RINTerval[?]				Repeat Interval
<Time>				
<Time>	Description of parameters	Def. value	Def. unit	FW vers.
1 s to 100 s	Repeat interval	1	s	V3.60
Description of command				Sig. State
This command defines the time between two consecutive echo requests.				all

CONFigure:PING:CONTRol:TOUT[?]				Timeout
<Time>				
<Time>	Description of parameters	Def. value	Def. unit	FW vers.
0.001 s to 10 s	Ping timeout	0.5	s	V3.60
Description of command				Sig. State
This command defines the timeout to wait for each reply.				all

CONFigure:PING:CONTRol:PSIZe[?]				Packet Size
<Bytes>				
<Bytes>	Description of parameters	Def. value	Def. unit	FW vers.
1 byte to 1520 bytes	Packet size	32	bytes	V3.60
Description of command				Sig. State
This command defines the number of bytes in the send buffer.				all

CONFigure:PING:CONTRol:MSIP[?]				Use MS IP Address
<Enable>				
<Enable>	Description of parameters	Def. value	Def. unit	FW vers.
ON OFF	Use MS IP Address Use address def. via <code>CONFigure:PING:CONTRol:IPADdress</code>	ON	–	V3.60
Description of command				Sig. State
This command qualifies whether the pings are sent to the MS IP address used for establishing the MIP/PPP connection or to a different address reserved for pings.				all

CONFigure:PING:CONTRol:IPADdress[?]				IP Address, Ping
<Addr_1>, <Addr_2>, <Addr_3>, <Addr_4>				
Address parts	Ranges of values	Def. value	Def. unit	FW vers.
<Addr_1>, <Addr_2>, <Addr_3>, <Addr_4>	0 to 255 0 to 255 0 to 255 0 to 255	0 0 0 0	– – – –	V3.60
Description of command				Sig. State
This command defines the IP address used for the ping measurement if <code>CONFigure:PING:CONTRol:MSIP OFF</code> is set.				all

Measured Values

The following commands return the results of the PING measurement.

		Ping Results:		
READ[:SCALAr]:PING?		Start single shot measurement and return results		
FETCh[:SCALAr]:PING?		Read out measurement results (unsynchronized)		
SAMPle[:SCALAr]:PING?		Read out measurement results (synchronized)		
<Results>	Description of parameters	Def. value	Def. unit	FW vers.
'0.0.0.0' to '255.255.255.255',	IP address 1 (16-character string)	NAN	—	V3.60
1 byte to 1520 bytes,	Packet size 1	NAN	—	
0.0 s to 10.0 s NHOS TOUT ILNK,	Ping time; time to wait for the reply 1	NAN	—	
...	
0.0 s to 10.0 s NHOS TOUT ILNK	Time to wait for the reply 5	NAN	—	
Description of command				Sig. State
These commands are always queries. They start the ping measurement (READ...) and return the results. If a ping count (CONFigure:PING:CONTRol:PCOunt) larger than 5 is set, the last 5 results in the statistics cycle are returned. If the ping timeout (CONFigure:PING:CONTRol:TOUT) is exceeded, one of the following error conditions is returned instead of the ping time:				PDOR, PCON
NHOS	No host			
NLK	Inactive link			
TOUT	Timeout			

9 Error Codes

Table 9-1 lists the error codes and associated messages that may occur when you are using the remote control commands.

Table 9-1 Error Codes

Error Code	Message
0	No error
-100	Command error
-101	Invalid character
-102	Syntax error
-103	Invalid separator
-104	Data type error
-105	GET not allowed
-108	Parameter not allowed
-109	Missing parameter
-111	Header separator error
-112	Program mnemonic too long
-113	Undefined header
-113	Undefined header
-114	Header suffix out of range
-120	Numeric data error
-121	Invalid character in number
-123	Exponent too large
-124	Too many digits
-128	Numeric data not allowed
-131	Invalid suffix
-134	Suffix too long
-138	Suffix not allowed
-141	Invalid character data
-144	Character data too long
-148	Character data not allowed
-151	Invalid string data
-158	String data not allowed
-161	Invalid block data
-168	Block data not allowed
-171	Invalid expression
-178	Expression data not allowed
-180	Macro error
-200	Execution error

-211	Trigger ignored
-221	Setting conflict
-222	Data out of range
-223	Too much data
-224	Illegal parameter value
-230	Data corrupt or stale
-240	Hardware error
-241	Hardware missing
-250	Mass storage error
-251	Missing mass storage
-252	Missing media
-253	Corrupt media
-254	Media full
-255	Directory full
-256	File name not found
-257	File name error
-258	Media protected
-300	Device-specific error
-310	System error
-311	Memory error
-313	Calibration memory lost
-314	Save/recall memory lost
-315	Configuration memory lost
-330	Self test failed
-350	Queue overflow
-360	Communication error
-361	Parity error in program message
-362	Framing error in program message
-363	Input buffer overrun
-400	Query error
-410	Query INTERRUPTED
-420	Query UNTERMINATED
-430	Query DEADLOCKED
-440	Query UNTERMINATED after indefinite response

Index

1

1st Service Class 4.45, 6.139

A

A Limit (Rise Time)..... 4.74, 6.250
 Accept MS Originated Call 4.127, 6.139
 Accept no Call..... 4.127
 Access probe power..... 4.46
 Access probes 4.160, 6.198
 Initial offset..... 6.198
 Mode..... 6.198
 Nominal offset 6.198
 Power increment 6.199
 Probes per sequence 6.199
 Sequences 6.199
 Acknowledgement (SMS)..... 4.143, 6.137, 6.173
 ACP 4.91, 6.80
 ACP 1..4 Limit 4.96
 ACP Frequency Offset 4.95
 ACP Spectrum 6.80
 Remote Control..... 6.80
 ACP Spectrum measurement (control)
 Remote control..... 6.82
 Active Set..... 4.155
 Active/Candidate Window 4.155, 6.191
 Add Time Stamp 4.143, 6.173
 Adjacent Channel Power..... See ACP
 AF/RF connectors
 Signalling 4.161
 Alerting..... 4.43
 Analyzer
 Frequency offset 6.3
 Non-Signalling 4.20
 Remote control (NS)..... 6.2, 6.205
 Signalling 4.165
 Analyzer frequency (NS) 4.21
 Analyzer Level
 Non Signalling 4.20
 Signalling 4.166
 Analyzer/Generator 4.2
 Any limit exceeded..... 4.60, 4.119
 Application 3.6
 Analzer/Generator (NS)..... 4.5
 Code domain power 4.98
 Modulation 4.79
 Power..... 4.64
 Power (NS) 4.13
 Receiver quality..... 4.114
 Area 1, ... , Area 4..... 4.28, 4.150
 Attenuation..... 4.29
 frequency-dependent 4.31
 Audio
 hotkey 2.7
 measurements (Non Signalling) 4.18
 Test setup, forward link 4.174
 Test setup, reverse link 4.175
 Audio measurements
 Non Signalling 4.18
 Authentication 4.156
 Authentication (PPP)..... 8.11
 Authentication Challenge 4.157
 Autoranging..... 4.20, 4.166
 Average 4.9, 4.59
 Average values (calculation) 3.7

AWGN..... 6.187
 Base station signal..... 4.148, 6.187
 AWGN Level..... 4.24
 Code Domain Power..... 6.90
 Forward Power Control..... 6.273
 Gated Output Power 6.249
 Min. Power..... 6.44, 6.231, 6.240
 Non Signalling..... 6.13
 Open Loop Time Resp..... 6.259
 Overview 6.209
 Receiver Quality 6.265

B

B Limit (Fall Time) 4.75, 6.250
 B Limit (Reference Time) 4.74, 6.251
 Band classes 6.131
 Bar graph
 Spectrum 4.93
 Base station ID..... 4.156, 6.192
 Base station properties 4.154
 Base station signal 4.147
 AWGN 4.148, 6.187
 Call loss detection time 4.154
 Carrier frequency offset 4.148, 6.187
 CDMA power 4.148
 DUT paging 4.154
 Fundamental channel 4.150
 Fundamental channel frame offset..... 4.152
 Fundamental channel QOF..... 4.152
 Impairments..... 4.148, 6.186
 Indicator bits 4.153
 Injected Tx FER..... 4.149, 6.187
 OCNS 4.148
 Output power 4.148
 Paging channel 4.153
 Paging level..... 4.153
 PICH level..... 4.148
 PN offset..... 4.154
 Quick paging channel 4.153
 Quick paging level 4.153
 RF channel 4.147
 Supplemental channel 4.152
 Supplemental channel level 4.152
 Sync level 4.148
 Bit reverse 4.108
 BS Frequency Offset 4.25
 Code Domain Power..... 6.91
 Forward Power Control..... 6.274
 Gated Output Power 6.249
 Min. Power..... 6.44, 6.231, 6.240
 Non Signalling..... 6.13
 Open Loop Time Resp..... 6.259
 Overview 6.209
 Receiver Quality 6.266
 BS levels
 CDMA power 6.176
 Output power 6.177
 Pilot level..... 6.177
 Sync level..... 6.177
 BS signal 2.13
 Call loss timer..... 4.154, 6.186
 Frame offset 6.180, 6.181, 6.183
 Menu 4.147
 Page Response Timeout 4.154, 6.186
 Paging channel 6.184
 Paging level 6.184, 6.185

- PN offset 6.186
 - Quick paging channel 6.184
 - Remote control 6.175
 - RF channel 6.176
 - RF unit 6.175
 - Traffic channel 6.179
 - BS Signal Level
 - Overview 4.73
 - BS Signal Level (Overview) 4.57
 - BS Signal Settings
 - Overview 4.73
 - BS Signal Settings (Overview) 4.58
 - BSID 6.192
 - Burst power (trace)
 - Peak code domain 6.107
 - Power 6.261
- C**
- C Limit 4.75, 6.251
 - Call established 4.43
 - Call from MS 4.43
 - Call Indicators 4.158, 6.193
 - Call loss detection time 4.154
 - Call loss timer 4.154, 6.186
 - Call setup 2.10
 - Call to MS 4.43
 - Call Waiting Indicator 4.158, 6.194
 - Caller ID 4.158, 6.193
 - Caller ID Presentation Indicator 4.158, 6.194
 - Cancel Prepar. 4.125
 - Candidate Set 4.155
 - Capture Buffer Size 4.15, 6.39
 - Care of Address 8.10, 8.26
 - Carrier feedthrough (NS) 4.7
 - Carrier frequency error (NS) 4.7
 - Carrier frequency offset 4.148, 6.187
 - Cause Code 6.137
 - CDMA Power 6.10
 - BS signal 4.148, 6.176
 - Code Domain Power 6.88
 - Forward Power Control 6.272
 - Gated Output Power 6.247
 - Min. Power 6.42, 6.229, 6.238
 - Open Loop Time Resp. 6.257
 - Overview 6.207
 - Receiver Quality 6.263
 - Channel power 4.103
 - Remote control 6.109
 - Statistic count 6.112, 6.118, 6.124
 - Channel quality
 - Limits 6.223
 - Maximum frames 6.222
 - Repetition 6.222
 - Status 6.221
 - Stepping mode 6.222
 - Stop condition 6.222
 - CHAP Interval (PPP authentication) 8.12, 8.29
 - Circular buffer frames 6.154, 6.157, 6.163
 - Test data 4.136, 4.138
 - Clock 6.203
 - Frequency 6.15, 6.203
 - Clock frequency 6.14
 - Clock state 6.14
 - Closed loop power control 4.149
 - Code domain power 4.100
 - control 4.107, 6.96
 - Measurements 4.97
 - Remote control 6.88, 6.94
 - Code domain power configuration 4.107
 - Code Domain Power measurements
 - Non Signalling 4.18
 - Coding
 - Packet Data 4.138, 4.142, 6.160, 6.165, 6.169, 6.171
 - Command
 - Order 5.10
 - Structure 5.1
 - Tables (description) 5.10
 - Command Set 6.31
 - Commands
 - Alphabetical list, non-signalling 6.284
 - Alphabetical list, signalling 6.298
 - Confidence limit exceeded 4.60, 4.119
 - Configurations 3.3
 - Connected 4.43
 - Connected MUX Options 6.136
 - FCH 6.136
 - Connected Radio Configurations
 - FCH 6.136
 - SCH0 6.137
 - Connected Service Options 6.136
 - Connected state 4.122
 - Connection (Alerting) 4.50
 - Connection (Connected) 4.122
 - Connection (Registered) 4.48
 - Connection (Signal Off) 4.44
 - Connection (Signal On) 4.46
 - Connection control
 - Non Signalling 4.19
 - Remote control (NS) 6.2
 - Remote control (Sig) 6.131
 - Signalling 4.43
 - Connection Control Behavior 4.168
 - remote control 6.206
 - Connection control parameters 3.4
 - Connection Information 4.123, 6.135, 6.137
 - Connectors (RF) 2.3
 - Continuous 5.5
 - Overview 4.58
 - Continuous measurement 4.8
 - Control
 - Overview 4.56
 - Power configuration 4.71
 - Spectrum 4.95
 - Counting 5.5
 - CRC (Cyclic redundancy check) 4.115
 - Current 4.9, 4.59
 - Current values (parameters) 6.132
 - Curve
 - Modulation (Constellation, Vector) 4.84
 - Modulation (I/Q Phase) 4.85
 - Modulation, I/Q Analyzer 6.79
 - Cyclic redundancy check 4.115

D

 - D Limit (absolute) 4.75, 6.251
 - D Limit (relative) 4.75, 6.251
 - Data rate 6.160, 6.161, 6.165, 6.166, 6.169, 6.172
 - SCH 4.145
 - Decoder Cal. 4.132
 - Default
 - Modulation configuration 4.89
 - Receiver quality configuration 4.118
 - Default Settings 4.8, 4.15
 - Default values (parameters) 6.132
 - Delta marker 4.170
 - Destination (handoff) 6.188
 - Destination Parameter 4.125
 - Destination Selection 4.124
 - DHCP 8.3
 - Dialed Number 6.135

Disconnect UE 4.50
 Display Area..... 4.65
 Display Limit Ref. Lines..... 4.74
 Display mode 3.7
 Modulation (NS) 4.9
 Overview 4.59
 D-Line 4.171
 Signalling 4.65, 4.80, 4.99
 DUT paging..... 4.154

E

E Limit (Gated On)..... 4.75, 6.252
 E Limit (Reference Time) 4.75, 6.252
 Eb/Nt calculation 4.151
 Echo 4.132
 Echo Delay 4.132, 6.151
 Enable software 1.7
 Encoder Cal 4.132
 Environment..... 4.168
 Environment Enable..... 6.206
 Forward Power Control 6.272
 Gated Output Power..... 6.247
 Open Loop Time Resp. 6.257
 Overview..... 4.57, 4.72
 Power..... 6.42, 6.88, 6.207, 6.228, 6.237, 6.263
 Error codes 9.1
 ESN
 Non Signalling 4.26, 6.9
 Ext. att. input..... 4.30, 6.14, 6.202
 Ext. att. output..... 4.29, 6.14, 6.202
 Extended event register 5.7, 6.35
 External attenuation 4.29
 frequency-dependent 4.31
 Remote control..... 6.201
 Remote control (NS)..... 6.13
 External trigger..... 4.36

F

Failure Code (dynamic IP addr.)..... 8.4
 FCH 4.150
 FCH & SCH configuration
 Packet Data 4.140
 Test data 4.135
 FCH Config. (SMS) 4.144, 6.174
 FCH configuration
 Loopback 4.129
 Speech..... 4.131
 FCH Eb/Nt 4.151
 FCH level 4.151, 6.10
 FER
 Forward power control..... 4.117
 Remote control..... 6.262
 F-FCH Eb/Nt
 BS Signal 6.180
 Code Domain Power 6.89
 Gated Output Power..... 6.248
 Min. Power..... 6.43, 6.230, 6.239
 Open Loop Time Resp. 6.258
 Overview..... 6.208
 Receiver Quality 6.264
 F-FCH Frame Offset (NS) 4.25
 F-FCH Frame Rate (NS) 4.25
 F-FCH Level
 Code Domain Power 6.89
 Forward Power Control 6.273
 Gated Output Power..... 6.247
 Min. Power..... 6.42, 6.229, 6.238
 Non Signalling 4.23
 Open Loop Time Resp. 6.257

Overview 6.208
 Receiver Quality 6.264
 F-FCH QOF (NS)..... 4.25
 Foreign Agent Home IP Addr. 8.9, 8.25, 8.26
 Forward power control..... 4.116
 Delay 4.119
 Modes..... 4.119, 6.277
 Target FER..... 6.278, 6.280
 FPC..... 4.116
 Delay 4.119
 Modes..... 4.119
 Setpoints 4.120
 Target FER..... 4.120
 F-PICH Level
 Code Domain Power 6.89
 Forward Power Control 6.272
 Gated Output Power 6.247
 Min. Power..... 6.42, 6.229, 6.238
 Open Loop Time Resp. 6.257
 Overview 6.207
 Receiver Quality 6.263
 Frame error rate..... 4.116
 Maximum 6.223
 Frame limit exceeded 4.60, 4.119
 Frame offset 4.25, 6.8
 BS signal 6.180, 6.181, 6.183
 Frame rate 4.25, 6.8, 6.143, 6.144
 Code Domain Power 6.90
 Forward Power Control 6.273
 Gated Output Power 6.249
 Loopback..... 4.129
 Min. Power..... 6.44, 6.231, 6.240
 Open Loop Time Resp. 6.259
 Overview 6.209
 Receiver Quality 6.265
 Frame Type
 Packet Data 4.137, 4.142
 SCH0..... 6.159
 SCH1 6.160
 SO32, SCH0..... 6.164
 SO32, SCH1 6.165
 SO33, SCH1 6.168, 6.171
 Free run trigger..... 4.36
 Frequency offset..... 6.213
 Analyzer..... 6.3
 Frequency unit..... 6.2, 6.7
 Frequency-dependent external attenuation..... 4.31
 F-SCH0 Eb/Nt
 BS Signal..... 6.182
 Code Domain Power 6.90
 Gated Output Power 6.248
 Min. Power..... 6.43, 6.230, 6.239
 Open Loop Time Resp. 6.258
 Overview 6.208
 Receiver Quality 6.265
 F-SCH0 Level
 Code Domain Power 6.89
 Forward Power Control 6.273
 Gated Output Power 6.248
 Min. Power..... 6.43, 6.229, 6.238
 Open Loop Time Resp. 6.258
 Overview 6.208
 Receiver Quality 6.264
 F-SCH1 Eb/Nt
 BS Signal..... 6.183
 Code Domain Power 6.90
 Gated Output Power 6.248
 Min. Power..... 6.44, 6.230, 6.239
 Open Loop Time Resp. 6.259
 Overview 6.209
 Receiver Quality 6.265
 F-SCH1 Level

Code Domain Power	6.89
Forward Power Control	6.273
Gated Output Power.....	6.248
Min. Power.....	6.43, 6.230, 6.239
Open Loop Time Resp.	6.258
Overview.....	6.208
Receiver Quality.....	6.264
Function group.....	5.1
Fundamental channel.....	4.150
Fundamental channel (NS).....	4.25

G

Gain	4.29
Gated Output	4.64, 4.70
Gateway	
static	8.4
Generator.....	4.22
Non-Signalling.....	4.21
Remote control (NS).....	6.6
Generator frequency (NS)	4.25
Generator level (NS)	4.22
Getting started	2.1
Global Emergency Call.....	6.136
GPIB Command Set Version.....	6.31
GPIB commands	
Alphabetical list, non-signalling	6.284
Alphabetical list, signalling	6.298
Non-signalling	6.1
Signalling	6.131
GPIB error codes	9.1
Graph	
Error.....	4.82
Gated Output Power.....	4.71
Power.....	4.69

H

Hadamard matrix.....	4.108
Handoff	4.124
Destination	4.124, 6.188
remote control	6.188
softkey	4.125
Target list	6.188
Hotkeys.....	3.3

I

I signal tolerance.....	6.108
I/Q Analyz. O-QPSK.....	4.80
I/Q-IF	4.39, 6.33
Non Signalling.....	4.39
Signalling	4.165
IF Level.....	4.40, 6.34
IF Power	6.5, 6.204
IF Power (trigger)	4.38
Impairments	
Analyzer (NS).....	4.21
AWGN.....	6.187
Base station signal	4.148, 6.186
Freq. offset.....	6.187
Overview	4.58, 4.73
Remote control (NS).....	6.13
IMSL_11_12.....	4.156, 6.192
Inactivity Control (PPP).....	8.12
Indicator bits	4.153
Info.....	6.31
Info-Box	4.69, 4.70
Injected TX FER.....	4.149, 6.187
Code Domain Power	6.91
Forward Power Control	6.274

Gated Output Power	6.249
Min. Power.....	6.45, 6.232, 6.241
Open Loop Time Resp.	6.260
Overview	6.210
Receiver Quality	6.266
Installing software.....	1.2
Flash disk	1.2
Floppy disks.....	1.2
Interference	2.3
IP address	
ping.....	8.21
PPP dynamic	6.173, 8.28
PPP, dynamic	8.11
PPP, static.....	6.172, 8.11, 8.28
static.....	8.4
IQ Leakage Check.....	6.92

L

Last Hold Bit.....	6.12, 6.179
Level (trigger, Non Signalling).....	4.38
Level Settings Out of Range !.....	4.148
Levels	
OCNS	6.178
Overview	4.54
Traffic channel	6.180, 6.181, 6.182
Limit.....	6.25
Check	5.6
Lines.....	5.6
Specify.....	5.6
Limit matching	
Bit field, gated output.....	6.255
Modulation, overview.....	6.53
Overview	6.220
Overview, channel quality	6.224
Power	6.234, 6.243
Limit Ref. Lines.....	4.65
Limits	
Code Dom. Power, CPCCCommon	6.92
Code Domain Power.....	6.85
Code domain power measurement, Signalling	4.110
Code Domain Power, CDPW	6.85
Lines, gated output	4.74
Modulation (Non Sig.).....	4.10
Modulation (Non Sig.).....	4.10
Modulation (NS).....	6.21
Modulation measurement, signalling.....	4.89
Modulation, OEMP.....	6.45, 6.46, 6.47, 6.48
Overview	4.60
Overview	6.215
Power	4.74, 4.76
Receiver quality	4.121
Receiver quality	6.269
Receiver quality, confidence	6.270
Receiver quality, FER.....	6.269
Spectrum	4.96
Literal	5.10
Loop back mode	4.115
Loopback (echo).....	4.132
Loopback service.....	4.128, 6.140

M

Main power switch	2.2
Manual control	3.1
Markers	4.170
Max slot cycle index	6.195
Max. FER	6.269
Max. frames (receiver quality).....	6.268
Max. Outgoing SMS Length.....	4.143, 6.174
Max. slot cycle index	4.159

Maximum
 Frame error rate 6.223
 Maximum FER limit 6.269
 Maximum frame error rate 6.223
 Maximum output 4.67
 Maximum Output H-PSK 4.65
 MCC type 6.189, 6.190
 Measurement control 5.3
 Measurement environment 3.4, 4.168, 5.6
 remote control 6.206
 Measurement groups 3.5
 Measurement object 5.3
 Measurement parameters 3.4
 Measurements and parameters 3.4
 Measurements per radio configuration 4.42
 Menu select 2.4
 Menu structure 3.1
 Messages, error 9.1
 Messaging (WMT) Information 4.123
 Min protocol revision 6.192
 Min. Confidence Level
 channel quality 6.223
 FER 6.270
 Min/IMSI (Registration Data) 4.158
 Minimum Output 4.66
 Minimum Output H-PSK 4.64
 MIP Authentication Type 8.11, 8.27
 MIP Stand Alone Mode 8.9, 8.25
 Mobile Capabilities Report 4.157, 6.190
 Mobile country code
 Mobile 4.157
 Network 4.157
 Mobile ID 4.157
 Mobile IP 8.7
 Mobile Node Home IP Addr 8.9, 8.25
 Mobile phone
 Connection 2.2
 Mobile settings 4.157
 Mod. Qual. H-PSK 4.5
 Mod. Qual. O-QPSK 4.5
 Mod. Qual. QPSK 4.5
 Modes
 Forward power control 6.277
 FPC 4.119
 Modulation 6.18
 Analyzer/Generator (NS) 4.4
 Remote control 6.41
 MODulation
 OEMP, limits 6.46, 6.48
 Modulation configuration
 Non Signalling 4.7
 Signalling 4.87
 Modulation measurement 4.77
 Remote control 6.41, 6.53, 6.61, 6.69, 6.76
 Remote control (NS) 6.16, 6.26
 Modulation measurement (control)
 Non Signalling 4.8
 Remote control 6.49, 6.53, 6.61, 6.69
 Modulation measurements
 Non Signalling 4.18
 Modulation mode 6.10
 Module test 2.6
 MP Agent Advertisements 8.10, 8.26
 MPPL 6.158, 6.164, 6.168, 6.171
 MS
 MCC type 6.190
 MSID type 6.190
 MS Dormant Control 8.12, 8.29
 MS Dormant Timer 8.12, 8.29
 MS info 6.133, 6.134
 Authentication 6.135
 Band class 6.134

Protocol revision 6.134
 Subband class 6.134
 Terminal 6.135
 MS Information 4.123
 MS Node Home Agent IP Addr 8.10, 8.26
 MS Node Home Agent Secret 8.10
 MSID type 6.190, 6.193
 Multiplex Option
 forward 6.143
 reverse 6.143
 MuxPDU (SCH) 4.145
 MuxPDUs / Layer 4.141

N

Narrow band power 4.12, 6.38
 Neighbor Set 4.155
 Neighbor Window 4.155, 6.191
 Network
 Access probes 4.160, 6.198
 BSID 6.192
 Call Indicators 4.158
 Identity 4.157
 IMSI 11 12 6.192
 Max slot cycle index 4.159, 6.195
 MCC type 6.189
 Mini protocol revision 6.192
 Mobile settings 4.157
 Paging 4.159
 Paging channel rate 6.194
 Protocol revision 6.192
 Registration 6.196
 Registration methods 4.160
 Slot cycle index 4.159
 System ID 6.191
 System parameters 4.155
 Wildcard 6.193
 Network ID 4.157
 Non Signalling 4.26, 6.9
 Network identity 4.157
 Network parameters 4.154
 remote control 6.189
 Network PPP Inactivity Timer 8.12, 8.29
 Network standard 6.131
 Networks Supported 1.1
 NID type 6.189
 Non-Signalling 3.2
 Non-Signalling measurements 2.6
 Notation (remote control) 5.10
 NPower 4.13, 6.39
 Repetition 6.40
 Signalling 4.64
 NPOwer 4.12, 6.38
 Number of Bits 4.28, 4.150, 6.12, 6.179

O

OCNS
 Base station signal 4.148
 Level 6.178
 OCNS (NS) 4.23, 6.6, 6.7
 OCNS Settings 6.178
 Offset Compensation 4.84, 6.79
 On Limit Failure 4.9
 Open Loop Time Resp. 4.64
 Open Loop Time Response 4.68
 Operating concept 3.1
 Options (query via remote control) 6.31
 Orthogonal Variable Spreading Factor 4.108
 Out of Tolerance 4.7
 Modulation, EVM 6.58

Modulation, magnitude error..... 6.74
 Modulation, phase error..... 6.66
 Outgoing SMS..... 4.144, 6.174
 Output power..... 6.10
 Base station signal..... 4.148
 BS levels..... 6.177
 Output Power (NS)..... 4.24
 Output Routing..... 6.5, 6.205
 Overview configuration..... 4.56
 Overview measurement..... 4.52, 6.207
 OVSF..... 4.108

P

Packet data service..... 4.139, 8.6
 Packet data service option..... 6.166
 Packet Data Testing..... 8.1
 Packet Size (ping)..... 8.20, 8.36
 Packet Zone Configuration..... 8.13
 Packet Zone Connect. Ctrl..... 8.13, 8.30
 Packet Zone ID..... 8.13, 8.30
 Packet Zone List Length..... 8.13, 8.30
 Page Response Timeout..... 4.154, 6.186
 Paging..... 4.159
 Paging channel..... 4.153, 6.184, 6.194
 Quick paging..... 4.153
 Paging channel rate..... 4.159, 6.194
 Non Signalling..... 4.26, 6.9
 Paging channel slot cycle index..... 4.159, 6.195
 Paging level..... 4.153, 6.11
 BS signal..... 6.184
 BS signals..... 6.185
 Paging Level
 Non Signalling..... 4.23
 Parameter
 command..... 5.10
 Current vs. default..... 6.132
 Parameter settings..... 3.4, 5.6
 Partial reset..... 6.32
 Password (PPP authentication)..... 8.11, 8.29
 Pattern..... 6.145, 6.146, 6.153, 6.156, 6.157, 6.162, 6.163
 Loopback..... 4.129
 Test data..... 4.136, 4.138
 Pattern generation..... 6.144, 6.145, 6.153, 6.156, 6.162
 Loopback..... 4.129
 Test data..... 4.136, 4.138
 Pattern generator 6.145, 6.146, 6.153, 6.156, 6.157, 6.162,
 6.163
 PCG Count..... 6.246
 Power..... 4.73
 PCH..... 4.153
 Peak code domain error power..... 4.103
 Phase offset
 remote control..... 6.117, 6.123
 Phase offset (control)
 remote control..... 6.118, 6.119, 6.124
 Phase Offset H-PSK..... 4.104
 PICH level..... 4.148
 Pilot level..... 4.23, 6.11
 BS levels..... 6.177
 Pilot power (Overview)..... 6.210
 Ping Configuration..... 8.20
 remote control..... 8.35
 Ping Count..... 8.20, 8.35
 Ping measurement
 remote control..... 8.34
 Ping measurement..... 8.18
 PN offset..... 4.154, 6.8, 6.186
 Non Signalling..... 4.25
 Polarity..... 4.28, 4.150, 6.12, 6.179
 Power

Narrow band..... 4.12
 Non Signalling..... 4.12
 Remote control..... 6.225, 6.234, 6.243, 6.256
 Signalling..... 4.46
 Power (wide band)
 Non Signalling..... 4.31
 remote control..... 6.36
 Remote control (Sig)..... 6.200, 8.34
 Power configuration..... 4.71
 Non Signalling..... 4.15
 Remote control..... 6.228, 6.237, 6.247, 6.257
 Power Control..... 4.58, 4.73
 Power control bits
 BS Signal..... 6.178
 Code Domain Power..... 6.91
 Forward Power Control..... 6.274
 Gated Output Power..... 6.249
 Min. Power..... 6.45, 6.232, 6.241
 Non Signalling..... 4.27, 6.12
 Open Loop Time Resp..... 6.260
 Overview..... 6.210
 Receiver Quality..... 6.266
 Signalling..... 4.149
 Power Meas. Width..... 6.27
 Power measurements..... 4.62
 Average values..... 4.66, 4.67
 Current values..... 4.66, 4.67
 Min/Max values..... 4.66, 4.67
 Waveform quality..... 4.66, 4.67
 Power step..... 6.260
 Power step direction..... 6.260
 Power switch..... 2.3
 Power vs. Frame..... 4.12, 4.13
 application example..... 2.26
 Power/Slot measurement (control)
 remote control..... 6.26, 6.27
 PPP..... 8.11
 PPP Authentication Type..... 8.11, 8.28
 Primary address..... 5.1
 Primary Service class..... 4.45
 Program example..... 7.1
 Protocol revision..... 4.156, 6.192
 Minimum..... 4.156
 Minimum (Non Signalling)..... 4.26, 6.9
 Non Signalling..... 4.26, 6.9

Q

Q signal tolerance..... 6.108
 QOF (NS)..... 4.25, 6.8
 QOF (supplemental channel).... 6.156, 6.162, 6.168, 6.170,
 6.182, 6.183
 SO32..... 4.137
 SO33..... 4.141
 QPCH..... 4.153
 Quasi-orthogonal Function..... 4.152
 Quick paging channel..... 4.153, 6.184
 Quick paging level..... 4.153

R

Radio configuration..... 4.42
 Connected state..... 4.146
 Loop..... 6.140, 6.141
 Loopback..... 4.129
 Non Signalling..... 4.26, 6.8
 Radio configuration, speech..... 6.147, 6.148
 Radio configuration, test data ... 6.152, 6.155, 6.161, 6.167,
 6.170
 Rate set..... 4.26, 6.8
 Recall configurations..... 6.32

Receiver quality		
Forward power control.....	4.116	
Max. frames.....	6.268	
Remote control.....	6.262	
Receiver quality configuration.....	4.117	
Receiver quality measurement.....	4.113	
REF OUT 2.....	6.203	
Reference frequency.....	4.33	
Remote control.....	6.203	
Remote control (NS).....	6.14	
Signalling.....	4.163	
Reference line.....	4.171	
Refresh Interval.....	8.16	
Registered.....	4.43	
Registration.....	6.196	
Home.....	6.196	
Methods.....	4.160	
NID.....	6.197	
Parameter.....	6.197	
Power down.....	6.197	
Power up.....	6.197	
SID.....	6.196	
Registration Reply Code.....	8.10, 8.27	
Registration Reply Lifetime.....	8.10, 8.27	
Rel. 1.....	4.170	
Rel. 2.....	4.170	
Remaining Set.....	4.155	
Remaining Window.....	4.155, 6.191	
Remote control		
basics.....	5.1	
Commands, non-signalling.....	6.1	
Commands, signalling.....	6.131	
Notation.....	5.10	
Program example.....	7.1	
Repeat Interval.....	8.20, 8.35	
Repetition		
ACP Spectrum.....	6.83	
Channel power.....	6.112, 6.119, 6.125	
Code domain power.....	6.97	
Forward power control.....	6.277	
Modulation.....	6.78	
Modulation (NS).....	4.8, 6.20	
Modulation, EVM.....	6.56	
Modulation, magnitude error.....	6.72	
Modulation, overview.....	6.51	
Modulation, phase error.....	6.64	
NPower.....	6.40	
Overview.....	4.58, 6.213	
Overview, channel quality.....	6.222	
Peak code domain.....	6.105	
Ping.....	8.35	
Power.....	6.228, 6.237	
Power, gated output.....	6.246	
Power, min output.....	6.228	
Repetition mode.....	3.6, 5.5	
Report mode.....	6.38	
Reset.....	2.4, 2.5	
Result		
ACP Spectrum.....	6.85	
Modulation.....	4.81	
MODulation		
IQANalyzer.....	6.79	
Power.....	4.66	
Spectrum.....	4.93	
Result (power)		
Signalling.....	4.100	
Result mode		
Channel power.....	6.112, 6.118, 6.124	
Code domain power.....	6.96	
Modulation.....	6.78	
Modulation, EVM.....	6.55	
Modulation, magnitude error.....	6.71	
Modulation, phase error.....	6.64	
Peak code domain.....	6.104	
Power, gated output.....	6.245	
Result order.....	4.108	
Code domain power.....	6.97	
Peak code domain.....	6.104	
RF analyzer.....	4.20, 6.2	
RF channel		
Analyzer (NS).....	4.21	
Generator.....	4.147	
Generator (NS).....	4.25	
RF connectors.....	2.3, 4.28	
RF frequency.....	6.3, 6.7	
RF generator.....	4.21, 6.6	
Remote control (NS).....	6.6	
RF input.....	4.30, 6.13, 6.201	
RF level, mode.....	6.3, 6.205	
RF max. level.....	6.3, 6.205	
RF Max. Level.....	4.20, 4.166	
RF Max. Level Deviation.....	4.17	
RF Mode.....	4.20, 4.166	
RF output.....	4.29, 6.14, 6.201	
RF Power.....	6.5, 6.204	
RF Power (trigger).....	4.38	
RF Selectivity.....	4.169, 6.35	
RLP / IP Statistics measurement.....	8.15	
remote control.....	8.32	
Routing (Trigger).....	4.38	
R-RC Dependent Measurements.....	4.168	
RX Path.....	4.39, 6.33	
S		
Save current configuration.....	6.32	
SCH		
Data rate.....	4.145	
Frame type.....	4.145	
MuxPDU.....	4.145	
SCH0 Channel.....	6.155, 6.167, 6.181	
SCH0 Enable.....	6.155, 6.167	
SCH0 Frame Offset.....	6.181	
SCH0 Level.....	6.181	
SCH0/1 configuration		
Packet Data.....	4.141	
Test data.....	4.137	
SCH0/1 Eb/Nt.....	4.152	
SCH0/1 enable		
Packet Data.....	4.141	
Test data.....	4.137	
SCH1 Channel.....	6.161, 6.170, 6.183	
SCH1 Enable.....	6.161, 6.170	
SCH1 Frame Offset.....	6.183	
SCH1 Level.....	6.182	
SCPI standard.....	5.2	
Secondary address.....	5.1, 5.7	
Selected Service Option.....	4.129, 4.143, 6.173	
Send SMS.....	4.48, 4.49, 4.123	
Sequence Mode.....	4.27, 4.150, 6.12, 6.178	
Service		
Loopback.....	4.128	
Packet data.....	4.139, 8.6	
Speech.....	4.131, 4.134	
Service class.....	4.45	
Service configuration		
Menu.....	4.126, 8.6	
Remote control.....	6.138	
Service Configuration Info.....	6.138	
Service option.....	4.126	
0x8000.....	4.133	
1.....	4.131	

17	4.133
2	4.129
3	4.132
32	4.135
33	4.140
55	4.130
9	4.129
connected	4.146
Service Option 33	8.1
Service Option 6 (SMS)	4.144
Service Option Control Message	
inactivity control	8.12, 8.30
packet zone	8.13, 8.31
Setpoints (FPC)	4.120
Short Message Service	See SMS
Side band freq. offset	
Modulation (NS)	4.10
Overview (Sig)	4.59, 6.214
Sideband freq. offset	
Modulation (NS)	6.20
Signal off	4.43, 4.47
Signal on	4.43, 4.45
Signalling	3.1, 4.43
Remote control	6.132
Signalling action	6.132
Signalling mode	5.1
Signalling Setup	4.123
Signalling state	6.133
Signalling symbols	3.2
Single shot	5.5
Overview	4.58
Single-shot measurement	4.8
Slope	6.5, 6.204
Slope (trigger)	4.37
Slot cycle index	4.159, 6.195
SMS @ Current Connection	4.144
SMS tests	4.51
SMS Text	6.138
Softkeys	3.3
Software (enable)	1.7
Software configuration	1.5
Software update and installation	1.1
Special character	5.11
Spectrum	6.80
Measurements	4.91
Remote control	6.81
Spectrum Configuration	4.94
Spectrum measurements	
Non Signalling	4.18
Speech coder (signal flow)	4.173
Speech Decoder	4.162
Speech Encoder	4.162
Speech input	6.202
Speech output	6.202
Speech service	4.131, 4.134
Speech service option	6.146
Spreading Factor	4.110
Code domain power	6.96
Standby mode	2.3
Standby power	4.46
Startup menu	1.1, 2.2
Statistic count	4.102, 5.5
ACP Spectrum	6.82
Channel power	6.112, 6.118, 6.124
Code domain power	6.96
Modulation (NS)	6.19
Modulation, EVM	6.56
Modulation, magnitude error	6.71
Modulation, overview	6.51
Modulation, phase error	6.63
Overview	4.59
Overview, channel quality	6.227, 6.236
Overview, overview	6.213
Peak code domain	6.103, 6.104
Power, gated output	6.245
Statistic Count	3.6
Modulation (NS)	4.10
Statistical quantities	3.8
Statistics	
Forward power control	6.276
NPower	6.39
Power, min output	6.227
Remote control	5.4
Statistics cycle	3.6
Status indication	2.7
Status register, extended	5.7, 6.35
Status reporting system	5.7
STAtus:OPERation-Register	
symbolic evaluation	5.7, 6.34
Step Count	4.16, 6.27
Step Delay	4.16, 6.28
Step Interval	4.17, 6.28
Step Size	4.150, 6.178
Step Width	4.16, 4.17, 6.27
Stepping mode	
ACP Spectrum	6.83
Channel power	6.112, 6.119, 6.125
Code domain power	6.97
Modulation	6.78
Modulation (NS)	6.20
Modulation, EVM	6.56
Modulation, magnitude error	6.72
Modulation, overview	6.51
Modulation, phase error	6.64
Overview	6.213
Overview, channel quality	6.222
Peak code domain	6.105
Ping	8.35
Power	6.228, 6.237
Power, gated output	6.246
Stop condition	4.60, 4.119
ACP Spectrum	6.83
Channel power	6.112, 6.119, 6.125
Code domain power	6.97
Modulation (NS)	6.20
Modulation, EVM	6.56
Modulation, magnitude error	6.72
Modulation, overview	6.51
Modulation, phase error	6.64
Overview	4.58, 6.213
Overview, channel quality	6.222
Peak code domain	6.105
Ping	8.35
Power	6.228, 6.237
Power, gated output	6.246
Power, min output	6.228
Stop Condition	3.7
Modulation	4.9, 6.78
Subarrays	
Modulation, EVM	6.57
Modulation, magnitude error	6.73
Modulation, phase error	6.65
Power	6.252
Subnet mask	
static	8.4
Supplemental channel	4.152
Data rate	4.145
Symbolic evaluation of status register	5.7, 6.34
Sync level	6.11
Base station signal	4.148
BS levels	6.177
Non Signalling	4.23
Synchronization	4.43
Remote control (NS)	6.14

System ID 4.155, 6.191
 System ID Number
 Non Signalling 4.26, 6.9
 System parameters 4.155, 6.191

T

Target FER
 Forward power control 6.278, 6.280
 FPC 4.120
 Target list 6.188
 Target PDSN 8.13, 8.30
 Test data service option 6.152
 Test mode 3.1
 Test mode 2.6
 Test name 4.118
 Test setup (Receiver Quality) 6.262
 Tests
 Non-Signalling 4.2
 Signalling 4.41
 Time Based Registration 6.196
 Time Offset H-PSK 4.106
 Time Stamp 6.137, 6.138
 Timeout (ping) 8.20, 8.36
 Trace 5.5
 Traffic channel 6.7
 BS signal 6.179
 Level 6.180, 6.181, 6.182
 Traffic channel (NS) 4.25
 Transmit off period 6.154, 6.155, 6.158, 6.164, 6.168, 6.171
 Transmit on period 6.154, 6.157, 6.163
 Transmit time error (NS) 4.7
 Trigger
 Non Signalling 4.35
 remote control (NS) 6.4
 Signalling 4.163
 Source 6.204
 Trigger Level
 Non Signalling 4.38
 Trigger source 6.4
 Trigger source (NS) 4.36, 4.38
 Trigger source (Sig) 4.164

Tx off period 4.136, 4.139
 Tx on period 4.136, 4.138
 TX Path 4.40, 6.34
 Type of CMU IP addressing 8.3

U

Updating software 1.2
 Use Measurement Environments 4.168
 Use Mobile Registration Data 4.158, 6.190
 Use MS IP Address (ping) 8.21, 8.36
 User guidance 4.168
 Username (PPP authentication) 8.11, 8.28

V

Version 6.31
 Version manager 1.2
 Voice coder 4.132

W

Walsh code (supplemental channel)
 SO32 4.137
 SO33 4.141
 Waveform quality 4.7
 Modulation 4.83
 Overview 6.215, 6.216, 6.217, 6.218
 Power, max output 6.241
 Power, min output 4.76, 6.232
 Waveform Type 4.88
 Wideband power
 Non Signalling 4.31
 remote control 6.36
 Remote control (Sig) 6.200
 Wildcard 4.156, 6.193

Z

Zero Long Code Mask 4.26, 6.9
 Zoom 4.88